

# Instruction Manual



## **TMS 260** **CPU32 Family Microprocessor Support** **070-9824-00**

There are no current European directives that apply to this product. This product provides cable and test lead connections to a test object of electronic measuring and test equipment.

### **Warning**

The servicing instructions are for use by qualified personnel only. To avoid personal injury, do not perform any servicing unless you are qualified to do so. Refer to all safety summaries prior to performing service.

Copyright © Tektronix, Inc. All rights reserved. Licensed software products are owned by Tektronix or its suppliers and are protected by United States copyright laws and international treaty provisions.

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013, or subparagraphs (c)(1) and (2) of the Commercial Computer Software – Restricted Rights clause at FAR 52.227-19, as applicable.

Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supercedes that in all previously published material. Specifications and price change privileges reserved.

Printed in the U.S.A.

Tektronix, Inc., P.O. Box 1000, Wilsonville, OR 97070-1000

TEKTRONIX and TEK are registered trademarks of Tektronix, Inc.

## SOFTWARE WARRANTY

Tektronix warrants that the media on which this software product is furnished and the encoding of the programs on the media will be free from defects in materials and workmanship for a period of three (3) months from the date of shipment. If a medium or encoding proves defective during the warranty period, Tektronix will provide a replacement in exchange for the defective medium. Except as to the media on which this software product is furnished, this software product is provided "as is" without warranty of any kind, either express or implied. Tektronix does not warrant that the functions contained in this software product will meet Customer's requirements or that the operation of the programs will be uninterrupted or error-free.

In order to obtain service under this warranty, Customer must notify Tektronix of the defect before the expiration of the warranty period. If Tektronix is unable to provide a replacement that is free from defects in materials and workmanship within a reasonable time thereafter, Customer may terminate the license for this software product and return this software product and any associated materials for credit or refund.

**THIS WARRANTY IS GIVEN BY TEKTRONIX IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED. TEKTRONIX AND ITS VENDORS DISCLAIM ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TEKTRONIX' RESPONSIBILITY TO REPLACE DEFECTIVE MEDIA OR REFUND CUSTOMER'S PAYMENT IS THE SOLE AND EXCLUSIVE REMEDY PROVIDED TO THE CUSTOMER FOR BREACH OF THIS WARRANTY. TEKTRONIX AND ITS VENDORS WILL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES IRRESPECTIVE OF WHETHER TEKTRONIX OR THE VENDOR HAS ADVANCE NOTICE OF THE POSSIBILITY OF SUCH DAMAGES.**

## HARDWARE WARRANTY

Tektronix warrants that the products that it manufactures and sells will be free from defects in materials and workmanship for a period of one (1) year from the date of shipment. If a product proves defective during this warranty period, Tektronix, at its option, either will repair the defective product without charge for parts and labor, or will provide a replacement in exchange for the defective product.

In order to obtain service under this warranty, Customer must notify Tektronix of the defect before the expiration of the warranty period and make suitable arrangements for the performance of service. Customer shall be responsible for packaging and shipping the defective product to the service center designated by Tektronix, with shipping charges prepaid. Tektronix shall pay for the return of the product to Customer if the shipment is to a location within the country in which the Tektronix service center is located. Customer shall be responsible for paying all shipping charges, duties, taxes, and any other charges for products returned to any other locations.

This warranty shall not apply to any defect, failure or damage caused by improper use or improper or inadequate maintenance and care. Tektronix shall not be obligated to furnish service under this warranty a) to repair damage resulting from attempts by personnel other than Tektronix representatives to install, repair or service the product; b) to repair damage resulting from improper use or connection to incompatible equipment; c) to repair any damage or malfunction caused by the use of non-Tektronix supplies; or d) to service a product that has been modified or integrated with other products when the effect of such modification or integration increases the time or difficulty of servicing the product.

**THIS WARRANTY IS GIVEN BY TEKTRONIX IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED. TEKTRONIX AND ITS VENDORS DISCLAIM ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TEKTRONIX' RESPONSIBILITY TO REPAIR OR REPLACE DEFECTIVE PRODUCTS IS THE SOLE AND EXCLUSIVE REMEDY PROVIDED TO THE CUSTOMER FOR BREACH OF THIS WARRANTY. TEKTRONIX AND ITS VENDORS WILL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES IRRESPECTIVE OF WHETHER TEKTRONIX OR THE VENDOR HAS ADVANCE NOTICE OF THE POSSIBILITY OF SUCH DAMAGES.**

# Table of Contents

<b>General Safety Summary</b> .....	<b>v</b>
<b>Service Safety Summary</b> .....	<b>vii</b>
<b>Preface: Microprocessor Support Documentation</b> .....	<b>ix</b>
Manual Conventions .....	ix
Logic Analyzer Documentation .....	x
Contacting Tektronix .....	x

## Getting Started

Support Description .....	1-1
Logic Analyzer Software Compatibility .....	1-2
Logic Analyzer Configuration .....	1-2
Requirements and Restrictions .....	1-2
Configuring the Probe Adapter .....	1-3
Connecting to a System Under Test .....	1-5
PGA Probe Adapter .....	1-6
PQFP Probe Adapter .....	1-9
CQFP Probe Adapter .....	1-12
Without a Probe Adapter .....	1-16

## Operating Basics

<b>Setting Up the Support</b> .....	<b>2-1</b>
Channel Group Definitions .....	2-1
Clocking Options .....	2-1
Probe Adapter .....	2-2
Show Cycles .....	2-2
Alternate Bus Master Cycles .....	2-2
Symbols .....	2-2
<b>Acquiring and Viewing Disassembled Data</b> .....	<b>2-5</b>
Acquiring Data .....	2-5
Viewing Disassembled Data .....	2-5
<b>Acquiring and Viewing Disassembled Data</b> .....	<b>2-8</b>
Software Display Format .....	2-9
Control Flow Display Format .....	2-9
Subroutine Display Format .....	2-10
Changing How Data is Displayed .....	2-10
Optional Display Selections .....	2-10
Marking Cycles .....	2-12
Exception Vectors .....	2-12
Viewing an Example of Disassembled Data .....	2-14

## Specifications

Probe Adapter Description .....	3-1
Configuring the Probe Adapter .....	3-1
Specifications .....	3-4
Channel Assignments .....	3-10
How Data is Acquired .....	3-15
Custom Clocking .....	3-15
Clocking Options .....	3-18
Alternate Microprocessor Connections .....	3-19
Signals On the Probe Adapter .....	3-19
Signals Not On the Probe Adapter .....	3-19
Extra Channels .....	3-20

## Maintenance

Probe Adapter Circuit Description .....	4-1
Replacing Signal Leads .....	4-1
Replacing Protective Sockets .....	4-1

## Replaceable Electrical Parts

Parts Ordering Information .....	5-1
Using the Replaceable Electrical Parts List .....	5-1

## Replaceable Mechanical Parts

Parts Ordering Information .....	6-1
Using the Replaceable Mechanical Parts List .....	6-1

## Index

# List of Figures

<b>Figure 1–1: Jumper locations on the 68331/332 QFP probe adapter .</b>	<b>1–4</b>
<b>Figure 1–2: Jumper locations on the 68340 PGA probe adapter . . . .</b>	<b>1–4</b>
<b>Figure 1–3: Jumper locations on the 68331/332 evaluation board probe adapter . . . . .</b>	<b>1–5</b>
<b>Figure 1–4: Placing a microprocessor into a PGA probe adapter . . .</b>	<b>1–7</b>
<b>Figure 1–5: Connecting probes to a PGA probe adapter . . . . .</b>	<b>1–8</b>
<b>Figure 1–6: Placing a PGA probe adapter onto the SUT . . . . .</b>	<b>1–9</b>
<b>Figure 1–7: Connecting probes to a PQFP probe adapter . . . . .</b>	<b>1–10</b>
<b>Figure 1–8: Placing a PQFP probe adapter onto the SUT . . . . .</b>	<b>1–12</b>
<b>Figure 1–9: Connecting probes to a CQFP probe adapter . . . . .</b>	<b>1–13</b>
<b>Figure 1–10: Placing a CQFP probe adapter onto the SUT . . . . .</b>	<b>1–15</b>
<b>Figure 2–1: Hardware display . . . . .</b>	<b>2–8</b>
<b>Figure 3–1: Jumper locations on the 68331/332 QFP probe adapter .</b>	<b>3–3</b>
<b>Figure 3–2: Jumper locations on the 68340 PGA probe adapter . . . .</b>	<b>3–3</b>
<b>Figure 3–3: Jumper locations on the 68331/332 Evaluation Board probe adapter . . . . .</b>	<b>3–4</b>
<b>Figure 3–4: Minimum clearance of the 68331/332 QFP probe adapter</b>	<b>3–7</b>
<b>Figure 3–5: Minimum clearance of the 68340 PGA probe adapter . .</b>	<b>3–8</b>
<b>Figure 3–6: Minimum clearance of the 68331/332 evaluation board probe adapter . . . . .</b>	<b>3–9</b>
<b>Figure 3–7: CPU32 Family bus timing for a normal Read/Write cycle</b>	<b>3–16</b>
<b>Figure 3–8: CPU32 Family bus timing for a Show Bus cycle . . . . .</b>	<b>3–17</b>

## List of Tables

<b>Table 1–1: Supported microprocessors</b> .....	<b>1–1</b>
<b>Table 1–2: 68331/332 QFP probe adapter jumper positions</b> .....	<b>1–3</b>
<b>Table 1–3: 68340 PGA probe adapter jumper positions</b> .....	<b>1–3</b>
<b>Table 1–4: 68331/332 Evaluation board probe adapter jumper positions</b>	<b>1–3</b>
<b>Table 1–5: CPU32 Family signal connections for channel probes</b> ...	<b>1–16</b>
<b>Table 1–6: CPU32 Family signal connections for clock probes</b> .....	<b>1–18</b>
<b>Table 2–1: Control group symbol table definitions</b> .....	<b>2–2</b>
<b>Table 2–2: Meaning if special characters in the display</b> .....	<b>2–6</b>
<b>Table 2–3: Cycle Type definitions</b> .....	<b>2–7</b>
<b>Table 2–4: Interrupt vectors</b> .....	<b>2–13</b>
<b>Table 3–1: 68331/332 QFP probe adapter jumper positions</b> .....	<b>3–2</b>
<b>Table 3–2: 68340 PGA probe adapter jumper positions</b> .....	<b>3–2</b>
<b>Table 3–3: 68331/332 evaluation board probe adapter jumper positions</b>	<b>3–2</b>
<b>Table 3–4: Electrical specifications</b> .....	<b>3–4</b>
<b>Table 3–5: Environmental specification*</b> .....	<b>3–6</b>
<b>Table 3–6: Certifications and compliances</b> .....	<b>3–10</b>
<b>Table 3–7: Address group channel assignments</b> .....	<b>3–10</b>
<b>Table 3–8: Data group channel assignments</b> .....	<b>3–12</b>
<b>Table 3–9: Control group channel assignments</b> .....	<b>3–13</b>
<b>Table 3–10: DataSize group channel assignments</b> .....	<b>3–14</b>
<b>Table 3–11: Misc group channel assignments</b> .....	<b>3–14</b>
<b>Table 3–12: Clock channel assignments</b> .....	<b>3–15</b>
<b>Table 3–13: CPU32 Family signals on J1612</b> .....	<b>3–19</b>
<b>Table 3–14: Extra module sections and channels</b> .....	<b>3–20</b>

# General Safety Summary

Review the following safety precautions to avoid injury and prevent damage to this product or any products connected to it. To avoid potential hazards, use this product only as specified.

*Only qualified personnel should perform service procedures.*

While using this product, you may need to access other parts of the system. Read the *General Safety Summary* in other system manuals for warnings and cautions related to operating the system.

## To Avoid Fire or Personal Injury

**Use Proper Power Cord.** Use only the power cord specified for this product and certified for the country of use.

**Use Proper Voltage Setting.** Before applying power, ensure that the line selector is in the proper position for the power source being used.

**Connect and Disconnect Properly.** Do not connect or disconnect probes or test leads while they are connected to a voltage source.

**Ground the Product.** This product is indirectly grounded through the grounding conductor of the mainframe power cord. To avoid electric shock, the grounding conductor must be connected to earth ground. Before making connections to the input or output terminals of the product, ensure that the product is properly grounded.

**Observe All Terminal Ratings.** To avoid fire or shock hazard, observe all ratings and marking on the product. Consult the product manual for further ratings information before making connections to the product.

The common terminal is at ground potential. Do not connect the common terminal to elevated voltages.

Do not apply a potential to any terminal, including the common terminal, that exceeds the maximum rating of that terminal.

**Avoid Exposed Circuitry.** Do not touch exposed connections and components when power is present.

**Do Not Operate With Suspected Failures.** If you suspect there is damage to this product, have it inspected by qualified service personnel.

**Do Not Operate in Wet/Damp Conditions.**

**Do Not Operate in an Explosive Atmosphere.**

**Keep Product Surfaces Clean and Dry.**

**Provide Proper Ventilation.** Refer to the manual's installation instructions for details on installing the product so it has proper ventilation.

**Symbols and Terms**

**Terms in this Manual.** These terms may appear in this manual:



---

**WARNING.** Warning statements identify conditions or practices that could result in injury or loss of life.

---



---

**CAUTION.** Caution statements identify conditions or practices that could result in damage to this product or other property.

---

**Terms on the Product.** These terms may appear on the product:

**DANGER** indicates an injury hazard immediately accessible as you read the marking.

**WARNING** indicates an injury hazard not immediately accessible as you read the marking.

**CAUTION** indicates a hazard to property including the product.

**Symbols on the Product.** The following symbols may appear on the product:



WARNING  
High Voltage



Protective Ground  
(Earth) Terminal



CAUTION  
Refer to Manual



Double  
Insulated

# Service Safety Summary

Only qualified personnel should perform service procedures. Read this *Service Safety Summary* and the *General Safety Summary* before performing any service procedures.

**Do Not Service Alone.** Do not perform internal service or adjustments of this product unless another person capable of rendering first aid and resuscitation is present.

**Disconnect Power.** To avoid electric shock, disconnect the main power by means of the power cord or, if provided, the power switch.

**Use Care When Servicing With Power On.** Dangerous voltages or currents may exist in this product. Disconnect power, remove battery (if applicable), and disconnect test leads before removing protective panels, soldering, or replacing components.

To avoid electric shock, do not touch exposed connections.

# Preface: Microprocessor Support Documentation

This instruction manual contains specific information about the TMS 260 CPU32 Family microprocessor support and is part of a set of information on how to operate this product on compatible Tektronix logic analyzers.

If you are familiar with operating microprocessor supports on the logic analyzer for which the TMS 260 CPU32 Family support was purchased, you will probably only need this instruction manual to set up and run the support.

If you are not familiar with operating microprocessor supports, you will need to supplement this instruction manual with information on basic operations to set up and run the support.

Information on basic operations of microprocessor supports is included with each product. Each logic analyzer has basic information that describes how to perform tasks common to supports on that platform. This information can be in the form of online help, an installation manual, or a user manual.

This manual provides detailed information on the following topics:

- Connecting the logic analyzer to the system under test
- Setting up the logic analyzer to acquire data from the system under test
- Acquiring and viewing disassembled data
- The TMS 260 CPU32 Family probe adapter

## Manual Conventions

This manual uses the following conventions:

- The phrase “information on basic operations” refers to online help, an installation manual, or a basic operations of microprocessor supports user manual.
- In the information on basic operations, the term XXX or P54C used in field selections and file names can be replaced with CPU32 Family. This is the name of the microprocessor in field selections and file names you must use to operate the CPU32 Family support.
- The term system under test (SUT) refers to the microprocessor-based system from which data will be acquired.
- The term logic analyzer refers to the Tektronix logic analyzer for which this product was purchased.

- The term module refers to a 102/136-channel or a 96-channel module.
- CPU32 Family refers to all supported variations of the 683xx microprocessor unless otherwise noted.

## Logic Analyzer Documentation

A description of other documentation available for each type of Tektronix logic analyzer is located in the corresponding module user manual. The user manual provides the information necessary to install, operate, maintain, and service the logic analyzer and associated products.

## Contacting Tektronix

Product Support	For application-oriented questions about a Tektronix measurement product, call toll free in North America: 1-800-TEK-WIDE (1-800-835-9433 ext. 2400) 6:00 a.m. – 5:00 p.m. Pacific time  Or, contact us by e-mail: tm_app_supp@tek.com  For product support outside of North America, contact your local Tektronix distributor or sales office.
Service Support	Contact your local Tektronix distributor or sales office. Or, visit our web site for a listing of worldwide service locations.  <a href="http://www.tek.com">http://www.tek.com</a>
For other information	In North America: 1-800-TEK-WIDE (1-800-835-9433) An operator will direct your call.
To write us	Tektronix, Inc. P.O. Box 1000 Wilsonville, OR 97070-1000

# Getting Started

This chapter provides information on the following topics:

- A description of the TMS 260 CPU32 Family microprocessor support
- Logic analyzer software compatibility
- Your CPU32 Family system requirements
- CPU32 Family support restrictions
- How to configure the probe adapter
- How to connect to the system under test (SUT)

## Support Description

The TMS 260 microprocessor support disassembles data from systems that are based on the Motorola CPU32 Family microprocessor. The support runs on a compatible Tektronix logic analyzer equipped with a 102-channel module, or a 96-channel module.

Refer to information on basic operations to determine how many modules and probes your logic analyzer needs to meet the minimum channel requirements for the TMS 260 microprocessor support.

Table 1–1 shows which microprocessors and their packages the TMS 260 supports.

**Table 1–1: Supported microprocessors**

Name	Package
68331	JEDEC PQFP JEDEC CQFP
68332	JEDEC PQFP JEDEC CQFP
68331 and 68332	Motorola 68331 or 68332 Evaluation Board
68340	PGA

A complete list of standard and optional accessories is provided at the end of the parts list in the *Replaceable Parts* chapter.

To use this support efficiently, you need to have the items listed in the information on basic operations as well as the *CPU32 Family Microprocessor User's Manual*, Motorola, 1995.

Information on basic operations also contains a general description of supports.

## Logic Analyzer Software Compatibility

The label on the microprocessor support floppy disk states which version of logic analyzer software the support is compatible with.

## Logic Analyzer Configuration

To use the CPU32 Family support, the Tektronix logic analyzer must be equipped with at least a 102-channel module or a 96-channel module. The module must be equipped with enough probes to acquire channel and clock data from signals in your CPU32 Family-based system.

Refer to information on basic operations to determine how many modules and probes the logic analyzer needs to meet the channel requirements.

## Requirements and Restrictions

You should review the general requirements and restrictions of microprocessor supports in the information on basic operations as they pertain to your SUT.

You should also review electrical, environmental, and mechanical specifications in the *Specifications* chapter in this manual as they pertain to your system under test, as well as the following descriptions of other CPU32 Family support requirements and restrictions.

**System Clock Rate.** The TMS 260 support can acquire data from the CPU32 Family microprocessor at speeds up to 16.78 MHz<sup>1</sup>.

<sup>1</sup> Specification at time of printing. Contact your Tektronix sales representative for current information on the fastest devices supported.

## Configuring the Probe Adapter

The standard 68331/332 QFP probe adapter, 68340 PGA probe adapter, and 68331/332 Motorola evaluation system board adapter probe contain jumpers that need to be in specific positions for proper disassembly. Tables 1–2, 1–3 and 1–4 show these positions.

**Table 1–2: 68331/332 QFP probe adapter jumper positions**

Jumper	Jumper position	
	Default	Alternate
A19-A23	pins 1, 2 (Gnd)*	pins 2, 3 (Address)
BGACK~	pins 1, 2 (High)	pins 2, 3 (BGACK~)
BG~	pins 1, 2 (High)	pins 2, 3 (BG~)
BR~	pins 1, 2 (High)	pins 2, 3 (BR~)

\* The podlets are grounded on the probe adapter only; the microprocessor signals are not affected.

**Table 1–3: 68340 PGA probe adapter jumper positions**

Jumper	Jumper position	
	Default	Alternate
A31-A24	pins 1, 2 (Gnd)*	pins 2, 3 (Address)


\* The podlets are grounded on the probe adapter only; the microprocessor signals are not affected.

**Table 1–4: 68331/332 Evaluation board probe adapter jumper positions**

Jumper	Jumper position	
	Default	Alternate
A31-A24	pins 1, 2 (Gnd)*	none
A23-A19	pins 1, 3 (Gnd)*	pins 3, 5 (Address)
DACK1~	pins 1, 2 (High)	none
DACK2~	pins 1, 2 (High)	none
BGACK~	pins 1, 3 (High)	pins 3, 5 (CS2~)
BG~	pins 1, 2 (High)	pins 2, 3 (BG~)
BR~	pins 1, 2 (High)	pins 2, 3 (BR~)


\* The podlets are grounded on the probe adapter only; the microprocessor signals are not affected.

Figure 1–1 shows the location of the jumpers in the default (off) position on the 68331/332 QFP probe adapter.



**Figure 1–1: Jumper locations on the 68331/332 QFP probe adapter**

Figure 1–2 shows the location of the jumpers in the default (off) position on the 68340 PGA probe adapter.



**Figure 1–2: Jumper locations on the 68340 PGA probe adapter**

Figure 1–3 shows the location of the jumpers on the 68331/332 evaluation board probe adapter.




Figure 1–3: Jumper locations on the 68331/332 evaluation board probe adapter

## Connecting to a System Under Test

Before you connect to the SUT, you must connect the probes to the module. Your SUT must also have a minimum amount of clear space surrounding the microprocessor to accommodate the probe adapter. Refer to the *Specifications* chapter in this manual for the required clearances.

The channel and clock probes shown in this chapter are for a 102-channel module. Your probes will look different if you are using a 96-channel module.

The general requirements and restrictions of microprocessor supports in the information on basic operations shows the vertical dimensions of a channel or clock probe connected to square pins on a circuit board.

## PGA Probe Adapter

To connect the logic analyzer to a SUT using a PGA probe adapter, follow these steps:

1. Turn off power to your SUT. It is not necessary to turn off power to the logic analyzer.



**CAUTION.** *Static discharge can damage the microprocessor, the probe adapter, the probes, or the module. To prevent static damage, handle all of the above only in a static-free environment.*

*Always wear a grounding wrist strap or similar device while handling the microprocessor and probe adapter.*

---


2. To discharge your stored static electricity, touch the ground connector located on the back of the logic analyzer. Then, touch any of the ground pins of the probe adapter to discharge stored static electricity from the probe adapter.
3. Place the probe adapter onto the antistatic shipping foam to support the probe as shown in Figure 1–4. This prevents the circuit board from flexing and the socket pins from bending.
4. Remove the microprocessor from your SUT.
5. Line up the pin A1 indicator on the probe adapter board with the pin A1 indicator on the microprocessor.



**CAUTION.** *Failure to correctly place the microprocessor into the probe adapter might permanently damage the microprocessor once power is applied.*


---

6. Place the microprocessor into the probe adapter as shown in Figure 1–4.



**Figure 1–4: Placing a microprocessor into a PGA probe adapter**

7. Connect the channel and clock probes to the probe adapter as shown in Figure 1–5. Match the channel groups and numbers on the probe labels to the corresponding pins on the probe adapter. Match the ground pins on the probes to the corresponding pins on the probe adapter.




**Figure 1-5: Connecting probes to a PGA probe adapter**

8. Line up the pin A1 indicator on the probe adapter board with the pin A1 indicator on your SUT.
9. Place the probe adapter onto the SUT as shown in Figure 1-6.

---

**NOTE.** You might need to stack one or more replacement sockets between the SUT and the probe adapter to provide sufficient vertical clearance from adjacent components. However, keep in mind that this might increase loading, which can reduce the electrical performance of your probe adapter.

---



**Figure 1-6: Placing a PGA probe adapter onto the SUT**

### PQFP Probe Adapter

To connect the logic analyzer to the SUT, do the following:

1. Turn off power to your SUT. It is not necessary to turn off the logic analyzer.




**CAUTION.** Static discharge can damage the microprocessor, the probe adapter, the podlets, or the module. To prevent static damage, handle all the above only in a static-free environment.

*Always wear a grounding wrist strap or similar device while handling the microprocessor and probe adapter.*

2. To discharge your stored static electricity, touch the ground connector located on the back of the logic analyzer. Then, touch any of the ground pins of the probe adapter to discharge stored static electricity from the probe adapter.
3. Place the probe adapter onto the antistatic shipping foam to support the probe as shown Figure 1-7. This prevents the circuit board from flexing.

4. Connect the clock and 8-channel probes to the probe adapter as shown in Figure 1–7. Match the channel groups and numbers on the probe labels to the corresponding pins on the probe adapter.

Use leadsets to connect at least one ground lead from each channel probe and the ground lead from each clock probe to ground pins on your test clip.



**Figure 1–7: Connecting probes to a PQFP probe adapter**



**CAUTION.** This JEDEC PQFP (Plastic Quad Flat Pack) probe adapter has been equipped with a clip that has been designed for tight tolerances.

The clip supports only Plastic Quad Flat Pack devices that conform to the JEDEC M0-069 October 1990 specification. Attaching the clip to a device that does not conform to this JEDEC standard can easily damage the clip's connection pins and/or the microprocessor, causing the probe adapter to malfunction.

Please contact your IC manufacturer to verify that the microprocessor you are targeting conforms to the JEDEC specification.

For best performance and long probe life, exercise extreme care when connecting the probe to the microprocessor.

---

5. Line up the pin 1 indicator on the microprocessor with the pin 1 indicator on the target head of the circuit board.



**CAUTION.** Failure to correctly place the probe adapter onto the microprocessor might permanently damage all electrical components when power is applied.

Center the clip on the microprocessor and apply an equal downward force on all four sides of the clip, slightly rocking the probe adapter in a clockwise circle.

Do not apply leverage to the probe adapter when installing or removing it.

---

6. Place the probe adapter onto the SUT as shown in Figure 1–8.




Figure 1-8: Placing a PQFP probe adapter onto the SUT



---

**CAUTION.** *The probe adapter board might slip off or slip to one side of the microprocessor because of the extra weight of the probes. This can damage the microprocessor and the SUT. To prevent this from occurring, stabilize the probe adapter by placing a non-conductive object (such as foam) between the probe adapter and the SUT.*

---

### CQFP Probe Adapter

To connect the logic analyzer to a SUT using a CQFP probe adapter, follow these steps:

1. Turn off power to your SUT. It is not necessary to turn off the logic analyzer.



**CAUTION.** Static discharge can damage the microprocessor, the probe adapter, the probes, or the module. To prevent static damage, handle all the above only in a static-free environment.

Always wear a grounding wrist strap or similar device while handling the microprocessor and probe adapter.

2. To discharge your stored static electricity, touch the ground connector located on the back of the logic analyzer. Then, touch any of the ground pins of the probe adapter to discharge stored static electricity from the probe adapter.
3. Place the probe adapter onto the antistatic shipping foam to support the probe as shown Figure 1–9. This prevents the circuit board from flexing.
4. Connect the channel and clock probes to the probe adapter as shown in Figure 1–9. Match the channel groups and numbers on the probe labels to the corresponding probe adapter pins. Match the ground pins on the probes to the corresponding pins on the probe adapter.




Figure 1–9: Connecting probes to a CQFP probe adapter



---

**CAUTION.** *This JEDEC CQFP (Ceramic Quad Flat Pack) probe adapter has been equipped with a clip that has been designed for tight tolerances.*

*The clip supports only Ceramic Quad Flat Pack devices that conform to the JEDEC M0-069 October 1990 specification. Attaching the clip to a device that does not conform to this JEDEC standard can easily damage the clip's connection pins and/or the microprocessor, causing the probe adapter to malfunction.*

*Please contact your IC manufacturer to verify that the microprocessor you are targeting conforms to the JEDEC specification.*

*For best performance and long probe life, exercise extreme care when connecting the probe adapter to the microprocessor.*

---


5. Place a little glue on each corner of the CQFP-to-PQFP converter.
6. Place the CQFP-to-PQFP converter over your CQFP microprocessor as shown in Figure 1–10.

---

**NOTE.** *Do not allow the glue to touch the pins of your microprocessor. This might interfere with the connection between the microprocessor and the probe adapter. An open connection will cause errors.*

---

7. Allow the glue to dry.



**Figure 1-10: Placing a CQFP probe adapter onto the SUT**

8. Line up the pin 1 indicator on CQFP clip on the probe adapter with the pin 1 indicator on the microprocessor.



**CAUTION.** Failure to correctly place the probe adapter onto the microprocessor might permanently damage all electrical components when power is applied.

Center the clip on the microprocessor and apply an equal downward force on all four sides of the clip, slightly rocking the probe adapter in a clockwise circle.

Do not apply leverage to the probe adapter when installing or removing it.

9. Place the probe adapter onto the SUT as shown in Figure 1-10.

**Without a Probe Adapter**

You can use channel probes, clock probes, and leadsets with a commercial test clip (or adapter) to make connections between the logic analyzer and your SUT.

To connect the probes to CPU32 Family signals in the SUT using a test clip, follow these steps:

1. Turn off power to your SUT. It is not necessary to turn off power to the logic analyzer.




---

**CAUTION.** Static discharge can damage the microprocessor, the probes, or the module. To prevent static damage, handle all of the above only in a static-free environment.

*Always wear a grounding wrist strap or similar device while handling the microprocessor.*

---

2. To discharge your stored static electricity, touch the ground connector located on the back of the logic analyzer. If you are using a test clip, touch any of the ground pins on the clip to discharge stored static electricity from it.




---

**CAUTION.** Failure to place the SUT on a horizontal surface before connecting the test clip might permanently damage the pins on the microprocessor.

---

3. Place the SUT on a horizontal static-free surface.
4. Use Table 1–5 to connect the channel probes to CPU32 Family signal pins on the test clip or in the SUT.

Use leadsets to connect at least one ground lead from each channel probe and the ground lead from each clock probe to ground pins on your test clip.

5. Align pin 1 or A1 of your test clip with the corresponding pin 1 or A1 of the CPU32 Family microprocessor in your SUT and attach the clip to the microprocessor.

**Table 1–5: CPU32 Family signal connections for channel probes**

Section:channel	CPU32 Family signal	Section:channel	CPU32 Family signal
A3:7	A31	D3:7	D31
A3:6	A30	D3:6	D30
A3:5	A29	D3:5	D29
A3:4	A28	D3:4	D28
A3:3	A27	D3:3	D27
A3:2	A26	D3:2	D26

Table 1-5: CPU32 Family signal connections for channel probes (cont.)

Section:channel	CPU32 Family signal	Section:channel	CPU32 Family signal
A3:1	A25	D3:1	D25
A3:0	A24	D3:0	D24
A2:7	A23	D2:7	D23
A2:6	A22	D2:6	D22
A2:5	A21	D2:5	D21
A2:4	A20	D2:4	D20
A2:3	A19	D2:3	D19
A2:2	A18	D2:2	D18
A2:1	A17	D2:1	D17
A2:0	A16	D2:0	D16
A1:7	A15	D1:7	D15
A1:6	A14	D1:6	D14
A1:5	A13	D1:5	D13
A1:4	A12	D1:4	D12
A1:3	A11	D1:3	D11
A1:2	A10	D1:2	D10
A1:1	A9	D1:1	D9
A1:0	A8	D1:0	D8
A0:7	A7	D0:7	D7
A0:6	A6	D0:6	D6
A0:5	A5	D0:5	D5
A0:4	A4	D0:4	D4
A0:3	A3	D0:3	D3
A0:2	A2	D0:2	D2
A0:1	A1	D0:1	D1
A0:0	A0	D0:0	D0
C3:7	IFT_NXT_D~	C2:7	RMC~
C3:6	IFETCH_B~	C2:6	BR_D~
C3:5	BKPT~	C2:5	BG_D~
C3:4	CLKOUT_B~	C2:4	BGACK_L~
C3:3	IPP_NXT_D~	C2:3	RESET_L~
C3:2	IPIPE_B~	C2:2	DS~
C3:1	FREEZE	C2:1	AS~
C3:0	TSTME_TSC~	C2:0	R_W~

**Table 1–5: CPU32 Family signal connections for channel probes (cont.)**

Section:channel	CPU32 Family signal	Section:channel	CPU32 Family signal
C1:7	not connected	C0:7	not connected
C1:6	not connected	C0:6	not connected
C1:5	not connected	C0:5	not connected
C1:4	not connected	C0:4	not connected
C1:3	not connected	C0:3	not connected
C1:2	not connected	C0:2	not connected
C1:1	not connected	C0:1	not connected
C1:0	not connected	C0:0	not connected

\* Signal not required for disassembly.

Table 1–6 shows the clock probes, and the CPU32 Family signal to which they must connect for disassembly to be correct.

**Table 1–6: CPU32 Family signal connections for clock probes**

Section:channel	CPU32 Family signal
CK:0	INV_CLKOUT
CK:1	BGACK~_ALT
CK:2	DACK1~
CK:3	DACK2~

# Setting Up the Support

This section provides information on how to set up the support. Information covers the following topics:

- Channel group definitions
- Clocking options
- Symbol table files

Remember that the information in this section is specific to the operations and functions of the TMS 260 CPU32 Family support on any Tektronix logic analyzer for which it can be purchased. Information on basic operations describes general tasks and functions.

Before you acquire and disassemble data, you need to load the support and specify setups for clocking and triggering as described in the information on basic operations. The support provides default values for each of these setups, but you can change them as needed.

## Channel Group Definitions

The software automatically defines channel groups for the support. The channel groups for the CPU32 Family support are Address, Data, Control, DataSize, and Misc. If you want to know which signal is in which group, refer to the channel assignment tables beginning on page 3–10.

## Clocking Options

The TMS 260 support offers a microprocessor-specific clocking mode for the CPU32 Family microprocessor. This clocking mode is the default selection whenever you load the CPU32 Family support.

A description of how cycles are sampled by the module using the support and probe adapter is found in the *Specifications* chapter.

Disassembly will not be correct with the Internal or External clocking modes. Information on basic operations describes how to use these clock selections for general purpose analysis.

The clocking options for the TMS 260 support are: Probe Adapter, Show Cycles, and Alternate Bus Master Cycles.

**Probe Adapter** You can acquire data with or without using the TMS 260 probe adapter.

**Show Cycles** A Show cycle is defined as any internal bus cycle made visible on the external bus. These types of cycles are acquired when you select Included.

**Alternate Bus Master Cycles** An alternate bus master cycle is defined as the cycle in which the CPU32 Family microprocessor gives up the bus to an alternate device (a DMA device or another microprocessor). These types of cycles are acquired when you select Included.

## Symbols

The TMS 260 support supplies one symbol table file. The CPU32 Family\_Ctrl file replaces specific Control channel group values with symbolic values when Symbolic is the radix for the channel group.

Table 2–1 shows the name, bit pattern, and meaning for the symbols in the file CPU32 Family\_Ctrl, the Control channel group symbol table.

**Table 2–1: Control group symbol table definitions**

Symbol	Control group value				Meaning
	RESET_L- FREEZE AVEC- IRO_ANY_D	BG_D- BGACK_L- BERR- HALT-	RMC- R_W- AS- DS-	IFETCH_B- IFT_NXT_D- IPIPE_B- IPP_NXT_D-	
RESET	0 X X X	X X X X	X X X X	X X X X	Reset
BK_GND_MD	X 1 X X	X X X X	X X X X	X X X X	Background mode
HALT	1 X X X	X X X 0	X X X X	X X X X	Halt
BUS_ERROR	1 X X X	X X 0 X	X X X X	X X X X	Bus error
ALT_RD	1 X X X	X 0 X X	X 1 X X	X X X X	Alternate bus master read cycle
ALT_RD+	1 X X X	0 X X X	X 1 X X	X X X X	Alternate bus master read cycle if the previous cycle was cleared
ALT_WR	1 X X X	X 0 X X	X 0 X X	X X X X	Alternate bus master write cycle
ALT_WR+	1 X X X	0 X X X	X 0 X X	X X X X	Alternate bus master write cycle if the previous cycle was cleared
ALT_BUS	1 X X X	X 0 X X	X X X X	X X X X	Any alternate bus master cycle
ALT_BUS+	1 X X X	0 X X X	X X X X	X X X X	Any alternate bus master cycle if the previous cycle was cleared
READ	1 X X X	X X X X	1 1 0 0	1 1 X X	Read
WRITE	1 X X X	X X X X	1 0 0 X	X X X X	Write
PREFETCH	1 X X X	X X X X	1 1 0 0	0 X X X	Read from program space

Table 2-1: Control group symbol table definitions (cont.)

Symbol	Control group value				Meaning
	RESET_L- FREEZE AVEC- IRQ_ANY_D	BG_D- BGACK_L- BERR- HALT-	RMC- R_W- AS- DS-	IFETCH_B- IFT_NXT_D- IPIPE_B- IPP_NXT_D-	
PREFETCH+	1 X X X	X X X X	1 1 0 0	X 0 X X	Read from program space if the previous cycle was cleared
SHOW_C_RD	1 X X X	X X X X	1 1 1 0	1 1 X X	Show cycle read
SHOW_C_WR	1 X X X	X X X X	1 0 1 X	X X X X	Show cycle write
SHOW_FETH	1 X X X	X X X X	1 1 1 0	0 X X X	Show cycle read from program space
SHOW_FET+	1 X X X	X X X X	1 1 1 0	X 0 X X	Show cycle read from program space if the previous cycle was cleared
SH_RMW_RD	1 X X X	X X X X	0 1 1 0	X X X X	Show cycle read (RMC cycle)
SH_RMW_WR	1 X X X	X X X X	0 0 1 X	X X X X	Show cycle write (RMC cycle)
BERR_RTRY*	1 X X X	X X 0 0	X X X X	X X X X	Bus error retry
RMW_READ	1 X X X	X X X X	0 1 0 0	X X X X	Read portion of a Read Modify Write cycle
RMW_WRITE	1 X X X	X X X X	0 0 0 X	X X X X	Write portion of a Read Modify Write cycle
RWM*	1 X X X	X X X X	0 X X X	X X X X	Read Modify Write cycle
INT_REQ*	1 X X 1	X X X X	X X X X	X X X X	Interrupt request
AVEC*	1 X 0 X	X X X X	X X X X	X X X X	Auto vector

\* Symbols used only for triggering; they do not appear in the Disassembly or State displays.

Information on basic operations describes how to use symbolic values for triggering and displaying other channel groups symbolically, like the Address channel group.

# Acquiring and Viewing Disassembled Data

This section describes how to acquire data and view it disassembled. Information covers the following topics:

- Acquiring data
- Viewing disassembled data in various display formats
- Cycle type labels
- How to change the way data is displayed
- How to change disassembled cycles with the mark cycles function

## Acquiring Data

Once you load the CPU32 Family support, choose a clocking mode and specify the trigger. You are now ready to acquire disassembled data.

If you have any problems acquiring data, refer to information on basic operations in your online help or *Appendix A: Error Messages and Disassembly Problems* in the basic operations user manual, whichever is available.

## Viewing Disassembled Data

You can view disassembled data in four different display formats: Hardware, Software, Control Flow, and Subroutine. The information on basic operations describes how to select the disassembly display formats.

---

**NOTE.** *Selections in the Disassembly property page (the Disassembly Format Definition overlay) must be set correctly for your acquired data to be disassembled correctly. Refer to Changing How Data is Displayed on page 2–10.*

---

The default display format shows the Address, Data, and Control channel group values for each sample of acquired data.

The disassembler displays special characters and strings in the instruction mnemonics to indicate significant events. Table 2–2 shows the special characters and strings displayed by the CPU32 Family disassembler and gives a definition of what they represent.

The disassembler will also display \* ILLEGAL INSTRUCTION \* whenever an unrecognizable combination of instructions occurs.

Asterisks in the Mnemonics column indicate that there is insufficient data available for complete disassembly of the instruction. The number of asterisks shows the width of the data that is not available. Two asterisks (\*\*) represent a byte.

**Table 2-2: Meaning if special characters in the display**

Character or string displayed	Meaning
m	The instruction was manually marked as a program fetch
****	Indicates there is insufficient data available for complete disassembly of the instruction; the number of asterisks will indicate the width of the data that is unavailable. Each two asterisks represent a byte.
#	Indicates an immediate value
t	Indicates the number shown is in decimal, such as #12t
* ILLEGAL INSTRUCTION *	Decoded as an illegal instruction
A-LINE OPCODE	Displayed for an A-Line trap instruction
F-LINE OPCODE	Displayed for an F-Line trap instruction

Table 2-3: Cycle Type definitions

Cycle Type	Definition
( ALT BUS MASTER: READ )	Another master has control of the bus and is executing a read cycle
( ALT BUS MASTER: WRITE )	Another master has control of the bus and is executing a write cycle
( BACKGROUND READ )	A read occurred while the microprocessor was operating in background mode
( BACKGROUND WRITE )	A write occurred while the microprocessor was operating in background mode
( BUS ERROR )	External logic aborts current bus cycle
( HALT )	HALT~ is asserted; microprocessor is halted
( READ )	Data read from memory
( READ RMW )	Read from memory during a read-modify-write cycle
( RESET )	RESET~ is asserted
( SHOW CYCLE READ )	An internal read cycle visible on the bus
( SHOW CYCLE WRITE )	An internal write cycle visible on the bus
( SHOW CYCLE READ RMW )	An internal read cycle visible on the bus and part of a read-modify-write cycle
( SHOW CYCLE WRITE RMW )	An internal write cycle visible on the bus and part of a read-modify-write cycle
( UNKNOWN )†	AN unrecognizable combination of control values
( WRITE )	Data write to memory
( WRITE RMW )	Data write to memory during a read-modify-write cycle
( BREAKPOINT ACK n)*	A19-A16 indicate type 0000 where n is the break number
( INT ACK LEVEL: n)*	A19-A16 indicate type 1111 where n is the level number
( INTERNAL REG ACCESS)*	A19-A16 indicate type 0011
( FLUSH )†	Pipeline flush that occurs when the microprocessor branches to a nonsequential address
( READ EXTENSION )†	Extension fetched from program space

\* Only displayed when FC2-FC0 are available and indicate CPU space.

† Computed cycle types.

## Acquiring and Viewing Disassembled Data

1	2	3	4	5	6
Sample	Address	Data	Mnemonic		Timestamp
35	0000302E	3158	( EXTENSION )	(S)	180 ns
36	00003030	4879	PEA 000031A4	(S)	180 ns
37	00003032	0000	( EXTENSION )	(S)	190 ns
38	0000FFB0	0000	( WRITE )	(S)	170 ns
39	0000FFB2	3158	( WRITE )	(S)	180 ns
40	00003034	31A4	( EXTENSION )	(S)	180 ns
41	00003036	0240	ANDI.W #0000,D0	(S)	180 ns
42	00003038	0000	( EXTENSION )	(S)	180 ns
43	0000FFAC	0000	( WRITE )	(S)	180 ns
44	0000FFAE	31A4	( WRITE )	(S)	170 ns
45	0000303A	303C	MOVE.W #0001,D0	(S)	190 ns
46	0000303C	0001	( EXTENSION )	(S)	170 ns
47	0000303E	4EB9	JSR 000030B0	(S)	180 ns
48	00003040	0000	( EXTENSION )	(S)	180 ns
49	00003042	30B0	( EXTENSION )	(S)	180 ns
50	00003044	4A40	( FLUSH )	(S)	180 ns
51	0000FFA8	0000	( WRITE )	(S)	290 ns
52	0000FFAA	3044	( WRITE )	(S)	180 ns
53	000030B0	48E7	MOVEM.L A43210/D21,-(A7)	(S)	180 ns
54	000030B2	60F8	( EXTENSION )	(S)	180 ns
55	000030B4	206F	MOVEA.L (0030,A7),A0	(S)	180 ns
56	000030B6	0030	( EXTENSION )	(S)	180 ns

Figure 2–1: Hardware display

- 1 **Sample Column.** Lists logic analyzer memory locations for the acquired data.
- 2 **Address Group.** Lists data from channels connected to the CPU32 Family Address bus.
- 3 **Data Group.** Lists data from channels connected to the CPU32 Family Data bus.
- 4 **Mnemonics Column.** Lists the instructions that have been disassembled.
- 5 The disassembler displays an (S) or (U) in the mnemonic column to indicate the mode in which the microprocessor is operating, Supervisor or User. The FC2-FC0 signals must be valid for the disassembly to recognize these modes. Figure 2–1 shows the microprocessor operating in Supervisor mode.
- 6 **Timestamp.** Lists the timestamp values when a timestamp selection is made in the Disassembly Format Definition overlay.

**Software Display Format**

The Software display format shows only the first fetch of executed instructions. Flushed cycles and extensions are not shown, even though they are part of the executed instruction. Read extensions will be used to disassemble the instruction, but will not be displayed as a separate cycle in the Software display format. Data reads and writes are not displayed.

The disassembler will also display the following cycles or instructions:

- Reset cycle
- Halt cycle
- Bus Error cycle
- Special cycles: Breakpoint Ack, Int Ack, and Internal Reg Access
- Reset Vector
- Reads from the interrupt table that appear due to servicing interrupts
- Illegal instructions

**Control Flow Display Format**

The Control Flow display format shows only the first fetch of instructions that change the flow of control.

The disassembler will also display the following cycles or instructions:

- Reset cycle
- Halt cycle
- Bus Error cycle
- Special cycles: Breakpoint Ack, Int Ack, and Internal Reg Access
- Reset Vector
- Reads from the interrupt table that appear due to servicing interrupts
- Illegal instructions

Instructions that generate a change in the flow of control in the CPU32 Family microprocessor are as follows:

Bcc	CHK2	JMP	RTR
BGND	DBcc	JSR	RTS
BKPT	DIVS	LPSTOP	STOP
BRA	DIVSL	RESET	TRAP
BSR	DIVU	RTD	TRAPcc
CHK	DIVUL	RTE	TRAPV

**Subroutine Display Format**

The Subroutine display format shows only the first fetch of subroutine call and return instructions. It will display conditional subroutine calls if they are considered to be taken.

The Subroutine display format also shows the following cycles:

- Reset Cycle
- Halt Cycle
- Bus Error Cycle
- Special cycles: Breakpoint Ack, Int Ack, Internal Reg Access
- Reset Vector
- Reads from the vector table that appear due to servicing exceptions
- Illegal instructions
- ( UNKNOWN ) cycle types; the disassembler does not recognize the Control group value

Instructions that generate a subroutine call or a return in the CPU32 Family microprocessor are as follows:

BGND	DIVS	LPSTOP	RTS
BKPT	DIVSL	RESET	STOP
BSR	DIVU	RTD	TRAP
CHK	DIVUL	RTE	TRAPcc
CHK2	JSR	RTR	TRAPV

## Changing How Data is Displayed

There are fields and features that allow you to further modify displayed data to suit your needs. You can make selections unique to the CPU32 Family support to do the following tasks:

- Change how data is displayed across all display formats
- Change the interpretation of disassembled cycles
- Display exception vectors

**Optional Display Selections**

You can make optional display selections for disassembled data to help you analyze the data. You can make these selections in the Disassembly property page (the Disassembly Format Definition overlay).

In addition to the common display options, (described in the information on basic operations) you can change the displayed data in the following ways:

- Define number of valid address lines
- Define if the FC2–FC0 lines are valid
- Specify the starting address of the interrupt table
- Specify the size of the interrupt table

The CPU32 Family support has four additional fields: Code Segment Size, Interrupt Table, Interrupt Table Address, and Interrupt Table Size. These fields appear in the area indicated in the information on basic operations.

**Valid Address Lines.** You can select the range of valid address lines used to disassembly data. The fourteen (14) ranges start with A0–A18 and end with A0–A31.

The CPU32 Family microprocessor can have an address bus width of 19 to 32 bits, inclusive. There are 14 ranges of valid address bits starting with A0–A18 (default) and ending with A0–A31.

The dissembler ignores upper address bits that fall outside the selected range and displays them as zero (0).

If you create a symbol table for the address group, be sure that the number of bits in the symbol table matches the number of valid bits for the address group.

**FC2–FC0 Lines Valid.** You can choose to use these lines for disassembly by selecting YES in this field.

The dissembler uses the value of the FC2–FC0 lines to determine if the instruction is from supervisor or user space. The dissembler then displays an S or a U next to the instruction. CPU space accesses are also displayed.

**Vector Base Register.** You can specify the base address of the vector register in hexadecimal. The default hexadecimal base address is 0x00000000.

The dissembler uses the vector base register (VBR) value (the base of the interrupt table) to compute the name of the interrupt or determine if a conditional interrupt occurred.

The dissembler ignores upper address bits that fall outside the selected range in the Valid Address Lines field of the Dissembler Format Definition overlay.

A0 and A0 of the VBR must be set to zero (0).

The reset vector information must be located from address 0x0 to 0x7. It does not matter what the VBR is set to: the disassembler always displays the reset vector at 0 (0x00000000).

**Vector Table Size.** You can specify the size of the vector table in hexadecimal. The default vector table size is 0x400.

The disassembler uses the vector table size to compute the name of the interrupt whenever an exception occurs.

Any value entered in this 12-bit wide field must be divisible by four.

### Marking Cycles

The disassembler has a Mark Opcode function that allows you to change the interpretation of a cycle type. Using this function, you can select a cycle and change it to one of the following cycle types:

- Opcode (the first word of an instruction)
- Extension (a subsequent word of an instruction)
- Flush (an opcode or extension that is fetched but not executed)

Mark selections are as follows:

OPCODE  
Ext  
Flush

Undo marks on this cycle

Information on basic operations contains more details on marking cycles.

### Exception Vectors

The disassembler can display exception vectors. You can select to display the interrupt vectors for Real, Virtual, or Protected mode in the Interrupt Table field. (Selecting Virtual is equivalent to selecting Protected.)

Interrupt cycle types are computed and cannot be used to control triggering. When the microprocessor processes an interrupt, the disassembler software displays the type of interrupt, if known.

You can make these selections in the Disassembly property page (the Disassembly Format Definition overlay).

Table 2–4 lists CPU32 Family exception vectors.

**Table 2–4: Interrupt vectors**

Vector Number	Displayed interrupt name
0	( RESET: STACK POINTER )
1	( RESET: PROGRAM COUNTER )
2	( BUS ERROR VECTOR )
3	( ADDRESS ERROR VECTOR )
4	( ILLEGAL INSTRUCTION VECTOR )
5	( ZERO DIVIDE VECTOR )
6	( CHK, CHK2 VECTOR )
7	( TRAP <sub>cc</sub> , TRAPV VECTOR )
8	( PRIV VIOLATION VECTOR )
9	( TRACE VECTOR )
10	( LINE 1010 EMULATOR VECTOR )
11	( LINE 1111 EMULATOR VECTOR )
12	( HARDWARE BREAKPOINT VECTOR )
13	( RESERVED VECTOR #13t )
14	( FORMAT ERROR VECTOR )
15	( UNINIT INTERRUPT VECTOR )
16-23	( RESERVED VECTOR #16t–#23t )
24	( SPURIOUS INTERRUPT VECTOR )
25	( IPL 1 AUTOVECTOR )
26	( IPL 2 AUTOVECTOR )
27	( IPL 3 AUTOVECTOR )
28	( IPL 4 AUTOVECTOR )
29	( IPL 5 AUTOVECTOR )
30	( IPL 6 AUTOVECTOR )
31	( IPL 7 AUTOVECTOR )
32-47	( TRAP #0t–#15t VECTOR )
48-63	( RESERVED VECTOR #48t–#63t )
64-255	( USER INT VECTOR )

## Viewing an Example of Disassembled Data

A demonstration system file (or demonstration reference memory) is provided so you can see an example of how your CPU32 Family microprocessor bus cycles and instruction mnemonics look when they are disassembled. Viewing the system file is not a requirement for preparing the module for use and you can view it without connecting the logic analyzer to your SUT.

Information on basic operations describes how to view the file.

# Specifications

This chapter contains the following information:

- Probe adapter description
- Specification tables
- Dimensions of the probe adapter
- Channel assignment tables
- Description of how the module acquires CPU32 Family signals
- List of other accessible CPU32 Family signals and extra acquisition channels

## Probe Adapter Description

The probe adapter is nonintrusive hardware that allows the logic analyzer to acquire data from a CPU32 Family microprocessor in its own operating environment with little effect, if any, on that system. Information on basic operations contains a figure showing the logic analyzer connected to a typical probe adapter. Refer to that figure while reading the following description.

The probe adapter consists of a circuit board and a socket for a CPU32 Family microprocessor. The probe adapter connects to the microprocessor in the SUT. Signals from the microprocessor-based system flow from the probe adapter to the channel groups and through the probe signal leads to the module.

All circuitry on the probe adapter is powered from the SUT.

Circuitry on the probe adapter can be powered from either the SUT or an external power source. Refer to *Applying and Removing Power* in the *Getting Started* chapter for information on using an external power source.

The PGA probe adapter accommodates the Motorola 68340 microprocessor in a 145-pin PGA package.

The PQFP probe adapter accommodates the Motorola 68340 microprocessor in a 145-pin PQFP or CQFP packages.

The Evaluation Board probe adapter accommodates the Motorola M68331/68332EVS evaluation board.

### Configuring the Probe Adapter

The standard 68331/332 QFP probe adapter, optional 68340 PGA probe adapter and optional 68331/332 Motorola evaluation system board adapter contain

jumpers that need to be in specific positions for proper disassembly. Tables 3–1, 3–2, and 3–3, show these positions.

**Table 3–1: 68331/332 QFP probe adapter jumper positions**

Jumper	Jumper position	
	Default	Alternate
A19-A23	pins 1, 2 (Gnd)*	pins 2, 3 (Address)
BGACK~	pins 1, 2 (High)	pins 2, 3 (BGACK~)
BG~	pins 1, 2 (High)	pins 2, 3 (BG~)
BR~	pins 1, 2 (High)	pins 2, 3 (BR~)

\* The podlets are grounded on the probe adapter only; the microprocessor signals are not affected.

**Table 3–2: 68340 PGA probe adapter jumper positions**

Jumper	Jumper position	
	Default	Alternate
A31-A24	pins 1, 2 (Gnd)*	pins 2, 3 (future)

\* The podlets are grounded on the probe adapter only; the microprocessor signals are not affected.

**Table 3–3: 68331/332 evaluation board probe adapter jumper positions**

Jumper	Jumper position	
	Default	Alternate
A31-A24	pins 1, 2 (Gnd)*	none
A23-A19	pins 1, 3 (Gnd)*	pins 3, 5 (Address)
DACK1~	pins 1, 2 (High)	none
DACK2~	pins 1, 2 (High)	none
BGACK~	pins 1, 3 (High)	pins 3, 5 (CS2~)
BG~	pins 1, 2 (High)	pins 2, 3 (BG~)
BR~	pins 1, 2 (High)	pins 2, 3 (BR~)

\* The podlets are grounded on the probe adapter only; the microprocessor signals are not affected.

Figure 3–1 shows the location of the jumpers on the 68331/332 QFP probe adapter.




Figure 3–1: Jumper locations on the 68331/332 QFP probe adapter

Figure 3–2 shows the location of the jumpers on the 68340 PGA probe adapter.




Figure 3–2: Jumper locations on the 68340 PGA probe adapter

Figure 3–3 shows the location of the jumpers on the 68331/332 Evaluation Board probe adapter.




Figure 3–3: Jumper locations on the 68331/332 Evaluation Board probe adapter

## Specifications

These specifications are for a probe adapter connected to a compatible Tektronix logic analyzer, and the SUT. Table 3–4 shows the electrical requirements the SUT must produce for the support to acquire correct data.

In Table 3–4, for the 102-channel module, one podlet load is 20 k $\Omega$  in parallel with 2 pF. For the 96-channel module, one podlet load is 100 k $\Omega$  in parallel with 10 pF. For the 80 channel module, one podlet load is 100 k $\Omega$  in parallel with 5 pF.

Table 3–4: Electrical specifications

Characteristics	Requirements	
SUT DC power requirements		
Voltage	4.75-5.25 VDC	
Current	I max (calculated)	102 mA
	I typ (measured)	55 mA
SUT clock	Min	DC
Clock rate	Max.	16.78 MHz
Minimum setup time required		
All signals	4 ns	
Minimum hold time required		
All signals	3 ns	
	Specification	
Measured typical SUT signal loading	AC load	DC load
CLKOUT	8 pF + 1 podlet	74AS1000
A31–A23	17 pF + 1 podlet	1 podlet
BG~	15 pF + 1 podlet	74AS1000 in parallel with 1 podlet (74AC20 on option 1A board)
BGACK~	12 pF	74F174
RESET~	12 pF + 1 podlet	74F174
IRQ~	11 pF	74F30 (74AC20 on option 1A board)
IFETCH~	10 pF + 1 podlet	74AS1034 in parallel with 1 podlet
IPIPE~	10 pF + 1 podlet	74AS1034 in parallel with 1 podlet
FREEZE	9 pF + 1 podlet	1 podlet
BKPT	9 pF + 1 podlet	1 podlet
All other signals	7 pF + 1 podlet	1 podlet

Table 3–5 shows the environmental specifications.

**Table 3–5: Environmental specification\***

Characteristic	Description
Temperature	
Maximum operating	+50°C           (+122°F)†
Minimum operating	0°C           (+32°F)
Non-operating	–55°C to +75°C   (–67°F to +167°F)
Humidity	10% to 95% relative humidity*
Altitude	
Operating	4.5 km (15,000 ft) maximum
Non-operating	15 km (50,000 ft) maximum
Electrostatic immunity	The probe adapter is static sensitive

\* Designed to meet Tektronix standard 062-2847-00 class 5.

† Not to exceed CPU32 Family microprocessor thermal considerations. Forced air cooling might be required across the CPU.

Figures 3–4, 3–5, and 3–6 show the dimensions of the probe adapters with the podlet attached. Figure 3–4 shows the standard 68331/332 QFP probe adapter; Figure 3–5 shows the 68340 PGA probe adapter. Figure 3–6 shows the 68331/332 Evaluation Board probe adapter.




Figure 3–4: Minimum clearance of the 68331/332 QFP probe adapter




Figure 3-5: Minimum clearance of the 68340 PGA probe adapter



Table 3–6 shows the certifications and compliances that apply to the probe adapter.

**Table 3–6: Certifications and compliances**

EMC Compliance	Meets the intent of Directive 89/336/EEC for Electromagnetic Compatibility when it is used with the product(s) stated in the specifications table. Refer to the EMC specification published for the stated products. May not meet the intent of the Directive if used with other products.
FCC Compliance	Emissions comply with FCC Code of Federal Regulations 47, Part 15, Subpart B, Class A Limits
Approvals	ANSI/ISA S82.01 – Safety standard for electrical and electronic test, measuring, controlling, and related equipment, 1994 UL3111-1 – Standard for electrical measuring and test equipment CAN/CSA C22.2 No. 1010.1 – Safety requirements for electrical equipment for measurement, control and laboratory use IEC1010-1 – Safety requirements for electrical equipment for measurement, control, and laboratory use

### Channel Assignments

Channel assignments shown in Table 3–7 through Table 3–12 use the following conventions:

- All signals are required by the support unless indicated otherwise
- Channels are shown starting with the most significant bit (MSB) descending to the least significant bit (LSB)
- Channel group assignments are for all modules unless otherwise noted
- A tilde (~) following a signal name indicates an active low signal
- An equals sign (=) following a signal name indicates that it is double probed

Table 3–7 shows the probe section and channel assignments for the Address group, and the microprocessor signal to which each channel connects. By default this channel group is displayed in hexadecimal.

**Table 3–7: Address group channel assignments**

Bit order	Section:channel	CPU32 Family signal name
31	A3:7	A31_D*†
30	A3:6	A30_D*†
29	A3:5	A29_D*†
28	A3:4	A28_D*†
27	A3:3	A27_D*†
26	A3:2	A26_D*†

Table 3–7: Address group channel assignments (cont.)

Bit order	Section:channel	CPU32 Family signal name
25	A3:1	A25_D*†
24	A3:0	A24_D*†
23	A2:7	A23_D*
22	A2:6	A22_D*
21	A2:5	A21_D*
20	A2:4	A20_D*
19	A2:3	A19_D*
18	A2:2	A18
17	A2:1	A17
16	A2:0	A16
15	A1:7	A15
14	A1:6	A14
13	A1:5	A13
12	A1:4	A12
11	A1:3	A11
10	A1:2	A10
9	A1:1	A9
8	A1:0	A8
7	A0:7	A7
6	A0:6	A6
5	A0:5	A5
4	A0:4	A4
3	A0:3	A3
2	A0:2	A2
1	A0:1	A1
0	A0:0	A0

† When acquiring data with the QFP probe adapter or without a probe adapter, these signals must be tied to ground. On the probe adapter position the jumpers associated with A31-A24 on pins 1 and 2.

\* Signals only used for disassembly when within the range of valid upper address bits selected in the Disassembly property page for the 102-channel module, or in the Disassembly Format Definition overlay for the 96-channel module. Upper address bits outside the selected range are ignored.

Table 3–8 shows the probe section and channel assignments for the Data group, and the microprocessor signal to which each channel connects. By default this channel group is displayed in hexadecimal.

**Table 3–8: Data group channel assignments**

Bit order	Section:channel	CPU32 Family signal name
15	D1:7	D15
14	D1:6	D14
13	D1:5	D13
12	D1:4	D12
11	D1:3	D11
10	D1:2	D10
9	D1:1	D9
8	D1:0	D8
7	D0:7	D7
6	D0:6	D6
5	D0:5	D5
4	D0:4	D4
3	D0:3	D3
2	D0:2	D2
1	D0:1	D1
0	D0:0	D0

Table 3–9 shows the probe section and channel assignments for the Control group, and the microprocessor signal to which each channel connects. By default this channel group is displayed symbolically

**Table 3–9: Control group channel assignments**

Bit order	Section:channel	CPU32 Family signal name
15	C2:3	RESET_L~
14	C3:1	FREEZE
13	D2:5	AVEC~ *†
12	D2:2	IRQ_ANY_D *‡
11	C2:5	BG_D~ §
10	C2:4	BGACK_L~ §
9	D2:1	BERR~
8	D2:0	HALT~

Table 3–9: Control group channel assignments (cont.)

Bit order	Section:channel	CPU32 Family signal name
7	C2:7	RMC~
6	C2:0	R_W~
5	C2:1	AS~
4	C2:2	DS~
3	C3:6	IFETCH_B~
2	C3:7	IFT_NXT_D~ #
1	C3:2	IPIPE_B~ *
0	C3:3	IPP_NXT_D~ *#

\* Signals not required for disassembly.

† When acquiring data with the PGA probe adapter or without a probe adapter, pull high if the port is set up for CS0~ (not AVEC~).

‡ When acquiring data without a probe adapter, pull low or connect to any inverted IRQ line.

§ When acquiring data without a probe adapter, pull high if not used or used as a chip select signal.

# When acquiring data without a probe adapter, connect IFETCH\* to both C3:6 & C3:7 podlets. Also connect IPIPEX to both C3:2 & C3:3 podlets.

Table 3–10 shows the probe section and channel assignments for the DataSize group, and the microprocessor signal to which each channel connects. By default this channel group is displayed symbolically.

Table 3–10: DataSize group channel assignments

Bit order	Section:channel	CPU32 Family signal name
7	D3:3	FC3
6	D3:2	FC2
5	D3:1	FC1
4	D3:0	FC0
3	D2:6	DSACK1~ *
2	D2:7	DSACK0~ *
1	D2:3	SIZ1
0	D2:4	SIZ0

\* Signals not required for disassembly.

Table 3–11 shows the probe section and channel assignments for the Misc group, and the microprocessor signal to which each channel connects. By default this channel group is displayed symbolically.

**Table 3–11: Misc group channel assignments**

Bit order	Section:channel	CPU32 Family signal name
4	C3:5	BKPT~ *
3	C2:6	BR_D~ *†
2	C3:0	TSTME_TSC *
1	D3:4	CSBOOT~ *
0	C3:4	CLKOUT_B *

\* Signal not required for disassembly.

† When acquiring data with the PGA probe adapter or without a probe adapter, pull high if the port is set up for CS0~ (not AVEC~).

Table 3–12 shows the probe section and channel assignments for the clock probes (not part of any group), and the CPU32 Family signal to which each channel connects.

**Table 3–12: Clock channel assignments**

Section:channel	CPU32 Family signal name
CK:3	DACK2~
CK:2	DACK1~
CK:1	BGACK~_ALT
CK:0	INV_CLKOUT

The channels in Table 3–12 are used only to clock in data. These channels are not acquired or displayed. To acquire data from any of the signals shown in Table 3–12, you must connect another channel probe to the signal. This technique is called double probing. An equals sign (=) following a signal name indicates that it is already double probed.

## How Data is Acquired

This part of this chapter explains how the module acquires CPU32 Family signals using the TMS 260 support and probe adapter. This part also provides additional information on microprocessor signals accessible on or not accessible

on the probe adapter, and on extra acquisition channels available for you to use for additional connections.

### Custom Clocking

A special clocking program is loaded to the module every time you select the microprocessor support. This special clocking is called Custom.

With Custom clocking, the module logs in signals from multiple groups of channels at different times as they become valid on the CPU32 Family bus. The module then sends all the logged-in signals to the trigger machine and to the acquisition memory of the module for storage.


In Custom clocking, the module clocking state machine (CSM) generates one master sample for each CPU32 Family bus cycle, no matter how many clock cycles are contained in the bus cycle. The CSM accommodates bus cycles with an arbitrary number of wait states, including zero.

Figure 3–7 shows the sample points and the master sample point.

A normal bus cycle begins when AS $\bar{}$  becomes low. All signals are then logged, and the CSM enters the BUS\_START state. One of the following options then occurs:

- If AS $\bar{}$  becomes high on the next cycle (a fast bus cycle lasting two clock cycles), Address and some control signals are logged in again and a master strobe is executed. This way, information on the IFETCH $\bar{}$  and IPIPE $\bar{}$  lines is not overwritten.
- If AS $\bar{}$  remains low on the next cycle, all signals are logged again and the CSM enters the BUS\_CONT state. While the CSM remains in this state, only the information from sample point 2 is logged, and is logged repetitively on every CLK cycle. This avoids overwriting information on the IFETCH and IPIPE lines. When AS $\bar{}$  becomes high again, a Master strobe sends the logged information to the PRISM.

If ALT\_BUS\_D becomes high at any time, logging of BG $\bar{}$  and BGACK $\bar{}$  stops. Consequently, if BG $\bar{}$  becomes true during a regular bus cycle, it is not recorded.



†Channels not set up in a channel group by the TMS 260 software are logged with the Master sample.


**Figure 3-7: CPU32 Family bus timing for a normal Read/Write cycle**

Sample point 1 includes A23-A0, IPIPE~, IFETCH~, BR\_D~, DS~, and RESET\_L~.

Sample point 2 includes D15-D0, IFT\_NXT\_D~, IPP\_NXT\_D~, DSACK0~, DSACK1~, AVEC~, SIZ0, SIZ1, IRQ\_ANY\_D, BERR~, HALT~, CSBOOT~, FC2-FC0, TSTME~\_TSC, RMC~, R\_W~, BKPT~, BG\_D~, FREEZE, AS~, BGACK\_L~, and CLKOUT\_B.

Figure 3–8 shows the sample points and the master sample for a Show bus cycle.

A Show cycle is any internal bus cycle made visible on the external bus. These cycles are characterized by the AS $\sim$  signal remaining high while the DS $\sim$  signal is asserted. Show cycles are made visible by writing to a register in the microprocessor. Micro clocking includes these cycles by default, but a selection on the Clock Menu allows you to exclude them. As with normal cycles, if the BGACK $\sim$ \_ALT signal becomes true, the BG $\sim$  and BGACK $\sim$  signals are no longer logged in.



**Figure 3–8: CPU32 Family bus timing for a Show Bus cycle**

Sample point 1 includes A23-A0, IPIPE $\sim$ , IFETCH $\sim$ , BR\_D $\sim$ , DS $\sim$ , and RESET\_L $\sim$ .

Sample point 2 includes D15-D0, IFT\_NXT\_D $\sim$ , IPP\_NXT\_D $\sim$ , DSACK0 $\sim$ , DSACK1 $\sim$ , AVEC $\sim$ , SIZ0, SIZ1, IRQ\_ANY\_D, BERR $\sim$ , HALT $\sim$ , CSBOOT $\sim$ , FC2-FC0, TSTME $\sim$ \_TSC, RMC $\sim$ , R\_W $\sim$ , BKPT $\sim$ , BG\_D $\sim$ , FREEZE, AS $\sim$ , BGACK\_L $\sim$ , and CLKOUT\_B.

Alternate Bus Master cycles are not normally acquired. You can include these cycles in the Alternate Bus Master Cycles field in the custom clocking dialog for the 102-channel module or in the Custom Clock Setup menu for the 96-channel module.

When ALT\_BUS\_D is sensed as high, the CSM goes to the DUMB\_IDLE state (except during a regular cycle, in which case the CSM logs the current cycle before entering the DUMB\_IDLE state). In the DUMB\_IDLE state, the CSM waits for strobes AS $\sim$  or DS $\sim$  to go active, then logs a normal bus cycle or a show cycle, respectively. If neither strobe becomes active but ALT\_BUS\_D is

deasserted, a bus cycle is sent with the signal logged on the previous clock edge. Otherwise, all bus cycles are logged in using the same method as regular cycles.

### Clocking Options

The clocking algorithm for the CPU32 Family support has two variations: Alternate Bus Master Cycles Excluded, and Alternate Bus Master Cycles Included.

**Probe Adapter.** With normal bus cycles, there are two sample points, of which the second sample point is also the master sample. Figures 3–7 and 3–8 show these sample points.

**Without Probe Adapter.** When no probe adapter is used, all data is logged in at the master sample point shown in Figures 3–7 and 3–8.

**Show Cycles Included.** With Show cycles included, there are two sample points, of which the second sample point is also the master sample. Figure 3–8 shows these sample points.

**Show Cycles Excluded.** Show cycle data is ignored, not acquired.

**Alternate Bus Master Cycles Excluded.** Alternate bus master cycles are not logged in.

**Alternate Bus Master Cycles Included.** All bus cycles, including Alternate Bus Master cycles, are logged in. If either BG $\sim$  or BGACK $\sim$  are true (signals selectable with jumpers on the probe adapter), the bus cycle will be considered an alternate bus master cycle. To log in these cycles, the DS $\sim$  or AS $\sim$  signals must also be active true.

When the BOFF# signal goes low (active), a backoff cycle has been requested, and the CPU32 Family microprocessor gives up the bus on the next clock cycle. The module aborts the bus cycle that it is currently logging in (the CPU32 Family microprocessor will restart this cycle once the BOFF# signal goes high). A backoff cycle will be logged in using one of the three interactions described for the HLDA signal (except that the BOFF# signal is stored as a low-level signal in each of the cases).

- If the alternate bus master drives the same control lines as the CPU32 Family microprocessor, and the CPU32 Family microprocessor “sees” these signals, the bus activity is logged in like normal bus cycles except that the BG $\sim$  or BGACK $\sim$  signal is low.
- If none of the control lines are driven or if the CPU32 Family microprocessor can not see them, the module will still clock in an alternate bus master cycle.

The information on the bus, one clock prior to the BG~ or BGACK~ signal going high is logged in.

- If some of the CPU32 Family microprocessor control lines are visible (but not all), the module logs in what it determines is valid from the control signals and logs in the remaining bus signals one clock cycle prior to the BG~ or BGACK~ signal going high.

## Alternate Microprocessor Connections

For a list of signals required or not required for disassembly, refer to the channel assignment tables beginning on page 3–10. Remember that these channels are already included in a channel group. If you connect extra these channels to other signals, you should set up another channel group for them.

### Signals On the Probe Adapter

The probe adapter board contains pins for microprocessor signals that are not acquired by the TMS 260 support. You can connect extra channels to these pins, because they can be useful for general purpose analysis.

These channels are not defined as a channel group and data acquired from them is not displayed. To display data you will need to define a channel group.

Table 3–13 shows the microprocessor signals available on J1612 of the probe adapter.

**Table 3–13: CPU32 Family signals on J1612**

Pin No.	CPU32 Family signal name		Pin No.	CPU32 Family signal name	
	68331	68332		68331	68332
1	GND	GND	10	OC4	TP8
2	PCLK	T2CLK	11	NC	TP7
3	PWMB	TP15	12	OC3	TP6
4	PWMA	TP14	13	OC2	TP5
5	NC	TP13	14	OC1	TP4
6	NC	TP12	15	IC3	TP3
7	NC	TP11	16	IC2	TP2
8	PAI	TP10	17	IC1	TP1
9	IC4/OC5	TP9	18	NC	TP0

### Signals Not On the Probe Adapter

The probe adapter does not provide access for the following microprocessor signals:

EXTAL	MOSI	PCS2~	SCK	VSTBY*
MISO	PCS0~/SS~	PCS3~	TXD	XFC
MODCLK	PCS1~	RXD	VDDSYN	XTAL

The following is a list of microprocessor signals that are not accessible on the 68340 PGA probe adapter.

CS1~	DREQ1~	RXDB	TGATE2~	TXDB
CS2~	DREQ2~	RXRDYA	TIN1	TXRDYA
CS3~	EXTAL	SCLK	TIN2	X1
CTSA~	MODCK	TCK	TMS	X2
CTSB~	RTSA~	TD0	TOUT1	XFC
DONE1~	RTSB~	TD1	TOUT2	XTAL
DONE2~	RXDA	TGATE1	TXDA	VCCSYN

### Extra Channels

Table 3–14 lists extra sections and channels that are left after you have connected all the probes used by the support. You can use these extra channels to make alternate SUT connections.

**Table 3–14: Extra module sections and channels**

Module	Section: channels
102-channels	C1:7-0, C0:7-0
136-channels	C1:7-0, C0:7-0, E3:7-0, E2:7-0, E1:7-0, E0:7-0
96-channels	C1:7-0, C0:7-0

These channels are not defined in any channel group and data acquired from them is not displayed. To display data, you will need to define a channel group.

**WARNING**

*The following servicing instructions are for use only by qualified personnel. To avoid injury, do not perform any servicing other than that stated in the operating instructions unless you are qualified to do so. Refer to all Safety Summaries before performing any service.*

# Maintenance

This section contains information on the following topics:

- Probe adapter circuit description

## Probe Adapter Circuit Description

The QFP probe adapter board and Evaluation Board Adapter board have the same circuitry (except that the 74F30 on the QFP probe adapter is replaced by a 74AC20 on the Evaluation Board probe adapter). The CLKOUT signal goes to the acquisition module after being inverted. The inverted clock also latches the asynchronous signals BGACK~ and RESET~ to avoid metastables going into the Clocking State Machine. The IFETCH~ and IPIPE~ lines are buffered through a 74AS1034 to minimize loading.

BG~ and BGACK\_L~ (and DACK1~ and DACK2~ on the option 1A board) are combined to form a signal called ALT\_BUS\_D. When this is high, the processor has given up the bus. Similarly, all the IRQ~s (IRQ3~, IRQ5~, IRQ6~, and IRQ7~ on the option 1A board) are OR'ed together to form a signal called IRQ\_ANY\_D that, when high, indicates an interrupt request is active.

All other acquired signals go directly to the logic analyzer podlets.

J1771 and J1671 are used to turn off the cache. The SUT drives these lines, therefore the SUT driver must be disabled to use this option.

## Replacing Signal Leads

Information on basic operations describes how to replace signal leads (individual channel and clock probes).

## Replacing Protective Sockets

Information on basic operations describes how to replace protective sockets.

# Replaceable Electrical Parts

This chapter contains a list of the replaceable electrical components for the TMS 260 CPU32 Family microprocessor support. Use this list to identify and order replacement parts.

## Parts Ordering Information

Replacement parts are available through your local Tektronix field office or representative.

Changes to Tektronix products are sometimes made to accommodate improved components as they become available and to give you the benefit of the latest improvements. Therefore, when ordering parts, it is important to include the following information in your order:

- Part number
- Instrument type or model number
- Instrument serial number
- Instrument modification number, if applicable

If you order a part that has been replaced with a different or improved part, your local Tektronix field office or representative will contact you concerning any change in part number.

Change information, if any, is located at the rear of this manual.

## Using the Replaceable Electrical Parts List

The tabular information in the Replaceable Electrical Parts List is arranged for quick retrieval. Understanding the structure and features of the list will help you find all of the information you need for ordering replacement parts. The following table describes each column of the electrical parts list.



**Manufacturers cross index**

<b>Mfr. code</b>	<b>Manufacturer</b>	<b>Address</b>	<b>City, state, zip code</b>
80009	TEKTRONIX INC	14150 SW KARL BRAUN DR PO BOX 500	BEAVERTON, OR 97077-0001
TK0875	MATSUO ELECTRONICS INC	831 S DOUBLAS ST	EL SEGUNDO CA 92641
00779	AMP INC	2800 FULLING MILL PO BOX 3608	HARRISBURG PA 17105
01295	TEXAS INSTRUMENTS INC SEMICONDUCTOR GROUP	13500 N CENTRAL EXPY PO BOX 655303	DALLAS TX 75262-5303
04222	AVX CERAMICS DIV OF AVX CORP	19TH AVE SOUTH P O BOX 867	MYRTLE BEACH SC 29577
04713	MOTOROLA INC SEMICONDUCTOR PRODUCTS SECTOR	5005 E MCDOWELL RD	PHOENIX AZ 85008-4229
15912	THOMAS AND BETTS CORP ELECTRONICS GROUP	76 FAIRBANKS	IRVINE CA 92718
26742	METHODE ELECTRONICS INC	7447 W WILSON AVE	CHICAGO IL 60656-4548
27014	NATIONAL SEMICONDUCTOR CORP	2900 SEMICONDUCTOR DR	SANTA CLARA CA 95051-0606
50434	HEWLETT-PACKARD CO OPTOELECTRONICS DIV	370 W TRIMBLE RD	SAN JOSE CA 95131-1008
53387	MINNESOTA MINING MFG CO	PO BOX 2963	AUSTIN TX 78769-2963
57668	ROHM CORPORATION	15375 BARRANCA PARKWAY SUITE B207	IRVINE CA 92718
63058	MCKENZIE TECHNOLOGY	910 PAGE AVENUE	FREMONT CA 94538
80009	TEKTRONIX INC	14150 SW KARL BRAUN DR PO BOX 500	BEAVERTON OR 97077-0001

**Replaceable electrical parts list**

<b>Component number</b>	<b>Tektronix part number</b>	<b>Serial no. effective</b>	<b>Serial no. discont'd</b>	<b>Name &amp; description</b>	<b>Mfr. code</b>	<b>Mfr. part number</b>
A01	671-2463-00			CIRCUIT BD ASSY:68331/2,PQFP132 SOLDERED, PROBE ADAPTER;	80009	671246300
A02	671-2495-00			CIRCUIT BD ASSY:M68331/2EVS,PRECONFIG INTERFACE;	80009	671249500
A03	671-3010-00			CIRCUIT BD ASSY:68340,PROBE ADAPTER,PGA0145SOCKETED;	80009	671301000
A01C1171	283-5004-00			CAP,FXD,CERAMIC:MLC;0.1UF,10%,25V,X7R,1206	04222	12063C104KAT3A
A01C1241	283-5004-00			CAP,FXD,CERAMIC:MLC;0.1UF,10%,25V,X7R,1206	04222	12063C104KAT3A
A01C1251	283-5004-00			CAP,FXD,CERAMIC:MLC;0.1UF,10%,25V,X7R,1206	04222	12063C104KAT3A
A01C1371	283-5004-00			CAP,FXD,CERAMIC:MLC;0.1UF,10%,25V,X7R,1206	04222	12063C104KAT3A
A01C1571	283-5004-00			CAP,FXD,CERAMIC:MLC;0.1UF,10%,25V,X7R,1206	04222	12063C104KAT3A
A01C1741	283-5004-00			CAP,FXD,CERAMIC:MLC;0.1UF,10%,25V,X7R,1206	04222	12063C104KAT3A
A01C1771	283-5004-00			CAP,FXD,CERAMIC:MLC;0.1UF,10%,25V,X7R,1206	04222	12063C104KAT3A

Replaceable electrical parts list (cont.)

Component number	Tektronix part number	Serial no. effective	Serial no. discont'd	Name & description	Mfr. code	Mfr. part number
A01C1851	290-5005-00			CAP,FXD,TANT:47UF,10%,10V,SMD,T&R	TK0875	267M-1002-476-K
A01J1161	-----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RMPL)		
A01J1201	-----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RMPL)		
A01J1311	-----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RPML)		
A01J1312	-----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RPML)		
A01J1411	-----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RPML)		
A01J1412	-----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RPML)		
A01J1491	-----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RMPL)		
A01J1511	-----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RPML)		
A01J1512	-----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGHTEMP (SEE RPML)		
A01J1513	-----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGHTEMP (SEE RPML)		
A01J1611	-----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RPML)		
A01J1612	-----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RMPL)		
A01J1881	-----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RMPL)		
A01J1891	-----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RMPL)		
A01J1921	-----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RMPL)		
A01P1311	-----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A01P1312	-----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A01P1411	-----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		

Replaceable electrical parts list (cont.)

Component number	Tektronix part number	Serial no. effective	Serial no. discont'd	Name & description	Mfr. code	Mfr. part number
A01P1412	----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A01P1511	----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A01P1512	----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A01P1513	----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A01P1611	----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A01P2551	----			CLIP,ELECTRICAL:ASSEMBLY,PQFP132		
A01R1670	321-5005-00			RES,FXD:THICK FILM;27.4 OHM,1%,0.125W, TC=100 PPM	57668	MCR18EZHFW 27E4
A01U1271	156-5193-00			IC,DIGITAL:FTTL,FLIP FLOP;HEX D-TYPE, WITH/MR	01295	SN74F174D
A01U1471	156-5500-00			IC,DIGITAL:FTTL,GATES;8-INPUT NAND	01295	SN74F30D
A01U1671	156-5804-00			IC,DIGITAL:ASTTL,GATE:QUAD 2-INPUT NAND BUFFER	01295	SN74AS1000AD
A01U1871	156-5392-00			IC,DIGITAL:ASTTL,BUFFER/DRIVER;HEX DRIVER	01295	SN74AS1034AD
A02C1190	290-5005-00			CAP,FXD,TANT:47UF,10%,10V,SMD,T&R	TK0875	267M-1002-476-K
A02C1320	283-5004-00			CAP,FXD,CERAMIC:MLC;0.1UF,10%,25V,X7R,1206	04222	12063C104KAT3A
A02C1460	283-5004-00			CAP,FXD,CERAMIC:MLC;0.1UF,10%,25V,X7R,1206	04222	12063C104KAT3A
A02C1470	283-5004-00			CAP,FXD,CERAMIC:MLC;0.1UF,10%,25V,X7R,1206	04222	12063C104KAT3A
A02C1480	283-5004-00			CAP,FXD,CERAMIC:MLC;0.1UF,10%,25V,X7R,1206	04222	12063C104KAT3A
A02C1650	283-5004-00			CAP,FXD,CERAMIC:MLC;0.1UF,10%,25V,X7R,1206	04222	12063C104KAT3A
A02C1670	283-5004-00			CAP,FXD,CERAMIC:MLC;0.1UF,10%,25V,X7R,1206	04222	12063C104KAT3A
A02C1860	283-5004-00			CAP,FXD,CERAMIC:MLC;0.1UF,10%,25V,X7R,1206	04222	12063C104KAT3A
A02J1150	----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RPML)		
A02J1300	----			CONN,HDR:PCB,;MALE,RTANG,2 X 40,0.1 CTR,0.2 35 MLG X 0.110 TAIL,30 GOLD (SEE RMPL)		
A02J1301	----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RPML)		
A02J1302	----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RPML)		
A02J1320	----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RPML)		
A02J1350	----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RPML)		

Replaceable electrical parts list (cont.)

Component number	Tektronix part number	Serial no. effective	Serial no. discont'd	Name & description	Mfr. code	Mfr. part number
A02J1351	----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RPML)		
A02J1352	----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RPML)		
A02J1401	----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RPML)		
A02J1402	----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RPML)		
A02J1403	----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RPML)		
A02J1440	----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RPML)		
A02J1500	----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RPML)		
A02J1501	----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RPML)		
A02J1502	----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RPML)		
A02J1540	----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RPML)		
A02J1545	----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RPML)		
A02J1550	----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RPML)		
A02J1610	----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RPML)		
A02J1640	----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RPML)		
A02J1645	----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RPML)		
A02J1650	----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RPML)		
A02J1690	----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RPML)		
A02J1900	----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RPML)		
A02J1950	----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RPML)		

Replaceable electrical parts list (cont.)

Component number	Tektronix part number	Serial no. effective	Serial no. discont'd	Name & description	Mfr. code	Mfr. part number
A02J1955	-----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RPML)		
A02P1	-----			CONN,DIN:PCB,;FEMALE,STR,2 X 32,0.1 CTR,0.4 54 H X 0.157 TAIL,30 GOLD (SEE RPML)		
A02P2	-----			CONN,DIN:PCB,;FEMALE,STR,2 X 32,0.1 CTR,0.4 54 H X 0.157 TAIL,30 GOLD (SEE RPML)		
A02P1301	-----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A02P1302	-----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A02P1350	-----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A02P1351	-----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A02P1352	-----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A02P1401	-----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A02P1402	-----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A02P1403	-----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A02P1440	-----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A02P1500	-----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A02P1501	-----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A02P1502	-----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A02P1540	-----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A02P1545	-----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A02P1640	-----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A02P1645	-----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A02P1950	-----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		
A02P1955	-----			CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 (SEE RPML)		

**Replaceable electrical parts list (cont.)**

<b>Component number</b>	<b>Tektronix part number</b>	<b>Serial no. effective</b>	<b>Serial no. discontin'd</b>	<b>Name &amp; description</b>	<b>Mfr. code</b>	<b>Mfr. part number</b>
A02U1460	156-5418-00			IC,DIGITAL:ACMOS,GATE;DUAL 4-INPUT NAND	04713	MC74AC20D
A02U1470	156-5392-00			IC,DIGITAL:ASTTL,BUFFER/DRIVER;HEX DRIVER	01295	SN74AS1034AD
A02U1470	156-5804-00			IC,DIGITAL:ASTTL,GATE;QUAD 2-INPUT NAND BUFFER	01295	SN74AS1000AD
A02U1480	156-5193-00			IC,DIGITAL:FTTL,FLIP FLOP;HEX D-TYPE,WITH/MR	01295	SN74F174D

## Replaceable electrical parts list (cont.)

Component number	Tektronix part number	Serial no. effective	Serial no. discont'd	Name & description	Mfr. code	Mfr. part number
A03	671-3010-00			CIRCUIT BD ASSY:68340,PROBE ADAPTER, PGA 0145 SOCKETED;	80009	671301000
A03C110	283-5004-00			CAP,FXD,CERAMIC:MLC:0.1UF,10%,25V,X7R,1206	04222	12063C104KAT3A
A03C120	283-5004-00			CAP,FXD,CERAMIC:MLC:0.1UF,10%,25V,X7R,1206	04222	12063C104KAT3A
A03C136	283-5004-00			CAP,FXD,CERAMIC:MLC:0.1UF,10%,25V,X7R,1206	04222	12063C104KAT3A
A03C310	283-5004-00			CAP,FXD,CERAMIC:MLC:0.1UF,10%,25V,X7R,1206	04222	12063C104KAT3A
A03C320	283-5004-00			CAP,FXD,CERAMIC:MLC:0.1UF,10%,25V,X7R,1206	04222	12063C104KAT3A
A03C330	283-5004-00			CAP,FXD,CERAMIC:MLC:0.1UF,10%,25V,X7R,1206	04222	12063C104KAT3A
A03C510	283-5004-00			CAP,FXD,CERAMIC:MLC:0.1UF,10%,25V,X7R,1206	04222	12063C104KAT3A
A03C530	283-5004-00			CAP,FXD,CERAMIC:MLC:0.1UF,10%,25V,X7R,1206	04222	12063C104KAT3A
A03CR110	152-5045-00			DIODE,SIG:SCHTKY,;20V,1.2PF,24 OHM	50434	HSMS-2810-T31
A03CR520	152-5045-00			DIODE,SIG:SCHTKY,;20V,1.2PF,24 OHM	50434	HSMS-2810-T31
A03J110	-----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RMPL)		
A03J130	-----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RMPL)		
A03J131	-----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RMPL)		
A03J132	-----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RMPL)		
A03J133	-----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RMPL)		
A03J134	-----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RMPL)		
A03J135	-----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RMPL)		
A03J136	-----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RMPL)		
A03J137	-----			CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE RMPL)		
A03J200	-----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RMPL)		
A03J240	-----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RMPL)		
A03J420	-----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RMPL)		

## Replaceable Electrical Parts

---

### Replaceable electrical parts list (cont.)

Component number	Tektronix part number	Serial no. effective	Serial no. discontinued	Name & description	Mfr. code	Mfr. part number
A03J510	----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RMPL)		
A03J530	----			CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 (SEE RMPL)		
A03U120	156-5418-00			IC,DIGITAL:ACMOS,GATE:DUAL 4-INPUT NAND	04713	MC74AC20D
A03U230	----			SOCKET,PGA:PCB,;145 POS,15 X 15,0.1CTR,0.173 H X 0.273 TAIL,GOLD/GOLD,PAT1521,RYTON OPEN CTR (SEE RMPL)		
A03U310	156-6401-00			IC,DIGITAL:FTTL,BUFFER:NON INV OCTAL LINE D RIVER,3-STATE	27014	74FR244SC
A03U320	156-5804-00			IC,DIGITAL:ASTTL,GATE:QUAD 2-INPUT NAND BUFFER	01295	SN74AS1000AD
A03U330	156-5193-00			IC,DIGITAL:FTTL,FLIP FLOP;HEX D-TYPE,WITH/MR	01295	SN74F174D

# Replaceable Mechanical Parts

This chapter contains a list of the replaceable mechanical components for the TMS 260 CPU32 Family microprocessor support. Use this list to identify and order replacement parts.

## Parts Ordering Information

Replacement parts are available through your local Tektronix field office or representative.

Changes to Tektronix products are sometimes made to accommodate improved components as they become available and to give you the benefit of the latest improvements. Therefore, when ordering parts, it is important to include the following information in your order:

- Part number
- Instrument type or model number
- Instrument serial number
- Instrument modification number, if applicable

If you order a part that has been replaced with a different or improved part, your local Tektronix field office or representative will contact you concerning any change in part number.

Change information, if any, is located at the rear of this manual.

## Using the Replaceable Mechanical Parts List

The tabular information in the Replaceable Mechanical Parts List is arranged for quick retrieval. Understanding the structure and features of the list will help you find all of the information you need for ordering replacement parts. The following table describes the content of each column in the parts list.

**Parts list column descriptions**

Column	Column name	Description
1	Figure & index number	Items in this section are referenced by figure and index numbers to the exploded view illustrations that follow.
2	Tektronix part number	Use this part number when ordering replacement parts from Tektronix.
3 and 4	Serial number	Column three indicates the serial number at which the part was first effective. Column four indicates the serial number at which the part was discontinued. No entries indicates the part is good for all serial numbers.
5	Qty	This indicates the quantity of parts used.
6	Name & description	An item name is separated from the description by a colon (:). Because of space limitations, an item name may sometimes appear as incomplete. Use the U.S. Federal Catalog handbook H6-1 for further item name identification.
7	Mfr. code	This indicates the code of the actual manufacturer of the part.
8	Mfr. part number	This indicates the actual manufacturer's or vendor's part number.

**Abbreviations**      Abbreviations conform to American National Standard ANSI Y1.1-1972.

**Chassis Parts**      Chassis-mounted parts and cable assemblies are located at the end of the Replaceable Electrical Parts List.

**Mfr. Code to Manufacturer Cross Index**      The table titled Manufacturers Cross Index shows codes, names, and addresses of manufacturers or vendors of components listed in the parts list.

**Manufacturers cross index**

Mfr. code	Manufacturer	Address	City, state, zip code
80009	TEKTRONIX INC	14150 SW KARL BRAUN DR PO BOX 500	BEAVERTON, OR 97077-0001
TK2508	CYPRESS ELECTRONICS	1235 SW 16TH	PORTLAND OR 97225
TK2548	XEROX BUSINESS SERVICES DIV OF XEROX CORPORATION	14181 SW MILLIKAN WAY	BEAVERTON OR 97077
00779	AMP INC	2800 FULLING MILL PO BOX 3608	HARRISBURG PA 17105
15912	THOMAS AND BETTS CORP ELECTRONICS GROUP	76 FAIRBANKS	IRVINE CA 92718
26742	METHODE ELECTRONICS INC	7447 W WILSON AVE	CHICAGO IL 60656-4548
53387	MINNESOTA MINING MFG CO	PO BOX 2963	AUSTIN TX 78769-2963
63058	MCKENZIE TECHNOLOGY	910 PAGE AVENUE	FREMONT CA 94538

Replaceable mechanical parts list

Fig. & index number	Tektronix part number	Serial no. effective	Serial no. discont'd	Qty	Name & description	Mfr. code	Mfr. part number
1-1	671-2463-00			1	CIRCUIT BD ASSY:68331/2,PQFP132 SOLDERED, PROBE ADAPTER;	80009	671246300
-2	131-4530-00			8	CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (J1311,J1312,J1411,J14112,J1511,J1512,J1611)	00779	104714-2
-3	131-4356-00			8	CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1CTR,0.630 H,BLK,W/HANDLE,JUMPER (P1311,P1312,P1411,P1412,P1511,P1513,P1611)	26742	9618-302-50
-4	131-5267-00			2	CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 MLG X 0.110 TAIL,30GOLD (J1161,J1201,J1491,1612,1881,1891,J1921)J1921)	53387	N-2480-6122-TB
<b>STANDARD ACCESSORIES</b>							
	070-9824-00			1	MANUAL,TECH:INSTRUCTION,CPU32 Family,DISSASSEMBLER,TMS 260	80009	070-9824-00
	020-1983-00			1	ACCESSORY PKG:PKG OF 5 COFP TO PQFP ADAPTER WITH INSTRUCTION SHEET	TK25 48	ORDER BY DESC
<b>OPTIONAL ACCESSORIES</b>							
	070-9802-00			1	MANUAL, TECH:BASIC OPS MICRO SUP ON TLA 500 SERIES & DAS LOGIC ANALYZERS	80009	070-9802-00




Figure 1: 68331/332 QFP probe adapter exploded view

Replaceable mechanical parts list

Fig. & index number	Tektronix part number	Serial no. effective	Serial no. discont'd	Qty	Name & description	Mfr. code	Mfr. part number
2-1	671-2495-00			1	CIRCUIT BD ASSY:M68331/2EVS,PRECONFIG INTERFACE;	80009	671249500
-2	131-4530-00			12	CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (J1301,J1302,J1350,J1351,J1401,J1402, J1403,J1500,J1501,J1502,J1950,J1955)	00779	104714-2
-3	131-4356-00			18	CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2, 0.1 CTR,0.630 H,BLK,W/HANDLE,JUMPER (P1301,P1302,P1350,P1351,P1352,P1401,P1402, P1440,P1500,P1502,P1540,P1545,P1640, P1640.P1645,P1900,P1955)	26742	9618-302-50
-4	131-5267-00			3	CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 MLG X 0.110 TAIL,30GOLD (J1150,J1320,J1352,J1440,J1540,J1550,J1610, J1640,J1645,J1650,J1690,J1900)	53387	N-2480-6122-TB
-5	131-5268-00			1	CONN,HDR:PCB,;MALE,RTANG,2 X 40,0.1 CTR,0.235 MLG X 0.110 TAIL,30 GOLD (J1300)	53387	2480-5122-TB
-6	131-2952-00			2	CONN,DIN:PCB,;FEMALE,STR,2 X 32,0.1 CTR,0.454 H X 0.157 TAIL,30 GOLD (P1,P2)	15912	FB064-031-2
					<b>STANDARD ACCESSORIES</b>		
	070-9824-00			1	MANUAL,TECH:INSTRUCTION,CPU32 Family,DISSASEM-BLER,TMS 260	80009	070-9824-00
					<b>OPTIONAL ACCESSORIES</b>		
	070-9802-00			1	MANUAL,TECH:BASIC OPS MICRO SUP ON TLA 500 SERIES & DAS LOGIC ANALYZERS	80009	070-9802-00




Figure 2: 68331/332 Evaluation Board probe adapter exploded view

Replaceable mechanical parts list

Fig. & index number	Tektronix part number	Serial no. effective	Serial no. discont'd	Qty	Name & description	Mfr. code	Mfr. part number
3-0	010-0569-00			1	PROBE ADAPTER:68340,PGA145 SOCKETED;	80009	010056900
-1	671-3010-00			1	CIRCUIT BD ASSY:68340,PROBE ADAPTER,PGA145 SOCKETED;	80009	671301000
-2	131-5267-00			3	CONN,HDR:PCB,;MALE,STR,2 X 40,0.1 CTR,0.235 MLG X 0.110 TAIL,30GOLD (J110,J200,J240,J420,J510,J530)	53387	N-2480-6122-TB
-3	131-4530-00			8	CONN,HDR:PCB,;MALE,STR,1 X 3,0.1 CTR,0.230 MLG X 0.120 TAIL,30 GOLD,BD RETENTION,HIGH TEMP (SEE EMPL J130,J131,J132,J133,J134,J135,J136,J137)	00779	104714-2
-4	131-4356-00			8	CONN,SHUNT:SHUNT/SHORTING,;FEMALE,1 X 2,0.1 CTR,0.630 H,BLK,W/HANDLE,JUMPER (P130,P131,P132,P133,P134,P135,P136,P137)	26742	9618-302-50
-5	136-0952-00			2	SOCKET,PGA:PCB,;145 POS,15 X 15,0.1 CTR,0.173 H X 0.183 TAIL,GOLD/GOLD,OPEN CTR,PATTERN 1521,CLIP 6(32),0.024 DIA PCB (U230)	63058	PGA145H101B1152
					<b>STANDARD ACCESSORIES</b>		
	070-9803-00			1	MANUAL, TECH:TLA 700 SERIES MICRO SUPPORT INSTALLATION	80009	070-9803-00
	070-9824-00			1	MANUAL,TECH:INSTRUCTION,CPU32 Family,DISSASSEMBLER,TMS 260	80009	070-9824-00
					<b>OPTIONAL ACCESSORIES</b>		
	070-9802-00			1	MANUAL, TECH:BASIC OPS MICRO SUP ON TLA 500 SERIES & DAS LOGIC ANALYZERS	80009	070-9802-00




Figure 3: 68340 PGA probe adapter exploded view

# Index

## A

- about this manual set, ix
- Address group
  - channel assignments, 3–11
  - display column, 2–8
- Alternate Bus Master Cycles
  - clocking option, 2–2
  - how data is acquired, 3–18
- alternate connections
  - extra channel probes, 3–20
  - to other signals, 3–19

## B

- basic operations, where to find information, ix
- bus cycles, displayed cycle types, 2–7
- bus timing, 3–16, 3–17

## C

- certifications, 3–10
- channel assignments
  - Address group, 3–11
  - clocks, 3–15
  - Control group, 3–13
  - Data group, 3–12
  - DataSize group, 3–14
  - Misc group, 3–14
- channel groups, 2–1
- clock channel assignments, 3–15
- clock rate, 1–2
- clocking, Custom, 2–1
  - how data is acquired, 3–15
- clocking options
  - Alternate Bus Master Cycles, 2–2
  - field names, 2–1
  - how data is acquired, 3–18
  - Probe Adapter, 2–2
  - Show Cycles, 2–2
- compliances, 3–10
- connections
  - no probe adapter, 1–16
    - channel probes, 1–16
    - clock probes, 1–18
  - other microprocessor signals, 3–19

- probe adapter to SUT
  - CQFP, 1–12
    - JEDEC clip, 1–14
  - PGA, 1–6
  - PQFP, 1–9
    - JEDEC clip, 1–11
- Control Flow display format, 2–9
- Control group
  - channel assignments, 3–13
  - symbol table, 2–2
- Custom clocking, 2–1
  - Alternate Bus Master Cycles, 2–2
  - how data is acquired, 3–15
  - Probe Adapter, 2–2
  - Show Cycles, 2–2
- cycle types, 2–7

## D

- data
  - disassembly formats
    - Control Flow, 2–9
    - Software, 2–9
    - Subroutine, 2–10
    - how it is acquired, 3–15
  - data display, changing, 2–10
- Data group
  - channel assignments, 3–12
  - display column, 2–8
- DataSize group, channel assignments, 3–14
- demonstration file, 2–14
- disassembled data
  - cycle type definitions, 2–7
  - viewing, 2–5
  - viewing an example, 2–14
- disassembler
  - definition, ix
  - logic analyzer configuration, 1–2
  - setup, 2–1
- Disassembly Format Definition overlay, 2–10
- Disassembly property page, 2–10
- display formats
  - Control Flow, 2–9
  - Software, 2–9
  - special characters, 2–5
  - Subroutine, 2–10

**E**

electrical specifications, 3–4  
environmental specifications, 3–5  
exception vectors, 2–12

**H**

Hardware display format, cycle type definitions, 2–7

**I**

installing hardware. *See* connections

**L**

leads (podlets). *See* connections  
logic analyzer  
    configuration for disassembler, 1–2  
    software compatibility, 1–2

**M**

manual  
    conventions, ix  
    how to use the set, ix  
Mark Cycle function, 2–12  
Mark Opcode function, 2–12  
marking cycles, definition of, 2–12  
microprocessor  
    package types supported, 1–1  
    signals not accessible on probe adapter, 3–20  
    specific clocking and how data is acquired, 3–15  
Misc group, channel assignments, 3–14  
Mnemonics display column, 2–8

**P**

Probe Adapter  
    clocking option, 2–2  
    how data is acquired, 3–18  
probe adapter  
    alternate connections, 3–19  
    circuit description, 4–1  
    clearance, 1–5  
        adding sockets, 1–8

    dimensions, 3–7  
    configuring, 1–3, 3–1  
    connecting leads, 1–10  
    hardware description, 3–1  
    jumper positions, 1–3, 3–1  
    not using one, 1–16  
    placing the microprocessor in, 1–7, 1–13

**R**

reference memory, 2–14  
restrictions, 1–2  
    without a probe adapter, 1–16

**S**

service information, 4–1  
setups, disassembler, 2–1  
Show Cycles  
    clocking option, 2–2  
    how data is acquired, 3–18  
signals  
    active low sign, x  
    alternate connections, 3–19  
    extra channel probes, 3–20  
Software display format, 2–9  
special characters displayed, 2–5  
specifications, 3–1  
    certifications, 3–10  
    channel assignments, 3–10  
    compliances, 3–10  
    electrical, 3–4  
    environmental, 3–5  
Subroutine display format, 2–10  
support setup, 2–1  
SUT, definition, ix  
symbol table, Control channel group, 2–2

**T**

terminology, ix

**V**

viewing disassembled data, 2–5