

Instructions



TLACAL1 & TLACAL2 Performance Verification Fixture 071-1125-01

This document applies to TLA System Software
version 4.20 and above.

www.tektronix.com



071112501

Copyright © Tektronix, Inc. All rights reserved.

Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supercedes that in all previously published material. Specifications and price change privileges reserved.

Tektronix, Inc., P.O. Box 500, Beaverton, OR 97077

TEKTRONIX and TEK are registered trademarks of Tektronix, Inc.

WARRANTY

Tektronix warrants that the products that it manufactures and sells will be free from defects in materials and workmanship for a period of one (1) year from the date of shipment. If a product proves defective during this warranty period, Tektronix, at its option, either will repair the defective product without charge for parts and labor, or will provide a replacement in exchange for the defective product.

In order to obtain service under this warranty, Customer must notify Tektronix of the defect before the expiration of the warranty period and make suitable arrangements for the performance of service. Customer shall be responsible for packaging and shipping the defective product to the service center designated by Tektronix, with shipping charges prepaid. Tektronix shall pay for the return of the product to Customer if the shipment is to a location within the country in which the Tektronix service center is located. Customer shall be responsible for paying all shipping charges, duties, taxes, and any other charges for products returned to any other locations.

This warranty shall not apply to any defect, failure or damage caused by improper use or improper or inadequate maintenance and care. Tektronix shall not be obligated to furnish service under this warranty a) to repair damage resulting from attempts by personnel other than Tektronix representatives to install, repair or service the product; b) to repair damage resulting from improper use or connection to incompatible equipment; c) to repair any damage or malfunction caused by the use of non-Tektronix supplies; or d) to service a product that has been modified or integrated with other products when the effect of such modification or integration increases the time or difficulty of servicing the product.

THIS WARRANTY IS GIVEN BY TEKTRONIX IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED. TEKTRONIX AND ITS VENDORS DISCLAIM ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TEKTRONIX' RESPONSIBILITY TO REPAIR OR REPLACE DEFECTIVE PRODUCTS IS THE SOLE AND EXCLUSIVE REMEDY PROVIDED TO THE CUSTOMER FOR BREACH OF THIS WARRANTY. TEKTRONIX AND ITS VENDORS WILL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES IRRESPECTIVE OF WHETHER TEKTRONIX OR THE VENDOR HAS ADVANCE NOTICE OF THE POSSIBILITY OF SUCH DAMAGES.

Contacting Tektronix

Phone	1-800-833-9200*
Address	Tektronix, Inc. Department or name (if known) 14200 SW Karl Braun Drive P.O. Box 500 Beaverton, OR 97077 USA
Web site	www.tektronix.com
Sales support	1-800-833-9200, select option 1*
Service support	1-800-833-9200, select option 2*
Technical support	Email: techsupport@tektronix.com 1-800-833-9200, select option 3* 6:00 a.m. - 5:00 p.m. Pacific time

* **This phone number is toll free in North America. After office hours, please leave a voice mail message. Outside North America, contact a Tektronix sales office or distributor; see the Tektronix web site for a list of offices.**

General Safety Summary

Review the following safety precautions to avoid injury and prevent damage to this product or any products connected to it. To avoid potential hazards, use this product only as specified.

Only qualified personnel should perform service procedures.

While using this product, you may need to access other parts of the system. Read the *General Safety Summary* in other system manuals for warnings and cautions related to operating the system.

To Avoid Fire or Personal Injury

Use Proper Power Cord. Use only the power cord specified for this product and certified for the country of use.

Use Proper Voltage Setting. Before applying power, ensure that the line selector is in the proper position for the power source being used.

Ground the Product. This product is grounded through the grounding conductor of the power cord. To avoid electric shock, the grounding conductor must be connected to earth ground. Before making connections to the input or output terminals of the product, ensure that the product is properly grounded.

Observe All Terminal Ratings. To avoid fire or shock hazard, observe all ratings and markings on the product. Consult the product manual for further ratings information before making connections to the product.

Connect the ground lead of the probe to earth ground only.

Do not apply a potential to any terminal, including the common terminal, that exceeds the maximum rating of that terminal.

Do Not Operate Without Covers. Do not operate this product with covers or panels removed.

Use Proper Fuse. Use only the fuse type and rating specified for this product.

Avoid Exposed Circuitry. Do not touch exposed connections and components when power is present.

Wear Eye Protection. Wear eye protection if exposure to high-intensity rays or laser radiation exists.

Do Not Operate With Suspected Failures. If you suspect there is damage to this product, have it inspected by qualified service personnel.

Do Not Operate in Wet/Damp Conditions.

Do Not Operate in an Explosive Atmosphere.

Keep Product Surfaces Clean and Dry.

Provide Proper Ventilation. Refer to the manual’s installation instructions for details on installing the product so it has proper ventilation.

Symbols and Terms

Terms in this Manual. These terms may appear in this manual:



WARNING. *Warning statements identify conditions or practices that could result in injury or loss of life.*



CAUTION. *Caution statements identify conditions or practices that could result in damage to this product or other property.*



Terms on the Product. These terms may appear on the product:

DANGER indicates an injury hazard immediately accessible as you read the marking.

WARNING indicates an injury hazard not immediately accessible as you read the marking.

CAUTION indicates a hazard to property including the product.

Symbols on the Product. The following symbols may appear on the product:



TLACAL1 & TLACAL2 Performance Verification Fixture Instructions

The TLACAL1 performance verification fixture is designed for use with the TLA5000 series logic analyzer mainframe and P64xx logic analyzer probes; the TLACAL2 performance verification fixture is designed for use with the TLA7Axx series logic analyzer modules and the P68xx series logic analyzer probes. Each test fixture uses unique software to complete the performance verification and certification procedures for the respective logic analyzer hardware and probes.

Refer to the appropriate service manual for performance verification and certification procedures. For the TLACAL1, refer to the *TLA5000 Series Logic Analyzer Mainframe Service Manual*; for the TLACAL2, refer to the *TLA7Axx Logic Analyzer Module Service Manual*.

Parts and Accessories

Table 1 lists the parts and accessories that accompany the performance verification fixtures. Use this table to verify that you have all of the parts and accessories. If any parts or accessories are missing, contact your local Tektronix representative for information on replacing any missing parts.

Table 1: TLACAL1 & TLACAL2 parts and accessories

Item and description	Tektronix part number
TLACAL1 Performance Verification fixture	
None	-
TLACAL2 Performance Verification fixture	
4 Module Interface Cards	650-4298-00
1 Probe Interface Card	650-4299-00
4 34-pin ribbon cables	174-4678-00
8 MCX-to-MCX coaxial cables	174-4138-00
1 Package of color bands (used with MCX-to-MCX coaxial cables to assist in identification)	016-1315-00
4 P6041 BNC-to-SMB cables	P6041
1 GPIB 2 m cable	012-0991-00
4 BNC to BNC, low-loss, 36-inch 10x cables	174-4595-00
Parts and accessories common to both TLACAL1 and TLACAL2 fixtures	
1 RS-232 serial null modem cable	012-1651-00
1 USB to RS-232 adapter	119-6837-00
1 TLACAL1 & TLACAL2 Performance Verification Fixture Instructions	071-1125-01
1 Certificate of calibration or compliance	-

Required Test Equipment

In addition to the performance verification fixture and accessories, you will need the test equipment listed in Table 2 and the performance verification software to run the performance verification and certification procedures. This equipment must be ordered separately from the performance verification test fixture.

The performance verification software is available on the TLA Application CD that comes with your Tektronix logic analyzer. The software must be installed on the hard disk of your Tektronix logic analyzer mainframe before you can use it. Refer to the *TLA5000 Series Logic Analyzer Mainframe Service Manual* (TLACAL1 fixture) or the *TLA7Axx Logic Analyzer Module Service Manual* (TLACAL2 fixture) for instructions on installing and using the software.

Table 2: Required test equipment

Item and description	Tektronix part number
TLACAL1 Performance Verification	
Tektronix TLA5000 series mainframe	TLA520x
1 Tektronix P6419 probe for every 34 channels on the TLA5000 series logic analyzer mainframe	P6419
TLA5000 Series Logic Analyzer Mainframe Service Manual	071-1236-XX
TLACAL2 Performance Verification	
Tektronix TLA700 Logic Analyzer mainframe	TLA7xx
Tektronix TLA7Axx Logic Analyzer module	TLA7Axx
Tektronix TDS694C Digital Oscilloscope	TDS694C
1 Tektronix P6860 probe for every 34 channels on the TLA7Axx Logic Analyzer module	P6860
TLA7Axx Logic Analyzer Module Service Manual	071-1043-XX
TLACAL1 and TLACAL2 Performance Verification	
iView External Oscilloscope cable kit	012-1614-00
Agilent 34401A Digital Multimeter	-

Options

Table 3 lists both TLACAL1 and TLACAL2 product options and Service Options. These options must be selected at the time of purchase.

Table 3: TLACAL1 and TLACAL2 Options

Option	Tektronix part number	Description
A0	061-0104-00	North American power cord, IEC320, right angle (125 V, 10A)
A1	161-0104-06	Universal European power cord, IEC320, right angle
A2	161-0104-07	United Kingdom power cord, IEC320, right angle
A3	161-0104-05	Australian power cord, IEC320, right angle
A4	161-0104-08	North American power cord, IEC320, right angle (250 V, 10 A)
A5	161-0167-00	Switzerland power cord, IEC320, right angle
A6	161-A005-00	Japanese power cord, IEC320, right angle
A10	161-0306-00	China power cord, IEC320, straight
A99	-	No power cord
C3	-	Initial certification plus two years further certification
C5	-	Initial certification plus four years further certification
D1	-	Test data report
D3	-	Test data report (must order Option C3)
D5	-	Test data report (must order Option C5)
R3	-	Repair warranty extended to cover three years
R5	-	Repair warranty extended to cover five years

Installation Instructions

This section describes line fuse and power cord information for both TLACAL1 and TLACAL2 test fixtures. For detailed installation instructions, connection procedures, and operation procedures, refer to the *TLA5000 Series Logic Analyzer Mainframe Service Manual* (TLACAL1 fixture) or the *TLA7Axx Logic Analyzer Module Service Manual* (TLACAL2 fixture).

Line Fuse Information

Check that the line fuse is correct for your application; see Table 4. The fuse and line cord connector are located at the back of the instrument.



WARNING. To avoid electrical shock, disconnect the power cord before removing the line fuse.

Table 4: TLACAL2 line fuses

Line voltage	Description	Tektronix part number
100 V to 120 V operation	5.0 mm x 20 mm, 1.0 A FAST 250 V	159-0356-00
200 V to 240 V operation	5.0 mm x 20 mm, 0.5 A FAST 250 V	159-0351-00

Setting the Line Voltage or Replacing a Fuse

The line voltage is properly set at the factory. If you need to change the line voltage setting, complete the following steps:

1. Disconnect the power cord at the rear of the instrument.
2. Locate the line selector/fuse holder at the rear of the instrument. The voltage setting appears in the small window on the line selector.
3. Note the fuse setting, either 115 V or 230 V. If you need to change the line voltage selection or if you need to change the line fuse, continue with the following steps.
4. Pry open the latch over the line voltage selector with a small flat-blade screwdriver.
5. Remove the red fuse holder with the flat-blade screwdriver.
6. Remove the fuse. If you are replacing a blown fuse, install the fuse holder and fasten the latch in place.
7. Remove the conversion clip from its current location and install it on the other side of the fuse holder.
8. Turn the fuse holder over.
9. Install the new fuse into the holder (see Table 4 for fuse information).

10. Install the fuse holder.

11. Fasten the latch in place.

Connecting the Line Cord

Connect the line cord to the rear of the instrument. Connect the other end of the line cord to the appropriate power connector.

Additional Installation and Operating Instructions

Refer to the *Performance Verification* chapter of the *TLA5000 Series Logic Analyzer Mainframe Service Manual* (TLACAL1 fixture) or the *TLA7Axx Logic Analyzer Module Service Manual* (TLACAL2 fixture) for detailed installation instructions, connection procedures, and operation procedures.



CAUTION. Do not connect or disconnect any ribbon cables, module interface cards, or the probe interface card to or from the test fixture while power is applied. Doing so will damage the fixture, the module interface cards, or the probe interface card. Refer to the *TLA7Axx Logic Analyzer Module Service Manual* for complete installation instructions.

Performance Verification Fixture Service

Both the TLACAL1 and TLACAL2 fixtures are calibrated at the factory. No additional calibration is required. If your fixture requires servicing or calibration you must return the fixture and all accessories to Tektronix.

Preventive Maintenance

Preventive maintenance mainly consists of periodic cleaning. Periodic cleaning reduces instrument breakdown and increases reliability. Clean the instrument as needed, based on the operating environment. Dirty conditions may require more frequent cleaning than computer room conditions.

Clean the exterior surfaces with a dry, lint-free cloth or a soft-bristle brush. If dirt remains, use a cloth or swab dampened with a 75% isopropyl alcohol solution. A swab is useful for cleaning in narrow spaces around the controls and connectors. Do not use abrasive compounds on any part of the instrument.



CAUTION. Avoid getting moisture inside the instrument during external cleaning; use only enough solution to dampen the cloth or swab.

Use only deionized water when cleaning. Use a 75% isopropyl alcohol solution as a cleanser and rinse with deionized water.

Do not use chemical cleaning agents; they may damage the instrument. Avoid chemicals that contain benzene, toluene, xylene, acetone, or similar solvents.

Specifications

The Table 5 provides abbreviated information on performance verification fixture specifications. For detailed specifications, refer to the *TLA5000 Series Logic Analyzer Mainframe Service Manual* (TLACAL1 fixture) or the *TLA7Axx Logic Analyzer Module Service Manual* (TLACAL2 fixture).

Table 5: Performance verification test fixture characteristics

Characteristic	Description
Power consumption	40 W maximum
Source voltage and frequency	100 V _{RMS} to 240 V _{RMS} ±10%, 50 Hz to 60 Hz ±10%, continuous range CAT II 115 V _{RMS} ±10%, 400 Hz, ±10%, continuous range CAT II
Cooling clearance	51 mm (2 inches) front, sides, and rear.
Temperature: Operating and nonoperating	Operating: +20 °C to +30 °C Nonoperating: +5 °C to +50 °C, 15 °C/hr maximum gradient, non-condensing.
Relative Humidity: Operating and nonoperating	Operating: 20% to 80% relative humidity, non-condensing. Maximum wet bulb temperature: +29 °C (derates relative humidity to approximately 22% at +50 °C). Nonoperating: 8% to 80% relative humidity, non-condensing. Maximum wet bulb temperature: +29 °C (derates relative humidity to approximately 22% at +50 °C).
Altitude: Operating and nonoperating	Operating: To 3040 m (10,000 ft.), derated 1° C per 305 m (1000 ft.) above 1524 m (5000 ft.) altitude. Nonoperating: 12190 m (40,000 ft.)

Table 6: TLACAL1 and TLACAL2 Performance verification and adjustment fixture certifications and compliances

Category	Standards or description
EC Declaration of Conformity - Low Voltage	<p>Compliance was demonstrated to the following specification as listed in the Official Journal of the European Communities:</p> <p>Low Voltage Directive 73/23/EEC, amended by 93/68/EEC</p> <p>EN 61010-1/A2:1995 Safety requirements for electrical equipment for measurement control and laboratory use.</p>
U.S. Nationally Recognized Testing Laboratory Listing	<p>UL3111-1 Standard for electrical measuring and test equipment.</p>
Canadian Certification	<p>CAN/CSA C22.2 No. 1010.1 Safety requirements for electrical equipment for measurement, control, and laboratory use.</p>
Additional Compliance	<p>IEC61010-1/A2:1995 Safety requirements for electrical equipment for measurement, control, and laboratory use.</p>
Installation (Overvoltage) Category Descriptions	<p>Terminals on this product may have different installation (overvoltage) category designations. The installation categories are:</p> <p>CAT III Distribution-level mains (usually permanently connected). Equipment at this level is typically in a fixed industrial location.</p> <p>CAT II Local-level mains (wall sockets). Equipment at this level includes appliances, portable tools, and similar products. Equipment is usually cord-connected.</p> <p>CAT I Secondary (signal level) or battery operated circuits of electronic equipment.</p>
Pollution Degree	<p>Pollution Degree 2 (as defined in IEC 61010-1). Note: Rated for indoor use only.</p>
Pollution Degree Descriptions	<p>A measure of the contaminates that could occur in the environment around and within a product. Typically the internal environment inside a product is considered to be the same as the external. Products should be used only in the environment for which they are rated.</p> <p>Pollution Degree 1 No pollution or only dry, nonconductive pollution occurs. Products in this category are generally encapsulated, hermetically sealed, or located in clean rooms.</p> <p>Pollution Degree 2 Normally only dry, nonconductive pollution occurs. Occasionally a temporary conductivity that is caused by condensation must be expected. This location is a typical office/home environment. Temporary condensation occurs only when the product is out of service.</p> <p>Pollution Degree 3 Conductive pollution, or dry, nonconductive pollution that becomes conductive due to condensation. These are sheltered locations where neither temperature nor humidity is controlled. The area is protected from direct sunshine, rain, or direct wind.</p> <p>Pollution Degree 4 Pollution that generates persistent conductivity through conductive dust, rain, or snow. Typical outdoor locations.</p>
Equipment Type	<p>Test and measuring</p>
Safety Class	<p>Class 1 (as defined in IEC 61010-1, Annex H) - grounded product</p>
Overvoltage Category	<p>Overvoltage Category II (as defined in IEC 61010-1, Annex J)</p>