



**SignalVu-PC**  
**Vector Signal Analysis Software**  
**Printable Help**



077-0720-12







**SignalVu-PC**  
**Vector Signal Analysis Software**  
**Printable Help**

Copyright © Tektronix. All rights reserved. Licensed software products are owned by Tektronix or its subsidiaries or suppliers, and are protected by national copyright laws and international treaty provisions.

Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supersedes that in all previously published material. Specifications and price change privileges reserved.

TEKTRONIX and TEK are registered trademarks of Tektronix, Inc.

Application help version: 076-0281-12

### **Contacting Tektronix**

Tektronix, Inc.  
14150 SW Karl Braun Drive  
P.O. Box 500  
Beaverton, OR 97077  
USA

For product information, sales, service, and technical support:

- In North America, call 1-800-833-9200.
- Worldwide, visit [www.tek.com](http://www.tek.com) to find contacts in your area.

# Table of Contents

## Welcome

Welcome .....	1
---------------	---

## Software and documentation

How to install product software .....	3
How to activate and purchase new application licenses (options) .....	3
How to install a license .....	5
How to return a license .....	6
How to move a license to a different host .....	7
How to activate legacy options (application licenses) .....	8
How to activate options in free trial (evaluation) mode .....	10
How to manage legacy option licenses .....	11
Available application options .....	11
Features by product .....	14
Documentation and support	
Available product documentation .....	14
Available demonstration guides .....	15
Video tutorials .....	17

## Orientation

Selecting Files for Analysis .....	19
Right-Click Action Menu .....	19
Elements of the Display .....	21

## Using SignalVu-PC

Restoring Default Settings .....	25
Presets .....	25
Settings Options .....	33
Connectivity .....	35

## Using the Measurement Displays

Selecting Displays .....	41
--------------------------	----

## Available Measurements

Measurements	
Available Measurements .....	43

## General Signal Viewing

Overview .....	53
DPX	
DPX primer .....	53
DPX display overview .....	74
DPX display .....	74
DPX settings .....	80
Time Overview	
Time Overview Display .....	89
Time Overview Settings .....	90
Navigator View .....	92
Spectrum	
Spectrum Display .....	95
Spectrum Settings .....	97
Spectrogram	
Spectrogram Display .....	99
Spectrogram Settings .....	101
Amplitude Vs Time	
Amplitude Vs Time Display .....	105
Amplitude Vs Time Settings .....	106
Frequency Vs Time	
Frequency Vs Time Display .....	107
Frequency Vs Time Settings .....	108
Phase Vs Time	
Phase Vs Time Display .....	109
Phase Vs Time Settings .....	110
RF I & Q Vs Time	
RF I & Q vs Time Display .....	111
RF I & Q vs Time Settings .....	112
Common Controls for General Signal Viewing Displays	
General Signal Viewing Shared Measurement Settings .....	113

## Analog Modulation

Overview .....	127
AM	
AM Display .....	127
AM Settings .....	128
FM	
FM Display .....	133
FM Settings .....	135
PM	
PM Display .....	141

PM Settings.....	143
------------------	-----

## RF Measurements

Overview .....	151
Channel Power and ACPR	
Channel Power and ACPR (Adjacent Channel Power Ratio) Display.....	151
Channel Power and ACPR Settings .....	154
Signal Strength Display	
Signal Strength Display .....	157
Signal Strength Settings.....	158
MCPR	
MCPR (Multiple Carrier Power Ratio) Display .....	164
MCPR Settings.....	168
Occupied BW & x dB BW	
Occupied BW & x dB BW Display.....	175
Occupied BW & x dB BW Settings .....	178
Spurious	
Spurious display .....	179
Spurious display settings.....	184
CCDF	
CCDF Display.....	191
CCDF Settings .....	192
Settling Time Measurements	
Settling Time Measurement Overview .....	195
Settling Time Displays	
Settling Time Displays .....	199
Settling Time Settings .....	207
Common Controls for Settling Time Displays	
Settling Time Displays Shared Measurement Settings .....	207
SEM (Spectrum Emission Mask)	
SEM Display .....	215
Spectrum Emission Mask Settings.....	219
Common Controls for RF Measurements Displays	
RF Measurements Shared Measurement Settings.....	226

## Tracking Generator

Tracking Generator .....	233
How to use the Transmission Gain display .....	233
Transmission Gain Settings	
Transmission Gain Display Settings .....	237

## Calibration for Cable Loss, Return Loss, and DTF measurements

Calibration for Cable Loss, Return Loss, and DTF measurements .....	243
Calibration types.....	243
How to perform a new calibration .....	244
How to load a User calibration.....	249
How to load a Factory calibration .....	249
How to save a calibration .....	251
Calibration status messages .....	255

## Return Loss Measurements

Return Loss measurements overview .....	257
How to make a Cable Loss measurement.....	257
How to make a Return Loss measurement.....	261
How to make a Distance to Fault measurement.....	264
How to change the vertical scale units .....	267
How to select the appropriate settings for DTF Setup.....	268
How to improve the display of distance to fault measurements.....	269
How to improve the resolution of distance to fault measurements.....	270
RL/DTF display overview .....	270

## Cable Loss Display Settings

## RL/DTF Display Settings

## WLAN Measurements

WLAN Overview.....	293
WLAN Chan Response	
WLAN Channel Response Display .....	295
WLAN Channel Response Settings.....	297
WLAN Constellation	
WLAN Constellation Display .....	298
WLAN Constellation Settings.....	299
WLAN EVM	
WLAN EVM Display .....	300
WLAN EVM Settings.....	301
WLAN Mag Error	
WLAN Magnitude Error Display .....	302
WLAN Magnitude Error Settings.....	303
WLAN Phase Error	
WLAN Phase Error Display .....	304
WLAN Phase Error Settings.....	305
WLAN Power vs Time	

WLAN Power vs Time Display .....	306
WLAN Power vs Time Settings.....	308
WLAN Spectral Flatness	
WLAN Spectral Flatness Display .....	309
WLAN Spectral Flatness Settings .....	310
WLAN Summary	
WLAN Summary Display .....	311
WLAN Summary Settings .....	315
WLAN Symb Table	
WLAN Symbol Table Display .....	316
WLAN Symbol Table Settings .....	318
Common Controls for WLAN Analysis Displays	
WLAN Analysis Shared Measurement Settings .....	318

## 802.11 ad Analysis

Overview of 802.11ad.....	329
802.11ad measurements.....	332
802.11ad displays .....	333
802.11ad Constellation Display	
802.11ad Constellation Display .....	333
802.11ad EVM vs Time	
802.11ad EVM vs Time .....	337
802.11ad Symbol Table	
802.11ad Symbol Table Display .....	339
802.11ad Summary	
802.11ad Summary Display .....	341
802.11ad Control Panel Settings	
802.11ad Control Panel Settings .....	344

## OFDM Analysis

Overview .....	355
OFDM Chan Response	
OFDM Channel Response Display .....	355
OFDM Channel Response Settings.....	357
OFDM Constellation	
OFDM Constellation Display .....	358
OFDM Constellation Settings .....	359
OFDM EVM	
OFDM EVM Display .....	359
OFDM EVM Settings .....	361
OFDM Flatness	
OFDM Spectral Flatness Display .....	361

OFDM Spectral Flatness Settings.....	363
OFDM Mag Error	
OFDM Magnitude Error Display .....	363
OFDM Magnitude Error Settings .....	365
OFDM Phase Error	
OFDM Phase Error Display .....	365
OFDM Phase Error Settings .....	367
OFDM Power	
OFDM Power Display .....	367
OFDM Power Settings .....	369
OFDM Summary	
OFDM Summary Display.....	369
OFDM Summary Settings .....	371
OFDM Symb Table	
OFDM Symbol Table Display.....	372
OFDM Symbol Table Settings .....	373
Common Controls for OFDM Analysis Displays	
OFDM Analysis Shared Measurement Settings.....	373

## **Pulsed RF**

Overview .....	381
Cumulative Histogram Display	
Cumulative Histogram Display .....	383
Cumulative Histogram display settings .....	385
Cumulative Statistics Table	
Cumulative Statistics Table display.....	387
Cumulative Statistics Table display settings .....	390
Pulse-Ogram	
Pulse-Ogram display .....	390
Pulse-Ogram display settings.....	392
Pulse Table Display	
Pulse Table display .....	392
Pulse Table display settings.....	394
Pulse Trace Display	
Pulse Trace display .....	394
Pulse Trace display settings .....	396
Pulse Statistics	
Pulse Statistics display .....	396
Pulse Statistics settings.....	399
Common Controls for Pulsed RF Displays	
Pulsed RF Measurement Settings .....	400



## EMC Accessories

EMC accessories .....	419
Radiated tests introduction .....	420
EMI-BICON-ANT (ABF-900A biconical antenna) .....	422
EMI-TRIPOD (AT-812 antenna tripod).....	424
EMI-CLP-ANT (ALC-100 Log Periodic Dipole Array (antenna) .....	425
EMI-PREAMP (PAM-103 preamplifier).....	427
Radiated pre-compliance test setup (30 MHz to 300 MHz) .....	428
Radiated pre-compliance test setup (300 MHz to 1 GHz) .....	431
Conducted tests introduction .....	433
EMI-LISN50UH (TBLC08 Line Impedance Stabilization Network) .....	436
CABLE (coaxial Type N to Type N) .....	437
EMI-LISN5UH (TBOH01 Line Impedance Stabilization Network) .....	437
EMI-TRANS-LIMIT (LIT-153A transient limiter).....	438
EMI-NF-AMP (TBWA2 amplifier).....	439
EMI-NF-PROBE (TBPS01 near field probe set).....	440
Accounting for accessories contributions in EMCVu software.....	441

## EMC Analysis

Introduction .....	443
EMC standards .....	443
Key features .....	444
How to open EMCVu .....	445
Pre-compliance	
Pre-compliance .....	447
How to perform an EMC pre-compliance test.....	448
EMC Project Setup Wizard .....	452
Measure ambient .....	467
Re-measure spot .....	469
Generating and saving reports.....	470
Troubleshooting	
EMC Troubleshooting .....	474
Harmonic Markers .....	475
Inspect.....	476
Level Target .....	480
Compare Traces .....	480
Persistence Display .....	484
EMC-EMI-display	
EMC-EMI display .....	484
EMC-EMI settings	
EMC-EMI settings.....	489
Accessories setup	

## EMC Ranges &amp; Limits tab

**APCO P25 Analysis**

APCO P25 Analysis.....	523
Overview .....	523
P25 Standards Presets .....	524
P25 Displays .....	525
P25 Measurements.....	526
P25 Test Patterns.....	534
P25 Constellation	
P25 Constellation Display .....	537
P25 Constellation Settings .....	539
P25 Eye Diagram	
P25 Eye Diagram Display .....	540
P25 Eye Diagram Settings .....	542
P25 Power vs Time	
P25 Power vs Time Display .....	543
P25 Power vs Time Settings .....	544
P25 Summary	
P25 Summary Display .....	545
P25 Summary Settings .....	548
P25 Symbol Table	
P25 Symbol Table Display.....	548
P25 Symbol Table Settings .....	551
P25 Frequency Deviation Vs Time	
P25 Frequency Dev vs Time Display.....	552
P25 Frequency Dev Vs Time Settings.....	554
Common Controls for P25 Analysis Displays	
P25 Analysis Shared Measurement Settings.....	555

**LTE Analysis**

LTE Analysis.....	567
Overview .....	567
LTE Standards preset test setups .....	568
LTE displays.....	573
LTE measurements .....	573
LTE Status Messages .....	580
LTE ACLR	
LTE ACLR display .....	580
LTE ACLR Settings .....	583
LTE Channel Spectrum	
LTE Channel Spectrum display .....	583

LTE Channel Spectrum Settings .....	585
LTE Constellation	
LTE Constellation display .....	585
LTE Constellation Settings .....	587
LTE Power vs Time	
LTE Power vs Time display .....	587
LTE Power vs Time Settings .....	589
Common Controls for LTE Analysis Displays	
LTE Analysis Measurement Settings .....	589

## Bluetooth Analysis

Bluetooth Analysis .....	607
Overview .....	607
Bluetooth Standards presets .....	609
Bluetooth displays .....	611
Bluetooth measurements and test setups .....	612
Bluetooth Status Messages .....	617
Bluetooth (BT) Constellation	
Bluetooth Constellation display .....	618
BT Constellation Settings .....	620
Bluetooth (BT) Eye Diagram	
Bluetooth Eye Diagram display .....	621
BT Eye Diagram Settings .....	623
Bluetooth (BT) CF Offset and Drift	
Bluetooth Carrier Frequency Offset and Drift display .....	624
BT CF Offset and Drift Settings .....	626
Bluetooth (BT) Summary	
Bluetooth Summary display .....	627
BT Summary Settings .....	631
Bluetooth (BT) Symbol Table	
Bluetooth Symbol Table display .....	631
BT Symbol Table Settings .....	635
Bluetooth (BT) Frequency Deviation Vs Time	
Bluetooth Frequency Dev vs Time display .....	635
BT Frequency Dev Vs Time Settings .....	639
Bluetooth (BT) 20dB Bandwidth	
Bluetooth 20dB Bandwidth display .....	639
BT 20dB BW settings .....	641
Bluetooth (BT) InBand Emission	
Bluetooth InBand Emission display .....	642
Common Controls for Bluetooth Analysis Displays	
Bluetooth Analysis Measurement Settings .....	644

## Audio Analysis

Overview .....	659
Audio Spectrum	
Audio Spectrum Display .....	659
Audio Spectrum Settings .....	660
Audio Summary	
Audio Summary Display .....	661
Audio Summary Settings .....	662
Common Controls for Audio Analysis Displays	
Audio Analysis Measurement Settings .....	663

## Audio Demodulation

Audio Demodulation .....	673
--------------------------	-----

## GP Digital Modulation

Overview .....	675
Constellation	
Constellation Display .....	676
Constellation Settings .....	677
Demod I & Q vs Time	
Demod I & Q vs Time Display .....	678
Demod I & Q vs Time Settings .....	680
EVM vs Time	
EVM vs Time Display .....	680
EVM vs Time Settings .....	681
Eye Diagram	
Eye Diagram Display .....	682
Eye Diagram Settings .....	684
Frequency Deviation vs Time	
Frequency Deviation vs Time Display .....	684
Frequency Deviation vs Time Settings .....	686
Magnitude Error vs Time	
Magnitude Error vs Time Display .....	687
Magnitude Error vs Time Settings .....	688
Phase Error vs Time	
Phase Error vs Time Display .....	689
Phase Error vs. Time Settings .....	690
Signal Quality	
Signal Quality Display .....	691
Signal Quality Settings .....	696
Symbol Table	
Symbol Table Display .....	697

Symbol Table Settings.....	698
Trellis Diagram	
Trellis Diagram Display.....	699
Trellis Diagram Settings .....	701
Common Controls for GP Digital Modulation Displays	
GP Digital Modulation Shared Measurement Settings .....	701
Standard Settings Button.....	702
Symbol Maps	
Symbol Maps.....	719
User Filters	
Overview: User Defined Measurement and Reference Filters.....	725
User Filter File Format.....	726

## Marker Measurements

Using Markers	
Using Markers.....	729
Controlling Markers with the Right-Click Actions Menu.....	729
Measuring Frequency and Power in the Spectrum Display .....	731
Common Marker Actions	
Marker Action Controls .....	732
Peak.....	732
Next Peak .....	732
Marker to Center Frequency .....	732
Define Markers Control Panel	
Enabling Markers and Setting Marker Properties .....	732
Markers Toolbar	
Using the Markers Toolbar.....	734
Noise Markers in the Spectrum Display	
Measuring Noise Using Delta Markers in the Spectrum Display.....	735

## Mask Testing

The Mask Test Tool .....	739
Mask Test Settings.....	739
Define Tab (Mask Test) .....	739
Actions Tab.....	744

## Analyzing Data

Analysis Settings	
Analysis Settings.....	745
Analysis Time Tab.....	745
Spectrum Time Tab .....	747
Frequency Tab.....	747

Units Tab.....	750
Analyzing Data Using Replay	
Replay Overview .....	751
Replay Menu .....	753
Acq Data.....	754
DPX Spectra.....	754
Replay All Selected Records .....	754
Replay Current Record.....	755
Replay from Selected.....	755
Pause .....	755
Stop.....	755
Select All .....	755
Select Records from History.....	755
Replay Toolbar .....	756

## **Amplitude Corrections**

Amplitude Settings .....	759
Internal Settings Tab .....	759
External Gain/Loss Correction Tab.....	760
External Gain Value .....	760
Apply External Corrections To.....	760
External Loss Tables .....	761

## **Controlling the Acquisition of Data**

Acquisition Controls in the Run Menu	
Continuous Versus Single Sequence.....	765
Run .....	765
Resume.....	765
Abort .....	766
Acquisition Controls in the Acquire Control Panel	
Acquire.....	766
IQ Sampling Parameters .....	767
Acquisition Data .....	768
Advanced .....	769
Frequency Reference .....	770
Timing Reference.....	772
Acquisition Controls in the Recording Control Panel	
The Recording Control Panel.....	773
Record Setup .....	774
Record.....	777
Playback .....	780
Using Triggers to Capture Just What You Want	

Triggering	
Triggering .....	781
Frequency Mask Trigger .....	784
Mask Editor (Frequency Mask Trigger) .....	784
Trigger Settings .....	787
Event Tab .....	788
Advanced Tab (Triggering) .....	793
Actions Tab (Triggering) .....	794
<b>GNSS and Antenna Features</b>	
How to set up GNSS .....	795
How to use the Antenna feature .....	797
How to use Map It .....	803
<b>Configure In/Out and IQ Streaming</b>	
IQ Streaming overview .....	807
IQ Streaming API .....	808
40 GbE IQ Streaming Ethernet .....	809
IQ Streaming LVDS .....	810
<b>Signal Database and Channel Navigation</b>	
How to use the Signal Database .....	813
Channel Navigation toolbar .....	816
<b>Signal Classification</b>	
Signal Classification .....	819
How to classify a signal .....	819
Signal Survey toolbar .....	827
The Signal Survey Editor .....	828
The Define Survey control panel .....	829
The Declare Region window (classify) .....	831
<b>Managing Data, Settings, and Pictures</b>	
Saving and Recalling Data, Settings, and Pictures .....	833
Data, Settings, and Picture File Formats .....	840
Printing Screen Shots .....	844
<b>Reference</b>	
Application Help .....	845
About the Vector Signal Analysis Software .....	845
Mapping Measurements	
Mapping Measurements .....	846

Menus	
Main menu overview .....	846
File Menu	
File Menu .....	848
View Menu	
View Menu .....	852
Run Menu	
Run Menu .....	856
Replay	
Replay Menu .....	857
Markers Menu	
Markers Menu .....	857
Setup Menu	
Setup Menu .....	857
Presets Menu	
Presets Menu .....	858
Tools Menu	
Tools Menu .....	858
Battery Status	
Battery Status tab .....	860
Connect menu	
Connect menu .....	862
Window menu	
Window menu .....	862
Help Menu	
Help Menu .....	863
PI Command Search	
PI Command Search tool .....	863
Favorites bar	
Favorites bar menus .....	864
Troubleshooting	
Error and Information Messages .....	864
Displaying the Windows Event Viewer .....	871
Upgrading the Product Software	
How to Find Out if Software Upgrades are Available .....	872
Changing Settings	
Settings .....	872

## Glossary

## Index



## Welcome

This Help provides in-depth information on how to use the SignalVu-PC Vector Signal Analysis Software.

Using the signal analysis engine of the RSA5100 and RSA6100 Series real-time signal analyzer, this vector signal analysis software helps you move your analysis of acquisitions off the instrument.

SignalVu-PC allows you to connect to the RSA306B, RSA500A series, RSA600A series, and RSA7100A spectrum analyzers. With Option CON installed, you can also connect to a MDO4000B/C series oscilloscope to acquire live data. Several features and settings become available in SignalVU-PC once connected to one of these instruments. These are noted where appropriate throughout this Help document.

---

**NOTE.** *Some of the screen illustrations in this document are taken from the vector signal analysis software version that runs on the RSA5100 Series Real-time Signal Analyzers. These instruments support additional hardware-based functionality and buttons that are not present in the SignalVu™ or SignalVu-PC application.*

---



## How to install product software

The SignalVu-PC product software is made up of the base software and any additionally purchased applications software (licensed optional software). The base software provides access to the standard SignalVu-PC applications. It is available for download, free of charge, from the Tektronix Web site at [www.Tek.com/downloads](http://www.Tek.com/downloads). Once you have the base version, you can purchase licenses for optional SignalVu-PC applications or choose to activate 30-day free trials of those applications.

SignalVu-PC optional applications (purchased after December 4, 2015) are controlled via license files, rather than the previous method of installing license keys.

SignalVu-PC licenses can be associated with and stored on either your PC or any RSA300 series, RSA500 series, RSA600 series, and RSA7100A spectrum analyzers. Two types of licenses (Node-locked and Floating) are available, and there are three methods to purchase them, (1) as an option to your hardware, or separately as a (2) Node-locked or (3) Floating license. Licenses are managed using the Tektronix Asset Management System (AMS) on Tek.com. If your licenses are purchased as an option to your instrument, use of the Tektronix AMS is not required for you to use them. Just connect the instrument to your PC with SignalVu-PC, and the licenses will be recognized automatically.

Tektronix is working to make it easier for you to manage the options you purchase for SignalVu-PC. If you purchase an optional license after December 4, 2015, you will set up a product license account that allows you to manage your product licenses. However, you can still activate or reactivate any options you have already purchased using the same option keys in the same way.

---

**NOTE.** *Options purchased prior to December 4, 2015 are referred to as legacy options.*

---

You will find the information you need to activate currently held legacy option licenses, newly purchased option licenses, and free trial licenses in the Help topics below:

- [How to activate and purchase new application licenses \(options\) \(see page 3\)](#)
- [How to activate legacy options \(application licenses\) \(see page 8\)](#)
- [How to activate options in free trial evaluation mode \(see page 10\)](#)
- [How to manage legacy option licenses \(see page 11\)](#)
- [List of available application options \(see page 11\)](#)

## How to activate and purchase new application licenses (options)

A variety of optional, licensed applications are available for purchase for SignalVu-PC. These licenses can be associated with and stored on either your PC or any RSA300 series, RSA500 series, RSA600 series, and RSA7100A spectrum analyzers. Licenses can be purchased as an option to your hardware, or separately as a Node-locked or a Floating license.

Contact your local Tektronix Account Manager to purchase a license. If your purchased license is not ordered as an option to your instrument, you will receive an email with a list of the applications purchased and the URL to the Tektronix Product License Web page, where you will create an account and can then manage your licenses using the Tektronix Asset Management System (AMS): <http://www.tek.com/products/product-license>.

AMS provides an inventory of the license(s) in your account. It enables you to check out or check in a license and view the history of licenses.

---

**NOTE.** *If you purchased licenses as options to the RSA7100A, these licenses are pre-installed on the instrument. No activation or installation is required.*

---

Optional applications are enabled by one of the following license types.

License type	Description
Node locked license (NL) purchased as an option to your instrument	<p>This license is initially assigned to a specific host id, which can be either a PC or an instrument. It can be reassigned to either a PC or another spectrum analyzer two times using Tek AMS.</p> <p>When associated with an instrument, this license is factory-installed on that instrument at the time of manufacture. It will be recognized by any PC operating with SignalVu-PC when the instrument is connected. However, the licensed application is deactivated from the PC if the licensed instrument is disconnected.</p> <p>This is the most common form of licensing, as it simplifies management of your applications.</p>
Node locked license (NL) purchased separately	<p>This license is initially assigned to a specific host id, which can be either a PC or an instrument. It can be reassigned to either a PC or instrument two times using Tek AMS.</p> <p>This license is delivered via email and is associated with either your PC or with an instrument when you install the license.</p> <p>This license should be purchased when you want your license to stay on your PC, or if you have an existing USB instrument on which you would like to install a license.</p>
Floating license (FL) purchased separately	<p>This license can be moved between different host ids, which can be either PCs or instruments. It can be reassigned to different PCs or instruments an unlimited number of times using Tek AMS.</p> <p>This license is delivered via email and is associated with either your PC or with an instrument when you install the license.</p> <p>This is the most flexible license and is recommended in applications where the license needs to be moved frequently.</p>

You can view a list of the currently installed application licenses and options in your product as follows:

- Select **Tools > Licenses > Manage** from the application's main toolbar.
- Select **Help > About Tektronix Real Time Signal Analyzer** to view a list of the installed options.


## How to install a license

Before installing an application license, you must first have purchased one and downloaded the license to your product or a portable memory device. The following instructions include information about how to download and purchase licenses.


(See [List of available application options](#).)

(Visit <http://www.Tek.com/products/product-license>.)

1. Select **Tools > Licenses > Manage** to open the Manage Licenses window.




2. Select **This computer** or other license host from the list on the left side of the window. Notice that the Host ID field will populate with the ID for the selected host. Currently installed licenses associated with that host will also appear in the bottom right panel of the window under Installed Licenses.
3. If you already have a license file (\*.lic) downloaded, click the **Install new license** button and navigate to the license you want to install, and then click **Open**. The license will install and appear in the Installed Licenses list. This task is now complete.

4. If the license you want to install is in your TekAMS system account, do the following:
  - a. Select the host on which you want to install the license from the **Select license host** list. For example, if you want to install the license on the computer, select **This computer**. Notice that the Host ID field on the right will populate with the ID for the selected host.
  - b. Click  to copy the host ID.
  - c. Navigate to the TekAMS system, log in, and enter the host ID in the appropriate field. The Tek AMS system can be accessed from a link on this page <http://www.Tek.com/products/product-license>.
  - d. Follow the instructions online to download the desired license file (\*.lic).
  - e. Once the license is downloaded, perform step 3 above.
5. If you do not have a license yet, do the following:
  - a. Using an Ethernet connection, navigate to [www.Tek.com/products](http://www.Tek.com/products) and find your product.
  - b. Click on the Additional Options tab. This tab lists all available software license options.
  - c. Find the option you want, then click on the related link to download a free trail version.
  - d. Click on the related link to request a quote.
  - e. After your purchase is complete, you will receive instructions for creating a TekAMS account to access and manage your licenses. Once your account is set up, perform step 4 above.


## How to return a license

You can return (uninstall) a license from a particular product as follows:

1. Select **Tools > Licenses > Manage** to open the Manage Licenses window.
2. In the **Manage Licenses** window, select the license you want to return.



3. Click **Uninstall selected license**. The following window will appear.



4. Click **Yes** to uninstall the license. You will then be prompted to save an exit license file. This is the file you will check into (return to) your TekAMS account.
5. Save the exit license file to the desired location.
6. Click **Close**.
7. Navigate to your TekAMS account and check in the saved exit license file.

## How to move a license to a different host

You can return a purchased license and then reassign it to a different host, as indicated below. See the [Available application options](#) topic for a list of available application licenses.

- **Node locked license (NL)**: This license type can be reassigned no more than two times. This allows you to reassign the license in the case of an upgrade to a new Windows platform, for example.
- **Floating license (FL)**: This license type can be reassigned an unlimited number of times.

When assigning a floating license, you need to specify the host id and the duration the feature is to be enabled on the host. After the license expires, the feature is automatically disabled on that host and the license is then available to be assigned to a different host.

- **Free trial license (FT)**: This license type expires after 30 days.

### See also:

<http://www.tek.com/products/product-license>

[How to install a license.](#)


[How to return a license.](#)

## How to activate legacy options (application licenses)

Activating options requires internet access. However, you can activate options on a PC that does not have internet access by using a second PC that does have internet access to contact the license server and use it to download a license file. The license file can then be transferred to the PC on which the option is to be activated. In order to use any options you have purchased for SignalVu-PC, you must activate each option individually one of the following two ways:

### To activate an option with Internet access

1. Launch the SignalVu-PC application.
2. Select **Tools > Licenses > Legacy > Activate...** to view the Activate Legacy License dialog.
3. In the dialog, select **Auto**.



4. In the **Enter Activation Key** text box, enter the option activation key provided when you purchased the option.
5. Click **OK**. SignalVu-PC will contact the license server and install a license file provided by the license server.
6. Repeat the steps above to activate each option, using the activation key specific to each option.


### To activate an option without Internet access

To activate options on a PC without internet access, you need use the Offline Activation Tool. The tool is provided with SignalVu-PC as a separate installation file.



1. Launch the SignalVu-PC application.
2. Select **Tools > Licenses > Legacy > Activate...** to view the Activate Legacy License dialog.

In the dialog, select **Manual**.



3. Write down the **Host ID** shown in your Activate Legacy License dialog, and then click **Cancel** to close the window.
4. Install the **Activation Assistant** software on a PC that has internet access.

The Activation Assistant software is located at:

- If you installed SignalVu-PC from a DVD or USB flash drive, navigate to the device, open the Offline Activation Tool folder, and run the Setup file located there.
  - If you downloaded SignalVu-PC from the Web, navigate to the location you extracted the installation files. Open the Offline Activation Tool folder and run the Setup file located there.
5. Launch the Activation Assistant application and follow the instructions to generate a license file. Repeat this step for each option that you have purchased. You will also need the option activation key you received.

Activation keys are specific to each option, therefore you must acquire a license file for each option purchased.

6. Copy the license file (or files) to the following location the PC on which SignalVu-PC is to be activated:  
`C:\ProgramData\Tektronix\RSA\SignalVu-PC\License`
7. Restart the SignalVu-PC application.

## How to activate options in free trial (evaluation) mode

If you don't have a license for one (or any) SignalVu-PC options, you can activate each option in evaluation mode for 30 days. Trial licenses are available at <https://www.tek.com/product-software-series/signalvu-pc>.

---

**NOTE.** *Each option has its own evaluation period.*

---

To activate an option in evaluation mode:

1. Launch **SignalVu-PC**.
2. Select **Tools > Licenses > Legacy > Manage...** to view the Manage Legacy License dialog.
3. Select the option you want to evaluate, and then click the **Start 30-day evaluation** button.

The Current Status box will change to display the number of days remaining for evaluation. Repeat this procedure for each of the options you wish to evaluate.

## How to manage legacy option licenses


Options are licensed for use on a single PC. However, you can move SignalVu-PC and its options from one PC to another PC by deactivating each option on the current installation and reactivating them on another PC. Each activated option needs to be deactivated as follows:

1. Launch the application.
2. Select **Tools > Licenses > Legacy > Manage...** to view the Manage Legacy License dialog.
3. Use the drop-down list under Option to select one of the options that is activated.

For example: **OFDM Measurements (SignalVu-PC SVO)**.

4. Starting with each installed option, click **Deactivate License**. Continue selecting options and clicking Deactivate License until all the options have been deactivated.

The SignalVu-PC options are now deactivated. You can now install the software on another PC and activate the options in the new installation.



---

**NOTE.** You can view already installed and activated options from the **Tools > Licenses > Legacy > Manage...** window.

---

## Available application options

The following table shows available optional applications for SignalVu-PC.

Application description	Application (option)	License type
AM/FM/PM/Direct Audio Analysis	SVANL-SVPC	Node Locked
	SVAFL-SVPC	Floating

Application description	Application (option)	License type
Settling Time (frequency and phase) measurements	SVTNL-SVPC	Node Locked
	SVTFL-SVPC	Floating
General Purpose Modulation Analysis to work with analyzer of acquisition bandwidth $\leq 40$ MHz and MDO	SVMNL-SVPC	Node Locked
	SVMFL-SVPC	Floating
General Purpose Modulation Analysis to work with analyzer of any acquisition bandwidth	SVMHNL-SVPC	Node Locked
	SVMHFL-SVPC	Floating
800 MHz acquisition bandwidth (for frequencies $> 3.6$ GHz (RSA7100A only))	B800NL-SVPC	Node Locked
	B800FL-SVPC	Floating
Pulse Analysis to work with analyzer of acquisition bandwidth $\leq 40$ MHz and MDO	SVPNL-SVPC	Node Locked
	SVPFL-SVPC	Floating
Pulse Analysis to work with analyzer of any acquisition bandwidth	SVPHNL-SVPC	Node Locked
	SVPHFL-SVPC	Floating
Advanced triggers (Frequency Mask, Density) for the RSA7100A (RSA7100A only)	TRIGHNL-SVPC	Node Locked
	TRIGHFL-SVPC	Floating
EMI Pre-compliance and Troubleshooting	EMCVUNL-SVPC	Node Locked
	EMCVUFL-SVPC	Floating
Flexible OFDM Analysis	SVONL-SVPC	Node Locked
	SVOFL-SVPC	Floating
WLAN 802.11a/b/g/j/p measurements	SV23NL-SVPC	Node Locked
	SV23FL-SVPC	Floating
WLAN 802.11n measurements (Requires SV23NL-SVPC or SV23FL-SVPC)	SV24NL-SVPC	Node Locked
	SV24FL-SVPC	Floating
WLAN 802.11ac measurement to work with analyzer of acquisition bandwidth $\leq 40$ MHz and MDO (Requires SV23NL-SVPC or SV23FL-SVPC and SV24NL-SVPC or SV24FL-SVPC)	SV25NL-SVPC	Node Locked
	SV25FL-SVPC	Floating
WLAN 802.11ac measurement to work with analyzer of any acquisition bandwidth and MDO (Requires SV23NL-SVPC or SV23FL-SVPC and SV24NL-SVPC or SV24FL-SVPC)	SV25HNL-SVPC	Node Locked
	SV25HFL-SVPC	Floating
APCO P25 measurements	SV26NL-SVPC	Node Locked
	SV26FL-SVPC	Floating
Bluetooth measurements <sup>1</sup>	SV27NL-SVPC	Node Locked
	SV27FL-SVPC	Floating
Bluetooth 5 measurements <sup>1</sup> (Requires SV27NL-SVPC or SV27FL-SVPC)	SV31NL-SVPC	Node Locked
	SV31FL-SVPC	Floating
Mapping	MAPNL-SVPC	Node Locked
	MAPFL-SVPC	Floating

Application description	Application (option)	License type
SignalVu-PC connection to the MDO4000B/C series oscilloscopes	CONNL-SVPC	Node Locked
	CONFL-SVPC	Floating
WLAN 802.11a/b/g/j/p/n/ac and option to connect to MDO4000B/C. Works with analyzer of acquisition bandwidth $\leq 40$ MHz and MDO. (This option bundles the following: SV23NL-SVPC or SV23FL-SVPC, SV24NL-SVPC or SV24FL-SVPC, SV25NL-SVPC or SV25FL-SVPC, and CONNL-SVPC or CONFL-SVPC)	SV2CNL-SVPC	Node Locked
	SV2CFL-SVPC	Floating
WLAN 802.11a/b/g/j/p/n/ac and option to connect to MDO4000B/C. Works with analyzer of any acquisition bandwidth. (This option bundles the following: SV23NL-SVPC or SV23FL-SVPC, SV24NL-SVPC or SV24FL-SVPC, SV25HNL-SVPC or SV25HFL-SVPC, and CONNL-SVPC or CONFL-SVPC)	SV2CHNL-SVPC	Node Locked
	SV2CHFL-SVPC	Floating
LTE Downlink RF measurements <sup>2</sup>	SV28NL-SVPC	Node Locked
	SV28FL-SVPC	Floating
WiGig 802.11ad measurements (only for offline analysis)	SV30NL-SVPC	Node Locked
	SV30FL-SVPC	Floating
EMI CISPR detectors	SVQPNL-SVPC	Node Locked
	SVQPFL-SVPC	Floating
Signal survey and classification	SV54NL-SVPC	Node Locked
	SV54FL-SVPC	Floating
Playback of recorded files (RSA500A series and RSA600A series only)	SV56NL-SVPC	Node Locked
	SV56FL-SVPC	Floating
Streaming data to RAID and 40 GbE (RSA7100A only)	STREAMNL-SVPC	Node Locked
	STREAMFL-SVPC	Floating
Streaming IQ data to a custom API application (RSA7100A only)	CUSTOM-APINL-SVPC	Node Locked
	CUSTOM-APIFL-SVPC	Floating
Return loss, VSWR, cable loss, and distance to fault (RSA500A series and RSA600A series only)	SV60NL-SVPC	Node Locked
	SV60FL-SVPC	Floating
Education-only version of all modules for SignalVu-PC	EDUFL-SVPC	Floating

<sup>1</sup> Bluetooth is a registered trademark of Bluetooth SIG, Inc.

<sup>2</sup> LTE is a trademark of ETSI.

**TIP.** See the [Features by product \(see page 14\)](#) topic for more information.

## Features by product

The following table lists a subset of features that may or may not be available for your analyzer when connected to SignalVu-PC. A “√” means the feature is available with the specified product. Some of these features require specific options be installed. You can view a list of options for SignalVu-PC [here \(see page 11\)](#).

Feature	RSA300 Series	RSA500 Series	RSA600 Series	RSA7100A
Audio demodulation (listening)	√	√	√	
DPX Spectrogram (DPXogram)	√	√	√	√
Fast Frame				√
Frequency Mask Trigger				√
DPX Density Trigger				√
Internal GPS		√	√	√
Playback of recorded files (Option SV56-SVPC)	√	√	√	
Playback of recorded files (external application)	√	√	√	√
Tracking generator and return loss, VSWR, cable loss, and distance to fault (Option 04 with SV60-SVPC)		√	√	

## Available product documentation

In addition to this Help, the following documents are available. For the most up to date documentation, visit the Tektronix Web site [www.tektronix.com/manuals](http://www.tektronix.com/manuals).

### Product documents

- **SignalVu-PC Quick Start User Manual** (Tektronix part number 077-1024-XX). This PDF document explains how to install and activate the SignalVu-PC software. The instructions also provide a brief overview of the SignalVu-PC interface to get you started. It is available for download at [www.Tek.com/manuals](http://www.Tek.com/manuals) and can also be accessed from the Help menu in the application.
- **SignalVu-PC Programmer Manual** (077-0721-XX). This PDF document provides detailed descriptions of the remote commands for the SignalVu-PC software and explains how to use the programming interface for SignalVu-PC.
- **SignalVu-PC Printable Help Document (PDF)** (077-0720-XX). A PDF file version of this Help that can be printed.
- **RSA500 Series Installation and Safety Manual** (Tektronix part number 071-3452-XX). This document explains how to install the instrument and battery, connect, and prepare the RSA500 Series

instruments for use. It is available for download at [www.Tek.com/manuals](http://www.Tek.com/manuals) and is shipped as a printed manual with your instrument.

- **WFM200BA Rechargeable Battery Pack Instructions** (Tektronix part number 075-1041-XX). This document contains information for handling, storing, maintaining, recycling, and transporting the WFM200BA Li-Ion rechargeable battery pack. For use with the RSA500 Series instruments.
- **WFM200BC External Battery Charger Instructions** (Tektronix part number 071-1042-XX). This document describes how to use the WFM200BC external battery charger to recharge the WFM200BA Li-Ion battery pack. For use with the RSA500 Series instruments.
- **RSA600 Series Installation and Safety Manual** (Tektronix part number 071-3460-XX). This document explains how to install, connect, and prepare the RSA600 Series instruments for use. It is available for download at [www.Tek.com/manuals](http://www.Tek.com/manuals) and is shipped as a printed manual with your instrument.
- **RSA306B Installation and Safety Manual** (Tektronix part number 071-3483-XX). This document explains how to install, connect, and prepare the RSA306B instrument for use. It is available for download at [www.Tek.com/manuals](http://www.Tek.com/manuals) and is shipped as a printed manual with your instrument.
- **RSA7100 Quick Start User Manual** (Tektronix part number 071-3504-XX). This document explains how to install, connect, and prepare the RSA7100 instrument for use. It also contains some basic operation procedures to get you started. It is available for download at [www.Tek.com/manuals](http://www.Tek.com/manuals) and is shipped as a printed manual with your instrument.
- If you are using an RSA306B, RSA500 Series, RSA600 Series, RSA7100, or MDO4000/B or C Series instrument with SignalVu-PC, you can find more product related documents than those listed above online at [www.Tek.com/manuals](http://www.Tek.com/manuals).

The most recent versions of the product documentation, in PDF format, can be downloaded from [www.Tek.com/manuals](http://www.Tek.com/manuals). You can find the manuals by searching on the product name and selecting the Manuals filter.

## Available demonstration guides

Available for download on [www.Tek.com](http://www.Tek.com).

### ■ Interference Hunting

This demonstration guide shows how spectrum management operators can discover and capture signals of interest, using Swept DPX, with as short as 100 us duration and 100% Probability of Intercept (POI) that would be easily hidden with traditional instruments. DPX can now be used to sweep across the entire instrument's frequency range. With traditional swept spectrum analyzers and vector signal analyzers, only 1 spectrum trace is displayed. With Swept DPX, the instrument dwells at each step to build the entire spectrum with thousands of spectrums displayed in a way that is usable for the engineers or spectrum managers.

### ■ EMC Precompliance and EMC testing

With this demonstration guide, you will explore what you can do with the Tektronix USB spectrum analyzer with EMCVu. Applications range from simple frequency / amplitude measurements of RF

signals to real-time and modulation analysis that provide you with a complete system view of your device under test.

#### ■ **Signal Locating**

RSA Map tool in the Tektronix RSA/SignalVu-PC/SPECMON lets you use an on-screen map to record the location and value of RSA/SignalVu-PC/SPECMON measurements. With RSA Map you can use a GPS receiver to automatically position measurements at your current location on maps with geophysical reference information. The example in this Demo guide uses a free online mapping source OpenStreetMap to capture maps. OpenStreetMap is a collaborative project to create a free editable map of the world. It can capture a map anywhere in the world and can export it in its native format, bitmap image, and embeddable HTML.

#### ■ **LTE**

In this demonstration guide, you will learn how to make LTE downlink measurements either using RSA demo board for base station transmitter tests, or using an antenna for the over-the-air signal analysis.

#### ■ **Internet of Things (IoT)**

In this demonstration guide, you will learn how to use Tektronix USB RSA to make the standard certification tests on IoT devices. Wireless technology standards are needed to ensure that products can interoperate within the ecosystem where they will be deployed. There are a number of technologies to choose from, including Wi-Fi®, Bluetooth®, ZigBee®, and LoRa®. However, to adhere to the standard, new products will need to meet qualification as defined per the standard selected. Failing qualification can mean design turns that will delay the final product release and draw additional significant development cost.

#### ■ **SignalVu-PC**

This demonstration guide is designed to help you understand the benefits of SignalVu PC for analysis of waveforms captured by Tektronix DPO/DSA/MSO Series digital oscilloscopes, MDO4000 Multi-Domain Oscilloscopes and Tektronix Real Time Signal Analyzers. Applications include: CW Tone, Wideband Radar, Hopping Waveforms, Wideband Modulation, Multi-domain oscilloscope acquisitions, AM/FM/PM/Audio Analysis, Signal Monitoring with RTSA waveforms, and WLAN 802.11ac Signal Analysis.



## Video tutorials

You can browse the Tektronix YouTube channel ([www.youtube.com/user/tektronix](http://www.youtube.com/user/tektronix)) to find video tutorials about various topics related to your product. You can also subscribe to the Tektronix YouTube channel to keep up with new postings.

### Searching for topics


For example, you can watch a video tutorial about performing basic EMI testing with a spectrum analyzer, or how to use WLAN presets and connect to an MDO4000B oscilloscope. To find a video on a topic, do the following. The following image shows you what the Tektronix YouTube Channel looks like.

1. Click on the search icon located just above the video you see when the page first loads.

---

**NOTE.** This icon allows you to search the Tektronix YouTube channel specifically. The search icon located at the top of the page allows you to search all of YouTube .

---



2. Type in the key phrase you are looking for in the search field. For example, “WLAN”.
3. Click the search icon to start the search.
4. Videos related to the topic will appear. Click a video to view it.




## Selecting Files for Analysis






The SignalVu-PC software can analyze waveform files saved by Tektronix oscilloscopes and real-time signal analyzers. SignalVu-PC can open several file types, including .wfm, .tiq, .iqd and .mat files. For more detailed information on opening the supported file types, see [Recalling waveforms with SignalVu-PC \(see page 834\)](#).

## Right-Click Action Menu

You can change marker settings and how waveforms are displayed by using the right-click Actions menu.




To use the right-click Actions menu, right-click in the graph area.

Icon	Menu	Description
	Select	Selects markers and adjusts their position.
	Span Zoom	Zooms the graph area about the selected point. Right-click in the graph display at a point of interest and drag to increase or decrease the span about the point of interest. Span Zoom adjusts the span control.
	CF Pan	Adjusts the Center Frequency according to horizontal movement.
	Zoom	Adjusts horizontal and vertical scale of the graph. The first direction with enough movement becomes the primary scale of adjustment. Adjustment in the secondary direction does not occur until a threshold of 30 pixels of movement is crossed.  Dragging to the left or down zooms out and displays a smaller waveform (increases the scale value). Dragging to the right or up zooms in and displays a larger waveform (decreases the scale value).
	Pan	Adjusts horizontal and vertical position of the waveform. The first direction with enough movement becomes the primary direction of movement. Movement in the secondary direction does not occur until a threshold of 30 pixels of movement is crossed.
-	Reset Scale	Returns the horizontal and vertical scale and position settings to their default values.
-	Marker to peak	Moves the selected marker to the highest peak. If no marker is turned on, this control automatically adds a marker.
-	Add marker	Defines a new marker located at the horizontal center of the graph.
-	All markers off	Removes all markers.

### SignalVu-PC Markers Menu


The SignalVu-PC Markers menu appears when you right-click on a marker. The SignalVu-PC Markers menu enables you to assign a marker to a different trace and pan the trace to place the marker at the measurement frequency.



Icon	Menu	Description
-	Pan to marker	Adjusts horizontal position of the waveform to locate the selected marker at the measurement frequency.
-	Assign to trace	Assigns the selected marker to Trace 1, Trace 2, Trace 3 or the Math trace. A trace must be enabled to assign a marker to it.


## Elements of the Display

**General application window areas.** The main areas of the application window are shown in the following figure.




**NOTE.** If values or buttons on the application UI become truncated or displaced, you may need to adjust the Microsoft Windows display settings or custom DPI percentage setting.

**Specific elements of the application display window.** Specific elements of the display are shown in the following figure. More detailed information is available in the [Menus](#) section.



Ref number	Setting	Description
1	Recall	Displays the Open window in order to recall setup files, acquisition data files, or trace files.
2	Save	Opens the Save As dialog in order to save setup files, pictures (screen captures), acquisition data files, or export measurement settings.
3	Undo/Redo	Undoes or redoes the previous edit to a display or measurement settings, a preset, or a measurement change.
4	Displays	Opens the Select Displays dialog box so that you can select measurement displays.
5	Settings	Opens the Settings control panel for the selected display. Each display has its own control panel.
6	Trigger (Only available when connected to an RSA306, RSA306B, RSA500A series, RSA600A series, RSA7100A, or MDO4000B/C.)	Opens the Trigger control panel so that you can define the instrument trigger settings.

Ref number	Setting	Description
7	Acquire	Opens the Acquire control panel, which displays the Sample Rate and Record length of the recalled waveform file.
8	Analysis	Opens the Analysis control panel so that you can define the analysis settings such as frequency, analysis time, and units.
9	Amplitude	Opens the Amplitude control panel so that you can define the Reference Level, configure internal attenuation, and specify external gain/loss corrections.
10	GNSS/Antenna	Opens the GNSS/Antenna control panel so that you can configure and activate an internal or external GNSS receiver and antenna.
11	Audio Demodulation	Opens the Audio control panel so that you can define the audio demodulation settings for the RSA306, RSA306B, RSA500A series, RSA600A series, and RSA7100A.
12	Recording	Opens the Recording control panel so that you can record and configure recording of signals. For detailed information, see the <a href="#">Setup Menu (see page 857)</a> topic.
13	Favorite User Presets	Click to select from a list of custom favorite User presets and load the selected preset. For more detailed information, see the <a href="#">Make a User preset a Favorite preset (see page 28)</a> topic.
14	Main menu bar	Contains access to menus. For detailed information, see the <a href="#">Main Menu (see page 846)</a> topic.
15	Preset	Recalls the <a href="#">Main</a> preset.
16	Replay	Runs a new measurement cycle on the existing acquisition data record using any new settings. See the <a href="#">Replay menu</a> topic for more details.

Ref number	Setting	Description
17	Run and Run/Stop toolbar (Only available when connected to an RSA306, RSA306B, RSA500A series, and RSA600A series, RSA7100A, or MDO4000B/C.)	<ul style="list-style-type: none"> <li>■ Run menu and Run/Stop toolbar Starts and stops data acquisitions and specifies the run conditions. For example, if you select Single in the Run/Stop toolbar (or Run Single in the Run menu), a single measurement cycle is run. If you select Continuous in the Run/Stop toolbar (or Run Continuous in the Run menu), the data acquisition runs until stopped.</li> <li>■ Run menu The Run menu also includes Resume and Abort. Resume restarts data acquisition, but does not reset accumulated results, such as Average or MaxHold. This allows you to stop acquisitions temporarily, then continue. Abort immediately halts the current acquisition/measurement cycle. In-process measurements and acquisitions are not allowed to complete. See the <a href="#">Run menu</a> topic for more details.</li> </ul>
18	:	<p>The Edit Favorites icon allows you access the below menu, which allows you to edit the contents of the Favorites bar. For more information, see the <a href="#">Favorites bar (see page 864)</a> topic.</p> 



## Restoring Default Settings

To restore the software to its factory default settings:

1. Select **Presets > Preset Options**.
2. In the Presets tab of the Options control panel, click to view the **Preset type** drop down menu and select **Main**.
3. Click to view the **Presets** drop down menu and select **Original**.
4. Click the red X icon in the top right corner of the Options control panel to close the panel.
5. Select **Presets > Main** from the menu bar to return the software to its original factory default settings.

---

**NOTE.** You can also click the **Preset** button on the right-hand side of the menu bar to load the Main preset.

---

## Presets

### Main menu bar: Presets

SignalVu-PC includes a set of standard configurations that are tailored to specific applications or types of analysis. These configurations, referred to as Presets, open selected displays and load settings that are optimized to address specific application requirements. You can also make your own User presets to fit your application. Any User preset can be added to the Favorites bar, enabling one-button access to your most used setups.

### Preset Options

Select the **Presets > Preset Options** menu to open the Options control panel. Once you have chosen these settings, you can access any preset or list of presets from **Presets** on the menu bar.

- **Preset type:** Select the Preset type.
- **Presets:** Select the specific preset you want to display for the selected preset type.
- **Preset action:** Selecting a preset from the Preset drop down menu results in one of two actions depending on which item you choose in the **Preset action** list: **Recall selected preset** will immediately execute a preset when it is selected from the Presets menu. **Show list** will display a list of preset subtypes from which you can then select the preset you want to recall.

### Available Presets

Select **Presets** from the menu bar to access the presets shown in the following table. Preset subtypes are managed in the Presets > [Preset Options](#) menu.

Preset	Description
<b>Main</b>	
Current	This Preset sets the analyzer to display a Spectrum display with settings appropriate for typical spectrum analysis tasks.
<a href="#">Original</a>	This Preset is the original factory preset used with your original SignalVu-PC software. This version of the factory preset is included to allow you to maintain compatibility with existing remote control software.
<b>DPX</b>	
(Only available when an RSA306, RSA306B, RSA500A series, RSA600A series, or RSA7100A is connected.)	
Open the DPX display	The Open the DPX display opens the DPX display without closing existing displays.
Swept	The DPX Swept Preset displays the DPX Spectrum display with the span set to maximum and the center frequency set to 1/2 the span.
Real Time	The DPX Real Time Preset displays the DPX Spectrum display with the center frequency set to 1.5 GHz and the span set to the maximum available real-time bandwidth.
<b>Standards</b>	
<a href="#">WLAN</a>	This preset sets the analyzer to display the WLAN Summary, WLAN Constellation, and SEM displays. After you select the standards and bandwidth, the software configures these displays to apply the parameters appropriate for typical WLAN analysis tasks.
<a href="#">APCO P25</a>	This preset sets the analyzer to display the P25 MCPR, Summary, P25 Constellation, and Time Overview displays. After you select the standard and modulation type, the software configures these displays to apply the parameters appropriate for typical P25 analysis tasks.
<a href="#">Bluetooth</a>	This preset loads a set of Bluetooth displays and test setup to perform Bluetooth SIG RF tests. The software configures these displays to apply the parameters appropriate for Bluetooth analysis tasks.
<a href="#">LTE</a>	This preset loads a set of LTE displays and a test setup, frame structure, and channel bandwidth to perform LTE tests. The software configures these displays to apply the parameters appropriate for LTE analysis tasks.
<a href="#">802.11ad</a>	This preset loads a set of standards (Control PHY and Single carrier PHY) for 802.11ad for offline analysis.
<b>Application</b>	
<a href="#">Modulation Analysis</a>	The Modulation Analysis setup application preset provides you with the most common displays used during modulation analysis. Only present when Option 21 is installed.
<a href="#">Pulse Analysis</a>	The Pulse Analysis application preset provides you with the most common displays used during pulse analysis, and makes changes to the default parameters to settings better optimized for pulsed signal analysis.
<a href="#">Time-Frequency Analysis</a>	The Time-Frequency preset configures the analyzer with settings suited to analyzing signal behavior over time.
<a href="#">Spectrum Analysis</a>	The Spectrum Analysis application preset provide you with the settings commonly used for general purpose spectrum analysis.
<a href="#">Spur Search Multi Zone 9k-1GHz</a>	The Spur Search application preset sets the analyzer to display all spurs that exceed the Threshold and Excursion values for the entire 9 kHz through 1 GHz range.
<b>User (Favorites)</b>	

<a href="#">User Preset 1</a>	This preset sets the analyzer to show these displays: Frequency vs Time, Time Overview, Spectrogram, and Spectrum. Settings commonly used for general purpose analysis are loaded.
<a href="#">User Preset 2</a>	This preset sets the analyzer to show the Spurious display. Settings commonly used for spur analysis are loaded.
<a href="#">Interference Hunting</a>	This preset sets the analyzer to show the DPX and Signal Strength displays.
<a href="#">Other user presets</a>	User presets you create and save will appear in the Preset drop down menu of the User Presets window. Any User preset that you have designated as a Favorite will be marked with an *.

## Recalling a Preset


To recall a preset, select **Presets** and then the desired preset type.

**NOTE.** You can set which presets to recall from the Presets > [Preset Options](#) control panel.

**NOTE.** You can also click the Preset button on the top right side of the menu bar to load the Main preset.

## User (Favorites) Presets

Select the **Presets > User (Favorites)** menu to open the User Presets window. The Presets drop-down list shows the three default user presets provided with the software.



- **User Preset 1:** Sets up the Spectrum, Time Overview, Spectrogram, and Frequency vs Time displays.
- **User Preset 2:** Sets up the Spurious display.
- **Interference Hunting:** Sets up the DPX and Signal Strength displays.


## Make a User preset

You can add your own User presets to the list that appears in the User Presets dialog box as follows:


1. Select **Save As** from the **File** menu to open the **Save As** dialog box.
2. Select to save to C:\SignalVu-PC Files\User Presets.
3. Enter a file name. The name you give the file will appear in the User Presets dialog box list.
4. Select Setup file to save from the **Save as type** drop-down list.
5. Click **Save**.



**Make a User preset a Favorite preset.** You can place one or more User presets on the Favorites bar as a Favorite preset for quick access. Do this as follows:


1. Select **Presets > User** to open the User Presets window.
2. Select the desired preset from the Presets drop-down list.
3. Click the **Add Favorite** button. The preset will now have an \* next to it. You can do this for more than one preset.



4. If desired, add a note for this preset in the Notes field and then click the **Save** button. Whenever you recall this preset, this note will appear in a separate window, as shown below.



5. Click the **OK** button in the User Presets window.
6. Click on the  icon on the Favorites bar and you will see the recently added Favorite preset listed.
7. When you are ready to recall a Favorite preset, click  and select the preset from the list that appears.
8. To remove a Favorite preset, select it from the User Presets window and click the **Remove Favorite** button. The \* should disappear from the list.



## Standards Presets

The Standards presets allow you to recall preconfigured displays for the standards that you select. You can select from the following standards groups.

- **WLAN:** The IEEE wireless LAN (WLAN) standards specify the wireless interface between two wireless clients or a wireless client and a base station. The WLAN presets allow you to access displays preconfigured for the WLAN standards and bandwidths you select.

---

**NOTE.** More information is available about WLAN standards [here](#). You can also watch a video tutorial about WLAN Presets at [www.youtube.com/user/tektronix](http://www.youtube.com/user/tektronix). Click [here](#) for information about searching the Tektronix YouTube channel for videos.

---

- **P25:** The Project 25 (P25) TIA-102 standards specify the design of interoperable digital two-way wireless communications products. The P25 presets allow you to access displays preconfigured for the P25 standards you select. You can choose either the Phase 1 (FDMA) standard or the Phase 2 (TDMA) standard.

---

**NOTE.** More information is available about P25 standards [here \(see page 523\)](#).

---

- **Bluetooth:** The Bluetooth standards specify short range RF signals. The Bluetooth presets allow you to access displays preconfigured for the specific Bluetooth standards you select: Basic Rate, Low Energy, and Enhanced Data Rate (EDR).

---

**NOTE.** More information is available about Bluetooth standards [here](#).

---

- **LTE:** The LTE standards ensure that the RF signals meet 3GPP measurements specifications. The LTE presets test setups load pre-configured displays and control setting as suggested by the selected standard to accelerate the test setup of the analyzer.

---

**NOTE.** More information is available about LTE standards and test setups [here](#).

---

### Application Preset: Modulation Analysis

The Modulation Analysis application preset opens the following displays:

- **DPX display:** Shows you a continuous spectrum monitoring of the specified carrier frequency.
- **Signal Quality:** Shows a summary of modulation quality measurements (EVM, rho, Magnitude Error, Phase Error, and others).
- **Constellation:** Shows the I and Q information of the signal analyzed in an I vs Q format.
- **Symbol Table:** Shows the demodulated symbols of the signal.

To use the Modulation Analysis preset (assuming the Preset action is set to Show list in the Presets tab of the Options control panel):

1. Select **Presets > Application**. Select **Modulation Analysis** and then click **OK**.
2. Set the reference level so that the peak of your signal is about 10 dB below the top of the DPX display.
3. Set the modulation parameters for your signal. This includes the Modulation Type, Symbol Rate, Measurement Filter, Reference Filter, and Filter Parameter. All of these settings are accessed by selecting **Tools > Settings**.

For most modulated signals, the Modulation Analysis application preset should present a stable display of modulation quality. Additional displays can be added by selecting **Setup > Displays**, and other settings can be modified to better align with your signal requirements.

### Application Preset: Pulse Analysis

The Pulse Analysis application preset opens the following displays:

- **DPX:** The DPX display is opened with the maximum available span.
- **Time Overview:** Shows amplitude vs. time over the analysis period.

- **Pulse Table:** This shows a full report for the user-selected pulse measurements. If you want to clear the Pulse Table results for a new acquisition, open the Time Overview window and select Autoscale. This causes the pulse table to refresh.
- **Pulse Trace:** Shows the trace of the selected pulse and a readout of the selected measurement from the pulse table.

You can make a selected pulse and measurement appear in the Pulse Trace display by highlighting it in the Pulse Measurement Table. Key pulse-related parameters that are set by the Pulse Analysis application preset are:

- **Measurement Filter:** No Filter-Max BW
- **Measurement Bandwidth:** This is set to the maximum real-time bandwidth of the instrument.

---

**NOTE.** The label on the “Measurement Bandwidth” setting is just “Bandwidth”. Like the main instrument Preset command and the other application presets, the Pulse Analysis application preset also sets most other instrument controls to default values.

---

- **Power threshold to detect pulses:** This is set to –10 dBc.
- **Minimum OFF time between pulses:** This is set to 400.000 ns to ensure a good probability of catching several pulses for typical signals.
- **Max number of pulses:** Check this box to limit the number of pulses to measure.

To use the Pulse Analysis preset (assuming the Preset action is set to Show list in the Presets tab of the Options control panel):

1. Select **Presets > Application**. Select **Pulse Analysis** and then click **OK**.
2. Set the Center Frequency control to the carrier frequency of your pulsed signal.
3. Set the Reference Level to place the peak of the pulse signal approximately 0-10 dB down from the top of the Time Overview display.

You may need to trigger on the signal to get a more stable display. This is set up in the Trigger control panel. (“Trig” button). Using the Power trigger type with the RF Input source works well for many pulsed signals.

4. Set the Analysis Period to cover the number of pulses in your signal that you want to analyze. To do this, click in the data entry field of the Time Overview window and set the analysis length as needed.

### Application Preset: Spectrum Analysis

The Spectrum Analysis application preset opens a Spectrum display and sets several parameters. The Spectrum Analysis preset sets the analyzer as follows.

- **Spectrum Analysis :** Sets the frequency range to maximum for the analyzer, and sets the RF/IF optimization to **Minimize Sweep Time**.

To use the Spectrum Analysis preset (assuming the Preset action is set to Show list in the Presets tab of the Options control panel):

1. Select **Presets > Application**. Select **Spectrum Analysis** and then click **OK**.
2. Set the measurement frequency using the front-panel knob or keypad.
3. Adjust the span to show the necessary detail.

### Application Preset: Time-Frequency Analysis

The Time-Frequency Analysis application preset opens the following displays:

- Time Overview: Shows a time-domain view of the analysis time 'window'.
- Spectrogram: Shows a three-dimensional view of the signal where the X-axis represents frequency, the Y-axis represents time, and color represents amplitude.
- Frequency vs. Time: This display's graph plots changes in frequency over time and allows you to make marker measurements of settling times, frequency hops, and other frequency transients.
- Spectrum: Shows a spectrum view of the signal. The only trace showing in the Spectrum graph after selecting the Time-Frequency Analysis preset is the Spectrogram trace. This is the trace from the Spectrogram display that is selected by the active marker. Stop acquisitions with the Run button because it's easier to work with stable results. In the Spectrogram display, move a marker up or down to see the spectrum trace at various points in time.

The analysis period (scale) is set to 5 ms.

To use the Time-Frequency Analysis preset (assuming that Time-Frequency Analysis is the selected preset on the list of Application Presets and Preset action is set to Recall selected preset):

1. Select **Presets > Application**. Select **Time-Frequency Analysis** and then click **OK**.
2. When the preset's displays and settings have all been recalled and acquisitions are running, adjust the center frequency and span to capture the signal of interest.
3. Set the Reference Level to place the peak of the signal approximately 0-10 dB down from the top of the Spectrum graph.
4. If the signal is transient in nature, you might need to set a trigger to capture it. Connect to an MDO4000B/C series oscilloscope or an RSA306, RSA306B, RSA500A series, RSA600A series, or RSA7100A spectrum analyzer and use its triggering functions to capture the signal. (Option CON is required to connect to an MDO4000B/C.)

When the signal has been captured, the spectrogram shows an overview of frequency and amplitude changes over time. To see frequency transients in greater detail, use the Frequency vs. Time display.

The Time-Frequency Analysis preset sets the analysis period to 5 ms. The Spectrum Span is 40 MHz. The RBW automatically selected for this Span is 300 kHz. For a 300 kHz RBW, the amount of data needed for a single spectrum transform is 7.46  $\mu$ s. A 5 ms Analysis Length yields 671 individual spectrum transforms, each one forming one trace for the Spectrogram to display as horizontal colored lines. This preset scales the Spectrogram time axis (vertical axis) to -2, which means that the Spectrogram has done two levels of time compression, resulting in one visible line for each four transforms. This results in 167 lines in the Spectrogram for each acquisition, each covering 29.84  $\mu$ s.



### Application Preset: Spur Search Multi Zone 9k-1GHz

The Spur Search Multi Zone 9k-1GHz application preset opens the Spurious display, which is set to display all spurs that exceed the Threshold and Excursion values for the entire 9 k through 1 GHz range.

To use the Spur Search Multi Zone 9k-1GHz preset (assuming that Preset action is set to Recall selected preset):

1. Select **Presets > Application**. Select **Spur Search Multi Zone 9k-1GHz** and then click **OK**.
2. Click **Setup > Settings** when the preset's display and settings have all been recalled and acquisitions are running.
3. Select the **Ranges and Limits** tab in the Spurious Settings control panel to view the spur information. You can click the **Expand** button to view the table in a separate window.

---


**NOTE.** You can read more about the [Spurious display \(see page 179\)](#) and its various parameters and settings in the RF Measurements section.

---

## Settings Options

### Main menu bar: Tools > Options

There are several settings you can change that are not related to measurement functions. The Option settings control panel is used to change these settings.



Settings tab	Description
Presets	Use this tab to configure Presets. You can select Presets and specify the action to take when a preset is recalled.
Analysis Time	Use this tab to specify the method used to automatically set the analysis and spectrum offsets when the <a href="#">Time Zero Reference (see page 745)</a> is set to Trigger.
Save and Export	Use this tab to specify whether or not save files are named automatically and what information is saved in acquisition data files.
Security	Selecting the <b>Hide Sensitive readouts</b> check box causes the instrument to replace measurement readouts with a string of asterisks.
Prefs	Use this tab to select different color schemes for the measurement graphs and specify how markers should react when dragged.

## Presets

The Presets tab in the Options control panel allows you to specify actions taken when you press the Preset button. You can read more about this tab [here \(see page 25\)](#).

## Analysis Time

The Analysis Time tab in the Options control panel is used to specify the method used to automatically set the analysis and spectrum offsets when the [Time Zero Reference \(see page 745\)](#) is set to Trigger. The available settings are:

- Include trigger point – Selects an algorithm that uses the measurements to determine how far in advance of the trigger to set the analysis offset. The analyzer tries to ensure that data about the trigger point is included in the analyses.
- Start at trigger point (legacy) – The method used by the instrument in prior versions, which sets the Analysis Offset to zero when possible. The analyzer tries to ensure that data following the trigger point is included in the analyses. Use this method if your measurements or procedures depend on past behavior of the Auto Analysis Offset function.

## Save and Export

The Save and Export tab allows you to specify whether or not files are saved with an automatically generated name, and how much data is saved in an acquisition data file.

**All files.** The **Automatically increment filename/number** function can automatically name saved files by appending a number to a base file name. Use this tab to enable/disable automatic naming of files. For example, if **Automatically Increment Filename Number** is disabled, when you select Save from the File menu, you will have to enter a name for the file.

**Acquisition data files.** This setting specifies whether saved data files include the entire acquisition record or only the data for the analysis length (a subset of the acquisition record).

**TIQ acquisition data files.** Specifies which data records to save. You can choose from the following:

- Current acquisition: Saves the current acquisition.
- Current frame: If Fast Frame is enabled, saves only the current frame. The current frame is the one most recently analyzed.
- Selected frames: If Fast Frame is enabled, saves the specified frames.
- All in history: Saves all acquisition records in the history.
- Save TIQ file now: Invokes the Save As dialog box with the Save as type drop-down list set to TIQ.

## Security

The Security tab enables you to hide sensitive readouts in displays with readouts, such as the OFDM Summary display.

## Prefs

The Prefs tab enables you to set properties that apply to all displays.

## Connectivity

The Connect menu allows you to connect your PC (with SignalVu-PC installed) to the following instruments:

- RSA306, RSA306B, RSA500A series, and RSA600A series spectrum analyzers via USB 3.0
- RSA7100A spectrum analyzer to the CTRL7100A via PCIe port
- MDO4000B/C Series instrument via USB, wireless, or LAN (Option CON required)

---

**NOTE.** Multiple instruments may be connected to the PC that runs SignalVu-PC, but only one instrument at a time can be connected to SignalVu-PC.

---

---

**TIP.** See the [Features by product \(see page 14\)](#) topic for more information about which features are available with which connected analyzers.

---

### Connecting to a Spectrum Analyzer



**USB3 connection.** Establishing a connection to an RSA306, RSA306B, RSA500A series, and RSA600A series is as simple as connecting the USB cable from the PC to the RSA, either before or after starting the SignalVu-PC application. During the connection process, SignalVu-PC indicates that it is finding and connecting to the instrument. Please wait for the connection process to complete before using the software.

---

**NOTE.** Your PC may notify you that it has found a new USB device and has loaded the device drivers. If you see these notifications, wait until the drivers are loaded before continuing.

---

**PCIe connection.** Establishing a connection to an RSA7100A is as simple as connecting the PCIe cable from the CTRL7100A to the RSA and then powering on the controller. The controller automatically turns on the RSA and launches the SignalVu-PC application.

The SignalVu-PC application always monitors the ports. Anytime an RSA is discovered, a connection is immediately established causing the Connect status indicator to turn green (). Disconnecting the RSA from the PC also disconnects the SignalVu-PC application, causing the Connect status indicator to turn red (.

If the SignalVu-PC application is already connected to another instrument (either USB, PCIe, or network), an automated connection will not take place. In this situation, do the following:

1. Select **Disconnect From Instrument** to end the existing connection.
2. Select **Connect To Instrument**. You should see the USB connected RSA in the instrument list.
3. Select the instrument.



---

**NOTE.** RSA306 devices require SignalVu-PC version 3.4.0253 or higher. RSA306B devices require SignalVu-PC version 3.7.01xx or higher. The latest version of software is available from the Tektronix web site [www.Tek.com/downloads](http://www.Tek.com/downloads).

---

4. A Connect Status dialog box will appear to confirm the instrument is connected and SignalVu-PC can receive live data from the instrument.

---

**NOTE.** You can quickly verify connection status by looking at the **Connected** indicator icon. It is green (  ) when an instrument is connected. It is red (  ) when it is not. You can also view the name of the instrument that is connected by hovering the pointer over the connection icon.

---

5. When you want to connect to a different instrument, select **Disconnect From Instrument** to end the current connection.

### Connecting to an MDO4000B/C Series instrument

---

**NOTE.** You can watch a video tutorial about using Connect (Option CON) to connect to an MDO4000B/C Series instrument and about WLAN Presets at [www.youtube.com/user/tektronix](http://www.youtube.com/user/tektronix). Learn more about the Tektronix YouTube channel [here \(see page 17\)](#).

---

**USB connection.** To establish a connection using USB, perform the following procedures in the order given.

1. Check that the MDO4000B/C is on.
2. Connect a USB cable to the MDO.
3. Connect the other end of that USB cable to the PC.

---

**NOTE.** Your PC may notify you that it has found a new USB device and has loaded the device drivers. If you see these notifications, wait until the drivers are loaded before continuing.

---

4. Double click the SignalVu-PC icon on the Desktop to start the application.
5. Click **Connect** on the menu bar to view the drop down menu.

---

**NOTE.** See [Elements of the Display \(see page 21\)](#) for information about menus and toolbars.

---

6. Select **Connect To Instrument**. You should see the USB connected MDO in the Connect To Instrument list.




---

**NOTE.** *If the PC is currently connected by LAN or USB to another instrument, that connection will also show in the Connect To Instrument list. You must select **Disconnect From Instrument** to end that connection before connecting to the newly found instrument.*

---

7. If you do not see the USB MDO, click **Search for Instrument**. TekVISA is now searching for instruments. A notification will briefly appear stating that the instrument was found. Check that the newly found instrument now appears in the **Connect To Instrument** list.
8. Select the instrument.
9. A Connect Status dialog box will appear to confirm the instrument is connected and SignalVu-PC can receive live data from the instrument.

---

**NOTE.** *You can quickly verify connection status by looking at the **Connected** indicator square at the bottom of the screen. It is green (  ) when an instrument is connected. It is red (  ) when it is not. You can also view the name of the instrument that is connected by hovering the pointer over the .*

---

10. Use SignalVu-PC to configure the MDO. Frequency, Amplitude, Span, Bandwidth, and Time Scaling parameters for the RF channels can only be changed using SignalVu-PC.

---

**NOTE.** *Press F1 on your keyboard to open the SignalVu-PC help for information about configuring and using the application. You can also click on Help > User Manual in the SignalVu-PC menu bar to open the help.*

---

11. When you are ready to connect to a different instrument, select **Disconnect From Instrument** to first end the current connection.

---

**NOTE.** *For more search options using TekVISA, go to the Visa Resource Manager (double click in the applications tray).*

---

**LAN or wireless connection.** To establish a connection using a LAN or wireless connection, perform the following procedures in the order given.

1. Check that the PC has a working LAN or wireless network connection.
2. Use an Ethernet cable to connect the MDO to the network.
3. Check that the MDO is on and wait for the IP Address to display on the screen. Write down the IP address to help you identify the MDO in the SignalVu-PC application.
4. Double click the SignalVu-PC icon on the Desktop to start the application.
5. Click **Connect** on the menu bar to view the drop down menu.

---

**NOTE.** See [Elements of the Display \(see page 21\)](#) for information about menus and toolbars.

---

6. Select **Search For Instrument**. TekVISA is now searching for instruments.
7. A notification will briefly appear stating that the instrument was found. Check that the newly found instrument now appears in the **Connect To Instrument** list and then click on the instrument name to connect.




---

**NOTE.** If the PC is currently connected by LAN/wireless or USB to another MDO4000B/C, that connection will also show in the Connect To Instrument list. You must select **Disconnect From Instrument** to end that connection before connecting to the newly found instrument.

---

8. If you do not see the LAN address of the MDO, click **Manually Search for LAN Instrument**. You will then need to enter the IP address of the MDO into the IP Address dialog box and click **Connect**.
9. A Connect Status dialog box will appear to confirm the instrument is connected and SignalVu-PC can receive live data from the instrument.

---

**NOTE.** You can quickly verify connection status by looking at the **Connected** indicator square at the bottom of the screen. It is green (  ) when an instrument is connected. It is red (  ) when it is not. You can also view the name of the instrument that is connected by hovering the pointer over the .

---

10. Use SignalVu-PC to configure the MDO. Frequency, Amplitude, Span, Bandwidth, and Time Scaling parameters for the RF channels can only be changed using SignalVu-PC.

---

**NOTE.** Press F1 on your keyboard to open the SignalVu-PC help for information about configuring and using the application. You can also click on Help > User Manual in the SignalVu-PC menu bar to open the help.

---

11. When you are ready to connect to a different instrument, select **Disconnect From Instrument** to first end the current connection.

---

**NOTE.** *For more search options using TekVISA, go to the Visa Resource Manager (double click in the Windows applications tray).*

---






## Selecting Displays

**Main menu bar:** Setup > Displays

**Favorites toolbar:** 

Use the **Select displays** dialog to choose the displays that appear on the screen.



To select displays:

1. Select **Setup > Displays** or click the icon.
2. Select one of the choices under **Measurements**. The measurement chosen determines the choices available in **Available displays**.
3. Double-click the desired display in the **Available displays** box or select the desired display and click **Add**.
4. Click **OK**.

---

**TIP.** See the [Features by product \(see page 14\)](#) topic for more information about which features are available with which connected analyzers.

---

## Available Measurements

Available automatic measurements include RF power measurements, OFDM analysis, WLAN analysis, APCO P25 analysis, Bluetooth analysis, LTE analysis, 802.11ad (for offline analysis only), audio analysis, analog modulation measurements, digital modulation measurements, return loss, distance to fault, and pulsed RF measurements.

See the specific measurement topic in this document for information about how to take a measurement.

---

**TIP.** See the [Features by product \(see page 14\)](#) topic for more information about which features are available with which connected analyzers.

---

### Power measurements

Measurement	Description
Channel Power	The total RF power in the selected channel (located in the Chan Pwr and ACPR display).
Adjacent Channel Power Ratio (ACPR)	Measure of the signal power leaking from the main channel into adjacent channels.
Multi-Carrier Power Ratio (MCPR)	The ratio of the signal power in the reference channel or group of channels to the power in adjacent channels.
Peak/Avg Ratio	Ratio of the peak power in the transmitted signal to the average power in the transmitted signal (located in the CCDF display).
CCDF	The <i>Complementary Cumulative Distribution Function</i> (CCDF). CCDF shows how much time a signal spends at or above a given power level relative to the average power of a measured signal.

## OFDM analysis

Measurement view	Description
Channel Response	Plots the channel response (magnitude or phase) versus the subcarrier or frequency. Here, the channel refers to all sources of signal frequency response impairment up to the analyzer input, including the transmitter itself, as well as any transmission medium through which the signal travels between the transmitter and the analyzer.
Constellation	Shows the WLAN signal modulation amplitude and phase in I (horizontal) versus Q (vertical) form. For multicarrier WLAN OFDM signals, the points show all data symbol subcarriers' modulation. For single-carrier 802.11b, each point corresponds to a single modulated chip.
EVM	The normalized RMS value of the error vector between the measured signal and the ideal reference signal over the analysis length. The EVM is generally measured on symbol or chip instants and is reported in units of percent and dB. EVM is usually measured after best-fit estimates of the frequency error and a fixed phase offset have been removed. These estimates are made over the analysis length. Displays RMS and Peak values with location of Peak value.
Flatness	Ratio of the peak power in the transmitted signal to the average power in the transmitted signal
Mag Error	The RMS magnitude difference between the measured signal and the reference signal magnitude. Displays RMS and Peak values with location of Peak value.
Phase Error	The RMS phase difference between the measured signal and the ideal reference signal. Displays RMS and Peak values with location of Peak value.
Power	shows the data symbols' individual subcarrier Power values versus symbol interval (time) and subcarrier (frequency).

## Tracking generator measurement

Measurement	Description
Transmission Gain (Requires Option 04)	Measure the gain/loss and response of filters, amplifiers, attenuators, and other such devices.

## Return loss measurements

Measurement	Description
Cable loss	Measure cable attenuation.
Return loss / VSWR	Measure return loss and VSWR on filters and antennas.
Distance to fault (DTF)	Measure distance to fault to find the fault.

## WLAN measurements

Measurement view	Description
Channel Response	Plots the channel response (magnitude or phase) versus the subcarrier or frequency. Here, the channel refers to all sources of signal frequency response impairment up to the analyzer input, including the transmitter itself, as well as any transmission medium through which the signal travels between the transmitter and the analyzer.
Constellation	Shows the WLAN signal modulation amplitude and phase in I (horizontal) versus Q (vertical) form. For multicarrier WLAN OFDM signals, the points show all data symbol subcarriers' modulation. For single-carrier 802.11b, each point corresponds to a single modulated chip.
EVM	The normalized RMS value of the error vector between the measured signal and the ideal reference signal over the analysis length. The EVM is generally measured on symbol or chip instants and is reported in units of percent and dB. EVM is usually measured after best-fit estimates of the frequency error and a fixed phase offset have been removed. These estimates are made over the analysis length. Displays RMS and Peak values with location of Peak value.
Flatness	Ratio of the peak power in the transmitted signal to the average power in the transmitted signal
Mag Error	The RMS magnitude difference between the measured signal and the reference signal magnitude. Displays RMS and Peak values with location of Peak value.
Phase Error	The RMS phase difference between the measured signal and the ideal reference signal. Displays RMS and Peak values with location of Peak value.
Power vs Time	The signal power amplitude versus time. For 802.11b signals, the packet Power-On and Power-Down ramp times are also measured.
Summary	Shows several measurements of WLAN signal quality.
Symbol Table	Shows decoded data values for each data symbol in the analyzed signal packet. For OFDM (non-802.11b) signals, results are presented with subcarrier (frequency) indices in the horizontal dimension and symbol (time) intervals in the vertical dimension. For 802.11b signals, the Preamble, Header, and Data (PSDU) symbol values are presented sequentially, with symbol indices in the left column.

## 802.11ad measurements

This option is available for offline analysis only.

Measurement view	Description
Constellation	Shows the 802.11ad signal modulation amplitude and phase in I (horizontal) versus Q (vertical) form.
EVM vs Time	Shows the EVM plotted against time in seconds or symbols. The analysis region in which the measurement is done is indicated by a purple line in the Time Overview display to indicate the region of analysis.
Symbol Table	Shows decoded data values for each data symbol in the analyzed signal packet.
Summary	Shows several measurements of 802.11ad signal quality.

## Digital Modulation measurements

### Measurements for all modulation types except nFSK, C4FM, OQPSK and SOQPSK

Measurement	Description
EVM	The normalized RMS value of the error vector between the measured signal and the ideal reference signal over the analysis length. The EVM is generally measured on symbol or chip instants and is reported in units of percent and dB. EVM is usually measured after best-fit estimates of the frequency error and a fixed phase offset have been removed. These estimates are made over the analysis length. Displays RMS and Peak values with location of Peak value.
Phase Error	The RMS phase difference between the measured signal and the ideal reference signal. Displays RMS and Peak values with location of Peak value.
Mag Error	The RMS magnitude difference between the measured signal and the reference signal magnitude. Displays RMS and Peak values with location of Peak value.
MER (RMS)	The MER is defined as the ratio of I/Q signal power to I/Q noise power; the result is indicated in dB.
IQ Origin Offset	The magnitude of the DC offset of the signal measured at the symbol times. It indicates the magnitude of the carrier feed-through signal.
Frequency Error	The frequency difference between the measured carrier frequency of the signal and the user-selected center frequency of the instrument.
Gain Imbalance	The gain difference between the I and Q channels in the signal generation path. Constellations with gain imbalance show a pattern with a width that is different from height.
Quadrature Error	The orthogonal error between the I and Q channels. The error shows the phase difference between I and Q channels away from the ideal 90 degrees expected from the perfect I/Q modulation. Not valid for BPSK modulation type.
Rho	The normalized correlated power of the measured signal and the ideal reference signal. Like EVM, Rho is a measure of modulation quality. The value of Rho is less than 1 in all practical cases and is equal to 1 for a perfect signal measured in a perfect receiver.

**Measurements for QPSK and SQPSK modulation types**

Measurement	Description
EVM	The normalized RMS value of the error vector between the measured signal and the ideal reference signal over the analysis length. The EVM is generally measured on symbol or chip instants and is reported in units of percent and dB. EVM is usually measured after best-fit estimates of the frequency error and a fixed phase offset have been removed. These estimates are made over the analysis length. Displays RMS and Peak values with location of Peak value.
Offset EVM	Offset EVM is like EVM except for a difference in the time alignment of the I and Q samples. For EVM, I and Q samples are collected at the same time, for every symbol decision point (twice the symbol rate for offset modulations). For Offset EVM, the I and Q symbol decision points are time-aligned before collecting the I and Q samples. In this case, one I and one Q sample is collected for each symbol (half as many samples as the same number of symbols for (non-offset) EVM).
Phase Error	The RMS phase difference between the measured signal and the ideal reference signal. Displays RMS and Peak values with location of Peak value.
Mag Error	The RMS magnitude difference between the measured signal and the reference signal magnitude. Displays RMS and Peak values with location of Peak value.
MER (RMS)	The MER is defined as the ratio of I/Q signal power to I/Q noise power; the result is indicated in dB.
IQ Origin Offset	The magnitude of the DC offset of the signal measured at the symbol times. It indicates the magnitude of the carrier feed-through signal.
Frequency Error	The frequency difference between the measured carrier frequency of the signal and the user-selected center frequency of the instrument.
Gain Imbalance	The gain difference between the I and Q channels in the signal generation path. Constellations with gain imbalance show a pattern with a width that is different from height.
Quadrature Error	The orthogonal error between the I and Q channels. The error shows the phase difference between I and Q channels away from the ideal 90 degrees expected from the perfect I/Q modulation. Not valid for BPSK modulation type.
Rho	The normalized correlated power of the measured signal and the ideal reference signal. Like EVM, Rho is a measure of modulation quality. The value of Rho is less than 1 in all practical cases and is equal to 1 for a perfect signal measured in a perfect receiver.

**Measurements for nFSK modulation types**

Measurement	Description
Peak FSK err	Peak value of the frequency deviation error at the symbol point.
RMS FSK Err	RMS value of the frequency deviation error at the symbol point.
Peak Mag Err	The Peak magnitude difference between the measured signal and the reference signal magnitude.
RMS Mag Err	The RMS magnitude difference between the measured signal and the reference signal magnitude.
Freq Error	The frequency difference between the measured carrier frequency of the signal and the user-selected center frequency of the instrument.
Freq Deviation	Frequency distance from the center frequency at the symbol point.
Symbol Rate Error	This compares the user-entered symbol rate to the instrument calculated symbol rate of the analyzed signal.
Symbol Rate	When in Auto-symbol rate, the instrument calculates the symbol rate of the signal and the instrument calculates the error between the user entered value and the instrument calculated value.

**Measurements for C4FM modulation type**

Measurement	Description
RMS Error Magnitude	RMS value of the frequency deviation error at the symbol point.
Carrier Frequency Error	Frequency difference between averaged signal frequency and the center frequency.
Deviation	Frequency distance from the center frequency at the symbol point.
Length	Number of symbols in the analysis area.

**Analog Modulation measurements****Measurements for AM modulation**

Measurement	Description
+AM	Positive peak AM value.
-AM	Negative peak AM value.
Total AM	Total AM value, which is equal to the peak-peak AM value divided by 2.

**Measurements for FM modulation**

Measurement	Description
+Pk	Positive peak frequency deviation.
-Pk	Negative peak frequency deviation.
RMS	RMS value of the frequency deviation.
Pk-Pk/2	Peak-to-peak frequency deviation divided by 2.
Pk-Pk	Peak-to-peak frequency deviation.



**Measurements for PM modulation**

Measurement	Description
+Pk	Positive peak phase deviation.
-Pk	Negative peak phase deviation.
RMS	RMS value of the phase deviation.
Pk-Pk	Peak-to-peak phase deviation.

**APCO P25 measurements**

Measurement	Description
RF output power	Measure of RF output power when the transmitter is connected to the standard load during defined duty cycle.
Operating frequency accuracy	Measure of the ability of the transmitter to operate on its assigned frequency.
Unwanted emissions (ACPR)	Ratio of the total power of a transmitter under prescribed conditions and modulation to that of the output power that falls within a prescribed bandwidth centered on the nominal frequency of adjacent channels.
Frequency deviation	Measurement of the amount of frequency deviation that results for a Low Deviation and High Deviation test pattern.
Modulation fidelity	Measures the degree of closeness to which the modulation follows the ideal theoretical modulation determined by the rms difference between the actual deviation and the expected deviation for the transmitted symbols.
Symbol rate accuracy	Measures the ability of the transmitter to operate at the assigned symbol rate (4.8 kHz for Phase 1, 6 kHz for Phase 2).
Transmitter power and encoder attack time	Measures the time required for a transmitter to prepare and transmit information on the radio channel after changing state from standby to transmit (applies to conventional mode).
Transmitter power and encoder attack time with busy/idle operations	Measures the time required for a transmitter to prepare and transmit information on the radio channel after the receiving channel changes state from busy to idle.
Transmitter throughput delay	Measures the time it requires for audio changes in the microphone to be encoded and transmitted over the air.
Transient frequency behavior	Measures the difference of the actual transmitter frequency and assigned transmitter frequency as a function of time when the RF output power is switched on or off.
HCPM transmitter logical channel time alignment	Measures the ratio of total transmitter power under prescribed conditions and modulation to the peak power that falls in a prescribed bandwidth centered on the nominal frequency of the adjacent channel during the transmitter power ramping interval.

**Bluetooth measurements**

Measurement	Description
Modulation characteristics	Verifies that the modulation characteristics of the transmitted signal are correct. This measurement can only be done if the payload has the bit pattern 10101010 or 11110000.
Carrier frequency offset and drift	Verifies that the carrier frequency offset and carrier drift of the transmitted signal is within the specified limits for the Basic Rate and Low Energy standards. This test can be done only if the payload contains 10101010 bit pattern.

Measurement	Description
Output power	Verifies the maximum peak and average power emitted from the EUT. The standard recommends this test be done for a PRBS payload pattern.
In-band emission / ACPR	Verifies that the in-band spectral emission is within limits. The standard document recommends that this measurement be done with Hopping off, finding the integrated power in 1 MHz band (with RBW 100 kHz) in 80 channels starting from 2401 MHz to 2481 MHz. The integrated power values calculated in the adjacent channels are compared against recommended limits (except the three channels around transmitted frequency). This measurement is referred to as ACPR in the Basic Rate standards document.
20 dB bandwidth	Verifies if the emissions inside the operating frequency range are within limits. This measurement is done with Hopping off. The difference between frequency points at which the power level drops to 20 dB below the peak power of the emission is found as 20 dB bandwidth.
Frequency range	These measurements verify if the emissions inside the operating frequency range are within the limits.
Power density	This measurement verifies the maximum RF output power density.
Out-of-band spurious emission	This measurement can be done for FCC or ETSI masks using the Spurious display.
Relative power	Verifies the relative power in the GFSK and PSK part of the Enhanced Data Rate signal. This measurement is supported only when an Enhanced Data Rate signal is detected.

### LTE measurements

Measurement	Description
Cell ID detection	The Cell ID is detected from the input LTE signal. For TDD and FDD.
Adjacent Channel Leakage Ratio (ACLR)	The Adjacent Channel integrated power is calculated and shown. The relative power compared to the reference signal is also computed. The computed power is compared against limits suggested by the selected standard and pass/fail is reported. For TDD and FDD.
Channel Power	The channel power is calculated in the channel bandwidth. For TDD and FDD.
Occupied Bandwidth	The Occupied bandwidth is calculated as bandwidth containing 99% of the total integrated power in the selected span around the selected center frequency. For TDD and FDD.
Operating Band Unwanted Emission	The power in the offset regions is calculated and presented and compared against limits set in the offset and limits table and pass/fail is reported. For TDD and FDD.
T <sub>OFF</sub>	The power in off-slot region is computed and compared against selected limits. For TDD only.

### Pulse measurements

Measurement	Description
Average ON Power	The average power transmitted during pulse on.
Peak Power	Maximum power during pulse on.

Measurement	Description
Average Transmitted Power	The average power transmitted, including both the time the pulse is on and the time it is off, and all transition times.
Pulse Width	The time from the rising edge to the falling edge at the $-3$ dB / $-6$ dB level (50%) of the user selected 100% level. Level is user selectable for Volts or Watts.
Rise Time	The time required for a signal to rise from 10% to 90% (or 20% to 80%) of the user selected 100% level.
Fall Time	The time required for a signal to fall from 90% to 10% (or 80% to 20%) of the user selected 100% level.
Repetition Interval	The time from a pulse rising edge to the next pulse rising edge.
Repetition Rate	The inverse of repetition interval.
Duty Factor (%)	The ratio of the width to the pulse period, expressed as a percentage.
Duty Factor (Ratio)	The ratio of the pulse width to the pulse period.
Ripple	<p>Ripple is the peak-to-peak ripple on the pulse top. It does not include any preshoot, overshoot, or undershoot. By default, the first 25% and the last 25% of the pulse top is excluded from this measurement to eliminate distortions caused by these portions of the pulse.</p> <p>If the Amplitude units selected in the Amplitude panel (affects all amplitude measurements for the analyzer) are linear, the Ripple results will be in %Volts. For log units, the Ripple results will be in %Watts. The default for the general Units control is dBm, so the Ripple results default is %Watts.</p> <p>See also <a href="#">Ripple (see page 886)</a>.</p>
Ripple dB	The Ripple measurement expressed in dB.
Droop	Droop is the power difference between the beginning and the end of the pulse On time. A straight-line best fit is used to represent the top of the pulse. The result is a percentage referenced to the Average ON Power.
Droop dB	The Droop measurement expressed in dB.
Overshoot	The amount by which the signal exceeds the 100% level on the pulse rising edge. Units are %Watts or %Volts.
Overshoot dB	The Overshoot measurement expressed in dB.
Pulse-ref-Phase Difference	The phase difference between the current pulse and the first pulse in the analysis window. The instantaneous phase is measured at a user-adjustable time following the rising edge of each pulse.
Pulse-ref Freq Difference	The difference between the frequency of the current pulse and frequency of the previous pulse. The instantaneous frequency is measured at a user-adjustable time following the rising edge of each pulse.
RMS Freq Error	The RMS Frequency Error measurement is the RMS average of the Freq Error vs. Time trace, computed over the Measurement Time.
Max Freq Error	The maximum frequency error is the difference between the measured carrier frequency of the signal and the user-selected center frequency of the analyzer.
RMS Phase Error	The RMS Phase Error measurement is the RMS average of the Phase vs Time trace, computed over the Measurement Time.

Measurement	Description
Max Phase Error	The phase is measured at each point during the pulse's ON time. The phase error for each point is the difference between the measured phase value and the calculated ideal phase value. After the phase error is calculated for all points in the acquisition record, the largest error in the positive direction and the largest in the negative direction are determined. Whichever of these two values has the greater absolute value is designated the Max Phase Error.
Freq Deviation	The Frequency Deviation measurement is the difference between the maximum and minimum measured values of the signal frequency during the Measurement Time.
Phase Deviation	The Phase Deviation is the difference between the maximum and minimum Phase values measured during the ON time of a pulse.
Impulse Response Amplitude	The difference in dB between the levels of the main lobe and highest side lobe.
Impulse Response Time	The difference in time between the main lobe and highest side lobe.
Absolute Frequency	The absolute pulse frequency measured at a point specified by the user. The measurement includes carrier frequency as well. The measurement point should be within the pulse width, starting from the 50% point.
Pulse-Pulse Frequency Difference	The difference between the frequency of the current pulse and frequency of the previous pulse. The instantaneous frequency is measured at a user-adjustable time following the rising edge of each pulse.
Pulse-Pulse Phase Difference	The phase difference between the selected pulse and the first pulse in the analysis window. The instantaneous phase is measured at a user-adjustable time following the rising edge of each pulse.

## Overview

The displays in General Signal Viewing (Displays > Measurements > General Signal Viewing) are:

- Amplitude vs Time
- DPX Spectrum
- Frequency vs Time
- Phase vs Time
- RF I & Q vs Time
- Spectrogram
- Spectrum
- Time Overview

These displays provide extensive time-correlated multi-domain views that connect problems in time, frequency, phase and amplitude for enabling you to more quickly understand cause and effect when troubleshooting.

---

**TIP.** See the [Features by product \(see page 14\)](#) topic for more information about which features are available with which connected analyzers.

---

## DPX primer

The information in this section is from the Tektronix DPX Primer, available separately as an application note and for download from [www.tek.com](http://www.tek.com). The DPX display can detect extremely brief signals and processes many thousands of spectrums per second. It then displays all these spectrums as a color-graded bitmap that reveals low-amplitude signals beneath stronger signals sharing the same frequency at different times.

The strong signal in the DPX spectrum graph, shown in Figure 1, is a repeating pulse at a fixed frequency. There is also a lower-power CW signal that steps very quickly through the same span. During the pulse's on time, the power of the two signals is additive, resulting in nearly undetectable differences in the pulse envelope shape. But during the time the pulse is off, the sweeping signal is detected and shown in its true form. Both signals are visible in the bitmap because at least one full cycle of their activities occurs within a single DPX display update.




Figure 1

Compare the display of a traditional swept spectrum analyzer (Figure 2) and that of a real-time signal analyzer with a DPX display (Figure 3). The signal captured is a typical WLAN interchange between a nearby PC and a more-distant network access point (AP). The laptop signal is nearly 30 dB stronger than the AP's signal because it is closer to the measuring antenna.




Figure 2




Figure 3

The traditional swept spectrum analyzer display, Figure 2, uses line traces that can show only one level for each frequency point, representing the largest, the smallest or the average power. After many sweeps, the

Max Hold trace shows a rough envelope of the stronger laptop signal. +Peak detection was selected for the other trace in an attempt to capture the weaker but more frequent AP signal, but the bursts are very brief, so the likelihood of seeing one in any particular sweep is small. It will also take a long time to statistically capture the entire spectrum of a bursted signal due to the architecture of the swept spectrum analysis.

The DPX display, Figure 3, reveals much more insight on the same signal. Since it is a bitmap image instead of a line trace, you can distinguish many different signals occurring within each update period and/or different version of the same signal varying over time. The heavy band running straight across the lower third of the graph is the noise background when neither the laptop nor the AP is transmitting. The red lump of energy in the middle is the ON shape of the AP signal. Finally, the more delicate spectrum above the others is the laptop transmissions. In the color scheme used for this demonstration (“Temperature”), the hot red color indicates a signal that is much more frequent than signals shown in cooler colors. The laptop signal, in yellow, green and blue, has higher amplitude but doesn't occur nearly as often as the AP transmissions because the laptop was downloading a file when this screen capture was taken.

## How DPX works

This section explains how DPX displays are created. The input RF signal is conditioned and down-converted as usual for a signal analyzer, then digitized. The digitized data is processed in SignalVu-PC, creating very fast spectral transforms. The resulting frequency-domain waveforms are rasterized to create the bitmaps.

The DPX bitmap that you see on screen is composed of pixels representing x, y, and z values for frequency, amplitude, and Density. A multi-stage process, shown in the following four figures, creates this bitmap, starting with analog-to-digital conversion of the input signal.

### Simplified Flow of Multi-stage Processing from RF Input Through to Spectrum Processing:




Figure 4a. RF signals are downconverted and sampled into a continuous data stream.




Figure 4b. Samples are segmented into data records for FFT processing based on the selected resolution bandwidth.




Figure 4c. Data records are processed in the DPX transform engine




Figure 4d. Overlapping the FFTs shortens the minimum event duration required for 100% probability of intercept.

**Collecting spectral data.** Sampling and digitization is continuous. The digitized data stream is chopped into data records whose length is based on the desired resolution bandwidth (RBW). An additional requirement is placed on FFT length by the desired number of points in a trace. The DPX transform engine performs a discrete Fourier transform on each record, continually producing spectral waveforms.

As long as spectral transforms are performed faster than the acquisition data records arrive, the transforms can overlap each other in time, so no events are missed in between. Minimum event length for guaranteed capture depends on the length of the data records being transformed. An event must last through two consecutive data records in order for its amplitude to be accurately measured. Shorter events are detected and visible on screen, but may be attenuated. The DPX Spectrum RBW setting determines the data record length; narrow RBW filters have a longer time constant than wide RBW filters. This longer time constant requires longer FFTs, reducing the transform rate.

The spectral waveforms are plotted onto a grid of counting cells called the “bitmap database”. The number held by each database cell is the z-axis count. For simplicity, the small example grid used in the following grids is 11x10, so our spectral waveforms will each contain 11 points. A waveform contains one (y) amplitude value for each (x) frequency. As waveforms are plotted to the grid, the cells increment their values each time they receive a waveform point.




Figure 5. Example 3-D Bitmap Database after 1 (left) and 9 (right) updates. Note that each column contains the same total number of “hits”.

The grid on the left shows what the database cells might contain after a single spectrum is plotted into it. Blank cells contain the value zero, meaning that no points from a spectrum have fallen into them yet.

The grid on the right shows values that our simplified database might contain after an additional eight spectral transforms have been performed and their results stored in the cells. One of the nine spectrums happened to be computed as a time during which the signal was absent, as you can see by the string of “1” occurrence counts at the noise floor.

**Frame updates.** The maximum rate for performing the variable-length frequency transforms that produce those waveforms varies with the PC you use and the length of the transform. Rates greater than 1 million transforms per second are performed with the RSA7100A. Measurement settings that slow this transform



rate include narrowing the RBW and increasing the number of points for the line traces available in the DPX display along with the bitmap. Even at their slowest, spectral transforms are performed orders of magnitude faster than a physical display can respond, and also too fast for humans to see, so there's no need to update the screen or measurements at this rate. Instead, the grid collects thousands of waveforms into “frames”, each covering about 50 milliseconds (ms). The actual frame rate varies with resolution bandwidth and the processor used in your PC. After each frame's waveforms have been mapped into the grid, the cell occurrence counts are converted to colors and written to the DPX bitmap, resulting in a bitmap update rate of around 20 per second.

Frame length sets the time resolution for DPX measurements. If the bitmap shows that a -10 dBm signal at 72.3 MHz was present for 10% of one frame's duration (5 ms out of 50 ms), it isn't possible to determine just from the DPX display whether the actual signal contained a single 5 ms pulse, one hundred 50 microsecond ( $\mu$ s) pulses, or something in between. For this information, you need to examine the spectral details of the signal or use another display with finer time resolution, such as Frequency vs. Time or Amplitude vs. Time.

**Converting occurrence counts to color.** About 20 times per second, the grid values are transferred to the next process step, in which the z-axis values are mapped to pixel colors in the visible bitmap, turning data into information. In this example, warmer colors (red, orange, yellow) indicate more occurrences. The color palette is user-selectable, but for now we will assume the default “temperature” palette.

Number of Occurrences	Color
0	black
1	blue
2	light blue
3	cyan
4	green blue
5	green
6	yellow
7	orange
8	red orange
9	red

The result of coloring the database cells according to the number of times they were written into by the nine spectrums, one per pixel on the screen, creates the DPX displays.




Figure 7. Color-coded low-resolution example (left) and a real DPX display (right).

In addition to the choice of palette, there are z-axis scaling adjustments for Maximum, Minimum, and Curve. Maximum sets the occurrence value that will be mapped to the highest color in the palette. Minimum sets the occurrence value for the lowest color. In the “temperature” palette, the highest color is deep red and the lowest is dark blue. Occurrence values less than the selected Minimum are represented with black pixels, while pixels that exceed the selected Maximum are red in hue but somewhat transparent. Values between Maximum and Minimum are represented by the other colors of the palette.

Adjusting the Minimum above the black default allows you to concentrate most of your color resolution over a small range of medium or higher occurrence rates to visually discriminate between different signals that have nearly equal probability values.

To see why adjustable color scaling is useful compare the following figures. On the Scale tab, the Max control is set to 100% in the first figure. The range of colors now covers the full z-axis range of densities from 0 to 100%. The signals used to create this bitmap are fairly diffused in both frequency and amplitude, so most pixels have low occurrence counts or density values and the upper half of the color palette is unused.




Figure 8. DPX spectrum bitmap with default color scale settings.

When the Auto Color button is selected, the Maximum control's value is set to the highest pixel value in the current bitmap, shown below. Now none of the available colors remain unused. The entire palette is mapped to the occurrence values present at the time the button is selected, providing better visual

resolution for low densities. Selecting the Autoscale button in the DPX display scales all three axes based on current results.




Figure 9. The Auto Color function optimizes the color scale settings.

### Color mapping curves

The mapping between z-axis values and color does not have to be linear. The Curve control lets you choose the shape of the mapping equation. A Curve setting of 1 selects the straight-line relationship. Higher Curve numbers pull the curve upwards and to the left, concentrating color resolution on lower densities. Settings less than 1 invert the curve, moving the focus of the color range towards higher density values. The following figure shows the mapping curves.




Figure 10. Representative color mapping curves for the “Temperature” palette.

Using the same signal shown in Figures 8 and 9, the impact of the Curve control can be observed. With the Curve control set to 1 in the Scale tab, shown in Figure 11, the mapping between color and density is linear, so the colors spread evenly across the full density range. The color distribution is visible in the colored palette illustration to the left of the Curve control in the Settings panel.




Figure 11. Over a narrow Signal Density range, the color curve is set to 1.

When the Curve control is set to 0.5, as shown in Figure 12, the best color resolution is in the upper half of the density range, and only the dark blues are assigned to densities below 50%. Note the difference in the palette illustration.




Figure 12. Adjusting to values less than 1, increases the contrast for viewing events in the top half of the selected density range.

In Figure 13, the Curve control is increased to 3. The majority of colors shifts to the lower half of the density scale, but various shades of orange and red are still available for densities above 50%.




Figure 13. For color curve settings greater than 1, better contrast is provided for events near the low end of the density range.

## Swept DPX

DPX Spectrum is not limited in span by its real-time bandwidth. Like the regular Spectrum display, DPX Spectrum steps through multiple real-time frequency segments, building a wide-span display with line traces and the bitmap. See Figure 14.




Figure 14. Off-air ambient signals over a 1 GHz span in the swept DPX display.

The analyzer “dwells” in each frequency segment for one or more DPX frames, each containing the results of up to 14,600 spectral transforms. Dwell time is adjustable, so you can monitor each segment of the sweep for up to 100 seconds before moving to the next step. While dwelling in a segment, the probability of intercept for signals within that frequency band is the same as in normal, real-time spans.

A full pixel bitmap is created for every segment and compressed horizontally to the number of columns needed for displaying the frequency segment. Compression is done by averaging pixel densities of the points being combined together. The final swept bitmap contains a representation of the same pixel bitmap resolution, just like the non-swept bitmaps. Line traces are also created in full for each segment, and then horizontally compressed to the user-selected number of trace points for the full span.

A complex algorithm for determining the number and width of each frequency segment has been implemented. The variables in the equation include user-adjustable control settings like Span, RBW, and number of trace points, RF and IF optimization, and Acquisition BW. Installed hardware options also can affect the span segmentation.

A helpful piece of information for operators is the actual Acquisition Bandwidth used for capturing each segment. “Acq BW” is shown in the Acquire control panel on the Sampling Parameters tab. Acq BW is typically set automatically by the instrument, based on the needs of all the open displays, but can also be set manually. In either case, the displayed bandwidth is used for every frequency segment in the swept DPX display, though in practice, the displayed portion of the segment is somewhat narrower than the actual Acquisition BW, for performance reasons.

The entire instrument frequency range of many GHz can be covered in a DPX sweep. The Dwell Time control sets the amount of time DPX spends in each segment. This control, shown below, can be set between 50 ms and 100 seconds.


Freq & Span		BW	Traces	Horiz & Vert Scale	Bitmap Scale	Prefs	Density
Frequency:	1.480 GHz	Span:	2.000 GHz	<button>Max Span</button>			
Start:	480 MHz	Step Size:	200.0000 MHz	<input checked="" type="checkbox"/> Auto			
Stop:	2.480 GHz	Dwell time:	50.0 ms	<input checked="" type="checkbox"/> Auto			
		(swept only)					

Figure 15. During swept DPX operation, the Dwell time control adjusts the observation time of each frequency segment used to construct the composite DPX display.

## Guaranteed capture in DPX real-time spans

All Tektronix real time spectrum analyzers are specified for the minimum signal duration for 100% probability of capture and display. This number can vary based on the processor used for SignalVu-PC. In the case of the RSA7100A, the processor is from Tektronix, and we provide published performance in the datasheet and *RSA7100A Specifications and Performance Verification Technical Reference* (available for download from [www.tek.com](http://www.tek.com)). In the case of USB RF spectrum analyzers, minimum signal duration can be as brief as 16  $\mu$ s. See the datasheet for your instrument to determine its performance.

You can also, at any time, have the instrument report its minimum signal duration by displaying it on the DPX spectrum screen as follows.

1. Check that the DPX spectrum display is active.
2. Click  to view the DPX settings control panel.
3. Select the **Prefs** tab.
4. Check the **Show parameter readouts** box. The minimum signal duration for 100 % POI will appear on the right side of the display.

The following table shows the specified minimum signal duration (MSD) for 100% probability of intercept under various combinations of Span and RBW in DPX for a representative signal analyzer. As you can see, MSD is affected by multiple factors.

To demonstrate the POI in action, a challenging bi-stable signal is used. A CW sinusoid sits at 2.4453 GHz most of the time, but every 1.28 seconds, its frequency changes for about 100  $\mu$ s before returning to normal. The duty factor of this transient is less than 0.01%.

Figure 16 shows a swept analyzer set up for a 5-second sweep of its MaxHold trace. It shows that there is something occurring around the signal. This sweep rate was empirically determined to be the optimum rate for reliable capture of this signal in the shortest time. Faster sweep times can reduce the probability of intercept and result in fewer intersections of the sweep with the signal transient.




Figure 16. Swept spectrum display of the infrequent transient.

The DPX display shown in Figure 17 shows the exact same event, also captured over a 5 second period. A lot more information can be discovered about the transient. It is obvious at first glance that the signal is hopping by about 3 MHz, with 1.2 MHz of frequency overshoot on transitions




Figure 17. The DPX spectrum display after 5 seconds. The MaxHold trace is cyan.

### Guaranteed capture in DPX swept spans

Probability of intercept (POI) for signals within a single segment, while DPX is dwelling in that segment, is the same as for non-swept DPX operation. But just as in traditional swept analyzers, during the time the acquisition is tuned to any one segment, the analyzer is not monitoring signals in any of the other segments, so probability of capture in segments other than the current one is zero. Because of the wide real-time



bandwidth, the number of segments needed to cover the span is much less than for swept analyzers, so the overall probability of intercept is significantly better for DPX sweeps.

Another factor affecting POI is number of trace points. The bitmap is always 801 points wide, but the line traces allow user selection for number of points. 801 is the default and the other choices are 2401, 4001, and 10401. Frequency transforms for traces containing more than 801 points take longer, and this lower waveform update rate increases the minimum signal duration proportionally. This caution applies for swept and non-swept operation. The trace length control is on the Prefs tab in the DPX control panel.

## DPX Density measurements

---

**NOTE.** *DPX Density measurements are only available when an RSA7100A is connected.*

---

Density is a measure of the amount of time during a defined measurement period during which signals are present within a particular area of the DPX Spectrum bitmap. A clean CW tone gives a 100% reading, while a pulse that is on for one microsecond out of every millisecond reads 0.1%. This section describes how density is computed from hit counts.

If we plot 41 more waveforms into the example grid we used previously in Figure 6 (in addition to the nine we already plotted), each column ends with a total of 50 hits (Figure 18). The density for any one cell in a column is its own count value divided by 50, expressed in percent as shown in Figure 19. The math is very simple: a cell with 24 counts has a 48% density. In practice, instead of batches of 50 waveforms, we collect a frame of thousands of waveforms before each update to the density bitmap.

					4					
					6					
					13					
					18					
				1	3	1				
		1	2	4		4				
1	2	1	43	41	2	38	6	1	2	2
47	46	47	5	4	3	7	43	47	46	47
2	2	1			1		1	2	2	1

Figure 18. Grid showing cell counts after 50 waveforms. For each column, the sum of z-axis values is 50.



0%	0%	0%	0%	0%	0%	0%	0%	0%	0%	0%
0%	0%	0%	0%	0%	8%	0%	0%	0%	0%	0%
0%	0%	0%	0%	0%	12%	0%	0%	0%	0%	0%
0%	0%	0%	0%	0%	26%	0%	0%	0%	0%	0%
0%	0%	0%	0%	0%	36%	0%	0%	0%	0%	0%
0%	0%	0%	0%	2%	6%	2%	0%	0%	0%	0%
0%	0%	2%	4%	8%	0%	8%	0%	0%	0%	0%
2%	4%	2%	86%	82%	4%	76%	12%	2%	4%	4%
94%	92%	94%	10%	8%	6%	14%	86%	94%	92%	94%
4%	4%	2%	0%	0%	2%	0%	2%	4%	4%	2%

Figure 19. Grid after converting occurrence counts to percent density values. The sums of the cell density measurements within each column are all 100%.

### Measuring density with markers

Hit counts are cleared after every frame update, as long as Persistence is not turned on. The density value for any pixel is simply the percent of time it was occupied during the most recent 50 ms frame. Markers can be used to see the Density value for one or more individual points on the screen, enabling measurements of the signal density at any interesting point in the DPX display.

In Figure 20, Wireless LAN signals are analyzed in the presence of a Bluetooth radio signal in the 2.4 GHz ISM band.




Figure 20. DPX display of WLAN and Bluetooth signals, with a marker on the highest signal.

The “Marker to Peak” function was used to find the peak signal recorded in the display. The marker readout in the upper left corner of Figure 20 shows the Density, Amplitude, and Frequency for the pixel you selected with the marker. By adding additional markers, you can measure the signal density differences between multiple signals of interest.

### Marker peak search in the DPX bitmap

Markers on the DPX bitmap can search for peaks, similar to marker peak searching on spectrum line traces. For a human, it is pretty easy to discern “signals” in the bitmap picture. Your brain intuitively identifies strings of contiguous bright pixels. This isn't so easy for a computer. The first thing the RSA must do for any peak search is analyze pixel density values to identify apparent signals. Then it can sift through these density peaks for the amplitude peaks you want to find.

Z-axis density values for the pixels in each column of the bitmap are internally converted into histograms to find density peaks indicating the presence of signals. Table 2 shows the five middle columns from the example grid we used to illustrate density measurements in a previous section (Figure 19). The density values for each pixel in the middle, highlighted column are plotted on the y axis in the bar chart in Figure 21. The bar chart x axis is bitmap row number, numbering from the top of the table.

**Table 1: Bitmap section showing density values.**

0%	0%	<b>0%</b>	0%	0%
0%	0%	<b>8%</b>	0%	0%
0%	0%	<b>12%</b>	0%	0%
0%	0%	<b>26%</b>	0%	0%
0%	0%	<b>36%</b>	0%	0%
0%	2%	<b>6%</b>	2%	0%
4%	8%	<b>0%</b>	8%	0%
86%	82%	<b>4%</b>	76%	12%
10%	8%	<b>6%</b>	14%	86%
0%	0%	<b>2%</b>	0%	2%




Figure 21. Bar chart of the density values in the bolded column of Table 2.

Assume that Density Threshold is set to 5% and Density Excursion to 5% also. Starting with  $x=1$  in the bar chart, test each bar against the threshold. The threshold criteria is met at  $x=2$ . Keep testing until you

find a bar that is shorter than the previous bar by at least the Excursion setting. In this case it is  $x=6$ . This tells us that a “signal” covers rows 2 through 5. Its density peak is at row 5.

Now you can look for another peak. Continue looking at bars to the right and you will find a density value at row 9 that meets the threshold criteria, but since there are no bars to the right of it that meet the excursion criteria, we can't declare row 9 a signal because it fails to meet the excursion criteria. If row 1 had 1% density, then row 9 would be a density peak.

Once density peaks are found for all columns in the bitmap, we can start looking for the amplitude peaks. When the **Peak** button is selected, the analyzer checks the histograms of every column in the bitmap and finds the density peak with the highest amplitude. The amplitude search has its own versions of Threshold and Excursion settings, but in dBm and dB units. When **Next Peak Down** command is given, the search will scan inside the current column for the next density peak. **Next Peak Right** examines each column to the right of the current marker location to locate density peaks that also meet the amplitude peak criteria.

To demonstrate the value of marker peak search in the DPX bitmap, we will use the time-multiplexed signals showing multiple amplitude levels from an example earlier in this manual. The **Peak** button and its menu equivalent place the active marker on the peak signal in Figure 22. The peak signal is the density peak of highest amplitude in the bitmap.




Figure 22. The marker was positioned by selecting the Peak button. Density, frequency, and amplitude measurements at the marker are displayed in the upper left corner of the graph.

The Marker Toolbar, at the bottom of Figure 22, allows easy navigation of peak signals (**Peak Left**, **Peak Right**, **Next Peak Up**, or **Next Peak Down**). Selecting the arrow keys enables the marker to search for amplitude/density peaks at other frequencies, while the **Next Peak Up** and **Next Peak Down** arrows enable the marker to search for other high-density points at the same frequency.

In the Define Peaks tab of the Define Markers control panel, Figure 24, you can adjust the density threshold and excursion controls to modify search behavior. The amplitude threshold and excursion controls also apply to DPX marker searches. Smoothing keeps the marker from finding multiple peaks within the same apparent signal by averaging an adjustable number of pixel densities together, but it does not affect the single-pixel measurement readout displayed by the marker.




Figure 24. Amplitude and Signal Density controls can be adjusted to define Peak search behavior.

### Density measurements over an adjustable area (The Box)

The density for a single pixel is its ratio of actual hits versus possible hits over a defined time period, and markers display these density values. For measuring density over an area larger than one pixel, the DPX display includes a measurement box you can resize and drag around in the DPX display.

If you could make the box so narrow that it contained only points within a single column of pixels, the density of this area would be the sum of the included pixels' density values. For example, if the box was three pixels tall and the density values for these pixels were 4, 2, and 7% respectively, the overall density for the three-pixel area would be 13%. Imagine a box one pixel wide and as tall as the graph. Assume that the input signal's amplitude was such that all hits fell at or near the vertical center of the screen. Since 100% of the waveforms written to the bitmap passed through the box, the density for the box is 100%.

$$\text{Density of an area} = \frac{(\text{Sum of densities of all pixels})}{(\text{Number of columns})}$$

When you widen the box to cover a broader range of frequencies, software computes the density sum for the included pixels in each column inside the box. The aggregate density value for this box is the average density, calculated by adding the column density sums then dividing by the number of columns. For a 100% result, there must not be any hits above the top edge of the box or below its bottom edge. In other words, every waveform drawn across the graph entered the box through its left side and exited the box through its right side, with no excursions out the top or bottom. Figure 24 demonstrates this principle on a CW signal. As you can see on the left-hand side, no amplitudes exist above or below the box; the density of the signal is 100%. On the right hand side, there are signals below the box, therefore the density is less than 100%.




Figure 24. Density of signals defined within an area. Left: Correct measurement of a CW signal. All columns in the box include the signal. Right: Incorrect measurement area. The measurement is accurate, but probably not what you expected. Some columns in the box contain no hits, so they contribute zeros to the calculation of average density.

The density measurement box's vertical size and location are always set in dB and dBm, no matter what units you have selected for measurements. The box is not draggable when the selected units are linear (such as Amps, Volts, Watts...), though you can still adjust its size and location using the Frequency and Amplitude controls. Since the vertical scale is non-linear, a box of constant amplitude changes visual height as it changes vertical position, a disconcerting effect if you are trying to drag it.




Figure 25. DPX Density control panel is used to define the area of interest for DPX density measurements.

A readout will appear somewhere in the graph. If the box is off-screen, the readout will be accompanied by an arrow pointing towards the invisible box. Drag the density readout to the area you want to measure.

## Persistence

Previous sections of this topic have assumed that persistence was not applied to the DPX bitmap. Without persistence, hit counts in the grid are cleared after each frame update. Now we will describe how persistence modifies this behavior, starting with infinite persistence because it is simpler than variable persistence.

Hit counts are not cleared between frames if infinite persistence is enabled. When the instrument is set up for continuous acquisitions, hits keep collecting until you stop acquisitions or click the Clear button above the DPX display. Software keeps track of the total number of waveforms computed during the entire collection period. Density equals the total number of hits to a cell divided by the total number of waveforms.

Variable persistence is trickier. A single-occurrence signal shown in the bitmap does not disappear suddenly upon the next frame update, nor does it linger forever. It fades gradually away. The user sets a time constant for the Dot Persistence control which determines how long it takes for signals to fade. Fading is accomplished by reducing the hit count in every cell, after each frame update, by a factor based on the persistence time constant. The longer the time constant, the less the hit counts are reduced.




Figure 26. Example of fast transient discovery with and without variable persistence turned on. In the display on the left, with variable persistence of 10 seconds, the occasional sub-second transient that spikes up above the normal signals is held in the display rather than disappearing as soon as the signal goes away. The display on the right, with persistence turned off, requires watching the display continually to see the brief signal.

Not only are single-occurrence signals allowed to remain in the display for awhile by variable persistence, additional hits keep piling on. The result is that cell values are no longer pure hit counts; they include counts due to new hits from waveforms plus proportionally reduced counts from prior frames. As part of translating hit counts into density values, a new software algorithm uses a finite-series equation to discriminate between the effects of persistence and the arrival of new hits. The inflationary effects of persistence on cell counts are removed, so density readings represent the true ratio of actual hits to possible hits over the persistence interval.

The density computation for variable persistence is a very good estimate of true signal density, with errors of less than 0.01%. For exact density measurements, use either no persistence or infinite persistence.

Another subtlety of persistence is its smoothing effect on the density measurement of intermittent signals. Consider a pulse that is on for 10 ms and off for 90 ms of each 100 ms cycle. We will make the simplifying assumption that the pulse ON time always falls entirely within a single DPX frame update (50 ms). If persistence is not applied, the density measurement is computed on each individual frame. The results will be 20% for each frame containing the ON time and 0% for the other frames. If infinite persistence is enabled, however, the density measurement will settle to 10% after the second frame, and remain at this value for as long as the pulsing continues. With persistence, the density is effectively computed over many frames.

### Persistence effects on density

Persistence does not alter colors in a density-based bitmap. Its effect is to extend the amount of time over which densities are calculated, leaving signal events visible for the persistence duration.

Before the introduction of density measurements and extra-long hit counters, persistence caused colors to “bloom”, becoming more and more intense over time as the hit counts increased. Longer persistence intervals caused increased blooming, turning crisp signals into fat red stripes. When hit counts are

converted to density values, the display is not subject to this effect. As long as the input signals maintain reasonably stable repetition rates and duty ratios, their density values will also remain stable despite ever-increasing hit counts in the underlying grid cells.

If you are accustomed to the original hit-count-based persistence displays, it may seem counter-intuitive that repeating signals in a density-based bitmap will not get brighter and redder over time with infinite persistence. A quick review of the density algorithm explains why: the hit count is divided by the total number of waveforms over the persistence interval. For example, if a signal occupies a pixel 50% of the time over a period of 15 minutes, the density reading will be 50% throughout the entire 15 minutes, though the underlying hit count is steadily increasing.

## Z-axis resolution

Another factor that can cause color bloom is overflow of the hit counters. If a pixel could only count up to 1000 hits, its density and color values would clip at 100% after just 1000 hits, even if waveform points continue to arrive in the same pixel location. counts add up really fast for highly-repetitive signals. Deeper counters permit higher hit counts, so overflow happens much later, as shown in Table 4.

**Table 2: Comparison of DPX z-axis resolution and its effect on saturation.**

Hit Count	36-bit custom float (equivalent to 33-bit integer)
Maximum Hit Count	$2^{33}$
Minimum Time until Overflow (for pixels with 100% density)	8.1 hours

Clipping due to overflow of the counters in one or more cells will not occur until hours have passed, or even days.

One more benefit to having deeper hit counters is better visual resolution of density. RSAs with the highest-performance DPX hardware installed use floating-point numbers to count hits, allowing us to count billions of waveforms while retaining one-hit resolution, providing better than 99 dB of dynamic range for density measurements. Density measurements in  $\mu\%$ ,  $n\%$ , and even  $f\%$  ranges are quite possible for extremely rare signals captured with infinite persistence.

With straight-line mapping between density and color (Curve setting of 1), resolution is fixed by the number of colors in the palette. For non-linear mappings (Curve settings higher or lower than 1), most of the colors are concentrated at either the low or high end of the density scale, so you can visually discriminate finer differences between density values in that range.

## Persistence adjustments

Dot Persistence can be enabled for the “Bitmap” trace using the Settings control panel. The Persistence can be displayed as Infinite or Variable. For Variable Persistence, you can select the time constant for fading in seconds as shown in Figure 27.






Figure 27. The trace settings control panel allows user control of persistence parameters.

Figure 28 demonstrates the observed behavior of variable persistence when a CW signal, represented in the first frame, is turned off. Even if the event was instantaneous and was confined within a single frame, you will observe the color changing to indicate lower and lower density values, until the signal finally disappears entirely.




Figure 28. With variable persistence, a brief CW signal captured by DPX remains in the display for an adjustable period of time before fading away.

## DPX density trigger

(Applies only to the RSA7100A with option TRIGH.)

The standard DPX display shows you a clear picture of transients and other hard-to-find signals and goes well beyond helping you discover these difficult to find signals by actually triggering on their appearance to capture them into acquisition memory for in-depth analysis. If you can see it in the DPX bitmap, you can trigger on it.

Other trigger methods can detect signals that exceed an amplitude threshold, or even a sophisticated amplitude vs. frequency mask, but they cannot find a signal at a particular frequency if another signal of higher amplitude is sometimes present at that same frequency. As shown in the following figure, the DPX Density trigger can discriminate signals within a precise amplitude-frequency range without the operator having to know any characteristics of the target signal besides where it might show up in the DPX Spectrum graph.






Figure 29. Example of Density Trigger. Left: A free-run DPX display showing pulses with varying frequency. Occasionally, a short pulse in the middle appears for a split instant, but it is hard to capture it with just a Run/Stop button. Right: The triggered DPX displays shows the low-amplitude pulse that was not apparent in the untriggered display. The analyzer was set to trigger whenever the average density in the user-drawn box measured 50% or higher.

The DPX Density trigger uses the same screen-based measurement box as the DPX Density measurement. While the target signal is absent, the density measurement characterizes the “normal” signals within the box. When the target signal finally appears, the density value increases. The trigger system monitors the density measurement and activates a trigger whenever the density value exceeds the adjustable density threshold. The only thinking you have to do is to set this threshold to a level somewhere between the normal density readings and the density due to the trouble-making signal. However, the instrument software can compute the threshold value automatically.

### Trigger On This™

The Trigger On This™ function allows you to point and click to set up the DPX density trigger. By right-clicking on a spot within the DPX display, or pressing and holding your finger on the touchscreen display for about a second, a menu selection will appear. Selecting **Trigger On This** causes a DPX Density box to appear and automatically adjusts the threshold. The DPX display will now only update whenever the automatic threshold is exceeded. Subsequently, if needed for your signal, open the Trigger control panel to adjust the density threshold or the size of the measurement box until the event is reliably captured.

### DPX density trigger timing

The time resolution for DPX density measurements is the frame length, around 50 ms. A basic implementation of the DPX density trigger concept is also frame-based, so a trigger event that occurs anywhere within a frame will not be recognized until the end of the frame. Therefore, the worst case trigger uncertainty is 50 ms.

DPX density trigger doesn't always have to wait until the end of a frame before firing. For the common configuration of triggering when the measured density is higher than the threshold, the density measurement in the trigger can be computed many times within each frame and it can fire the trigger as soon as the threshold is exceeded.

Consider the case where the threshold is zero. As soon as a single waveform causes a hit within the measurement box, we know that the density is greater than zero. It takes a little longer to test for a 5 or 10% density, and even more time for thresholds at or near 100%.

The DPX density trigger can also be set to fire when the measured density is below the threshold value. This is useful when you suspect that your signal is missing some of the time. For a signal that is supposed to be CW, you can set the trigger controls to acquire when the density measurement of the signal peak drops below 100%. When using the “lower than” form of the DPX density trigger, the time resolution is one frame because of the following logic: We can't be sure the actual density is less than, say, 15% until at least 85% of the full test time has elapsed. In order to keep things simple and fast in the trigger module, the RSA just waits until the end of each 50 ms frame to do the “lower than” comparisons.

### Persistence and DPX density trigger

The smoothing effect of persistence on density measurements can help in determining a good threshold value. With persistence turned off, an infrequent signal's density reading jumps between higher and lower values as it turns on and off, and it can be hard to read these flashing numbers. By turning persistence on, you instruct the instrument to average the density over a longer time period. This density result is somewhere between the ON and OFF density values - the very definition of a good trigger threshold.

Like the DPX density measurement, the DPX density trigger is affected by persistence. The trigger decision is made on the persisted measured value in the box.

## DPX display overview

The DPX display enables you to see how traces change over time and thus displays signal events that cannot be seen on a swept spectrum analyzer. A DPX Spectrum indicates how traces change in two ways. First, it uses color shading to show how consistent the shape of a trace is. Second, it uses persistence to hold signals on the screen so you can see them longer.

Read more about the DPX display in the following topics:

[DPX display \(see page 74\)](#)

[DPX settings \(see page 80\)](#)

## DPX display

The DPX display works by using a two-dimensional array to represent points on the display. Each time a trace writes to a point on the display, a counter in the array is incremented. A color is assigned to each point in the display based on the value of its counter. Thus, as acquisitions occur over time, a colored waveform, the Bitmap, develops on the display that shows how frequently each display point has been written to.

An important feature of the DPX display is dot persistence. Dot persistence sets how long a point on the display will be visible. You can set the Dot Persistence to be Variable or Infinite. In variable persistence mode, you specify a decay period that limits how long a point will be displayed. In infinite persistence mode, once a point in the display has been written to, it will remain visible indefinitely.

---

**TIP.** See the [Features by product \(see page 14\)](#) topic for more information about which features are available with which connected analyzers.


---

The DPX display can plot the trace in the following views:

- **Spectrum** – This view plots power on the vertical axis versus frequency on the horizontal axis. This display is similar to a standard Spectrum display. In the spectrum display, you can view any of three traces, a math trace, and the selected DPX-ogram trace.
- **DPXogram** (available when an RSA306, RSA306B, RSA500A series, RSA600A series, or RSA7100A instrument is connected). This view is a spectrogram version (time plotted along the vertical axis versus frequency on the horizontal axis) of the DPX Spectrum trace. DPX spectrogram (on the instrument that created the DPX acquisition data) creates the spectrogram in real time, and does not require an acquisition to be transferred into memory and analyzed. Because of this real time processing, there are no gaps in the spectral lines, even for monitoring periods that can last for several days.
- **Split** - This view consists of two DPX views. A DPXogram view appears on the top half of the display and a DPX Spectrum view appears on the bottom half of the display.


To display a DPX view:

1. Recall a DPX waveform acquisition data file.
2. Select **Frequency** and set the measurement frequency.
3. Select the **Displays** icon or **Setup > Displays**. This displays the **Select Displays** dialog box.
4. From the **Measurements** box, select **General Signal Viewing**.
5. Select **DPX** from the **Available displays** box.
6. Click the **Add** button. This will add the DPX icon to the Selected Displays box (and remove it from the Available displays box).
7. Click the **OK** button. This displays the DPX Spectrum view.
8. Select the desired view from the drop-down list on the left side of the graph.




Example of the DPX Split view

### Elements of the DPX display



Item	Display element	Description
1	Vert Position	Sets the top of graph value. This is only a visual control for panning the graph. The Reference Level is adjusted in the Toolbar and the Ampl control panel. By default, Vert Position = Ref Level.
2	Units	Sets the global Amplitude units for all the views in the analysis window. This will change the Amplitude selection in the Units tab of Analysis control panel.
3	dB/div	Sets the vertical scale value. The maximum value is 20.00 dB/division.
4	RBW	Sets the resolution bandwidth. Note that when the RBW is set to Auto, its value is italicized.
5	DPX view	Selects the DPX view. Choices are Spectrum, DPXogram, and Split.
6	Autoscale	Adjusts the Vertical and Horizontal scaling to display the entire trace on screen.
7	CF	Adjusts the analyzer center frequency.
8	CF indicator	Indicates the center frequency.
9	Span/Scale	Span - Adjusts frequency range of the measurement. Scale - If Horizontal scale has been manually adjusted in Settings > Scale, then this control adjusts the visual graph scaling without affecting the Span.
10	Clear	Erases the bitmap and traces in the graph and restarts multi-trace functions (Avg, Hold).
11	Function	Readout of the Detection and Function selections for the selected trace.
12	Show	Controls whether the selected Trace is visible or not. When trace is Off, the box is not checked.
13	Trace	Selects a trace. Touching here pops up a context menu listing the available traces, whether they are enabled or not. If you select a trace that is not currently enabled, it will be made enabled.

## Additional elements of the DPXogram split display



This display is only available when a compatible real time spectrum analyzer is connected.

Item	Display element	Description
1	Spectrums/line	Appears only when the display is stopped. Readout of the number of spectrum lines represented by each line of the DPXogram display. This value changes when the Time/div or Time resolution settings are changed. Line time depends on RBW and FFT processing.
2	DPXogram trace	The selected line in the DPXogram graph can be shown in the DPX Spectrum graph of the Split view. The most recent DPXogram line, usually at the bottom of the graph, is selected by default. If any markers are on, the selected marker determines the selected line.
3	Color scale	Legend at the right side of the DPX Spectrum display. This element illustrates the relationship between the colors in the DPXogram plot and the amplitude axis of the DPX Spectrum plot. This scale changes with Color (DPXogram) palette selection and Max and Min settings on the Ampl Scale tab.

## Time resolution of DPXogram display

Due to the large amount of data produced by the DPX hardware during acquisitions, a compressed version of the plot is shown while running. This plot is limited to 500 lines, with each line having 267 points. However, a much longer record, with higher frequency resolution is being collected. As soon as the instrument is stopped, this underlying data is shown, replacing the temporary version. There are 50 lines in each vertical division of the 2-D DPXogram plot, so the time resolution of the graph is Time/div

divided by 50. However, you can set the instrument to collect multiple spectra per line, allowing you to zoom in later on this high-time-resolution data.

$$\text{Time Resolution} = \frac{10 \times \text{Time/Division}}{500}$$

When the DPXogram display is stopped, the analyzer can display the full resolution of the captured data. The Time Resolution readout applies only when the DPXogram is running.

**Effects of changing time resolution.** The Time Resolution control affects acquisition parameters for the DPX hardware. This means that if you change the Time Resolution value while the instrument is stopped, the new value applies to the NEXT acquisition, and might not represent the results currently shown in the display.

Time resolution can be changed either directly, by manually adjusting the Time Resolution control, or automatically, by changing the Time/div control. Auto is the default, yielding one spectrum per line in the display. When the Time Resolution is decreased below its auto value, multiple spectra are collected to create each line in the DPXogram graph. Once you stop the instrument, you can decrease the Time/div value or use Zoom to see increased time resolution.

If the time resolution is set to a very small number while the Time/div is set to a large value, you might notice that there is a limit to the number of spectra that can be collected. This limit depends on the number of trace points selected. The number of lines available for the USB-RF instruments and the RSA7100A are different. The RSA7100A has a much deeper memory for this application and can display over 1 million lines, depending up the selected trace length. See individual datasheets for more information. The time capacity for any combination of settings is displayed in the Time and Frequency panel of the DPX settings display.

### Screen actions on markers in the graph area

Action	Description
Mouse click within 1/2 div. of a marker	Selects the marker and updates the marker display to show the selected marker's values.
Click on a marker to select and then use the arrow keys to move the marker	Adjust the setting associated with the Marker.
Click and drag a marker	Changes marker position to the "drop point". You can use Tools > Options > Prefs to change whether markers jump from one peak to the next while dragging or move smoothly along the trace.

### Available traces for display

The DPX display can be viewed as a DPX Spectrum display or as a Split display. The Split display consists of a DPXogram display on the top half and a DPX Spectrum display on the bottom half.

For the DPXogram display, only one trace is available: the DPXogram trace.

For the Split display, you can display the Bitmap trace, Trace 1, Trace 2, Trace 3, Math trace, and Ogram Line (the selected line from the DPXogram display) on the DPX Spectrum portion of the display.



---

**NOTE.** The DPXogram display is only available when a compatible real time spectrum analyzer is connected.

---

See also. [Changing the DPX Display Settings \(see page 80\)](#)

## DPX settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The measurement settings for the DPX display are shown in the following table.

Settings tab	Description
<a href="#">Freq &amp; Span (see page 114)</a>	Sets frequency and span parameters for the DPX display. This tab appears for the Spectrum and DPXogram displays.
<a href="#">BW (see page 119)</a>	Sets Resolution Bandwidth.
<a href="#">Traces (see page 81)</a>	Allows you to select the number and types of traces to display and their functions.
<a href="#">Horiz &amp; Vert Scale (see page 85)</a>	Sets the vertical and horizontal scale parameters for all the DPX views. (Available only when Spectrum view is active.)
<a href="#">Bitmap Scale (see page 86)</a>	Sets the DPX Bitmap display parameters. (Available only when Spectrum view or Split view is active.)
<a href="#">Amplitude Scale</a>	The Amplitude Scale tab allows you to change the vertical scale and offset, enable the 3-D Waterfall display, and set the color scheme used for the DPXogram trace. (Available only when DPXogram view or Split view is active.)
<a href="#">Time &amp; Freq (see page 103)</a>	The Time and Freq Scale tab allows you to change the vertical and horizontal scale settings, number of points in the trace, and Time resolution. (Available only when DPXogram view or Split view is active.)
<a href="#">Prefs (see page 122)</a>	Specifies whether certain display elements are visible.
<a href="#">Density (see page 88)</a>	Specifies location and size for the DPX Density measurement box. (Available only when Spectrum view or Split view is active.)

---

**TIP.** See the [Features by product \(see page 14\)](#) topic for more information about which features are available with which connected analyzers.

---



## Traces tab

The Traces tab allows you to set the display characteristics of displayed traces in the DPX display. The Traces tab settings vary depending on the DPX display view enabled (Spectrum, DPXogram, or Split).

The screenshot shows the 'Traces' tab selected in the DPX display interface. The tabs at the top are 'Freq & Span', 'BW', 'Traces', 'Horiz & Vert Scale', 'Bitmap Scale', and 'Prefs'. The 'Traces' tab contains the following settings:

- Trace: Trace1 (dropdown menu)
- ☒ Show
- ☐ Freeze
- Save Trace As... (button)
- Detection: Avg (VRMS) (dropdown menu)
- ☐ Count
- ☐ Show recalled trace
- Function: Avg (VRMS) (dropdown menu)
- 10 (text input field)
- [...] (button)

Traces tab with Trace1 and average selected

The screenshot shows the 'Traces' tab selected in the DPX display interface. The tabs at the top are 'Freq & Span', 'BW', 'Traces', 'Ampl Scale', 'Time & Freq', and 'Prefs'. The 'Traces' tab contains the following settings:


- Trace: DPXogram (dropdown menu)
- ☒ Show
- ☐ Freeze
- Detection: +Peak (dropdown menu)

Traces tab with DPXogram selected

The screenshot shows the 'Traces' tab selected in the DPX display interface. The tabs at the top are 'Freq & Span', 'BW', 'Traces', 'Horiz & Vert Scale', 'Bitmap Scale', 'Prefs', 'Density', and 'Audio Demod'. The 'Traces' tab contains the following settings:

- Trace: Bitmap (dropdown menu)
- ☒ Show
- ☐ Freeze
- Save Trace As... (button)
- ☒ Dot Persistence
- ☒ Variable: 1.0 s (text input field)
- ☐ Infinite
- ☐ Show recalled trace
- [...] (button)

Traces tab with Bitmap selected



Traces tab with Math Trace selected

**NOTE.** The DPXogram display is only available when a compatible real time spectrum analyzer is connected.

Setting	Description
Trace drop-down list	Selects which trace to configure. The available traces are Bitmap, Trace 1, Trace 2, Trace 3, and Math. A DPXogram trace selection is also available when an RSA306, RSA306B, RSA500A series, RSA600A series, or RSA7100A instrument is connected.
Show	Specifies whether or not the trace shown in the Trace setting is displayed.
Freeze	Halts updates to the selected trace.
Detection	Sets the Detection method used for the trace. Available detection methods are +Peak, -Peak, and Avg (VRMS).
Function	Selects the trace processing method. Available settings are: Normal, Average, and Hold.
Count	Sets the number of traces averaged to generate the displayed trace. (Present only when Function is set to Average.)
Intensity (Available only when Bitmap is selected)	Use Intensity to control the visibility of events. An increased intensity level allows a single, short event to be seen. This also makes such an event subject to the persistence controls. This allows you to see the effect of the Persistence controls on infrequent events. Range is 1-100%. Resolution: 1.
Dot Persistence (Available only when Bitmap is selected)	Allows a dot to remain visible if it is not updated with new data. Choices for this setting are Variable and Infinite.
Variable	The Variable dot persistence setting controls how long a point in the display is visible before fading. Range: 100 ms – 60 s. Resolution 0.1.
Infinite	The Infinite dot persistence setting prevents a point in the display from fading (not available for the DPXogram trace).
Trace minus Trace (Available only when Math Trace is selected)	The Math trace is a mathematically-derived trace defined as Trace A minus Trace B. You can select Trace 1, 2, or 3 to serve as either Trace A or Trace B.
Save Trace As	Saves the selected trace to a file for later recall and analysis.
Show Recalled Trace	Displays a saved trace instead of a live trace.

## Detection

Trace Detection occurs when the trace is being decimated by the measurement. For example, if the maximum number of trace points is 100,000, and the selected analysis region is 200,000 samples, the measurement must decimate the 200,000 resulting trace points by 2 to prevent exceeding the 100,000 trace point limit. Since only one value can be selected for each trace point, an algorithm must be used to select (detect) the appropriate value to use.

The available detection methods are:

- **+Peak** – Each point on the trace is the result of detecting the positive peak value present in the set of IQ samples available to that trace point.
- **-Peak** – Each point on the trace is the result of detecting the negative peak value present in the set of IQ samples available to that trace point.
- **Avg (VRMS)** [Average  $V_{RMS}$ ] – Each point on the trace is the result of determining the RMS Voltage value for all of the IQ samples available to the trace point. When displayed in either linear (Volts, Watts) or Log (dB, dBm), the correct RMS value results. When the averaging function is applied to a trace, the averaging is performed on the linear (Voltage) values, resulting in the correct average for RMS values.

---

**NOTE.** *The Detection setting does not affect the trace until the spectrum length is longer than the Auto setting.*

---

## Dot Persistence

Dot Persistence is the characteristic of the DPX display that determines how long a pixel in the display remains visible.

To set the Persistence:

1. Select **Setup > Settings**.
2. Select the **Traces** tab.
3. Select the Bitmap trace.
4. Select **Dot Persistence**.
5. Select either **Infinite** or **Variable**.
6. If you select Variable, enter a value in the text box. The Variable persistence value can be set from 0.05 to 100 seconds.

## DPX Trace Processing

The +Peak, -Peak, and Average traces can be processed to display in different ways. The Function setting controls trace processing.

- **Hold** - Displays the value in the trace record for each display point. Each new trace display point is compared to the previous maximum value and the greater value is retained for display and subsequent comparisons. Available for traces using +Peak or -Peak detection.
- **Normal** - Displays the trace record for each display point without additional processing. Available for all detection selections.
- **Average** - Default setting for the Average. Multiple traces are averaged together to generate the displayed trace. There is one vertical value for each underlying frequency data point. Once the specified number of traces have been acquired and averaged to generate the displayed trace, each new trace takes the place of the oldest trace in the calculation. The **Count** setting specifies how many traces are averaged. Available for traces using Average detection.

Trace averaging uses the exponential method. If Count = 10, the newest trace's contribution to the averaged trace is 10%. When Count is not checked, the algorithm assumes the maximum number of traces contributing to the average is  $2^{32}$ .

## Saving Traces

To save a trace for later analysis:


1. Select the **Save Trace As** button. This displays the Save As dialog box.
2. Type a name for the saved trace and click **Save**.

## Recalling Traces

You can recall a previously saved trace for comparison to a live trace. First, specify a trace for recall and second, enable Show Recalled Trace.

To select a trace for recall:

1. Click the ... button to display the Open dialog box.



2. Navigate to the desired file and click **Open**.
3. Check the **Show Recalled Trace** check box.
4. Verify that the trace's **Show** check box is selected (either on this tab or next to the drop-down list located at the top-left corner of the graph).

## Horiz & Vert Scale Tab


The Horiz & Vert Scale tab allows you to change the vertical scale settings used for the Bitmap trace. Changing the scale settings changes how the trace appears on the display but does not change control settings such as Measurement Frequency.

The screenshot shows the 'Horiz & Vert Scale' tab selected. It contains two main sections: 'Vertical' and 'Horizontal'. The 'Vertical' section has a 'Scale' input field set to '100.00 dB' and a 'Position' input field set to '0.00 dBm', with an 'Autoscale' button below. The 'Horizontal' section has a 'Scale' input field set to '1.000 s' and a 'Position' input field set to '0.000 s', also with an 'Autoscale' button below. The top of the window shows other tabs: 'Params', 'Freq & BW', 'Traces', 'Horiz & Vert Scale' (active), 'Bitmap Scale', and 'Prefs'.

Setting	Description
Vertical	Controls the vertical position and scale of the trace display.
Scale	Changes the vertical scale.
Offset	Adjusts the Reference Level away from the top of the trace display.
Reset Scale	Sets Scale to its default value and Offset to zero. Disabled when Units (Setup > Analysis > Units) is set to Watts or Volts.
Autoscale	Resets the scale of the vertical axis to contain the complete trace. Disabled when Units (Setup > Analysis > Units) is set to Watts or Volts.
Horizontal	Controls the horizontal position and scale of the trace display.
Scale	Changes the horizontal scale.
Position	Adjusts the horizontal position of the signal. This does not change the center frequency.
Autoscale	Resets the scale of the horizontal axis to contain the complete trace.

## Bitmap Scale Tab

The Bitmap Scale tab allows you to set the color scheme used for the Bitmap trace. Changing the DPX bitmap Color, Max and Min scale settings changes how the trace appears on the display but does not change control settings such as Measurement Frequency.



Setting	Description
DPX Bitmap (Signal Density)	Controls the appearance and scale of the DPX Bitmap trace.
Color	Allows you to select the color palette used for the DPX Bitmap trace.
Max	Sets the hit density represented by the top of the color scale. "Clipping" occurs for densities greater than this value. Range: 1p% - 100%; Default: 100%.
Min	Sets the hit density represented by the bottom of the color range. Range: 0 - 80%; Default: 0.
Curve	Adjusts how colors are mapped to the signal density. The mapping can be linear (Curve = 1), or it can be set to concentrate the resolution on the lower level of the range (Curve > 1) or the mapping can be set to show the best resolution on the upper range of density or hit count (Curve < 1).
Auto Color	Adjusts the Max and Min settings to display the broadest range of colors.

## Time & Freq Tab


The Time and Freq tab allows you to change the vertical and horizontal scale settings, and set the time resolution and number of trace points of the DPXogram display.

The screenshot shows the 'Time & Freq' tab selected in a software interface. It contains two main sections: 'Vertical (time)' and 'Horizontal (frequency)'. The 'Vertical (time)' section includes fields for 'Time/div' (2.50 s), 'Trace Points' (801), 'Position' (0.0 div), 'Time resolution' (50.0 ms), 'Time at position' (0.000 s), and a 'Capacity (DD:HH:MM:SS)' readout (0:50:00). There is a 'Reset Scale' button. The 'Horizontal (frequency)' section includes fields for 'Scale' (40.00 MHz) and 'Position' (1.00000 GHz), with an 'Autoscale' button.


Setting	Description
<b>Vertical (time)</b>	
Time/div	For most Spectrogram applications. Primary time scale control is Time/div. Time scale can be zoomed in or out when acquisitions are stopped.
Position	The position of the DPXogram record at the bottom of the display. Position cannot be changed while acquisitions are active, and is reset to zero when acquisitions are started again.
Time at position	Displays the time of the DPXogram line shown at the bottom of the graph. This time is relative to the Time Zero Reference of the current acquisition. If Position is set to a negative value, the Time at position readout will be blanked.
Reset Scale	Sets the Time/div and Position settings to their default values.
Trace Points	Sets the number of trace points computed for each DPXogram line. These are the points used for marker measurements and for results export.
Time resolution	Specifies the length of time represented by each line in the graph. 'Line time depends on RBW and FFT processing.
Auto	Sets the time represented by each line in the graph to be adjusted by the analyzer checked) or manually (when unchecked). When Auto is enabled, Time Resolution change based on Time/div.
Capacity	Readout of the total length of time that can be captured. This readout is provided so that you can see how changing the Trace Points and Time resolution affects the amount of data that can be captured. Capacity is represented in the format dd:hh:mm:ss.
<b>Horizontal (frequency)</b>	
Scale	Sets the displayed frequency range of the graph. This control affects only visual scaling, and does not change the acquisition or analysis parameters.
Position	Sets the frequency displayed at the center of the graph. Changing this value does not change the Frequency setting.
Autoscale	Sets the frequency scale to the Spectrogram Span value.

## Density Tab

The Density tab specifies the parameters of the measurement box used for measuring average signal density of an area in the bitmap. The measurement box is also used by DPX Density triggering.



To measure the average signal density over a rectangular portion of the DPX bitmap, you can adjust the size and location of the measurement area using these controls, or by dragging the measurement box in the graph. You move the box by dragging the readout. You adjust the size of the box by dragging the corners or edges.



Setting	Description
Show Measurement	Shows or hides the measurement box in the graph when Triggering is not set to DPX Density. If Triggering is set to DPX Density, the measurement box is always visible.
Frequency	Specifies the frequency at the center of the measurement box. The +/- value specifies the width of the measurement box.
Amplitude	Specifies the amplitude of the center of the measurement box. The +/- value specifies the height of the measurement box.




## Time Overview Display

The Time Overview display shows the entire acquisition record and shows you how the spectrum time and analysis time fit within the acquisition record. This enables you to see how you can adjust the spectrum time and analysis time to measure portions of the data.

You can specify the maximum number of trace points in the Time Overview display. You can set the maximum number of trace points to 1K, 10K, 100K, 1M points or to Never decimate. If the Acquisition Length includes more than 10,000 sample points (and Max trace points is not set to Never decimate), the trace is decimated (using the +Peak method, similar to +Peak detection in a Spectrum display) to 10,000 points. This decimated trace is what is used for marker measurements.

The Time Overview window displays the Spectrum Length and Analysis Length. The Spectrum Length is the period of time within the acquisition record over which the spectrum is calculated. The Analysis Length is the period of time within the acquisition record over which all other measurements (such as Amplitude vs. Time) are made. The Spectrum Length and Analysis Length can be locked together so that the data used to produce the Spectrum display is also used for measurement displays; however, they do not have to be tied together. They are by default specified separately and used to analyze different parts of the acquisition record.

### Elements of the Time Overview Display



Item	Element	Description
1	Time	Select the type of time analysis to be performed. You can select Analysis, Spectrum, or Linked.
2	Offset	Sets the offset of the selected analysis time control.
3	Length	Sets the length of the selected analysis time control.
4	Position and Scale	Adjusts the vertical scale and position.
5	Scale indicators	Shows the vertical scale.
6	Autoscale button	Resets the horizontal scale to display the entire acquisition record and the vertical scale to show all trace points.
7	Horizontal offset	Adjusts the horizontal offset.
8	Results Timeline	This fuchsia line indicates the portion of the record actually used for calculating the selected result. For example: if a pulse measurement is selected, it shows the period of the specific pulse. For a constellation display, it shows the points included in the demodulation.
9	Amplitude vs. Time graph	The trace represents the entire acquisition record (at full horizontal scale). The graph indicates the Analysis Length or Spectrum Length on the graph with a darker background.
10	Horizontal Scale	Adjusts the span of the graph. By decreasing the scale, the graph essentially becomes a window that you can move over the acquisition record by adjusting the offset.
11	Spectrum Length and Offset Indicator (red line, top of graph)	This red line indicates the Spectrum Length and Offset. The longer the time, the longer the bar. Adjusting the offset shifts the bar left or right.
12	Analysis Length and Offset Indicator (blue line, top of graph below red line)	The blue line indicates the Analysis Length and Offset. The longer the time, the longer the bar. Adjusting the offset shifts the bar left or right.

**NOTE.** The area with black background (not gray) in the Amplitude vs. Time Graph highlights the control selected in the Analysis Time Control drop-down list.

[Changing the Time Overview Display Settings \(see page 90\)](#)

## Time Overview Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The Setup settings for Time Overview are shown in the following table.

Settings tab	Description
<a href="#">Scale (see page 121)</a>	Adjusts the vertical and horizontal scale and offset of the display.
<a href="#">Trace (see page 93)</a>	Allows you to select the types of trace to display and its function.
<a href="#">Prefs (see page 122)</a>	Specifies whether or not certain display elements are shown.


## Navigator View

The Time Overview Navigator View places the Time Overview display across the top of the application screen. This allows you to adjust the area of interest in the Navigator View and see the results simultaneously in the other displays. For example, in the following image, adjusting the mask in the Navigator View moves the trace and markers in all of the other displays.



### Show Navigator View

To show the Navigator View, select **View > Navigator View**. To remove the Navigator View, deselect Navigator View in the View menu.



## Trace Tab

The Trace Tab allows you to set the display characteristics of displayed traces.

Setting	Description
Show	Shows / hides the selected trace.
Detection	Sets the Detection method used for the trace. Not available for saved traces. Available detection methods are +Peak, -Peak, +/-Peak, Avg (VRMS), and Sample. Not all detection methods are available in all displays.
Function	Selects the trace processing method. Available settings are: Normal, Average, Max Hold, and Min Hold.
(Number of Traces)	Sets the number of traces averaged to generate the displayed trace. (Present only when Function is set to Average.)
Freeze	Halts updates to the selected trace.
Save Trace As	Saves the selected trace to a file for later recall and analysis.
Show Recalled trace	Displays a saved trace instead of a live trace.

### Detection

Trace Detection occurs when the trace is being decimated by the measurement. For example, if the maximum number of trace points is 100,000, and the selected analysis region is 200,000 samples, the measurement must decimate the 200,000 resulting trace points by 2 to prevent exceeding the 100,000 trace point limit. Since only one value can be selected for each trace point, an algorithm must be used to select (detect) the appropriate value to use.

The IQ samples in a data acquisition can be detected in a variety of ways. The number of IQ samples available to each trace point varies with both analysis length and trace length. For example, with Spectrum Length set to 'Auto' in the Analysis menu, the instrument analyzes just enough samples to produce one IQ sample pair per trace point. In this case, the detection method chosen has very little effect, as the +Peak, -Peak, Avg (VRMS) and Sample values are all equal. Changing the Spectrum Length causes the available detection methods to differ in value because they have a larger set of samples for the various detection methods to process.

The available detection methods (depending on the display) are:

- **+Peak** – Each point on the trace is the result of detecting the positive peak value present in the set of IQ samples available to that trace point.
- **-Peak** – Each point on the trace is the result of detecting the negative peak value present in the set of IQ samples available to that trace point.
- **+/-Peak** – Selects the highest and lowest values of all the samples contained in two consecutive acquisition intervals.
- **Avg (VRMS)** [Average  $V_{RMS}$ ] – Each point on the trace is the result of determining the RMS Voltage value for all of the IQ samples available to the trace point. When displayed in either linear (Volts, Watts) or Log (dB, dBm), the correct RMS value results. When the averaging function is applied to a trace, the averaging is performed on the linear (Voltage) values, resulting in the correct average for RMS values.
- **Sample** – The result is calculated based on the first sample available in the set of IQ samples for each trace point.


## Trace Processing

Traces can be processed to display in different ways. The Function setting controls trace processing.

- **Normal** - Each new trace is displayed and then replaced by the next trace. Each data point contains a single vertical value.
- **Average** - Multiple traces are averaged together to generate the displayed trace. There is one vertical value for each underlying frequency data point. Once the specified number of traces have been acquired and averaged to generate the displayed trace, each new trace takes the place of the oldest trace in the calculation. The **Number of Traces** setting specifies how many traces averaged.
- **Max Hold** - Displays the maximum value in the trace record for each display point. Each new trace display point is compared to the previous maximum value and the greater value is retained for display and subsequent comparisons.
- **Min Hold** - Displays the minimum value in the trace record for each display point. Each new trace display point is compared to the previous minimum value and the lesser value is retained for display and subsequent comparisons.

## Saving Traces

To save a trace for later analysis:


1. Select the Save icon . This displays the Save As dialog box.
2. Navigate to the desired folder or use the default.
3. Type a name for the saved trace and click **Save**.

## Recalling Traces

You can recall a previously saved trace for analysis or comparison to a live trace.

To select a trace for recall:

1. Select the trace into which the recalled trace will be loaded, from the Trace drop-down list.
2. Check the **Show** check box.
3. Click the ... button to display the Open dialog box.




4. Navigate to the desired file and click **Open**.
5. Check the **Show Recalled Trace** check box.
6. Verify that the trace's **Show** check box is selected (either on this tab or next to the drop-down list located at the top-left corner of the graph).

## Spectrum Display

To display a spectrum:

1. Click the **Displays** button or select **Setup > Displays**.
2. From the Measurements box, select **General Signal Viewing**.
3. Double-click the **Spectrum** icon in the **Available displays** box. This adds the Spectrum icon to the **Selected displays** box (and removes it from the Available displays box). Alternatively, you can click the Spectrum icon and then click the Add button to select Spectrum for display.
4. Click the **OK** button.

## Elements of the Spectrum Display





Item	Display element	Description
1	Vertical position	Sets the top of graph value. This is only a visual control for panning the graph. The Reference Level is adjusted in the Toolbar and the Amplitude control panel. By default, Vert Position = Ref Level.
2	Units	Sets the global Amplitude units for all the views in the analysis window. This will change the Amplitude selection in the Units tab of Analysis Control panel.
3	dB/div	Sets the vertical scale value. The maximum value is 20.00 dB/division.
4	RBW	Sets the resolution bandwidth. Note that when the RBW is set to Auto, its value is italicized.
5	VBW	Enables the VBW (Video Bandwidth) filter. See Setup > Settings > <a href="#">BW Tab (see page 119)</a> .
6	Autoscale	Adjusts the Vertical and Horizontal scaling to display the entire trace on screen.
7	Position	Default function is CF - center frequency (equivalent to the Freq setting). If Horizontal scaling has been manually adjusted in Settings > Scale, then Offset will replace CF as the setting at the bottom-left corner of the screen.
8	CF indicator	Indicates the center frequency.
9	Span / Scale	Default function is Span - frequency difference between the left edge of the display and the right edge. If Horizontal scaling has been manually adjusted in Settings > Scale, then Scale will replace Span as the setting at the bottom-right corner of the screen.
10	Clear	Restarts multi-trace functions (Avg, Hold).
11	Function	Readout of the Detection and Function selections for the selected trace.
12	Show	Controls whether the selected Trace is visible or not. When trace is Off, the box is not checked.
13	Trace	Selects a trace. Clicking here pops up a context menu listing the available traces, whether they are enabled or not. If you select a trace that is not currently enabled, it will be made enabled.

[Changing the Spectrum Display Settings \(see page 97\)](#)

## Spectrum Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the Spectrum display are shown in the following table.

Settings tab	Description
<a href="#">Freq &amp; Span (see page 114)</a>	Sets frequency and span parameters for the Spectrum Analysis display.
<a href="#">BW (see page 119)</a>	Sets Resolution Bandwidth and windowing parameters.
<a href="#">Traces (see page 115)</a>	Sets Trace display parameters.
<a href="#">Traces (Math) (see page 119)</a>	Sets the traces used to create the Math trace.
<a href="#">Scale Tab (see page 98)</a>	Sets vertical and horizontal scale and position parameters.
<a href="#">Prefs Tab (see page 122)</a>	Specifies whether or not certain display elements are shown.

## Scale Tab

The Scale tab allows you to change the vertical and horizontal scale settings. Changing the scale settings changes how the trace appears on the display but does not change control settings such as Measurement Frequency. In effect, these controls operate like pan and zoom controls.



Setting	Description
<b>Vertical</b>	
Scale	Changes the vertical scale.
Position	Vertical Position adjusts the top of graph amplitude value. This control allows you to move ("pan") the traces up and down in the graph without changing the Reference Level.
Autoscale	Resets the Offset so that the trace appears below the top of the graph.
<b>Horizontal</b>	
Scale	Allows you to change the range of frequencies shown in the graph without changing the span or measurement frequency.
Position	Allows you pan the graph.
Autoscale	Resets Scale to the Span setting.
Reset Scale	Resets all settings to their default values.
Log scale	Resets the display to show the frequency axis in a logarithmic scale.

## Spectrogram Display

The Spectrogram is a display with the vertical axis (time) composed of successive spectral displays, each having the amplitude represented by color or intensity. The horizontal axis represents frequency. The most recently acquired spectrum results are added to the bottom of the spectrogram. The addition of a new spectrum can occur at the fastest rate that new spectra can be plotted, or, if you choose, new spectra can be added at a timed rate. The spectrogram view is well-suited to displaying long-term trends of spectral data. The maximum number of lines that can be displayed in a spectrogram is 31,250.

The spectrogram can also be displayed in a 3-D waterfall format. In the 3-D waterfall format, the spectrogram displays the time axis along a simulated Z-axis.

---


**NOTE.** Spectrogram data is shared with the Spectrum display. There is no linkage between DPX and Spectrogram.


---

To display a Spectrogram:

1. Select the **Displays** button or select **Setup > Displays**. This displays the **Select Displays** dialog box.
2. From the **Measurements** box, select **General Signal Viewing**.
3. Double-click the **Spectrogram** icon in the **Available Displays** box. This adds the Spectrogram icon to the Selected displays box.
4. Click the **OK** button. This displays the spectrogram view.
5. To display a 3-D version of the spectrogram, select the 3-D checkbox.

### Elements of the Spectrogram Display





Item	Display element	Description
1	Check mark indicator	The check mark indicator in the upper, left-hand corner of the display shows when the Spectrogram display is the optimized display.  <b>NOTE.</b> When Best for multiple windows is selected in the Amplitude control panel's RF & IF Optimization control, none of the measurement displays shows a checkmark, as there is not a single optimized measurement.
2	Time/div	Sets the length of time represented by each vertical division. Divisions are indicated by tick marks along the left edge of the graph.
3	RBW	Sets the resolution bandwidth. Note that when the RBW is set to Auto, its value is italicized.
4	VBW	Enables the VBW (Video Bandwidth) filter. See Setup > Settings > <a href="#">BW Tab (see page 119)</a> .
5	3-D checkbox	Enables and disables the 3-D view.
6	Selected records indicators	Shows the positions of the start and stop records selected on the Select data records tab. Drag the indicators to select which records will be played by Replay All. Note that these are not visible while acquisitions are running; the instrument must be stopped for the indicators to be visible.
7	T	Trigger indicator. This icon indicates the trigger point within the current acquisition.
8	Pos	Position indicates the bottom line visible in graph. Changing this setting scrolls the window up and down through the displayed acquisition records.
9	Autoscale	Resets Vertical and Horizontal scale and Pos to default values.
10	CF	Sets the Center Frequency.
11	Span	Sets the span of the spectrogram display.
12	Current data record indicator	A blue line indicates the current data record. When the analysis length is short, the blue line appears as a thin line much like the selected indicator line. When the analysis length is relatively long, the blue line appears more like a blue bar.
13	Position scroll bar	Changes the position of the trace in the window. Changing the position scroll bar is the same as adjusting the Pos setting.

Item	Display element	Description
14	Selected indicator	This inverse-colored line indicates the Spectrogram line that will appear in the Spectrum display when the Spectrogram trace is enabled. This line is attached to the selected marker.
15	Clear	Clears the spectrogram display; however, data records in acquisition history remain in memory and are available for replay. To clear memory, select <b>File &gt; Acquisition Data Info &gt; Delete All Data</b> .
16	Marker indicators	These icons indicate the position of markers in the spectrogram. You can move markers by dragging the desired marker indicator.
17	Detection setting	Displays the selected Detection method (see <a href="#">Settings &gt; Trace (see page 102)</a> tab).
18	Marker readout	Marker readout for the selected marker. In the Spectrogram display, the marker readout includes a date and timestamp. The time is displayed in a 24-hour format. The timestamp readout can be shown or hidden independently of the other marker readouts (see <a href="#">Settings &gt; Prefs (see page 122)</a> ).
19	Time Scale status readout	Three readouts can appear here depending on settings: Time/update, Spectrums/line, and Overlap. See <a href="#">Time Scale Status Readout (see page 101)</a> .

### Time Scale Status Readout

Three types of readouts can appear in the display depending on settings:

- Time/update – Displays minutes:seconds when Spectrum Monitor is selected in the **Settings > Time & Freq Scale** tab in the **Vertical (Time)** section.
- Spectrums/line – Displays an integer number when vertical scale is Normal and each line contains the results from one or more frequency transforms (whether zoomed out or not).
- Overlap – Displays the overlap percentage when vertical scale is Normal and each line's transform shares some points with the transforms of lines before and after it (zoomed in). Overlap can only be done when the Analysis Length > 2x RBW frame length.

The Spectrogram can show results from one or multiple acquisitions and it can show one or multiple lines for each acquisition.

[Changing the Spectrogram Display Settings \(see page 101\)](#)

## Spectrogram Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The Setup settings for the Spectrogram display are visible when Spectrogram is the selected display.

Settings tab	Description
<a href="#">Freq &amp; Span (see page 114)</a>	Sets frequency and span parameters for the Spectrogram display.
<a href="#">BW (see page 119)</a>	Sets Resolution Bandwidth and windowing parameters.
<a href="#">Trace (see page 102)</a>	Sets Trace display parameters.
<a href="#">Amplitude Scale (see page 103)</a>	Selects between 2-D and 3-D, sets height scale, position and orientation for 3-D display. Sets color parameters for the spectrogram trace.
<a href="#">Time &amp; Freq Scale (see page 103)</a>	Sets the vertical and horizontal scale parameters for the spectrogram trace. The Spectrum Monitor controls are also on this tab.
<a href="#">Prefs (see page 122)</a>	Specifies whether or not certain display elements are shown.

## Trace Tab

The Spectrogram Trace tab controls let you specify the Detection method, save traces, and recall saved traces for display. The Spectrogram Trace tab does not have all the controls that other Trace tabs contain, however, it does have a unique display element, the Selected Line readout. For details on Detection, Freeze, and saving and recalling traces, see the [Traces Tab \(see page 115\)](#).

### Selected Line

Displays the time at the Selected Line. If Markers are enabled, the selected line is positioned by the selected marker. If no markers are enabled, the selected line is the first line in the current analysis period.

## Amplitude Scale Tab

The Amplitude Scale tab allows you to change the vertical and horizontal scale settings, enable the 3-D Waterfall display, and set the color scheme used for the spectrogram trace.

Setting	Description
Height (3-D only)	
Scale	Changes the vertical scale for trace Amplitude in the graph (not the vertical scale for Time).
Position	Specifies the level displayed at the bottom edge of the graph. (Bottom front edge in the 3-D view).
Autoscale	Adjusts the vertical position and scale of the trace lines to bring them into the visible portion of the graph.
3-D Waterfall	Displays the spectrogram in a 3-D format.
Northeast	Shifts the perspective of the 3-D graph so that the oldest traces move back and to the right.
Northwest	Shifts the perspective of the 3-D graph so that the oldest traces move back and to the left.
Reset Scale	Resets the Height and Color settings to their default values.
Color (Power)	
Color	Displays a drop-down list that allows you to set the color scheme used for the spectrogram trace.
Max	Sets the maximum power level represented by the top of the color scale.
Min	Sets the minimum power level represented by the bottom of the color scale.

## Time & Freq Scale Tab

The Time and Freq Scale tab allows you to change the vertical and horizontal scale settings, enable the 3-D Waterfall display, and set the color scheme used for the spectrogram trace.

Setting	Description
<b>Vertical (Time)</b>	
Normal	For most Spectrogram applications. Primary time scale control is Time/div. Time scale can be zoomed in or out.
Spectrum Monitor	For long-term signal monitoring applications. In spectrum monitor mode, each line in the spectrogram represents the period of time specified by the Time/update parameter. Time scale can be zoomed out, but not zoomed in (no overlap).
Time/update	Sets the time, in minutes and seconds, represented by each line of the spectrogram. Only available in Spectrum Monitor.
Reset Scale	Resets the Time/div and Pos settings to their default values.
Autoscale	Scales the vertical (time) axis to compress all existing trace lines into the visible area of the graph. Resets the Position value to zero, placing the most recent spectrogram line at the bottom of the spectrogram display. Only Position is affected by Autoscale when Spectrum Monitor is selected.
Time/div	Sets the time displayed per division.
Visible elapsed time	Displays the length of time visible in the display. This does not represent the total time available to view.
Position	Adjusts vertical position of the trace within the graph area. Setting represents the offset, in divisions, between the bottom of the graph and the bottom (most recent) line in the results trace.
Time at position	Displays the time of the spectrogram line shown at the bottom of the graph. This time is relative to the Time Zero Reference of the current acquisition.
<b>Horizontal (Frequency)</b>	
Scale	Sets the frequency range of the graph without changing the Span value.
Position	Sets the frequency displayed at the center of the graph. Changing this value does not change the Freq setting.
Autoscale	Sets the frequency scale to the Spectrogram Span value.

## Spectrum Monitor

Spectrum Monitor performs long term monitoring. The monitor mode compresses time into each line of the spectrogram, which enables you to monitor long periods of time (from 1 second per line up to 600 minutes per line). You can capture up to 31,250 lines.

During each line's collection period, spectrum transforms are computed for each acquisition taken by the instrument. As each transform completes, it is incorporated into the current spectrogram line. How each line of the spectrogram is created in spectrum monitor mode depends on the detection setting (Settings >



Trace). For example, if Detection is set to +Peak, each spectrogram line is effectively a peak hold display of all the spectral data captured since the prior line.

## Amplitude Vs Time Display


The Amplitude vs. Time display plots the signal amplitude against time. The amplitude appears on the vertical axis while time is plotted along the horizontal axis.

Note that the trace(s) in the Amplitude vs. Time display can be set to a maximum of 100,000 points (however, the actual number of trace points can extend up to 1,000,000 points if Max trace points is set to Never Decimate). If the Analysis Length includes more than the selected Max trace points value, the trace is decimated (using the method specified with the Detection control) to be equal to or less than the Max trace points setting (except when Max trace points is set to Never Decimate). This decimated (or undecimated) trace is what is used for marker measurements and for results export. You can set the Max trace points on the **Settings > Prefs** tab.

To show Amplitude vs. Time display:

1. Press the **Displays** button or select **Setup > Displays**.
2. In the **Select Displays** dialog, select **General Signal Viewing** in the **Measurements** box.
3. In the **Available displays** box, double-click the **Amplitude vs. Time** icon or select the icon and click **Add**. The Amplitude vs. Time icon will appear in the **Selected displays** box and will no longer appear under Available displays.
4. Click **OK**.

### Elements of the Display



Item	Display element	Description
1	Vertical scale adjustment	Adjusts the vertical scaling.
2	Span	Adjust the bandwidth of the data to be analyzed. (Not the period of time shown in the display.)
3	Autoscale	Adjusts the vertical and horizontal settings to provide the best display.
4	Offset	Adjust the horizontal offset.
5	Max and Min readouts	Displays the maximum and minimum amplitudes, as well as when those values occur.
6	Scale	Sets the time spanned by the graph.
7	Clear button	Restarts multi-trace functions (Avg, Hold).
8	Trace function	Displays the current trace function setting (Settings > Trace tab > Function).

Reference. [Changing Amplitude vs Time Display Settings \(see page 106\)](#)

## Amplitude Vs Time Settings

**Main menu bar:** Setup > Settings


**Favorites toolbar:** 

The settings for the Amplitude vs. Time display are shown in the following table.

Settings tab	Description
<a href="#">Freq &amp; BW (see page 107)</a>	Sets the Bandwidth Method used for setting the measurement bandwidth.
<a href="#">Traces (see page 115)</a>	Allows you to select the type of trace to display and their functions.
<a href="#">Traces (Math) (see page 119)</a>	Sets the traces used to create the Math trace.
<a href="#">Scale (see page 121)</a>	Sets the vertical and horizontal scale parameters.
<a href="#">Prefs (see page 122)</a>	Specifies whether certain display elements are visible.

## Freq & BW Tab

The Freq & BW (Bandwidth) tab allows you to specify the bandwidth parameters used for setting measurement bandwidth. This determines what Acq BW the measurement will request.



### Settings Description

## Frequency Vs Time Display


The Frequency vs. Time Display shows how the signal frequency varies with time.

Note that the trace(s) in the Frequency vs. Time display can be set to a maximum of 100,000 points (however, the actual number of trace points can extend up to 1,000,000 points if Max trace points is set to Never Decimate). If the Analysis Length includes more than the selected Max trace points value, the trace is decimated (using the method specified with the Detection control) to be equal to or less than the Max trace points setting (except when Max trace points is set to Never Decimate). This decimated (or undecimated) trace is what is used for marker measurements and for results export. You can set the Max trace points on the **Settings > Prefs** tab.

To display the Frequency vs. Time Display:

1. Select the **Displays** button or **Setup > Displays**.
2. In the **Select Displays** dialog, select **General Signal Viewing** in the **Measurements** box.
3. In the **Available displays** box, double-click the **Frequency vs. Time** icon or select the icon and click **Add**. The Frequency vs. Time icon will appear in the **Selected displays** box and will no longer appear under Available displays.
4. Click **OK** to display the Freq vs. Time display.

## Elements of the Display



Item	Display element	Description
1	Top of graph adjustment	Use the knob to adjust the frequency range displayed on the vertical axis.
2	Offset adjustment	Adjusts the frequency shown at the center of the display.
3	Autoscale button	Adjusts the offset and range for both vertical and horizontal to provide the best display.
4	Maximum and Minimum frequency readouts	Displays the maximum and minimum values, as well as when those values occur.
5	Horizontal Scale	Sets the time spanned by the graph.
6	Clear button	Restarts Average trace.
7	Trace function	Displays the current trace function setting (Settings > Trace > Function).

[Changing Frequency vs Time Display Settings \(see page 108\)](#)

## Frequency Vs Time Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The Setup settings for Frequency vs. Time are shown in the following table.

Settings tab	Description
<a href="#">Freq &amp; BW (see page 113)</a>	Sets the frequency and bandwidth parameters.
<a href="#">Trace (see page 115)</a>	Sets the trace display parameters.
<a href="#">Scale (see page 121)</a>	Sets the Vertical and Horizontal scale and offset parameters.
<a href="#">Prefs (see page 122)</a>	Specifies whether certain display elements are visible.

## Phase Vs Time Display


The Phase vs. Time display plots the signal phase against time. The phase appears on the vertical axis while time is plotted along the horizontal axis.

Note that the trace(s) in the Phase vs. Time display can be set to a maximum of 100,000 points (however, the actual number of trace points can extend up to 1,000,000 points if Max trace points is set to Never Decimate). If the Analysis Length includes more than the selected Max trace points value, the trace is decimated (using the method specified with the Detection control) to be equal to or less than the Max trace points setting (except when Max trace points is set to Never Decimate). This decimated (or undecimated) trace is what is used for marker measurements and for results export. You can set the Max trace points on the **Settings > Prefs** tab.

To display Phase vs. Time:

1. Press the **Displays** button or select **Setup > Displays**.
2. In the **Select Displays** dialog, select **General Signal Viewing** in the **Measurements** box.
3. In the **Available displays** box, double-click the **Phase vs. Time** icon or select the icon and click **Add**. The Phase vs. Time icon will appear in the **Selected displays** box and will no longer appear under Available displays.
4. Click **OK** to show the Phase vs. Time display.

## Elements of the Display



Item	Display element	Description
1	Top of graph adjustment	Adjusts the vertical scale. Use the knob to adjust the value of the top of the graph.
2	Vertical offset adjustment	Adjusts the phase error shown at the vertical center of the display.
3	Autoscale button	Adjusts the vertical and horizontal settings so that the entire trace fits in the view.
4	Horizontal Offset	Adjusts the horizontal position of the trace.
5	Max and Min readouts	Displays the maximum and minimum value of the phase error within the analysis times and the times at which they occurred.
6	Horizontal Scale	Sets the time spanned by the graph.
7	Clear button	Restarts multi-trace functions (Avg, Hold).
8	Trace function	Shows the trace function as set on the Settings > Trace tab.

[Changing the Phase vs Time Display Settings \(see page 110\)](#)

## Phase Vs Time Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the Phase vs. Time display are shown in the following table.

Settings tab	Description
<a href="#">Freq &amp; BW (see page 113)</a>	Sets the frequency and bandwidth parameters.
<a href="#">Trace (see page 115)</a>	Sets the trace display parameters.
<a href="#">Scale (see page 121)</a>	Sets the Vertical and Horizontal scale and offset parameters.
<a href="#">Prefs (see page 122)</a>	Specifies whether certain display elements are visible.

## RF I & Q vs Time Display


This is a plot of the baseband In-Phase (I) and Quadrature (Q) components of a modulated carrier. The plot is in the time domain, with I and/or Q values the Y-axis.

Note that the trace(s) in the RF I & Q vs. Time display can be set to a maximum of 100,000 points (however, the actual number of trace points can extend up to 1,000,000 points if Max trace points is set to Never Decimate). If the Analysis Length includes more than the selected Max trace points value, the trace is decimated (using the method specified with the Detection control) to be equal to or less than the Max trace points setting (except when Max trace points is set to Never Decimate). This decimated (or undecimated) trace is what is used for marker measurements and for results export. You can set the Max trace points on the **Settings > Prefs** tab.

To display an RF I & Q vs. Time display:

1. Select the **Displays** button or select **Setup > Displays**. This shows the **Select Displays** dialog box.
2. From the **Measurements** box, select **General Signal Viewing**.
3. Double-click the **RF I&Q vs. Time** icon in the **Available Displays** box. This adds the RF I & Q vs. Time icon to the **Selected displays** box.
4. Click the **OK** button.

## Elements of the Display



Item	Display element	Description
1	Top of Graph adjustment	Use the knob to adjust the vertical scaling.
2	Vertical offset adjustment	Adjusts the level shown at the center of the display.
3	Autoscale button	Adjusts the offset and scale for both vertical and horizontal to provide the best display.
4	Maximum and Minimum level readouts	Displays the maximum and minimum values, within the Analysis Time, as well as the times at which they occurred.
5	Scale	Sets the time spanned by the graph.
6	Clear button	Restarts multi-trace functions (Avg, Hold).
7	Trace function	Displays the current trace function setting (Settings > Trace > Function). If the traces are averaged, the number of averages is displayed.
8	Trace Control	Selects which trace is displayed (using the drop-down list) and which trace is active (click on the trace name to display a menu).

[Changing the RF I & Q vs Time Display Settings \(see page 112\)](#)

## RF I & Q vs Time Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The Setup settings for RF I&Q vs. Time are shown in the following table.



Settings tab	Description
<a href="#">Freq &amp; BW (see page 113)</a>	Sets the frequency and bandwidth parameters.
<a href="#">Trace (see page 115)</a>	Sets the trace display parameters.
<a href="#">Scale (see page 121)</a>	Sets the Vertical and Horizontal scale and offset parameters.
<a href="#">Prefs (see page 122)</a>	Specifies whether certain display elements are visible.

## General Signal Viewing Shared Measurement Settings

The control panel tabs in this section are identical or very similar for each of the displays in the General Signal Viewing folder (Setup > Displays). Some tabs are shared by all the displays, some tabs are shared by only a couple of displays.

For some tabs, the control values are shared across all the General Signal Viewing displays. For other control values, each display has unique values for the controls. Details are provided for the specific tabs.

### Common controls for general signal viewing displays

Settings tab	Description
<a href="#">Freq &amp; Span (see page 114)</a>	Sets the frequency and span parameters.
<a href="#">Trace (see page 115)</a>	Sets the trace display parameters.
<a href="#">Traces – Math (see page 119)</a>	Sets the traces used to create the Math trace.
<a href="#">BW (see page 119)</a>	Sets the Bandwidth Method used for setting the measurement bandwidth.
<a href="#">Scale (see page 121)</a>	Sets the Vertical and Horizontal scale and offset parameters.
<a href="#">Prefs (see page 122)</a>	Specifies whether certain display elements are visible.

## Freq & BW Tab — Freq vs Time, Phase vs Time, RF I & Q vs Time Display

The Freq & BW tab provides access to settings that control frequency settings for the Freq vs Time, Phase vs Time, RF I & Q vs Time display.

The screenshot shows the 'Freq & BW' tab selected in a software interface. The tab bar includes 'Freq & BW', 'Traces', 'Scale', and 'Prefs'. The main area contains the following controls:

- Measurement Freq:** A text box containing '1.000 GHz'.
- Measurement BW, no filter:** A text box containing '500 MHz'.
- Link to Span:** A checked checkbox.
- Set to max BW:** A button.

Setting	Description
Measurement Freq	The frequency at the which measurements are made. This value is the same as the setting for Frequency in the Application bar.
Measurement BW	This control limits the bandwidth of measurements. You use the measurement bandwidth setting to improve the signal-to-noise ratio of the measurement, resulting in lower measurement uncertainty. However, if the measurement bandwidth is set too low, resulting in fewer samples per second, it can reduce the number of points within the measurement length below the 256 stable samples required, thus causing the analysis to fail.
Link to Span	When enabled, the measurement bandwidth of the RF I & Q display is determined by the span of the analyzer. When unchecked, the measurement bandwidth is specified by the user, and no additional filter is applied.
Set to max BW	Sets the measurement bandwidth to the maximum acquisition bandwidth of the instrument.

## Freq & Span Tab

The Freq & Span tab provides access to settings that control frequency settings for the trace display. The control values set in this tab are shared by all the General Signal Viewing displays.

Freq & Span
BW
Traces
Horiz & Vert Scale
Bitmap Scale
Prefs
Density

Frequency: 5.000 GHz
Span: 800 MHz
Max Span

Start: 4.600 GHz
Step Size: 50.0000 MHz
☒ Auto

Stop: 5.400 GHz
Dwell time: 50.0 ms (swept only)
☒ Auto

Setting	Description
Frequency	The frequency at the center of the selected span.
Start	The lowest frequency in the span.
Stop	The highest frequency in the span.
Span	The difference between the start and stop frequencies. This is the measurement bandwidth for the general signal viewing displays.
Step Size	Sets the increment/decrement size for Frequency, Start, and Stop values.
Dwell time (DPX display only)	The amount of time the DPX sweep remains in a frequency segment collecting data and updating the bitmap and traces before moving on to the next higher frequency segment. The minimum Dwell Time setting is 50 ms, the normal update rate for DPX computations. Maximum Dwell Time per frequency segment is 100 s. The number of frequency segments and their start/stop frequencies are internally determined based on span, acquisition bandwidth, RBW, and other parameters.
Max Span	Sets the span to the maximum value.
Auto checkbox	Sets the Step Size and Dwell time automatically when checked.

### Frequency, Start, Stop, and Span frequencies are correlated

Changing the values for center frequency, start frequency, stop frequency or span will change the values for the other settings, depending on which setting you change. For example, if you change the center frequency, the start and stop frequencies will be adjusted automatically to maintain the same span.

If, however, the start and stop frequencies are changed so that they are closer than the minimum span setting, the start and stop frequencies will be adjusted to maintain the minimum span setting.

Setting changed manually	Settings changed automatically as a result	Setting not automatically changed
Start	Center, Span	Stop
Stop	Center, Span	Start
Center Frequency	Start, Stop	Span
Span	Start, Stop	Center

## Traces Tab

The Traces Tab allows you to set the display characteristics of displayed traces.

The screenshot shows the 'Traces' tab selected in the software interface. It contains several controls for managing traces:

- Trace:** A dropdown menu currently set to 'Trace 1'.
- Show:** A checked checkbox.
- Freeze:** An unchecked checkbox.
- Save Trace As...:** A button to save the current trace.
- Detection:** A dropdown menu currently set to '+Peak'.
- Show recalled trace:** An unchecked checkbox.
- Function:** A dropdown menu currently set to 'Normal'.
- Text Input:** A text field with a button next to it, likely for naming or identifying the trace.

Setting	Description
Trace	Selects a trace. (This setting is not present for every display.)
Show	Shows / hides the selected trace.
Detection	Sets the Detection method used for the trace. Not available for saved traces. Available detection methods are +Peak, -Peak, +/-Peak, Avg (VRMS), Sample, CISPR Avg, CISPR Pk, and CISPR QPk. Not all detection methods are available in all displays. (CISPR detection requires Option SVQPNL or SVQPFL.)
Function	Selects the trace processing method. Available settings are: Normal, Average, Max Hold, and Min Hold.
Count	Sets the number of traces averaged to generate the displayed trace. (Present only when Function is set to Average, Min Hold, or Max Hold.)
Freeze	Halts updates to the selected trace.
Save Trace As	Saves the selected trace to a file for later recall and analysis.
Show Recalled trace	Displays a saved trace instead of a live trace. When a trace is recalled, controls such as show, freeze, function, and detection of trace will be disabled.

## Trace

Available traces for Spectrum are: Trace 1, Trace 2, Trace 3, Math, and Spectrogram. Other displays support fewer traces. Traces 1-3 are based on the input signal and enable you to display the input signal using different processing. For example, you could display Trace 1 with Function set to Normal, Trace 2 with Function set to Max Hold and Trace 3 with Function set to Min Hold.

The Math trace is the result of subtracting one trace from another.

The Spectrogram trace applies only to the Spectrum display and is available only if the Spectrogram display is shown. The Spectrogram trace shows the trace selected in the Spectrogram as a spectrum trace.

## Detection

Trace Detection is used to reduce the results of a measurement to the desired number of trace points. For example, if the maximum number of trace points is 100,000, and a measurement over the selected analysis length yields 200,000 points, the measurement must decimate these 200,000 trace points by 2 to prevent exceeding the 100,000 trace point limit. Since only one value can be represented for each trace point, an algorithm must be used to select (detect) the appropriate value to use.

The results array from an analysis can be detected (or “decimated”) in a variety of ways. The number of results points produced for each trace point varies with both analysis length and trace length. For example, the frequency transform used for the Spectrum display produces just one output value for each desired trace point. In this case, the detection method chosen has no effect, as no decimation is required. Increasing the Analysis Length (or for the Spectrum display, the Spectrum Length), causes the available detection method's output traces to differ from each other because they have a larger set of samples for the various detection methods to process.

The available detection methods (depending on the display) are:

- **+Peak** – The highest value is selected from the results to be compressed into a trace point.
- **-Peak** – The lowest value is selected from the results to be compressed into a trace point.

- **+/-Peak** – Both the highest and lowest values are selected from the results to be compressed into a trace point.
- **Avg (VRMS)** [Average  $V_{RMS}$ ] – Each point on the trace is the result of determining the RMS Voltage value for all of the results values it includes. When displayed in either linear (Volts, Watts) or Log (dB, dBm), the correct RMS value results.
- **Avg (of logs)** – The detector is used to emulate legacy spectrum analyzer results and for the specification of displayed average noise level. In older swept analyzers, a voltage envelope detector is used in the process of measuring signal level, and the result is then converted to Watts and then to dBm. Averaging is then applied to the resultant traces.

For CW signals, this method results in an accurate power measurement. However, with random noise and digitally modulated carriers, errors result from this 'average of logs' method. For random noise, the average of logs methods results in power levels -2.51 dB lower than that measured with a power meter, or with a signal analyzer that measures the rms value of a signal, and performs averaging on the calculated power in Watts and not dBm or other log-power units.

This detector should be used when following a measurement procedure that specifies it, or when checking the Displayed Averaged Noise Level (DANL) of the instrument. The 'average of logs' detection and trace function is used for DANL specification to provide similar results to other spectrum/signal analyzers for comparison purposes. Use of the Average of Logs method of measurement is not recommended for digitally modulated carriers, as power measurement errors will occur.

---

**NOTE.** *The Detection setting does not affect the trace until the spectrum length is longer than the Auto setting.*

---

- **Sample** – The first value is selected from the set of results to be compressed into a trace point.
- **CISPR Peak** – The trace value is calculated by the methods described for peak detectors in the CISPR documents.
- **CISPR QPk** – The trace value is calculated by the methods described for quasi peak detectors in the CISPR documents.  
(Requires Option SVQPNL or SVQPFL.)
- **CISPR Avg** – The trace value is calculated by the methods described for average detectors in the CISPR documents.  
(Requires Option SVQPNL or SVQPFL.)

## Trace Processing

Traces can be processed to display in different ways. The Function setting controls trace processing.

- **Normal** - Each new trace is displayed and then replaced by the next trace. Each data point contains a single vertical value.
- **Average** - Multiple traces are averaged together to generate the displayed trace, which will contain just one vertical value for each underlying frequency data point. Once the specified number of traces have been acquired and averaged to generate the displayed trace, additional traces contribute to the running average, except in Single Sequence run mode. In the case of Single Sequence, the instrument stops running after the specified number of traces have been averaged together. The **Number of Traces** setting specifies how many traces are averaged. The averaging is performed on the linear (Voltage) values, resulting in the correct RMS average).
- **Max Hold** - Displays the maximum value in the trace record for each display point. Each new trace's display point is compared to the previous maximum value and the greater value is retained for display and subsequent comparisons.
- **Min Hold** - Displays the minimum value in the trace record for each display point. Each new trace's display point is compared to the previous minimum value and the lesser value is retained for display and subsequent comparisons.

### Saving Traces

To save a trace for later analysis:


1. Select the **Save Trace As** button. This displays the Save As dialog box.
2. Navigate to the desired folder or use the default.
3. Type a name for the saved trace and click **Save**.

### Recalling Traces

You can recall a previously saved trace for analysis or comparison to a live trace.

To select a trace for recall:

1. Select the trace into which the recalled trace will be loaded, from the Trace drop-down list.
2. Check the **Show** check box.
3. Click the ... button to display the Open dialog box.




4. Navigate to the desired file and click **Open**.

5. Check the **Show Recalled Trace** check box.
6. Verify that the trace's **Show** check box is selected (either on this tab or next to the drop-down list located at the top-left corner of the graph).

## Traces tab - Math Trace

This tab is not a distinct tab, it is just how the Traces tab appears when Math is selected in the Traces drop-down list.




Trace 4 is a mathematically-derived trace defined as Trace A minus Trace B. You can select Trace 1, 2, or 3 to serve as either Trace A or Trace B.

Setting	Description
Trace	When set to Trace 4 (Math), this tab is displayed.
Show	Shows / hides the selected trace.
Freeze	Halts updates to the selected trace.
Save Trace As	Saves the selected trace to a file for later recall and analysis.
Trace minus Trace	Selects which traces serve as Trace A and Trace B.

## BW Tab

The BW (bandwidth) tab allows you to change Resolution Bandwidth and Video Bandwidth settings, and set the windowing method used by the transform process by selecting a filter shape (not present for all displays).



Setting	Description
RBW	Sets the Resolution Bandwidth value to be used in the spectrum analysis view. The value is italicized when Auto is selected.
Auto	When Auto is checked, the RBW is calculated as a percentage of the Span. Kaiser is selected as the windowing method. When Auto is unchecked, the RBW is set by the user. Selecting any Window other than Kaiser changes the RBW setting to manual.
Span/RBW ratio	If Auto is checked, this value is used to calculate the RBW. If Auto is unchecked, this setting is not selectable.
Filter Shape	Specifies the windowing method used for the transform (when Auto is unchecked). (Spectrum and Spectrogram displays only.)
VBW	Adjusts the VBW (Video Bandwidth) value. (Spectrum and Spectrogram displays only.)

### Filter shape settings

In the analyzer, computationally efficient discrete Fourier transform algorithms such as FFT (Fast Fourier Transform) or CZT (Chirp-Z Transform) are generally employed to transform time-domain signals into frequency-domain spectra. There is an assumption inherent in the mathematics of Discrete Fourier Transforms that the data to be processed is a single period of a periodically repeating signal. The discontinuities between successive frames will generally occur when the periodic extension is made to the signal. These artificial discontinuities generate spurious responses not present in the original signal, which can make it impossible to detect small signals in the presence of nearby large ones. This phenomenon is called spectral leakage.

Applying a filter, such as Kaiser, to the signal to be transformed is an effective method to combat the spectral leakage problem. Generally the filter has a bell shape. Multiplying the transform frame by the filter function eliminates or reduces the discontinuities at the ends of the frame, however, at the expense of increased RBW.

### Filter shape characteristics

The choice of filter shape depends on its frequency response characteristics such as side-lobe level, equivalent noise bandwidth and maximum amplitude error. Use the following guidelines to select the best filter shape.

Filter Shape	Characteristics
Kaiser (RBW)	Best side-lobe level, shape factor closest to the traditional Gaussian RBW.
-6dB RBW (MIL)	These filters are specified for bandwidth at their -6 dB point, as required by military EMI regulations.
CISPR	These filters comply with the requirements specified in the P-CISPR 16 -1-1 document for EMI measurements.
Blackman-Harris 4B	Good side-lobe level.
Uniform (None)	Best frequency resolution, poor side-lobe level and amplitude accuracy.
Flat-Top (CW ampl)	Best amplitude accuracy, best representation of brief events captured near the beginning or end of the time-domain data frame, poor frequency resolution.
Hanning	Good frequency resolution, high side-lobe roll-off rate.



## VBW

The VBW setting enables/disables the Video Bandwidth filter. VBW is used in traditional swept analyzers to reduce the effect of noise on the displayed signal. The VBW algorithm in the analyzer emulates the VBW filters of traditional swept analyzers.


The maximum VBW value is 10 times the current RBW setting. The minimum VBW value is 1/10,000 of the RBW setting. VBW is disabled when the Filter shape is set to CISPR.

**NOTE.** If you are following a procedure that says to "set VBW to three times the RBW value or greater", it means that the test should be conducted with no VBW effects. In the SignalVu-PC software, this condition is met by disabling the VBW function.

## Scale Tab

The Scale tab allows you to change the vertical and horizontal scale settings. Changing the scale settings changes how the trace appears on the display but does not change control settings such as Measurement Frequency. In effect, these controls operate like pan and zoom controls.

The Scale tab values are unique to each display. Also, note that each display uses horizontal and vertical units that are appropriate for the display. For example, for the Spectrum display uses power (dBm) units and frequency (Hz) units; the Amplitude vs. Time display uses power (dBm) and time (seconds) units; and the Phase vs. Time display uses phase (degrees) and time (seconds) units.




Setting	Description
Vertical	Controls the vertical position and scale of the trace display.
Scale	Changes the vertical scale.
Position	Vertical position adjusts the reference level away from top of the graph.
Autoscale	Resets the scale of the vertical axis to contain the complete trace.
Horizontal	Controls the horizontal position and scale of the trace span of the trace display and position of the trace.
Scale	Changes the range shown between the left and right sides of the graph.
Position	Changes the position of the acquisition record shown at the left edge of the graph.
Reset Scale	Resets all settings to their default values.

## Prefs Tab


The Prefs tab enables you to change parameters of the measurement display. The parameters available on the Prefs tab vary depending on the selected display, but include such items as enabling/disabling marker Readout and switching the Graticule display on/off.

Each of the General Signal Viewing displays maintains its own separate values for the controls that appear on the Prefs tab. Some parameters appear with most displays while others appear with only one display.


For example, in the following image, the Show Marker readout in graph check box appears in the Prefs tab for every display. However, the Show Power Trigger level check box only appears on the Amplitude vs Time Prefs tab.




The following image shows the Prefs tab for the Time Overview display.



The following image shows the Prefs tab for the DPX display when DPXogram or Split is the selected view.



The following image shows the Prefs tab for the DPX display when Spectrum is the selected view.



The following table explains the controls that can appear on the Prefs tab.

Setting	Description
Show	Sets the horizontal settings that appear below the graph area. You can select Start, Stop or Center, Span.
Trace points	Sets the number of trace points used for marker measurements and for results export.
Max trace points (Time Overview display only)	Sets the maximum number of trace points used for marker measurements and for results export.
Show trace legend	Enables display of a legend in the measurements area that shows the Detection method and Function setting for displayed traces. The color of the legend text matches the color of the associated trace.
Show graticule	Check to display the graticule. Uncheck to hide the graticule.
Navigator View (Time Overview display only)	Places the Time Overview display across the top of the application window, above all other active displays.
Show parameter readouts	For the DPX display, enables/disables the display of DPX parameters. The parameters readout shows 100% Probability of Intercept, Transforms/s, and FFT Points.
Show Marker readout in graph (selected marker)	Shows or hides the readout for the selected marker in the graph area.
Show timestamp in graph (selected line)	For spectrogram displays, this readout shows or hides the timestamp associated with the selected line or marker position.
DPX shows only trigger frames	For the DPX Spectrum display, check to show only trigger frames.
Show Power Trigger Level	Displays or hides a green line in the graph that indicates the level at which the power trigger is set. The line is not displayed if Trigger is set to Free Run.

### Show parameter readouts (DPX Spectrum only)

The elements of the Show parameter readouts are:

- 100% POI – This is the minimum event duration required to ensure 100% Probability of Intercept or event capture. This duration depends on interaction between span, RBW, and FFT length. You can

use the POI time value to determine if you are at risk of either missing a narrow transient or of its captured amplitude being less than the actual signal.

#### Minimum signal duration for 100% probability of trigger at 100% amplitude

Frequency-Mask and DPX signal processing				Minimum signal duration, 100% probability of intercept, Frequency-Mask and DPX density trigger (μs)	
Span	RBW (kHz)	FFT length	Spectrums/sec	Standard	
				Full amplitude	-3 dB
165 MHz	20000	1024	390,625	15.5	15.4
	10000	1024	390,625	15.6	15.4
	1000	1024	390,625	17.8	15.7
	300	2048	195,313	23.4	16.3
	100	8192	48,828	44.5	23.4
	30	32768	12,207	161.9	91.7
85 MHz	10000	1024	390,625	15.6	15.4
	1000	1024	390,625	17.8	15.7
	500	1024	390,625	20.2	15.9
	300	1024	390,625	23.4	16.3
	100	4096	97,656	44.5	23.4
	30	16384	24,414	121.0	50.7
40 MHz	20	16384	24,414	161.0	55.6
	5000	1024	390,625	15.8	15.4
	1000	1024	390,625	17.8	15.7
	300	1024	390,625	23.3	16.3
	100	2048	195,313	39.4	18.3
	30	4096	97,656	90.4	21.8
25 MHz	20	8192	48,828	140.7	36.3
	10	16384	24,414	281.3	72.6
	3800	1024	390,625	16.0	15.4
	1000	1024	390,625	17.7	15.7
	300	1024	390,625	23.4	16.3
	200	1024	390,625	27.4	16.8

- Transforms/s – This is the number of transforms/second being performed by the DPX engine. It is a function of the selected resolution bandwidth and number of trace points. The desired RBW determines the number of points required in each transform, which alters the transform rate. Additionally, the selected trace length may place requirements on the number of points required in the transform independent of the selected resolution bandwidth.
- FFT Points – The approximate number of points in the FFT of the input signal. FFT points provides an indication of frequency resolution, but it is not an exact measurement. Note that higher numbers for FFT points mean that the instrument is taking a longer string of input samples for each FFT, which decreases the time resolution.

#### Minimum FFT length versus trace length - independent of span and RBW

Trace length (points)	Minimum FFT length
801	1,024
2,401	4,096

**Minimum FFT length versus trace length - independent of span and RBW (cont.)**

Trace length (points)	Minimum FFT length
4,001	8,192
10,401	16,384



## Overview

The displays in Analog Modulation (Displays > Measurements > Analog Modulation) are:

- AM
- FM
- PM

The Analog Modulation displays provide measurements and time-domain trace displays.


## AM Display

The Amplitude Modulation Display is a graph of Modulation Factor vs Time. The AM display includes three numeric readouts.

To show the AM display:

1. Select the **Displays** button or select **Setup > Displays**. This shows the **Select Displays** dialog box.
2. From the **Measurements** box, select **Analog Modulation**.
3. Double-click the **AM** icon in the **Available Displays** box. This adds the AM icon to the **Selected displays** box.
4. Click the **OK** button. This shows the AM display.

### Elements of the Display



Item	Element	Description
1	Check mark indicator	The check mark indicator in the upper, left-hand corner of the display shows when the AM display is the optimized display.  <b>NOTE.</b> When <i>Best for multiple windows</i> is selected in the <i>Amplitude control</i> panel's <i>RF &amp; IF Optimization control</i> , none of the measurement displays shows a checkmark, as there is not a single optimized measurement.
2	Top of Graph	Sets the %AM indicated at the top of the graph by increasing or decreasing the vertical scale. Changing the top value affects the bottom of graph value because the graph scales about vertical center. Also, note that the top of graph setting interacts with the internal vertical scale setting (which is not user settable).
3	Position	Specifies the %AM shown at the center of the graph display.
4	Bottom Readout	Displays the value of the modulation factor shown at the bottom of graph.
5	Measurement readouts	Displays numeric values for the +AM (positive modulation factor), -AM (negative modulation factor), and Total AM.
6	Position	Specifies the horizontal position of the trace on the graph display.
7	Scale	Adjusts the horizontal range of the graph. By decreasing the scale (time across the entire graph), the graph essentially becomes a window that you can move over the trace by adjusting the position.
8	Clear	Erases the trace from the graph.
9	Trace Detection readout	Displays the Settings > Trace > Detection setting.


[Changing the AM Settings \(see page 128\)](#)

## AM Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The AM Settings control panel provides access to settings that control parameters of the AM Display.






Setting	Description
<a href="#">Parameters (see page 129)</a>	Sets the Carrier Amplitude Detection method. You can choose either Average or Median.
<a href="#">Trace (see page 130)</a>	Sets Trace display parameters.
<a href="#">Scale (see page 132)</a>	Sets vertical and horizontal scale and position parameters.
<a href="#">Prefs (see page 133)</a>	Specifies whether or not certain display elements are shown. Specifies the maximum number of points shown in the display graph.

## Parameters Tab

The Parameters tab enables you to specify two parameters that control the carrier amplitude detection.



Setting	Description
Average	Selects the Average method for computing the average baseline for measurements.
Median	Selects the Median method for computing the average baseline for measurements.
Measurement BW	Specifies the bandwidth about the center frequency at which measurements are made.

## AM Modulation

An amplitude modulated carrier can be described mathematically by:

$$X(t) = [A + a(t)] \cos \omega_0 t$$

A, in the above equation, represents the carrier amplitude, a(t) represents the time-varying modulation and  $\omega_0$  represents the carrier frequency.

The signal modulation envelope is given by:

$$E_M(t) = A + a(t)$$

There are several ways to express the AM modulation depth, expressed as a percentage.

*Peak method*

$$AMModulationDepth = \frac{Max[A + a(t)]}{A}$$

*Trough Method*

$$AMModulationDepth = \frac{Min[A + a(t)]}{A}$$

*Max-Min Method*

$$AMModulationDepth = \frac{Max[A + a(t)] - Min[A + a(t)]}{2A}$$

In each case, the value of the carrier amplitude,  $A$ , needs to be estimated from the input signal.

The instrument represents signals in a sampled form. The sampled envelope can be expressed as a function of sample index  $K$  and sampling period  $T$  as:

$$E_M[KT] = A + a[KT]$$

The instrument allows the choice of two methods for estimating the carrier amplitude:

#### Average Method

$$A = Average \{E_M[KT]\}$$

#### Median Method

$$A = Median \{E_M[KT]\}$$

In both cases, the instrument computes the average and the median over the analysis period. It should be noted that the two methods give the same result for sinusoidal modulation where the sampling frequency is much higher than the modulation frequency.

## Trace Tab

The Trace Tab allows you to set the display characteristics of a trace.



Setting	Description
Show	Shows/hides the trace. If the instrument continues to run, the measurement results below the graph display continue to update even if the trace is hidden.
Detection	Sets the Detection method used for the trace. Available detection methods are +Peak, -Peak, and Avg (VRMS). Not available for saved traces.
Function	Selects the trace processing method. The only available setting is Normal.
Freeze	Halts updates to the trace.
Save Trace As	Saves the trace to a file for later recall and analysis.
Show recalled trace	Displays a saved trace instead of a live trace.

## Detection

Detection refers to the method of processing the data acquisition points when creating a trace. The IQ samples in a data acquisition can be detected in a variety of ways. The number of IQ samples available to each trace point varies with both analysis length and trace length. For example, with Spectrum Length set to 'Auto' in the Analysis menu, the instrument analyzes just enough samples to produce one IQ sample pair per trace point. In this case, the detection method chosen has very little effect, as the +Peak, -Peak, and Avg (VRMS) are all equal. Changing the Spectrum Length causes the available detection methods to differ in value because they have a larger set of samples for the various detection methods to process.

The available detection methods are:

- **+Peak** – Each point on the trace is the result of detecting the positive peak value present in the set of IQ samples available to that trace point.
- **-Peak** – Each point on the trace is the result of detecting the negative peak value present in the set of IQ samples available to that trace point.
- **Avg (VRMS)** [Average  $V_{RMS}$ ] – Each point on the trace is the result of determining the RMS Voltage value for all of the IQ samples available to the trace point. When displayed in either linear (Volts, Watts) or Log (dB, dBm), the correct RMS value results. When the averaging function is applied to a trace, the averaging is performed on the linear (Voltage) values, resulting in the correct average for RMS values.

## Trace Processing

Traces can be processed to display in different ways. The Detection setting controls trace decimation, when needed. When the trace points each cover more than one sample data point, the vertical results values for multiple data points are combined into each trace point. Each trace point ends up with a single vertical value.

- **Average** - Each trace point is computed by averaging together the multiple results points it represents.
- **+Peak** - Each trace point represents the highest vertical value among the results it includes.
- **-Peak** - Each trace point represents the lowest vertical value among the results it includes.

## Saving Traces

To save a trace for later analysis:

1. Select the **Save Trace As** button. This displays the Save As dialog box.
2. Navigate to the desired folder or use the default.
3. Type a name for the saved trace and click **Save**.

## Recalling Traces

You can recall a previously saved trace for analysis or comparison to a live trace.

To select a trace for recall:

1. Click the ... button to display the Open dialog box.
2. Navigate to the desired file and click **Open**.
3. Check the **Show Recalled Trace** check box.
4. Verify that the **Show** check box is selected.

## Scale Tab


The Scale tab allows you to change the vertical and horizontal scale settings. Changing the scale settings changes how the trace appears on the display but does not change control settings such as Measurement Frequency. In effect, these controls operate like pan and zoom controls.

The screenshot shows the 'Scale' tab in a software interface. It has four tabs: 'Parameters', 'Trace', 'Scale' (selected), and 'Prefs'. The 'Scale' tab is divided into two sections: 'Vertical' and 'Horizontal'. Each section contains a 'Scale' input field, a 'Position' input field, and an 'Autoscale' button. In the 'Vertical' section, the Scale is set to '143 %' and the Position is set to '-1.00 %'. In the 'Horizontal' section, the Scale is set to '4.600 ms' and the Position is set to '400.000 us'.

Setting	Description
Vertical	
Scale	Changes the range shown between the top and bottom of the graph.
Position	Adjusts the level shown at the center of the graph.
Autoscale	Resets the Position so that the entire trace is in the graph.
Horizontal	
Scale	Changes the range shown between the left and right sides of the graph.
Position	Adjusts the position of the acquisition record shown at the left edge of the graph.
Autoscale	Resets the Scale and Position settings to provide the optimum display.

## Prefs Tab

The Prefs tab enables you to change appearance characteristics of the AM display.



Setting	Description
Show graticule	Shows or hides the graticule.
Show Marker readout in graph (selected marker)	Shows or hides the readout for the selected marker in the graph area.
Max trace points	The trace in the AM display can be set to a maximum of 100,000 points (however, the actual number of trace points can extend up to 500,000 points if Max trace points is set to Never Decimate). If the Analysis Length includes more than the selected Max trace points value, the trace is decimated (using the method specified with the Detection control) to be equal to or less than the Max trace points setting (except when Max trace points is set to Never Decimate). This decimated (or undecimated) trace is what is used for marker measurements and for results export.


## FM Display

The Frequency Modulation Display shows Frequency Deviation vs. Time. The vertical axis units are Hertz and the horizontal axis units are seconds. When taking measurements, only the first burst in the Analysis period is analyzed. No trace points are shown for data outside the first detected burst, nor are measurements made on data outside the first detected burst.

To show the FM display:

1. Select the **Displays** button or select **Setup > Displays**. This shows the **Select Displays** dialog box.
2. From the **Measurements** box, select **Analog Modulation**.
3. Double-click the **FM** icon in the **Available Displays** box. This adds the FM icon to the **Selected displays** box.
4. Click the **OK** button. This shows the FM display.

## Elements of the Display



Item	Element	Description
1	Check mark indicator	The check mark indicator in the upper, left-hand corner of the display shows when the FM display is the optimized display.  <b>NOTE.</b> When Best for multiple windows is selected in the Amplitude control panel's RF & IF Optimization control, none of the measurement displays shows a checkmark, as there is not a single optimized measurement.
2	Top of Graph control	Sets the frequency indicated at the top of the graph. Since the Position value at the vertical center of this graph remains constant as the Top of Graph value is adjusted, the Vertical Scale increases as the Top of Graph value increases, which also affects the bottom of graph readout. Vertical Scale can also be controlled from the Settings control panel's Scale tab.
3	Position	Specifies the frequency shown at the center of the graph display. Changing this value moves the trace up and down in the graph, which affects the Top of Graph and Bottom of Graph values as well.
4	Bottom of Graph Readout	Displays the frequency value at the bottom of the graph.
5	Measurement readouts	Displays numeric values for the +Pk (positive frequency deviation), -Pk (negative frequency deviation), RMS (RMS value of the deviation), Pk-Pk (peak-to-peak frequency deviation), and Pk-Pk/2 (peak-to-peak frequency deviation divided by two).
6	Position	Specifies the horizontal position of the trace on the graph display.
7	Scale	Adjusts the time range of the graph. By decreasing the scale (full-scale time over 10 divisions), the graph essentially becomes a window that you can move over the acquisition record by adjusting the horizontal position.
8	Clear	Clears the trace and numeric measurement results.
9	Trace Detection readout	Displays the Settings > Trace > Detection setting.
10	Freq Error	This readout can show Freq Error or Freq Offset. When it displays Freq Error, it shows the difference between the instrument Frequency setting and the measured value of the signal's carrier frequency. When it displays Freq Offset, it shows the frequency offset specified on the Settings > Parameters tab. If Freq Error is displayed, it also indicates that the Carrier frequency detection setting is Auto. If Freq Offset is displayed, it indicates that the Carrier frequency detection setting is manual.

[Changing the FM Settings \(see page 135\)](#)

## FM Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The FM Settings control panel provides access to settings that control parameters of the FM Display.

The screenshot shows the 'Parameters' tab of the FM Settings dialog. It contains four input fields: 'Burst detect threshold' set to '-100 dBc', 'Frequency offset' set to '-50.54 Hz' with an 'Auto' checkbox checked, 'Measurement BW' set to '100.0 kHz', and a 'Load from marker' button.

Setting	Description
<a href="#">Parameters (see page 663)</a>	Sets the burst detection threshold, measurement bandwidth, and carrier frequency detection method.
<a href="#">Trace (see page 138)</a>	Sets Trace display parameters.
<a href="#">Scale (see page 140)</a>	Sets vertical and horizontal scale and position parameters.
<a href="#">Prefs (see page 141)</a>	Specifies whether or not certain display elements are shown. Specifies the maximum number of points shown in the display graph.



## Parameters Tab

The Parameters tab enables you to specify parameters for carrier detection.

The screenshot shows the 'Parameters' tab selected in a software interface. It contains the following controls:

- Burst detect threshold:** A text input field containing '-100 dBc'.
- Measurement BW:** A text input field containing '100.0 kHz'.
- Frequency offset:** A text input field containing '-50.54 Hz'.
- Auto:** A checked checkbox next to the label 'Auto'.
- Load from marker:** A button located below the Frequency offset field.

Setting	Description
Burst detect threshold	This parameter specifies the power level used to determine whether a burst is present. A valid burst is required to take measurements. The burst detected first is used for the analysis. The units for burst detect threshold are dBc, relative to the maximum acquisition sample data points level.
Measurement BW	Specifies the bandwidth about the center frequency at which measurements are made.
Frequency offset	Displays the carrier signal's offset from the instrument's measurement frequency. Auto is used to select the method for determining the carrier frequency. When Auto is selected, the instrument determines the carrier frequency by analyzing the signal. When Auto is deselected, you can set the carrier frequency offset using Frequency Offset.
Load from Marker	Pressing this button sets the frequency offset to the frequency offset of the selected marker. (Pressing this button automatically deselects Auto.)

### Frequency Offset

In Auto (Auto is selected), the instrument scans the measurement bandwidth about the measurement frequency and looks for the highest-powered signal. This is defined as the carrier frequency. In Manual (Auto is deselected), the carrier frequency is specified by adding/subtracting the specified Frequency offset from the measurement frequency. Range:  $-(\text{Measurement BW} \times 1.1)/2$  to  $+(\text{Measurement BW} \times 1.1)/2$ . If the **Load from Marker** button is pressed, the frequency offset is determined from the phase difference between the two markers on screen compared to the time between the two markers. This function is useful for removing frequency slope from the phase modulated signal.

### Load from Marker

When the Auto check box is selected, the instrument scans the measurement bandwidth about the center frequency and looks for the highest-powered signal. This is defined as the carrier frequency. When the Auto check box is deselected, the carrier frequency is specified by adding/subtracting the specified Frequency offset from the center frequency. Pressing the Load from Marker button loads the marker frequency into the Frequency offset box.

## Trace Tab

The Trace Tab allows you to set the display characteristics of displayed traces.



Setting	Description
Show	Shows / hides the trace. If the instrument continues to run, the measurement results below the graph display continue to update even if the trace is hidden.
Detection	Sets the Detection method used for the trace. Available detection methods are +Peak, -Peak, and Avg (VRMS). Not available for saved traces.
Function	Selects the trace processing method. The only available setting is Normal.
Freeze	Halts updates to the trace.
Save Trace As	Saves the trace to a file for later recall and analysis.
Show Recalled trace	Displays a saved trace instead of a live trace.

### Detection

Detection refers to the method of processing the data acquisition points when creating a trace. The IQ samples in a data acquisition can be detected in a variety of ways. The number of IQ samples available to each trace point varies with both analysis length and trace length. For example, with Spectrum Length set to 'Auto' in the Analysis menu, the instrument analyzes just enough samples to produce one IQ sample pair per trace point. In this case, the detection method chosen has very little effect, as the +Peak, -Peak, and Avg (VRMS) are all equal. Changing the Spectrum Length causes the available detection methods to differ in value because they have a larger set of samples for the various detection methods to process.

The available detection methods are:

- **+Peak** – Each point on the trace is the result of detecting the positive peak value present in the set of IQ samples available to that trace point.
- **-Peak** – Each point on the trace is the result of detecting the negative peak value present in the set of IQ samples available to that trace point.
- **Avg (VRMS)** [Average  $V_{RMS}$ ] – Each point on the trace is the result of determining the RMS Voltage value for all of the IQ samples available to the trace point. When displayed in either linear (Volts, Watts) or Log (dB, dBm), the correct RMS value results. When the averaging function is applied to a trace, the averaging is performed on the linear (Voltage) values, resulting in the correct average for RMS values.

## Trace Processing

Traces can be processed to display in different ways. The Function setting controls trace processing.

- **Normal** - Each new trace is displayed and then replaced by the next trace. Each data point contains a single vertical value.
- **Average** - Each trace point is computed by averaging together the multiple results points it represents.
- **+Peak** - Each trace point represents the highest vertical value among the results it includes.
- **-Peak** - Each trace point represents the lowest vertical value among the results it includes.

## Saving Traces

To save a trace for later analysis:

1. Select the **Save Trace As** button. This displays the Save As dialog box.
2. Navigate to the desired folder or use the default.
3. Type a name for the saved trace and click **Save**.

## Recalling Traces

You can recall a previously saved trace for analysis or comparison to a live trace.

To select a trace for recall:

1. Click the **...** button to display the Open dialog box.
2. Navigate to the desired file and click **Open**.
3. Check the **Show Recalled Trace** check box.
4. Verify that the **Show** check box is selected.

## Scale Tab


The Scale tab allows you to change the vertical and horizontal scale settings. Changing the scale settings changes how the trace appears on the display but does not change control settings such as Measurement Frequency. In effect, these controls operate like pan and zoom controls.

The screenshot shows the 'Scale' tab in a software interface. It has four tabs at the top: 'Parameters', 'Trace', 'Scale' (which is selected), and 'Prefs'. The 'Scale' tab is divided into two main sections: 'Vertical' and 'Horizontal'. Each section contains a 'Scale' input field, a 'Position' input field, and an 'Autoscale' button. In the 'Vertical' section, the Scale is set to '10.0 kHz' and the Position is '0.000 Hz'. In the 'Horizontal' section, the Scale is set to '35.280 us' and the Position is '92.160 us'.

Setting	Description
Vertical	
Scale	Changes the range shown between the top and bottom of the graph.
Position	Adjusts the frequency shown at the center of the graph.
Autoscale	Resets the Position so that the entire trace fits within the graph.
Horizontal	
Scale	Changes the range shown between the left and right sides of the graph.
Position	Adjusts the position of the acquisition record shown at the left edge of the graph.
Autoscale	Resets the Scale and Position settings to provide the optimum display.

## Prefs Tab

The Prefs tab enables you to change appearance characteristics of the FM display.




Setting	Description
Show graticule	Shows or hides the graticule.
Show Marker readout in graph (selected marker)	Shows or hides the readout for the selected marker in the graph area.
Max trace points	The trace in the FM display can be set to a maximum of 100,000 points (however, the actual number of trace points can extend up to 500,000 points if Max trace points is set to Never Decimate). If the Analysis Length includes more than the selected Max trace points value, the trace is decimated (using the method specified with the Detection control) to be equal to or less than the Max trace points setting (except when Max trace points is set to Never Decimate). This decimated (or undecimated) trace is what is used for marker measurements and for results export.

## PM Display

The Phase Modulation Display shows Phase vs. Time. The vertical axis units are degrees and the horizontal axis units are seconds. When taking measurements, only the first burst in the Analysis period is analyzed. No trace points are shown for data outside the first detected burst, nor are measurements made on data outside the first detected burst.

## Elements of the Display



Item	Element	Description
1	Check mark indicator	The check mark indicator in the upper, left-hand corner of the display shows when the PM display is the optimized display.  <b>NOTE.</b> When Best for multiple windows is selected in the Amplitude control panel's RF & IF Optimization control, none of the measurement displays shows a checkmark, as there is not a single optimized measurement.
2	Top of Graph control	Sets the phase value indicated at the top of the graph. Since the Position value at the vertical center of this graph remains constant as the Top of Graph value is adjusted, the Vertical Scale increases as the Top of Graph value increases, which also affects the bottom of graph readout. Vertical Scale can also be controlled from the Settings control panel's Scale tab.
3	Position	Specifies the phase shown at the center of the graph display. Changing this value moves the trace up and down in the graph, which affects the Top of Graph and Bottom of Graph values as well.
4	Bottom of Graph Readout	Displays the phase value at the bottom of the graph.
5	Measurement readouts	Displays numeric values for the +Pk (positive phase deviation), -Pk (negative phase deviation), Pk-Pk (peak-to-peak phase deviation), and RMS (RMS value of the phase deviation).
6	Position	Specifies the horizontal position of the trace on the graph display.
7	Scale	Adjusts the time range of the graph. By decreasing the scale (full-scale time over 10 divisions), the graph essentially becomes a window that you can move over the acquisition record by adjusting the horizontal position.
8	Clear	Clears the measurement results.
9	Trace Detection readout	Displays the Trace Detection setting (see Settings > Trace > Detection).
10	Freq Error	This readout can show Freq Error or Freq Offset. When it displays Freq Error, it shows the difference between the instrument Frequency setting and the measured value of the signal's carrier frequency. When it displays Freq Offset, it shows the frequency offset specified on the Settings > Parameters tab. If Freq Error is displayed, it also indicates that the Carrier frequency detection setting is Auto. If Freq Offset is displayed, it indicates that the Carrier frequency detection setting is manual.

[Changing the PM Settings \(see page 143\)](#)

## PM Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The PM Settings control panel provides access to settings that control parameters of the PM Display.

Parameters

Trace

Scale

Prefs

Burst detect threshold: -100 dBc

Frequency offset: -383.2 Hz ☐ Auto

Load Δ from marker

Measurement BW: 1.000 MHz

Phase offset: 128 ° ☐ Auto

Load from marker

Setting	Description
<a href="#">Parameters (see page 144)</a>	Sets the Carrier Frequency Detection method. You can choose either Automatic or Manual. Sets burst threshold and phase detection method.
<a href="#">Trace (see page 145)</a>	Sets Trace display parameters.
<a href="#">Scale (see page 148)</a>	Sets vertical and horizontal scale and position parameters.
<a href="#">Prefs (see page 149)</a>	Specifies whether or not certain display elements are shown. Specifies the maximum number of points shown in the display graph.

## Parameters Tab

The Parameters tab enables you to specify parameters that control the carrier frequency and phase detection.

Parameters

Trace

Scale

Prefs

Burst detect threshold: -100 dBc

Frequency offset: -383.2 Hz ☐ Auto

Load Δ from marker

Measurement BW: 1.000 MHz

Phase offset: 128 ° ☐ Auto

Load from marker



Setting	Description
Burst detect threshold	Specifies the power level used to determine whether a burst is present. A valid burst is required to take measurements. The burst detected first is used for the analysis. The units for burst detect threshold are dBc, relative to the maximum acquisition sample data points level.
Measurement BW	Specifies the bandwidth about the center frequency at which measurements are made.
Frequency offset	Displays the carrier signal's frequency offset from the instrument's Measurement Frequency. Auto is used to select the method for determining the carrier frequency. When Auto is selected, the instrument determines the carrier frequency by analyzing the signal. When Auto is deselected, you can set the carrier frequency offset using Frequency Offset.
Load $\Delta$ from Marker	Pressing this button disables the Auto Frequency Offset function and sets the Frequency offset to the frequency offset calculated from the difference between MR (the marker reference) and the selected marker (or M1 if MR is currently the selected marker).
Phase offset	Displays the phase offset. When Auto is selected, the instrument determines the phase offset. When Auto is deselected, the user sets the phase offset with this control.
Load from marker	Pressing this button sets the phase offset to the phase offset of the selected marker. (Pressing this button automatically deselects Auto.)

### Frequency Offset

In Auto (Auto is selected), the instrument scans the measurement bandwidth about the Measurement Frequency and looks for the highest-powered signal. This is defined as the carrier frequency. In Manual (Auto is deselected), the carrier frequency is specified by adding/subtracting the specified Frequency offset from the Measurement Frequency. Range:  $-(\text{Measurement BW} \times 1.1)/2$  to  $+(\text{Measurement BW} \times 1.1)/2$ . If the **Load  $\Delta$  from marker** button is pressed, the frequency offset is determined from the phase difference between the two markers on screen compared to the time between the two markers. This function is useful for removing frequency slope from the phase modulated signal.

### Phase Offset

In Auto (Auto is selected), the instrument sets the phase offset to fit the waveform to the screen centering  $0^\circ$  phase on the vertical axis. The actual phase offset is indicated on the Phase Offset readout. In Manual (Auto is deselected), the instrument sets the phase offset using the value specified in Phase offset. For example, when Phase offset is set to  $10^\circ$ , the waveform shifts upward by  $10^\circ$  on screen. Selecting **Load from marker** sets the phase offset to the value of the selected marker. Range:  $-180$  to  $+180^\circ$ .

## Trace Tab

The Traces Tab allows you to set the display characteristics of displayed traces.

The screenshot shows the 'Trace' tab in a software interface. It contains several controls: a 'Show' checkbox (checked), a 'Freeze' checkbox (unchecked), and a 'Save Trace As...' button. Below these are two dropdown menus: 'Detection' set to '+Peak' and 'Function' set to 'Normal'. To the right of the 'Detection' dropdown is a 'Show recalled trace' checkbox (unchecked). At the bottom right, there is a text input field and a button with three dots.

Setting	Description
Show	Shows / hides the trace. If the instrument continues to run, the measurement results below the graph display continue to update even if the trace is hidden.
Detection	Sets the Detection method used for the trace. Available detection methods are +Peak, -Peak, and Avg (VRMS). Not available for saved traces.
Function	Selects the trace processing method. The only available setting is Normal.
Freeze	Halts updates to the trace.
Save Trace As	Saves the trace to a file for later recall and analysis.
Show Recalled trace	Displays a saved trace instead of a live trace.

## Detection

Detection refers to the method of processing the data acquisition points when creating a trace. The IQ samples in a data acquisition can be detected in a variety of ways. The number of IQ samples available to each trace point varies with both analysis length and trace length. For example, with Spectrum Length set to 'Auto' in the Analysis menu, the instrument analyzes just enough samples to produce one IQ sample pair per trace point. In this case, the detection method chosen has very little effect, as the +Peak, -Peak, and Avg (VRMS) are all equal. Changing the Spectrum Length causes the available detection methods to differ in value because they have a larger set of samples for the various detection methods to process.

The available detection methods are:

- **+Peak** – Each point on the trace is the result of detecting the positive peak value present in the set of IQ samples available to that trace point.
- **-Peak** – Each point on the trace is the result of detecting the negative peak value present in the set of IQ samples available to that trace point.
- **Avg (VRMS)** [Average  $V_{RMS}$ ] – Each point on the trace is the result of determining the RMS Voltage value for all of the IQ samples available to the trace point. When displayed in either linear (Volts, Watts) or Log (dB, dBm), the correct RMS value results. When the averaging function is applied to a trace, the averaging is performed on the linear (Voltage) values, resulting in the correct average for RMS values.

## Trace Processing

Traces can be processed to display in different ways. The Function setting controls trace processing.

- **Normal** - Each new trace is displayed and then replaced by the next trace. Each data point contains a single vertical value.
- **Average** - Each trace point is computed by averaging together the multiple results points it represents.
- **+Peak** - Each trace point is represents the highest vertical value among the results it includes.
- **-Peak** - Each trace point is represents the lowest vertical value among the results it includes.

### Saving Traces

To save a trace for later analysis:

1. Select the **Save Trace As** button. This displays the Save As dialog box.
2. Navigate to the desired folder or use the default.
3. Type a name for the saved trace and click **Save**.

### Recalling Traces

You can recall a previously saved trace for analysis or comparison to a live trace.

To select a trace for recall:

1. Click the ... button to display the Open dialog box.
2. Navigate to the desired file and click **Open**.
3. Check the **Show Recalled Trace** check box.
4. Verify that the **Show** check box is selected.

## Scale Tab


The Scale tab allows you to change the vertical and horizontal scale settings. Changing the scale settings changes how the trace appears on the display but does not change control settings such as Measurement Frequency. In effect, these controls operate like pan and zoom controls.

The screenshot shows the 'Scale' tab in a software interface. It has four tabs at the top: 'Parameters', 'Trace', 'Scale' (which is selected), and 'Prefs'. The 'Scale' tab is divided into two main sections: 'Vertical' and 'Horizontal'. Each section contains a 'Scale' input field, a 'Position' input field, and an 'Autoscale' button. In the 'Vertical' section, the Scale is set to '22.8 °' and the Position is set to '-24.7 m°'. In the 'Horizontal' section, the Scale is set to '1.840 ms' and the Position is set to '160.000 us'.

Setting	Description
Vertical	
Scale	Changes the range shown between the top and bottom of the graph.
Position	Adjusts the phase shown at the center of the graph.
Autoscale	Resets the Position so that the entire trace in the graph.
Horizontal	
Scale	Changes the range shown between the left and right sides of the graph.
Position	Adjusts the phase shown at the left edge of the graph.
Autoscale	Resets the Scale and Position settings to show the entire trace within the graph.

## Prefs Tab

The Prefs tab enables you to change appearance characteristics of the PM display.



Setting	Description
Show graticule	Shows or hides the graticule.
Show Marker readout in graph (selected marker)	Shows or hides the readout for the selected marker in the graph area.
Max trace points	The trace in the PM display can be set to a maximum of 100,000 points (however, the actual number of trace points can extend up to 500,000 points if Max trace points is set to Never Decimate). If the Analysis Length includes more than the selected Max trace points value, the trace is decimated (using the method specified with the Detection control) to be equal to or less than the Max trace points setting (except when Max trace points is set to Never Decimate). This decimated (or undecimated) trace is what is used for marker measurements and for results export.



## Overview

The displays in RF Measurements (Displays > Measurements > RF Measurements) are:

- CCDF
- Channel Power and ACPR
- Frequency and Phase Settling Time (Option SVT)
- MCPR
- Occupied Bandwidth
- Spurious
- Signal Strength


The RF Measurements power measurements and signal statistics help you characterize components and systems.

### Power Measurements

Measurement	Description
Channel Power	The total RF power in the selected channel (located in the ACPR display).
Adjacent Channel Power Ratio	Measure of the signal power leaking from the main channel into adjacent channels.
Multi-Carrier Power Ratio	The ratio of the signal power in the reference channel or group of channels to the power in adjacent channels.
Peak/Avg Ratio	Ratio of the peak power in the transmitted signal to the average power in the transmitted signal (located in the CCDF display).
CCDF	The <i>Complementary Cumulative Distribution Function</i> (CCDF). CCDF shows how much time a signal spends at or above a given power level relative to the average power of a measured signal.


## Channel Power and ACPR (Adjacent Channel Power Ratio) Display

Use the **Channel Power and ACPR** measurement to measure channel power by itself, or adjacent channel leakage ratio with one main channel.



### Measuring Adjacent Channel Power Ratio

1. If needed, recall the acquisition data file you wish to analyze.
2. Select the **Displays** button.
3. Select **RF Measurements** from the **Measurements** box.
4. Double-click **Chan Power and ACPR** in the Available displays box. Click **OK** to complete your selection.
5. Select **Settings** to display the Settings control panel for Chan Power and ACPR (the tab displayed will be the tab displayed the last time the Settings panel was opened).



6. Select the **Freq & RBW** tab and adjust the frequency to that of your main channel. You can also change the frequency from the Status bar found at the bottom left side of the display.
7. To set the number of adjacent channels, select the **Channels** tab. Enter the number of channels in the **Number of adjacent pairs** value box. If zero is entered for the number of adjacent pairs, the resultant measurement will be channel power only.

**NOTE.** As you add adjacent channels, the span of the display is adjusted so that all the channels can be seen. Use the horizontal scale and offset to zoom the display in on any portion of the trace.



8. To set the spacing between channel centers, enter the required value in the **Channel Spacing** value box.
9. To set the channel bandwidth, enter the required value in the **Channel Bandwidth** value box.
10. After you have configured the channel settings, click the close button in the Settings panel or press **Settings** again to remove the Settings panel.
11. Click **Run** to take the measurements. Click **Replay** if you are using recalled acquisition data.

## Viewing Results

Measurement results are displayed in a table below the graph and within the graph itself (which can be enabled/disabled in the Settings > Prefs tab). To see all measurements, you might need to scroll the table. The size of the results table can be changed by dragging the horizontal divider bar between the graph and table areas.

Channel Power (Main): -1.94 dBm	Ch	Offset	Lower	Upper
	A1	2.000 MHz	-65.69 dB	-64.82 dB

Heading	Description
Channel	Identifies the displayed channels. A1 means the first adjacent channel. A2 means second adjacent channel. Adjacent channels are numbered according to their offset from the Main channel. The closest channel is numbered 1. The next closest channel is numbered 2; and so forth.
Lower	The power measured for the lower adjacent channel. Adjacent channel power measurements are displayed in dB relative to the Main channel.
Upper	The power measured for the upper adjacent channel. Adjacent channels power measurements are displayed in dB relative to the Main channel.
Avg Channel Power (Main)	The power measured for the Main channel. The detection type used for measuring channel power and adjacent channel powers is Average. This means that the average of the linear (pre-log) samples is used to determine the power. The Main channel power is displayed in dBm.

[Setting Channel Power and ACPR Settings Parameters \(see page 154\)](#)

## RF Channel Power Measurement

The RF channel power gives an indication of the total average (and other measures) RF power in a given channel.

For some communications systems, there is an “out-of-service” total power measurement defined in the specifications that calls for a specified constant modulation. In this case, the output power should be relatively constant. For many measurements, this may not be the case, and the Power Measurement results will vary as the signal varies.

Average power is the square root of the sum of the squares of the voltage samples over the measurement time.

The defined “channel” width for the Power Measurement defines the bandwidth and shape of the filter used to remove any RF power on frequencies outside of the channel bandwidth.

## Channel Power

The total RF power in the selected frequency band. The detection type used for measuring channel power is Average. This means that the average of the linear (pre-log) samples is used to determine the channel power. To measure channel power, use the ACLR measurement, and set the number of adjacent channels to zero. This results in only the channel power being measured.

## Average Channel Power

The total RF power in the selected channel (located in the ACPR display).

## Adjacent Channel Leakage Power Ratio

Adjacent Channel Leakage power Ratio (ACLR) is the ratio of the mean power centered on the assigned channel frequency to the mean power centered on an adjacent channel frequency. In the 3GPP specification, both the main channel and adjacent channels are required to be filtered with RRC (Root Raised Cosine) filters.

## Adjacent Channel Power

Measure of the signal power leaking into nearby channels.

## Channel Power and ACPR Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the Channel Power and ACPR display are shown in the following table.



Freq & RBW | Measurement Params | Channels | Scale | Prefs

Meas Freq: 1.50000 GHz RBW: 30.000 kHz ☒ Auto


Step: 2.0000 MHz ☒ Auto ☐ VBW:

Settings tab	Description
<a href="#">Freq &amp; RBW (see page 170)</a>	Specify the frequency and resolution bandwidth used for the ACPR measurement.
<a href="#">Measurement Params (see page 170)</a>	Specify several parameters that control the measurement, such as channel filter, chip rate, averaging, and correcting for noise floor.
<a href="#">Channels (ACPR) (see page 155)</a>	This tab specifies the BW and offset parameters of the Channels for the selected ACPR measurement.
<a href="#">Scale (see page 231)</a>	Specifies the vertical and horizontal scale settings.
<a href="#">Prefs (see page 164)</a>	Specifies whether certain display elements are visible.

**Restore defaults.** Sets parameters for a 1-channel WCDMA measurement.

## Channels Tab for ACPR

The Channels tab is where you specify parameters for the channels measured in the ACPR display.



Freq & RBW | Measurement Params | Channels | Scale | Prefs


Number of adjacent pairs: 1

Channel Bandwidth: 1.000 MHz

Channel Spacing: 2.000 MHz

Setting	Description
Number of adjacent pairs	Specifies the number of adjacent channel pairs. Range: 1 - 50; Resolution 1.
Channel Bandwidth	Specifies the frequency width of each channel (all channels share the same value). The maximum channel bandwidth is 39.6 MHz for USB instruments.
Channel Spacing	Specifies the difference in frequency between the centers of each channel.

The following figure illustrates the settings controlled from the Channels tab.



### Changing the Number of Adjacent Pairs

1. Select **Number of adjacent pairs** number entry box.
2. Enter a value for the number of adjacent pairs using the knob or the keypad.

---

**NOTE.** As you change the value for the number of adjacent pairs, the analyzer will update the spectrum display to identify the adjacent channels.

---

3. Select the Close box when you have finished making changes.

### Changing the Channel Bandwidth

1. Select the **Channel Bandwidth** number entry box.
2. Enter a value for the number of adjacent pairs using the knob or the keypad.

---

**NOTE.** As you change the value for the number of adjacent pairs, the analyzer will update the display to indicate the channel bandwidth.

---

3. Select the Close box when you have finished making changes.

### Channel Spacing


1. Select **Channel Spacing** number entry box.
2. Enter a value for the difference in center frequency between channels using the knob or the keypad.

**NOTE.** As you change the value for the number of adjacent pairs, the analyzer will update the display to indicate the channel bandwidth.

3. Select **Close** when you have finished making changes.

## Signal Strength Display

Use the **Signal Strength** display to measure signal strength (channel power and peak channel power).



### Measuring channel power and field strength

1. Select the **Displays** button.
2. Select **RF Measurements** from the **Measurements** box.
3. Double-click **Signal Strength** in the Available displays box. Click **OK** to complete your selection.
4. Tune the analyzer to the channel. To do this, you can enter the frequency directly into the Frequency field on the Basic Toolbar (see the bottom of the above image), or you can use the **Select Channel** button on the Channel Navigation toolbar.
5. Press the **Run** button to take the measurements. If you are using a data acquisition file, click **Replay**.
6. If you are measuring a signal with a directional antenna, select the **Audio** check box located above the graph, on the left side.

When Audio is checked, the analyzer sounds a tone that varies in frequency with the channel power. If you change the direction of the antenna and the channel power drops, the frequency of the audio tone will also drop. If the channel power increases, the audio tone frequency will also increase.

As channel power changes, the vertical channel power bar graph located on the far right side of the measurement display will rise and fall with the channel power.

## Viewing Results

Measurement results are displayed below the graph and within the graph itself (the latter of which can be enabled/disabled in the Signal Strength Settings > Prefs tab).

Channel Power (Main):	Peak Channel Power (Main):
-10.00 dBm	14.09 dBm

Results for Signal Strength measurement

Heading	Description
Channel Power (Main)	The integrated power measured for the Main channel.
Peak Channel Power (Main)	The maximum integrated power measured for the Main channel.

[Signal Strength Settings \(see page 158\)](#)

# Signal Strength Settings

**Menu Bar:** Setup > Settings

**Basic Control Toolbar:** 

The settings for the Signal Strength display are shown in the following table.

Freq & RBW	Measurement Params	Channels	Scale	Prefs
Meas Freq: 1.50000 GHz <span style="margin-left: 100px;">RBW: 30.000 kHz</span> <span style="margin-left: 20px;"><input checked="" type="checkbox"/> Auto</span>				
Step: 2.0000 MHz <span style="margin-left: 20px;"><input checked="" type="checkbox"/> Auto</span> <span style="margin-left: 20px;"><input type="checkbox"/> VBW:</span>				

Settings tab	Description
<a href="#">Freq &amp; RBW (see page 160)</a>	Specify the frequency and resolution bandwidth used for the signal strength measurements.
<a href="#">Measurement Params (see page 160)</a>	Specify several parameters that control the measurement, averaging. External amplitude corrections, and display units.
<a href="#">Channels (see page 162)</a>	This tab specifies the BW
<a href="#">Scale (see page 163)</a>	Specifies the vertical and horizontal scale settings.
<a href="#">Prefs (see page 164)</a>	Specifies trace points, trace detection, and visible display elements ( graticule, marker readouts, etc ) for the Signal Strength measurement display.

## Freq & RBW Tab for Signal Strength display

The Freq & RBW tab specifies frequency parameters for the signal strength measurements.

The screenshot shows the 'Freq & RBW' tab with the following settings:

- Meas Freq: 1.00000 GHz
- RBW: 30.000 kHz
- Step: 2.0000 MHz
- Auto: ☒
- VBW: ☐

Setting	Description
Meas Freq	Specifies the center/measurement frequency.
Step	The Step control sets the increment/decrement size for the adjustment of the center frequency. If Auto is enabled, the analyzer will adjust the Step size as required.
RBW	Select Auto or Manual. Adjusts the RBW for the entire measurement. This setting is Independent of the Spectrum view's RBW setting.
VBW	Adjusts the VBW (Video Bandwidth) value. VBW Maximum = 10 times the current RBW value. VBW Minimum = 1/10,000 RBW setting.

**NOTE.** While the center frequency and step settings on this control tab are shared between ACPR, MCPR and Occupied Bandwidth, the RBW setting is not shared. The RBW setting is unique for each measurement.

### VBW

The VBW setting enables/disables the Video Bandwidth filter. VBW is used in traditional swept analyzers to reduce the effect of noise on the displayed signal. The VBW algorithm in the analyzer emulates the VBW filters of traditional swept analyzers.

The maximum VBW value is 10 times the current RBW setting. The minimum VBW value is 1/10,000 of the RBW setting.

**NOTE.** If you are following a procedure that says to "set VBW to three times the RBW value or greater", it means that the test should be conducted with no VBW effects. In the application, this condition is met by disabling the VBW function.

## Measurement Params Tab for Signal Strength display

The Measurement Params tab is where you set parameters that control the Signal Strength measurement.



Freq & RBW | **Measurement Params** | Channels | Scale | Prefs

Average: Frequency Domain   
     Off  
     Time Domain  
     Frequency Domain

Number: 10


Freq & RBW | **Measurement Params** | Channels | Scale | Prefs

Average: Off

Parameter	Description
Average	Enables/disables measurement averaging. Averaging can be enabled in either the Frequency Domain or Time Domain.
Frequency domain	This setting takes the average linear value of the traces (so that rms values are preserved). The number of averages is user-defined. Frequency domain averaging is available in spans larger (or smaller) than the maximum real time bandwidth. This is the mode to use unless you need to extract maximum dynamic range from an ACPR measurement.
Time domain	This setting takes the average linear value of the traces. It is useful if you need to extract maximum dynamic range from an ACPR measurement. The number of traces is user defined. But, the signals must be triggered and repeating. That is, the signal needs to be exactly the same for each acquisition. When this condition is met, each waveform contains the same signal, but the random noise changes from acquisition to acquisition and the average value of the random noise is lowered, while the signal value remains constant. Time domain averaging is not available in spans wider than the maximum real-time bandwidth.
Off	This setting turns averaging off.
Number	Specifies the number of acquisitions to be averaged when Averaging is set to Frequency Domain. Specifies the number of successive capture records that are averaged when Averaging is set to Time Domain.
Amplitude Units	Opens the <a href="#">Amplitude Units (see page 750)</a> dialog box.
Ext Corrections	Opens the <a href="#">External Gain/Loss Correction (see page 760)</a> dialog box.

## Channels Tab for Signal Strength display

The Channels tab is where you specify the channel bandwidth measured in the Signal Strength display.



The screenshot shows a software interface with five tabs: 'Freq & RBW', 'Measurement Params', 'Channels', 'Scale', and 'Prefs'. The 'Channels' tab is selected and highlighted. Below the tabs, there is a label 'Channel Bandwidth:' followed by a text input field containing the value '1.000 MHz'.

### Changing the Channel Bandwidth

1. Select the **Channel Bandwidth** number entry box.
2. Enter a value for the channel bandwidth.
3. Select the Close box when you have finished making changes.

## Scale Tab for Signal Strength display

The Scale tab allows you to change the vertical and horizontal scale settings. Changing the scale settings changes how the trace appears on the display but does not change control settings such as Center Frequency.

The screenshot shows the 'Scale' tab in the SignalVu-PC interface. It contains two main sections: 'Vertical' and 'Horizontal'. The 'Vertical' section has a 'Scale' input set to '100.00 dB' and a 'Position' input set to '0.00 dBm', with an 'Autoscale' button below. The 'Horizontal' section has a 'Scale' input set to '39.00 MHz' and a 'Position' input set to '1.50000 GHz', with an 'Autoscale' button below. A 'Reset Scale' button is positioned between the two sections.

Setting	Description
Vertical	Controls the vertical position and scale of the trace display.
Scale	Changes the vertical scale units. This is only accessible when the vertical units are set to dBm.
Autoscale	Automatically scales the vertical axis to contain the complete trace.
Horizontal	Controls the span of the trace display and position of the trace.
Scale	Allows you to, in effect, change the span.
Autoscale	Automatically scales the horizontal axis to optimize the display of the trace.
Reset scale	Resets all settings to their default values.

# Prefs Tab

The Prefs tab enables you to change parameters of the measurement display. The parameters include enabling/disabling Marker Readout, switching the Graticule display on/off, and trace points and detection.


Setting	Description
Trace Points	Sets the number of trace points computed for each line. These are the points used for marker measurements and for results export.
Show graticule	Shows or hides the graticule.
Trace Detection	<p><b>+Peak</b>: Shows the peak power in a bin (of chosen RBW) if there are multiple points to choose from within a bin.</p> <p><b>Avg (VRMS)</b>: Shows the average power in a bin (of chosen RBW) if there are multiple points to choose from within a bin.</p>
Show Marker readout in graph (selected marker)	Shows or hides the readout for the selected marker in the graph area.

# MCPR (Multiple Carrier Power Ratio) Display

Use the MCPR measurement to measure adjacent channel power ratio for multiple main channels or when adjacent channel pairs have different offsets and/or bandwidths. The MCPR display show the Reference Power and the ratio of each adjacent channel to the Reference Power. You can select whether the Reference Power is the total of all active channels or a single channel.

## Measuring Multiple Carrier Power Ratio

1. Recall an appropriate acquisition data file, if needed.
2. Press the front-panel **Displays** button.
3. From the **Select Displays** window, select **RF Measurements** or **P25 Analysis** from the Measurements box.
4. Double-click the **MCPR** icon in the **Available displays** box. Click **OK** to complete your selection.
5. Press the **Settings** button. This displays the control panel for MCPR (the tab displayed will be the tab displayed the last time the Settings panel was opened).




6. Select the **Freq & RBW** tab and adjust the frequency to that of the main channel. You can also adjust the frequency on the Status bar using the Frequency field on the bottom left of the display.
7. Click on the **Channels** tab. To set the number of Main channels, enter the number of Main channels in the **Number** text entry box under **Main Channels**.

---

**NOTE.** As you add channels, the span of the display will be adjusted so that all the channels can be seen.

---

8. To set the bandwidth of all main channels, enter a value in the **BW** value box.
9. To set the spacing between the main channels, enter a value in the **Spacing** value box.
10. To prevent a main channel power level from being included in the Power Reference (Total) calculation, select the channel to be excluded in the **Inactive** box.
11. To add adjacent channels, click the **Add** button under **Adj Chans**.




12. To edit Frequency Offset or Bandwidth, click within the value box and use the front-panel knob or your keyboard to set the value. Click **Close** to save your changes.

---

**NOTE.** Frequency Offset is the difference between the center frequency of the selected channel and the Measurement Frequency. All channels (Main or Adjacent) are specified by their offset from the Measurement Frequency.

---


13. To enable and define power limits, check the **Enable Power Limits** box and enter the desired Upper and Lower limits. You can read more about power limits [here \(see page 167\)](#).



14. After you have configured the Main and Adjacent channels, click the close button in the Settings panel or the **Settings** button to remove the settings panel.

## Viewing Results

MCPR measurement results are displayed both in the spectrum graph and in a table below the spectrum display. Individual Main channel power measurements appear in the graph under their channel identifiers. Individual adjacent channel power ratios also appear in the graph under the adjacent channel identifier.



The following table details the entries in the results table.


Heading	Description
Ch	Identifies the adjacent channels. Adjacent channels are numbered according to their offset from the Main channel. The closest channel is numbered 1. The next closest channel is numbered 2; and so forth. The prefix "L" means lower; "U" means upper.
Offset	The offset is the difference in frequency between the Measurement Frequency and the center frequency of the channel.
Lower	Displays the ratio of the lower adjacent channel power to the Power Reference.
Upper	Displays the ratio of the upper adjacent channel power to the Power Reference.
L. Limit	Displays the lower power limit.
U. Limit	Displays the upper power limit.
Power Reference	Depending on the selected Power Ref, this readout displays either the power of the selected main channel or the total power in the active main channels.

Depending on the number of adjacent channels, to see all the measurements, you might need to drag the divider bar between the main display and the results table at the bottom of the window to change the height of the results table.

[Setting MCPR Measurement Parameters \(see page 170\)](#)

### Setting Power Limits

When power limits are enabled (**Settings > Channels > Add** or **Settings > Channels > Edit**), the comparison of the actual results of an adjacent channel is done against the limits. If there is a failure, the Lower and Upper power cells in the MCPR table will be red and the failure segments of the trace display will be red. The words **Fail** in red will also appear in the top left corner of the display (even if one adjacent band fails). See the following image for an example.




## Multiple Carrier Power Ratio

The ratio of the signal power in an adjacent channel to the power in one or more main channels.

## MCPR Settings

**Main menu bar: Setup > Settings**

The Setup control panel tabs for MCPR (Multiple Carrier Power Ratio) are:





Settings tab	Description
<a href="#">Freq &amp; RBW (see page 170)</a>	Specify the frequency and resolution bandwidth used for the MCPR measurements.
<a href="#">Measurement Params (see page 170)</a>	Specifies parameters controlling how the MCPR measurement is made.
<a href="#">Channels (see page 173)</a>	Specifies the parameters of the channels to be measured.
<a href="#">Scale (see page 231)</a>	Specifies the vertical and horizontal scale and offset values.
<a href="#">Prefs (see page 164)</a>	Specifies whether or not certain display elements are shown.

**Restore defaults.** Sets parameters for a 4-carrier WCDMA measurement.

# Freq & RBW Tab for ACPR and MCPR Displays

The Freq & RBW tab specifies frequency parameters for the Channel Power & ACPR measurements and MCPR measurement.

Freq & RBW

Measurement Params

Channels

Scale

Prefs

Meas Freq: 1.00000 GHz

RBW: 30.000 kHz

☒ Auto

Step: 2.0000 MHz

☒ Auto

☐ VBW:

Setting	Description
Meas Freq	Specifies the center/measurement frequency.
Step	The Step control sets the increment/decrement size for the adjustment of the center frequency. If Auto is enabled, the analyzer will adjust the Step size as required.
RBW	Select Auto or Manual. Adjusts the RBW for the entire measurement. This setting is Independent of the Spectrum view's RBW setting.
VBW	Adjusts the VBW (Video Bandwidth) value. VBW Maximum = 10 times the current RBW value. VBW Minimum = 1/10,000 RBW setting.

**NOTE.** While the center frequency and step settings on this control tab are shared between ACPR, MCPR and Occupied Bandwidth, the RBW setting is not shared. The RBW setting is unique for each measurement.

## VBW

The VBW setting enables/disables the Video Bandwidth filter. VBW is used in traditional swept analyzers to reduce the effect of noise on the displayed signal. The VBW algorithm in the analyzer emulates the VBW filters of traditional swept analyzers.

The maximum VBW value is 10 times the current RBW setting. The minimum VBW value is 1/10,000 of the RBW setting.

# Measurement Params for ACPR and MCPR Displays

The Measurement Params tab is where you set parameters that control the ACPR and MCPR measurements.

Freq & RBW	Measurement Params	Channels	Scale	Prefs	
<i>Requires triggered synchronous signal</i>					
Average:	Time Domain	Number:	10	Channel Filter:	Root-raised Cosine
<input type="checkbox"/> Correct for Noise Floor					
Power Reference:	Total (active channels)	Filter Parameter:		0.22	
		Chip Rate:		3.84 MHz	

Freq & RBW	Measurement Params	Channels	Scale	Prefs	
Average:	Frequency Domain	Number:	10	Channel Filter:	Root-raised Cosine
<input checked="" type="checkbox"/> Correct for Noise Floor					
		Filter Parameter:		0.22	
		Symbol/Chip Rate:		3.84 MHz	

Parameter	Description
Average	Enables/disables measurement averaging. Averaging can be enabled in either the Frequency Domain or Time Domain.
Frequency-domain	This setting takes the average linear value of the traces (so that rms values are preserved). The number of averages is user-defined. Frequency domain averaging is available in spans larger (or smaller) than the maximum real time bandwidth. This is the mode to use unless you need to extract maximum dynamic range from an ACPR measurement.
Time-domain	This setting takes the average linear value of the traces. It is useful if you need to extract maximum dynamic range from an ACPR measurement. The number of traces is user defined. But, the signals must be triggered and repeating. That is, the signal needs to be exactly the same for each acquisition. When this condition is met, each waveform contains the same signal, but the random noise changes from acquisition to acquisition and the average value of the random noise is lowered, while the signal value remains constant. Time domain averaging is not available in spans wider than the maximum real-time bandwidth.
Off	This setting turns Average off.
Number	Specifies the number of acquisitions to be averaged when Averaging is set to Frequency Domain. Specifies the number of successive capture records that are averaged when Averaging is set to Time Domain.
Correct for Noise Floor	Enables/disables the Noise Floor Correction function.
Power Reference	Specifies power against which the results are compared. Choices available are each of the existing main channels and "Total (active channels)". Only present when MCPR is the selected display.
Channel Filter	Specify the channel filter used. Select between None (default) and Root-raised Cosine.
Filter Parameter	Value entry box for the Root-raised Cosine filter Adjacent Channel Filter. Present only when the Channel Filter is set to Root-raised Cosine.
Chip Rate	Value entry box for the Root-raised Cosine chip rate. Present only when the Channel Filter is set to Root-raised Cosine.

### Correct for Noise Floor

This setting is only available when an RSA500 series or RSA600 series instrument is connected.

When this setting is enabled, the instrument applies a correction to the ACPR or MCPR measurement to reduce the effect of instrument noise on the results. It generates this correction by taking a preliminary acquisition to measure the instrument noise floor. Once this is done, the measurement proceeds, applying the correction to each result. When any relevant settings (reference level, attenuator, frequency, or span) are changed, the instrument performs a new noise measurement and correction.

The noise correction signal is created by switching off the input to the RSA and performing acquisitions of the instrument internal noise. A minimum of 100 acquisitions are averaged to create the noise reference signal. It is possible to increase the number of acquisitions for creation of the noise reference signal. When frequency domain averaging is enabled and the number of averages exceeds 100, the number of frequency domain averages becomes the total number of acquisitions to determine the instrument internal noise. Noise is measured for each channel defined by the measurement. The noise reference from each channel is

subtracted from the incoming signal power for each channel to create the corrected result. All calculations are performed in Watts, and then converted to the desired units.

The amount of noise correction is limited to 12 dB to avoid the possibility of a negative power measurement. This is a rare condition that could occur if the subtraction of the reference power from the channel power results in a negative value (or 'infinite' dBm).


The measured values differ from the displayed trace in two ways. First, any filtering applied to the channels is not displayed on the trace. Second, the single value of measured noise for a channel is subtracted from each trace point in the channel, rather than offsetting the entire channel by a single amount. This produces a smooth trace with no discontinuities at the channel edges.

## Channels Tab for MCPR

**Main menu bar: Setup > Settings > Channels**


**Favorites toolbar:** 

The Channels tab is where you specify the parameters for the channels measured in the MCPR display.



Setting	Description
<b>Main Channels</b>	
Number	Sets the number of Main channels.
BW	Sets the bandwidth of the Main channels. The maximum channel bandwidth is 39.6 MHz for USB instruments.
Spacing	Sets the frequency difference between the centers of the Main channels.
Inactive	Selected channels are ignored by the measurement routine.
<b>Adj Chans</b>	
Add	Opens the Edit Channel Parameters dialog, which you use to specify the parameters of a new pair of adjacent channels. You can add up to 50 adjacent channel pairs.
Edit	Opens the Edit Channel Parameters dialog box. (You must first select a channel to enable the Edit button.)
Delete	Deletes the selected main channel or adjacent channel pair.
Channel Definition table	A table of the parameters for every channel. Offset is the frequency difference between the Center Frequency and center of the selected channel. Nothing in the table is editable directly. You can set the upper and lower limits by clicking on the Add button.

The following figure illustrates the settings controlled from the Channels tab.



### Editing Channel Parameters

To edit the offset or bandwidth of a Main channel:

1. Select the value in the **BW** or **Spacing** number entry boxes.
2. Adjust the value as required. All the Main channels share the same BW and Spacing.
3. Select the appropriate check box to make a channel Inactive, as appropriate.
4. Click the Close button when you have finished making changes.

To edit the offset or bandwidth of an Adjacent channel:

1. Select the channel to be edited in the channel definition table.
2. Select **Edit**. This displays the **Edit Channel Parameters** dialog box.
3. Adjust the values for the **Frequency Offset**, **Bandwidth**, and upper and lower **Limits**, as required.
4. Click the Close button when you have finished making changes.

### Adding Channels

To add a main channel:

1. Select the **Number** entry box.
2. Use the knob to enter a value for the desired number of Main channels.
3. Click the Close button when you have finished making changes.

To add an adjacent channel pair:

1. Select **Add**. This displays the **Edit Channel Parameters** dialog box.
2. Use the knob to enter values for the **Frequency Offset**, **Bandwidth**, and upper and lower **Limits**, as required. The Frequency Offset is measured from the Meas Frequency of the Main channels.
3. Click the Close button when you have finished making changes.

### Deleting Channels

To delete a main channel:

1. Select the **Number** entry box.
2. Use the knob to reduce the number of channels or enter a new value using the front-panel keypad.
3. Click the Close button when you have finished making changes.

To delete an adjacent channel:

1. Select the channel to be deleted in the channel definition table.
2. Select **Delete**. This removes the selected channel from the channel table.
3. Click the Close button when you have finished making changes.


## Occupied BW & x dB BW Display

The Occupied BW display shows the bandwidth within which 99% (a user-defined value, the default is 99%) of the power transmitted within the measurement bandwidth falls.

To show the Occupied BW display:

1. Recall an appropriate acquisition data file.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **RF Measurements** in the **Measurements** box.
4. In the **Available displays** box, double-click the **Occupied Bandwidth** icon or select the icon and click **Add**. The Occupied Bandwidth icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to display the Occupied Bandwidth.
6. Press the **Replay** button to take measurements on the recalled acquisition data file.

## Elements of the Display





Item	Display element	Description
1	Check mark indicator	The check mark indicator denotes the display for which the acquisition hardware is optimized. This indicator appears only when the display is the selected display.  <b>NOTE.</b> When Best for multiple windows is selected in the Amplitude control panel's RF & IF Optimization control, none of the measurement displays shows a checkmark, as there is not a single optimized measurement.
2	Averaging readout	Appears when averaging is enabled (Settings > Parameters tab > Average results). Displays "Avg: n of m" while averaging the results and "Avg: m" once the requested number of results have been averaged.
3	Autoscale	Adjusts the vertical and horizontal settings so that the entire trace fits in the graph.
4	Trace function readout	Displays either Normal or MaxHold to indicate trace function.
5	Clear	Resets count for Average and MaxHold functions. Enabled only when Averaging or MaxHold is enabled. Pressing Clear will clear the trace and, if acquisition is running, restart the averaging or hold process.
6	Graph	Displays the input signal. Shaded areas indicate the measurement bandwidth (Settings > Parameters tab > Measurement BW).
7	Blue lines	The blue lines indicate where the selected results (selected in the Main results area) are being measured on the trace.
8	Grid divider	Determines the portion of the display allocated to the graph and detailed results area. You can move the grid divider all the way to the top or bottom and any position in between.
9	Detailed results area	Displays additional measurements results.
10	Position and dB/div Units (not shown)	Position sets the top of graph value. The dB/div setting is the vertical scale value.  Sets the global amplitude units for all the views in the analysis window. This will change the amplitude selection in the Units tab of the Amplitude control panel.
11	Main results area	Displays results for Occupied Bandwidth (OBW) and x dB bandwidth. Use the two radio buttons to select which of the two results are illustrated in the graph with the blue lines and arrows. There are also controls for adjusting OBW % Power, x dB BW, and RBW.
12	VBW	Enables the VBW (Video Bandwidth) filter. Displays current VBW filter setting. See Setup > Settings > <a href="#">Freq &amp; RBW tab (see page 170)</a> .

### Detailed Results Readouts

Measurement	Description
Freq Error	The frequency difference between the measured carrier frequency of the signal and the user-selected center frequency of the analyzer.
OBW Level left	The signal level at the left edge of the occupied bandwidth.
OBW Level right	The signal level at the right edge of the occupied bandwidth.
OBW Ref Power	The total power measured within the measurement bandwidth.
x dB BW Ref Power	The peak power measured within the measurement bandwidth.

[Changing the Occupied Bandwidth Settings \(see page 178\)](#)

## Occupied Bandwidth

Bandwidth within which some defined percentage of the power transmitted on a single channel lies.

## Occupied BW & x dB BW Settings

**Main menu bar: Setup > Settings**

The control panel tabs for the Occupied Bandwidth display are shown in the following table.

Settings tab	Description
<a href="#">Freq &amp; RBW (see page 227)</a>	Allows you to specify the Center Frequency, Step size and RBW.
<a href="#">Parameters (see page 179)</a>	Allows you to specify the Occupied BW % Power, x dB level, Measurement BW, enable averaging and the Max Hold function.
<a href="#">Scale (see page 231)</a>	Allows you to set the vertical and horizontal scale parameters.
<a href="#">Prefs (see page 164)</a>	The Prefs tab enables you to set characteristics of the measurement display.

## Parameters Tab

The Parameters tab enables you to specify parameters that control the Occupied BW measurement.

The screenshot shows the 'Parameters' tab in a software interface. It contains several input fields and checkboxes. The 'Occupied BW % Power' field is set to 99.0 %. The 'x dB level' field is set to -26.0 dB. The 'Measurement BW' field is set to 10.00 MHz. There are two checkboxes: 'Max Hold spectral data' and 'Average results', both of which are currently unchecked. The 'Count' field is set to 10.

Setting	Description
Occupied BW % Power	Specifies the proportion of power within the occupied bandwidth (referenced against the total power in the measurement bandwidth).
x dB level	x dB level defines the x dB BW level search threshold.
Measurement BW	Specifies the frequency range used by the measurement.
Max Hold spectral data	Enables the Max Hold function.
Average results	Enables/disables results averaging. Note that this is not an averaging of the trace, but an averaging of the results.
Count	Specifies the number of results averaged to calculate the Occupied BW. Range: 2 to 10,000.

### x dB Level

The x dB level determines the x dB BW. The instrument analyzes the spectrum trace to locate the frequencies at which the level is x dB down from the peak level calculated over the measurement bandwidth. The frequency difference between the upper and lower crossing thresholds is the x dB BW.

Range: -80.0 to -1.0 dB; Resolution: 0.1%; Inc/dec small: 0.1%, large: 1%; Default: -26 dB

### Max Hold Spectral Data

Max Hold displays the maximum value in the acquisition record for each display point. Each new trace display point is compared to the previous maximum value and the greater value is retained for display and subsequent comparisons.


## Spurious display

To show the Spurious display:

1. Recall an appropriate acquisition data file.
2. Click the **Displays** button or select **Setup > Displays**.


- From the Measurements box, select **RF Measurements**.
- Double-click the **Spurious** icon in the **Available displays** box. This adds the Spurious icon to the **Selected displays** box (and removes it from the Available displays box). Alternatively, you can click the Spurious icon and then click the Add button to select Spurious for display.
- Click the **OK** button.
- Press the **Replay** button to take measurements on the recalled acquisition data file.








### Elements of the Spurious Display



Item	Display element	Description
1	Check mark indicator	Indicates the display for which the acquisition hardware is optimized.  <b>NOTE.</b> When Best for multiple windows is selected in the Amplitude control panel's RF & IF Optimization control, none of the measurement displays shows a checkmark, as there is not a single optimized measurement.
2	Vert Position	Sets the top of graph value. This is only a visual control for panning the graph. The Reference Level is adjusted in the Toolbar and the Ampl control panel. By default, Vert Position = Ref Level.
3	Units	Sets the global Amplitude units for all the views in the analysis window. This will change the Amplitude selection in the Units tab of Analysis Control panel.
4	dB/ div	Sets the vertical scale value. The maximum value is 20.00 dB/division.
5	Bottom-of-graph readout	Indicates the amplitude at the bottom of the graph. This value changes with the dB/div and Vertical Position settings.
6	Autoscale	Adjusts the Vertical and Horizontal scaling to display the entire trace on screen. Selects Multi-range display mode.
7	Start	Adjusts the graph start frequency. This setting affects only visual scaling, not measurement parameters.
8	Green bar	Indicates the range that is selected on the Settings > Ranges and Settings > Limits tabs.
9	Spur table	Displays spur measurements. See the following table for details.
10	Stop	Adjusts the graph stop frequency. This setting affects only visual scaling, not measurement parameters.
11	Clear	Restarts multi-trace functions (Average, Max Hold).
12	Trace function	Indicates the trace processing method. If Average or Max Hold is selected, this readout displays the number of traces being processed (averaged or compared for the Max Hold value).
13	Show	Controls whether the selected trace is visible or not. When trace is Off, the box is not checked.
14	Trace	Selects a trace. Clicking here pops up a context menu listing the available traces, whether they are enabled or not. If you select a trace that is not currently enabled, it will be made enabled.
15	Ref:	If enabled, displays the power reference level.
16	Pass / Fail readout	Indicates whether one or more spurs have exceeded a limit specified on the <b>Settings &gt; Limits</b> tab.

## Elements of the Spurious Graph Display



Item	Display element	Description
1		The green line or shading indicates an Abs (absolute) limit. The absolute limit is enabled when the mask is set to Abs, Abs & Rel, or Abs OR Rel. Note that absolute and relative amplitude masks can overlap.
2		The gray-shaded area indicates a portion of the spectrum where no measurements are being taken.
3		The cyan line or shading indicates a Relative limit. The relative limit is enabled when the mask is set to Rel, Abs & Rel, or Abs OR Rel. Note that absolute and relative amplitude masks can overlap.
4	abs rel	Reminder that green-shaded areas highlight absolute limits and cyan-shaded areas highlight relative limits.
5		This indicates the selected spur, when it is in violation of the limits. In Run mode, this is the peak spur violation. The selected marker is highlighted in the Spur table below the graph with a blue background.
6		A spur marker. Indicates a spur that does not exceed the mask settings. See the <a href="#">Settings &gt; Ranges and Limits tab (see page 187)</a> .
7		A violation marker. Indicates a spur that exceeds the mask settings. See the <a href="#">Settings &gt; Ranges and Limits tab (see page 187)</a> .
--		Indicates the selected spur when it is not in violation of the limits. The selected marker is highlighted in the Spur table below the graph with a blue background.
8	1, 2, 3...	A Spur number. The number indicates the row in the spur table that corresponds to the spur. The instrument can display up to 999 spurs.
9	A, B, C, D...	Identifies the enabled ranges.
10	Green bar	Indicates the range selected on the <a href="#">Settings &gt; Ranges and Limits (see page 187)</a> tab.
11	Ref	Indicates the location of the power reference. See <a href="#">Settings &gt; Reference (see page 185)</a> .

## Elements of the Spur Table

Spur	Range	Freq Abs	Freq Rel	Ampl Abs	Ampl Rel	Limit Abs	Limit Rel
1	B	1.751145 GHz	– Hz	-5.91 dBm	4.09 dB	-15.00 dBm	-15.00 dB
2	E	2.053875 GHz	– Hz	-8.99 dBm	1.01 dB	-15.00 dBm	-10.00 dB
3	D	1.903950 GHz	– Hz	-10.48 dBm	-0.48 dB	-50.00 dBm	-57.00 dB
4	A	1.748826 GHz	– Hz	-39.57 dBm	-29.57 dB	-57.00 dBm	-30.00 dB
5	D	1.899062 GHz	– Hz	-40.31 dBm	-30.31 dB	-50.00 dBm	-57.00 dB

Column	Description
Spur	A number that identifies a spur in the graph area. The instrument can display a maximum of 999 spurs.
Range	The letter representing the frequency range where the spur is located.
Freq Abs	The absolute frequency at which the spur occurs.
Freq Rel	The relative frequency at which the spur occurs. The relative frequency is the difference between the absolute frequency (absolute) and the carrier frequency.
Ampl Abs	The absolute amplitude of the spur.
Ampl Rel	The relative amplitude at which the spur occurs. The relative amplitude is the difference between the absolute amplitude and the carrier amplitude. See the <a href="#">Settings &gt; Limits</a> tab.
Lim Abs	The value of the absolute amplitude limit at the spur frequency. This value can vary even with small spur frequency changes if the start and stop limit values are different. See the <a href="#">Settings &gt; Ranges and Limits</a> tab (see page 187).
Lim Rel	The relative amplitude limit at which the spur occurs. This value can vary even with small spur frequency changes if the start and stop relative amplitude limit values are different. See the <a href="#">Settings &gt; Ranges and Limits</a> tab (see page 187).
Blue background	The cell in the Spur column with a blue background identifies the selected spur.
Red background	Cells in the Spur column with a red background identify violations. Cells in the results area with a red background identify the measurement that exceeded a limit.

## Rearranging the Columns in the Spur Table

You can rearrange the order of the columns in the Spur Table. To move a column, click on the column heading and drag it to the desired position.

## Sorting the Rows in the Spur Table

You can sort the rows in the Spur table by clicking on the column heading. For example, if you click on the Freq Abs heading, the results in the Spur table will be sorted by frequency. If you click on Range, the rows will be sorted by range. Clicking a second time on the same heading reverses the order.

[Changing the Spurious Display Settings \(see page 184\)](#)

## Spurious display settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The control panel tabs for the Spurious display are shown in the following table.

Settings tab	Description
<a href="#">Parameters (see page 185)</a>	Specifies whether the graph displays one range or multiple ranges. Specifies whether all spurs are shown or only spurs over specified limits.
<a href="#">Reference (see page 185)</a>	Specifies the Power Reference level.
<a href="#">Ranges (see page 187)</a>	Specifies start and stop frequencies of ranges and which ranges to take measurements in. Sets parameters that define a spur. Review, save and load the Range table from this tab.
<a href="#">Limits (see page 187)</a>	Specifies Pass/Fail limit parameters.
<a href="#">Traces (see page 228)</a>	Specifies the trace Function.
<a href="#">Scale (see page 231)</a>	Specifies the vertical and horizontal scale settings.
<a href="#">Prefs (see page 164)</a>	Specifies the appearance features of the graph area.

**Restore defaults.** Sets the Spurious parameters to their default values.



## Parameters Tab

The Parameters tab enables you to specify settings that control the Spurious measurement.

The screenshot shows the 'Parameters' tab selected in a software interface. It contains two main sections: 'Frequency Ranges' and 'List Spurs'. In 'Frequency Ranges', the 'Multi' radio button is selected. In 'List Spurs', the 'Over Limit' radio button is selected.

Setting	Description
<b>Frequency Ranges</b>	
Multi	Enables the instrument to display all enabled ranges in the graph.
Single	Limits the graph to the display of only one range. The displayed range is set to the range that contains the selected spur.
<b>List Spurs</b>	
All spurs	Displays any spur that exceeds the Threshold and Excursion values set on the Ranges tab.
Over Limit	Displays only spurs that exceed both the Threshold and Excursion values set on the Ranges tab and the limits specified on the Limits tab.


## Reference Tab

The Reference tab enables you to specify the Power Reference parameter. The Power reference parameter is used to calculate relative values in the Spur table and to calculate relative amplitude limits.

The screenshot shows the 'Reference' tab selected in a software interface. It contains two settings: 'Power reference' with a dropdown menu showing 'Manual level' selected, and 'Reference power level' with a text box containing '-10.00 dBm'.

Setting	Description
Power Reference	Specifies the power reference level used for relative values and limits.
No reference	Power level readings are calculated only for absolute values, no relative values are calculated.
Manual level	The reference level for relative measurements is specified by the Reference power level setting.
Carrier	The reference level for relative measurements is based on the power level calculated at the specified carrier frequency.

### Setting the Power Reference Level to No Reference




The screenshot shows the 'Reference' tab selected in the top navigation bar. Below the tabs, the 'Power reference:' label is followed by a dropdown menu that currently displays 'No reference'.

To set the power reference to No Reference:

- Select **No reference** from the **Power reference** drop-down list.

### Setting the Power Reference Level to Manual Level



The screenshot shows the 'Reference' tab selected. The 'Power reference:' dropdown menu is now set to 'Manual level'. To its right, a text entry box labeled 'Reference power level:' contains the value '-10.00 dBm'.

To set the power reference to manual level:

1. Select **Manual level** from the **Power reference** drop-down list. This displays the **Reference power level** entry box.
2. Specify the desired power level in the **Reference power level** entry box.

## Setting the Power Reference Level to Carrier

Parameters Reference Ranges and Limits Trace Scale Prefs

Power reference: Carrier

Frequency: 1.466000 GHz Res BW: 85 kHz ☒ Auto Detection: +Peak

Channel width: 8.500 MHz

Threshold: -10.00 dBm Integration BW: 2 MHz

To set the power reference to Carrier:

1. Select **Carrier** from the **Power reference** drop-down list.
2. To set the Carrier frequency, specify the necessary values in the **Frequency** and **Channel width** entry boxes .
3. Specify the **Threshold** level.
4. Specify the **Integration BW**. The Integration BW is the bandwidth over which the carrier is measured.
5. If necessary, specify the Resolution Bandwidth by changing the value in the **Res BW** entry box. Auto is the recommended setting.
6. Set the **Detection** method. Select **+Peak**, **Avg (VRMS)**, or **Avg (of logs)**.

---

**NOTE.** If the power level measured over the Integration BW about the carrier frequency is below the threshold level, the instrument concludes that no carrier is present and no relative measurements will be taken. Absolute measurements will still be taken.

---

## Ranges and Limits Tab

Use the Ranges and Limits tab to specify the parameters that control the Spurious measurement. From the Ranges and Limits tab, you specify the start and stop frequencies for ranges, whether or not a range is enabled, the parameters that specify what constitutes a spur, measurement filter shape and bandwidth, and the detection method used for processing signals, as well as the pass/fail parameters for limit testing.

	On	Start (Hz)	Stop (Hz)	Filter Shape	BW (Hz)	Auto	Detector	VBW (Hz)	VBW On
A	<input checked="" type="checkbox"/>	1.492500G	1.507500G	RBW	100.000k	X	+Peak	100k	
B	<input checked="" type="checkbox"/>	1.512500G	1.537500G	RBW	200.000k	X	+Peak	200k	
C	<input type="checkbox"/>	0.000000	0.000000	RBW	1.000M	X	+Peak	1M	
D	<input type="checkbox"/>	0.000000	0.000000	RBW	1.000M	X	+Peak	1M	
E	<input type="checkbox"/>	0.000000	0.000000	RBW	1.000M	X	+Peak	1M	

Expand Reset layout Load... Save...


Setting	Description
Expand	Displays the Ranges and Limits Table in a new, resizable window.
Reset layout	You can reorder columns in the Ranges and Limits Table by dragging the columns to a new position. Clicking Reset Layout returns the column order to the factory default order.
Load	Click to load a saved Ranges and Limits table from a file. The default directory is the last folder to which you saved an Acq data export (.CSV)" file.
Save	Click to save the current Ranges and Limits table to a file. The default directory is the last folder to which you saved an Acq data export (.CSV)" file.

To specify the ranges and limits for the Spurious measurement:

- Edit the values in the Ranges and Limits table.

You can edit the Ranges and Limits table in two ways:

- Edit values directly from the Ranges and Limits tab. You will need to scroll the table to access all settings.
- Click the **Expand** button. This displays the Ranges and Limits Table in a new window that can be sized to the full screen.



The following table describes the parameters that are set in the Ranges and Limits Table.

### Ranges and Limits Table Settings

Setting	Description
On	Specifies whether or not measurements are taken in the specified range.
Start (Hz)	Readout of the start frequency for the selected range.
Stop (Hz)	Readout of the stop frequency for the selected range.
Filter shape	Specifies the filter shape used for the Spurious measurement.
BW (Hz)	Specifies the bandwidth used for the selected filter shape.
Auto	Sets the BW automatically. If CISPR is selected for Filter shape, this control is disabled.

Setting	Description
Detector	For CISPR detectors, this selection enables calculation as per the methods described in the CISPR documents. Supported CISPR detectors include CISPR Pk, CISPR QPk, and CISPR Avg. (Requires option SVQPNL or SVQPFL.) For non-CISPR detectors, this selection indicates the processing method used for compressing excess intermediate data into the desired number of trace points.
VBW (Hz)	Adjusts the VBW (Video Bandwidth) value. VBW Maximum: 10 times RBW current value; VBW Minimum: 1/10,000 RBW setting. Disabled when Filter shape is set to CISPR.
VBW On	Specifies whether the VBW filter is applied.
Thrshld (dBm)	Threshold specifies the level that must be exceeded for a signal peak to be recognized as a spur. A signal peak must also exceed the Excursion setting to be considered a spur.
Excrsn (dB)	Excursion specifies the peak to peak magnitude that must be exceeded for a signal peak to be recognized as a spur. A signal transition must also exceed the Threshold setting to be considered a spur.
Mask	Selects the type of limits used for Pass/Fail testing. Spurs that exceed the mask settings are considered violations. The available choices are shown below.
Abs	Spurs that exceed the Absolute limits settings are identified as violations.
Rel	Spurs that exceed the Relative limits settings are identified as violations.
Abs & Rel	Spurs that exceed both the Absolute and Relative limits settings are identified as violations.
Abs OR Rel	Spurs that exceed either the Absolute or Relative limits settings are identified as violations.
Off	Turns off limit testing for the selecting range. Measurements are still taken in the range, but violations are not flagged. Signal peaks that exceed the Threshold and Excursions values will still be identified as spurs.
(Abs Start and Abs Stop)	Absolute amplitude limits are not based on the measured carrier amplitude or manual reference. Start and stop values can be different.
Abs Start (dBm)	Abs Start specifies the limit at the start frequency of the range.
Abs Stop (dBm)	Abs Stop specifies the limit at the stop frequency of the range.
Abs Same	Sets the limit at the start and stop frequencies to the value set for the start frequency.
(Rel Start and Rel Stop)	Relative amplitude limits are calculated from the Power Reference. If the Power Reference is set to the Carrier level, the relative amplitude limits will change with the carrier level. Start and stop values can be different.
Rel Start (dB)	Specifies the limit at the start frequency of the range.
Rel Stop (dB)	Specifies the limit at the stop frequency of the range.
Rel Same	Sets the limit at the stop frequency to the value set for the start frequency.
Save As	Click to save the current Ranges and Limits table to a file.
Load	Click to load a saved Ranges and Limits table from a file.
Done	Save changes and close the Ranges and Limits Table window.

### Changing the Range Start and Stop Frequencies

To change the range start and stop frequencies, edit the Start and Stop frequencies in the Ranges and Limits Table:

1. Click the **Expand** button on the **Settings > Range and Limits** tab. This displays the Ranges and Limits Table.
2. Click the **On** box for a range to take measurements in the range.
3. Click on the Start or Stop frequency setting to change it. Type in a number for the frequency and a letter as a multiplier. You can use k, m, or g to set the frequency multiplier.
4. Click **Done** to save your changes.

### Specifying Spur Requirements

A spur is a signal peak that exceeds both the Threshold and Excursion settings in the Ranges and Limits table. The Threshold and Excursion settings are absolute values; they are not calculated relative to a reference. The Threshold and Excursion settings are specific to the selected range. If you want to use different settings for spurs in different ranges, you have to set the values separately for each range. The Excursion control is used to avoid interpreting a single spur as multiple narrower spurs by requiring the amplitude to drop by the Excursion amount between spurs. Raising the Threshold value means that fewer, larger signals will be identified as spurs.

To specify the spur requirements for a range:

1. Click the **Expand** button on the **Range and Limits** tab. This displays the Ranges and Limits Table.
2. Select the **Range** (A–T) for which you want to specify the spur requirements.
3. Set the **Thrshld** value.
4. Set the **Excrsn** value.

### Setting Limits

Use the Limits settings in the Ranges and Limits Table to specify the pass/fail parameters for the Spurious measurement. When the Mask setting is set to any value except off, the instrument identifies any signal peak that exceeds the specified limits as a violation and displays Fail on the screen. If no signal peak exceeds the limits, the instrument displays Pass on the screen.

### Performing Pass/Fail Limit Testing

To set limits:

1. Click the **Expand** button on the **Range and Limits** tab. This displays the Ranges and Limits Table.
2. Adjust the Start and Stop frequencies as required for each range you want to test.
3. For ranges that you wish to test, verify that the **On** box is checked.
4. For each range you wish to test, select the desired **Mask** type from the drop-down list.
5. Set the limits as desired in the **Abs Start**, **Abs Stop**, **Rel Start**, and **Rel Stop** boxes. The values you can edit depend on the mask type you select.
6. Verify that the **Thrshld** and **Excrsn** values are set as required. These are the values that define a spur.

7. Click **Done** to save your changes and close the Range and Limits Table window.
8. Click **Run** to begin testing.


## CCDF Display

The CCDF (Complementary Cumulative Distribution Function) is a statistical characterization that plots power level on the x-axis and probability on the y-axis of a graph. Each point on the CCDF curve shows what percentage of time a signal spends at or above a given power level. The power level is expressed in dB relative to the average signal power level. The CCDF Display also shows the Average power level and the Peak/Average ratio.

To show the CCDF display:

1. Recall an appropriate acquisition data file.
2. Press the **Displays** button or select **Setup > Displays**. This shows the **Select Displays** dialog box.
3. From the **Measurements** box, select **RF Measurements**.
4. Double-click the **CCDF** icon in the **Available Displays** box. This adds the CCDF icon to the **Selected displays** box.
5. Click the **OK** button.
6. Press the **Replay** button to take measurements on the recalled acquisition data file.

### Elements of the CCDF Display



Item	Display element	Description
1	100%	The top of the graph represents the 100% probability that the signal will be at or above the average signal level.
2	Power level select	Adjust to display the value of the CCDF curve at a specific power level. The selected power level is indicated by a small triangle on the CCDF curve.
3	CCDF value	Readout of the value of the CCDF curve at the selected power level.
4	Avg	Readout of the Average power level and the CCDF value at the Average power level.
5	Readout Table	Readout of the CCDF curve at six points.
6	Pk / Avg	Readout of the Peak to Average power ratio.
7	Measurement time	Readout of the length of time used for the measurement. Displays --- s when the Measurement time is set to continuous.

[Changing the CCDF Display Settings \(see page 192\)](#)

## CCDF Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The control panel tabs for the CCDF Display are shown in the following table.


Settings tab	Description
<a href="#">Parameters (see page 194)</a>	Specifies the time to be measured.
<a href="#">Traces (see page 228)</a>	Select the trace to be measured and select reference trace for display.
<a href="#">Scale (see page 193)</a>	Specifies the vertical and horizontal scale settings.
<a href="#">Prefs (see page 164)</a>	Specifies whether on not certain display elements are shown.

**Restore defaults.** Sets the CCDF parameters to their default values.



## Scale Tab

The Scale tab for the CCDF display allows you to change the start and stop points for the horizontal trace. Changing the scale settings changes how the trace appears on the display but does not change control settings such as Center Frequency.




The screenshot shows a software interface with four tabs: Parameters, Traces, Scale, and Prefs. The Scale tab is active. Below the tabs is a section titled 'Horizontal'. Inside this section, there are two input fields: 'Start:' with the value '0.00 dB' and 'Stop:' with the value '20.00 dB'. To the right of these fields is a button labeled 'Reset Scale'.

Setting	Description
Reset Scale	Resets all settings to their default values.
Horizontal	Controls the span of the trace display and position of the trace.
Start	Sets the starting range of the trace.
Stop	Sets the end range of the trace.

## Parameters Tab

The Parameters tab enables you to specify several parameters that control signal acquisition for the CCDF Display.



Setting	Description
Single	When Single is selected, the CCDF measurement is based on the Analysis Time parameters set on Analysis control panel (Setup > Analysis > Analysis Time), shared by all displays. In Single, CCDF is time-correlated with the other open displays.
Total Time	When Total Time is selected, you can adjust its value. The value set here changes the Analysis Length (and Acquisition Length, if needed) to 20 msec. If the Total Time value is longer than the Analysis Length, CCDF uses multiple acquisitions to collect signal data.
Continuous	When Continuous is selected, the CCDF measurement combines each new record (Actual Analysis Length) into the existing result. It does not erase and start over until user presses STOP or CLEAR.
Span	Specifies the range of frequencies used for analysis.

### Single

To have statistically meaningful results, CCDF works best when calculated on at least 1 ms of data. Depending on the Analysis Time setting, the CCDF display may present error messages:

- If the Actual Analysis Time is greater than 1 ms, the CCDF Display will calculate the trace without any problems.
- If the Actual Analysis time is less than 1 ms, the CCDF Display will measure the data as best it can, but if it receives fewer than 20 samples, the CCDF display will clear the trace and report "Not enough samples".

### Total Time

Setting the Measurement Time to Total Time changes the Analysis Length (and Acquisition Length, if needed) to 20 msec. This can impact other measurements. For instance, the OBW measurement would change because it would get more analysis length than it normally needs, so switching in/out of the CCDF Total Time selection noticeably affects OBW results. This happens to a lesser amount when Measurement Time is set to Single or Continuous. This is because each sets Analysis Length to 1 msec. These different Analysis Lengths may affect other measurements, too.

## Settling Time Measurement Overview

The Settling Time measurement (Option SVT) is used to measure frequency and phase settling time of frequency-agile oscillators and subsystems. Automated measurements can reduce user-to-user measurement variations, improve repeatability and measurement confidence, and save time in gathering results.

### Measurement Definitions

**Settling time.** The time measured from a reference point to when the signal of interest settles to within user-defined tolerance.

**Settled frequency.** The final reference frequency, determined automatically or manually. The tolerance band is centered about this settled frequency.

**Settled phase.** The final reference phase, determined automatically or manually. The tolerance band is centered about this settled phase.


### Mask Testing

Mask testing is a tool to automatically determine the pass/fail state of the Device-Under-Test. The mask is defined over three or fewer user-defined time zones, with an independent limit band for each time zone. If the mask is violated, the area of violation is highlighted in red on screen, and a Fail message is displayed. The pass/fail status of the mask test can be queried over GPIB for rapid results. To configure Mask testing, see the [Mask tab \(see page 211\)](#).


The instrument's Search function can watch the Settling Time measurement for either pass or fail results, and perform actions such as stopping or saving data when the defined condition occurs. See [Mask Test Limits Settings \(see page 739\)](#) for details on configuring Mask Test.

### Frequency Settling Time Theory of Operation

The following paragraphs describe how a frequency and phase settling measurement is made.



Frequency settling time flow diagram



Phase settling time flow diagram

Acquisition hardware collects I and Q samples at the measurement frequency. Sample Rate is based on the measurement bandwidth setting.


The instantaneous phase is computed as:

$$Ph_{(n)} = \text{atan} \left( \frac{Q_{(n)}}{I_{(n)}} \right)$$

The instantaneous frequency is the derivative of the phase:

$$Fr_{(n)} = (Ph_{(n-1)} - Ph_{(n+1)}) \times \left( \frac{F_{\text{sampling}}}{(2 \times 2\pi I)} \right)$$

Data smoothing is applied (if selected by the user). This filtering method uses  $\pm n$  adjacent samples to produce an average value that is used to replace the values of the original  $2n$  samples. An example is shown below.




If averaging is turned on, the smoothed data array is averaged with data arrays of previous acquisitions on a point-by-point basis. Smoothing has the advantage of reducing noise-like variations in the measurement, but carries the risk of masking real measurement data. The amount of smoothing applied must be determined by evaluating the waveform you see for artifacts that result from the process.

Next, Settled Frequency is calculated. Settled frequency is the average frequency determined by looking back in time from the point set by the Measurement Length control over a minimum of 256 samples. This value is used to determine the frequency level about which to center the Tolerance range. The measurement then searches backward through the data until it finds the first point that exceeds the tolerance range. A maximum of 20 million acquisition data samples can be processed by the measurement.

Settling Time is measured as the time from the start reference to the point where the frequency remains within the tolerance band. The start reference can be any of three points:

- The trigger point
- The beginning of the analysis period. This result can only be computed when the instrument can find a previous settled state within the measurement period
- The point at the end of the previous frequency hop where the frequency first leaves the tolerance band. This result can only be computed when the instrument can find a previous settled state within the measurement period.



Settling time start reference points

All measurements are now complete and the numeric settling time values can be sent to the display. However, no result traces have been produced yet. Detection is used to reduce the measured points (which can number up to 10 million) to a number more easily processed by the display processor. +/- Peak detection is always used, preserving the maximum positive and negative excursions for display. Reducing the number of points in the result reduces the time resolution of the markers. If averaging is on, the measurement results are computed on the average of the undecimated results.

### Phase Settling Time Overview

Phase settling time is determined, as described previously, with the addition of tilt correction.


The instrument estimates tilt (or slope of the phase) using linear least square fitting over (at least) 256 samples of the phase vs. time waveform, looking backwards from the point set by the Measurement Length. The instrument adjusts the phase waveform so that its phase is of zero value at the point set by the Measurement Length.

## Settling Time Displays

The Frequency Settling Time measurement is used to measure the frequency settling time of frequency-agile oscillators and subsystems. The Phase Settling Time measurement is used to measure the phase settling time of phase-agile oscillators and subsystems. Automated measurements can reduce user-to-user measurement variations, improving repeatability and measurement confidence and saving time in gathering results. To measure phase settling, a phase reference is required. This means that the measurement tool must be frequency- referenced to the device under test, or must act as the frequency reference to the device under test. To lock the reference to an external source, go to Setup > Configure In/Out > Frequency Reference and choose **External**. Values from 1 MHz to 25 MHz in 1 MHz steps can be used as an external reference.


To show a Settling Time display:

1. Recall an appropriate acquisition data file.
2. Click the **Displays** button or select **Setup > Displays**.
3. From the Measurements box, select **RF Measurements**.
4. Double-click the **Freq Settling** icon or the **Phase Settling** icon in the **Available displays** box. This adds the selected display to the **Selected displays** box (and removes it from the Available displays box).
5. Click the **OK** button.
6. Press the **Replay** button to take measurements on the recalled acquisition data file.



Frequency settling time display





Phase settling time display

## Elements of the Display

Item	Display element	Description
1	Top of graph	Sets the frequency/phase that appears at the top of the graph. However, note that the top of graph setting, vertical scale setting (Settings > Scale tab), and Vertical Position settings interact. Adjusting this value changes the frequency/phase at the top of the graph by adjusting the scale setting. <b>Phase Settling Time:</b> Sets
2	Vertical Position	Sets the frequency/phase value at the vertical center of the graph.
3	Autoscale	Adjusts the Vertical and Horizontal scaling to display the entire trace on screen.
4	Horizontal Position	Sets the horizontal position of the trace on the graph.
5	Measurement readouts	Displays measurement results. See <i>Measurement Readout Text Color</i> below.
6	Signal transition start indicator	A blue vertical line that indicates the starting point of the Settling Time measurement that is based on the signal transition away from the previous settled state, if a previous settled state is found within the measurement period.
7	Trigger point indicator	An orange line and "T" (which appears below the graph) that indicates the location of the trigger point in time.
8	+/- Tolerance indicators	A pair of blue horizontal lines that show the tolerance range.
9	Settled time indicator	A blue vertical bar that shows the point on the trace at which the measurement has determined the signal frequency or phase to be settled.
10	Measurement length indicator	A magenta vertical line that specifies the end of the allowed measurement period. This is a control, not a result.
11	Scale	Adjusts the horizontal (time) scale of the graph.
12	Clear	Restarts multi-trace functions (Avg, Hold) and erases the trace.
13	Function	Displays the Detection and Function selections for the selected trace. (Detection is always +/-Peak for Settling Time measurements.)
14	Show	Controls whether the selected Trace is visible or not. When trace is Off, the box is not checked.
15	Trace	Selects a trace. Touching here displays a menu that shows the available traces and whether they are enabled or not. If you select a trace that is not currently enabled, it will be enabled.

## Measurement Readout Text Color


The measurement readouts can appear in either black text or red text. Measurement results that appear in black text indicate:

- the signal is settled AND
- the signal is settled longer than the minimum settled duration AND
- the settling time is valid OR the settling time from trigger is valid

If any of the conditions listed are not met, the measurement results text is red.

### Elements of the Frequency Settling Time Graph


The following illustration shows the various indicators that appear in the Frequency Settling Time graph.



**NOTE.** The blue vertical bar that indicates the end of the previous settled state may not always appear. For frequency settling time, this can happen because the starting frequency is outside the measurement bandwidth.

### Elements of the Phase Settling Time Graph

The following illustration shows the various indicators that appear in the Phase Settling Time graph. For most phase settling time measurements, there is not a previous settled state within the measurement period, making it impossible to measure the settling time from the previous settled value. However, the settling time from trigger is typically available.



**NOTE.** The blue vertical bar indicating the measurement start time may not appear. Zero phase is referenced to the measured hop, as the phase will not typically have a settled value during the previous hop.


### Measuring Settling Time

1. Select the **Displays** button.
2. Select **RF Measurements** from the **Measurements** box.
3. Double-click the **Freq Settling** icon or **Phase Settling** icon in the Available displays box. Click **OK** to complete your selection.
4. Select **General Signal Viewing** from the **Measurements** box.
5. Double-click the **Time Overview** icon in the Available displays box. Click **OK** to complete your selection.
6. Press the front-panel **Freq** button and use the front-panel keypad or knob to adjust the frequency to that of the signal you want to measure.

7. Select the Trig button.
8. In the Trigger control panel, select Triggered. Configure the trigger settings as needed to achieve a triggered signal.

For the next step in measuring settling time, you must set the starting point of the measurement. To do this, you will use the Time Overview display.

9. Select the Time Overview display.
10. At the left edge of the graph, drag across the graph to adjust the analysis offset. Adjust the Analysis Offset to locate the start of the settling time measurement just ahead of the signal transition where you want to measure the settling time. Any portion of the signal in the gray area will be excluded from the settling time measurement.



Setting the starting point of the settling time measurement

Even if the signal transition is difficult to see on the Time Overview display, you can set the starting point based on the location of the Trigger indicator below the graph. Or open the Frequency vs. Time graph to see the frequency transition.

11. Click in the Settling Time display to select it.
12. Select the **Settings** button to display the **Settling Time Settings** control panel.
13. On the **Define** tab, adjust the [Meas BW \(see page 208\)](#) to improve the signal-to-noise ratio as appropriate. Make sure the bandwidth covers the settled frequency, particularly when the instrument Measurement Frequency is not locked to the spectrum Center Frequency (Analysis control panel > Frequency tab).
14. Set the [Target reference \(see page 209\)](#) to Auto or Meas freq as appropriate. If you select Meas freq, also set Offset to fine-tune the measurement frequency if necessary.
15. Set the [Tolerance \(see page 209\)](#) as required for your measurement.


If your signal must be settled for a period of time before it is considered settled, you can specify a minimum settled duration for the settling time measurement.

16. Select the Time Params tab. Adjust the [Min settled duration \(see page 210\)](#) as required.


To get the measurement made in the correct location on the signal, you must adjust the measurement length. You do this by dragging the magenta line in the Settling Time graph.

17. Drag the measurement length indicator (magenta line) to the correct location on the signal. Choose a point at which the signal appears to be well settled. The measurement will then find the exact time at which the signal actually settled to within the specified tolerance.

Note the difference in the settling time in the two illustrations that follow. In both examples, the Target reference is set to Auto. The only difference is the measurement length, as shown by the magenta line.



Frequency settling time display before setting the measurement length



Frequency settling time display after setting the measurement length

## Settling Time Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the Frequency and Phase Settling Time displays are shown in the following table.

Settings tab	Description
<a href="#">Define (see page 208)</a>	Sets the measurement parameters that characterize the settling time measurement.
<a href="#">Time Params (see page 210)</a>	Sets measurement end-time and minimum settled duration parameters.
<a href="#">Mask (see page 211)</a>	Enable or disables mask testing and sets the parameters that specify the three zones used for mask testing.
<a href="#">Trace (see page 211)</a>	Specifies trace display characteristics and which traces are displayed.
<a href="#">Scale (see page 214)</a>	Sets vertical and horizontal scale and position parameters.
<a href="#">Prefs (see page 164)</a>	Specifies whether or not to show certain display elements, the maximum number of points in the exported trace, and the displayed precision of the settling time measurement.

## Settling Time Displays Shared Measurement Settings

The control panel tabs in this section are shared by the Frequency and Phase Settling Time displays. These control panel tabs are not shared with other RF Measurement displays. With few exceptions, each display shares values for each of the controls on these tabs. For example, Vertical Scale values are independent for each of the displays (degrees for Phase Settling Time and Hertz for Frequency Settling Time).

## Common controls for settling time measurement displays

Settings tab	Description
<a href="#">Define (see page 208)</a>	Specifies the parameters that characterize the settling time measurement.
<a href="#">Time Params (see page 210)</a>	Specifies the Measurement length and minimum settled duration for the settling time measurement.
<a href="#">Mask (see page 211)</a>	Specifies the parameters used for Mask testing.
<a href="#">Trace (see page 211)</a>	Specify which traces to show and how they are computed.
<a href="#">Scale (see page 214)</a>	Specifies the vertical and horizontal scale settings.
<a href="#">Prefs (see page 215)</a>	Specifies display parameters of the Settling Time displays.

## Define Tab for Settling Time Displays

The Define tab for the Frequency Settling Time measurement controls several parameters that affect how the measurement is made.

The screenshot shows the 'Define' tab selected in a software interface. The tab bar includes 'Define', 'Time Params', 'Mask', 'Trace', 'Scale', and 'Prefs'. The main area contains the following controls:

- Meas Freq:** A text box containing '2.44700 GHz'.
- Target reference:** A dropdown menu with 'Auto' selected.
- Offset:** A text box containing '0.0000 Hz'.
- Meas BW:** A text box containing '40.00 MHz'.
- actual:** A text box containing '40.00 MHz'.
- Tolerance (+/-):** A text box containing '500.0 kHz'.

### Meas Freq

Select the frequency of the signal to be measured. Measurement Frequency can be selected as the target frequency (see *Target Reference*).

---

**NOTE.** *If Lock Center Frequency of Spectrum Display to Measurement Frequency is unchecked, then Measurement Frequency is independent of Center Frequency) Range: Entire input frequency of the instrument*

---

### Meas BW

This control limits the bandwidth of the Settling Time measurement. You use the measurement bandwidth setting to improve the signal-to-noise ratio of the measurement, resulting in lower measurement uncertainty. However, if the measurement bandwidth is set too low, resulting in fewer samples per second, it can reduce the number of points within the measurement length below the 256 stable samples required, thus causing the analysis to fail. The measurement bandwidth depends on the oscilloscope on which the recalled file was acquired. To see the effect of measurement bandwidth on measurement uncertainty, see the *RSA6100B Series Specifications and Performance Verification Reference*, Tektronix part number 077-0647-XX. This manual can be downloaded from [www.tek.com/manuals](http://www.tek.com/manuals).



### Target Reference

The target reference is a calculated or user-specified value of final settled frequency within the measurement period. When set to **Auto**, the instrument determines this value by averaging at least the last 256 samples at the end of the measurement period. When set to **Meas freq**, the Target Reference is set to the Measurement Frequency of the instrument. You can enter a manual offset from the target frequency to fine-tune the Target Reference when **Meas freq** is selected.

### Tolerance(+/-)

The Tolerance is the frequency or phase range within which the signal must remain to be considered settled. This is set as a  $\pm$  value by the user. In the frequency settling time measurement, the tolerance band is centered about the target value. In the phase settling time measurement, the tolerance band is centered about the settled phase value.

The target frequency depends on the Target reference value setting:

- If Target Reference is set to **AUTO**, then the target value is the settled value (the frequency at which the signal is considered settled).
- If Target Reference is set to **MeasFreq**, then the Target value = **Meas Frequency** + **Offset**.

### Offset

Offset is used for fine-tuning the Target Reference when **Meas freq** is selected. The value for Offset is entered manually.

## Time Params Tab for Settling Time Displays

The Time Params tab is used to set the Measurement length and minimum settled duration parameters.

Define Time Params Mask Trace Scale Prefs

Measurement length: 1.000 ms (from Analysis Offset to End of Measurement Marker)  
actual: 938.4 us

Min settled duration: 0.0000 s (from Settled Point to End of Measurement Marker)

### Measurement Length

Measurement length locates the end of the measurement period for settling time. This value is set independently of the analysis period for other measurements in the analyzer. This allows other measurements to display multiple frequency hops during an analysis, while focusing the settling time analysis on a single hop. You can set the measurement length either by entering a value in the entry box, or by dragging the magenta bar to the desired location in the graph. Traces and the display to the right of the measurement time are shown in grey to indicate that this section of the waveform is not being used in the measurement. If your signal does not settle to within your tolerance band, make sure that the measurement time ends during the settled portion of the waveform. The beginning of the settling time measurement is set with the analysis offset control, the same as other measurements in the instrument. Use analysis offset to exclude earlier hops from the measurement. See [Analysis Time \(see page 745\)](#) for setting the analysis offset control.

If there is more than one phase or frequency hop in the signal to be analyzed, use the Measurement Length control to instruct the analyzer which hop to measure. First, adjust the main Analysis Offset control to a point in time slightly earlier than the transition you wish to measure. Do this in the Time Overview display or the Analysis Settings control panel. Then adjust the Measurement Length so the end of the Settling Time measurement falls within the apparent settled period after the signal transition. The reason it is important for the user to set this control is that the Settling Time measurements start at this point and look backwards in time (towards the signal transition) to find the latest trace point that is not inside the tolerance band.

---

**NOTE.** *If your signal does not settle to within your tolerance bands, make sure that the measurement time ends during the settled portion of the waveform.*

---

### Min Settled Duration

The minimum settled duration is the amount of time the signal must remain within the tolerance band to be considered settled. Some user specifications require that the signal be settled for a minimum period. If this is not required in your application, set this value to the default of 0 seconds.

## Mask Tab for Settling Time Displays

The Mask tab is used to specify the parameters used for Mask testing.

Mask time reference		Time	Limit (+/-)
<input type="checkbox"/> Enable mask test	<input checked="" type="radio"/> Trigger <input type="radio"/> Signal transition	Start 1: 0.0000 s	500.0 kHz
		Start 2: 100.0 us	500.0 kHz
		Start 3: 1.000 ms	500.0 kHz
		Stop: 13.18 ms	

### Enable Mask Test

Enables or disables mask testing.

### Start 1, 2, 3

Sets the starting point for the time zone of interest. If you don't want to use all three zones, set the Start Time for the unneeded zones to a time after the end of the Measurement Length.

### Stop

Sets the end point for the final time zone of interest.

### Limit (+/-)

Sets the mask violation limits for each time zone.


### Mask Time Reference

When mask testing is enabled, the Mask time reference selection specifies the starting point of the mask. You can choose to start the mask test at the trigger point or at the point on the trace where the signal began its transition from its previous settled frequency or phase level to the level you intend to measure.

This capability is useful because some applications do not have a trigger signal available. For those situations where a trigger signal is available, the specification for the device-under-test may require that measurements be referenced to that signal.


## Trace Tab for Settling Time Displays

The Traces Tab allows you to set the display characteristics of displayed traces.



## Smooth

Smooth is a low-pass filter function that uses  $n$  points in the trace to determine the smoothed value. For example, in the case of  $n=3$ , 3 consecutive points are averaged to determine the result of the smoothed output. This is very useful for single-shot signals that contain significant noise where multiple trace averages cannot be used. However, smoothing does have limits, and the user should visually determine whether smoothing is removing noise from the measurement, or if it is affecting the signal. The following illustration shows the effect smoothing has on the displayed trace.



The range for the Smooth function is 2–1000. The setting resolution is 1. arrow keys increment it in steps of 1, 2, 5, 10. When smoothing is enabled, it applies to both traces. Smooth is turned off by default.

## Average

This sets the number of acquisitions to be averaged together to produce the result. Averaging reduces random variations but maintains the correct waveshape for repeating signal aberrations. To use averaging, the signal must be repetitive. For example, the tuning direction must always be same for each measurement to be averaged. Signals that vary in tuning direction will tend to average positive-going effects with negative-going effects and the settling time characteristics will cancel out.

The range for the Average function is 2–10000. The setting resolution is 1. arrow keys increment it in steps of 1, 2, 5, 10. When smoothing is enabled, it applies to both traces. Smooth is turned off by default.

### Trace

Selects a trace for display. Choices are Trace 1 and 2. Either trace can be a recalled trace.

### Saving Traces

To save a trace for later analysis:


1. Select the **Save Trace As** button. This displays the Save As dialog box.
2. Navigate to the desired folder or use the default.
3. Type a name for the saved trace and click **Save**.

### Recalling Traces

You can recall a previously saved trace for analysis or comparison to a live trace.

To select a trace for recall:

1. Select the trace into which the recalled trace will be loaded, from the Trace drop-down list.
2. Check the **Show** check box.
3. Click the ... button to display the Open dialog box.



4. Navigate to the desired file and click **Open**.
5. Check the **Show Recalled Trace** check box.
6. Verify that the trace's **Show** check box is selected (either on this tab or next to the drop-down list located at the top-left corner of the graph).

## Scale Tab for Settling Time Displays


The Scale tab allows you to change the vertical and horizontal scale settings. Changing the scale settings changes how the trace appears on the display but does not change control settings such as Measurement Frequency. In effect, these controls operate like pan and zoom controls.

The screenshot shows the 'Scale' tab in the software interface. It contains two main sections: 'Vertical' and 'Horizontal'. The 'Vertical' section has a 'Scale' field set to '7.0000 MHz', a 'Position' field set to '-200.00 kHz', a checked 'Relative Freq' checkbox, and an 'Autoscale' button. The 'Horizontal' section has a 'Scale' field set to '1.020 ms', a 'Position' field set to '81.602 us', a checked 'Auto' checkbox, and an 'Autoscale' button. The tabs at the top are 'Define', 'Time Params', 'Mask', 'Trace', 'Scale', and 'Prefs'.

Setting	Description
Vertical	
Scale	Changes the vertical scale or span of the graph.
Position	Sets the frequency (or phase) at the vertical center of the graph.
Relative Freq	Sets the vertical (position) display readouts to show frequency values relative to the center frequency or as absolute values.
Autoscale	Resets the Scale and Position to center the trace in the graph.
Horizontal	
Scale	Sets the range of time shown in the graph.
Position	Allows you to pan the graph left and right.
Autoscale	Resets Scale and Position to the automatically determined settings.

## Prefs Tab for Settling Time Displays

The Prefs tab allows you to change display parameters of the Settling Time displays.



The screenshot shows the 'Prefs' tab selected in a software interface. The settings are as follows:

- Max trace points: 100K (dropdown menu)
- ☒ Show graticule
- ☒ Show Marker readout in graph (selected marker)
- Settling Time decimal places: 2 (text input)

The following table explains the controls that can appear on the Prefs tab.

Setting	Description
Max trace points	Sets the number of trace points used for marker measurements and for results export.
Show graticule	Select to display or hide the graticule.
Show Marker readout in graph (selected marker)	Shows or hides the readout for the selected marker in the graph area.
Settling Time decimal places	Specifies the precision of the settling time measurement readout that appears below the graph. This setting does not affect the precision of internal calculations.

## SEM Display

The SEM (Spectrum Emission Mask) display measures out-of-band emissions immediately outside the channel bandwidth that result from the modulation process and non-linearity in the transmitter. The Spectrum Emission Mask display allows you to define up to six pair of masks, or offsets, that specify the limits for out-of-band emissions and performs a pass/fail tests of the signal against the defined offsets and limits.

To show the Spectrum Emission Mask display:

1. Recall an appropriate acquisition data file.
2. Select **Displays** or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **RF Measurements** or **WLAN Analysis** in the Measurements box.
4. In the Available displays box, double-click the **SEM** icon or select the icon and click **Add**. The SEM icon will appear in the Selected displays box and will no longer appear under Available displays.
5. Click **OK** to show the Spectrum Emission Mask display.
6. Press the **Replay** button to take measurements on the recalled acquisition data file.





## Elements of the Display

Item	Display element	Description
1	Check mark indicator	Indicates the display for which the acquisition hardware is optimized.  <b>NOTE.</b> When <i>Best for multiple windows</i> is selected in the Amplitude control panel's RF & IF Optimization control, none of the measurement displays shows a checkmark, as there is not a single optimized measurement.
2	Top-of-graph setting	Sets the level that appears at the top of the graph.
(not shown)	Units	Sets the global amplitude units for all the views in the analysis window. This will change the amplitude selection in the Units tab of the Amplitude control panel.
3	dB/div	Sets the vertical scale value. The maximum value is 20.00 dB/division.
4	Bottom-of-graph readout	Indicates the amplitude at the bottom of the graph. This value changes with the dB/div and Vertical Position settings.
5	Autoscale	Properly offsets the peak of the display from the top of the screen. If the screen has been enlarged through a manual vertical (dB/div) setting entry, the view is not vertically rescaled when Autoscale is used.
6	CF / Pos	Default function is CF - center frequency (equivalent to the Measurement Freq setting). If Horizontal scaling has been manually adjusted in Setup > Settings > Scale, then Pos replaces CF as the setting at the bottom-left corner of the screen. Adjusting Pos shifts the trace left or right in the graph, but does not change the measurement frequency.
7	Span / Scale	Default function is Span - frequency difference between the left edge of the display and the right edge. If Horizontal scaling has been manually adjusted in Settings > Scale, then Scale will replace Span as the setting at the bottom-right corner of the screen.
8	Clear	Erases the current results from the display.
9	Function readout	Readout of the Function selection for the Reference channel (Setup > Processing > Function). Spurious
10	Detection readout	Readout of the Detection selection for the Reference channel (Setup > Processing > Detection).
11	Pass / Fail readout	Readout indicating whether any part of the trace has exceeded the any of the limits defined in the Offsets & Limits table (Setup > Settings > Offsets & Limits Table).

## Pass / Fail Readout

This readout displays either **Pass** or **Fail XX%**. When the signal exceeds the mask in any offset, it is considered a mask violation, and results in **Fail XX%** being displayed. If there are no mask violations, **Pass** is displayed.

**How the fail percentage is determined.** Each offset has two sides, one lower and one upper. For example, Offset A has two sides: AL (lower side) and AU (upper side). In the SEM display, there is a maximum of six offsets (A-F) and each offset can have a maximum of two sides (if Both is selected for Side in the Offsets & Limits table). This results in a total of six offsets multiplied by two sides per offset, which results in 12 offsets. Mask violations can occur in any of these offsets. The failure percentage is calculated as follows:

Fail percentage = Number of offsets with mask violations x 100 / Total number of enabled offsets

For example: Assume there are three enabled offsets: A, B, C, and all these offsets have both lower and upper sides. Thus, the total number of enabled offsets is equal to six. Suppose there are mask violations in the offsets AL and CU, then the number of offsets having mask violations is equal to 2. Therefore, Fail percentage =  $2 * 100 / 6 = 33\%$ .

## Results Display

The Results Display shows the measurement results for the SEM display.

Ref: Total Power	Row	Offset	Start Freq	Stop Freq	Peak Abs (dBm)	Margin Abs (dB)	Peak Rel (dBc)	Margin Rel (dB)	@Freq	Integ Abs (dBm)
-16.93 dBm	1	EL	-12.500 MHz	-8.000 MHz	-73.83	-82.33	-91.81	--	8.010000 MHz	-68.44
	2	DL	-8.000 MHz	-4.000 MHz	-73.17	-81.67	-91.16	--	-7.460000 MHz	-67.61
	3	CL	-4.000 MHz	-3.515 MHz	-87.63	-83.13	-105.62	--	-3.965444 MHz	-77.11
	4	BL	-3.515 MHz	-2.715 MHz	-87.77	-75.17	-105.76	--	-2.722000 MHz	-75.14
	5	AL	-2.715 MHz	-2.515 MHz	-70.18	-57.68	-88.16	--	-2.515000 MHz	-70.74
	6	AU	2.515 MHz	2.715 MHz	-70.73	-58.23	-87.67	--	2.515000 MHz	-70.54
	7	BU	2.715 MHz	3.515 MHz	-87.66	-87.24	-104.59	--	3.243000 MHz	-74.72
	8	CU	3.515 MHz	4.000 MHz	-88.01	-83.51	-106	--	3.976356 MHz	-77.04

### Readout

### Description

Ref:	A two-part readout to the left of the table that displays information about the Reference Channel. The first part of the readout displays the Measurement Type selected on the Parameters tab. The second part of the readout displays the measurement result for the Reference channel.
Row	A sequence number for ordering the offsets. Click to organize by row number, resort rows from high to low or low to high.
Offset	The Offset name. A combination of the offset (A-F) and the location (U for upper and L for Lower).
Start Freq	The start frequency of the offset (relative to the Measurement Freq).
Stop Freq	The stop frequency of the offset (relative to the Measurement Freq).
Peak Abs	Absolute power peak power at worst case margin of the offset
Margin Abs	The worst case difference between the trace and the absolute limit line. Note that an offset can have different start and stop levels, thus, the margin can vary if the offset start and stop levels are different.
Peak Rel	Relative peak power of worst case margin of the offset. Relative with respect to the reference power level.
Margin Rel	The worst-case difference between the trace and the relative limit line. Because an offset can have different start and stop levels, the margin can vary if the offset start and stop levels are different.
@Freq	The frequency at which the worst margin occurs.
Integ Abs	The absolute integrated power of the offset.
Integ Rel	The relative integrated power of the offset (with respect to the reference power).

**Reordering results in the results table.** You can sort the results in the Results table by clicking the column heading containing the values you want to sort on. You can sort results for the following columns: Row, Offset, Start Frequency, Stop Frequency, Peak Abs, and Peak Rel.

**Rearranging columns in the results table.** You can rearrange the order of the columns and their size. To rearrange columns, select the column heading you want to move and drag it to the new position; the new location is indicated by a dark blue bar that appears between column headings.

You can resize the columns by selecting the divider between columns and dragging it to a new position.

## Spectrum Emission Mask Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the Spectrum Emission Mask display are visible when SEM is the selected display. To display the SEM Settings, select **Setup > Settings**.

Settings tab	Description
<a href="#">Parameters Tab (see page 219)</a>	Specifies several characteristics that control how the measurement is made.
<a href="#">Processing Tab (see page 221)</a>	Specifies settings for detection on the Reference channel and the offsets. Specifies the function setting.
<a href="#">Ref Channel Tab (see page 222)</a>	Specifies how the measurements on the reference channel are performed.
<a href="#">Offsets &amp; Limits Table (see page 222)</a>	Specifies characteristics of offsets and mask limits.
<a href="#">Scale Tab (see page 225)</a>	Specifies the vertical and horizontal scale settings.
<a href="#">Prefs Tab (see page 226)</a>	Specifies the appearance features of the graph area and the maximum trace points.
<a href="#">Standards Presets (see page 25)</a> button	Click this button to access the Standards Presets options dialog window. You can select the standard and bandwidth to apply to the standard you select. Click on the link to the left for information about standards presets.

## Parameters Tab - SEM


The Parameters tab specifies several characteristics that control how the Spectrum Emission Mask measurements are made.

Setting	Description
Meas Freq	Specify the frequency of the signal to be measured.
Step	Sets the increment size when changing the Frequency using the knob or mouse wheel.
Auto	When Auto is enabled, the step size is adjusted automatically based on the span setting.
Real-Time	When Real-Time mode is enabled, the entire SEM span is measured using a real-time/contiguous acquisition. Not all described parameters are available in Real-Time mode.

Setting	Description
Measure Noise floor (Only available when SignalVu-PC is connected to an MDO4000B/C instrument.)	Takes preliminary acquisitions to measures the instrument noise floor. This initiates a noise correction. A noise correction signal is created by switching off the RF input to the MDO4000B/C and performing acquisitions of the instrument's internal noise. Fifty acquisitions are averaged to create the noise reference signal. The noise reference signal is measured for the Reference channel and each Offset is defined by the measurement settings.
Apply noise correction (Only available when SignalVu-PC is connected to an MDO4000B/C instrument.)	<p>This item is enabled and the check box automatically checked after the noise reference signal is taken when the Measure Noise floor button is clicked. This initiates noise reference subtraction from the incoming signal power for each region to create the corrected result. All calculations are performed in Watts and then converted to the desired units.</p> <p>The amount of noise correction is limited to 20 dB to avoid the possibility of a negative power measurement. This is a rare condition that could occur if the subtraction of the reference power from the channel power results in a negative value (or "infinite" dBm). The noise reference for a region is subtracted from each trace point in the channel, rather than offsetting the entire region by a single amount. This produces a smooth trace with no discontinuities at the region edges.</p> <p><b>NOTE.</b> If any relevant settings (such as reference level, frequency, span, RBW) are changed once the noise reference is measured, the following warning message will be displayed to notify you that Noise Correction was not applied:</p> <p><i>Noise correction not applied - select Measure Noise Floor for new noise correction.</i></p>
Measurement Type	Specifies the type of measurement for the reference channel; used as a reference for the offsets.
Total Power	Sets the reference to the integrated power of the reference channel within the reference's integration bandwidth.
PSD	Sets the reference to the mean of the power spectral density (dBm/Hz) of the reference channel. The trace and the absolute and relative limits line are also in dBm/Hz
Peak	Sets the reference to the Peak power of the reference channel.
Offset definition	Defines the relative position of the start/stop frequency of an offset. Choose the offset definition based on the standard.
Ref center to OS center	Specifies that the start/stop frequencies are defined from the center frequency of the reference channel to the center of the filter BW.
Ref center to OS edge	Specifies that the start/stop frequencies are defined from the center frequency of the reference channel to the center of the (inner) edge of the filter BW of the offset.
Ref Edge to OS center	Specifies that the start/stop frequencies are defined from the edge of the reference channel to the center of the filter BW of the offset.
Ref Edge to OS edge	Specifies that the start/stop frequencies are defined from the edge of the reference channel to the (inner) edge of the filter BW of the offset.
Filter Shape	Specifies the shape of the filter determined by the window that is applied to the data record, in the spectrum analysis, to reduce spectral leakage. 3GPP specifies a Gaussian window shape be applied to the reference channel measurements.
Gaussian	This filter shape provides optimal localization in the frequency domain.
Rectangular	This filter shape provides the best frequency, worst magnitude resolution. This is essentially the same as no window.

## Processing Tab - SEM

The Processing tab controls the Detection settings for the Reference Channel and Offsets, as well as selecting the Function.



Parameters Processing Ref Channel Offsets & Limits Table Scale Prefs

Detection (in each record)

Ref Channel: Avg (VRMS)

Offsets: Avg (VRMS)

Function (across multiple records)

Normal

Processing settings affect all SEM numeric and trace results.

Settings tab	Description
<b>Detection (in each sweep)</b>	
Ref Channel	Specifies the Detection method used for the Reference Channel. Detection is used to produce the desired measurement result (peak or average) and to reduce the results of a measurement to the desired number of trace points.
Avg (VRMS)	For each sweep, each point of the trace is the result of determining the RMS voltage value for the last 'n counts' of the collected traces for the same point. When 'n count' has not been reached, partial averaging results are displayed.
+Peak	Selects the +Peak detection method. With this method, the highest value is selected from the results to be compressed into a trace point.
Offsets	Specifies the detection method used for the offsets.
Avg (VRMS)	Selects the Average Vrms detection method. With this method, each point on the trace in each offset is the result of determining the RMS Voltage value for all of the results values it includes.
+Peak	Selects the +Peak detection method. With this method, the highest value in each offset is selected from the results to be compressed into a trace point.
<b>Function (across multiple sweeps)</b>	
Function	Selects the trace processing method. Available settings are: Normal, Avg (VRMS), and Hold.
Normal	When a new trace has been computed, it replaces the previous trace.
Max Hold	With each sweep, each trace point in the new trace is compared to the point's value in the old trace and the greater value is retained for display and subsequent comparisons.
Avg (VRMS)	For each sweep, each point on the trace is the result of determining the RMS Voltage value for all of the collected traces' values for the same point.


## Ref Channel Tab

The Ref Channel tab controls how the measurement of the Reference channel is performed.

Settings tab	Description
Power Reference	The value used to calculate relative measurements.
Auto	When Auto is unchecked, you can enter a value for the reference power, and the measured reference power is not used or displayed
RBW	Sets the RBW for the Reference Channel.
VBW	Enables/disables the Video Bandwidth filter. VBW is used in traditional swept analyzers to reduce the effect of noise on the displayed signal. The VBW algorithm in the analyzer emulates the VBW filters of traditional swept analyzers. When the checkbox next to VBW is not checked, the VBW filter is not applied. SEM standards specify what value of VBW should be applied, if any.
Channel width	Specifies the width of the reference channel.
Integration BW	Specifies the integration bandwidth used to compute the total power in the reference channel.
Channel Filter	Specifies the measurement filter used in the Reference Channel. Choices are None and Root-raised Cosine.
Filter param	Specifies the alpha value (or roll-off factor) of the Root-raised cosine filter. Present only when Channel Filter is set to Root-raised Cosine.
Chip rate	Specifies the chip rate used for the Root-raised Cosine filter. Present only when Channel Filter is set to Root-raised Cosine.

## Offsets & Limits Table Tab - SEM

The Offsets & Limits Table tab is used to specify parameters that define Offsets and masks.



	On	Start (Hz)	Stop (Hz)	Side	RBW (Hz)	n (RBWs)	Filter BW (n x RBW)	VBW (Hz)	VBW On	Mask
▶ A	✓	9.000000M	11.000000M	Both	100.000k	1	100.000k	30.000k	✓	Rel
B	✓	11.000000M	20.000000M	Both	100.000k	1	100.000k	30.000k	✓	Rel
C	✓	20.000000M	30.000000M	Both	100.000k	1	100.000k	30.000k	✓	Rel
D	✓	30.000000M	50.000000M	Both	100.000k	1	100.000k	30.000k	✓	Rel
E		50.000000M	100.000000M	Both	100.000k	1	100.000k	30.000k	✓	Rel
F		100.000000M	150.000000M	Both	100.000k	1	100.000k	30.000k	✓	Rel

Expanded display of Offsets &amp; Limits Table

Setting	Description
<b>Buttons</b>	
Expand	Displays the Offsets & Limits Table in a new, resizable window.
Reset Layout	You can reorder columns in the Offsets & Limits Table by dragging the columns to a new position. Clicking Reset Layout returns the column order to the factory default order.
Load	Click to load a saved Offsets & Limits table from a file.
Save As	Click to save the current Offsets & Limits table to a file.
Done	When the table is expanded, click Done when you have finished editing the table to save your changes and close the expanded table display.
<b>Table columns</b>	
On	Specifies whether or not measurements are taken in the specified offset.
Start (Hz)	Start Frequency of the selected offset.
Stop (Hz)	Stop Frequency of the selected offset.
Side	Specifies whether the specified range appears on both side of the carrier frequency or just one side (left or right).
RBW (Hz)	Specifies the RBW for the selected range.
n (RBWS)	An integer value that specifies how many times to multiply the RBW to set the Filter bandwidth.
Filter BW (n x RBW)	Displays the Filter BW. Filter BW is the equivalent BW of each point in the offset. When $n > 1$ , an integration technique is used to achieve the Filter BW using narrower RBWs. For most SEM measurements, this value is set to 1. The 3GPP standard suggests n greater than 1.
VBW (Hz)	Adjusts the VBW (Video Bandwidth) value. VBW Maximum: RBW current value; VBW Minimum: 1/10,000 RBW setting.
VBW On	Specifies whether the VBW filter is applied.
Mask	Select the type of limits used for Pass/Fail testing. Signal excursions that exceed the mask settings are considered violations. The available choices are shown below.
Abs Start (dBm)	Specifies the mask level at the inner edge of the selected offset.
Abs Stop (dBm)	Specifies the mask level at the outer edge of the selected offset.
Abs Same	Specifies whether the value for the inner and outer edges of the offset must be the same value. When enabled, the Abs Stop cell is grayed-out and set to the value of the Abs Start cell.
Rel Start (dBm)	Specifies the mask level for the Relative mask at the inner edge of the selected offset.
Rel Stop (dBm)	Specifies the mask level for the Relative mask at the outer edge of the selected offset.
Rel Same	Specifies whether the inner and outer edges of the offset must be the same value. When enabled, the Rel Stop cell is grayed-out and its value is set to the value of the Rel Start cell.



## Scale Tab - SEM

Use the Scale tab to change the vertical and horizontal scale settings. Changing the scale settings changes how the trace appears on the display. In effect, these controls operate like pan and zoom controls.

Setting	Description
Vertical	Controls the vertical position and scale of the trace display.
Scale	Changes the vertical scale units.
Position	Adjusts the reference level away from top of the graph.
Autoscale	Resets the scale of the vertical axis to contain the complete trace.
Horizontal	Controls the span of the trace display and position of the trace.
Scale	Specifies the frequency range displayed in the graph
Position	Specifies the frequency shown at the center of the graph.
Autoscale	Resets the scale of the horizontal axis to optimize the display of the trace.
Reset Scale	Resets all settings to their default values.

## Prefs Tab - SEM

The Prefs tab enables you to change parameters of the measurement display. The parameters available on the Prefs tab vary depending on the selected display, but include such items as enabling/disabling Marker Readout and switching the Graticule display on/off. Some parameters appear with most displays while others appear with only one display.

Parameters Processing Ref Channel Offsets & Limits Table Scale Prefs

Max Trace points: 801 (per range)

☒ Show graticule

☒ Show Marker readout in graph (selected marker)

Show limits: Line only

Setting	Description
Show graticule	Controls the vertical position and scale of the trace display.
Max Trace points (per range)	When the spectrum analysis produces more than the selected maximum number of points, the method specified in Detection control is used to decimate the result. This setting applies to both the Reference channel and offsets.
Show Marker readout in graph	Adjusts the reference level away from top of the graph.
Show limits	Controls the appearance of mask limits in the graph.
Shaded	Shows limits using a shaded area. Green shading is used to identify Absolute limits. Blue shading is used to indicate Relative limits.
Line only	Shows limits using only a line. A green line is used to identify Absolute limits. A blue line is used to indicate Relative limits.
None	No lines or shading are used to indicate limits in the graph. Violations of the mask are still identified by red shading.

## RF Measurements Shared Measurement Settings

The control panel tabs in this section are shared by multiple displays in the RF Measurement folder (Setup > Displays). With few exceptions, each display maintains separate values for each of the controls on these tabs. For example, Scale values are independent for each of the displays.

## Common controls for RF measurement displays

Settings tab	Description
<a href="#">Freq &amp; RBW (see page 227)</a>	Allows you to specify the Center Frequency, Step size and RBW.
<a href="#">Traces (see page 228)</a>	Specifies trace parameters such as detection method and whether smoothing is enabled. Traces can also be saved and loaded for reference from this tab.
<a href="#">Scale (see page 231)</a>	Specify vertical and horizontal scale settings.
<a href="#">Prefs (see page 164)</a>	Specify appearance features of the graph area.

## Freq & RBW Tab

The Freq & RBW tab specifies frequency parameters for some of the RF Measurements displays.

The screenshot shows the 'Freq & RBW' tab selected in a software interface. The tab bar includes 'Freq & RBW', 'Measurement Params', 'Channels', 'Scale', and 'Prefs'. The main area contains the following controls:

- Meas Freq:** A text box containing '1.00000 GHz'.
- RBW:** A text box containing '30.000 kHz' and a checked checkbox labeled 'Auto'.
- Step:** A text box containing '2.0000 MHz' and a checked checkbox labeled 'Auto'.
- VBW:** An unchecked checkbox labeled 'VBW'.

Setting	Description
Meas Freq	Specifies the measurement frequency.
Step	The Step control sets the increment/decrement size for the adjustment of the center frequency. If Auto is enabled, the analyzer will adjust the Step size as required.
RBW	Select Auto or Manual. Adjusts the RBW for the entire measurement. This setting is Independent of the Spectrum view's RBW setting.
VBW	Adjusts the VBW (Video Bandwidth) value.

**NOTE.** While the measurement frequency and step settings on this control tab are shared between ACPR, MCPR and Occupied Bandwidth, the RBW setting is not shared. The RBW setting is unique for each measurement.

### VBW

The VBW setting enables/disables the Video Bandwidth filter. VBW is used in traditional swept analyzers to reduce the effect of noise on the displayed signal. The VBW algorithm in the analyzer emulates the VBW filters of traditional swept analyzers.

The maximum VBW value is 10 times the current RBW setting. The minimum VBW value is 1/10,000 of the RBW setting.

# Traces Tab

The Traces tab enables you to select traces for display. You can choose to display live traces and/or recalled traces. The [Trace tab \(see page 211\)](#) for Settling Time displays is described in the Settling Time controls section.

**NOTE.** *Not all RF Measurements support multiple traces and/or save and recall of traces.*

The screenshot shows the 'Traces' tab in a software interface. It has several sub-tabs: Parameters, Reference, Ranges and Limits, Traces (selected), Scale, and Prefs. The main area contains controls for 'Trace 1'. There is a dropdown menu for 'Trace' set to 'Trace 1', a checked 'Show' checkbox, an unchecked 'Freeze' checkbox, and a 'Save Trace As...' button. Below these, there is a 'Function' dropdown set to 'Avg (of logs)', a checked 'Count' checkbox, a text box with '10', and a 'Show recalled trace' checkbox which is unchecked. A three-dot menu button is also present.

Setting	Description
Trace	Selects a trace for display. CCDF display: Choices are Trace 1, 2, and Gaussian. Trace 1 and 2 can be recalled. Spurious display: Choices are Trace 1, 2, 3, 4, and Math trace. All traces can be recalled. Math trace is computed for all ranges.
Show	Shows / hides the selected trace.
Freeze	Halts updates to the selected trace.
Save Trace As	Saves the selected trace to a file for later recall and analysis.
Show recalled trace	Used to select a saved trace for display. When a trace is recalled, controls such as show, freeze, and function will be disabled.
Function	Selects the trace processing method (Spurious display only). Possible settings are: Normal, Average (VRMS), Avg (of logs), and Max Hold.

## Trace processing (Function)

The trace can be processed to display in different ways. The Function setting controls trace processing.

- **Max Hold** - Displays the maximum value in the trace record for each display point. Each new trace display point is compared to the previous maximum value and the greater value is retained for display and subsequent comparisons.
- **Normal** - Displays the trace record for each display point without additional processing.
- **Avg (VRMS)** [Average  $V_{RMS}$ ] – Multiple traces are averaged together to generate the displayed trace, which will contain just one vertical value for each underlying frequency data point. Once the specified number of traces have been acquired and averaged to generate the displayed trace, additional traces contribute to the running average, except in Single Sequence run mode. In the case of Single

Sequence, the instrument stops running after the specified number of traces have been averaged together. The Number of Traces setting specifies how many traces are averaged. The averaging is performed on the linear (Voltage) values, resulting in the correct RMS average).

- **Avg (of logs)** – This is a trace function used to emulate legacy spectrum analyzer results and for the specification of displayed average noise level. In older swept analyzers, a voltage envelope detector is used in the process of measuring signal level, and the result is then converted to Watts and then to dBm. Averaging is then applied to the resultant traces.

For CW signals, this method results in an accurate power measurement. However, with random noise and digitally modulated carriers, errors result from this 'average of logs' method. For random noise, the average of logs methods results in power levels -2.51 dB lower than that measured with a power meter, or with a spectrum analyzer that measures the rms value of a signal, and performs averaging on the calculated power in Watts and not dBm or other log-power units.

This detector should be used when following a measurement procedure that specifies it, or when checking the Displayed Averaged Noise Level (DANL) of the instrument. The 'average of logs' detection and trace function is used for DANL specification to provide similar results to other spectrum/signal analyzers for comparison purposes. Use of the Average of Logs method of measurement is not recommended for digitally modulated carriers, as power measurement errors will occur.

---

**NOTE.** *The Detection setting does not affect the trace until the spectrum length is longer than the Auto setting.*

---

## Saving Traces

To save a trace for later analysis:


1. Select the **Save Trace As** button. This displays the Save As dialog box.
2. Navigate to the desired folder or use the default.
3. Type a name for the saved trace and click **Save**.

## Recalling Traces

You can recall a previously saved trace for analysis or comparison to a live trace.

To select a trace for recall:


1. Select the trace into which the recalled trace will be loaded, from the Trace drop-down list.
2. Check the **Show** check box.
3. Click the ... button to display the Open dialog box.



1. Navigate to the desired file and click **Open**.
2. Check the **Show Recalled Trace** check box.
3. Verify that the trace's **Show** check box is selected (either on this tab or next to the drop-down list located at the top-left corner of the graph).

### Gaussian Trace (applies only to CCDF)

The Gaussian trace is a reference trace that you can compare your trace against. Because the Gaussian trace is for reference, there are no settings for the trace other than whether or not it is shown.




## Scale Tab

The Scale tab allows you to change the vertical and horizontal scale settings. Changing the scale settings changes how the trace appears on the display but does not change control settings such as Center Frequency. Parameters on this tab may vary depending on the selected display.

Setting	Description
Vertical	Controls the vertical position and scale of the trace display.
Scale	Changes the vertical scale units. This is only accessible when the vertical units are set to dBm.
Position	Adjusts the level shown at the center of the graph.
Autoscale	Resets the scale of the vertical axis to contain the complete trace.
Reset Scale	Resets all settings to their default values.
Horizontal	Controls the span of the trace display and position of the trace.
Scale (Start)	Allows you to, in effect, change the span.
Position (Stop)	Adjusts the position of the acquisition record shown at the left edge of the graph.
Autoscale	Resets the scale of the horizontal axis to contain the complete trace.
Log (Spurious only)	Resets the display to show the frequency axis in a logarithmic scale.

# Prefs Tab

The Prefs tab enables you to change parameters of the measurement display. The parameters available on the Prefs tab vary depending on the selected display, but include such items as enabling/disabling Marker Readout and switching the Graticule display on/off. Some parameters appear with most displays while others appear with only one display.



Setting	Description
Show graticule	Shows or hides the graticule.
Show Marker readout in graph (selected marker)	Shows or hides the readout for the selected marker in the graph area.
Max trace points	In general, time-domain traces can include up to 100K points and frequency-domain traces can include up to 10K points. When the analysis produces a results array longer than the selected trace length, the trace is decimated (using the method specified with the Detection control) to be equal to or less than the Max trace points setting (except when Max trace points is set to Never Decimate). This decimated (or undecimated) trace is what is used for marker measurements and for results export.
Settling Time decimal places (Frequency and Phase Settling Time displays only)	Specifies the number of decimal places shown in the results readout below the graph. This setting does not affect the precision of internal calculations.
Show trace legend (CCDF (Complementary Cumulative Distribution Function) display only)	Displays or hides the trace legend.



## Tracking Generator

The tracking generator feature (Option 04) enables the Transmission Gain measurement and allows you to use the internal signal generator to measure the gain and response of filters, amplifiers, attenuators, and other such devices. The Transmission Gain display shows the frequency on the horizontal axis and the gain or loss on the vertical axis. You may also use this display to tune responses to needed specifications. When used for gain and loss, the tracking generator trace can be normalized using the calibrate function. You may select important operating parameters, including number of measurement points, output power, and measurement resolution bandwidth.

The [Return Loss \(see page 257\)](#) measurements (Option SV60-SVPC) provide return loss, VSWR, cable loss, and distance to fault (DTF) measurements. The Return Loss option requires the tracking generator option (Option 04). These measurements use a vector calibration, which requires the use of an open, short, and load calibration kit. Calibration kits are available from Tektronix, or you can use your own.

---

**NOTE.** Options 04 and SV60-SVPC are not available for the RSA7100A or RSA306B.

---



---


**TIP.** See the [Features by product \(see page 14\)](#) topic for more information about which features are available with which connected analyzers.


---

### How to use the Transmission Gain display

Perform the following procedures in the order presented to perform a transmission gain measurement.

#### Access the Settings panel

1. Select Setup > Displays.
2. In the Measurements panel, select Tracking Generator.
3. Double click the Transmission Gain icon in the Available displays panel to select that display.
4. Click **OK**.
5. Click  on the Favorites bar to open the Transmission Gain Settings panel.



Transmission Gain Settings

Freq Setup | **Track Gen** | Traces | Scale | Prefs

Frequency: 1.00000 GHz      Start Freq: 980.00 MHz

Span: 40.00 MHz      Stop Freq: 1.02000 GHz

Points: 101      Res BW: 50.0 kHz

### Set parameters before running normalization

1. Connect your test setup without the DUT (filter) to the RF Out and RF In connectors.
2. Set the Start and Stop frequencies and the RBW in the Freq Setup tab of the Settings panel.

Entering the Start and Stop frequencies sets the measurement span.

3. If desired, select how you want the display to appear in the Prefs tab.

### Run a normalization

1. Click the **Normalize** button on the Transmission Gain Settings panel. The following dialog will appear. The first column shows the conditions of the most recent normalization. The second column shows the current settings.

The dialog box titled "Normalization" contains a table with two columns: "Normalized Condition:" and "Changed Condition:". The table lists various parameters and their values. Below the table, there is a checkbox for "Perform normalization recommended when condition changes" and a label for "Current Temperature: 46.3 °C". At the bottom, there are two buttons: "Perform Normalization..." and "Close".


	Normalized Condition:	Changed Condition:
Date:	8/16/2016 3:41:24 PM	
Temperature:	49.3 °C	
Start/Stop Freq:	10.00 MHz - 7.500 GHz	
Number Freq Points:	101	
Output Power Level:	-8.0 dBm	
Ref Level:	-8.0 dBm	
Preamp:	OFF	
RF Atten:	Auto	

Perform normalization recommended when condition changes

Current Temperature: 46.3 °C


Perform Normalization... Close

2. Click the **Perform Normalization...** button. The following dialog will appear with a connection diagram.



3. Set the amplitude, connect the test setup (without the DUT) between the RF Out/REFL In and RF In ports.
4. Click the **Normalize** button. Progress is shown in yellow text on the display as percent complete.
5. When the process is complete, the normalization conditions will show in the dialog.
6. Click **Close**.
7. The normalization status will show as Norm: On in the top left portion of the display.


### Taking a measurement

1. Once the normalization is complete, connect the DUT into the test setup and the measurement will begin.
2. Select **Setup > Amplitude** to open the Amplitude control panel.
3. In the Internal Settings tab, set Internal Attenuator to 0 dB. This will reduce the noise floor. You may want to set this to something else depending on your measurement environment, but this is typical for a 3 GHz loss filter.
4. Click  to return to the Transmission Gain Settings control panel and select the Tracking Gen tab.

5. Set the Output Power Level. You should set this and the Ref Level to the same value. In the following example (see below image), both are set to  $-8$  dB.
6. If you change settings after the initial normalization, run another normalization with the new settings and then rerun the measurement.

## Reading the display

The following image shows a measurement performed on a low pass filter from 10 MHz to 7.5 GHz. A reference marker (MR) is placed at 3.006 GHz. A marker (M1) is placed at the minimum gain value.



1. Norm: Shows the normalization status at the top of the Transmission Gain display. This can be one of the following:
  - **On:** The unit has been normalized and is making measurements at the same frequencies at which it was normalized.
  - **On: Interp:** The unit has been normalized, but is making measurements at frequencies other than the normalized points and is interpolating the normalization between points.
  - **Off:** The unit has not been normalized or one or more of the operating conditions has changed. Operating conditions are Frequency Range (outside normalized frequency range), Tracking

Generator Output Power, Reference Level, Preamplifier On/Off, RF Attenuation, or Temperature (>5° C from the normalized temperature).

2. **Start:** Shows the start frequency of the measurement, which is set in the Freq Setup tab of the Settings control panel.
3. **Stop:** Shows the stop frequency of the measurement, which is set in the Freq Setup tab of the Settings control panel.


## Transmission Gain Display Settings

### Favorites Toolbar:

The Settings control panel tabs allow you to change various parameters and settings for the Transmission Gain display.

## Freq Setup - Tracking generator

The Freq Setup tab provides access to frequency settings for the Transmission Gain display.



Setting	Value
Frequency	3.75 GHz
Span	7.49 GHz
Points	101
Start Freq	10 MHz
Stop Freq	7.50 GHz
Res BW	10.0 kHz

Setting	Description
Frequency	The frequency at the center of the selected Span.
Span	The difference between the start and stop frequencies.
Points	The number of frequency points in the measurement range.
Res BW	The resolution bandwidth of the measurement.
Start Freq	The lowest frequency in the span.
Stop Freq	The highest frequency in the span.

### Center, Start, Stop, and Span Frequencies Are Correlated


Changing the values for the Frequency, Start frequency, Stop frequency or Span will change the values for the other settings, depending on the setting you change. For example, if you change the Frequency, the Start and Stop frequencies will be adjusted automatically to maintain the same Span.

If the Start and Stop frequencies are changed so that they are closer than the minimum span setting, the Start and Stop frequencies will be adjusted to maintain the minimum Span setting.

Setting Changed Manually	Settings Changed Automatically As a Result	Setting Not Automatically Changed
Start	Frequency, Span	Stop
Stop	Frequency, Span	Start
Frequency	Start, Stop	Span
Span	Start, Stop	Frequency


## Track Gen tab - Tracking generator

The Track Gen tab allows you to adjust the output power level from 0 dBm to -43 dBm.



## Prefs tab - Tracking generator

The Prefs tab enables you to change parameters of the measurement display.



Setting	Description
Show measurement points	Marks each measurement point on the trace.
Show graticule	Displays or hides the graticule in the display.
Show Marker readout in graph	When a marker is enabled, this setting displays or hides the marker readout, but not the marker itself, on the graph area.

## Scale tab - Tracking generator

The Scale tab allows you to change the vertical and horizontal scale settings. Changing the scale settings changes how the trace appears on the display but does not change control settings such as Center Frequency.

Setting	Description
Vertical	Controls the vertical position and scale of the trace display.
Scale	Changes the vertical scale units.
Position	Set the position in the middle of the vertical axis.
Autoscale	Resets the scale of the vertical axis to contain the complete trace.
Reset	Resets both vertical and horizontal scales.
Horizontal	Controls the span of the trace display and position of the trace.
Start	Set the Zoom Start frequency. This only affects the start frequency shown on the graph.
Stop	Set the Zoom Stop frequency. This only affects the start frequency shown on the graph.
Autoscale	Resets the scale of the horizontal axis to contain the complete trace.
Log	Resets the display to show the frequency axis in a logarithmic scale.

## Traces tab - Tracking generator

The Traces tab allows you to set the display characteristics of displayed traces.

Setting	Description
Trace	Selects a trace.
Show	Shows / hides the selected trace.
Function	Selects the trace processing method. Available settings are: Normal, Average (VRMS), Max Hold, Min Hold and Average (of logs).
Count	Sets the number of traces averaged to generate the displayed trace. (Present only when Function is set to anything but Normal.)
Freeze	Halts updates to the selected trace.
Save Trace As	Saves the selected trace to a file for later recall and analysis.
Show recalled trace	Displays a saved trace instead of a live trace.

## Trace

Available traces for Transmission Gain are: Trace 1, Trace 2, and Trace 3. These traces are based on the input signal and enable you to display the input signal using different processing (Function). For example, you could display Trace 1 with Function set to Normal, Trace 2 with Function set to Max Hold and Trace 3 with Function set to Min Hold.

## Function (trace processing)

The Function setting controls how traces are processed to display.

- **Normal** - Each new trace is displayed and then replaced by the next trace. Each data point contains a single vertical value.
- **Avg (VRMS)** [Average  $V_{RMS}$ ] – Each point on the trace is the result of determining the RMS Voltage value for all of the IQ samples available to the trace point. When the averaging function is applied to a trace, the averaging is performed on the linear (Voltage) values, resulting in the correct average for RMS values.
- **Max Hold** - Displays the maximum value in the trace record for each display point. Each new trace's display point is compared to the previous maximum value and the greater value is retained for display and subsequent comparisons.
- **Min Hold** - Displays the minimum value in the trace record for each display point. Each new trace's display point is compared to the previous minimum value and the lesser value is retained for display and subsequent comparisons.
- **Avg (of logs)** – In the process of measuring signal level, the result is converted to Watts and then to dBm. Averaging is then applied to the resultant traces.

## Saving Traces

To save a trace for later analysis:

1. Select the **Save Trace As** button. This displays the Save As dialog box.
2. Navigate to the desired folder or use the default.
3. Type a name for the saved trace and click **Save**.




## Recalling Traces

You can recall a previously saved trace for analysis or comparison to a live trace.

To select a trace for recall:

1. Select the trace into which the recalled trace will be loaded, from the Trace drop-down list.
2. Click the ... button to display the Open dialog box.
3. Navigate to the desired file and click **Open**.
4. Check the **Show Recalled Trace** check box.



5. Verify that the **Show** check box is selected for the trace (either on this tab or next to the drop-down list located at the top-left corner of the graph).



## Calibration for Cable Loss, Return Loss, and DTF measurements

The instrument uses the vector values of the transmitted and reflected signals when making a cable loss, return loss, and distance to fault (DTF) measurement. These vector values can change with operating conditions, particularly over temperature, making recalibration sometimes necessary for best results.

---

**NOTE.** Option SV60-SVPC (Cable Loss, Return Loss, and DTF) available for the RSA500A series and RSA600A series only.

---

---

**TIP.** See the [Features by product \(see page 14\)](#) topic for more information about which features are available with which connected analyzers.

---

You can perform a new calibration or load an existing calibration. Select one of the following topics to view the related procedure.

- [How to perform a new calibration \(see page 244\)](#)
- [How to save a calibration \(see page 251\)](#)
- [How to load a User calibration \(see page 249\)](#)
- [How to load a Factory calibration \(see page 249\)](#)

You can also view the following calibration topics in this section:

- [Calibration types \(see page 243\)](#)
- [Calibration status messages \(see page 255\)](#)

## Calibration types

The instrument can be used with three different types of calibrations.

### Factory

This calibration set is generated during initial factory adjustment or whenever the instrument is returned for service for NIST calibration, and is stored in the instrument hardware. The factory calibration can be recalled at any time, and cannot be changed by the user. The calibration is done at high and low level power settings over the entire frequency range of the instrument. This calibration provides good measurement accuracy without requiring the use of a calibration kit.

This calibration is good to the PORT of the instrument and does not include any additional cabling (jumpers) used in your measurement.

### Full

This calibration set is generated by the user at a single power level, over the full frequency range of the instrument. The number of calibration points used in this calibration is fixed. This was selected as a trade off between interpolation accuracy versus calibration time. This calibration can be named and stored by users, and multiple Full calibrations can be saved.


### Custom

This calibration is generated by the user and it is user-controlled with regards to power level, start and stop frequency, and number of calibration points. You can name and store this calibration, and multiple Custom calibrations can be saved. Because the frequency range of the calibration is limited by your specified settings, it is recommended only for when you need to optimize measurement speed by specifying a limited operation range with a defined number of points.


## How to perform a new calibration

Before performing a calibration, disconnect any signal from the RF In port. To perform a new calibration for a cable loss, return loss, or distance to fault measurement, perform the following procedure.


1. Click the **Calibrate** button located at the bottom right of the display window. The following dialog will appear. This dialog allows you to select the calibration type.




2. Click the **New Calibration** button to open the New Calibration window, and then select a calibration type.
  - If you select **Full**, then you will need to set the Power Level for a calibration covering the full frequency range of the instrument.



- If you select **Custom**, then you will need to enter frequency, power level, and number of points.



3. If desired, click the **Notes...** button and enter notes for this specific calibration. Click **OK** to save and close the window.



4. If you want to change the calibration kit details or load an existing calkit file, click on the **Cal Kit Info** button. Enter the calkit information and then do one of the following:

Cal Kit Information

Active Cal Kit: (unsaved)

Open	Short	Load
Impedance: 50 $\Omega$	Impedance: 50 $\Omega$	Impedance: 50 $\Omega$
Delay*: 53.637 ps	Delay*: 53.504 ps	
Loss: 0 G $\Omega$ /s	Loss: 0 G $\Omega$ /s	
C0: -6.4 $\times 10^{-15}$ F	L0: 20 $\times 10^{-12}$ H	
C1: 1.444 $\times 10^{-27}$ F/Hz	L1: -5.842 $\times 10^{-24}$ H/Hz	
C2: 0.01383 $\times 10^{-36}$ F/Hz <sup>2</sup>	L2: 0.416 $\times 10^{-33}$ H/Hz <sup>2</sup>	
C3: -0.01003 $\times 10^{-45}$ F/Hz <sup>3</sup>	L3: 0 $\times 10^{-42}$ H/Hz <sup>3</sup>	

\* Delay (Length / Speed of light)

Buttons: Load Cal Kit File, Cal Kit Default, Save As, OK, Cancel

- Click **Save As** to save the calkit file.
  - Click **OK** to close the Calkit Information window and use the information one time without saving a calkit file.
  - Click **Load Cal Kit File** to load your own file.
  - Click **Cal Kit Default** to load the Spinner 3-N-1 default calkit file.
5. Connect one end of the cable to the REFL In port of the instrument. Ideally, you should use the cable for the calibration with which you will perform the measurement, effectively removing its influence from the measurement.
  6. Terminate the other end of the cable with an open termination (from the calibration kit).  
 Later in the procedure, you will switch out the open for the short and then the short for the load. However, you can do this in any order.
  7. Click the **Open** button to run the Open calibration.

Calibrating

0%

Cancel

Start Frequency: 0 Hz

Stop Frequency: 100.0 GHz

Power Level: High

Points: 201

Notes...

Cal Kit: Spinner 3-N-1

Buttons: Open, Short, Load, Save As, OK, Cancel

Calibrating

Uncalibrated

Uncalibrated

8. Verify a check mark and the “Complete” message has appeared next to the **Open** button. This means that the Open calibration is complete.
9. Remove the open termination from the cable and attach the short termination.
10. Click the **Short** button to run the Short calibration.
11. Verify a check mark and the “Complete” message has appeared next to the **Short** button. This means that the Short calibration is complete.
12. Remove the short termination from the cable and attach the load termination.
13. Click the **Load** button to run the Load calibration.
14. Verify a check mark and the “Complete” message has appeared next to the **Load** button. This means that the Load calibration is complete.
15. The **Save As** and **OK** buttons will become available once all calibrations are complete. Select **OK** to accept the calibration but not save the file for future use. Select **Save As** to [save the calibration \(see page 251\)](#) as a file.
16. Click on the **Details** button in the Active Calibration window to view the calibration details.
17. Remove the calibration kit from the test setup before starting a measurement.

**You are now ready to take a measurement:**

[Make a cable loss measurement \(see page 257\)](#)


[Make a return loss measurement \(see page 261\)](#)

[Make a distance to fault measurement \(see page 264\)](#)



## How to load a User calibration

Before performing a calibration, disconnect any signal from the RF In port. If you want to load and use an existing calibration, click the **Load calibration** button in the Active calibration window. You will then need to navigate to the stored calibration file and select it. Click **OK** to load the calibration.



You are now ready to take a measurement:


[How to make a cable loss measurement \(see page 257\)](#)

[How to make a return loss measurement \(see page 261\)](#)

[How to make a distance to fault measurement \(see page 264\)](#)

## How to load a Factory calibration

Before performing a calibration, disconnect any signal from the RF In port. If you want to load Factory calibration, click the **Factory calibration** button in the Active calibration window.



### Choose the Power Output Level

The High Power Level output is  $-10$  dBm. High power measurements are the default setting and are recommended for measurements of all passive circuits such as cables and filters.

The Low Power Level output is  $-30$  dBm. Low power measurements may be needed for testing circuits that have gain and may be compressed if there are high powers input to them.

### Load calibration

Click **OK** to load the calibration. The Active Calibration window will close.

**You are now ready to take a measurement:**

[How to make a cable loss measurement \(see page 257\)](#)


[How to make a return loss measurement \(see page 261\)](#)

[How to make a distance to fault measurement \(see page 264\)](#)

## How to save a calibration

Before performing a calibration, disconnect any signal from the RF In port. To save a new calibration, do the following:

1. Click the **Calibrate** button located at the bottom right of the display window. The following dialog will appear. This dialog allows you to select the calibration type.



2. Click the **New Calibration** button to open the New Calibration window, and then select a calibration type.
  - If you select **Full**, then you will need to set the Power Level for a calibration covering the full frequency range of the instrument.

The High Power Level output is –10 dBm. High power measurements are the default setting and are recommended for measurements of all passive circuits such as cables and filters.

The Low Power Level output is –30 dBm. Low power measurements may be needed for testing circuits that have gain and may be compressed if there are high powers input to them.

**New Calibration**

Select Calibration Type: **Full**

Connect reference standards, "Open", "Short" and "Load". OK button is available when all calibrations are complete.

**Setup**

Start Frequency: 0.0000 Hz

Stop Frequency: 100.0 GHz

Power Level: Low

Notes...

**Perform Calibration**

Open Uncalibrated

Short Uncalibrated

Load Uncalibrated

Cal Kit Spinner 3-N-1

Save As OK Cancel

- If you select **Custom**, then you will need to enter frequency, power level, and number of points.

The High Power Level output is –10 dBm. High power measurements are the default setting and are recommended for measurements of all passive circuits such as cables and filters.

The Low Power Level output is –30 dBm. Low power measurements may be needed for testing circuits that have gain and may be compressed if there are high powers input to them.

**New Calibration**

Select Calibration Type: **Custom**

Connect reference standards, "Open", "Short" and "Load". OK button is available when all calibrations are complete.

**Setup**

Start Frequency: 0 Hz

Stop Frequency: 100.0 GHz

Power Level: Low

Points: 201

Notes...

**Perform Calibration**

Open Uncalibrated


Short Uncalibrated

Load Uncalibrated

Cal Kit Spinner 3-N-1

Save As OK Cancel

3. If desired, click the **Notes...** button and enter notes for this specific calibration. Click **OK** to save and close the window.




**Calibration Notes**

Name:

Note:

OK Cancel

4. If you want to change the calibration kit details or load an existing calkit file, click on the **Cal Kit Info** button. Enter the calkit information and then do one of the following:



**Cal Kit Information**

Active Cal Kit: (unsaved)

Open	Short	Load
Impedance: 50 $\Omega$	Impedance: 50 $\Omega$	Impedance: 50 $\Omega$
Delay*: <input type="text" value="53.637"/> ps	Delay*: <input type="text" value="53.504"/> ps	
Loss: <input type="text" value="0"/> G $\Omega$ /s	Loss: <input type="text" value="0"/> G $\Omega$ /s	
C0: <input type="text" value="-6.4"/> x 10 <sup>-15</sup> F	L0: <input type="text" value="20"/> x 10 <sup>-12</sup> H	
C1: <input type="text" value="1.444"/> x 10 <sup>-27</sup> F/Hz	L1: <input type="text" value="-5.842"/> x 10 <sup>-24</sup> H/Hz	
C2: <input type="text" value="0.01383"/> x 10 <sup>-36</sup> F/Hz <sup>2</sup>	L2: <input type="text" value="0.416"/> x 10 <sup>-33</sup> H/Hz <sup>2</sup>	
C3: <input type="text" value="-0.01003"/> x 10 <sup>-45</sup> F/Hz <sup>3</sup>	L3: <input type="text" value="0"/> x 10 <sup>-42</sup> H/Hz <sup>3</sup>	


\* Delay (Length / Speed of light)

Load Cal Kit File Cal Kit Default Save As OK Cancel

- Click **Save As** to save the calkit file.
  - Click **OK** to close the Calkit Information window and use the information one time without saving a calkit file.
  - Click **Load Cal Kit File** to load your own file.
  - Click **Cal Kit Default** to load the Spinner 3-N-1 default calkit file.
5. Connect one end of the cable to the REFL In port of the instrument. Ideally, you should use the cable for the calibration with which you will perform the measurement, effectively removing its influence from the measurement.
  6. Terminate the other end of the cable with an open termination (from the calibration kit).

Later in the procedure, you will switch out the open for the short and then the short for the load. However, you can do this in any order.

7. Click the **Open** button to run the Open calibration.



8. Verify a check mark and the “Complete” message has appeared next to the **Open** button. This means that the Open calibration is complete.
9. Remove the open termination from the cable and attach the short termination.
10. Click the **Short** button to run the Short calibration.
11. Verify a check mark and the “Complete” message has appeared next to the **Short** button. This means that the Short calibration is complete.
12. Remove the short termination from the cable and attach the load termination.
13. Click the **Load** button to run the Load calibration.
14. Verify a check mark and the “Complete” message has appeared next to the **Load** button. This means that the Load calibration is complete.
15. Click the **Save As** button, which will become available once all calibrations are complete. Enter the file name and save the file.
16. Click on the **Details** button in the Active Calibration window to view the calibration details.
17. Remove the calibration kit from the test setup before starting a measurement.

**You are now ready to take a measurement:**

[Make a cable loss measurement \(see page 257\)](#)

[Make a return loss measurement \(see page 261\)](#)

[Make a distance to fault measurement \(see page 264\)](#)

## Calibration status messages

The calibration status of a measurement will show as one of the following at the top right of the display.

- **Uncalibrated:** The measurement is not calibrated. This may be because the measurement parameters have changed versus the loaded calibration set, or the instrument temperature has changed more than 5 degrees from the loaded calibration set.
- **Factory:** The measurement is using the Factory calibration set.
- **User:** The measurement is performed at the same frequency range, power level, and temperature at which it was calibrated.
- **Interpolated:** The measurement is calibrated. Calibration data used during the measurement is interpolated to match the measurement frequency's points (if the measurement frequency range is less than the calibration set frequency range).

### Tooltips

Hovering over the calibration status with the mouse will show you one of the following calibration messages.

- **Calibration is uncalibrated:** This indicates that the original calibration conditions have changed and so the calibration is not valid for the current conditions. We recommend you set the User Calibration to maximize possible measurement accuracy.
- **Temperature outside calibration spec:** This indicates that the temperature of the calibration is out of range. We recommend you set the User Calibration to maximize possible measurement accuracy.
- **Factory calibration:** This message indicates that a Factory Calibration was performed.
- **Calibration data interpolated. May reduce accuracy of measurement:** This indicates that the calibration data used during the measurement is interpolated to match the measurement frequency's points. We recommend you set the User Calibration to maximize possible measurement accuracy.





## Return Loss measurements overview

The Return Loss measurement suite (Option SV60-SVPC) provides return loss, VSWR, cable loss, Distance to Fault (DTF) Return Loss, and DTF VSWR measurements. These measurements are vector calibrated. The vector calibration is performed using three known mismatches: open, short, and load, and they are part of a calibration kit. Calibration kits are available from Tektronix, or you can use your own.

This option also requires the tracking generator option (Option 04).

---

**NOTE.** Option SV60-SVPC (Cable Loss, Return Loss, and DTF) available for the RSA500A series and RSA600A series only.

---

---

**TIP.** See the [Features by product \(see page 14\)](#) topic for more information about which features are available with which connected analyzers.

---

The following displays are available in the Return Loss suite:

- [Cable Loss display \(see page 259\)](#)
- [RL/DTF \(Return Loss / Distance to Fault\) display \(see page 270\)](#)

The following topics about Return Loss measurements are available:

- [How to make a Cable Loss measurement \(see page 257\)](#)
- [How to make a Return Loss measurement \(see page 261\)](#)
- [How to make a Distance to Fault measurement \(see page 264\)](#)

## How to make a Cable Loss measurement

Disconnect any signal from the RF In port before performing a measurement. Perform the following procedures in the order presented to use the Cable Loss display to perform a cable loss measurement. You can also read more about the elements of the Cable Loss display in the [Elements of the display \(see page 259\)](#) topic.

---

**NOTE.** Option SV60-SVPC (Cable Loss, Return Loss, and DTF) available for the RSA500A series and RSA600A series only.

---


---


**TIP.** See the [Features by product \(see page 14\)](#) topic for more information about which features are available with which connected analyzers.

---

3. [Select display and set parameters](#)
4. [Perform or load a calibration \(see page 258\)](#)
5. [Take a measurement \(see page 259\)](#)

### Select display and set parameters

1. Select **Setup > Displays**.
2. In the Measurements panel, select Return Loss.
3. Double click the Cable Loss icon in the Available displays panel to select that display, and then click OK.
4. Click  on the Favorites bar to open the Cable Loss Settings control panel.



The screenshot shows a software window titled 'Cable Loss Settings'. It has a tabbed interface with 'Setup', 'Parameters', 'Cable Type', 'Traces', 'Scale', and 'Prefs'. The 'Setup' tab is active, displaying three input fields: 'Start Freq:' with a value of '9 kHz', 'Stop Freq:' with a value of '3.500 GHz', and 'Points:' with a value of '201' and a small dropdown arrow icon to its right.

5. In the Setup tab, set the start and stop frequencies and the number of desired measurement points for the frequency sweep. Use the Parameters tab to set the Output Power Level. Use the Traces, Scale, and Prefs tabs to set various trace and display preferences.

### Perform or load a calibration


Before you can take a measurement you must perform or load a calibration. View one of the following topics and follow those procedures before going to the next section.

- [Perform a new calibration \(see page 244\)](#)
- [Load a Factory calibration \(see page 249\)](#)
- [Load a User calibration \(see page 249\)](#)

## Take a measurement

1. Connect your DUT and the measurement will start.

## Elements of the display



Item	Display element	Description
1	Show	Indicates whether the trace is Off (unchecked box) or if the trace is showing (checked box) and which method that trace is processed (Normal, Avg, Min, or Max). Set trace processing using the Function menu in the Traces tab of the Cable Loss Settings control panel.
2	Trace	Indicates the selected trace. The trace is only displayed if the Show box is checked.
3	Calibration status	Indicates which calibration set the analyzer is using. See the <a href="#">Calibration status messages (see page 255)</a> topic for details.
4	dB (upper limit)	Vertical scale position (top of display range).
5	dB/div	Bottom of the vertical display range.
6	dB (lower limit)	Lower limit of cable loss.
7	Autoscale	Properly offsets the peak of the display from the top of the screen. If the screen has been enlarged through a manual vertical (dB/div) setting entry, the view is not vertically rescaled when Autoscale is used.
8	Start	Shows the start frequency of the frequency sweep. Set in the Setup tab of the Cable Loss Settings control panel.
9	Average	Average cable loss over the frequency range measured from the selected trace.
10	Maximum	The maximum value of the selected trace and the frequency at which that value occurs.
11	Stop	Shows the stop frequency of the frequency sweep. Set in the Setup tab of the Cable Loss Settings control panel.
12	Slope	Shows the rate of change of the cable loss over the frequency range for the selected trace.
13	Minimum	The minimum value of the selected trace and the frequency at which that value occurs.
14	Clear	Erases the current results from the display.

## Cable Loss display Settings control panel

**Main menu:** Setup > Settings

**Favorites Toolbar:** 

The Settings control panel tabs for the Cable Loss display are shown in the following table. Click on a link to view the parameters and settings associated with a tab.

Settings tab	Description
<a href="#">Setup (see page 275)</a>	Specifies the start and stop frequencies and the number of measurement (display) points in the frequency sweep.
<a href="#">Parameters (see page 276)</a>	Specifies output power level.
<a href="#">Cable Type (see page 277)</a>	Specifies the cable type and allows you to add a new cable type.
<a href="#">Traces (see page 278)</a>	Specifies the display characteristics of displayed traces and allows you to save and recall trace.
<a href="#">Scale (see page 280)</a>	Specifies the vertical and horizontal scale settings.
<a href="#">Prefs (see page 281)</a>	Specifies whether or not certain display elements are shown.

## How to make a Return Loss measurement

Disconnect any signal from the RF In port before performing a measurement. Perform the following procedures in the order presented to make a return loss measurement. You can also read more about the elements of the RL/DTF display in the [Elements of the display \(see page 262\)](#) topic.

---

**NOTE.** Option SV60-SVPC (Cable Loss, Return Loss, and DTF) available for the RSA500A series and RSA600A series only.

---




---


**TIP.** See the [Features by product \(see page 14\)](#) topic for more information about which features are available with which connected analyzers.

---

3. [Select display and set parameters](#)
4. [Perform or load a calibration \(see page 262\)](#)
5. [Take a measurement \(see page 262\)](#)

### Select display and set parameters

1. Select Setup > Displays.
2. In the Measurements panel, select Return Loss.
3. Double click the RL/DTF icon in the Available displays panel to select that display, and then click **OK**.
4. Click  on the Favorites bar to open the RL/DTF Settings control panel.
5. Click on the **Displays** tab, select **Return Loss** for Display 1, and then select **Display 1** in the **Show Displays** panel to view the Return Loss display only.



6. In the Setup tab, set the start and stop frequencies and the Points value. Use the Parameters tab to set the Output Power Level. Use the Traces, Scale, and Prefs tabs to set various trace and display preferences.

---

**TIP.** *The Factory Calibration will be used if you change the power level to a value that is different from your calibration, or is you change the start and/or stop frequency to be outside of the range that you calibrated.*

---

### Perform or load a calibration

Before you can take a measurement you must perform or load a calibration. View one of the following topics and follow those procedures before going to the next section.


- [Perform a new calibration \(see page 244\)](#)
- [Load a Factory calibration \(see page 249\)](#)
- [Load a User calibration \(see page 249\)](#)

### Take a measurement

1. Connect your DUT and the measurement will start.

### Elements of the Return Loss display

The following image and table show the elements of the RL/DTF display.



Item	Display element	Description
1	Show	Indicates whether the trace is Off (unchecked box) or if the trace is showing (checked box) and which method that trace is processed (Normal, Avg (VRMS), Min Hold, or Max Hold).
2	Trace	Indicates the selected trace. Note that the selected trace will only be visible if the "show" box is checked identifies if the selected trace is on the RL or DTF display view.
3	Calibration status	Indicates which calibration set the analyzer is using. See the <a href="#">Calibration for cable loss, return loss, DTF measurements</a> topic for details.
4	dB (upper limit)	Vertical scale position (top of display range)
5	dB/div	Sets the vertical scale value. The maximum value is 20.00 dB/division.
6	dB (lower limit)	Bottom of vertical display range (vertical position - vertical scale)
7	Autoscale	Properly offsets the peak of the display from the top of the screen. If the screen has been enlarged through a manual vertical (dB/div) setting entry, the view is not vertically rescaled when Autoscale is used.
8	Start	Shows the start frequency set of the measurement. Set in the Setup Tab with the Start Freq control in the Settings control panel.
9	Maximum	The maximum value of the selected trace and the distance at which that occurs.
10	Minimum	The minimum value of the selected trace and the distance at which that occurs.
11	Stop	Shows the stop frequency of the measurement. Set in the Setup Tab with the Start Freq control in the Settings control panel.
12	Clear	Erases the current measurement results and active trace(s) from the display.

## How to make a Distance to Fault measurement

Disconnect any signal from the RF In port before performing a measurement. Perform the following procedures in the order presented to make a Distance to Fault measurement. You can also read more about the elements of the RL/DTF display in the [Elements of the display \(see page 262\)](#) topic.

---

**NOTE.** Option SV60-SVPC (Cable Loss, Return Loss, and DTF) available for the RSA500A series and RSA600A series only.

---

---

**TIP.** See the [Features by product \(see page 14\)](#) topic for more information about which features are available with which connected analyzers.


---


3. [Select display and set parameters](#)
4. [Perform or load a calibration \(see page 266\)](#)
5. [Take a measurement \(see page 266\)](#)

Learn more about DTF parameters in the following topics:

- [How to change the vertical scale units \(see page 267\)](#)
- [How to limit the bandwidth for a bandpass filter \(see page 268\)](#)
- [How to improve the display of distance to fault measurements \(see page 269\)](#)
- [How to improve the resolution of distance to fault measurements \(see page 270\)](#)

### Select display and set parameters

1. Select **Setup > Displays**.
2. In the Measurements panel, select Return Loss.
3. Double click the RL/DTF icon in the Available displays panel to select that display, and then click OK.
4. Click  to open the RL/DTF Settings control panel.



RL/DTF Settings

Setup Parameters Displays Cable Type Traces Scale Prefs

Start Freq: 0 Hz


Stop Freq: 100.0 GHz

Points: 201

DTF Setup




- Click on the **Displays** tab, select **DTF/Return Loss** for Display 2, and then select **Display 2** in the **Show Displays** panel to view the DTF/Return Loss display only.




- Use the Parameters tab to set the Output Power Level and the DTF Window view. Use the Traces, Scale, and Prefs tabs to set various trace and display preferences.

You can read about the DTF Window settings in the [How to improve the display of distance to fault measurements \(see page 269\)](#) topic.


- Select the Cable Type tab and specify the cable type. If the cable type is not listed, you can add a cable by clicking the New Cable button. This provides access to the New Cable panel where you can add a name, velocity, and loss for the cable.



- Click on the **DTF Setup** button to open the DTF Setup window.
- Set the **Cover Distance**. Specify the length of the cable or the distance to the DUT (for example, an antenna). This setup is recommended when there are no frequency limitations on the signal path between the analyzer and the system under test. However, you can reduce the cover distance to just include the fault (for example, if your cable is 100 m long, but there is one fault at 30 m, you can reduce the distance to 35 m).



- If you want to set a bandwidth limit for the system instead of using distance, select Limit Bandwidth. Otherwise, go to step 11



This setup is recommended when frequency-limited devices, such as filters, are in the signal path between the analyzer and the system under test.

11. In the Parameters column of the DTF Setup window, change the Center Freq, if needed. A range of values for the center frequency is provided as an aid. The center frequency depends on the system or DUT.
12. Select the Method: Fast, Normal, Long Distance (if Limit Bandwidth is selected), or High Resolution (if Cover Distance is selected). Each method provides a range of number of points for the frequency sweep. The Fast method has the smallest range of points, and the Long Distance and High Resolution methods have the largest range of points. If you select Limit Bandwidth, increasing the number of points will result in a longer measurable distance.
13. In the Results column, inspect the results. They show the parameters for the frequency sweep and the distance values that will be used for the DTF measurement. If these results do not suit your measurement needs, you will need to adjust the measurement parameters (Setup, Center Freq. and Method) to achieve your desired measurement settings results.
14. Click **OK** to accept the settings and close the DTF Setup window.

### Perform or load a calibration

Before you can take a measurement you must perform or load a calibration. View one of the following topics and follow those procedures before going to the next section.

- [Perform a new calibration \(see page 244\)](#)
- [Load a Factory calibration \(see page 249\)](#)
- [Load a User calibration \(see page 249\)](#)

### Take a measurement

1. Connect your DUT and the measurement will start.

Read about the display in the [Elements of the RL/DTF display \(see page 271\)](#) topic.

### Explore these topics related to DTF measurements

[How to change the vertical scale units \(see page 267\)](#)

[How to limit the bandwidth for a bandpass filter \(see page 268\)](#)

[How to improve the display of DTF measurements \(see page 269\)](#)

[How to improve the resolution of DTF measurements \(see page 270\)](#)

[About the RL/DTF display \(see page 270\)](#)

## How to change the vertical scale units

The default setting for vertical scale units for the Return Loss and DTF measurements is dB. You can also display faults using VSWR as the vertical scale unit. Use the Displays tab in the DTF/Return Loss Settings control panel to change the vertical scale unit to VSWR. Select VSWR for the desired display.

The screenshot shows the 'Displays' tab of the DTF/Return Loss Settings control panel. The panel has a tabbed interface with 'Setup', 'Parameters', 'Displays', 'Cable Type', 'Traces', 'Scale', and 'Prefs'. The 'Displays' tab is active. On the left, under 'Show Displays', there are three radio buttons: 'Display 1', 'Display 2' (which is selected), and 'Both'. On the right, there are two sections: 'Display 1' and 'Display 2'. In the 'Display 1' section, there are two radio buttons: 'Return Loss' (selected) and 'VSWR'. In the 'Display 2' section, there are two radio buttons: 'DTF/Return Loss' and 'DTF/VSWR' (selected).

## How to select the appropriate settings for DTF Setup

The analyzer automatically adjusts the frequencies it uses to make the distance to fault measurement depending on the user selected Method and Cover Distance settings in the [DTF Setup window \(see page 283\)](#). The Cover Distance setting is recommended when there is low or no restriction on the frequency of the system and provides the most flexibility in selections of method (number of points) and desired measurement distance. However, if your antenna uses a filter to minimize interference from other sources, you will need to limit the measurement bandwidth used by the analyzer so that its measurement signal can pass through the filter.

The distance resolution of the DTF waveform is inversely proportional to the frequency range of the sweep. By constraining the bandwidth of the sweep (frequency range of the sweep), the resolution of the DTF waveform is decreased.

The analyzer automatically computes the results for the available methods in this setup. Each Method has a range of number of points, with Fast having the smallest range of measurement points and Long Distance (High Resolution) having the largest range. By increasing the number of points, more points are added inside the limited bandwidth of the sweep. This decreases the frequency step in the sweep (the frequency points in the sweep will be closer), resulting in longer measurable distance in the DTF waveform.


In the Method drop-down menu, only the methods that can yield to the Limit Bandwidth (or less ) will be available. If a desired method is not available, try changing the limit bandwidth or the center frequency.

Values in the Results column will change as you change values for the Setup, cover distance, Method, Limit Bandwidth or the Center Frequency. If the DTF setup results don't meet your measurement requirements, adjust these parameters to achieve your desired measurement setup.

## How to improve the display of distance to fault measurements

The DTF display will show a large main lobe at a fault location, surrounded by series of side lobes of decreasing amplitude. The analyzer provides a choice of windowing functions that enable you to make a tradeoff between resolution of the fault location and suppression of waveform “noise” (side lobe magnitude). This setting is in the Parameters tab of the DTF/Return Loss Settings control panel.

The Rectangular window produces a display with a narrow main lobe and relatively higher side lobes, resulting in better distance resolution but a “noisier” waveform. Nominal, Low, and Minimum Side Lobes windows produce a display with lower size lobes and wider main lobes, respectively. The lower side lobes make the fault easier to identify as the noise around the main lobe is reduced. On the other hand, the wider main lobe reduces the distance resolution.



## How to improve the resolution of distance to fault measurements

The resolution (distance between data points) shown in the DTF display is based on several interacting factors. Resolution is important because it limits how accurately you can locate a fault. The distance resolution is inversely proportional to the frequency range of the sweep: the wider the frequency range, the smaller the distance resolution. The maximum distance of the DTF waveform depends on the frequency step of the sweep. Therefore, when setting the DTF by Cover Distance, the frequency step size of the sweep is also set.

The analyzer automatically computes the results for the methods in this setup. Each method has a range of number of points, with Fast having the smallest range and Long Distance having the largest range. By increasing the number of points, more points are added inside the limited bandwidth of the sweep. This increases the frequency step in the sweep, resulting in better distance resolution. Distance resolution is inversely proportional to the frequency bandwidth (span) of the sweep.

Increase the bandwidth to get better distance resolution. The number of points only affects the max cover distance (for a fixed bandwidth).

Values in the Results column of the DTF Setup window will change as you change the Cover Distance or the Center Frequency.

Normally, the only settings you need to adjust are the maximum distance and the method. However, if your antenna has a bandpass filter installed, you will need to limit the bandwidth on the analyzer to make correct distance to fault measurements. Limiting the bandwidth used by the analyzer may limit the distance and resolution of the measurement. Refer to the [How to select the appropriate settings for DTF \(see page 268\)](#) section for additional information.

## RL/DTF display overview


You can perform Return Loss (RL) and Distance to Fault (DTF) measurements using the RL/DTF display. Return loss, as a function of frequency, measures the ratio in dB of the signal reflected by the DUT to the signal sent to the DUT. A larger (absolute) value of return loss indicates less signal is reflected by the DUT. DTF is the return loss measured as a function of distance along the cable connected to the DUT. It is used to locate faults when the return loss as a function of frequency indicates a problem.

This display allows you to view the RL and DTF/Return Loss (DTF/VSWR) displays together or one at a time. Return Loss or VSWR are different views of ratio of the signal reflected from the DUT and the signal sent to the DUT.

Read the [How to make a Return Loss measurement](#) topic to help you perform a return loss measurement. Read the [How to make a Distance to Fault measurement \(see page 264\)](#) topic to help you perform a DTF measurement.

## Elements of the display

The following image shows the DTF view of the RL/DTF display. However, the elements of the display are the same for the Return Loss display view, so the table that follows applies to both display views.



Item	Display element	Description
1	Show	Indicates whether the selected trace is Off (unchecked box) or if the trace is showing (checked box) and which method that trace is processed (Normal, Avg, Min, or Max). Set this using the Function menu in the Traces tab of the settings control panel.
2	Trace	Indicates the selected trace and identifies if the selected trace is on the RL or DTF display view (trace is only visible if the "show" box is checked).
3	Calibration status	Indicates which calibration set the analyzer is using. See the <a href="#">Calibration status messages (see page 255)</a> topic for details.
4	dB (upper limit)	Vertical scale position (top of display range).
5	dB/div	Sets the vertical scale value in dB/div (when not in VSWR mode).
6	dB (lower limit)	Bottom of vertical display range (vertical position - vertical scale).
7	Autoscale	Properly offsets the peak of the display from the top of the screen. If the screen has been enlarged through a manual vertical (dB/div) setting entry, the view is not vertically rescaled when Autoscale is used.
8	Start	Shows the start frequency of the frequency sweep. Set in the Setup Tab Start Freq control of the Settings control panel.
9	Maximum	The maximum value of the selected trace and the frequency at which that occurs.
10	Minimum	The minimum value of the selected trace and the frequency at which that occurs.
11	Stop	Shows the stop frequency of the frequency sweep. Set in the Setup Tab Start Freq control of the Settings control panel.
12	Clear	Erases the current measurement results and active traces from the display.

## RL/DTF display Settings control panel

**Main menu:** Setup > Settings

**Favorites Toolbar:** 

The following table shows the contents of the Settings control panel for this display. Click on a link to view detailed information about the parameters accessible from each tab.



Settings tab	Description
<a href="#">Setup (see page 284)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Parameters (see page 285)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Cable Type (see page 286)</a>	Specifies the cable type and allows you to add a new cable type.
<a href="#">Displays (see page 287)</a>	Specifies to display the RL measurement, the DTF measurement, or both. You can also select VSWR view in either measurement.
<a href="#">Traces (see page 287)</a>	Specifies the display characteristics of displayed traces and allows you to save and recall a trace.
<a href="#">Scale (see page 289)</a>	Specifies the vertical and horizontal scale settings.
<a href="#">Prefs (see page 291)</a>	Specifies whether or not certain display elements are shown.
<a href="#">DTF Setup button (see page 283)</a>	Configure distance to fault measurement by Cover Distance or Limit Bandwidth settings.
(Only available in the DTF/Return Loss view)	




## Cable Loss Display Settings

**Favorites Toolbar:** 

The Settings control panel tabs allow you to change various parameters and settings for the Cable Loss display.

### Setup - Cable Loss

The Setup tab provides access to frequency settings for the Cable Loss display.




The screenshot shows the 'Setup' tab selected in a settings panel. Below the tabs are three input fields: 'Start Freq' with the value '9 kHz', 'Stop Freq' with the value '3.500 GHz', and 'Points' with the value '201' and a dropdown arrow.

Setting	Description
Start Freq	The lowest frequency used for the measurement.
Stop Freq	The highest frequency used for the measurement.
Points	The number of measurement points from start frequency to stop frequency.

## Parameters tab - Cable Loss

The Parameters tab allows you to adjust the output power level to High or Low.



The screenshot shows a software interface with a tabbed menu at the top. The tabs are labeled 'Setup', 'Parameters', 'Cable Type', 'Traces', 'Scale', and 'Prefs'. The 'Parameters' tab is currently selected. Below the tabs, there is a label 'Output Power Level:' followed by a dropdown menu. The dropdown menu is open, showing the word 'High' and a small blue arrow icon on the right side.

Setting	Description
Output Power Level	Select from High and Low output power levels.

## Cable Type

Setting	Description
Cable	<p>Select a cable from the drop-down list. You can also click in the Cable field and search for the cable name by typing in the name.</p> <p>The  icon at the bottom of the drop-down list allows you to clear search results and view the full list again.</p>
Velocity	The velocity factor of the cable.
Loss	The loss per meter at the loss frequency.
New Cable button	Click this button to access the New Cable panel where you can enter and save cable information.
Name	Enter the cable name.
Velocity	Enter the velocity factor of the cable.
Loss	Enter the power. This dB value will be divided by the Loss Distance value to provide the loss per meter at the loss frequency.
Loss Distance	Enter the loss distance in meters or feet.
Loss Frequency	Enter the loss frequency.
Metric Units	Check this box to use metric units for distance.
Save	Click to save the cable. Once saved, the cable name will appear in the Cable drop-down list.
Cancel	Click to cancel a New Cable entry and close the New Cable panel.

## Traces tab - Cable Loss

The Traces tab allows you to set the display characteristics of displayed traces.

Setting	Description
Trace	Selects a trace. The selected trace is the source for the displayed measurements (max, min, freq, etc).
Function	Selects the trace processing method. Available settings are: Normal, Average (VRMS), Max Hold, and Min Hold.
Show	Shows / hides the selected trace.
Count	Sets the number of traces averaged to generate the displayed trace. (Present only when Function is not set to Normal.)
Freeze	Halts updates to the selected trace.
Save Trace As	Saves the selected trace to a file for later recall and analysis.
Show recalled trace	Displays a saved trace instead of a live trace.

### Trace

Available traces for Cable Loss are: Trace 1, Trace 2, and Trace 3. These traces are based on the input signal and enable you to display the input signal using different processing (Function). For example, you could display Trace 1 with Function set to Normal, Trace 2 with Function set to Max Hold and Trace 3 with Function set to Min Hold.

### Function (trace processing)

The Function setting controls how traces are processed to display.

- **Normal** - Each new trace is displayed and then replaced by the next trace. Each data point contains a single vertical value.
- **Avg (VRMS)** [Average  $V_{RMS}$ ] – Displays the average of measured value of each trace point.

- **Max Hold** - Displays the maximum value in the trace record for each display point. Each new trace's display point is compared to the previous maximum value and the greater value is retained for display and subsequent comparisons.
- **Min Hold** - Displays the minimum value in the trace record for each display point. Each new trace's display point is compared to the previous minimum value and the lesser value is retained for display and subsequent comparisons.

### Saving Traces

To save a trace for later analysis:


1. Select the **Save Trace As** button. This displays the Save As dialog box.
2. Navigate to the desired folder or use the default.
3. Type a name for the saved trace and click **Save**.

### Recalling Traces

You can recall a previously saved trace for analysis or comparison to a live trace.

To select a trace for recall:

1. Select the trace into which the recalled trace will be loaded, from the Trace drop-down list.
2. Check the **Show** check box in the display.
3. Click the ... button in the Traces tab to display the Open dialog box.



4. Navigate to the desired file and click **Open**.
5. Check the **Show recalled trace** check box in the Traces tab.
6. Verify that the **Show** check box in the display is selected for the trace (either on this tab or next to the drop-down list located at the top-left corner of the graph).

## Scale tab - Cable Loss

The Scale tab allows you to change the vertical and horizontal scale settings. Changing the scale settings changes how the trace appears on the display but does not change control settings such as center frequency.


The screenshot shows the 'Scale' tab of the 'Cable Loss Display Settings' window. The window has a series of tabs at the top: 'Setup', 'Parameters', 'Cable Type', 'Traces', 'Scale' (which is currently selected), and 'Prefs'. The 'Scale' tab is divided into two main sections: 'Vertical' on the left and 'Horizontal' on the right. In the 'Vertical' section, there are two input fields: 'Scale' set to '10.0 dB' and 'Position' set to '1.00 dB'. Below these fields is an 'Autoscale' button. In the 'Horizontal' section, there are two input fields: 'Start' set to '0 Hz' and 'Stop' set to '100.0 GHz'. Below these fields is another 'Autoscale' button. A 'Reset Scale' button is located in the center, between the 'Vertical' and 'Horizontal' sections.

Setting	Description
Vertical	Controls the vertical position and scale of the trace display.
Scale	Sets the vertical scale (overall vertical display range).
Position	Set the position in the middle of the vertical axis.
Autoscale	Resets the scale of the vertical axis to contain the complete trace.
Reset Scale	Resets both vertical and horizontal scales.
Horizontal	Controls the span of the trace display and position of the trace.
Start	Set the Start frequency. This affects the Start frequency of the measurement.
Stop	Set the Stop frequency. This affects the Stop frequency of the measurement.
Autoscale	Resets the scale of the horizontal axis to contain the complete trace.



## Prefs tab - Cable Loss

The Prefs tab enables you to change parameters of the measurement display.



Setup Parameters Cable Type Traces Scale Prefs

☒ Show graticule ☒ Show Marker readout in graph (selected marker)

☐ Show measurement points

Setting	Description
Show graticule	Displays or hides the graticule in the display.
Show measurement points	Marks each measurement point on the trace.
Show Marker readout in graph (selected marker)	When a marker is enabled, this setting displays or hides the marker readout, but not the marker itself, on the graph area.




## RL/DTF Display Settings

### Favorites Toolbar:

The Settings control panel tabs allow you to change various parameters and settings for the RL/DTF display.


## DTF Setup button – RL/DTF

The DTF Setup button allows you to access DTF measurement specific parameters and results information.



The DTF Setup dialog box is shown with three tabs: Setup, Parameters, and Results. The Setup tab is active, showing two radio buttons: 'Cover Distance' (selected) and 'Limit Bandwidth'. The 'Cover Distance' option has a value of 16.00 m and a range of 3 m to 1500 m. The 'Limit Bandwidth' option has a value of 50.00 MHz and a range of 1 MHz to 7.49 GHz. The Parameters tab shows a Center Freq of 3.755 GHz and a Range of 946.8 MHz to 6.5631 GHz. The Results tab shows Points: 201, Resolution: 80 mm, Distance: 16 m, Bandwidth: 1.8737 GHz, Start Freq: 2.81815 GHz, and Stop Freq: 4.69185 GHz. OK and Cancel buttons are at the bottom right.

Tab	Parameter	Value	Range
Setup	Cover Distance	16.00 m	3 m to 1500 m
	Limit Bandwidth	50.00 MHz	1 MHz to 7.49 GHz
Parameters	Center Freq	3.755 GHz	
	Range		946.8 MHz to 6.5631 GHz
Results	Points	201	
	Resolution	80 mm	
	Distance	16 m	
	Bandwidth	1.8737 GHz	
	Start Freq	2.81815 GHz	
	Stop Freq	4.69185 GHz	



The DTF Setup dialog box is shown with three tabs: Setup, Parameters, and Results. The Setup tab is active, showing two radio buttons: 'Cover Distance' and 'Limit Bandwidth' (selected). The 'Cover Distance' option has a value of 16.00 m and a range of 3 m to 1500 m. The 'Limit Bandwidth' option has a value of 50.00 MHz and a range of 999 kHz to 7.49 GHz. The Parameters tab shows a Center Freq of 3.755 GHz and a Range of 35 MHz to 7.475 GHz. The Results tab shows Points: 11, Resolution: 3 m, Distance: 30 m, Bandwidth: 49.965 MHz, Start Freq: 3.730017 GHz, and Stop Freq: 3.779982 GHz. OK and Cancel buttons are at the bottom right.

Tab	Parameter	Value	Range
Setup	Cover Distance	16.00 m	3 m to 1500 m
	Limit Bandwidth	50.00 MHz	999 kHz to 7.49 GHz
Parameters	Center Freq	3.755 GHz	
	Range		35 MHz to 7.475 GHz
Results	Points	11	
	Resolution	3 m	
	Distance	30 m	
	Bandwidth	49.965 MHz	
	Start Freq	3.730017 GHz	
	Stop Freq	3.779982 GHz	

Setting	Description
Cover Distance	Select and specify the length of the cable or the distance to the device under test. This selection is recommended when there are no frequency limitations on the signal path between the analyzer and the system under test.
Range	Shows the possible cable length range in meters as 3 m to 1500 m. Changing the Cover Distance value changes this range. A cable distance of greater than 1500 m would result in attenuation of the signal below the noise floor.
Limit Bandwidth	Select and specify the maximum bandwidth for the measurement. This selection is recommended when frequency-limited devices, such as filters, are in the signal path between the analyzer and the system under test.
Range	Shows the possible bandwidth range when Limit Bandwidth is selected. This range is based on the limits of the analyzer.
Center Freq	Specify the desired center frequency for the measurement.
Range	Shows the possible center frequency range for the measurement.
Method	Select Fast or Normal. If Limit Bandwidth is selected, then you can also choose Long Distance if the measurement points value is below 1500 m. If Cover Distance is selected, then you can also choose High Resolution.
Results	Panel shows the DTF setup values.

## Setup - RL/DTF

The Freq Setup tab provides access to frequency settings for the RL/DTF display.

Setup Parameters Cable Type Traces Scale Prefs

Start Freq: 9 kHz


Stop Freq: 3.500 GHz

Points: 201 ▼

Setting	Description
Start Freq	The lowest frequency in the measurement.
Stop Freq	The highest frequency in the measurement.
Points	The number of measurement points from start frequency to stop frequency.


## Parameters tab - RL/DTF

The Parameters tab allows you to set the output power level and DTF Window view.



Setting	Description
Output Power Level	Select from High and Low output power levels. The High Power Level output is –10 dBm. High power measurements are the default setting and are recommended for measurements of all passive circuits such as cables and filters. The Low Power Level output is –30 dBm. Low power measurements may be needed for testing circuits that have gain and may be compressed if there are high powers input to them.
DTF Window	Select a setting to improve the display of DTF measurements. You can read more about this feature in the <a href="#">How to improve display (see page 269)</a> topic.

## Cable Type

Setting	Description
Cable	Select a cable from the drop-down list. You can also click in the Cable field and search for the cable name by typing in the name. 
Velocity	The velocity factor of the cable.
Loss	The loss per meter at the loss frequency.
New Cable button	Click this button to access the New Cable panel where you can enter and save cable information.
Name	Enter the cable name.
Velocity	Enter the velocity factor of the cable.
Loss	Enter the power. This dB value will be divided by the Loss Distance value to provide the loss per meter at the loss frequency.
Loss Distance	Enter the loss distance in meters or feet.
Loss Frequency	Enter the loss frequency.
Metric Units	Check this box to use metric units for distance.
Save	Click to save the cable. Once saved, the cable name will appear in the Cable drop-down list.
Cancel	Click to cancel a New Cable entry and close the New Cable panel.

## Displays tab - RL/DTF

Setting	Description
Show Displays	Select to show Display 1 only, Display 2 only, or both displays simultaneously.
Display 1	Select which display type you want to appear in Display 1. You can select Return Loss or VSWR.
Display 2	Select which display type you want to appear in Display 2. You can select DTF/Return Loss or DTF/VSWR.

## Traces tab - RL/DTF

The Traces tab allows you to set the display characteristics of displayed traces.

Setting	Description
Trace	Selects a trace.
Show	Shows / hides the selected trace.
Function	Selects the trace processing method. Available settings are: Normal, Average (VRMS), Max Hold, and Min Hold.
Count	Sets the number of traces averaged to generate the displayed trace. (Present only when Function is set to anything but Normal.)
Freeze	Halts updates to the selected trace.
Save Trace As	Saves the selected trace to a file for later recall and analysis.
Show recalled trace	Displays a saved trace instead of a live trace.

## Trace

Available traces for the RL/DTF display are: DTF Trace 1, DTF Trace 2, and DTF Trace 3. These traces are based on the input signal and enable you to display the input signal using different processing (Function). For example, you could display DTF Trace 1 with Function set to Normal, DTF Trace 2 with Function set to Max Hold and DTF Trace 3 with Function set to Min Hold.

## Function (trace processing)

The Function setting controls how traces are processed to display.

- **Normal** - Each new trace is displayed and then replaced by the next trace. Each data point contains a single vertical value.
- **Avg (VRMS)** [Average  $V_{RMS}$ ] – Each point on the trace is the result of determining the RMS Voltage value for all of the IQ samples available to the trace point. When the averaging function is applied to a trace, the averaging is performed on the linear (Voltage) values, resulting in the correct average for RMS values.
- **Max Hold** - Displays the maximum value in the trace record for each display point. Each new trace's display point is compared to the previous maximum value and the greater value is retained for display and subsequent comparisons.
- **Min Hold** - Displays the minimum value in the trace record for each display point. Each new trace's display point is compared to the previous minimum value and the lesser value is retained for display and subsequent comparisons.
- **Avg (of logs)** – In the process of measuring signal level, the result is converted to Watts and then to dBm. Averaging is then applied to the resultant traces.

## Saving Traces

To save a trace for later analysis:

1. Select the **Save Trace As** button. This displays the Save As dialog box.
2. Navigate to the desired folder or use the default.
3. Type a name for the saved trace and click **Save**.




## Recalling Traces

You can recall a previously saved trace for analysis or comparison to a live trace.

To select a trace for recall:

1. Select the trace into which the recalled trace will be loaded, from the Trace drop-down list
2. Click the ... button in the Traces tab to display the Open dialog box.
3. Navigate to the desired file and click **Open**.
4. Check the **Show recalled trace** check box in the Traces tab.
5. Verify that the **Show** check box in the display is selected for the trace (either on this tab or next to the drop-down list located at the top-left corner of the graph).



## Scale tab - RL/DTF

The Scale tab allows you to change the vertical and horizontal scale settings. The content on this tab changes depending on which displays are active. Changing the scale settings changes the measurement parameters. This is different than Spectrum displays, for example, where the scale controls allow you to zoom without changing the underlying measurement. Also note that you may still right click in the measurement window and zoom the horizontal display without impacting the underlying RL/DTF measurement settings.

The following image shows the Scale tab when Return Loss is selected for Display 1 and viewing is set to Display 1 only.




The following image shows the Scale tab when VSWR is selected for both displays and viewing is set to both displays.

The following image shows the Scale tab when both VSWR is selected for Display 1 and Return Loss is selected for Display 2.

Setting	Description
Vertical	Controls the vertical position and scale of the trace display.
Scale	Sets the vertical scale (overall vertical display range).
Position	Set the vertical position (top of measurement scale for vertical display).
Autoscale	Resets the scale of the vertical axis to contain the complete trace.
Link scales	Check this box to link vertical scale in both displays. This selection works when Both is the display view selection and both displays are set to either Return Loss or VSWR.
Reset Scale	Resets both vertical and horizontal scales.
Horizontal	Controls the span of the trace display and position of the trace.
Start	Set the measurement Start frequency.
Stop	Set the measurement Stop frequency.
Autoscale	Resets the scale of the horizontal axis to contain the complete trace.

## Prefs tab - RL/DTF

The Prefs tab enables you to change parameters of the measurement display.



Setup Parameters Displays Cable Type Traces Scale Prefs

☒ Show graticule ☒ Show Marker readout in graph (selected marker) Distance Units: meters meters feet

☐ Show measurement points ☒ Negative Return Loss

Setting	Description
Show measurement points	Marks each measurement point on the trace.
Show graticule	Displays or hides the graticule in the display.
Show Marker readout in graph (selected marker)	When a marker is enabled, this setting displays or hides the marker readout, but not the marker itself, on the graph area.
Distance Units	Sets units to meters or feet.



## WLAN Overview

The WLAN Analysis option allows you to evaluate WLAN signals, performing standards based transmitter measurements in the time, frequency, and modulation domains. WLAN measurements can be made on signals defined by 802.11a/b/g/j/n/p (standard IEEE 802.11-2012) and 802.11ac (draft IEEE P802.11ac-D4.0 or later). User controls allow you to modify signal parameters for analysis of signals. The analysis results give multiple views of WLAN signal characteristics to allow the diagnosis of signal imperfections and impairments quickly and easily. Display controls allow you to selectively display the analysis results to help locate trouble-spots in the signal.

### WLAN Standards

The following options support the given standards:

- **Option SV23:** Supports IEEE 802.11a, g, j, and p OFDM signals and 802.11b DSSS/CCK signals
- **Option SV24:** Supports IEEE 802.11n signals with bandwidths of 20 MHz and 40 MHz
- **Option SV25:** Supports IEEE 802.11ac signals with bandwidths of 20, 40, 80, and 160 MHz

### WLAN Standards Presets

The **Standards Presets** button located on the WLAN Settings Control Panel allows you to recall preconfigured displays for the standards and bandwidths that you select. You can also access these presets from **Presets** on the display menu bar. You can read more information about the [Standards Presets \(see page 25\)](#).

The following table shows the center frequency and displays that are automatically loaded for each of the listed standards and bandwidths. SEM masks are also loaded and are explained [here \(see page 525\)](#).

Table 3: WLAN presets standards, bandwidths, center frequencies, and displays

Standard	Bandwidth (MHz)	Center frequency (GHz)	Displays loaded
802.11a	20	5.18	SEM, Time Overview, WLAN Constellation, WLAN Summary
802.11g	20	2.412	
802.11j	10	5.18	
	20		
802.11p	5	5.8	
	10		
	20		
802.11n	20	2.412	
	40		
802.11ac	20	5.18	
	40	5.19	
	80	5.21	
	160	5.25	
802.11b		2.412	

**SEM mask parameters.** The SEM wireless standard masks that are applied to the WLAN signal depend on the standard you select when you configure the preset. Once you select a standard and bandwidth, the application will automatically load the mask that best fits the signal for which the standard applies. All mask parameters are derived from IEEE standards and loaded for you. This provides you the assurance that you are evaluating the signal with the most appropriate mask.

## WLAN Displays

The displays in WLAN Analysis (Setup > Displays > Measurements) are:

- [SEM \(see page 215\)](#)
- [WLAN Channel Response \(see page 295\)](#)
- [WLAN Constellation \(see page 298\)](#)
- [WLAN EVM \(see page 300\)](#)
- [WLAN Magnitude Error \(see page 302\)](#)
- [WLAN Phase Error \(see page 304\)](#)
- [WLAN Power versus Time \(see page 306\)](#)
- [WLAN Spectral Flatness \(see page 309\)](#)

- [WLAN Summary \(see page 311\)](#)
- [WLAN Symbol Table \(see page 316\)](#)

## WLAN Channel Response Display

The WLAN Channel Response display plots the channel response (magnitude and phase) versus the subcarrier or frequency. Here, the channel refers to all sources of signal frequency response impairment up to the analyzer input, including the transmitter itself, as well as any transmission medium through which the signal travels between the transmitter and the analyzer.

---


**NOTE.** *WLAN Channel Response is only available for OFDM (non-802.11b) signals.*

---

To show the WLAN Channel Response display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **WLAN Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **WLAN Chan Response** icon or select the icon and click **Add**. The WLAN Chan Response icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the WLAN Chan Response display.
6. Set the Frequency appropriate for the signal.
7. Select **Setup > Settings** to display the control panel.
8. Select the Modulation Params tab. Set the Standard, Guard Interval, Subcarrier Spacing, and Bandwidth controls as appropriate for the input signal.
9. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

## Elements of the Display



0519-048



Item	Display element	Description
<b>1</b>	<b>Magnitude graph (top graph)</b>	
1a	Top of graph	Sets the level that appears at the top of the magnitude graph. This is only a visual control for panning the graph. The Reference Level is adjusted in the Toolbar and the Ampl control panel. By default, Vert Position = Ref Level.
1b	Position (dB)	Sets the vertical position value. The maximum value is 20.00 dB. The readout indicates the subcarrier (for non-b standards only) or frequency shown at the bottom of the display.
1c	Bottom of graph readout	Indicates the magnitude at the bottom of the top graph. This value changes with the dB and vertical Position settings.
<b>2</b>	<b>Phase graph (bottom graph)</b>	
2a	Top of graph	Sets the phase value indicated at the top of the graph. Since the Position value at the vertical center of this graph remains constant as the Top of Graph value is adjusted, the Vertical Scale increases as the Top of Graph value increases, which also affects the bottom of graph readout.
2b	Position (°)	Specifies the phase shown at the center of the graph display. Changing this value moves the trace up and down in the graph, which affects the Top of Graph and Bottom of Graph values as well.
2c	Bottom of bottom graph readout	Indicates the phase at the bottom of the bottom graph. This value changes with the Position setting.
3	Autoscale	Adjusts the Vertical and Horizontal scaling to optimize the trace display on screen.
4	Start (Position)	Shifts the trace left or right in the graph. The readout indicates the subcarrier (for non-b standards only) or frequency shown at the left edge of the display.
5	Stop (Scale)	Specifies the number of subcarriers (for non-b standards only) shown in the graph.

## WLAN Channel Response Settings

The WLAN Channel Response Settings control panel provides access to settings that control parameters of the Channel Response Display.

Settings tab	Description
<a href="#">Modulation Params (see page 319)</a>	Specifies the input signal standard and additional user-settable signal parameters.
<a href="#">Analysis Params (see page 320)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Data Range Tab (see page 322)</a>	Specifies which symbols and subcarriers of the signal to display.
<a href="#">Analysis Time Tab (see page 323)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the time units (Symbols or Seconds) for WLAN Analysis displays.

Settings tab	Description
<a href="#">Traces Tab (see page 324)</a>	Enables you to select from magnitude or phase trace, save a trace, and recall an trace
<a href="#">Scale Tab (see page 325)</a>	Specifies the Zoom scale, and vertical and horizontal positions of the display.
<a href="#">Prefs Tab (see page 328)</a>	Specifies the units of the display and whether elements of the graphs are displayed.


## WLAN Constellation Display

The WLAN Constellation Display shows the WLAN signal modulation amplitude and phase in I (horizontal) versus Q (vertical) form. For multicarrier WLAN OFDM signals, the points show all data symbol subcarriers' modulation. For single-carrier 802.11b, each point corresponds to a single modulated chip.

To show the WLAN Constellation display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **WLAN Constellation** in the **Measurements** box.
4. In the Available displays box, double-click the **WLAN Constellation** icon or select the icon and click **Add**. The WLAN Constellation icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the WLAN Constellation display.
6. Set the **Frequency** appropriate for the signal.
7. Select **Setup > Settings** to display the control panel.
8. Select the **Modulation Params** tab. Set the Standard, Guard Interval, Channel Bandwidth, and Subcarrier Spacing controls as appropriate for the input signal.
9. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

## Elements of the Display



Item	Display element	Description
1	Plot	Constellation graph.
2	Marker readout	If markers are enabled, the marker readout shows the selected Marker, Symbol, Subcarrier, Type, Value, Magnitude, and Phase for the symbol at the marker location. Located to the left of the constellation plot or below it, depending on the size of the window.
3	Marker controls	Define and position markers.

## WLAN Constellation Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The WLAN Constellation Settings control panel provides access to settings that control parameters of the Constellation Display.

Settings tab	Description
<a href="#">Modulation Params (see page 319)</a>	Specifies the input signal standard and additional user-settable signal parameters.
<a href="#">Analysis Params (see page 320)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Data Range (see page 322)</a>	Specifies which symbols and subcarriers of the signal to display.
<a href="#">Analysis Time Tab (see page 323)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for WLAN Analysis displays.
<a href="#">Trace Tab (see page 324)</a>	Enables you to freeze the display or hide the measurement or average trace.
<a href="#">Scale Tab (see page 325)</a>	Specifies the Zoom scale, and vertical and horizontal positions of the display.
<a href="#">Prefs Tab (see page 328)</a>	Specifies the units of the display and whether elements of the graphs are displayed.

## WLAN EVM Display

The WLAN EVM display shows the data symbols' individual subcarrier Error Vector Magnitude values versus symbol interval (time) and subcarrier (frequency).

---


**NOTE.** For 802.11b analysis, the subcarrier graph is not displayed.

---

To show the WLAN EVM display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **WLAN EVM** in the **Measurements** box.
4. In the Available displays box, double-click the **WLAN EVM** icon or select the icon and click **Add**. The WLAN EVM icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the WLAN EVM display.
6. Set the **Frequency** appropriate for the signal.
7. Select **Setup > Settings** to display the control panel.
8. Select the **Modulation Params** tab. Set the Standard as appropriate. Set the Standard, Guard Interval, Channel Bandwidth, and Subcarrier Spacing controls as appropriate for the input signal.
9. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

## Elements of the Display



Item	Display element	Description
1	Top of graph	Sets the EVM value that appears at the top of the graph. This is only a visual control for panning the graph.
2	Bottom of graph	Sets the EVM value that appears at the bottom of the graph. This is only a visual control for panning the graph.
3	Autoscale	Adjusts the vertical and horizontal settings to provide the best display.
4	Start (Position)	Specifies the horizontal position of the trace on the graph display.
5	Stop (Scale)	Adjusts the horizontal range of the graph. By decreasing the scale, the graph essentially becomes a window that you can move over the analysis results by adjusting the position.

## WLAN EVM Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the WLAN EVM display are shown in the following table.

Settings tab	Description
<a href="#">Modulation Params (see page 319)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Analysis Params (see page 320)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Data Range (see page 322)</a>	Specifies which symbols and subcarriers of the signal to display.
<a href="#">Analysis Time (see page 323)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for WLAN Analysis displays.
<a href="#">Trace (see page 324)</a>	Enables you to freeze the display or hide the measurement or average trace.
<a href="#">Scale (see page 325)</a>	Specifies the vertical, subcarrier (for non-b standards only) and symbols scale and position settings.
<a href="#">Prefs (see page 328)</a>	Specifies the units of the display and whether elements of the graphs are displayed.

## WLAN Magnitude Error Display

The WLAN Magnitude Error display shows the data symbols' individual subcarrier Magnitude Error values versus symbol interval (time) and subcarrier (frequency).

---


**NOTE.** For 802.11b analysis, the subcarrier graph is not displayed.

---

To show the WLAN Magnitude Error display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **WLAN Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **WLAN Mag Error** icon or select the icon and click **Add**. The WLAN Mag Error icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the WLAN Mag Error display.
6. Set the **Frequency** appropriate for the signal.
7. Select **Setup > Settings** to display the control panel.
8. Select the **Modulation Params** tab. Set the Standard, Guard Interval and Spacing and Bandwidth controls as appropriate for the input signal.
9. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

## Elements of the Display



Item	Display element	Description
1	Top of graph	Sets the Magnitude Error value that appears at the top of the graph. This is only a visual control for panning the graph.
2	Bottom of graph	Sets the Magnitude Error value that appears at the bottom of the graph. This is only a visual control for panning the graph.
3	Autoscale	Adjusts the vertical and horizontal settings to provide the best display.
4	Pos	Specifies the horizontal position of the trace on the graph display.
5	Scale	Adjusts the horizontal range of the graph. By decreasing the scale, the graph essentially becomes a window that you can move over the analysis results by adjusting the position.

## WLAN Magnitude Error Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the WLAN Mag Error display are shown in the following table.

Settings tab	Description
<a href="#">Modulation Params (see page 319)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Analysis Params (see page 320)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Data Range (see page 322)</a>	Specifies which symbols and subcarriers of the signal to display.
<a href="#">Analysis Time Tab (see page 323)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for WLAN Analysis displays.
<a href="#">Trace (see page 324)</a>	Enables you to display or hide the measurement or average trace.
<a href="#">Scale Tab (see page 325)</a>	Specifies the vertical, subcarrier (for non-b standards only), and symbols scale and position settings.
<a href="#">Prefs Tab (see page 328)</a>	Specifies the units of the display and whether elements of the graphs are displayed.

## WLAN Phase Error Display

The WLAN Phase Error display shows the data symbols' individual subcarrier Phase Error values versus symbol interval (time) and subcarrier (frequency).

---

**NOTE.** For 802.11b analysis, the subcarrier graph is not displayed.


---

To show the WLAN Phase Error display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **WLAN Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **WLAN Phase Error** icon or select the icon and click **Add**. The WLAN Phase Error icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the WLAN Phase Error display.
6. Set the **Frequency** appropriate for the signal.
7. Select **Setup > Settings** to display the control panel.
8. Select the **Modulation Params** tab. Set the Standard, Guard Interval and Spacing and Bandwidth controls as appropriate for the input signal.
9. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.



### Elements of the Display



Item	Display element	Description
1	Top of graph	Sets the Phase Error value that appears at the top of the graph. This is only a visual control for panning the graph.
2	Bottom of graph	Sets the Phase Error value that appears at the bottom of the graph. This is only a visual control for panning the graph.
3	Autoscale	Adjusts the vertical and horizontal settings to provide the best display.
4	Pos	Specifies the horizontal position of the trace on the graph display.
5	Scale	Adjusts the horizontal range of the graph. By decreasing the scale, the graph essentially becomes a window that you can move over the analysis results by adjusting the position.

## WLAN Phase Error Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the WLAN Phase Error display are shown in the following table.

Settings tab	Description
<a href="#">Modulation Params (see page 319)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Analysis Params (see page 320)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Data Range (see page 322)</a>	Specifies which symbols and subcarriers of the signal to display.
<a href="#">Analysis Time Tab (see page 323)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for WLAN Analysis displays.
<a href="#">Trace (see page 324)</a>	Enables you to display or hide the measurement or average trace.
<a href="#">Scale Tab (see page 325)</a>	Specifies the vertical, subcarrier (for non-b standards only), and symbols scale and position settings.
<a href="#">Prefs Tab (see page 328)</a>	Specifies the units of the display and whether elements of the graphs are displayed.

## WLAN Power vs Time Display

The WLAN Power vs Time display shows the signal power amplitude versus time. For 802.11b signals, the packet Power-On and Power-Down ramp times are also measured.

To show the WLAN Power vs Time display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **WLAN Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **WLAN Power vs Time** icon or select the icon and click **Add**. The WLAN Power vs Time icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the WLAN Power vs Time display.
6. Set the **Frequency** appropriate for the signal.
7. Select **Setup > Settings** to display the control panel.
8. Select the **Modulation Params** tab. Set the Standard, Guard Interval and Spacing and Bandwidth controls as appropriate for the input signal.
9. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

## Elements of the Display



Item	Display element	Description
1	Top of graph, first setting	Sets the Power level that appears at the top of the graph, in dBm. This is only a visual control for panning the graph.
(not shown)	Units	Sets the global amplitude units for all the views in the analysis window. This will change the amplitude selection in the Units tab of the Amplitude control panel.
2	Top of graph, second setting	Sets the vertical Scale of the graphs, in dB/div. This is only a visual control for panning the graph.
3	View	<p>Selects the specific view of the packet burst within the display:</p> <ul style="list-style-type: none"> <li>- Full Burst displays the entire packet, with vertical lines indicating length of the packet</li> <li>- Rising Edge zooms the display into the interval around the packet rising edge, with vertical lines indicating the 10% to 90% Power-On Ramp time</li> <li>- Falling Edge zooms the display into the interval around the packet falling edge, with vertical lines indicating the 90% to 10% Power-Down Ramp time</li> </ul>
4	Bottom of graph readout	Shows the Power level at the bottom of the graph in dBm.
5	Autoscale	Adjusts the vertical and horizontal settings to provide the best display.
6	Bottom of graph, left side	Sets the starting time of the graph in seconds
7	Bottom of graph, right side	Sets the scale (width) of the graph in seconds
8	Table below graph	<ul style="list-style-type: none"> <li>- Burst Power: Average power of the burst packet, in dBm</li> <li>- Burst Width: Measured time width of the burst packet from Power-On to Power-Down (or end of waveform, if that occurs before Power-Down), in seconds</li> </ul> <p><b>NOTE.</b> <i>Power-On Ramp Time and Power-Down Ramp Time values are only available for 802.11b analysis.</i></p> <ul style="list-style-type: none"> <li>- Power-On Ramp Time: Time interval for signal level to increase from 10% to 90% of maximum packet power, in seconds</li> <li>- Power-Down Ramp Time: Time interval for signal level to decrease from 90% to 10% of maximum packet power, in seconds. This value is not available if the analysis record does not include the packet power-down portion.</li> </ul>

## WLAN Power vs Time Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the WLAN Power vs Time display are shown in the following table.

Settings tab	Description
<a href="#">Modulation Params (see page 319)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Analysis Params (see page 320)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Data Range (see page 322)</a>	Specifies which symbols and subcarriers of the signal to display.
<a href="#">Analysis Time (see page 323)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for WLAN Analysis displays.
<a href="#">Scale (see page 325)</a>	Specifies the vertical, subcarrier (for non-b standards only), and symbols scale and position settings.
<a href="#">Prefs (see page 328)</a>	Specifies the units of the display and whether elements of the graphs are displayed.

## WLAN Spectral Flatness Display

The WLAN Spectral Flatness display shows the average power levels of subcarriers across the signal bandwidth and indicates if they remain within the limits defined for a particular standard.

The averaged subcarrier level is shown as a line on the display, while the individual subcarrier levels are shown as points. The Pass or Fail result indicates whether the average line remains between the upper and lower limit mask boundaries.

---


**NOTE.** *WLAN Spectral Flatness is only available for OFDM (non-802.11b) signals.*

---

To show the WLAN Spectral Flatness display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **WLAN Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **WLAN Flatness** icon or select the icon and click **Add**. The WLAN Flatness icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the WLAN Flatness display.
6. Set the **Frequency** appropriate for the signal.
7. Select **Setup > Settings** to display the control panel.
8. Select the **Modulation Params** tab. Set the Standard, Guard Interval, Subcarrier Spacing, and Channel Bandwidth controls as appropriate for the input signal.
9. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

## Elements of the Display



Item	Display element	Description
1	Top of graph, first setting	Sets the Flatness value that appears at the top of the graph in dB. This is only a visual control for panning the graph.
2	Top of graph, second setting	Sets the lower range of the Flatness value that appears at the top of the graph in dB/div. This is only a visual control for panning the graph.
3	Bottom of graph	Shows the Flatness value set at the bottom of the graph.
4	Autoscale	Adjusts the vertical and horizontal settings to provide the best display.
5	Posn	Specifies the horizontal position of the trace on the graph display.
6	Scale	Adjusts the horizontal range of the graph. By decreasing the scale, the graph essentially becomes a window that you can move over the analysis results by adjusting the position.

## WLAN Spectral Flatness Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the WLAN Spectral Flatness display are shown in the following table.

Settings tab	Description
<a href="#">Modulation Params (see page 319)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Analysis Params (see page 320)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Data Range (see page 322)</a>	Specifies which symbols and subcarriers of the signal to display.
<a href="#">Analysis Time Tab (see page 323)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis.  <b>NOTE.</b> The Units control on this tab only affects the Analysis Length (AFAIK). Use the Units control in the Prefs tab to affect the displays.
<a href="#">Trace (see page 324)</a>	Enables you to display or hide the measurement or average trace.
<a href="#">Scale Tab (see page 325)</a>	Specifies the vertical, subcarrier (for non-b standards only), and symbols scale and position settings.
<a href="#">Prefs Tab (see page 328)</a>	Specifies the units of the display and whether elements of the graphs are displayed.

## WLAN Summary Display

The WLAN Summary display shows several measurements of WLAN signal quality. The summary display and its contents will vary by standard selected. Not all of the display contents are provided in this section.

To show the WLAN Summary display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **WLAN Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **WLAN Summary** icon or select the icon and click **Add**. The WLAN Summary icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the WLAN Summary display.
6. Set the **Frequency** appropriate for the signal.
7. Select **Setup > Settings** to display the control panel.
8. Select the **Modulation Params** tab. Set the Standard, Guard Interval and Spacing and Bandwidth controls as appropriate for the input signal.
9. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

## WLAN Summary Display for 802.11a/g/j/p/n/ac Signals

<b>Standard:</b> 802.11n		<b>Bandwidth:</b> 40 MHz		<b>Guard Interval:</b> Auto from SIG		<input type="button" value="Clear"/>
<b>Burst Power:</b>	-0.01 dBm	<b>Peak-to-Average:</b>	9.80 dB			
<b>Burst Index:</b>	1	<b>IQ Origin Offset:</b>	-82.25 dB			
<b>Frequency Error:</b>	-140.27 mHz	<b>Common Pilot Error:</b>	0.337 %			
<b>Symbol Clk Error:</b>	-0.070 ppm					

<b>L-SIG Data</b>		<b>Parity:</b> Pass	
<b>Rate</b>	13	<b>Reserved</b>	0
<b>Length</b>	312	<b>Parity</b>	1
<b>Tail</b>	0		

<b>EVM</b>			
	<b>All</b>	<b>Pilots</b>	<b>Data</b>
<b>RMS</b>	-39.91 dB	-40.40 dB	-39.89 dB
<b>Peak</b>	-27.33 dB	-31.09 dB	-27.33 dB
<b>Pk@Sym/Sub</b>	32 / 58	85 / 53	32 / 58
<b>Avg RMS</b>	-39.91 dB		
1 of 1 Bursts			
<b>Max RMS</b>	-39.91 dB		

<b>HT-SIG Data</b>		<b>CRC:</b> Pass	
<b>MCS</b>	0	<b>CBW</b>	1
<b>Length</b>	672	<b>Smoothing</b>	0
<b>Not Sound</b>	0	<b>Reserved</b>	1
<b>Aggregation</b>	0	<b>STBC</b>	0
<b>FEC Coding</b>	0	<b>Short GI</b>	0
<b>Ness</b>	0	<b>CRC</b>	1
<b>Tail</b>	0		

<b>Packet Format:</b> HT_MF		<b>Data Modulation:</b> BPSK	
		<b>Guard Interval:</b> 1/4	
	<b>Symbols</b>	<b>EVM</b>	<b>Avg Power</b>
<b>L-STF</b>	2	-44.57 dB	0.00 dBm
<b>L-LTF</b>	2	-40.02 dB	-0.01 dBm
<b>L-SIG</b>	1	-40.43 dB	-0.26 dBm
<b>HT-SIG</b>	2	-40.34 dB	-0.47 dBm
<b>HT-STF</b>	1	-44.08 dB	-0.01 dBm
<b>HT-LTF</b>	1	-42.43 dB	0.00 dBm
<b>Data</b>	100	-39.91 dB	0.01 dBm



### Elements of the Display for 802.11a/g/j/p/n/ac Signals

Measurement	Description
Standard	Display of the standard selected on the Setup > Settings > Modulation Params tab.
Bandwidth	Display of the channel bandwidth selected on Setup > Settings > Modulation Parameters tab.
Burst Power	The average power of all symbols in the packet, including Preamble and Data segments.
Peak-to-Average	The ratio of the highest instantaneous signal power level to the average signal power.
Burst Index	The index of the analyzed packet within the analysis record.
IQ Origin Offset	The average magnitude of the DC subcarrier level relative to total signal power. It indicates the level of carrier feedthrough detected at the center (DC) subcarrier.
Frequency Error	The frequency difference between the measured carrier frequency of the signal and the measurement frequency setting.
Common Pilot Error	The RMS magnitude error of the pilots over all data symbols.
Symbol Clk Error	The symbol clock error in parts per million.
EVM	<p>The RMS and Peak values of the normalized subcarrier Error Vector Magnitude values. The normalized subcarrier EVM values are calculated as the difference between the detected received signal subcarrier constellation points and ideal reference points estimated by the instrument from the received signal. Values are reported in units of percent or dB. Peak values include the symbol and subcarrier location.</p> <p>RMS and Peak values are displayed for groupings of all subcarriers, Pilots only and Data only. Results are calculated over all Data symbols in the packet.</p> <p>Average RMS and Peak RMS values are accumulated over multiple packet analysis cycles. The Clear button on the display resets these values by clearing the result memory.</p>
Packet Format	Displays the packet format: AG, HT_MF, HT_GF, VHT.
Data Modulation	Displays the modulation used in the Data symbols: BPSK, QPSK, 16QAM, 64QAM, 256QAM.
Guard Interval	Displays the Guard Interval used by the Data symbols: 1/4, 1/8.
Symbols, EVM, Avg Power	Displays the type and number of symbols, EVM-RMS and average power of the Preamble and Data portions of the packet.
SIG Data L-SIG Data HT-SIG Data VHT-SIG Data	Displays the decimal values of the received packet SIGNAL, HT-SIGNAL and VHT-SIGNAL symbols' fields. The Pass/Fail result in each heading line indicates whether the calculated Parity or CRC value matches the received Parity or CRC value of the corresponding SIGNAL symbol grouping.

## WLAN Summary Display for 802.11b Signals

<b>Standard:</b> 802.11b		<b>Packet Format:</b> Auto Detect <input type="button" value="Clear"/>	
<b>Burst Power:</b>	-1.22 dBm	<b>Peak-to-Average:</b>	1.50 dB
<b>Burst Index:</b>	1	<b>IQ Origin Offset:</b>	-39.12 dB
<b>Frequency Error:</b>	-2.34 Hz		

<b>EVM</b>		
	<b>All</b>	<b>1k Chips</b>
<b>RMS</b>	-39.12 dB	-39.02 dB
<b>Peak</b>	-30.29 dB	-30.32 dB
<b>Pk @ Chip</b>	2992	66
<b>Avg RMS</b>	-39.12 dB	
1 of 1 Bursts		
<b>Max RMS</b>	-39.12 dB	

<b>Packet Format:</b> DSSS 2M		<b>Data Modulation:</b> DSSS 2M	
	<b>Chips</b>	<b>EVM</b>	<b>Avg Power</b>
<b>Preamble:</b>	1584	-38.96 dB	-1.72 dBm
<b>Header:</b>	528	-39.06 dB	-1.23 dBm
<b>Data:</b>	4400	-39.19 dB	-1.23 dBm

<b>Header Data</b>		<b>CRC:</b> Pass	
<b>Signal</b>	20	<b>Service</b>	0
<b>Length</b>	400	<b>CRC</b>	17735

### Elements of the Display for 802.11b Signals

Measurement	Description
Standard	Display of the standard selected on the Setup > Settings > Modulation Parameters tab.
Burst Power	The average power of the entire packet.
Peak-to-Average	The ratio of the highest instantaneous packet signal power level to the average signal power.
Burst Index	The index of the analyzed packet within the analysis record.
IQ Origin Offset	The amount of power at the signal carrier frequency relative to the total power of the signal.
Frequency Error	The frequency difference between the measured carrier frequency of the signal and the measurement frequency setting.
EVM	<p>The RMS and Peak values of the normalized Error Vector Magnitudes taken at signal chip intervals. The normalized EVM values are calculated as the difference between the detected received signal constellation points and ideal reference points estimated by the instrument from the received signal. Values are reported in units of percent or dB. Peak values indicate the associated chip locations.</p> <p>RMS and Peak values are displayed for groupings of All chips, and the first 1000 (1k) chips.</p> <p>Average RMS and Peak RMS values are accumulated over multiple packet analysis cycles. The Clear button on the display resets these values by clearing the result memory.</p>
Packet Format	Displays the packet format: DSSS 1M, DSSS 2M, CCK 5.5M or CCK 11M.
Data Modulation	Displays the modulation used in the PSDU/Data packet segment.
Chips, EVM, Avg Power	Displays the number of chips, EVM-RMS and average power of the Preamble, Header and Data portions of the packet.
Header Data	Displays the decimal values of the received packet Header's Signal, Service, Length, and CRC fields. The CRC Pass/Fail result indicates if the received CRC value is equal to the CRC value computed from the received Signal, Service and Length values.

## WLAN Summary Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the WLAN Summary display are shown in the following table.

Settings tab	Description
<a href="#">Modulation Params (see page 319)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Analysis Params (see page 320)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Data Range (see page 322)</a>	Specifies which symbols and subcarriers of the signal to display.
<a href="#">Analysis Time (see page 323)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for WLAN Analysis displays.
<a href="#">EVM (see page 327)</a>	Specifies the EVM units (dB or %) and Max Bursts to Avg. The EVM is generally measured on symbol or chip instants and is usually measured after best-fit estimates of the frequency error and a fixed phase offset have been removed.
<a href="#">Prefs (see page 328)</a>	Specifies the units of the display and whether elements of the graphs are displayed.


## WLAN Symbol Table Display

The WLAN Symbol Table display shows decoded data values for each data symbol in the analyzed signal packet. For OFDM signals (all standards except 802.11b), results are presented with subcarrier (frequency) indices in the horizontal dimension and symbol (time) intervals in the vertical dimension. For 802.11b signals, the Preamble, Header, and Data (PSDU) symbol values are presented sequentially, with symbol indices in the left column.

To show the WLAN Symbol Table display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **WLAN Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **WLAN Symb Table** icon or select the icon and click **Add**. The WLAN Symbol icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the WLAN Symbol Table display.
6. Set the **Frequency** appropriate for the signal.
7. Select **Setup > Settings** to display the control panel.
8. Select the **Modulation Params** tab. Set the Standard, Guard Interval and Spacing and Bandwidth controls as appropriate for the input signal.
9. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

## WLAN Symbol Table for OFDM signals



Item	Description
1	Subcarrier identifiers (OFDM only). Yellow column indicates Pilot subcarrier locations.
2	Symbol identifiers.
3	Subcarrier data values.
4	Marker readout when markers are enabled.

## WLAN Symbol Table for 802.11b signals

Symbols	(Preamble, Header, Data)															
130	0	0	0	1	0	1	1	1	0	0	1	1	1			
143	1															
144	0	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
157	0	0	0	0	0	0	0	1	0	0	1	1	0	1	0	0
170	0	0	0	0	0	0	1	1	1	0	0	0	0	1		
183	0	1	0	1	0	0	0	1	0							
192	0	2	0	2	1	3	1	1	1	0	1	1	1	1	1	1
205	3	0	0	0	3	0	2	3	3	3	2	0	1			
218	0	1	3	0	0	3	3	1	3	0	0	1	3			
231	0	2	1	1	1	2	1	1	2	2	2	2	2	2	2	2
244	2	2	3	0	1	2	3	2	2	1	3	0	3			
257	0	0	2	3	1	2	2	0	3	3	3	1	1			
270	3	0	1	0	3	3	2	0	0	3	3	1	3			
283	2	3	0	3	2	0	0	3	1	1	2	2	3			
296	0	0	2	1	2	2	3	2	0	2	2	2	1			
309	3	3	3	2	0	1	0	0	1	2	1	3	2			
322	3	1	0	1	2	1	2	0	0	0	2	1	0			
335	1	0	0	0	0	1	1	1	2	0	1	2	1			
348	2	1	2	3	1	1	2	1	3	3	1	1	2			
361	0	3	1	3	3	1	2	3	1	1	3	2	1			
374	1	2	3	2	3	2	2	0	2	2	1	2	0			
387	3	2	2	1	3	3	2	0	0	0	2	3	2			

Item	Description
1	Symbol number index (from beginning of packet or segment) of first Symbol data value on the line.
2	Symbol values, with the value in column 2 of each row corresponding to the symbol number index in column 1, and then the symbol value in column 3 corresponding to the next symbol number index, etc., to the end of each row.  For example: The symbol number index 130 = 0 in column 2. The symbol number index for column 3 is 131, which equals 0. The symbol number index for column 4 is 132, which equals 1. This pattern continues to the end of the row.

## WLAN Symbol Table Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the WLAN Symbol Table display are shown in the following table.

Settings tab	Description
<a href="#">Modulation Params (see page 319)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Analysis Params (see page 320)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Data Range (see page 322)</a>	Specifies which symbols and subcarriers of the signal to display.
<a href="#">Analysis Time (see page 323)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for WLAN Analysis displays.
<a href="#">Prefs (see page 328)</a>	Specifies the units of the display and whether elements of the graphs are displayed.

## WLAN Analysis Shared Measurement Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 


The control panel tabs in this section are shared between the displays in the WLAN Analysis folder (Setup > Displays). Some tabs are shared by all the displays, some tabs are shared by only a subset of displays. The settings available on some tabs change depending on the selected display.

## Common controls for WLAN analysis displays

Settings tab	Description
<a href="#">Modulation Params (see page 319)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Analysis Params (see page 320)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Data Range (see page 322)</a>	Specifies which symbols and subcarriers of the signal to display.
<a href="#">Analysis Time (see page 323)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for WLAN Analysis displays.
<a href="#">Trace (see page 324)</a>	Enables you to display or hide the measurement or average trace.
<a href="#">Scale (see page 325)</a>	Specifies the vertical, subcarrier (for non-b standards only), and symbols scale and position settings.
<a href="#">EVM (see page 327)</a>	Specifies the EVM units and max burst averages.
<a href="#">Prefs (see page 328)</a>	Specifies the units of the display and whether elements of the graphs are displayed.

## Modulation Params Tab - WLAN

The Modulation Params tab specifies the type of modulation used by the input signal and other parameters that define the signal format.



Modulation Params Analysis Params Data Range Analysis Time Trace Scale Prefs

Standard: 802.11g Guard Interval: Auto from SIG


Channel Bandwidth: 20 MHz Subcarrier Spacing: 312.500 kHz ☒ Auto

FFT Sample Rate: 20.000 MS/s FFT Length: 64

Settings	Description
Standard	Specifies the standard used for the input signal. Choices are 802.11a/b/g/j/n/p/ac.
Guard Interval	Specifies the guard interval used in the input signal. You can select the following: <ul style="list-style-type: none"> <li>– Auto from SIG uses the Guard Interval value extracted from the signal</li> <li>– 1/8 allows setting the value manually</li> <li>– 1/4 allows setting the value manually</li> </ul>
Channel Bandwidth	Specifies the nominal channel bandwidth. This setting affects the Subcarrier Spacing value when the Subcarrier Spacing Auto box is checked.
Subcarrier Spacing	Specifies the spacing between subcarriers. When Auto is selected, this setting is automatically calculated according to the Channel Bandwidth value. If Auto is unchecked, a custom subcarrier spacing value can be entered for nonstandard signal definition.
FFT Sample Rate	Indicates the FFT sample rate, based on the bandwidth or subcarrier setting.
FFT Length	Indicates the fixed FFT length.

## Analysis Params Tab - WLAN

The Analysis Params tab contains parameters that control the analysis of the input signal.



Modulation Params Analysis Params Data Range Analysis Time Traces Scale Prefs

Burst Selection Index: 1

Frequency Error: 0.000 Hz ☒ Auto

Symbol Analysis Offset: -50 %

Swap I & Q: ☐

Equalizer Training: Preamble

Data Modulation: Auto Detect

☒ Enable 1024QAM Detection

Pilot Tracking

☒ Phase ☐ Amplitude ☐ Timing



Settings	Description
Burst Selection Index	Allows specifying the burst you want to measure when multiple bursts are present in an acquisition. Index number of the first burst is 1, second burst is 2, etc.
Frequency Error	When the Auto box is checked, the analysis determines the Frequency Error and the measured Frequency Error is displayed. When the Auto box is unchecked, the entered value is used by the analysis as a fixed frequency offset. This is useful when the exact frequency offset of the signal is known.
Symbol Analysis Offset	Specifies the analysis offset in the symbol interval. This value is a percentage of the Guard Interval. The allowable range is -100% to 0%. -100% positions the FFT to start at the beginning of the Guard Interval, 0% positions it to start at the end of the Guard Interval. Default value is -50% which usually gives the best measurement results.
Swap I & Q	Select the checkbox to swap the I and Q components of a signal. This compensates the input signal for spectral inversion.
Equalizer Training	Specifies the method used to estimate channel frequency response and equalization. This control can be used to diagnose changes in frequency response over the signal packet.
Preamble	The instrument uses only the Preamble to estimate channel frequency response. This response is then used to equalize the entire signal packet.
Preamble + Data	The instrument makes an initial channel frequency response estimate from the Preamble. It then estimates the channel response for each data symbol using the decoded data content to derive equalization for each symbol individually. This allows compensation for time-varying channel response over the packet.
Data Modulation	Allows choice of automatic or manual method of data symbol modulation identification, as follows: <ul style="list-style-type: none"> <li>– Auto Detect estimates the modulation from the data symbol IQ content.</li> <li>– Auto from SIG sets the modulation as indicated by the embedded SIG preamble symbol format data.</li> <li>– Manual allows specifying the modulation type regardless of the signal content.</li> </ul>
Enable 1024QAM detection	Check box to enable auto-detection of 1024QAM.
Pilot tracking	Specifies if pilot subcarriers should be used to correct amplitude, phase, and symbol timing variations over the packet. The choices available are Phase, Amplitude, and Timing. The default setting is Phase correction enabled, Amplitude and Timing correction disabled..
Subcarrier derotation	Allows some displays to show subcarriers with or without Gamma subcarrier phase rotation removed. Gamma phase rotation is applied to 802.11n and 802.11ac subcarriers in defined subranges depending on the selected Channel Bandwidth >40 MHz. Only Constellation and Symbol Table results are affected by this control. <p>When the box is unchecked, the rotation is not removed, which provides a direct view of the physical modulation on the channel.</p> <p>When the box is checked, the rotation is removed, allowing easier decoding of the underlying data content.</p>

## Data Range Tab - WLAN

The Data Range tab enables you to control how much signal is analyzed, as well as specify the range of results that are displayed for the WLAN Constellation, EVM, Flatness, Magnitude Error, Phase Error, and Symbol Table graphs. The tab contents vary by standard.

Data Range tab for non-b standards.

Settings	Description
Symbols	Specifies which symbols are displayed in the graphs.
All	Select All to display all symbols.
Range	Select Range to specify a subset of symbols for display.
Start	Specifies the first symbol to include in the display.
Stop	Specifies the last symbol to include in the display.
Single	Select Single to display a single symbol.
Index	Use Index to specify the symbol you want to display.
Subcarriers	Specifies which subcarriers are displayed.
All	Select All to display all subcarriers in the signal.
Pilots	Select Pilot to display only pilot subcarriers.
Data	Select Data to display only data subcarriers.
Single	Specifies a specific subcarrier for display.
Index	Specifies the specific subcarrier to be displayed.
Range	Specifies a range of subcarriers to be displayed.
Start	Specifies the start value of the range to be displayed.
Stop	Specifies the ending value of the range to be displayed.
Max symbols to analyze	Specifies how many symbols are analyzed. You can use this setting to speed analysis by limiting the number of symbols being analyzed.

Data Range tab for 802.11b standards.

Settings	Description
Chips	Specifies which symbols are displayed in the graphs.
All	Select All to display all chips.
Preamble Only	Select to include only the Preamble in the display.
Header Only	Select to include only the Header in the display.
Data Only	Select to include only the Data in the display.
Max number of chips to analyze	Specifies how many chips are analyzed. You can use this setting to speed analysis by limiting the number of chips being analyzed. Check this box and then enter the maximum number of chips to analyze.

## Analysis Time Tab - WLAN


The Analysis Time tab contains parameters that define how the signal is analyzed in the WLAN Analysis displays.

The screenshot shows the 'Analysis Time' tab selected in a settings window. The 'Analysis Length' is set to '200.000 Symbol' and the 'Auto' checkbox is checked. The 'Units' dropdown menu is set to 'Symbols'.

Settings	Description
Analysis Length	Specifies the length of the analysis period to use in measurements. Length is specified in either symbols or seconds, depending on the Units setting. Use this to specify how long a period of time is analyzed. – Range: minimum value depends on modulation type – Resolution: 1 symbol
Auto	When enabled, causes the instrument to set the Analysis Length value based on the requirements of the selected display.
Units	Specifies the units of the Analysis Length in either Symbols or Seconds.

# Trace Tab - WLAN


The Trace tab allows you to set the trace display characteristics of the selected display. This tab is not available for all WLAN displays.



Settings	Description
Trace	Use this drop-down list to select whether or not the Average trace or the measurement trace is displayed. The measurement trace depends on the selected display.
Show Symbols	Select or deselect this checkbox to show or hide symbols.
Freeze	Selecting Freeze halts updates to the symbols.

# Traces Tab - WLAN Channel Response

The Traces tab allows you to set the trace display characteristics of the WLAN Channel Reponse display.



Settings	Description
Trace	Selects the Magnitude or Phase trace for saving or recalling.
Save Trace As . . .	Select to save a trace.
Recall Trace . . .	Select to recall a trace.

## Scale Tab - WLAN

The Scale tab allows you to change the scale settings that control how the trace appears on the display but does not change control settings such as Measurement Frequency. There are four versions of the Scale tab for WLAN displays. One version is used for the Constellation display, one for the Spectral Flatness display, one for the Power vs Time display, and one for the EVM, Magnitude Error, Phase Error, and Channel Response displays.

The image shows the 'Scale' tab for the 'Power vs Time' display. The tab bar at the top includes 'Modulation Params', 'Analysis Params', 'Data Range', 'Analysis Time', 'Scale', and 'Prefs'. The 'Scale' tab is active. It contains two main sections: 'Vertical' and 'Horizontal Full Burst'. The 'Vertical' section has a 'Scale' field set to '100.00 dB', a 'Position' field set to '-11.00 dBm', and an 'Autoscale' button. The 'Horizontal Full Burst' section has a 'Scale' field set to '100.000 us' and a 'Position' field set to '0.000 s', with an 'Autoscale' button. A 'Reset' button is located between the two sections.


Scale tab for the WLAN Power vs Time display

The image shows the 'Scale' tab for EVM, Magnitude Error, Phase Error, and Channel Response displays. The tab bar at the top includes 'Modulation Params', 'Analysis Params', 'Data Range', 'Analysis Time', 'Trace', 'Scale', and 'Prefs'. The 'Scale' tab is active. It contains three main sections: 'Vertical', 'Horizontal Symbol', and 'Horizontal Subcarrier'. The 'Vertical' section has a 'Scale' field set to '7.80 °' and a 'Position' field set to '-3.90 °', with a 'Reset' button. The 'Horizontal Symbol' section has a 'Start' field set to '0 Symbol', a 'Stop' field set to '99 Symbol', an 'Auto' checkbox (checked), and a 'Reset' button. The 'Horizontal Subcarrier' section has a 'Start' field set to '-58 Subcarrier', a 'Stop' field set to '58 Subcarrier', and a 'Reset' button.

Scale tab for WLAN EVM, Magnitude Error, Phase Error, and Channel Response displays

The image shows the 'Scale' tab for the 'Constellation' display. The tab bar at the top includes 'Modulation Params', 'Analysis Params', 'Data Range', 'Analysis Time', 'Trace', 'Scale', and 'Prefs'. The 'Scale' tab is active. It contains a 'Zoom' section with a 'Scale' field set to '3', a 'Vertical Position' field set to '0', and a 'Horizontal Position' field set to '0'.

Scale tab for WLAN Constellation display




Scale tab for WLAN Spectral Flatness display

Settings	Description
Vertical	Controls the vertical position and scale of the trace display.
Scale	Changes the vertical scale of the graph.
Position	Adjusts the reference level away from top of the graph.
Autoscale	Resets the scale of the vertical axis to contain the complete trace.
Subcarrier	Controls the scale of the subcarrier graph and position of the trace.
Scale	Specifies how many subcarriers are displayed horizontally.
Position	Specifies the subcarrier that appears at the left edge of the subcarrier graph.
Autoscale	Resets the scale of the horizontal axis to contain the complete trace.
Symbols	Controls the scale of the Symbols graph.
Scale	Specifies the number of symbols that appear in the symbols graph.
Position	Specifies the symbol that appears at the left edge of the Symbols graph.
Autoscale	Resets the scale and position settings to optimize the display.
Auto	When Auto is checked, the scale and position values for the Symbols graph are automatically adjusted to maintain the optimal display.
Zoom	Sets the Constellation display size and position.
Scale	Sets the magnification value for the Constellation display.
Vertical Position	Sets the vertical location of the Constellation display within the graph. Range is -3.7 to +3.7.
Horizontal Position	Sets the horizontal location of the Constellation display within the graph. Range is -3.7 to +3.7.

## EVM Tab - WLAN

The EVM Tab enables you to choose between dB and percent for the EVM units and to select to set the maximum bursts to average. The EVM Tab is only available for the WLAN Summary display.




The screenshot shows the EVM Tab interface with the following settings:

- EVM Units:** A dropdown menu currently set to **dB**.
- Max Bursts to Avg:** A text input field containing the value **20**.
- Count:** A checkbox that is currently unchecked.

Settings	Description
EVM units	Specifies whether the displayed EVM units are dB or percent.
Max Bursts to Avg	Specifies the maximum number of bursts to average when Count is selected.
Count	Enables the Max Bursts to Avg function.

## Prefs Tab - WLAN

The Prefs tab enables you to change appearance characteristics of the WLAN Analysis displays. Not all settings on the Prefs tab shown below appear for every WLAN display.



Settings	Description
Time units	Specifies whether the displayed time units are seconds or symbols.
Freq units	Specifies whether the displayed frequency units are frequency (Hz) or subcarrier channel.
Radix	Specifies whether symbol values are displayed in binary or hex format (for example, in the Symbol Table or markers readouts).
Show graphs	Specifies which graphs are displayed. Select from Symbols, Subcarriers or Both, Magnitude, Phase, or Both. Disabled (no masks), Shaded Region, or Line Only. These selections are only available for OFDM signals.
Show graticule	Specifies to show the graticule on the display when checked.
Show marker readout	Specifies to show the marker readout when checked.



## Overview of 802.11ad

The optional Tektronix 802.11ad solution provides repeatable signal quality measurement (such as EVM) for the single carrier 802.11ad Transmitter PHY at RF (up to 66 GHz) for offline analysis.


The IEEE 802.11ad-2012 standard was approved on December 2012 and amended in 2014. It allows wireless communication of devices at multi-gigabit speeds and enables high performance wireless data, display, and audio applications that supplement the capabilities of previous wireless LAN devices. It operates in the 60 GHz band and delivers data transfer rates up to 7 Gbit/s, while maintaining compatibility with existing Wi-Fi devices. The 60 GHz signal cannot typically penetrate walls, but can propagate off reflections from walls, ceilings, floors, and objects using beamforming built into an 802.11ad system. When roaming away from the main room, the protocol can switch to make use of the other 802.11 lower bands at a much lower rate, but which can propagate through walls.

ITU-T recommends the use of the following four channels at the 60 GHz band.


Chan- nel	Center (GHz)	Min (GHz)	Max (GHz)	BW (GHz)
1	58.32	57.24	59.4	2.16
2	60.48	59.4	61.56	2.16
3	62.64	61.56	63.72	2.16
4	64.8	63.72	65.88	2.16


### 802.11ad Standards Presets


Select **Presets > Standards** in the menu to open the window to select the 802.11ad preset. You can then select to recall preconfigured displays for the Single Carrier or Control PHY standards. The preset displays are Spectrum, Time Overview, 802.11ad Summary, and 802.11ad Constellation. The preset sets the measurement filter is to Root Raised Cosine, the filter parameter to 0.25, and the default data length to analyze at *1000* for Single Carrier and *512* for Control PHY in EVM test setup. You can read more about [Standards Presets \(see page 25\)](#).


Preset:  


Preset displays:


  
Spectrum

  
Time Overview

  
802.11ad  
Summary

  
802.11ad  
Constellation

Standard:  

Test Setup:  


☐ Retain current Center Frequency setting

☒ Retain current Ref Level setting


To go directly to a preset in the future, use Presets->Preset Options->Presets->Preset action

Preset:

Preset displays:



SEM



Time Overview

Standard:

Test Setup:

☐ Retain current Center Frequency setting

☒ Retain current Ref Level setting

To go directly to a preset in the future, use Presets->Preset Options->Presets->Preset action

---

**NOTE.** The default resolution bandwidth for the SEM display is 1 MHz.

---

Settings	Description
Standard	Allows you to choose between Single Carrier and Control PHY.
Test Setup	Allows you to choose between EVM and SEM.
Retain current center frequency setting	Allows you to retain the previous center frequency. It is disabled by default. To enable or disable this setting, select the checkbox.
Retain current reference level setting	Allows you to retain the previous reference level. It is enabled by default. To enable or disable this setting, select the checkbox.

### 802.11ad topics in this Help

The following information about the 802.11ad Analysis option is available:

- [802.11ad measurements](#)
- [802.11ad displays](#)
- [802.11ad measurement control settings](#)

## 802.11ad measurements

The 802.11ad option supports the Control PHY and Single Carrier PHY standards. Information about the packet type and frame format is given in Section 21 of IEEE Std 802.11adTM (Amendment 3).

These measurements are only supported for Windows oscilloscopes of bandwidth > 3 GHz. ATI oscilloscopes support real time data analysis at RF, without any downconverters. The 802.11ad option allows you to do the following:

- Automatically detect the packet start, if it is included in the analysis region
- Synchronize to preamble start using the Golay codes in STF (Short training field) region
- Demodulate Preamble, Header, and Payload regions separately and measure EVM in each of these sections.

The input data is filtered with a RRC filter, corrected for frequency, phase and symbol timing errors, IQ DC offset errors and Equalization is done based on Channel estimated using the Channel Estimation Field (CEF) data.

- Decode packet information in header (like MCS, length etc.)
- Measure the following:
  - EVM
  - RF power and Received Power Indicator (RCPI)
  - Estimated SNR
  - Frequency error
  - IQ DC origin offset
  - IQ Gain imbalance is calculated with the equation  

$$\text{Gain Error in dB} = 20 \log [(1 + \epsilon_A)/(1 - \epsilon_A)]$$
 Where,  $2\epsilon_A$  is the amplitude difference between the signal paths.
  - IQ phase imbalance or quadrature error
- Perform Transmit Mask measurement with the set up file given under Example Files. The Mask (Offset frequencies and Start and Stop limits) is developed as per standard recommendations. After loading set up file, you can set the Center Frequency manually to that of the signal.

The following features are also available:

- Analyze EVM result with and without equalization.
- Analyze EVM result with and without IQ DC offset correction.

- View the constellation color coded for the preamble, header, guard, and payload regions. You can also view the  $\pi/2$  rotated constellation against the final de-rotated constellation.
- View the demodulated symbols in tabular form with different color codes and with an option to traverse to the start of each region.
- View the EVM spread across the analyzed packet with color codes differentiating regions.
- View of scalar results in the Summary display.
- EVM numbers can be seen in percentage or in dB.
- EVM and Frequency Error limits for the transmitter can be set in the Limits tab of the Settings control panel. If the measured EVM is greater than the limits, or if the measured Frequency Error is greater than the limit, then a FAIL status will appear against the respective measurement.
- Save the Channel Impulse response coefficients as a .txt or .csv file.

## 802.11ad displays

The displays in 802.11ad Analysis (Setup > Displays > Measurements) are:

- [802.11ad Constellation display \(see page 333\)](#)
- [802.11ad EVM vs Time display \(see page 337\)](#)
- [802.11ad Symbol Table display \(see page 339\)](#)
- [802.11ad Summary display \(see page 341\)](#)


## 802.11ad Constellation Display

This display shows a digitally-modulated signal in constellation form.


To show the 802.11ad Constellation display:

1. Recall the data file.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **802.11ad Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **802.11ad Constellation** icon or select the icon and click **Add**. The 802.11ad Constellation icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the 802.11ad Constellation display.
6. Press the **Replay** button to take measurements on the recalled acquisition data file.


## Elements of the display



Item	Display element	Description
A	Scalar results	Gives results of Data EVM (Average EVM over the data region and the Peak Error in the data region), Freq Error, and IQ Origin Offset.
B	Marker readout	Specifies the Marker readout values.
C	Graph	Displays the input signal.



The above image shows an 802.11ad signal with QPSK data region



The above image shows an 802.11ad signal with 16QAM data region



## Constellation display settings

Settings tab	Description
<a href="#">Modulation Params (see page 345)</a>	Specifies the input signal standard, measurement filters and filter parameters.
<a href="#">Analysis Params (see page 346)</a>	Specifies parameters used by the instrument and software to analyze the input signal.
<a href="#">Advanced Params (see page 347)</a>	Specifies additional parameters used by the instrument and software to analyze the input signal.
<a href="#">Analysis Time (see page 348)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) and Time Zero Reference (Trigger or Acquisition Start) for 802.11ad Analysis displays.
<a href="#">EVM (see page 349)</a>	Specifies the EVM units, start and length of data symbols to be analyzed for EVM, and the number of acquisitions used for averaging. For Control PHY, the Start and Length of data symbols is specified in terms of de-spread symbols and also the number of Bursts to Avg by enabling the count.
<a href="#">Traces (see page 353)</a>	Specifies the trace type and the result content. Select either rotated or de-rotated constellation. De-rotated constellation is shown by default.
<a href="#">Prefs (see page 352)</a>	Specifies the radix of the data symbols and the option to see the marker readout.
<a href="#">Scale (see page 351)</a>	Defines the vertical and horizontal axes.


## 802.11ad EVM vs Time

This display shows the EVM plotted against time in seconds or symbols. The analysis region in which EVM measurement done is indicated by a purple line in the Time Overview to indicate the region of analysis.

To show the 802.11ad EVM vs Time Display:

1. Recall the data file.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **802.11ad Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **802.11ad EVM vs Time** icon or select the icon and click **Add**. The 802.11ad EVM vs Time icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the 802.11ad EVM vs Time display.
6. Press the **Replay** button to take measurements on the recalled acquisition data file.

## Elements of the display



Item	Display element	Description
A	Freq error	Displays the frequency error which has been corrected after which the EVM is calculated. The displayed frequency error is followed by either Auto or Manual. This indicates the error calculation mode which is set under Settings >Analysis Params.
B	Top of graph	The error at the top of the graph in dB or percent.
C	Position	The error at the bottom of the graph in dB or percent.
D	Autoscale	Adjusts the vertical and horizontal settings to provide the best display.
E	Position	Displays the horizontal position of the trace on the graph display.
F	Scale	Adjusts the span of the graph in seconds or symbols.
G	Graph	Displays the input signal. Different color codes are used in the 802.11ad EVM vs Time to indicate different regions of the packet. Check legend at the bottom of the symbol table for color codes

### EVM vs Time display settings

Settings tab	Description
<a href="#">Modulation Params (see page 345)</a>	Specifies the input signal standard, measurement filters, and filter parameters.
<a href="#">Analysis Params (see page 346)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Advanced Params (see page 347)</a>	Specifies parameters used by the instrument to analyze the input signal, with options to enable the Equalizer and IQ DC Offset correction.
<a href="#">Analysis Time (see page 348)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) and Time Zero Reference (Trigger or Acquisition Start) for 802.11ad Analysis displays.
<a href="#">EVM (see page 349)</a>	Specifies the number of data symbols to be analyzed for EVM. For Control PHY, the Start and Length of data symbols is specified in terms of de-spread symbols.
<a href="#">Prefs (see page 352)</a>	Specifies the radix of the marker readout and whether elements of the graphs are displayed.
<a href="#">Scale (see page 351)</a>	Defines the vertical and horizontal axes.

## 802.11ad Symbol Table Display

This display shows a digitally-modulated signal. It is similar to the Constellation display except that a text table is used to display data bits as symbols rather than a graph.

1. Recall the data file.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **802.11ad Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **802.11ad Symbol Table** icon or select the icon and click **Add**. The 802.11ad Symbol Table icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the 802.11ad Symbol Table display.
6. Press the **Replay** button to take measurements on the recalled acquisition data file.

## Elements of the display

Symbol	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
0	+1	+1	-1	-1	-1	-1	-1	-1	-1	+1	-1	+1	+1	-1	-1	+1
16	+1	+1	-1	-1	+1	+1	+1	+1	-1	+1	-1	+1	-1	+1	+1	-1
32	-1	-1	+1	+1	+1	+1	+1	+1	+1	-1	+1	-1	-1	+1	+1	-1
48	+1	+1	-1	-1	+1	+1	+1	+1	-1	+1	-1	+1	-1	+1	+1	-1
64	+1	+1	-1	-1	-1	-1	-1	-1	-1	+1	-1	+1	+1	-1	-1	+1
80	+1	+1	-1	-1	+1	+1	+1	+1	-1	+1	-1	+1	-1	+1	+1	-1
96	+1	+1	-1	-1	-1	-1	-1	-1	-1	+1	-1	+1	+1	-1	-1	+1
112	-1	-1	+1	+1	-1	-1	-1	-1	+1	-1	+1	-1	+1	-1	-1	+1
128	+1	+1	-1	-1	-1	-1	-1	-1	-1	+1	-1	+1	+1	-1	-1	+1
144	+1	+1	-1	-1	+1	+1	+1	+1	-1	+1	-1	+1	-1	+1	+1	-1
160	-1	-1	+1	+1	+1	+1	+1	+1	+1	-1	+1	-1	-1	+1	+1	-1
176	+1	+1	-1	-1	+1	+1	+1	+1	+1	-1	+1	-1	+1	-1	+1	-1
192	+1	+1	-1	-1	-1	-1	-1	-1	-1	+1	-1	+1	+1	-1	-1	+1
208	+1	+1	-1	-1	+1	+1	+1	+1	-1	+1	-1	+1	-1	+1	+1	-1
224	+1	+1	-1	-1	-1	-1	-1	-1	-1	+1	-1	+1	+1	-1	-1	+1
240	-1	-1	+1	+1	-1	-1	-1	-1	+1	-1	+1	-1	+1	-1	-1	+1
256	+1	+1	-1	-1	-1	-1	-1	-1	-1	+1	-1	+1	+1	-1	-1	+1
272	+1	+1	-1	-1	+1	+1	+1	+1	+1	-1	+1	-1	+1	-1	+1	-1
288	-1	-1	+1	+1	+1	+1	+1	+1	+1	-1	+1	-1	-1	+1	+1	-1
304	+1	+1	-1	-1	+1	+1	+1	+1	-1	+1	-1	+1	-1	+1	+1	-1
320	+1	+1	-1	-1	-1	-1	-1	-1	-1	+1	-1	+1	+1	-1	-1	+1
336	+1	+1	-1	-1	+1	+1	+1	+1	-1	+1	-1	+1	-1	+1	+1	-1
352	+1	+1	-1	-1	-1	-1	-1	-1	-1	+1	-1	+1	+1	-1	-1	+1
368	-1	-1	+1	+1	-1	-1	-1	-1	-1	+1	-1	+1	-1	-1	-1	+1
384	+1	+1	-1	-1	-1	-1	-1	-1	-1	+1	-1	+1	+1	-1	-1	+1
400	+1	+1	-1	-1	+1	+1	+1	+1	+1	-1	+1	-1	+1	-1	+1	-1
416	-1	-1	+1	+1	+1	+1	+1	+1	+1	-1	+1	-1	-1	+1	+1	-1
432	+1	+1	-1	-1	+1	+1	+1	+1	-1	+1	-1	+1	-1	+1	+1	-1
448	+1	+1	-1	-1	-1	-1	-1	-1	-1	+1	-1	+1	+1	-1	-1	+1
464	+1	+1	-1	-1	+1	+1	+1	+1	-1	+1	-1	+1	-1	+1	+1	-1
480	+1	+1	-1	-1	-1	-1	-1	-1	-1	+1	-1	+1	+1	-1	-1	+1
496	-1	-1	+1	+1	-1	-1	-1	-1	+1	-1	+1	-1	+1	-1	-1	+1
512	+1	+1	-1	-1	-1	-1	-1	-1	-1	+1	-1	+1	-1	-1	-1	+1
528	+1	+1	-1	-1	+1	+1	+1	+1	+1	-1	+1	-1	+1	-1	+1	-1

Navigate To: ☒ Preamble (pi/2-BPSK) ☐ Header (pi/2-BPSK) ☐ Data (pi/2-16QAM) ☐ Guard (pi/2-BPSK)

Marker: MR Time: 3.057 us Symbol: 5543 Value: 3

Different Color codes are used in the table to indicate different regions of the packet. The legend at the bottom of the table indicates which color represents which packet component. The bit colors in the table match the packet colors. The packet will have the following regions:

- Preamble (pi/2-BPSK)
- Header (pi/2-BPSK)
- Data (pi/2 BPSK, pi/2 QPSK or pi/2 16QAM)
- Guard (pi/2-BPSK)

## Using markers

Markers are indicators in the display that you can position on a trace to measure values such as frequency, power, and time. A Marker always displays its position and, if the Delta readout is enabled, will display the difference between its position and that of the Marker Reference. Within the Symbol Table, colored cells indicate the location of markers. The selected Marker is highlighted with a light green background. All other markers are highlighted with a light gray background. In the Symbol Table, the marker readout below the table shows the marker location in time, symbol numbers and symbol value.

### Symbol Table display settings

Settings tab	Description
<a href="#">Modulation Params (see page 345)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Analysis Params (see page 346)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Advanced Params (see page 347)</a>	Specifies additional parameters used by the instrument to analyze the input signal.
<a href="#">Analysis Time (see page 348)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) and Time Zero Reference (Trigger or Acquisition Start) for 802.11ad Analysis displays.
<a href="#">Prefs (see page 352)</a>	Specifies the radix of the symbols and the option to see the marker readout.


## 802.11ad Summary Display

The 802.11ad Summary display shows a summary of all scalar measurements done on the acquired test pattern. Pass/Fail information is also provided in this display for all enabled scalar measurements. You can set limits and choose which measurement to compare for Pass/Fail from the Limits tab in the 802.11ad Summary Settings control panel. The default limits come from the performance recommendation limits given by the Standards document. The default limits can be reloaded by selecting the 802.11ad as the preset in the Standards Preset window.

1. Recall the data file.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **802.11ad Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **802.11ad Summary** icon or select the icon and click **Add**. The 802.11ad Summary icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the 802.11ad Summary display.
6. Press the **Replay** button to take measurements on the recalled acquisition data file.

### Elements of the display

The results presented in the display include scalar results of modulation characteristics, shown in the following areas of the display: EVM - Packet, Average results over multiple Acquisitions (One Bust per Acquisition), and Packet Information. These scalar results are averaged over the previously acquired packets. The packet number to be analyzed is set in the EVM tab of the Settings control panel.



The above image shows an 802.11ad Single Carrier signal with  $\pi/2$  16QAM data modulation

Display element	Description
Standard	Display of the standard selected on the Setup > Settings > Standard Params tab.
Data Modulation	Indicates data modulation. Data modulation types are as follows: Single Carrier: pi/2 BPSK, pi/2 QPSK, pi/2 16QAM Control PHY: pi/2 DBPSK
Clear	Click to reset the scale measurements.
RF Power	Measures the RF power in the signal.
RCPI	Calculates the Received Channel Power Indicator from RF power.
Frequency error	The frequency difference between the measured carrier frequency of the signal and the measurement frequency setting in ppm and Hz.
Estimated SNR	Measures the estimated SNR in the measurement setup.
IQ Origin Offset	The average magnitude of the DC subcarrier level relative to total signal power. It indicates the level of carrier feedthrough detected at the center (DC) carrier.
IQ Gain Imbalance	Measures the Gain mismatch of the signal (sinusoid) in dB. It indicates the mismatch between I and Q signal paths.
IQ Quadrature Error	Measures the phase part of the imbalance in degrees. It indicates the mismatch between I and Q signal paths.
EVM – Packet	Gives EVM results for each packet region. The number of symbols analyzed in each region is given alongside the packet region labels. Single Carrier: STF, CEF, Header, Guard, and Data Control PHY: STF, CEF and Data + Header in despread symbols
EVM	Gives Average EVM in the region of the packet.
Peak EVM	Gives the Peak error/EVM in the corresponding region of the packet.
@ Symbol	Gives the symbol index at which the peak error occurred out of the entire set of symbols in the packet (it is not an index just within the region). The symbol index shown here can be used to place a marker in the Symbol Table or EVM vs Time displays to observe the exact symbol position at which the peak error occurred.
Average results over multiple acquisitions (one burst per acquisition)	Gives data EVM and Frequency error results over multiple acquisitions. Gives both the Average and Max over multiple acquisitions. Also shows how many acquisitions have been used for these results below. The number of acquisitions to be used for these measurements can be selected from the EVM tab of the Settings Control panel using the Max Bursts to Avg selection.
Avg Data EVM	
Max Data EVM	
Avg Frequency Error	
Max Frequency Error	
Packet Information	The packet header information includes the Scrambler initialization, MCS, Length, Packet type, Training Length, Turnaround and HCS. MCS, Length and Training length are shown in decimal.  PDDU, Aggregation, Beam Tracking Request, and Last RSSI are shown only for Single Carrier.

### Summary Table display settings

Settings tab	Description
<a href="#">Modulation Params (see page 345)</a>	Specifies the input signal standard and other signal parameters.
<a href="#">Analysis Params (see page 346)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Advanced Params (see page 347)</a>	Specifies additional parameters used by the instrument to analyze the input signal.
<a href="#">Analysis Time (see page 348)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) and Time Zero Reference (Trigger or Acquisition Start) for 802.11ad Analysis displays.
<a href="#">EVM (see page 349)</a>	Specifies the EVM units and number of data symbols to be analyzed for EVM. For Control PHY, the Start and Length of data symbols is specified in terms of de-spread symbols and also the number of Bursts to Avg by enabling the count.
<a href="#">Limits (see page 354)</a>	Load and define 802.11ad measurement limits for Pass/Fail comparison. You can save defined limits as a .csv file and also load previously saved .csv files.

## 802.11ad Control Panel Settings

### Favorites Toolbar:

The control panel tabs in this section are shared between the displays in the 802.11ad Analysis folder (Setup > Displays). Some tabs are shared by all the displays, some tabs are shared by only a couple of displays. The settings available on some tabs change depending on the selected display.



Settings tab	Description
<a href="#">Modulation Params (see page 345)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Analysis Params (see page 346)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Advanced Params (see page 347)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Analysis Time (see page 348)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) and Time Zero Reference (Trigger or Acquisition Start) for 802.11ad Analysis displays.
<a href="#">EVM (see page 349)</a>	Specifies the EVM units and number of data symbols to be analyzed for EVM.
<a href="#">Limits (see page 354)</a>	Load and define 802.11ad measurement limits for Pass/Fail comparison. You can save defined limits as a .csv file and also load previously saved .csv files.
<a href="#">Traces (see page 353)</a>	Specifies the trace type and the result content. Select either rotated or de-rotated constellation. De-rotated constellation is shown by default.
<a href="#">Prefs (see page 352)</a>	Specifies the radix of the symbols, the option to see the marker readout, and whether elements of the graphs are displayed.
<a href="#">Scale (see page 351)</a>	Defines the vertical and horizontal axes.

## Modulation Params tab – 802.11ad

The Modulation Params tab specifies the type of modulation used by the input signal and other parameters that define the signal format. This tab is available for the 802.11ad EVM vs Time, Constellation, Symbol Table, and Summary displays.

802.11ad Symbol Table Settings

Modulation Params Analysis Params Advanced Params Analysis Time Prefs

Standard: Single Carrier Measurement Filter: Root raised cosine

Filter Parameter: 0.250

Standard Presets

Settings	Description
Standard	Specifies the standard used for the input signal. Choices are Control PHY and Single Carrier.
Measurement filter	Specify whether a filter is used to limit the bandwidth of the input signal. Options are None and Root Raised Cosine.
Filter parameter	Enter a value used for defining the alpha parameter for Root Raised Cosine filter. (Not present when Measurement filter is None.)

## Analysis Params tab – 802.11ad

This tab contains parameters to control the analysis of the input signal. This tab is available for the 802.11ad EVM vs Time, Constellation, Symbol Table, and Summary displays.

The screenshot shows the '802.11ad EVM Vs Time Settings' dialog box with the 'Analysis Params' tab selected. The 'Modulation Params' tab is also visible. The 'Frequency Error' is set to 1.914 kHz with an 'Auto' checkbox checked. The 'Measurement BW' is set to 3.000 GHz with a dropdown menu set to 'Auto'. A 'Standard Presets' button is located on the left side of the dialog.

Settings	Description
Frequency Error	When Auto is checked, the analysis determines the Frequency Error and the measured Frequency Error is displayed. When unchecked, the entered value is used by the analysis as fixed frequency offset. This is useful when the exact frequency offset of the signal is known.
Measurement BW	Specifies the bandwidth about the center frequency at which measurements are made. Select Manual, Auto, or Link to Span.

## Advanced Params tab – 802.11ad

This tab specifies additional parameters that control the demodulation of the signal. This tab is available for the 802.11ad EVM vs Time, Constellation, Symbol Table, and Summary displays. Not all settings appear for every display.

Settings	Description
Enable DC Offset Correction	Enables DC offset correction before EVM results are calculated.
Blockwise Correction	Enables impairments correction in a blockwise approach. This selection allows you to see if impairments like frequency error vary within the packet. Disabled by default.
Handle Multipath Channels	Select to enable. Allows you to experiment with multipath channels (This selection is disabled by default).
Save Chan Imp Resp As...	<p>Opens a file dialogue box that allows you to save the Estimated Channel Impulse response (64 coefficients). You can save it as a .txt or .csv file.</p> <p>The saved file will have two columns. The first and the second columns give the 64 real and imaginary coefficients, respectively.</p> <p>The generated coefficients are that of the last analyzed acquisition.</p> <p>The impulse response will show an early and a late multipath propagation.</p> <p>When channel response coefficients are plotted, the horizontal axis represents symbols.</p>
OFF	The EVM measurement is done with the equalizer switched off.
Non Adaptive (CEF)	The EVM measurement is done with an equalizer that is non-adaptive and the equalization is done based on the data in Channel Estimation Field (CEF).
Adaptive (STF and CEF)	The EVM measurement is done with the equalizer that adapts its coefficients from acquisition to acquisition. Equalization in this case is done based on the data in the Short Training Field (STF) and Channel Estimation Field (CEF) regions.
Mode	Specifies whether the equalizer is in learning (Train) mode or analysis (Hold) mode.
Convergence	Specifies the update rate.
Taps/Symbol	The number of filter coefficients per symbol used by the filter
Taps	The number of filter coefficients. Range: 3 to 100 (you can set a higher number, but 100 is the practical limit).
Length	Specifies the number of symbols analyzed (or filter length).
Reset Equalization	Resets the equalizer.
	You can read more about how to use the equalizer in the topic <a href="#">here (see page 710)</a> .
Swap I & Q	Enables swapping of I & Q when there are multiple up converter stages.

## Analysis Time tab – 802.11ad

This tab contains parameters that define how the signal is analyzed in the 802.11ad EVM vs Time, Constellation, Symbol Table, and Summary displays.

802.11ad Constellation

Modulation Params Analysis Params Advanced Params Analysis Time EVM Traces Scale Prefs

Analysis Offset: 0.000 s ☐ Auto Time Zero Reference: Trigger ☒

Analysis Length: 10.000 us ☐ Auto Units: Seconds ☒

Standard Presets

Actual: 0.000 s

Settings	Description
Analysis Offset	Specifies the location of the first time sample to use in measurements.
Auto	When enabled, causes the instrument to set the Analysis Offset value based on the requirements of the selected display.
Analysis Length	Specifies the length of the analysis period to use in measurements. Length is specified in either symbols or seconds, depending on the Units.
Auto	When enabled, causes the instrument to set the Analysis Length value based on the requirements of the selected display.
Actual	This readout displays the analysis length (time or symbols) used by the analyzer. This value may not match the Analysis Length requested in manual mode.
Time Zero Reference	Specifies the zero point for the analysis time.
Units	Specifies the units of the analysis length to either Symbols or Seconds.

### Analysis offset

Use analysis offset to specify where measurements begin. Be aware that you cannot set the Analysis Offset outside the range of time covered by the current acquisition data (all time values are relative to the Time Zero Reference).

You can set the Analysis Length so that the requested analysis period falls partly or entirely outside the current range of acquisition data settings. When the next acquisition is taken, its Acquisition Length will be increased to cover the new Analysis Length, as long as the Sampling controls are set to Auto. If the Sampling parameters are set to manual, or if the instrument is analyzing saved data, the actual analysis length will be constrained by the available data length, but in most cases, measurements are able to be made anyway. The instrument will display a notification when measurement results are computed from less data than requested. Range: 0 to [(end of acquisition) - Analysis Length]. Resolution: 1 effective sample (or symbol).

### Analysis length

Use the analysis length to specify how long a period of time is analyzed. As you adjust this value, the actual amount of time for Analysis Length, in Symbol or Seconds units, is shown below the control in the

"Actual" readout. This setting is not available when Auto is checked. Range: minimum value depends on modulation type. Resolution: 1 symbol.

### Time zero reference


All time values are measured from this point (such as marker position or horizontal position (in Y vs Time displays). Choices are: Acquisition Start or Trigger.

**Acquisition Start** sets the analyzer to measure the offset from the starting point of the acquisition.


**Trigger** sets the analyzer to measure the offset from the trigger point of the acquisition.

## EVM tab – 802.11ad

This tab enables you to set the EVM Units, Data Start, and Data Length. Not all settings appear for every display.



The above image is the EVM tab for the 802.11ad EVM vs Time and Constellation displays for Single Carrier



The above image is the EVM tab for the 802.11ad EVM vs Time and Constellation displays for Control PHY

802.11ad Summary Settings

Modulation Params Analysis Params Advanced Params Analysis Time Limits EVM

Standard Presets

EVM Units: dB

Max Bursts to Avg: 10

☒ Count

Data Symbols

Start: 0

Length: 1000


☐ Analyze all

The above image is the EVM tab for the 802.11ad Summary display for Single Carrier


Settings	Description
EVM Units	Specifies whether the displayed EVM units are dB or percent.
Max Bursts to Avg	Specifies the maximum number of acquisitions to average when Count is selected.
Count	Enables the Avg function. Multiple acquisitions are averaged when this is enabled.
Data Symbols (for Single Carrier)	
De-spread Data Symbols (for Control PHY)	
Start	Specifies the EVM measurement start data symbol.
Length	Specifies the length in terms of Data Symbols to analyze the EVM in data region starting from Start.
Analyze all	Check to analyze all data symbols in the packet. When checked, Start and Length options will be disabled. However, Length will be automatically updated to the number of data symbols analyzed when this option is selected.

## Scale tab – 802.11ad

This tab allows you to change the scale settings that control how the trace appears on the display but does not change control settings such as Measurement Frequency. There are two versions of the Scale tab for 802.11ad displays. One version is used for Constellation display, and one for EVM vs Time. Not all settings appear for every display.



The above image is the Scale tab for the 802.11ad Constellation display




The above image is the Scale tab for the 802.11ad EVM vs Time display


Settings	Description
<b>Vertical</b>	
Scale	Changes the vertical scale.
Position	Adjusts the reference level away from top of the graph.
Autoscale	Resets the scale of the vertical axis to contain the complete trace.
<b>Horizontal</b>	
Scale	Changes the horizontal scale.
Position	Adjusts the reference level away from top of the graph.
Autoscale	Resets the scale of the vertical axis to contain the complete trace.
<b>Zoom</b>	
Scale	Sets the magnification value for the Constellation display.
Vertical position	Sets the vertical location of the Constellation display within the graph.
Horizontal position	Sets the horizontal location of the Constellation display within the graph.

## Prefs tab – 802.11ad


This tab enables you to change appearance characteristics of the 802.11ad Analysis displays. Not all settings appear for every display.



The above image is the Prefs tab for the 802.11ad Constellation display



The above image is the Prefs tab for the 802.11ad Symbol Table display




The above image is the Prefs tab for the 802.11ad EVM vs Time display

Settings	Description
Data radix	Specifies whether symbol values are displayed in binary or decimal format (for example, in the Symbol Table or markers readouts).
Show graticule	Specifies to show the graticule on the display when checked.
Show Marker readout in graph (selected marker)	Specifies to show the marker readout when checked.



## Traces tab – 802.11ad


This tab allows you to set the trace display characteristics of the selected display.



Settings	Description
Trace Type	Specifies the trace type is regular or pi/2 rotated.
Result Contents	Selects which regions of the packet to show in constellation display. You can choose from Preamble, Header, Guard, and Data for Single Carrier. You can choose from Preamble, Header, and Data for Control PHY.

## Limits tab – 802.11ad

This tab allows you to load an existing limits table, save a limits table, or edit limits values. By default, FreqErrorLimit is turned on and EVMLimit is turned off. This tab is available for the 802.11ad Summary display only.



Settings	Description
On	Click on a cell in the On column next to the measurement name to specify whether or not measurements are selected for limit comparison to indicate Pass or Fail. EVMLimit is off by default and FreqErrorLimit is on by default.
Measurement Name	Specifies the name of the measurement related to the limit (not editable).
Limit	Specifies the value of the limit to the related measurement. When the cell is selected, the value is shown along with the units. This is editable.
Load	Click to load a saved Limits table from a .csv file.
Save	Click to save the current Limits table to a .csv file.

### Edit Limits

To directly edit measurement limits in the table, click on the value in the Limit column that you want to change.

## Overview

The OFDM Analysis option provides measurements for OFDM signals specified by 802.11a/g/j (Wifi) and 802.16 (2004) (commonly known as Fixed WiMAX) standards. User controls allow you to modify signal parameters for analysis of non-standard signals. The analysis results give multiple views of OFDM signal characteristics to allow diagnosing signal imperfections and impairments quickly and easily. Display controls provide the ability to selectively display the analysis results to help locate trouble-spots in the signal.

The displays in OFDM Measurements (Displays > Measurements > OFDM Measurements) are:

- [OFDM Channel Response \(see page 355\)](#)
- [OFDM Constellation \(see page 358\)](#)
- [OFDM EVM \(see page 359\)](#)
- [OFDM Spectral Flatness \(see page 361\)](#)
- [OFDM Mag Error \(see page 363\)](#)
- [OFDM Phase Error \(see page 365\)](#)
- [OFDM Power \(see page 367\)](#)
- [OFDM Summary \(see page 369\)](#)
- [OFDM Symbol Table \(see page 372\)](#)

## OFDM Channel Response Display



The OFDM Channel Response display plots the channel response (magnitude or phase) versus the subcarrier or frequency. Here, the channel refers to all sources of signal frequency response impairment up to the analyzer input, including the transmitter itself, as well as any transmission medium through which the signal travels between the transmitter and the analyzer.

To show the OFDM Channel Response display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **OFDM Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **OFDM Chan Response** icon or select the icon and click **Add**. The OFDM Chan Response icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the OFDM Chan Response display.
6. Set the Frequency appropriate for the signal.
7. Select **Setup > Settings** to display the control panel.

8. Select the Modulation Params tab. Set the Standard, Guard Interval and Spacing and Bandwidth controls as appropriate for the input signal.
9. If you are analyzing a stored data file, press the **Replay** button to take measurements on the recalled acquisition data file.

### Elements of the Display



Item	Display element	Description
1	Top-of-graph (magnitude)	Sets the level that appears at the top of the magnitude graph. This is only a visual control for panning the graph. The Reference Level is adjusted in the Toolbar and the Ampl control panel. By default, Vert Position = Ref Level.
2	dB/div (magnitude)	Sets the vertical scale value. The maximum value is 20.00 dB/division.
3	Display selector	Selects the display type. Channel Response Magnitude or Phase can be displayed as a Magnitude or Phase graph.
4	Bottom-of-graph readout (magnitude)	Indicates the amplitude at the bottom of the graph. This value changes with the dB/div and Vertical Position settings.
5	Autoscale	Adjusts the Vertical and Horizontal scaling to display the optimize the trace display on screen.
6	Pos	Shifts the trace left or right in the graph. The readout indicates the subcarrier or frequency shown at the left edge of the display.
7	Scale	Specifies the number of subcarriers shown in the graph.
8	Top-of-graph (phase)	Sets the phase value indicated at the top of the graph. Since the Position value at the vertical center of this graph remains constant as the Top of Graph value is adjusted, the Vertical Scale increases as the Top of Graph value increases, which also affects the bottom of graph readout.
9	Position (phase)	Specifies the phase shown at the center of the graph display. Changing this value moves the trace up and down in the graph, which affects the Top of Graph and Bottom of Graph values as well.
10	Bottom-of-graph (phase)	Indicates the phase at the bottom of the graph. This value changes with the Position setting.

## OFDM Channel Response Settings

The OFDM Channel Response Settings control panel provides access to settings that control parameters of the Channel Response Display.

Settings tab	Description
<a href="#">Modulation Params (see page 374)</a>	Specifies the input signal standard and additional user-settable signal parameters.
<a href="#">Advanced Params (see page 375)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Data Range Tab (see page 376)</a>	Specifies which symbols and subcarriers of the signal to display.
<a href="#">Analysis Time Tab (see page 376)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the time units (Symbols or Seconds) for OFDM Analysis displays.
<a href="#">Prefs Tab (see page 380)</a>	Specifies the units of the display and whether elements of the graphs are displayed.


## OFDM Constellation Display

Display shows the OFDM signal subcarriers' amplitude and phase in IQ constellation form.

To show the OFDM Constellation display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **OFDM Constellation** in the **Measurements** box.
4. In the Available displays box, double-click the **OFDM Constellation** icon or select the icon and click **Add**. The OFDM Constellation icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the OFDM Constellation display.
6. Set the **Frequency** appropriate for the signal.
7. Select **Setup > Settings** to display the control panel.
8. Select the **Modulation Params** tab. Set the Standard, Guard Interval and Spacing and Bandwidth controls as appropriate for the input signal.
9. If you are analyzing a stored data file, press the **Replay** button to take measurements on the recalled acquisition data file.

### Elements of the Display



Item	Display element	Description
1	Plot	Constellation graph.
2	Marker Readout	If markers are enabled, the marker readout shows the selected Marker, Symbol, Subcarrier, Type, Value, Magnitude, and Phase for the symbol at the marker location. Located to the left of the constellation plot or below it, depending on the size of the window.

## OFDM Constellation Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The OFDM Constellation Settings control panel provides access to settings that control parameters of the Constellation Display.

Settings tab	Description
<a href="#">Modulation Params (see page 374)</a>	Specifies the input signal standard and additional user-settable signal parameters.
<a href="#">Advanced Params (see page 375)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Data Range (see page 376)</a>	Specifies which symbols and subcarriers of the signal to display.
<a href="#">Analysis Time Tab (see page 376)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for OFDM Analysis displays.
<a href="#">Trace (see page 378)</a>	Enables you to freeze the display or hide the measurement or average trace.
<a href="#">Scale Tab (see page 378)</a>	Specifies the Zoom scale, and vertical and horizontal positions of the display.
<a href="#">Prefs Tab (see page 380)</a>	Specifies the units of the display and whether elements of the graphs are displayed.

## OFDM EVM Display


The OFDM EVM display shows the data symbols' individual subcarrier Error Vector Magnitude values versus symbol interval (time) and subcarrier (frequency).

To show the OFDM EVM display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **OFDM EVM** in the **Measurements** box.
4. In the Available displays box, double-click the **OFDM EVM** icon or select the icon and click **Add**. The OFDM EVM icon will appear in the **Selected displays** box and will no longer appear under Available displays.

5. Click **OK** to show the OFDM EVM display.
6. Set the **Frequency** appropriate for the signal.
7. Select **Setup > Settings** to display the control panel.
8. Select the **Modulation Params** tab. Set the Standard as appropriate. Set the Standard, Guard Interval and Spacing and Bandwidth controls as appropriate for the input signal.
9. If you are analyzing a stored data file, press the **Replay** button to take measurements on the recalled acquisition data file.

### Elements of the Display




---

**NOTE.** *There is no carrier assigned to DC.*

---



Item	Display element	Description
1	Top of graph	Sets the EVM value that appears at the top of the graph. This is only a visual control for panning the graph.
2	Bottom of graph	Sets the EVM value that appears at the bottom of the graph. This is only a visual control for panning the graph.
3	Autoscale	Adjusts the vertical and horizontal settings to provide the best display.
4	Pos	Specifies the horizontal position of the trace on the graph display.
5	Scale	Adjusts the horizontal range of the graph. By decreasing the scale, the graph essentially becomes a window that you can move over the analysis results by adjusting the position.

## OFDM EVM Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the OFDM EVM display are shown in the following table.

Settings tab	Description
<a href="#">Modulation Params (see page 374)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Advanced Params (see page 375)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Data Range (see page 376)</a>	Specifies which symbols and subcarriers of the signal to display.
<a href="#">Analysis Time (see page 376)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for OFDM Analysis displays.
<a href="#">Trace (see page 378)</a>	Enables you to freeze the display or hide the measurement or average trace.
<a href="#">Scale (see page 378)</a>	Specifies the vertical, subcarrier, and symbols scale and position settings.
<a href="#">Prefs (see page 380)</a>	Specifies the units of the display and whether elements of the graphs are displayed.

## OFDM Spectral Flatness Display


The OFDM Spectral Flatness display shows the average power levels of subcarriers across the signal bandwidth and indicates if they remain within the limits defined for a particular standard.

The averaged subcarrier level is shown as a line on the display, while the individual subcarrier levels are shown as points. The Pass or Fail result indicates whether the average line remains between the upper and lower limit mask boundaries.

To show the OFDM Spectral Flatness display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **OFDM Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **OFDM Flatness** icon or select the icon and click **Add**. The OFDM Flatness icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the OFDM Flatness display.
6. Set the **Frequency** appropriate for the signal.
7. Select **Setup > Settings** to display the control panel.
8. Select the **Modulation Params** tab. Set the Standard, Guard Interval, Subcarrier Spacing and Channel Bandwidth controls as appropriate for the input signal.
9. If you are analyzing a stored data file, press the **Replay** button to take measurements on the recalled acquisition data file.

### Elements of the Display



Item	Display element	Description
1	Top of graph	Sets the Flatness value that appears at the bottom of the graph in dB. This is only a visual control for panning the graph.
2	Bottom of graph	Shows the Flatness value set at the top of the graph.
3	Autoscale	Adjusts the vertical and horizontal settings to provide the best display.
4	Pos	Specifies the horizontal position of the trace on the graph display.
5	Scale	Adjusts the horizontal range of the graph. By decreasing the scale, the graph essentially becomes a window that you can move over the analysis results by adjusting the position.

## OFDM Spectral Flatness Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the OFDM Spectral Flatness display are shown in the following table.

Settings tab	Description
<a href="#">Modulation Params (see page 374)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Advanced Params (see page 375)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Data Range (see page 376)</a>	Specifies which symbols and subcarriers of the signal to display.
<a href="#">Analysis Time Tab (see page 376)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for WLAN Analysis displays.
<a href="#">Trace (see page 378)</a>	Enables you to display or hide the measurement or average trace.
<a href="#">Scale Tab (see page 378)</a>	Specifies the vertical, subcarrier, and symbols scale and position settings.
<a href="#">Prefs Tab (see page 380)</a>	Specifies the units of the display and whether elements of the graphs are displayed.

## OFDM Magnitude Error Display


The OFDM Mag Error display shows the data symbols' individual subcarrier Magnitude Error values versus symbol interval (time) and subcarrier (frequency).

To show the OFDM Magnitude Error display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **OFDM Analysis** in the **Measurements** box.

4. In the Available displays box, double-click the **OFDM Mag Error** icon or select the icon and click **Add**. The OFDM Mag Error icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the OFDM Mag Error display.
6. Set the **Frequency** appropriate for the signal.
7. Select **Setup > Settings** to display the control panel.
8. Select the **Modulation Params** tab. Set the Standard, Guard Interval and Spacing and Bandwidth controls as appropriate for the input signal.
9. If you are analyzing a stored data file, press the **Replay** button to take measurements on the recalled acquisition data file.

### Elements of the Display



Item	Display element	Description
1	Top of graph	Sets the Magnitude Error value that appears at the top of the graph. This is only a visual control for panning the graph.
2	Bottom of graph	Sets the Magnitude Error value that appears at the bottom of the graph. This is only a visual control for panning the graph.
3	Autoscale	Adjusts the vertical and horizontal settings to provide the best display.
4	Pos	Specifies the horizontal position of the trace on the graph display.
5	Scale	Adjusts the horizontal range of the graph. By decreasing the scale, the graph essentially becomes a window that you can move over the analysis results by adjusting the position.

## OFDM Magnitude Error Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the OFDM Mag Error display are shown in the following table.

Settings tab	Description
<a href="#">Modulation Params (see page 374)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Advanced Params (see page 375)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Data Range (see page 376)</a>	Specifies which symbols and subcarriers of the signal to display.
<a href="#">Analysis Time Tab (see page 376)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for OFDM Analysis displays.
<a href="#">Trace (see page 378)</a>	Enables you to display or hide the measurement or average trace.
<a href="#">Scale Tab (see page 378)</a>	Specifies the vertical, subcarrier, and symbols scale and position settings.
<a href="#">Prefs Tab (see page 380)</a>	Specifies the units of the display and whether elements of the graphs are displayed.

## OFDM Phase Error Display


The OFDM Phase Error display shows the data symbols' individual subcarrier Phase Error values versus symbol interval (time) and subcarrier (frequency).

To show the OFDM Phase Error display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **OFDM Analysis** in the **Measurements** box.

4. In the Available displays box, double-click the **OFDM Phase Error** icon or select the icon and click **Add**. The OFDM Phase Error icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the OFDM Phase Error display.
6. Set the **Frequency** appropriate for the signal.
7. Select **Setup > Settings** to display the control panel.
8. Select the **Modulation Params** tab. Set the Standard, Guard Interval and Spacing and Bandwidth controls as appropriate for the input signal.
9. If you are analyzing a stored data file, press the **Replay** button to take measurements on the recalled acquisition data file.

### Elements of the Display



Item	Display element	Description
1	Top of graph	Sets the Phase Error value that appears at the top of the graph. This is only a visual control for panning the graph.
2	Bottom of graph	Sets the Phase Error value that appears at the bottom of the graph. This is only a visual control for panning the graph.
3	Autoscale	Adjusts the vertical and horizontal settings to provide the best display.
4	Pos	Specifies the horizontal position of the trace on the graph display.
5	Scale	Adjusts the horizontal range of the graph. By decreasing the scale, the graph essentially becomes a window that you can move over the analysis results by adjusting the position.

## OFDM Phase Error Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the OFDM Phase Error display are shown in the following table.

Settings tab	Description
<a href="#">Modulation Params (see page 374)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Advanced Params (see page 375)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Data Range (see page 376)</a>	Specifies which symbols and subcarriers of the signal to display.
<a href="#">Analysis Time Tab (see page 376)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for OFDM Analysis displays.
<a href="#">Trace (see page 378)</a>	Enables you to display or hide the measurement or average trace.
<a href="#">Scale Tab (see page 378)</a>	Specifies the vertical, subcarrier, and symbols scale and position settings.
<a href="#">Prefs Tab (see page 380)</a>	Specifies the units of the display and whether elements of the graphs are displayed.

## OFDM Power Display


The OFDM Power display shows the data symbols' individual subcarrier Power values versus symbol interval (time) and subcarrier (frequency).

To show the OFDM Power display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **OFDM Analysis** in the **Measurements** box.

4. In the Available displays box, double-click the **OFDM Power** icon or select the icon and click **Add**. The OFDM Power icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the OFDM Power display.
6. Set the **Frequency** appropriate for the signal.
7. Select **Setup > Settings** to display the control panel.
8. Select the **Modulation Params** tab. Set the Standard, Guard Interval and Spacing and Bandwidth controls as appropriate for the input signal.
9. If you are analyzing a stored data file, press the **Replay** button to take measurements on the recalled acquisition data file.

### Elements of the Display





Item	Display element	Description
1	Vertical Position	Sets the top of graph value. This is only a visual control for panning the graph. The Reference Level is adjusted in the Toolbar and the Ampl control panel. By default, Vert Position = Ref Level.
2	dB/div	Sets the vertical scale value. The maximum value is 20.00 dB/division.
(not shown)	Units	Sets the global amplitude units for all the views in the analysis window. This will change the amplitude selection in the Units tab of the Amplitude control panel.
2	Bottom of graph readout	Indicates the amplitude at the bottom of the graph. This value changes with the dB/div and Vertical Position settings.
3	Autoscale	Adjusts the vertical and horizontal settings to provide the best display.
4	Pos	Specifies the horizontal position of the trace on the graph display.
5	Scale	Adjusts the horizontal range of the graph. By decreasing the scale, the graph essentially becomes a window that you can move over the analysis results by adjusting the position.

## OFDM Power Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the OFDM Power display are shown in the following table.

Settings tab	Description
<a href="#">Modulation Params (see page 374)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Advanced Params (see page 375)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Data Range (see page 376)</a>	Specifies which symbols and subcarriers of the signal to display.
<a href="#">Analysis Time (see page 376)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for OFDM Analysis displays.
<a href="#">Trace (see page 378)</a>	Enables you to display or hide the measurement or average trace.
<a href="#">Scale (see page 378)</a>	Specifies the vertical, subcarrier, and symbols scale and position settings.
<a href="#">Prefs (see page 380)</a>	Specifies the units of the display and whether elements of the graphs are displayed.

## OFDM Summary Display

The OFDM Summary display shows several measurements of OFDM signal quality.

To show the OFDM Summary display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **OFDM Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **OFDM Summary** icon or select the icon and click **Add**. The OFDM Summary icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the OFDM Summary display.
6. Set the **Frequency** appropriate for the signal.
7. Select **Setup > Settings** to display the control panel.
8. Select the **Modulation Params** tab. Set the Standard, Guard Interval and Spacing and Bandwidth controls as appropriate for the input signal.
9. If you are analyzing a stored data file, press the **Replay** button to take measurements on the recalled acquisition data file.

## Elements of the Display

Frequency: 5.90000 GHz    RefLev: 0.00 dBm <a href="#">Print</a> <a href="#">Replay</a> <a href="#">Run</a>			
<b>802.11a/g/j</b>			
Symbols:	13		
Frequency Error:	1.75 Hz	Symbol Clk Error:	-0.502 ppm
IQ Origin Offset:	-74.31 dB	CPE:	1.509 %
Average Power:	-24.31 dBm	Peak-to-Average:	9.53 dB
<b>Subcarriers:</b>	<b>All</b>	<b>Pilots</b>	<b>Data</b>
RMS EVM:	-35.17 dB	-36.43 dB	-35.08 dB
	1.744 %	1.509 %	1.763 %
Peak EVM:	-23.75 dB	-27.80 dB	-23.75 dB
	6.492 %	4.074 %	6.492 %
at symbol:	1	5	1
at subcarrier:	26	21	26

Measurement	Description
Standard	Display of the standard selected on the Setup > Settings > Modulation Params tab.
Frequency Error	The frequency difference between the measured carrier frequency of the signal and the measurement frequency setting.
IQ Origin Offset	The average magnitude of the DC subcarrier level relative to total signal power. It indicates the level of carrier feedthrough detected at the center (DC) subcarrier.
Average Power	The average power of all symbols in the analysis. Calculated over only the data symbols in the packet.
Symbols	How many symbols were analyzed.
Symbol Clk Error	The symbol clock error in parts per million.
CPE	CPE, Common Pilot Error, is the RMS magnitude error of the pilots over all analyzed symbols.
Peak-to-Average	The ratio of the highest instantaneous signal power level to the average signal power. Calculated over only the data symbols in the packet.
EVM	The RMS and Peak values of the normalized subcarrier Error Vector Magnitude values. The normalized subcarrier EVM values are calculated as the difference between the detected received signal subcarrier constellation points and ideal reference points estimated by the instrument from the received signal. Values are reported in units of percent and dB. Peak values include the symbol and subcarrier location.  RMS and Peak values are displayed for groupings of all subcarriers, Pilots only and Data only. Results are calculated over the entire signal packet analyzed, covering the number of Symbols indicated in the Summary display.

## OFDM Summary Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the OFDM Summary display are shown in the following table.


Settings tab	Description
<a href="#">Modulation Params (see page 374)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Advanced Params (see page 375)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Data Range (see page 376)</a>	Specifies which symbols and subcarriers of the signal to display.
<a href="#">Analysis Time (see page 376)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for OFDM Analysis displays.
<a href="#">Prefs (see page 380)</a>	Specifies the units of the display and whether elements of the graphs are displayed.

## OFDM Symbol Table Display

The OFDM Symbol Table display shows decoded data bits for each subcarrier in each symbol in the analyzed signal packet. Results are presented with subcarrier (frequency) indices in the horizontal dimension and symbol (time) intervals in the vertical dimension.

To show the OFDM Symbol Table display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **OFDM Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **OFDM Symb Table** icon or select the icon and click **Add**. The OFDM Symbol icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the OFDM Symbol Table display.
6. Set the **Frequency** appropriate for the signal.
7. Select **Setup > Settings** to display the control panel.
8. Select the **Modulation Params** tab. Set the Standard, Guard Interval and Spacing and Bandwidth controls as appropriate for the input signal.
9. If you are analyzing a stored data file, press the **Replay** button to take measurements on the recalled acquisition data file.



Item	Description
1	Subcarrier identifiers.
2	Symbol identifiers.

(cont.)

Item	Description
3	Subcarrier data values.
4	Marker readout when markers are enabled.

## OFDM Symbol Table Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the OFDM Symbol Table display are shown in the following table.

Settings tab	Description
<a href="#">Modulation Params (see page 374)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Advanced Params (see page 375)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Data Range (see page 376)</a>	Specifies which symbols and subcarriers of the signal to display.
<a href="#">Analysis Time (see page 376)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for OFDM Analysis displays.
<a href="#">Prefs (see page 380)</a>	Specifies the units of the display and whether elements of the graphs are displayed.

## OFDM Analysis Shared Measurement Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The control panel tabs in this section are shared between the displays in the OFDM Analysis folder (Setup > Displays). Some tabs are shared by all the displays, some tabs are shared by only a couple of displays. The settings available on some tabs change depending on the selected display.

## Common controls for OFDM analysis displays

Settings tab	Description
<a href="#">Modulation Params (see page 374)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Advanced Params (see page 375)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Data Range (see page 376)</a>	Specifies which symbols and subcarriers of the signal to display.
<a href="#">Analysis Time (see page 376)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for OFDM Analysis displays.
<a href="#">Trace (see page 378)</a>	Enables you to display or hide the measurement or average trace.
<a href="#">Scale (see page 378)</a>	Specifies the vertical, subcarrier, and symbols scale and position settings.
<a href="#">Prefs (see page 380)</a>	Specifies the units of the display and whether elements of the graphs are displayed.

## Modulation Params Tab - OFDM

The Modulation Params tab specifies the type of modulation used by the input signal and other parameters that control the demodulation of the input signal.

Modulation Params | Advanced Params | Data Range | AnalysisTime | Trace | Scale | Prefs

Standard: 802.16 (2004) ▼  
FFT Length : 256

Guard Interval: 1/8 ▼

Spacing and Bandwidth

☒ Subcarrier Spacing 90.000 kHz  
☐ Channel Bandwidth 20.160 MHz

FFT Sample Rate: 23.040 MS/s

Settings	Description
Standard	Specifies the standard used for the input signal. Choices are 802.11a/g/j and 802.16 (2004).
Guard Interval	Specifies the guard interval used in the input signal. Choices are 1/4, 1/8, 1/16, 1/32, and User. When you select User, you can enter a percentage value to specify the size of the guard interval as a percentage of the useful symbol interval. The Guard Interval range is 0–100%.
Spacing and Bandwidth	Specifies the spacing between subcarriers and the nominal channel bandwidth. Only one of these settings can be set at a time, the other setting is automatically calculated.
Sample Rate	Indicates the FFT sample rate, based on the bandwidth or subcarrier setting.

## Advanced Params Tab - OFDM

The Advanced Params tab contains parameters that control the analysis of the input signal.


The screenshot shows the 'Advanced Params' tab in the software interface. It contains several settings:

- Constellation determination:** A dropdown menu set to 'Auto Detect'.
- Channel Estimation:** A dropdown menu set to 'Preamble'.
- Pilot tracking:** A group of three checkboxes: 'Phase' (checked), 'Amplitude' (unchecked), and 'Timing' (unchecked).
- Symbol analysis offset:** A text input field containing '-0.5 %'.
- Swap I & Q:** An unchecked checkbox.

Settings	Description
Constellation determination	Specifies the method used to detect the constellation. Auto Detect analyzes the signal to determine the appropriate constellation, Manual allows you to specify the constellation type. Manual choices are: BPSK, QPSK, 16QAM, and 64QAM.
Symbol analysis offset	Specifies the analysis offset in the symbol interval. This value is a percentage of the Guard Interval. The allowable range is -100% to 0%. -100% positions the FFT to start at the beginning of the Guard Interval, 0% positions it to start at the end of the Guard Interval. Default value is -50% which usually gives the best measurement results.
Channel Estimation	Specifies the method used to estimate channel frequency response and equalization. This control can be used to diagnose changes in frequency response over the signal packet.
Preamble	When you select Preamble, the instrument uses only the Preamble to estimate channel frequency response. This response is then used to equalize the entire signal packet.
Preamble + Data	When you select Preamble + Data, the instrument makes an initial channel frequency response estimate from the Preamble. Then estimates the channel response for each data symbol using the decoded data content to derive equalization for each symbol individually. This allows compensation for time-varying channel response over the packet.
Pilot tracking	Specifies if pilot subcarriers should be used to correct amplitude, phase, and symbol timing variations over the packet. The choices available are Phase, Amplitude, and Timing. The default setting is Phase.
Swap I & Q	Select the checkbox to swap the I and Q components of a signal. This compensates the input signal for spectral inversion.

## Data Range Tab - OFDM

The Data Range tab enables you to control how much signal is analyzed, as well as specify the range of results that are displayed in the Constellation, EVM, Magnitude Error, Phase Error, Power and Symbol Table graphs.



Settings	Description
Symbols	Specifies which symbols are displayed in the graphs.
All	Select All to display all symbols.
Range	Select Range to specify a subset of symbols for display.
Start	Specifies the first symbol to include in the display.
Number	Specifies how many symbols to display in the graphs.
Single	Select Single to display a single symbol.
Index	Use Index to specify the symbol you want to display.
Subcarriers	Specifies which subcarriers are displayed.
All	Select All to display all subcarriers in the signal.
Pilots Only	Select Pilot to display only pilot subcarriers.
Data Only	Select Data to display only data subcarriers.
Single	Specifies a specific subcarrier for display.
Index	Specifies the specific subcarrier to be displayed.
Range	Specifies a range to subcarriers to be displayed.
Start	Specifies the start value of the range to be displayed.
Stop	Specifies the ending value of the range to be displayed.
Max symbols to analyze	Specifies how many symbols are analyzed. You can use this setting to speed analysis by limiting the number of symbols being analyzed.

## Analysis Time Tab - OFDM

The Analysis Time tab contains parameters that define how the signal is analyzed in the OFDM Analysis displays.



Modulation Params | Advanced Params | Data Range | **AnalysisTime** | Trace | Scale | Prefs

Analysis Offset:  ☒ Auto Time Zero Reference:

Analysis Length:  ☒ Auto Units:

Actual: 66.000 Sym

Settings	Description
Analysis Offset	Specifies the location of the first time sample to use in measurements.
Auto	When enabled, causes the instrument to set the Analysis Offset value based on the requirements of the selected display.
Analysis Length	Specifies the length of the analysis period to use in measurements. Length is specified in either symbols or seconds, depending on the Units setting.
Auto	When enabled, causes the instrument to set the Analysis Length value based on the requirements of the selected display.
Actual	This is a displayed value, not a setting. It is the Analysis Length (time or symbols) being used by the analyzer, this value may not match the Analysis Length requested (in manual mode).
Time Zero Reference	Specifies the zero point for the analysis time.
Units	Specifies the units of the Analysis Length to either Symbols or Seconds.

### Analysis Offset

Use analysis offset to specify where measurements begin. Be aware that you cannot set the Analysis Offset outside the range of time covered by the current acquisition data. (all time values are relative to the Time Zero Reference).

You can set the Analysis Length so that the requested analysis period falls partly or entirely outside the current range of acquisition data settings. When the next acquisition is taken, its Acquisition Length will be increased to cover the new Analysis Length, as long as the Sampling controls are set to Auto. If the Sampling parameters are set to manual, or if the instrument is analyzing saved data, the actual analysis length will be constrained by the available data length, but in most cases, measurements are able to be made anyway. The instrument will display a notification when measurement results are computed from less data than requested. Range: 0 to [(end of acquisition) - Analysis Length]. Resolution: 1 effective sample (or symbol).

### Analysis Length

Use the analysis length to specify how long a period of time is analyzed. As you adjust this value, the actual amount of time for Analysis Length, in Symbol or Seconds units, is shown below the control in the "Actual" readout. This setting is not available when Auto is checked. Range: minimum value depends on modulation type. Resolution: 1 symbol.


### Time Zero Reference

All time values are measured from this point (such as marker position or horizontal position (in Y vs Time displays). Choices are: Acquisition Start or Trigger.

Parameter	Description
Acquisition Start	Offset is measured from the point at which acquisition begins.
Trigger	Offset is measured from the trigger point.

## Trace Tab - OFDM

The Trace tab allows you to set the trace display characteristics of the selected display. This tab is not available for all OFDM displays.



Settings	Description
Trace	Use this drop-down list to select whether or not the Average trace or the measurement trace is displayed. The measurement trace depends on the selected display.
Show	Select or deselect this checkbox to show or hide the trace selected in the Trace drop-down list.
Freeze	Selecting Freeze halts updates to the trace.

## Scale Tab - OFDM

The Scale tab allows you to change the scale settings that control how the trace appears on the display but does not change control settings such as Measurement Frequency. There are two versions of the Scale tab for OFDM displays. One version is used only for the Constellation display and the other version is used for the OFDM EVM, OFDM Magnitude Error, OFDM Phase Error, and OFDM Power displays.

Modulation Params | Advanced Params | Data Range | AnalysisTime | Trace | **Scale** | Prefs

Vertical  
Scale: 41.8 %  
Position: -21.9 %  
Autoscale

Subcarrier  
Scale: 200 Subc  
Position: -100 Subc  
Autoscale

Symbols  
Scale: 12 Sym  
Position: 0 Sym  
☒ Auto Autoscale

Scale tab for OFDM EVM, OFDM Mag Error, OFDM Phase Error, and OFDM Power displays

Modulation Params | Advanced Params | Data Range | AnalysisTime | Trace | **Scale** | Prefs


Zoom  
Scale: 3  
Vertical Position: 0  
Horizontal Position: 0

Scale tab for OFDM Constellation display

Settings	Description
Vertical	Controls the vertical position and scale of the trace display.
Scale	Changes the vertical scale of the graph.
Position	Adjusts the reference level away from top of the graph.
Autoscale	Resets the scale of the vertical axis to contain the complete trace.
Subcarrier	Controls the scale of the subcarrier graph and position of the trace.
Scale	Specifies how many subcarriers are displayed horizontally.
Position	Specifies the subcarrier that appears at the left edge of the subcarrier graph.
Autoscale	Resets the scale of the horizontal axis to contain the complete trace.
Symbols	Controls the scale of the Symbols graph.
Scale	Specifies the number of symbols that appear in the symbols graph.
Position	Specifies the symbol that appears at the left edge of the Symbols graph.
Autoscale	Resets the scale and position settings to optimize the display.
Auto	When Auto is checked, the scale and position values for the Symbols graph are automatically adjusted to maintain the optimal display.
Zoom	Sets the Constellation display size and position.
Scale	Sets the magnification value for the Constellation display.
Vertical Position	Sets the vertical location of the Constellation display within the graph. Range is -3.7 to +3.7.
Horizontal Position	Sets the horizontal location of the Constellation display within the graph. Range is -3.7 to +3.7.

## Prefs Tab - OFDM

The Prefs tab enables you to change appearance characteristics of the OFDM Analysis displays. Not all settings on the Prefs tab shown below appear for every OFDM display.



The screenshot shows the 'Prefs' tab in the OFDM Analysis software. The tab is selected, and the settings are as follows:

- Time units: Symbols
- Freq units: Subcarrier
- Radix: Binary
- Show graphs: Both (selected), Subcarriers, Symbols
- Show graticule: ☒
- Show marker readout: ☒

Settings	Description
Time units	Specifies whether the displayed time units are seconds or symbols.
Freq units	Specifies whether the displayed frequency units are frequency (Hz) or subcarrier channel.
Radix	Specifies whether symbol values are displayed in binary or hex format (for example, in the Symbol Table or markers readouts).
Show graphs	Specifies which graph types are displayed.
Both	Displays both the Subcarrier and Symbol graphs.
Subcarriers	Displays only the subcarrier graph.
Symbols	Displays only the symbol graph.
Show graticule	Displays or hides the graticule in the graphs.
Show marker readout	Displays or hides the marker readouts in the graphs.

## Overview

The Pulsed RF option (SVPH-SVPC) allows you to take measurements that provide deep insight into pulse train behavior. You can define and analyze unique pulse characteristics in the time and frequency domains and gain additional insight into the performance of Radar or EW subsystems. The Pulse Cumulative Histogram and Pulse Cumulative Statistics Table accumulate results over multiple acquisitions. The remaining Pulse displays show results for the current acquisition. You can use cross-correlated markers to pinpoint events in one display and debug in other displays.

The displays in Pulsed RF (Setup > Displays > Pulsed RF) are:

- [Cumulative Histogram](#)
- [Cumulative Statistics](#)
- [Pulse-Ogram™](#)
- [Pulse Statistics](#)
- [Pulse Table](#)
- [Pulse Trace](#)

### Pulse Measurements

The analyzer takes the following pulse measurements.

Measurement	Description
Average ON Power	The average power transmitted during pulse on.
Peak Power	Maximum power during pulse on.
Average Transmitted Power	The average power transmitted, including both the time the pulse is on and the time it is off, and all transition times.
Pulse Width	The time from the rising edge to the falling edge at the -3 dB / -6 dB level (50%) of the user selected 100% level. Level is user selectable for Volts or Watts.
Rise Time	The time required for a signal to rise from 10% to 90% (or 20% to 80%) of the user selected 100% level.
Fall Time	The time required for a signal to fall from 90% to 10% (or 80% to 20%) of the user selected 100% level.
Repetition Interval	The time from a pulse rising edge to the next pulse rising edge.
Repetition Rate	The inverse of repetition interval.
Duty Factor (%)	The ratio of the width to the pulse period, expressed as a percentage.
Duty Factor (Ratio)	The ratio of the pulse width to the pulse period.

Measurement	Description
Ripple	<p>Ripple is the peak-to-peak ripple on the pulse top. It does not include any preshoot, overshoot, or undershoot. By default, the first 25% and the last 25% of the pulse top is excluded from this measurement to eliminate distortions caused by these portions of the pulse.</p> <p>If the Amplitude units selected in the Amplitude panel (affects all amplitude measurements for the analyzer) are linear, the Ripple results will be in %Volts. For log units, the Ripple results will be in %Watts. The default for the general Units control is dBm, so the Ripple results default is %Watts.</p> <p>See also <a href="#">Ripple (see page 886)</a>.</p>
Ripple dB	The Ripple measurement expressed in dB.
Droop	Droop is the power difference between the beginning and the end of the pulse on time. A straight-line best fit is used to represent the top of the pulse. The result is a percentage referenced to the Average ON Power.
Droop dB	The Droop measurement expressed in dB.
Overshoot	The amount by which the signal exceeds the 100% level on the pulse rising edge. Units are %Watts or %Volts.
Overshoot dB	The Overshoot measurement expressed in dB.
Pulse-ref-Phase Difference	The phase difference between the current pulse and the first pulse in the analysis window. The instantaneous phase is measured at a user-adjustable time following the rising edge of each pulse.
Phase Difference	The time interval by which one wave leads or lags another.
Pulse-ref Freq Difference	The difference between the frequency of the current pulse and frequency of the previous pulse. The instantaneous frequency is measured at a user-adjustable time following the rising edge of each pulse.
RMS Freq Error	The RMS Frequency Error measurement is the RMS average of the Freq Error vs. Time trace, computed over the Measurement Time.
Max Freq Error	The maximum frequency error is the difference between the measured carrier frequency of the signal and the user-selected center frequency of the analyzer.
RMS Phase Error	The RMS Phase Error measurement is the RMS average of the Phase vs Time trace, computed over the Measurement Time.
Max Phase Error	The phase is measured at each point during the pulse on time. The phase error for each point is the difference between the measured phase value and the calculated ideal phase value. After the phase error is calculated for all points in the acquisition record, the largest error in the positive direction and the largest in the negative direction are determined. Whichever of these two values has the greater absolute value is designated the Max Phase Error.
Freq Deviation	The Frequency Deviation measurement is the difference between the maximum and minimum measured values of the signal frequency during the Measurement Time.
Phase Deviation	The Phase Deviation is the difference between the maximum and minimum Phase values measured during the on time of a pulse.
Impulse Response Amplitude	The difference in dB between the levels of the main lobe and highest side lobe.
Impulse Response Time	The difference in time between the main lobe and highest side lobe.
Time	This is the time in seconds relative to the time reference point in the first acquisition record in the data set.

Measurement	Description
Absolute Frequency	The absolute pulse frequency measured at a point specified by the user. The measurement includes carrier frequency as well. The measurement point should be within the pulse width, starting from the 50% point.
Pulse-Pulse Frequency Difference	The difference between the frequency of the current pulse and frequency of the previous pulse. The instantaneous frequency is measured at a user-adjustable time following the rising edge of each pulse.
Pulse-Pulse Phase Difference	The phase difference between the selected pulse and the first pulse in the analysis window. The instantaneous phase is measured at a user-adjustable time following the rising edge of each pulse.
Delta Frequency (Non-chirped pulse)	<p>The Delta Frequency measurement is the difference from the measurement frequency to each pulse frequency. Pulse frequency is calculated across the time defined by the Frequency Domain Linearity setting in the Define tab.</p> <p>The measurement is available for modulation types CW (Constant Phase), CW (Changing phase), and Other (manual) setting in the Freq Estimation tab.</p> <p>The measurement is not specified for chirp or other signals and no answer is returned when frequency estimation is set to Chirp.</p> <p>If frequency estimation is set to Other, then Frequency Offset must be set to 0 Hz and the Range can be set to <math>\pm 40\%</math> of the acquisition bandwidth.</p> <p>A least-square fit of slope of phase vs. time over the measurement period is used for the measurement of the individual pulse frequency. Frequency difference is calculated as the difference between the reference frequency and the calculated frequency of the pulse.</p>


## Cumulative Histogram Display

This histogram display shows the numerical distribution of the various pulse measurement results accumulated over multiple frames (in Fast Frame mode) and acquisitions. You can see the pulse count in a chosen bin by choosing the bin number or the X value (of the chosen result). Pulses that do not lie within the chosen Min/Max are shown as outliers.

To show the Cumulative Histogram display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **Pulse Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **Cumulative Histogram** icon or select the icon and click **Add**. The icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the Cumulative Histogram display.
6. If you are analyzing a stored data file, press the **Replay** button to take measurements on the recalled acquisition data file.

## Elements of the display





Item	Display element	Description
1	Result	Drop down list of measurements. The results of the selected measurement in this Cumulative Histogram display will also show in the Pulse Statistics display and be highlighted in the Pulse Table display. All results will be available for view when Auto mode is enabled in the <a href="#">Histogram Settings button (see page 386)</a> window. Only selected results will be available for view when Manual mode is enabled in the Histogram Settings window.
2	X	A value of the selected result where the pulse indicator is positioned. Changing X will automatically change the bin number to the one that contains the X value.
3	Bin	Bin number where the indicator is positioned. Changing this number will change the value of X to the middle of the selected bin.
4	Pulses in Bin	Number of pulses in the selected bin.
5	Total Pulses	Total number of pulses analyzed in the current acquisition.
6	Vertical	Sets the vertical range.
7	Autoscale	Sets the axes to values for clear visibility of trace points.
8	Horizontal offset and scale	Controls that specify the offset and scale on the horizontal axis.
9	Clear button	Clears results from the display and starts a new measurement.
10	Outliers	Number of pulses that have measurement values outside of the maximum and minimum values indicates the outliers below the lower limit and those exceeding the upper limit.
11	Histogram Table button	Contains the Bin number, Bin Range, and Pulses in bin for the chosen measurement.

Bin Number	Bin Range	Pulses in Bin
1	196.00 MHz - 198.42 MHz	2
2	198.42 MHz - 200.84 MHz	1
3	200.84 MHz - 203.26 MHz	0
4	203.26 MHz - 205.68 MHz	0
5	205.68 MHz - 208.10 MHz	0
6	208.10 MHz - 210.52 MHz	0
7	210.52 MHz - 212.94 MHz	1
8	212.94 MHz - 215.36 MHz	0
9	215.36 MHz - 217.77 MHz	0
10	217.77 MHz - 220.19 MHz	0
11	220.19 MHz - 222.61 MHz	0
12	222.61 MHz - 225.03 MHz	0
13	225.03 MHz - 227.45 MHz	0
14	227.45 MHz - 229.87 MHz	0
15	229.87 MHz - 232.29 MHz	0

## Cumulative Histogram display settings

**Main menu:** Setup > Settings

**Favorites Toolbar:** 


The Settings control panel tabs for the Cumulative Histogram display are shown in the following table.

Settings tab	Description
<a href="#">Params</a>	Specifies several parameters that control how pulses are counted and defined.
<a href="#">Define</a>	Specifies parameters that control where measurements are taken on a pulse.
<a href="#">Levels</a>	Specifies parameters that control the method and levels used to calculate some pulse values.
<a href="#">Freq Estimation</a>	Specifies the reference used for computing frequency error.
<a href="#">Scale</a>	Specifies the vertical and horizontal scale settings.
<a href="#">Prefs</a>	Specifies whether or not certain display elements are shown.


### Histogram Settings button

This button is located on the Pulse Cumulative Histogram Settings control panel. Click this button to open a window where you can select which measurement results will be available in the Result drop down menu. You can select to use Auto or Manual mode.

**Manual mode for histogram settings.** In **Manual** mode, the histogram computation is done for the selected measurement results. You set the maximum and minimum values. The **Bin** field represents the total number of bins used in the histogram.



**Auto mode for histogram settings.** In **Auto** mode, the histogram computation is done for all measurement results. Minimum and maximum limits are chosen automatically based on the first 10,000 pulses. The **Bin** field represents the total number of bins used in the histogram.



### Restore Defaults button


This button is located on the Pulse Cumulative Histogram Settings control panel. Click this button to set the Cumulative Histogram parameters to their default values.

## Cumulative Statistics Table display



This display is a statistics table that provides information on Pulse Count, Max, Max TimeStamp, Min, Min TimeStamp, Peak to Peak, Average, and Standard Deviation over different acquisitions.

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **Pulsed RF** in the **Measurements** box.
4. In the Available displays box, double-click the **Cumulative Statistics** icon or select the icon and click **Add**. The icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the Cumulative Statistics display.
6. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

## Elements of the display



Statistics	Avg ON	Width	Rep Int	
<b>Pulse Count</b>	<b>16</b>	<b>16</b>	<b>15</b>	
Max	-1.36 dBm	100.00345 ns	4.90990 us	
Max TimeStamp	8/27/2008 7:20:52.87	8/27/2008 7:20:52.87	8/27/2008 7:20:52.87	
Min	-1.41 dBm	99.37347 ns	2.90983 us	
Min TimeStamp	8/27/2008 7:20:52.87	8/27/2008 7:20:52.87	8/27/2008 7:20:52.87	
Peak to Peak	-46.74 dBm	629.97429 ps	2.00008 us	
Avg	-1.38 dBm	99.63989 ns	3.31002 us	
Std Dev	-55.91 dBm	168.95610 ps	799.79884 ns	

Display element	Description
Measurement	<p>The row across the top of the table shows the selected measurement.</p> <p>You can right click on this row to access this menu to edit the table:</p>  <p>Select Add Measurements to open this window to select measurements:</p> 
Maximum	Maximum value of the measurement across acquisitions with a time stamp.
Maximum TimeStamp	This time stamp denotes the time the maximum value of the measurement occurred across acquisitions.
Minimum	Minimum value of the measurement across acquisitions with a time stamp.
Minimum TimeStamp	This time stamp denotes the time the minimum value of the measurement occurred across acquisitions.
Average	Average value of the measurement values accumulated over multiple acquisitions until the current acquisition.
Peak to peak	This is the difference between Maximum and Minimum value of the measurement
Standard deviation	Standard deviation of the measurement that has a population equal to the Pulse Count value.
Clear button	Clear the results and starts a new measurement.

---

**NOTE.** When analysis is done on only one pulse, the Standard Deviation is zero. Log10 (0) is not defined and thus is represented by a “–” when the unit is dB.

---

## Cumulative Statistics Table display settings

**Main menu:** Setup > Settings

**Favorites Toolbar:** 

The Settings control panel tabs for the Cumulative Statistics Table display are shown in the following table.

Settings tab	Description
<a href="#">Measurements</a>	Specifies which measurements to show in the table. Click the box(es) next to the measurement(s) you want to show. You can also click the Select All and Clear All buttons.
<a href="#">Params</a>	Specifies how pulses are counted and defined.
<a href="#">Define</a>	Specifies parameters that control where measurements are taken on a pulse.
<a href="#">Levels</a>	Specifies parameters that control the method and levels used to calculate some pulse values.
<a href="#">Freq Estimation</a>	Specifies the reference used for computing frequency error.
<a href="#">Prefs (see page 416)</a>	Specifies whether or not certain display elements are shown.

### Restore defaults button

This button is located on the Cumulative Statistics Table Settings control panel. Sets the Cumulative Statistics Table parameters to their default values.

## Pulse-Ogram display

The Pulse-Ogram™ display shows a stacked view of radar pulses when the analyzer is using fast-frame mode. The fast-frame captures IQ samples around a pulse when triggered. Each fast frame is configured to capture few IQ samples before rise-time, and after fall-time of a single pulse, and a timestamp associated with that pulse. With this information, the different fast-frame captures are stacked one after the other and displayed as Time v/s Time, and the corresponding spectrum information as Frequency v/s Time. The stacking allows for overlap of adjacent frames. The user can also select the range of frames for viewing in the display. This enables the user to study various aspects of pulse such as pulse width, reflections, rise-time, fall-time, etc.

### Marker correlation in Pulse-Ogram


At the end of an acquisition, the TOV and Spectrum show the last frame acquired. When we place a marker in Pulse-Ogram, the marker would not move in TOV and Spectrum unless you bring the marker to

the last frame in Pulse-Ogram. Similarly, if marker is moved in TOV and Spectrum, then the marker in Pulse-Ogram will move to the last frame automatically.

If you want the marker movement in Pulse-Ogram to change the pulse indicator in the Pulse Table or Pulse Trace display, then you must add the Pulse Statistics display in Time trend mode. Movement of the marker now in the Pulse Statistics display or Pulse-Ogram display will change the pulse indicator position too, and therefore the appropriate pulse will be shown in the Pulse Trace display.

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **Pulsed RF** in the **Measurements** box.
4. In the Available displays box, double-click the **Pulse-O-gram** icon or select the icon and click **Add**. The icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the Pulse-O-gram display.
6. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

## Elements of the display



Display element	Description
Time vs Time	This view has the IQ data captured in the fast frames in a stacked view (with overlap).
Frequency vs Time	This view has the corresponding spectrum of the signal captured.
Frame offset	Controls the number of frames that are offset in the display. The starting frame will be frame offset + 1.
Frame scale	Controls the number of frames that can be seen in the display.
Frame count	Total number of fast frames in the acquisition.
Frame #	Indicates the frame number in which the marker is present. This option will only appear when the marker is added.
Plot type	Shows Stacked and is not selectable.
Display	Select to view Time vs Time or Frequency vs Time or Both.
RBW	Shows the resolution bandwidth for the Frequency vs Time view.

## Pulse-Ogram display settings

**Main menu:** Setup > Settings

**Favorites Toolbar:** 

The Settings control panel tabs for the Pulse-Ogram display are shown in the following table.

Settings tab	Description
<a href="#">Analysis</a>	Specifies settings related to analysis of the signal.
<a href="#">Traces</a>	Specifies the display characteristics of displayed traces.
<a href="#">Scale</a>	Specifies the parameters related to fast frame.
<a href="#">Prefs</a>	Specifies marker readout options.

## Pulse Table display

The Pulse Table lists selected measurements in a spreadsheet format, showing the pulse numbers and all the results for each measurement on all the detected pulses. Pulses are numbered from one.



Freq Error: -4.208 kHz (Auto)		Freq: 999.9957918 MHz					
Pulse #	Avg ON	Width	Rise	Rep Int	RMS Ø Err	Peak	Avg Tx
1	-1.40 dBm	100.00345 ns	7.99554 ns	4.90948 us	802.20618 °	-0.85 dBm	-18.32 dBm
2	-1.38 dBm	99.52590 ns	7.83859 ns	2.91027 us	278.82507 °	-0.84 dBm	-16.10 dBm
3	-1.37 dBm	99.73721 ns	7.80641 ns	2.91002 us	280.49780 °	-0.70 dBm	-16.10 dBm
4	-1.36 dBm	99.85104 ns	7.68201 ns	2.91014 us	284.17639 °	-0.62 dBm	-16.08 dBm
5	-1.37 dBm	99.50647 ns	7.98586 ns	2.91022 us	287.90259 °	-0.64 dBm	-16.08 dBm
6	-1.40 dBm	99.67329 ns	8.03208 ns	4.90946 us	806.15570 °	-0.73 dBm	-18.32 dBm
7	-1.36 dBm	99.91533 ns	7.84547 ns	2.91045 us	272.54922 °	-0.62 dBm	-16.08 dBm
8	-1.36 dBm	99.55097 ns	7.48575 ns	2.90986 us	276.32895 °	-0.78 dBm	-16.08 dBm
9	-1.39 dBm	99.41364 ns	7.65567 ns	2.91011 us	280.42859 °	-0.87 dBm	-16.11 dBm
10	-1.36 dBm	99.56028 ns	7.80557 ns	2.91018 us	284.14838 °	-0.74 dBm	-16.07 dBm
11	-1.40 dBm	99.63683 ns	8.02328 ns	4.90990 us	810.08453 °	-0.86 dBm	-18.31 dBm
12	-1.38 dBm	99.55033 ns	7.95047 ns	2.91008 us	268.64148 °	-0.74 dBm	-16.10 dBm
13	-1.37 dBm	99.37347 ns	7.73742 ns	2.90983 us	272.31412 °	-0.68 dBm	-16.09 dBm
14	-1.36 dBm	99.58830 ns	7.79934 ns	2.91000 us	275.92587 °	-0.77 dBm	-16.08 dBm
15	-1.37 dBm	99.59512 ns	7.74599 ns	2.91024 us	279.55917 °	-0.53 dBm	-16.08 dBm
16	-1.41 dBm	99.75660 ns	8.28168 ns	-- s	814.49548 °	-0.90 dBm	-- dBm

## Displaying the Pulse Table

1. Press the **Displays** button or select **Setup > Displays**.
2. Select **Pulsed RF** in the Measurements box.
3. **Double-click Pulse Table** in the **Available displays** box to add the display to the Selected displays box.
4. Click **OK**.

## Selecting the Measurements to Show

1. With the Pulse Table selected, press the **Settings** button.
2. In the Pulse Table Settings control panel, select the **Measurements** tab.

Measurements Params Define Levels Freq Estimation Prefs

Show in Pulse Table:

- ☒ Average ON Power
- ☐ Peak Power
- ☒ Average Transmitted Power
- ☒ Pulse Width
- ☐ Rise Time

Select all

Clear all

3. Select the measurements you wish to take from the list of measurements or click **Select all** to choose all measurements.
4. Click the close box ( ) to remove the Settings control panel.

[Changing the Pulse Table Display Settings \(see page 394\)](#)

## Pulse Table display settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The Settings control panel tabs for the Pulse Table Display are shown in the following table.

Settings tab	Description
<a href="#">Measurements</a>	Selects the measurements to be show in the Pulse Table.
<a href="#">Params</a>	Specifies several parameters that control how pulses are counted and defined.
<a href="#">Define</a>	Specifies parameters that control where measurements are taken on a pulse.
<a href="#">Levels</a>	Specifies parameters that control the method and levels used to calculate some pulse values.
<a href="#">Freq Estimation</a>	Specifies the reference used for computing frequency errors.

### Restore defaults button

This button is located on the Pulse Table Settings control panel. Sets the Pulse Table parameters to their default values.


### Clearing results

If you want to clear the Pulse Table results for a new acquisition, open the Time Overview window and select Autoscale. This causes the Pulse Table to refresh.

## Pulse Trace display

The Pulse Trace display shows one measurement result and a trace graph illustrating that measurement for a selected pulse number. You can also choose to display arrows and lines in the graph that illustrate where on the pulse the measurement is being taken.

## Elements of the Pulse Trace Display



Item	Display element	Description
1	Check mark indicator	The check mark indicator in the upper, left-hand corner of the display shows when the Pulse Trace display is the optimized display.  <b>NOTE.</b> When <i>Best for multiple windows</i> is selected in the <i>Amplitude control</i> panel's <i>RF &amp; IF Optimization</i> control, none of the measurement displays shows a checkmark, as there is not a single optimized measurement.
2	Result	Use this list to select the measurement to show. The measurement chosen here selects the same result to be displayed in the Statistics view and highlighted in the Table view. Selecting a result in any of these views causes the same result to be selected in all of them.
3	Pulse	Selects which pulse result is shown. Like the Result, this selection is shared with the Statistics and Table views. The maximum number of pulses that can be measured is limited to 10000.
4	Pulse threshold indicator	This green triangle indicates the power threshold used to detect pulses. See Settings > Params > Power threshold to detect pulses.
5	Autoscale	Set the axes to values that show all trace points.
6	Horizontal offset and scale	Located along the bottom edge of the trace display, these controls specify the offset and scale on the horizontal axis.
7	Top of graph adjustment	Sets the power level shown at the top of the graph. If the number is greater than the Ref Level, a white line will appear in the graph to indicate the Ref Level.
(not shown)	Units	Sets the global amplitude units for all the views in the analysis window. This will change the amplitude selection in the Units tab of the Amplitude control panel.
8	Vertical scale	Sets the vertical scale value.

[Changing the Pulse Trace Display Settings \(see page 396\)](#)

## Pulse Trace display settings

**Main menu:** Setup > Settings

**Favorites Toolbar:** 

The Setup settings for the Pulse Trace display are shown in the following table.

Settings tab	Description
<a href="#">Params (see page 402)</a>	Specifies several parameters that control how pulses are counted and defined.
<a href="#">Define (see page 404)</a>	Specifies parameters that control where measurements are taken on a pulse.
<a href="#">Levels (see page 409)</a>	Specifies parameters that control the method and levels used to calculate some pulse values.
<a href="#">Freq Estimation (see page 410)</a>	Specifies the reference used for computing frequency error.
<a href="#">Scale (see page 414)</a>	Specifies the vertical and horizontal scale settings.
<a href="#">Prefs (see page 416)</a>	Specifies whether or not certain display elements are shown.

### Restore defaults button


This button is located on the Pulse Trace Settings control panel. Sets the Pulse Trace display parameters to their default values.

## Pulse Statistics display


The Pulse Statistics view displays a plot of a pulse measurement's values for every pulse in the analysis period. For example, the Pulse Statistics display will show the Rise Time measurement for each of 30 pulses, with rise time on the Y axis and pulse number on the X axis. Alternatively, the Statistics Display can show an FFT trace for the values of a measurement over all the pulses analyzed. Numeric readouts of Pulse Count, Max, Min, Peak to Peak, Average, and Standard Deviation in this display summarize results for the selected pulse measurement.

### Elements of the Pulse Statistics Display


The following images show the display when different plot types are selected. The table following these images explains the elements of these displays.




The above image shows an FFT plot.



The above image shows a Trend plot.



The above image shows a Time Trend plot.



The above image shows a Histogram plot.

Item	Display element	Description
1	Result	Use this list to select which measurement statistics to display. The measurement chosen here selects the same result to be displayed in the Pulse Trace display and the Pulse Table display. Selecting a result in any of these views causes the same result to be selected in all of them.
2	Results indicators	(The indicators shown depend on the plot type selection. The values shown are plot indicator (Item 9) values.)
	Pulse	Pulse indicator for Trend or Time Trend plots that indicates the pulse selected by the Pulse setting.
	Freq	Pulse indicator for FFT plots that marks the trace point at the selected frequency.

Item	Display element	Description																																																
	X	For Histogram plots: A value of the selected result where the pulse indicator is positioned. Changing X will automatically change the bin number to the one that contains the X value.																																																
	Bin	For Histogram plots: Bin number where the indicator is positioned. Changing this number will change the value of X to the middle of the selected bin.																																																
	Pulses in Bin	For Histogram plots: Number of pulses in the selected bin.																																																
	Total Pulses	For Histogram plots: Total number of pulses analyzed in the current acquisition.																																																
3	Vertical	Sets the vertical range.																																																
4	Autoscale	Sets the axes to values for clear visibility of trace points.																																																
5	Histogram Table button	Contains the Bin number, Bin range, and Pulses in bin for the chosen measurement.																																																
	<table border="1"> <thead> <tr> <th>Bin Number</th><th>Bin Range</th><th>Pulses in Bin</th></tr> </thead> <tbody> <tr><td>1</td><td>196.00 MHz - 198.42 MHz</td><td>2</td></tr> <tr><td>2</td><td>198.42 MHz - 200.84 MHz</td><td>1</td></tr> <tr><td>3</td><td>200.84 MHz - 203.26 MHz</td><td>0</td></tr> <tr><td>4</td><td>203.26 MHz - 205.68 MHz</td><td>0</td></tr> <tr><td>5</td><td>205.68 MHz - 208.10 MHz</td><td>0</td></tr> <tr><td>6</td><td>208.10 MHz - 210.52 MHz</td><td>0</td></tr> <tr><td>7</td><td>210.52 MHz - 212.94 MHz</td><td>1</td></tr> <tr><td>8</td><td>212.94 MHz - 215.36 MHz</td><td>0</td></tr> <tr><td>9</td><td>215.36 MHz - 217.77 MHz</td><td>0</td></tr> <tr><td>10</td><td>217.77 MHz - 220.19 MHz</td><td>0</td></tr> <tr><td>11</td><td>220.19 MHz - 222.61 MHz</td><td>0</td></tr> <tr><td>12</td><td>222.61 MHz - 225.03 MHz</td><td>0</td></tr> <tr><td>13</td><td>225.03 MHz - 227.45 MHz</td><td>0</td></tr> <tr><td>14</td><td>227.45 MHz - 229.87 MHz</td><td>0</td></tr> <tr><td>15</td><td>229.87 MHz - 232.29 MHz</td><td>0</td></tr> </tbody> </table>		Bin Number	Bin Range	Pulses in Bin	1	196.00 MHz - 198.42 MHz	2	2	198.42 MHz - 200.84 MHz	1	3	200.84 MHz - 203.26 MHz	0	4	203.26 MHz - 205.68 MHz	0	5	205.68 MHz - 208.10 MHz	0	6	208.10 MHz - 210.52 MHz	0	7	210.52 MHz - 212.94 MHz	1	8	212.94 MHz - 215.36 MHz	0	9	215.36 MHz - 217.77 MHz	0	10	217.77 MHz - 220.19 MHz	0	11	220.19 MHz - 222.61 MHz	0	12	222.61 MHz - 225.03 MHz	0	13	225.03 MHz - 227.45 MHz	0	14	227.45 MHz - 229.87 MHz	0	15	229.87 MHz - 232.29 MHz	0
Bin Number	Bin Range	Pulses in Bin																																																
1	196.00 MHz - 198.42 MHz	2																																																
2	198.42 MHz - 200.84 MHz	1																																																
3	200.84 MHz - 203.26 MHz	0																																																
4	203.26 MHz - 205.68 MHz	0																																																
5	205.68 MHz - 208.10 MHz	0																																																
6	208.10 MHz - 210.52 MHz	0																																																
7	210.52 MHz - 212.94 MHz	1																																																
8	212.94 MHz - 215.36 MHz	0																																																
9	215.36 MHz - 217.77 MHz	0																																																
10	217.77 MHz - 220.19 MHz	0																																																
11	220.19 MHz - 222.61 MHz	0																																																
12	222.61 MHz - 225.03 MHz	0																																																
13	225.03 MHz - 227.45 MHz	0																																																
14	227.45 MHz - 229.87 MHz	0																																																
15	229.87 MHz - 232.29 MHz	0																																																
6	Plot type selector	Select Trend, Time Trend, FFT, or Histogram as plot type.																																																
7	Horizontal offset	Adjusts the horizontal offset.																																																
8	Statistics summary	Display of measurement statistics for the selected result.																																																
9	Pulse indicator	For Trend and Time Trend plot types, this indicates the pulse selected by the Pulse setting. For the FFT plot type, this indicator marks the trace point at the selected frequency. For Histogram plot types, this indicator marks the selected results bin.																																																
10	Scale	Adjusts the horizontal scale.																																																

[Changing the Pulse Statistics Display Settings \(see page 399\)](#)

## Pulse Statistics settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the Pulse Statistics display are shown in the following table.

Settings tab	Description
<a href="#">Params (see page 402)</a>	Specifies several parameters that control how pulses are counted and defined.
<a href="#">Define (see page 404)</a>	Specifies parameters that control where measurements are taken on a pulse.
<a href="#">Levels (see page 409)</a>	Specifies parameters that control the method and levels used to calculate some pulse values.
<a href="#">Freq Estimation (see page 410)</a>	Specifies the reference used for computing frequency errors.
<a href="#">Scale (see page 414)</a>	Specifies the vertical and horizontal scale settings.
<a href="#">Prefs (see page 416)</a>	Specifies whether or not certain elements of the display are shown.

### Restore defaults button

This button is located on the Pulse Statistics Settings control panel. Sets the Pulse Statistics display parameters to their default values.

## Pulsed RF Measurement Settings

Some of the control panel tabs are shared by the Pulsed RF displays (Setup > Displays). Changing a setting in a shared tab changes that setting for all the Pulsed RF displays. The other control panel tabs are unique for each display. The following information explains both types.



### Common controls for pulsed RF displays

Settings tab	Description
<a href="#">Measurements (see page 401)</a>	Specifies which measurement results appear in the Cumulative Statistics Table and Pulse Table displays.
<a href="#">Params (see page 402)</a>	Specifies several parameters that control how pulses are counted and defined.
<a href="#">Define (see page 404)</a>	Specifies parameters that control where measurements are taken on a pulse.
<a href="#">Analysis (see page 411)</a> (Only Available for the Pulse-Ogram display)	Specifies parameters related to analysis of the signal.
<a href="#">Levels (see page 409)</a>	Specifies parameters that control the method and levels used to calculate some pulse values.
<a href="#">Freq Estimation (see page 410)</a>	Specifies the reference used for computing frequency errors.
<a href="#">Traces (see page 413)</a> (Only available for the Pulse-Ogram display)	Specifies the smooth points for the Time vs Time view and the detection method for the Frequency vs Time view.
<a href="#">Scale (see page 414)</a>	Specifies the vertical and horizontal scale settings.
<a href="#">Prefs (see page 416)</a>	Specifies whether or not certain elements of the display are shown.

## Measurements Tab

The Measurements tab is used to specify the measurements that appear in the Cumulative Statistics Table display and the Pulse Table display.

### Show in Cumulative Statistics Table

Checked measurements appear in the table.

### Select all


Click **Select all** to choose all measurements for display in the table.

### Clear all

Click **Clear all** to remove all measurements from the table display.

## Params Tab

The Params tab enables you to adjust several measurement parameters for Pulsed RF displays. Not all parameters show for all displays.



The screenshot shows the 'Params' tab selected in a software interface. The tab is part of a group including 'Define', 'Levels', 'Freq Estimation', 'Scale', and 'Prefs'. The 'Params' tab contains the following settings:

- Measurement Filter:** A dropdown menu set to 'Gaussian'.
- Power threshold to detect pulses:** A text input field set to '-10 dBc'.
- Bandwidth:** A text input field set to '10 MHz'.
- Minimum OFF time between pulses:** A text input field set to '100.000 ms'.
- Max number of pulses:** A checkbox is checked, and the text input field is set to '100'.

Setting	Description
Measurement Filter	Specify whether a filter is used to limit the bandwidth of the input signal.
Bandwidth	Sets the bandwidth of the measurement filter.
Power threshold to detect pulses	Specifies the level used for locating pulses in the data.
Minimum OFF time between pulses	Specifies the time the signal must fall below the power threshold for two pulses to be considered separate pulses.
Max number of pulses	Specifies the number of pulses to measure within the analysis time. (Only available for the Pulse Statistics, Pulse Trace, and Pulse Table displays.)

### Measurement Filter

Three choices are available for the measurement filter:

- **No Filter - Max BW:** The widest acquisition bandwidth available is used. The **Bandwidth** setting is disabled, but shows the value in use.
- **No Filter:** - This is the default. The Bandwidth control is enabled to specify an acquisition bandwidth.
- **Gaussian** - The Bandwidth control is enabled for you to specify a value. The instrument uses an acquisition bandwidth two times wider than the entered value.

### Power Threshold to Detect Pulses

Specifies the minimum power level the trace must exceed to be detected as a pulse. The range for this setting is: -3 to -70 dBc. The setting resolution is 1 dB. The default value is -10 dB.

### Minimum OFF time between pulses

Specifies the time the signal must fall below the power threshold for two pulses to be considered separate pulses. The minimum value for this setting is 1.000 ns.

### Max Number of Pulses

Only available for the Pulse Statistics, Pulse Trace, and Pulse Table displays.

If the Analysis Time contains fewer pulses than specified, the analyzer will measure all the pulse within the analysis time. If there are more pulses in the Analysis Time, than the specified number, the analyzer measures the specified number of pulses and ignores the rest. The setting resolution is: 1. If this setting is not checked, the analyzer will measure all pulses within the Analysis Time.

To determine the maximum number of pulses that can be analyzed, use the following equation:

$$\text{Max number of pulses that can analyzed} = \text{Pulse Rate} \times \text{capacity}$$

where:

- Pulse rate is the number of pulses per second (frequency).
- Capacity is a length of time which is displayed on the **Acquire > Sampling Parameters** tab.

Note that the maximum number of pulses is affected by several parameters. For example, measurement bandwidth affects the sample rate. The measurement algorithm also can reduce the maximum number of pulses that can be analyzed (by increasing the sample rate) based on the characteristics of the signal.

Additionally, when FastFrame is enabled, determining the maximum number of pulses is even more challenging. In FastFrame mode, the signal analyzer samples the signal around events of interest and ignores the signal between events of interest. Thus, if the instrument is only looking at pulses and ignoring the signal between pulses, the number of pulses that can be analyzed depends strongly on the characteristics of the pulse itself (for example, fewer wide pulses can be analyzed than narrow pulses, all other things being equal).

The Pulse Cumulative Statistics display provides statistics of pulses like Average, Standard Deviation, and Peak to Peak. Pulse Count does not have an upper limit for Pulse Cumulative Statistics. The Pulse Cumulative Histogram display provides information about the trend of the Pulse characteristics and outliers. This display does not support any upper limit or lower limit.

---

**NOTE.** In Fast Save mode, Pulse /Frame Count can go up to 200,000. This count also depends on the hard disk drive (HDD) capacity to store acquisitions.

The asterik (\*) around a pulse number indicates that it is a Fast Frame.

*All Pulse Analysis displays except the Pulse-Ogram update results only after analysis of all fast frames.*

---

## Define Tab

The Define tab enables you to specify parameters that control where measurements are made on a pulse. The settings available depend on the measurement selected. This tab is not available for the Pulse-Ogram display.



Measurements Params Define Levels Freq Estimation

Measurement(s):  
Impulse Response

☒ Apply ampl corrections  
Keep-out time (+/-): 0.000 s

Time method: Absolute

Ref (R): 100 %  
Start (S): 0.000 s  
Length (L): 1.00 us



The settings that appear on the Define tab are described below. They may vary according to the Measurement(s) selection.


### Freq-Domain Linearity

Measurements Params Define Levels Freq Estimation

Measurement(s):  
Freq-domain Linearity

Time method: Absolute

Ref (R): 100 %  
Start (S): 0.000 s  
Length (L): 1.00 us



Setting	Description
Time method	Specifies how the measurement's duration is determined. The choices are Absolute and Relative.
Absolute time method	
Ref (R)	Ref specifies the level along the pulse rising edge that is defined as the point from which Start time is counted. Choices: 50%, 60%, 70%, 80%, 90% 100%; Default: 100%
Start (S)	Start specifies the time the instrument waits after the rising-edge reference before starting to measure the pulse. The Start time is measured from the point along the pulse rising edge specified by the Ref setting. Start Range: $\pm 100$ ms; Resolution: 3 digits; inc/dec small: 1 ns, large: 1,2,5,10...; Default: 0
Length (L)	Length specifies the period of time that is used for pulse measurements. The measurement time begins at the Start point and continues for the amount of time specified by Length.
Relative time method	
Length	In the Relative time method, Length specifies the percentage of the top of the pulse that is used for measurements. The instrument automatically determines the pulse top. The measurement length is centered within the pulse ON time.

## Impulse Response

Measurements
Params
Define
Levels
Freq Estimation

Measurement(s):  
Impulse Response

☒ Apply ampl corrections  
Keep-out time (+/-): 0.000 s

Time method: Absolute
Ref (R): 100 %
Start (S): 0.000 s
Length (L): 1.00 us

Setting	Description
Apply ampl corrections	Enable/disable corrections that remove errors due to the window function and to the time offset of the side lobe.
Keep-out time (+/-)	The Keep-out time specifies a region that is ignored when the trace is analyzed for side lobes. The setting defines a region to the left and to the right of the center of the main lobe. Lobes that fall within this time region are not eligible to be the "highest side lobe".
Time method	Specifies how measurement parameters are determined. The choices are Absolute and Relative.
Absolute time method	
Ref (R)	Ref specifies the level along the pulse rising edge that is defined as the point from which Start time is counted. Choices: 50%, 60%, 70%, 80%, 90% 100%; Default: 100%
Start (S)	Start specifies the time the instrument waits after the rising-edge reference before starting to measure the pulse. The Start time is measured from the point along the pulse rising edge specified by the Ref setting. Start Range: $\pm 100$ ms; Resolution: 3 digits; inc/dec small: 1 ns, large: 1,2,5,10...; Default: 0
Length (L)	Amount of time that should be included in the measurement. The measurement time begins at the Start point and continues for the amount of time specified by Length.
Relative time method	
Length	In the Relative time method, Length specifies the percentage of the top of the pulse that is used for measurements. The instrument automatically determines the pulse top. The measurement length is centered within the pulse ON time.

### P-R F Diff, P-P F Diff, F Abs, P-R $\emptyset$ Diff, P-P $\emptyset$ Diff

Params

Define

Levels


Freq Estimation

Scale

Prefs

Measurement(s):  

P-R F Diff, P-P F Diff, F Abs, P...



Measurement point: 

500.000 ns

Setting	Description
Measurement point	Specifies the period in time after the 50% rising edge at which frequency and phase difference measurements are made.

## Ripple

Measurements	Params	Define	Levels	Freq Estimation
Measurement(s):				
Ripple		Time method: Relative	Ref (R): 100 %	
			Start (S): 0.000 s	
			Length (L): 50.0 %	




### Setting

### Description

**Length**  
Length specifies the percentage of the top of the pulse that is used for measurements. The instrument automatically determines the pulse top. The measurement length is centered within the pulse ON time. Only the Relative Time method is available for Ripple.

## Overshoot

Measurements	Params	Define	Levels	Freq Estimation
Measurement(s):				
Overshoot		Time method: Absolute	Ref (R): 100 %	
			Start (S): 0.000 s	
			Length (L): 1.00 us	




Setting	Description
Time method	Specifies how measurement parameters are determined. The choices are Absolute and Relative.
Absolute time method	
Ref (R)	Ref specifies the level along the pulse rising edge that is defined as the point from which Start time is counted. Choices: 50%, 60%, 70%, 80%, 90% 100%; Default: 100%
Start (S)	Start specifies the time the instrument waits after the rising-edge reference before starting to measure the pulse. The Start time is measured from the point along the pulse rising edge specified by the Ref setting. Start Range: $\pm 100$ ms; Resolution: 3 digits; inc/dec small: 1 ns, large: 1,2,5,10...; Default: 0
Length (L)	Amount of time that should be included in the measurement. The measurement time begins at the Start point and continues for the amount of time specified by Length.
Relative time method	
Ref	Ref specifies the level along the pulse rising edge that is defined as the point from which Start time is counted. Choices: 50%, 60%, 70%, 80%, 90% 100%; Default: 100%
Start	Start specifies the time the instrument waits after the rising-edge reference before starting to measure the pulse. The Start time is measured from the point along the pulse rising edge specified by the Ref setting. Start Range: $\pm 100$ ms; Resolution: 3 digits; inc/dec small: 1 ns, large: 1,2,5,10...; Default: 0
Length	In the Relative time method, Length specifies the percentage of the top of the pulse that is used for measurements. The instrument automatically determines the pulse top. The measurement length is centered within the pulse ON time.



## Levels Tab

Use the Levels tab to set parameters that control the method and levels used to calculate some pulse values.



Setting	Description
100% Level	Specifies the method used to determine the 100% level(s).
50% Level	Specifies the method used to determine the 50% level on the pulse.
Rise/Fall Levels	Select whether to use the 10% to 90% or 20% to 80% points (based on voltage level) to define the rise and fall times.

### 100% Level

Use the 100% Level settings to select the method used to determine the 100% level(s) used for calculating pulse parameters, for example, Rise, Fall, and Width.

The Pulse Average Amplitude defines the pulse top as the average of the values of all the points along the pulse top. This average is used as the 100% level, from which the 10, 20, 50, 80 and 90% levels are calculated. Pulse measurements are referenced against these various levels. For example, Rise is the time between the 10 and 90% (or 20 and 80%) levels on the rising edge of the pulse. When the Pulse Average Amplitude method is selected, the same 100% level is used for both rising and falling edges.

Because some RF pulse types have droop (a height difference between the beginning and ending points of the pulse top), the 100% percent level on the rising edge may not be equal to the 100% level on the falling edge. The Independent method of pulse point location is designed for pulses with different 100% levels at their rising and falling edges. The Independent method calculates the 100% level for the rising edge separately from the 100% level of the falling edge. As a result, the 10, 20, 50, 80 and 90% levels are also different for the rising and falling edges, allowing for more accurate measurements on pulses with droop.

### 50% Level

Select Voltage to use -6 dB as the 50% point. Select Power to use -3 dB as the 50% level.

## Freq Estimation Tab

Use the Freq Estimation tab to specify parameters used for determining frequency offset. This tab is not available for the Pulse-Ogram display.

The screenshot shows the 'Freq Estimation' tab selected. The 'Modulation type' dropdown is set to 'Linear Chirp'. The 'Pulse Frequency Reference' section contains two fields: 'Freq Offset' with a value of 169.1 Hz and 'Chirp Slope' with a value of 0.0000 Hz/us. Both fields have an 'Auto' checkbox checked to their right.

Setting	Description
Modulation type	Specifies which algorithm to use for estimating frequency error.
Pulse Frequency Reference	Specifies the method used to determine the pulse frequency error and if applicable, the chirp slope.
Auto	Selecting Auto causes the instrument to calculate the frequency offset and if applicable, the chirp slope.
Freq Offset	If Auto is not enabled, specify the value for frequency offset here. If Auto is enabled, the offset is set to zero and this readout displays the calculated frequency error.
Chirp BW	If Auto is not enabled, specify the value for Chirp Slope here. If Auto is enabled, this readout displays the calculated Chirp slope. This setting is used only when the modulation type is set to Linear Chirp.

### Modulation Type

Frequency estimation is performed by the instrument using selectable methods, depending on signal type. The selections for modulation type are CW (constant phase), CW (changing phase), Linear Chirp and Other. Select the method of frequency method based upon a best match to your signal based on the following descriptions:

- CW (constant phase): The signal is not designed to change in either frequency or phase during the measured pulse train.
- CW (changing phase): The signal does not change the carrier phase within each pulse, although it could change the phase from one pulse to another pulse. The signal is not designed to make frequency changes.
- Linear Chirp: The signal changes frequency in a linear manner during each pulse. The signal has the same carrier phase at the same time offset from the rising edge of the pulse.
- Other: The signal is not one of the listed types. You must manually enter the Frequency Offset value.

The following table maps the appropriate signal type selection with the signal characteristics.

Signature	Phase offset from one pulse to another	
	Zero	Any (unknown)
CW	CW Constant Phase	CW Changing Phase
LFM	Linear Chirp	N/A

## Analysis Tab

The Analysis tab is only available for the Pulse-Ogram display. It allows you to set parameters related to analysis of the signal. The settings vary depending on which spectrum analysis region you select.

Analysis Traces Scale Prefs

Measurement Bandwidth  
40 MHz

Frequency vs Time

Filter Shape: Kaiser (RBW)

Spectrum Analysis Region: ☒ Use Analysis Time settings  
☐ Pulse ON Time  
☐ Independent

Analysis Traces Scale Prefs

Measurement Bandwidth  
40 MHz


Frequency vs Time

Filter Shape: Kaiser (RBW)

Spectrum Analysis Region: ☐ Use Analysis Time settings  
☒ Pulse ON Time  
☐ Independent

Length: 100 %

Power threshold to detect pulses: -10 dBc



Analysis Traces Scale Prefs

Measurement Bandwidth  
40 MHz

Frequency vs Time

Filter Shape: Kaiser (RBW)

Spectrum Analysis Region: ☐ Use Analysis Time settings  
☐ Pulse ON Time  
☒ Independent


Start: 0.000 s

Length: 89.143 us

Setting	Description
Measurement bandwidth	Specifies the frequency range used by the measurement. This control is linked to the Bandwidth control of other Pulsed RF Displays. If <b>No Filter – Max BW</b> is selected in other displays, the control setting is disabled, but shows the maximum value possible. If <b>No Filter</b> or <b>Gaussian</b> is selected in other displays, then the Bandwidth control is also enabled in the Pulse-Ogram display.
Filter shape	Spectrum of the signal is windowed by the desired filter shape.
Use analysis time settings	Provides the complete analysis length as displayed in Time Overview.
Pulse on time	Analysis is done in the ON period of the data.
Length	Specifies the analysis length.
Power threshold to detect pulses	Specifies the level used for locating pulses in the data.
Independent	In Manual option, you can choose the analysis length of the desired type for the Freq vs Time view in the display.
Start	Specify the analysis offset. The default value is the offset in Time Overview.
Length	Specify the analysis length. The default value is the length in Time Overview.

## Traces Tab

The Traces tab is only available for the Pulse-Ogram display. It allows you to set the trace characteristics for the display.



Setting	Description
Smooth points	Shows the number of filter coefficients used for smoothening the noisy region for visual clarity.
Detection	Trace Detection is used to reduce the results of a measurement to the desired number of trace points.

### Detection

Trace Detection is used to reduce the results of a measurement to the desired number of trace points. For example, if the maximum number of trace points is 100,000 and a measurement over the selected analysis length yields 200,000 points, the measurement must decimate these 200,000 trace points by 2 to prevent exceeding the 100,000 trace point limit. Since only one value can be represented for each trace point, an algorithm must be used to select (detect) the appropriate value to use.

The results array from an analysis can be detected (or “decimated”) in a variety of ways. The number of results points produced for each trace point varies with both analysis length and trace length. For example, the frequency transform used for the Spectrum display produces just one output value for each desired trace point. In this case, the detection method chosen has no effect, as no decimation is required.

Increasing the Analysis Length (or for the Spectrum display, the Spectrum Length), causes the available detection method's output traces to differ from each other because they have a larger set of samples for the various detection methods to process.

The available detection methods are:

- **+Peak**: The highest value is selected from the results to be compressed into a trace point.
- **–Peak**: The lowest value is selected from the results to be compressed into a trace point.
- **Avg (VRMS)**: Each point on the trace is the result of determining the RMS Voltage value for all of the results values it includes. When displayed in either linear (Volts, Watts) or Log (dB,dBm), the correct RMS value results.
- **Sample**: The first value is selected from the set of results to be compressed into a trace point.

## Scale Tab

The Scale tab is only available for trace displays. It allows you to change the vertical and horizontal scale settings. Changing the scale settings changes how the trace appears on the display but does not change control settings such as Measurement Frequency. In effect, these controls operate like pan and zoom controls. Each display has different settings, as shown below.

The screenshot shows the Scale tab interface for the Pulse Statistics display. It features a tabbed menu at the top with 'Params', 'Define', 'Levels', 'Freq Estimation', 'Scale' (selected), and 'Prefs'. The main area is divided into two panels: 'Vertical' and 'Horizontal'. The 'Vertical' panel has a 'Scale' input set to '10.00', a 'Position' input set to '0.0000', an 'Autoscale' button, and a 'Reset Scale' button. The 'Horizontal' panel has a 'Scale' input set to '0.000', a 'Position' input set to '0.000', an 'Autoscale' button, and a 'Plot' dropdown menu currently showing 'Histogram'.

The above image shows the Scale tab for the Pulse Statistics display.

The screenshot shows the Scale tab interface for the Pulse Trace display. It features a tabbed menu at the top with 'Params', 'Define', 'Levels', 'Freq Estimation', 'Scale' (selected), and 'Prefs'. The main area is divided into two panels: 'Vertical' and 'Horizontal'. The 'Vertical' panel has a 'Scale' input set to '100.00 dB', a 'Position' input set to '0.00 dBm', an 'Autoscale' button, and a 'Reset Scale' button. The 'Horizontal' panel has a 'Scale' input set to '10.0 us', a 'Position' input set to '0.000 s', an 'Autoscale' button, and a 'Full scale' section with two radio buttons: 'Selected' (which is selected) and 'Max pulse'.

The above image shows the Scale tab for the Pulse Trace display.

The screenshot shows the Scale tab interface for the Pulse Cumulative Statistics display. It features a tabbed menu at the top with 'Params', 'Define', 'Levels', 'Freq Estimation', 'Scale' (selected), and 'Prefs'. The main area is divided into two panels: 'Vertical' and 'Horizontal'. The 'Vertical' panel has a 'Scale' input set to '10.00 %', a 'Position' input set to '0.0000 %', an 'Autoscale' button, and a 'Reset Scale' button. The 'Horizontal' panel has a 'Scale' input set to '7920000000000', a 'Position' input set to '0.000 dBm', an 'Autoscale' button, and a 'Reset Scale' button.

The above image shows the Scale tab for the Pulse Cumulative Statistics display.

Setting	Description
Vertical	Controls the vertical position and scale of the trace display.
Scale	Changes the vertical scale. The units for this setting depend on the statistic selected from the Result drop-down list in the Pulse Statistics display.
Position	Adjusts the Reference Level away from the top of the trace display. The units for this setting depend on the statistic selected from the Result drop-down list in the Pulse Statistics display.
Autoscale	Resets the scale of the vertical axis to contain the complete trace.
Horizontal	Controls the span of the trace display and position of the trace.
Scale	Allows you to change the span.
Position	Allows you to pan a zoomed trace.
Full Scale (Pulse Trace display only)	Specifies the Horizontal scale default.
Selected	Sets the horizontal scale default to be based on the result value for the currently-select pulse.
Max Pulse	Sets the horizontal scale default to be based on the largest value for the selected pulse measurement.
Autoscale	Resets the scale of the horizontal axis to contain the complete trace.
Plot (Pulse Statistics display only)	Specifies the FFT, Trend, Time Trend, or Histogram plot.
Reset Scale	Restores all settings to their default values.

Analysis

Traces

Scale

Prefs

Vertical

Frame Offset:

Frame Scale:

Horizontal

Time vs Time:

Position:

Scale:

Reset Scale

Frequency vs Time:

Start Freq:

Stop Freq:


Reset Scale

The above image shows the Scale tab for the Pulse-Ogram display.


Setting	Description
Vertical	Controls the vertical position and scale of the trace display.
Frame Offset	Display will start after the indicated frame number.
Frame Scale	Shows how many frames are displayed in both Time vs Time and Frequency vs Time views.
Horizontal (Time vs Time view)	Controls the span of the Time vs Time trace display and position of the trace.
Position	Allows you to pan a zoomed trace. The default value matches the offset of the acquisition.
Scale	Allows you to change the span. The default value matches the length of the acquisition.
Reset Scale	Restores the position and scale settings to default value.
Horizontal (Frequency vs Time view)	Controls the span of the Frequency vs Time trace display and position of the trace.
Start Freq	Allows you to set the starting frequency shown in the graph without changing analysis. The default value matches the highest frequency of the span.
Stop Freq	Allows you to set the stop frequency shown in the graph without changing analysis. The default value matches the highest frequency of the span.
Reset Scale	Restores the start frequency and stop frequency to default values.

## Prefs Tab

The Prefs tab is only available for Pulsed RF trace displays. It is not available for the table displays. It enables you to change parameters of the measurement display. Available parameters vary depending on the selected display.



The above image shows the Prefs tab for the Pulse Cumulative Histogram display.



The above image shows the Prefs tab for the Pulse-Ogram display.



The screenshot shows a software interface with a tabbed menu at the top containing 'Measurements', 'Params', 'Define', 'Levels', 'Freq Estimation', and 'Prefs'. The 'Prefs' tab is selected. Below the tabs, there is a single checkbox labeled 'Calculate statistics in linear scale (for results in log)' which is currently unchecked.

The above image shows the Prefs tab for the Pulse Cumulative Statistics display.

The screenshot shows a software interface with a tabbed menu at the top containing 'Params', 'Define', 'Levels', 'Freq Estimation', 'Scale', and 'Prefs'. The 'Prefs' tab is selected. Below the tabs, there are three checkboxes: 'Calculate statistics in linear scale (for results in log)' (unchecked), 'Show Marker readout in graph (selected marker)' (checked), and 'Show graticule' (checked).

The above image shows the Prefs tab for the Pulse Statistics display when Time Trend is the selected plot type. Trend and FFT plot types do not show the Show Marker readout selection.

The screenshot shows a software interface with a tabbed menu at the top containing 'Params', 'Define', 'Levels', 'Freq Estimation', 'Scale', and 'Prefs'. The 'Prefs' tab is selected. Below the tabs, there are three checkboxes: 'Calculate statistics in linear scale (for results in log)' (unchecked), 'Show graticule' (checked), and 'Show Marker readout in graph (selected marker)' (checked). To the right of the 'Show graticule' checkbox, there is a label 'Histogram readout:' followed by a dropdown menu set to 'Count', a label 'Bins:' followed by a text input field containing '10', and an 'Auto' checkbox which is checked.

The above image shows the Prefs tab for the Pulse Statistics display when Histogram is the selected plot type.

The screenshot shows a software interface with a tabbed menu at the top containing 'Params', 'Define', 'Levels', 'Freq Estimation', 'Scale', and 'Prefs'. The 'Prefs' tab is selected. Below the tabs, there are two checkboxes: 'Show graticule' (checked) and 'Show Marker readout in graph (selected marker)' (checked).

The above image shows the Prefs tab for the Pulse Trace display.

Setting	Description
Show graticule	Displays or hides the graticule in the trace display.
Show Marker readout in graph (Only available for Pulse Trace and Pulse-Ogram displays.)	When a marker is enabled, this setting displays or hides the maker readout, but not the maker itself, on Time Trend plots.
Histogram readout (Only available for Cumulative Histogram display and the Pulse Statistics display when Histogram is the plot type.)	Controls the parameters Histogram readout and Bins. Histogram readout can be set to either Count or %. Count indicates the number of hits that fell into each bin. % indicates percentage of the total count (for the acquisition) that fell into each bin.
Calculate statistics in linear scale (for results in log) (Only available for Pulse Statistics display.)	Checking this box allows for calculation of statistics in the linear domain (for example, the Power values in dB are converted to Watts (linear scale) and statistics are computed in Watts and then converted back to dB scale). This measurement will be observed only when this box is selected.  This selection only appears in the Pulse Statistics display for these measurements: Average ON Power, Average Transmitted Power, Peak Power, Impulse Response Amplitude, Droop dB, Overshoot dB, and Ripple dB.
Bins (Only available for Pulse Statistics display when Histogram is the plot type.)	Specifies how many "bins" or histogram bars the results are distributed into.
Auto (Only available for Pulse Statistics display when Histogram is the plot type.)	Sets the bin number to automatic default, which is 10.
Outlier readout (Only available for Cumulative Histogram display)	Controls the parameters Outlier readout and Bins. Outlier readout can be set to either Count or %. Count indicates the number of hits that fell into each bin. % indicates percentage of the total count (for the acquisition) that fell into each bin.
Trace points (Only available for the Pulse-Ogram display.)	Sets the number of trace points used for marker measurements and for results export.
Frame Info (Only available for the Pulse-Ogram display.)	Displays or hides the frame information in the display.

The statistics can be calculated in the linear domain as well the log

Average ON Power, Average Transmitted Power, Peak Power, Impulse Response Amplitude, Droop dB, Overshoot dB, Ripple dB, the statistics can be calculated in linear domain as well, i.e. the Power values in dB are converted to watts (linear scale) and statistics are computed in watts and then converted back to dB scale. This measurement will be observed only when the Calculate statistics in linear scale (for results in log) is selected.

## EMC accessories

Tektronix has accessories for EMC pre-compliance testing available to you. The following topics are presented to assist you with using these accessories to perform tests.

- [Radiated tests introduction \(see page 420\)](#)
- Antennas and radiated test accessories
  - [EMI-BICON-ANT biconical antenna \(see page 422\)](#)
  - [EMI-CLP-ANT Log Periodic Dipole Array antenna \(see page 425\)](#)
  - [EMI-PREAMP preamplifier \(see page 427\)](#)
  - [EMI-TRIPOD antenna tripod \(see page 424\)](#)
- How to set up a radiated pre-compliance test for
  - [30 MHz to 300 MHz \(see page 428\)](#)
  - [300 MHz to 1 GHz \(see page 431\)](#)
- [Conducted tests introduction \(see page 433\)](#)
- Conducted test accessories
  - [EMI-LISN50UH-US \(see page 436\)](#)
  - [EMI-LISN50UH-GB \(see page 436\)](#)
  - [EMI-LISN50UH-EU \(see page 436\)](#)
- [How to set up a conducted pre-compliance test with LISN \(see page 436\)](#)
- Other accessories
  - [CABLE-1M, CABLE-3M, CABLE-5M \(see page 437\)](#)
  - [EMI-LISN5UH \(see page 437\)](#)
  - [EMI-NF-AMP \(see page 439\)](#)
  - [EMI-NF-PROBE \(see page 440\)](#)
  - [EMI-TRANS-LIMIT \(see page 438\)](#)
- [Accounting for accessories contributions in the EMCVu software \(see page 441\)](#)

---

**TIP.** View the topics in the [EMC Analysis \(see page 443\)](#) section of this Help for information about using the EMC Analysis software.

---


## Radiated tests introduction

Radiated emissions testing is about measuring the electromagnetic field strength of the emissions that are unintentionally generated by your product. Emissions are integral to the switching voltages and currents within any digital circuit; however, it is important that they comply emission limits.

The actual setup for Compliance tests is clearly specified in the standard document as applicable to the different types of products. You should refer to these standards for details about the actual setup. There are several challenges in the actual Radiated test setup. The electromagnetic waves don't extend out from your product in a nice spherical pattern. The emissions tend to be directional, so a test lab would typically vary the height of the receiving antenna between 1 and 4 meters as well as rotate a turntable. The receiving antenna picks up both the signal direct from the EUT, as well as a bounce off the ground. To increase measurement accuracy, the ground is covered with an electromagnetically reflective surface (aluminum, steel, wire mesh etc..) and this ground plane must be relatively flat. The EUT will be scanned in the frequency band of interest and you will look for emissions that are close to the limits.

Pre-compliance can help you find out emission issues early or troubleshoot emissions issues reported by a test house. A Radiated Emission Pre-Compliance test setup diagram is shown below with the equipment under test (EUT), ground plane, antenna mounted on a tripod, a pre-amplifier, and a spectrum analyzer. The picture that follows the diagram is provided to show the antenna connected to pre-amplifier to spectrum analyzer (without the ground plane). The radiation from the EUT is picked up by the antenna, the output of which is amplified by a pre-amplifier for better sensitivity. The output of the pre-amplifier is connected to the input of the analyzer that acquires the signal and analyzes it with the help of the software (EMCVu).


## Radiated Emissions Test Setup






## EMI-BICON-ANT (ABF-900A biconical antenna)

The EMI-BICON-ANT (Com-Power ABF-900A) is a broadband, linearly polarized Biconical Dipole Antenna with collapsible elements, operating over the frequency range of 25 MHz to 300 MHz. Each full-size biconical element (54 cm cage diameter) collapses to a maximum diameter of 5 cm for easy transport/storage.



The ABF-900A biconical antenna is intended for use as an EMI test antenna for qualification-level regulatory compliance measurements (FCC, CE, Mil-Std, RTCA DO-160, FDA, SAE Automotive, etc.).

ABF 900 has the following characteristics (Antenna factor).



These factors can be loaded into the EMCVu Accessories tab (located in the EMC Settings control panel or the EMC Project Setup Wizard). The file will be available to you in *C:\SignalVu-PCFiles\EMC\_Accessories*.

---

**TIP.** See the [Radiated tests introduction \(see page 420\)](#) topic for more information and to view a connections diagram.

---

## EMI-TRIPOD (AT-812 antenna tripod)

The recommended support structure for the Com-Power ABF-900A is the Com-Power AT-812 Antenna Tripod. One of the standard AT-812 accessories is the Com-Power ATHP-812 Antenna Pipe Holder, which clamps securely around the one-inch diameter feed tube of the ABF-900A. The ATHP-812 is then secured to a tripod or mast via its 1/4" x 20 thread mounting hole.



The above image shows the tripod.





The above image shows the mounted antenna with the pipe holder.

---

**TIP.** See the [Radiated test introduction \(see page 420\)](#) topic for more information and to view a connections diagram.

---


## EMI-CLP-ANT (ALC-100 Log Periodic Dipole Array (antenna))

The Com-Power ALC-100 is a broadband, linearly polarized Log Periodic Dipole Array (LPDA) antenna, operating over the frequency range of 200 MHz to 1 GHz and with excellent efficiency between 300 MHz and 1 GHz.

The ALC-100 Compact Log Periodic Antenna is intended for use as an EMI test antenna for qualification-level regulatory compliance measurements (FCC, CE, RTCA DO-160, FDA, SAE Automotive, etc.).



The ALC-100 can also be mounted using the AT-812 tripod (which is a part of the accessories given by Tektronix).



---

**TIP.** See the [Radiated tests introduction \(see page 420\)](#) topic for more information and to view a connections diagram.

---


## EMI-PREAMP (PAM-103 preamplifier)

The Com-Power PAM-103 is a broadband, high gain, low-noise preamplifier operating over the frequency range of 1 MHz to 1 GHz. Its high gain (33 dB  $\pm$ 3 dB) and low noise figure (<3.3 dB) make the PAM-103 preamplifier the ideal choice for optimizing your EMI measurement system, whether it be a test chamber, open area test site, or tem-cell.

The PAM-103 can be powered by its internal, rechargeable battery packs, or by its AC to DC power adapter/battery charger. On a full charge, the preamp will operate on battery power for over 13 hours. The battery low indicator light will let you know when it is time to plug it in and the charging indicator light will let you know that it is charging. If you are unable to plug it in, you can feel confident in continuing your test, because the PAM-103 will turn itself off before the battery voltage reaches the point at which the gain could become unstable. Whether it is operating on battery power or external power, if the amp is on, the output should be stable and the gain should remain constant.



Nearly all measurement systems for radiated EMI tests require preamplification to achieve the necessary sensitivity.



---

**TIP.** See the [Radiated tests introduction \(see page 420\)](#) topic for more information and to view a connections diagram.

---

## Radiated pre-compliance test setup (30 MHz to 300 MHz)

A simple pre-compliance setup is shown below using a ABF-900 antenna, a preamplifier, and an RSA306B real-time spectrum analyzer.

1. Mount the antenna pipe holder ATHP-812 on the top support (ATTs-812) of the tripod (AT-812).




2. Mount the antenna pipe AB-900A on the antenna pipe holder (ATHP-812).



3. Fix the biconical antenna (ABF-900) to the antenna pipe (AB-900A).







4. Connect the output of the antenna pipe to a pre-amplifier through a Tektronix [cable \(see page 437\)](#).
5. Connect the output of the pre-amplifier to a Tektronix USB spectrum analyzer or a RSA5100B series spectrum analyzer.

---

**TIP.** See the [Radiated tests introduction \(see page 420\)](#) topic for more information and to view a connections diagram.

---

## Radiated pre-compliance test setup (300 MHz to 1 GHz)

A pre-compliance setup is shown below using the ALC-100 antenna, a preamplifier, and an RSA306B real-time spectrum analyzer.

1. Clamp the accessory to the top support (ATTS-812) of the tripod (AT-812).



2. Mount the antenna (ALC-100) to the accessory connected in the previous step.





3. Connect the output of the antenna to a pre-amplifier through a Tektronix [cable \(see page 437\)](#).
4. Connect the output of the pre-amplifier to a Tektronix USB spectrum analyzer or an RSA5100B series spectrum analyzer.

---

**TIP.** See the [Radiated tests introduction \(see page 420\)](#) topic for more information and to view a connections diagram.

---


## Conducted tests introduction

Conducted emission tests are about testing the portion of electromagnetic energy created by your device that is conducted onto the power supply cord. To restrict the amount of interference your device can couple back onto a power supply, test labs measure these emissions (usually from 150 kHz - 30 MHz) and verify that they comply with specified limits.

This helps to ensure that the local power supply remains relatively clean and nearby devices will not be affected by your device. Conducted emissions testing is usually performed on devices that connect to

an AC power supply. For some standards, there are also limits placed on devices that operate from a DC power supply.

## Conducted Emissions Test Setup



LISN is one of the key accessories required for doing a conducted test.



## EMI-LISN50UH (TBLC08 Line Impedance Stabilization Network)

The following models are available:

- EMI-LISN50UH-US: This model supports DUT devices with US main power.
- EMI-LISN50UH-GB: This model supports DUT devices with GB main power.
- EMI-LISN50UH-EU: This model supports DUT devices with EU main power.

The 50  $\mu$ h AC line Tekbox TBLC08 is a Line Impedance Stabilization Network (LISN) for the measurement of line-conducted interference within the range of 9 kHz to 30 MHz, as per the CISPR16 standard. The device is designed for testing single phase, AC-powered equipment with supply voltages up to maximum 260 V. Conducted noise can be measured on the phase and on the neutral conductor. The TBLC08 is equipped with a switchable limiter/attenuator.



The LISN provides for stabilization and lets you measure what amount of energy is fed back to the power line. The LISN is powered and the front-end power socket lets you power your equipment under test (EUT). The emissions that is fed back to the power line is available at RF out for a receiver or spectrum analyzer to measure.

The LISN is connected to the AC power supply and provides power to the EUT. The spectrum analyzer is connected to the RF out of the LISN. TBLC08 has an built-in limiter that can be switched ON to avoid transients. The emission that is usually fed back to the power line is made available at RF OUT by the stabilization network.

---

**TIP.** See the [Conducted tests introduction \(see page 433\)](#) topic for more information and to view a connections diagram.

---

## CABLE (coaxial Type N to Type N)

The following cables for EMI testing are available from Tektronix:

- CABLE-1M: 1 meter RF coaxial Type N to Type N cable
- CABLE-3M: 3 meter RF coaxial Type N to Type N cable
- CABLE-5M: 5 meter RF coaxial Type N to Type N cable

## EMI-LISN5UH (TBOH01 Line Impedance Stabilization Network)

The 5  $\mu$ H DC line Tekbox TBOH01 is a Line Impedance Stabilization Network (LISN) for the measurement of line-conducted interference within the range of 150 kHz to 110 MHz. It is inserted into the supply line of the DUT.



---

**TIP.** See the [Conducted tests introduction \(see page 433\)](#) topic for more information and to view a connections diagram.

---

## EMI-TRANS-LIMIT (LIT-153A transient limiter)

The Com-Power LIT-153A is a transient limiter that protects the EMI receiver input via the LISN from any short transients (a few microseconds or less) on the power supply lines.



---

**TIP.** See the [Conducted tests introduction \(see page 433\)](#) topic for more information and to view a connections diagram.

---

## EMI-NF-AMP (TBWA2 amplifier)

The TekBox TBWA2 is a 20 dB or 40 dB wideband amplifier for use with the TBPS01 probes.



---

**TIP.** See the [EMI-NF-PROBE \(see page 440\)](#) accessory topic.

See the [Radiated tests introduction \(see page 420\)](#) topic for more information and to view a connections diagram.

---

## EMI-NF-PROBE (TBPS01 near field probe set)

The TekBox TBPS01 is a near field probe set.



---

**TIP.** See the [EMI-NF-AMP \(see page 427\)](#) accessory topic.

See the [Radiated tests introduction \(see page 420\)](#) topic for more information and to view a connections diagram.

---



## Accounting for accessories contributions in EMCVu software

Each accessory has its own Gain/Loss (antenna factor in the case of antennas) that must be accounted for to get an accurate emission measurement. The measured reading must be corrected for the Gain/Loss/Factor contribution due to the accessories.

The EMCVu software allows you to correct for the accessory contributions. You can either use the Setup Wizard – Accessories tab or the Accessories tab in the Settings control panel to account for these contributions. You can view the Combined Impact of all the accessories in a graph, too.

The typical values of Gains/Losses/Factors of each of the Tektronix provided accessories is available for you to easy load. You can either use the “Load Tektronix provided Accessories Gains/Losses” from the Setup Wizard or you can load individual accessory files using “Configure Accessories > Edit > Load”. The individual .csv files are available in *C:\SignalVu-PC Files\EMC Accessories*.

---

**TIP.** See the [How to perform an EMC pre-compliance test \(see page 448\)](#) topic for more information of how you can perform an emission measurement. See the [Combined impact of gains/losses \(see page 500\)](#) to read more about contributions.

---



## Introduction

The Electro Magnetic Compatibility (EMC) Analysis option (Option EMCVUNL-SVPC and EMCVUFL-SVPC) allows you to perform pre-compliance emissions tests for your devices and troubleshoot emission issues. A separate EMCVu icon is loaded to your Desktop for quick access to the EMC displays, setups, and standards. These same displays, setups, and standards can also be accessed from the SignalVu-PC application.

EMC is a measure of the capability of a device to operate as expected in its operating environment. A device should not affect the capability of other equipment in a certain proximity to operate as expected. EMI can be defined as electromagnetic energy that affects the functioning of an electronic device. Sources of EMI are predominantly from electronic devices or electrical systems. While EMI can be generated from any electronic device, certain equipment and components, such as cell phones, welders, motors, and LED screens, are more likely to create disturbances than others. Measuring the amount of EMI generated by the internal systems of devices is a process known as emissions testing. The RF range is generally split into a Conducted range and a Radiated range.

Several consequences, including safety risks and product failures, can result if you fail to properly anticipate the EMC of a device. Tektronix's EMC solution helps you find the emission problems in your device and troubleshoot them.

## EMC standards

The EMC standards bring a common approach to every member state to EMC/EMI testing. It is important to purchase the standards document to do these tests because it lays out a clear procedure for test setup and methodologies. The CISPR standards usually define test procedures for commercial products.

The various standards set down limits for conducted and radiated EMI emissions. Typically, limit lines are defined separately for residential areas and industrial areas. These two areas are represented by two classes of limits: class A represents the industrial environment; class B defines the limits for residential areas.

The following are standards for which limit lines can be easily loaded in this application. Complete information about setup and testing can be found in the standard document.

### Available standards under Europe are:

- EN55011: Industrial, scientific and medical (ISM) equipment containing a radio-frequency generator
- EN55012: Vehicles, motor boats and internal combustion engines - protection of off-board receivers
- EN55013: Sound / television broadcast receivers and associated equipment
- EN55014: Household appliances, portable electrical tools and similar apparatus, parts
- EN55015: Electrical lighting and similar equipment, for example fluorescent lamps
- EN55025: Vehicles, motor boats and internal combustion engines- protection of on-board receivers
- EN55032: Multimedia equipment (replaces CISPR 13 and CISPR 22 from 2017)

- EN60601: Medical Electrical equipment
- DEF STAN: Defense Standard for equipment and sub systems

**Available standards under US are:**

- FCC Part 15
- FCC Part 18
- MIL-STD 4161G

## Key features

EMC testing with Tektronix provides you the following suite of pre-compliance and troubleshooting tools and displays to help you debug problems faster.

### [Pre-compliance \(see page 448\)](#)

- [EMC Project Setup Wizard \(see page 452\)](#): Use the EMC Project Setup Wizard to include contributions due to accessories, load ranges and limits based on standards recommendations, choose between measurement types, and include information for reports.
- [Measure Ambient \(see page 467\)](#): Measure emission not contributed by the Equipment under Test (EUT) and compare it with results obtained when the EUT is turned on.
- [Re-measure Spot \(see page 469\)](#): Identify emission results from a scan and re-measure on the selected spot (frequencies that have failed Threshold/Limit lines) with detectors recommended by the standard or detectors defined by you.
- [Report \(see page 466\)](#): Include measurement results and settings in a report. Include multiple measurement results in a report.

### [Troubleshooting \(see page 474\)](#)

- [Harmonic Markers \(see page 475\)](#): Allows you to place markers at selected harmonic factors of a known fundamental frequency to find if the emissions are caused by known design issues.
- [Inspect Suspect Frequencies \(see page 476\)](#): Inspect a set of suspect frequencies in discrete mode or a set of harmonics of as many as 3 fundamental frequencies. You can use this tool with a near field probe set to see from where the suspect emission frequencies come.
- [Level Target \(see page 480\)](#): Place a level target in the display and compare scans against the target visually.
- [Compare Traces \(see page 480\)](#): Compare different scan traces, save traces, recall traces, and compare against limit lines. Compare Ambient traces and use the Math function (the difference of two traces) to create a Math trace.
- [Persistence Display \(see page 484\)](#): Troubleshoot intermittently occurring emissions using the persistence tool with the DPX display.


## Displays

- [EMC-EMI \(see page 484\)](#)
- [DPX \(see page 74\)](#)
- [Spectrogram \(see page 99\)](#)
- [Spectrum \(see page 95\)](#)

## How to open EMCVu

You can start the EMC Analysis tool one of the following ways:




1. Double click  on the Desktop. This EMCVu icon will open the SignalVu-PC application defaulted to the EMC Analysis display with the Setup Wizard open.


---


**TIP.** *EMCVu is best viewed in 1920x1080 or 1920x1200 resolution.*


---




2. Double click  on the Desktop. This SignalVu-PC icon will open the SignalVu-PC application.
  - a. Select **Setup** from the Main menu bar and select EMC. This allows you to access various EMC functions. To get started with an EMC pre-compliance test, select **Setup Wizard**. You can read more about the EMC Project Setup Wizard [here \(see page 452\)](#).




- b. Click the  icon on the [Favorites bar](#) (see [page 864](#)) and check the box next to EMC. This will place the EMC menu options on the Favorites bar for quick access.



## Elements of the EMC Analysis window



0720-016

Element	Description
1	These menu items on the Favorites bar are EMC Analysis specific. You can add or remove these items from the <a href="#">Favorites bar (see page 864)</a> by clicking the  icon (located at the far right end of the bar) and then checking or unchecking the box next to <b>EMC</b> .
2	The graph of the currently selected display appears here.
3	Emissions results will appear here.

## Pre-compliance

The Tektronix EMC analysis option allows you to perform pre-compliance testing of your equipment to detect possible emissions at an early stage, reducing the chances of failure at the test house. The EMC software can be accessed through the analyzer application interface or through the EMCVu icon on your Desktop. This analysis option provides the following four key features to perform pre-compliance testing.

1. [Quick start \(see page 448\)](#) guide on how to perform a pre-compliance test.
2. [Setup Wizard \(see page 452\)](#)
  - [Accessories tab \(see page 454\)](#)
  - [Ranges & Limits tab \(see page 460\)](#)
3. [Measure Ambient \(see page 467\)](#)
4. [Re-measure Spot \(see page 469\)](#)
5. [Report \(see page 470\)](#)

CISPR (International Special Committee on Radio Interference) detectors are needed when performing EMC testing of electronic devices. Specifically, levels of EMI need to be under a reference while being measured with a specified CISPR detector. These detectors are defined in Publication 16 of CISPR. Option SVQPNL-PC and SVPQFL-PC adds these CISPR detectors and filters so you can perform the required EMI measurements needed for your DUT (Device Under Test). These detectors can be invoked in the Spectrum display or in the EMC–EMI display. Note that these detectors process the signal over a long period of time (2 seconds), so it is expected that the user interface may seem less responsive during that time.

---

**TIP.** Click here to see [how to launch EMCVu \(see page 445\)](#) (EMC Analysis).


---


---

**TIP.** The EMC Project Setup Wizard contains a subset of available EMC settings. See the [EMC-EMI display settings \(see page 489\)](#) topic for information about those additional settings.


---

## How to perform an EMC pre-compliance test




1. Double click  on the Desktop. This EMCVu icon will open the analyzer application defaulted to the EMC Analysis view with the Setup Wizard open on the Getting Started tab.





2. Select **Conducted** or **Radiated** as the Emission Type. This selection is located at the top of the Setup Wizard window.
3. Select the Accessories tab.




4. Click the **Load Tektronix Provided Accessories Gains/Losses** button.
5. If you selected **Conducted** emissions, a window will appear prompting you to turn on the limiter in LISN. When you have done this, click **OK** to continue.



LISN and cable will be loaded for the conducted pre-compliance setup. If you need to add other accessories, do so now. View the [Add/edit individual accessories \(see page 457\)](#) or [Load accessories from a saved file \(see page 459\)](#) topics for detailed instructions.

6. If you selected **Radiated** emissions, a window will appear prompting you to select the frequency range of the antenna. When you have done this, click **OK** to continue.



Antenna, Cable, Pre-Amplifier, and Cable will be loaded for the radiated pre-compliance setup. If you need to add other accessories, do so now. View the [Add/edit individual accessories \(see page 457\)](#) or [Load accessories from a saved file \(see page 459\)](#) topics for detailed instructions.

7. Select the **Ranges & Limits** tab. View the [Load from Standard \(see page 460\)](#) and [Choose a measurement method \(see page 462\)](#) topics to read about how to use this tab.
8. Select the **Reports** tab and select the information to be contained in the report. View the [Report Wizard and Report tab \(see page 466\)](#) topic for details about how to do this.
9. Click the **Setup Complete– Run Test** button to initiate a single scan.
10. If desired, you can change the Reference Level for better sensitivity. In general, you can set the reference level based on the largest signal of interest.

For example, for a 50 dBuV reference level, the maximum emission level that can be measured is 55 dBuV (5 dB over-scale). If the signal of interest is lower, then the reference level can be adjusted

accordingly. Emission levels that are approximately 10 dB higher than the noise level can be measured accurately.


The noise level can be easily measured by terminating the input to the LISN/Antenna or removing the EUT and other sources of EMI from the test setup. The noise floor has to be measured with the same RBW that is used to measure emission level (recommended by the standard). For example, if the noise floor is measured at -5 dBuV for 120 kHz RBW, then emission levels at 5 dBuV or higher can be accurately measured.

---

**TIP.** Read about troubleshooting tools and displays in the [Troubleshooting \(see page 474\)](#) topic.

---

---

**TIP.** To access more [EMC settings \(see page 489\)](#), click the  icon or select **Setup > Settings** from the Main menu bar when the [EMC-EMI display \(see page 484\)](#) is selected.

---


---

**TIP.** The EMC Project Setup Wizard contains a subset of available EMC settings. See the [EMC-EMI display settings \(see page 489\)](#) topic for information about those additional settings.

---

## EMC Project Setup Wizard

The EMC Project Setup Wizard opens on the Getting Started tab. The content on the Getting Started tab leads you through a series of well-defined steps to set up and perform an EMC pre-compliance test. The other tabs, buttons, and settings of the Setup Wizard allow you to select accessories, set ranges and limits, create reports, and perform other tasks, as shown in the following table.



**TIP.** EMCVu is best viewed in 1920x1080 or 1920x1200 resolution.

**TIP.** The EMC Project Setup Wizard contains a subset of available EMC settings. See the [EMC-EMI display settings \(see page 489\)](#) topic for information about those additional settings.


Setting/Tab	Description
Emission Type	Allows you to select the emission type: Conducted or Radiated.
Getting Started	Guides you through a pre-compliance test.
<a href="#">Accessories (see page 454)</a>	Allows you to specify accessory related settings.
<a href="#">Ranges &amp; Limits (see page 460)</a>	Allows you to specify range and limit related settings for comparison, choose measurement modes, and load standard recommended values.
<a href="#">Reports (see page 466)</a>	Allows you to specify the details to be included in the test report.
Help	All of the Setup Wizard tabs, except Getting Started, have a Help button. Clicking this button opens a Help file with information related to the currently active tab. For more in-depth information about the EMC Analysis displays, settings, and functionality, select Help > User Manual from the Main menu bar in the analyzer application.
Setup Complete — Run Test	Allows you to begin a scan, initiating the test run.

Setting/Tab	Description
Save Project Setup	Allows you to save all of the Setup Wizard settings as an EMC project setup file.
Recall Project Setup	Allows you to recall a saved EMC project setup.

**TIP.** The Setup Wizard will open every time the EMC-EMI display is launched. This behavior can be suppressed from the Prefs tab in the EMC Settings control panel by disabling **Show Setup Wizard on EMC-EMI display startup**.

## Accessories tab

This tab in the EMC Project Setup Wizard lists, and allows you to set up, the accessories required for the test. You can also view a graph showing the combined impact of accessories gains and losses. The final measurement reading is corrected based on these accessory contributions before it is shown in the display. The correction is calculated by negating the combined impact of all of the accessory gains/losses you entered.





---

**TIP.** The EMC Project Setup Wizard contains a subset of available EMC settings. See the [EMC-EMI display settings \(see page 489\)](#) topic for information about those additional settings.

---

---

**TIP.** Read more about the plot on this tab in the [Combined impact of gains/losses \(view in plot\) \(see page 500\)](#) topic.

---

**You can load accessories one of the following ways:**


- Use the [Load Tektronix provided Accessories Gains/Losses \(see page 455\)](#) button.
- Manually [Add and/or edit individual accessory details \(see page 457\)](#).
- Use the [Load All Accessories \(see page 459\)](#) button.

**More topics about setting up accessories and related information:**

- [Accessories setup \(see page 493\)](#)
- [Combined impact of gains/losses \(view in plot\) \(see page 500\)](#)
- [Calculation of combined impact of accessories gainslosses \(see page 502\)](#)
- [Edit accessory contributions \(see page 494\)](#)
- [External correction in DPX \(see page 506\)](#)
- [Loading accessories from a file \(see page 497\)](#)
- [Available accessories in the drop-down lists \(see page 494\)](#)
- [Two types of mismatch issues when recalling the csv file \(see page 497\)](#)
- [Changing accessory details \(see page 496\)](#)

## Load Tektronix provided accessories gains/losses

1. Select either **Conducted** or **Radiated** as the Emission Type (top of window, above the tab headings).
2. Click the **Load Tektronix Provided Accessories Gains/Losses** button.



3. For Conducted emissions:

You will be prompted to turn on the limiter in LISN. The default contributions loaded for the conducted pre-compliance setup are LISN and cable. However, you can add any other accessories as needed.


4. For Radiated emissions:

The default contributions loaded for the radiated pre-compliance setup are Antenna, Cable, Pre-Amplifier, and Cable. However, you can add any other accessories as needed.

You will also be prompted to choose the antenna that is being used for the test. The biconical antenna is used for tests between 30 MHz and 300 MHz. The log periodic antenna is used for tests between 300 MHz and 1 GHz. Depending on the range of the test, you can make the choice and the contribution due to those set of accessories will be loaded.

The parameters loaded for Cable are those of the [CABLE-1M \(see page 437\)](#) (1 meter) cable. If you are using a 3 m or 5 m cable, please load the appropriate file from the *C:\SignalVu-PC Files\EMC Accessories* folder.





---

**TIP.** Read more about editing accessories in the [Accessories tab \(see page 492\)](#) and [Accessories setup \(see page 493\)](#) topics.

---

## Add and/or edit individual accessories

1. To add an accessory, click on the arrow next to an accessory field and select from the drop down list. The list is dependent on the selected emission type (Conducted or Radiated).

Configure Accessories

Load Tektronix provided Accessories Gains/Losses

☒ Antenna

☒ Cable

☒ Antenna

☒ Near Field Probe

☒ Cable

☒ Amplifier

☒ Limiter

☒ Attenuator

☐ Filter

☐ Others

☐ Others

2. To edit the details of an accessory, click the **Edit** button next the accessory you want to edit. A window will appear containing the parameters of the accessory.

Edit Antenna

Model: ABF900

Serial:

Asset Tag:

Cal Due Date: 05/28/2017 ☐ Disable Cal Due Date

Distance: 10 m

Select Gain/Loss Format

☐ Constant Gain/Loss

☐ Antenna Gain/Loss Table

☒ Antenna Factor

Frequency Interpolation

☒ Linear

☐ Log

Antenna Factor

	Freq (Hz)	Factor (dB/m)
1	25.000M	11.01
2	30.000M	11.93
3	35.000M	11.75
4	40.000M	10.64
5	45.000M	9.43
6	50.000M	9.35
7	55.000M	9.77
8	60.000M	9.99
9	65.000M	11.34

3. Edit the desired parameters. You can edit the following:
    - Model number
    - Serial number
    - Asset tag
    - Calibration due date
    - Distance (for Antenna)
    - Gain/Loss format
      - Constant gain/loss <sup>1</sup>
      - Antenna gain/loss table <sup>1</sup>
      - Antenna factor
    - Frequency interpolation (Linear or Log)
  4. Click the **OK** button to close the edit window and go to another accessory.
  5. Edit any other accessories, if needed.
  6. Click the **Save All Accessories** button to save the updated details of all edited accessories to a file.
  7. Click the **Load All Accessories** button to load the updated accessories to the current setup.
- <sup>1</sup> Values are entered in dB with gain represented as positive values and loss as negative. For antennas, either isotropic gain information is entered in dBi or antenna factors in dB/m.

---

**TIP.** Read more about editing accessories in the [Accessories tab \(see page 492\)](#) and [Accessories setup \(see page 493\)](#) topics.

---

## Load accessories from a saved file

1. Click the **Load All Accessories** button to load accessories from a saved setup file.

---

**NOTE.** The parameters loaded for Cable are those of the [CABLE-1M \(see page 437\)](#) (1 meter) cable. If you are using a 3 m or 5 m cable, please load the appropriate file from the C:\SignalVu-PC Files\EMC Accessories folder.

---


---

**TIP.** Read about the combined impact of accessories and accessories setup information in the [Accessories setup \(see page 493\)](#) topic.

---

## Ranges and Limits tab

The Ranges and Limits tab of the EMC Project Setup Wizard allows you to specify the parameters that control the EMC-EMI measurement. You can:



- [Load from Standard \(see page 461\)](#)
- [View Ranges and Limits plot and edit label \(see page 461\)](#)
- [Edit Ranges and Limits \(see page 462\)](#)
- [Choose a measurement method \(see page 462\)](#)
- [Edit Scan and Spot Setup \(see page 465\)](#)


---

**TIP.** The EMC Project Setup Wizard contains a subset of available EMC settings. See the [EMC-EMI display settings \(see page 489\)](#) topic for information about those additional settings.

---


### Load from Standard

Click the **Load from Standard** button on the Ranges and Limits tab in the EMC Project Setup Wizard to load from a standard based on the region selected. The following window will appear from which you can make selections.



- This window allows you to choose the region for which your product is intended and then a standard from a list of standards in that region. You will need a copy of the standard document (the version number of the standard is mentioned as you make a choice of the standard from the drop down).
- The various frequency ranges / limit line tables provided from the standard will be listed in a drop down for selection.
- Once the appropriate standard is loaded, you will see the ranges and limits recommended by the standard in a plot. The detector choice recommended by the standard is also shown in the Scan Definition and Spot Setup below the plot. The limit line against which the detector results will be compared is also shown as a mapping against each detector choice.
- A margin also can be set (shown by the dotted line) and this is applicable to all limit lines. The Margin setting is located to the left of the plot.
- Some tables in standards recommend separate limit lines for each detector choice and all of them will be loaded.

## View Ranges and Limits plot and edit label

- The Ranges and Limits loaded from standard can be seen in the plot in the Ranges & Limits tab of the EMC Project Setup Wizard.
- When loaded from standard, the limit label is set appropriately based on the standard and limit table choice. However, this can be edited by clicking  (Edit Label button).
- The Limits are shown in different colors when more than one limit line is selected. This is indicated in the Limit legends.
- Margin for every limit line is shown in dotted form for every limit in the respective color.
- Frequency scale can be viewed in Linear or Log.

## Edit Ranges and Limits

Ranges and limits can be customized from the Ranges & Limits tab of the EMC Project Setup Wizard. If you want to customize the limit lines loaded from a standard or you want to create your own limit lines, do as follows.

1. Click the **Edit Ranges and Limits** button to left of the plot. The following expanded table will appear.

	On	Start (Hz)	Stop (Hz)	RBW (Hz)	Auto	VBW (Hz)	VBW On	Thrshld (dBuV)	Excrsn (dB)	Limit1 Start (dBuV)	Limit1 Stop (dBuV)	Limit1 Same	
A	✓	150.0000...	500.0000...	9.000k	✓	1M		100.00	6.0	130.00	130.00	✓	1
B	✓	500.0000...	5.000000M	9.000k	✓	1M		95.00	6.0	125.00	125.00	✓	1
C	✓	5.000000M	30.000000M	9.000k	✓	1M		85.00	6.0	115.00	115.00	✓	1
D		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
E		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
F		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
G		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
H		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
I		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
J		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
K		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
L		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
M		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
N		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
O		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
P		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
Q		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
R		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5


2. Edit the start and stop frequencies, RBW and VBW settings, and limit values.

As many as 3 limit lines can be included. The limit lines will be shown with individual color codes and the corresponding margin lines shown in same color but in dotted form. The margin control is only one control applied in common to all limit lines.

3. Check to see that the customized limit lines appear in the plot.
4. Save frequency ranges and limit lines by clicking the **Save** button. You can also load from these saved files later.

## Choose a measurement method

Once the desired ranges and limits are loaded, you can decide to do the measurement in one of the following three measurement methods, which are available for most standards.



- **Pre-scan + Manual Spot:** A quick pre-scan followed by choosing spots from results table and re-measuring them with detectors recommended by the standard (or that of your choice).
- **Pre-scan + Auto Spot:** A pre-scan followed by an Automated re-measurement for a chosen number of spots.
- **Complete Scan:** A complete scan with detectors recommended by the standard - could be time consuming if detectors such as CISPR Quasi Peak or CISPR Avg are chosen.

---

**TIP.** You can read more about measurement methods and how they can be set from the Ranges & Limits tab in the EMC Settings control panel in the [Measurements \(see page 511\)](#) topic.

---

The mapping of limit lines to the detectors is also shown under Scan Definition and Spot measurement. This tells you which detector will be used for Scan and Spot measurements and which limit line will the Scan or Spot results be compared against.

The Estimated Analysis Time is shown to give an idea of how much time the Scan is expected to take for the detectors chosen. This Estimated time is based out of the choice of detectors and the span of the actual scan measurement and is calculated under ideal conditions for a machine with 16 GB RAM. Actual time taken for measurement could vary.

This estimated analysis time could be higher if detectors such as CISPR Quasi Peak are used for a larger span range.

The following three images show how the Scan Definition and Spot Measurement information may vary depending on the selected measurement method.


Measurement Methods	Scan Definition	Spot measurement (only on failures)
<input checked="" type="radio"/> Pre-scan + Manual Spot (on failures)	<b>CISPR +Pk</b> compared with <b>Limit2</b>	<b>CISPR QPk</b> compared with <b>Limit1</b> <b>CISPR Avg</b> compared with <b>Limit2</b>
<input type="radio"/> Pre-scan + Auto Spot (on failures)		
<input type="radio"/> Complete Scan		
Estimated Analysis Time: 1 s		
<a href="#">Edit Scan &amp; Spot Setup</a>		

Measurement Methods	Scan Definition	Spot measurement (only on failures)
<input type="radio"/> Pre-scan + Manual Spot (on failures)	<b>CISPR +Pk</b> compared with <b>Limit2</b>	<b>CISPR QPk</b> compared with <b>Limit1</b> <b>CISPR Avg</b> compared with <b>Limit2</b>
<input checked="" type="radio"/> Pre-scan + Auto Spot (on failures)		
<input type="radio"/> Complete Scan		
Estimated Analysis Time: 1 s		Max Spots: <input type="text" value="2"/> <input type="checkbox"/> All
<a href="#">Edit Scan &amp; Spot Setup</a>		

Measurement Methods	Scan Definition
<input type="radio"/> Pre-scan + Manual Spot (on failures)	<b>CISPR QPk</b> compared with <b>Limit1</b>
<input type="radio"/> Pre-scan + Auto Spot (on failures)	
<input checked="" type="radio"/> Complete Scan	
Estimated Analysis Time: 1011 s	

The three measurement methods might not be shown for some standards if they do not recommend detectors such as CISPR Quasi Peak (for example, Mil/Gov 461G and DEF STAN). This is because the scan itself is done with CISPR Peak detector which can be done faster and there is no need for a Pre-scan followed by spot measurements in such a case.





## Edit Scan and Spot Setup

Edit Scan and Spot Setup allows you to modify any detector choice or dwell time. You can also do the limit mapping appropriately.

- Choose the appropriate detector for scan and spot re-measurement
- Set dwell time
- Choose the limit line mapping

By default, the standard recommended limit line is mapped to appropriate detectors.

Scan & Spot Setup

Scan Setup

☒ CISPR +Pk compared with Limit2 ☒

☐ CISPR QPk compared with Limit1 ☐

Dwell Time: 10 ms ☒ Auto

Estimated Analysis Time: 1 s

Spot Measurement Setup (only on failures)

☒ CISPR QPk compared with Limit1 ☒

☒ CISPR Avg compared with Limit2 ☒

☐ CISPR QPk compared with Limit1 ☐

Dwell Time: 2.0 s ☒ Auto

Done

**TIP.** You can read more about scan and spot setup in the [Edit Scan and Spot Setup \(see page 465\)](#) topic.

## Reports

The Reports tab in the EMC Project Setup Wizard allows you to select the information you want to include in a report.

EMC Project Setup Wizard

Emission Type: ☒ Conducted ☐ Radiated

Getting Started | Accessories | Ranges & Limits | **Reports**

**User information**

Engineer name  Project

Organization

Add Information

**Environment information**

Temperature  0 °C Humidity  0 RH

Testing location

Add Information

**EUT information**

Device type  Manufacturer

Model name  Serial number

Add Information

Information to include:

- ☒ User information
- ☒ Environment information
- ☒ EUT information

Reports Help Save Project Setup Recall Project Setup Setup Complete - Run Test

Item	Description
User information	Includes user information in the report: Engineer name, Project name, and Organization name. Empty fields will not be included in the report. If you do not want to include a default field, you can leave it empty.
Environment information	Includes environment information in the report: Temperature, Humidity, and Testing location. Empty fields will not be included in the report. If you do not want to include a default field, you can leave it empty.

Item	Description
EUT information	Includes equipment under test (EUT) information in the report: Device type, Model Name, Manufacturer name, and Serial number. Empty fields will not be included in the report. If you do not want to include a default field, you can leave it empty.
Add Information	New information details can be added to any of the three information areas by clicking an Add Information button in the associated area. You can then providing details such as title and value of the new item in the Add Information window.
Information to include	Select which information areas to include in a report from this list. Check a box to include the associated information. Uncheck a box to leave out the associated information.

1. Check the boxes in the **Information to include:** area of the Reports tab that are next to the information you want included in the report.
2. Edit the information fields in the User, Environment, and EUT (equipment under test) areas, as needed.
3. If needed, click the **Add Information** button in the desired information area to add an additional field to the selected information area.


**TIP.** Read the [Generating and saving reports \(see page 470\)](#) topic for detailed information about saving, generating, viewing, and exporting reports.

**TIP.** The Setup Wizard will open every time the EMC-EMI display is launched. This behavior can be suppressed from the [Prefs tab \(see page 521\)](#) in the EMC Settings control panel by disabling **Show Setup Wizard on EMC-EMI display startup**.

## Measure ambient

An Ambient scan analysis can be done to quickly check if the Spots (emission at specific frequencies) obtained are due to ambient emissions or the actual equipment. Perform this ambient scan analysis procedure to quickly check if the listed Spots are due to ambient interference or the equipment.

1. Select **Setup > EMC > Measure Ambient** or click **Measure Ambient** from the EMC related items on the [Favorites toolbar \(see page 864\)](#). Alternatively, you can recall a trace saved from the Ambient tab in the EMC Settings control panel.
2. Follow the prompt that appears and turn off the Equipment under Test (EUT) or completely remove it from the setup.



3. Click the Ambient tab in the EMC Settings control panel and set Detector, Dwell Time, and Delta Threshold appropriately.
4. Return the EUT to the setup, if removed, and turn it on.
5. Perform a scan with the same detector set in the Measurement Type tab.
6. View the Ambient trace in the graph.

---

**TIP.** Read about comparing ambient scan results in the [Comparing ambient scan results \(see page 468\)](#) topic.

---

---

**TIP.** See the [Ambient tab \(see page 518\)](#) topic for more information about ambient settings.

---

## Comparing ambient scan results

If you performed an ambient scan with the EUT turned on and the results table is populated with Spots (frequencies that have failed the threshold or limit line), then comparison of those results with an ambient scan with the EUT off can be done. The comparison between the Ambient trace (the scan with the EUT off) and Scan trace (the scan with the EUT on) is done at each failing frequency (Spot) in the Emission Results table.

- Comparison of results is done only at all failing frequencies. The Delta difference between the Ambient trace and the Scan trace is shown.
- The comparison of results is done only if the detector type for Scan and Ambient match.
- This Delta difference is compared against the Delta threshold setting made in from the Ambient tab in the EMC Settings control panel.
- If the absolute difference between the Ambient trace and Scan trace is less than the delta threshold, then those cells are shown shaded in blue in the Emission Results table, as shown below. This means that the emission could be the result of the environment and not the EUT.

Emission Results									
Spot ...	Spot #	Range	Freq (Hz)	Scan CISPR +Pk		Ambient CISPR +Pk			
				Ampl	Delta(Limit1)	Ampl	Delta(Scan)		
<input checked="" type="checkbox"/>	1	A	99.725 MHz	23.1 dBuV...	3.07 dBuV...	7.64 dBu...	15.4 dBu...		
<input checked="" type="checkbox"/>	2	B	560.041 MHz	21.0 dBuV...	1.02 dBuV...	10.6 dBu...	10.4 dBu...		
<input checked="" type="checkbox"/>	3	B	922.037 MHz	18.8 dBuV...	-1.20 dBu...	19.3 dBu...	-0.486 dB...		
<input checked="" type="checkbox"/>	4	B	945.907 MHz	16.2 dBuV...	-3.85 dBu...	15.9 dBu...	0.269 dB...		

**NOTE.** The Measure Ambient item in the Favorites toolbar will not be active if no instrument is connected or if no playback is selected.

## Re-measure spot

Click **Setup > EMC > Re-measure Spot** or click **Re-measure Spot** from the from the EMC related items on the [Favorites toolbar \(see page 864\)](#), to perform the spot re-measurement.

Spot re-measurement is performed on the selected spot (frequencies that have failed Threshold/Limit lines) from the Emission Results table with detectors recommended by the standard or detectors defined by you. These detectors could typically be detectors that require larger measurement/dwell time like CISPR Quasi peak.

Spot re-measurement is useful when you want to do a quick pre-scan with peak detectors and then apply detectors with larger dwell time only on those frequencies that have failed the Threshold or Limit line settings. It is also useful when the selected measurement method is Pre-scan + Manual Spot or Pre-scan + Auto Spot.

Emission Results									
Spot ...	Spot #	Range	Freq (Hz)	Scan CISPR +Pk		Spot CISPR QPk		Spot CISPR Avg	
				Ampl	Delta(Limit1)	Ampl	Delta(Limit1)	Ampl	Delta(Limit1)
<input checked="" type="checkbox"/>	1	A	99.725 MHz	23.1 dBuV...	3.07 dBuV...	15.1 dBuV...	-4.93 dBu...	7.86 dBuV...	-12.1 dBu...
<input checked="" type="checkbox"/>	2	B	560.041 MHz	21.0 dBuV...	1.02 dBuV...	14.2 dBuV...	-5.77 dBu...	9.39 dBuV...	-10.6 dBu...
<input checked="" type="checkbox"/>	3	B	922.037 MHz	18.8 dBuV...	-1.20 dBu...	5.15 dBuV...	-14.8 dBu...	-2.20 dBu...	-22.2 dBu...
<input checked="" type="checkbox"/>	4	B	945.907 MHz	16.2 dBuV...	-3.85 dBu...	12.1 dBuV...	-7.91 dBu...	4.44 dBuV...	-15.6 dBu...

- Once the scan is done for the trace, failing frequencies are listed in the Emission Results table and you can choose the spot(s) which should be re-measured.
- You can choose the Spot(s) for performing spot measurements either from the plot or from the Emission Results table.
- The RBW for Spot measurement will be the same as that used by the pre-scan. This is because it would only be correct to compare scan and spot results when they are done with the same RBW.

- The detector choice, limit line for comparison and dwell time for spot measurement are based on the choices you made while using the Setup Wizard.
- You can also change the choice of detector(s) from the [Measurement Type \(see page 511\)](#) tab in the EMC Settings control panel. You can also choose up to 3 detectors to analyze these spots.
- The Limit lines for comparison and the dwell time also can be edited.
- The re-measured spot results are then shown in the Emission Results table and also compared with appropriate limit lines.


If the Measurement method chosen is Pre-scan + Auto Spot, then the Re-measure Spot step is automatically performed. You can set the maximum number spots to be automatically re-measured in the Measurement Type tab of the EMC Settings control panel. This option is visible only when the measurement method is Pre-scan + Auto Spot.

---

**NOTE.** *The Re-measure Spot item on the Favorites toolbar will not be active when no device is connected or when no playback is selected.*

---

## Generating and saving reports

The Results and Reports window can be opened by selecting the  (Report) icon from the EMC related items on the [Favorites toolbar \(see page 864\)](#). This window has two tabs that allow you to save results, select what to include in a report, generate a report, export a report, and view a report.

## Save Results tab

The screenshot shows a software window titled "Results and Reports" with a close button in the top right corner. Inside the window, there are two tabs: "Save Results" (which is active) and "Generate Report".

Under the "Save Results" tab, the following fields and options are visible:

- Measurement Heading:** A text box containing "RunHeading".
- Time Stamp:** A text box containing "11-15-2017 10:52:48 AM".
- User Notes:** A large text area containing "User Notes".
- Settings:** A section containing a checked checkbox for "Include Control Settings".
- Measurement Results:** A section containing three checked checkboxes: "Include Graph", "Include Emission Results", and "Include Inspect Freq Results".
- Include Images:** A section with three empty text boxes, each followed by a browse button (three dots in a square).
- Save:** A button at the bottom right of the dialog.

1. Fill in the Measurement Heading field.
2. Add any additional information related to the test in the User Notes field.
3. Check the **Include Control Settings** box to include the EMC Settings control panel settings in the report.
4. Check the **Include Graph** check box and the **Include Emission Results** check box to include plot results and emission results in the test report.
5. If available, check the **Include Inspect Freq Result** box to include Inspect results in the test report. This option is only available if an Inspect measurement is chosen.
6. Select and browse to include any images in the report. Select the image file and click **OK**.
7. Click **Save** in the Save Results tab. The view will then change to the Generate Report tab where you can proceed to generate the report.


## Generate Report tab

The screenshot shows a software window titled "Results and Reports" with a close button in the top right corner. It has two tabs: "Save Results" and "Generate Report", with the latter being the active tab. On the left, under "Information to include:", there are three checked checkboxes: "User information", "Environment information", and "EUT information". Below these is an "Edit" button. On the right, a "History" table lists three entries. Each entry has an expandable icon, a checkbox, a description, a timestamp, and three action icons (edit, view, delete). At the bottom, there are "Delete selected" and "Generate Report" buttons.

		Measurement ...	Time Stamp	
▶	<input type="checkbox"/>	Run Heading	12/13/2017 2:03:12 PM	
	<input type="checkbox"/>	scan	12/13/2017 2:03:12 PM	
	<input type="checkbox"/>	Spot Results	12/13/2017 2:03:12 PM	

1. Select the details to be included in the report by checking or unchecking User Information, Environment information, and EUT information.
2. Click the **Edit** button to edit the information, as needed. The following window will appear.





The **Information Form** dialog box is divided into three sections: **User information**, **Environment information**, and **EUT information**. Each section contains input fields for specific data and an **Add Information** button. At the bottom of the dialog are **Save**, **Recall**, **OK**, and **Cancel** buttons.

User information	
Engineer name	Project
Organization	
Add Information	


Environment information	
Temperature 0 °C	Humidity 0 RH
Testing location	
Add Information	

EUT information	
Device type	Manufacturer
Model name	Serial number
Add Information	

Save Recall OK Cancel

3. Click the **Add Information** button in the desired information area to add an extra field or a parameter.
4. Click the **Save** button to save the information to a file for later recall. Or you can simply click the **OK** button to save the information for this report. The Information Form will close and you can then select your results.
5. Check the box next to the result(s) for which you want to generate a report. You can select more than one result if you want to include multiple measurement results in a single report.



6. Click the **Generate Report** button to generate a report.
7. A preview window of the generated report will open. This window allows you to navigate, print, bookmark, email, and export the report. A report can be exported in the preferred format (.pdf, .rtf, .xlsx, etc.) and saved locally for future use. Recommended file types are .pdf and .rtf.
8. To delete existing results from the History panel of the Generate Report tab, check the boxes next to the items you want to delete, and then click the **Delete selected** button. You can also use the edit, view, and delete icons next to a result to perform the related task.

## EMC Troubleshooting

EMC testing with Tektronix provides you the following suite of troubleshooting tools and displays to help you debug problems faster.

### Tools

- [Harmonic Markers \(see page 475\)](#)
- [Inspect \(see page 476\)](#) (suspect frequencies)


- [Level Target \(see page 480\)](#)
- [Compare Traces \(see page 480\)](#)
- [Persistence Display \(see page 484\)](#)


## Displays

- [EMC-EMI \(see page 484\)](#)
- [DPX \(see page 74\)](#)
- [Spectrogram \(see page 99\)](#)
- [Spectrum \(see page 95\)](#)

## Harmonic Markers

Harmonic markers tool allows you to place the markers at selected harmonic factors of a chosen fundamental frequency. It will be helpful for you to see if certain emissions that result out of a scan are caused due to the harmonics of a known fundamental frequency. The harmonic marker toolbar is used to define the fundamental frequency and harmonic factors.

1. Click **Setup > EMC > Harmonic Markers** from the Main menu bar, or click  (Harmonic Markers) on the Favorites bar to open the Harmonic Markers toolbar.



2. Enter the Fundamental frequency in the Harmonic Markers toolbar. This is the base frequency on which harmonics are calculated.
3. Choose the harmonic factors from the drop down for the 5 markers (MR, M1, M2, M3, M4). The harmonic factors in the drop down can be 1/8, 1/4, 1/2, 1, 2, 3, 4, 5, 6, 7, 8, 9 or 10.
4. Click **Apply** to place the markers at the appropriate harmonics.
5. Clicking **Apply** will also open the Marker table which will give information about the frequency at which these markers are placed and the amplitude values can be seen under the respective display column (for example, in the EMC-EMI if that is the active display).

Marker	Frequency	Δ Frequency	Time	Δ Time	Amplitude	Δ Amplitude	Phase	Δ Phase	Distance	Δ Distance	EMC-EMI	Δ EMC-EMI
MR	0.000 Hz		-5.086 ms		106.99 dBm		0.0000 °		0.000 m		---	
M1	0.000 Hz	0.000 Hz	-5.086 ms	0.0000 s	106.99 dBm	0.00 dBm	0.0000 °	0.0000 °	0.000 m	0.000 m	---	---
M2	0.000 Hz	0.000 Hz	-5.086 ms	0.0000 s	106.99 dBm	0.00 dBm	0.0000 °	0.0000 °	0.000 m	0.000 m	---	---
M3	0.000 Hz	0.000 Hz	-5.086 ms	0.0000 s	106.99 dBm	0.00 dBm	0.0000 °	0.0000 °	0.000 m	0.000 m	---	---
M4	0.000 Hz	0.000 Hz	-5.086 ms	0.0000 s	106.99 dBm	0.00 dBm	0.0000 °	0.0000 °	0.000 m	0.000 m	---	---

When the chosen harmonic factors are not in the range of the scan results then the markers could be aligned with the left or right edges to indicate that the chosen factors are outside the range of the scan. For example, if the stop frequency is 6.2 GHz and if we attempt to place a marker at the 10th harmonic of a fundamental frequency that is 1 GHz, then the marker will be placed at 6.2 GHz itself.


---

**TIP.** Harmonic markers can be used for other spectral displays; that is, displays having Amplitude vs Freq, such as Spectrum and DPX). Even if EMC-EMI display is not open, this toolbar can be invoked from **View > Harmonic Markers**.

---

## Inspect

Inspect is a troubleshooting tool you can use to analyze a set of suspect frequencies in more detail. As many as 3 detectors can be selected and the detector results will be shown in a table format for each of the suspect frequencies. The result can also be compared with a comparison level and the entire set of results can be reported out.

Click **Setup > EMC > Inspect** from the Main menu bar, or click  (Inspect) on the Favorites bar to open the Results table, which shows the Inspect results.


On Selecting Inspect from EMC Toolbar or from Setup > EMC > Inspect, the results table and the Settings Control will open.

The measurement can be triggered by clicking Single or Continuous (located at the top of the Results table). The results can also be brought into the Report using the Report tool from EMC Toolbar.

The Inspect display has the following two modes of harmonics measurement:

### Harmonic mode

- In Harmonic mode, the suspect frequencies are built as harmonics of fundamental frequencies.



- The detectors can be chosen from the drop down in the Detectors Setup. As many as 3 detectors can be chosen. Comparison level can also be chosen for each detector too. Dwell time can be controlled too.
- Harmonic factors can be entered for each of the fundamental frequency by clicking on Edit factors (see snapshots below). Final frequency is calculated as Fundamental Frequency \* Harmonic factor. The Edit Harmonic Factors/RBW table will allow you to edit RBW settings for the frequency that is being analyzed. Auto RBW flag will set RBW based on the chosen detector and frequency band in which the final frequency falls.

**Edit Harmonic Factors/RBW**

Fundamental Frequency:

	On	Harmonic Factor	Final Frequency (Hz)	RBW (Hz)	Auto RBW All <input checked="" type="checkbox"/>
▶	✓	1/4	12.500M	9.000k	✓
	✓	1/2	25.000M	9.000k	✓
	✓	2	100.000M	120.000k	✓
	✓	3	150.000M	120.000k	✓
		4	200.000M	120.000k	✓
		5	250.000M	120.000k	✓
		6	300.000M	120.000k	✓
		7	350.000M	120.000k	✓
		8	400.000M	120.000k	✓
		9	450.000M	120.000k	✓

**Done**


- After selecting Single or Continuous in the Inspect Suspect Frequencies display, the Inspect results will be shown and they will be compared with the respective Comparison Levels. Failures will be shown in red.
- Inspect Suspect frequencies can be done in Single (Stops after all suspect frequencies are analyzed once) or Continuous mode (will continue updating the results table until stopped).

**Inspect Suspect Frequencies**


Index	Fundame... Freq (Hz)	Harmonic Factor	Freq (Hz)	RBW (Hz)	Detector1: CISPR QPk	
					Abs	Delta from 11.0 dBuV/m
1	50.000 MHz	1/4	12.500 MHz	9.000 kHz	16.0 dBuV...	5.02 dBuV...
2	50.000 MHz	1/2	25.000 MHz	9.000 kHz	-6.70 dBu...	-17.7 dBu...
3	50.000 MHz	2	100.000 MHz	120.000 kHz	10.4 dBuV...	-0.575 dB...
4	50.000 MHz	3	150.000 MHz	120.000 kHz	11.7 dBuV...	0.653 dBu...
5	35.000 MHz	1	35.000 MHz	120.000 kHz	10.1 dBuV...	-0.927 dB...
6	35.000 MHz	2	70.000 MHz	120.000 kHz	10.2 dBuV...	-0.836 dB...

## Discrete mode


- In Discrete mode, you can develop a list of suspect frequencies by clicking on Edit Frequencies.



- The detectors can be chosen from the drop down in the Detectors Setup. As many as 3 detectors can be chosen. Comparison level can also be chosen for each detector.
- Suspect frequencies can be entered by clicking on Edit Frequencies button.



- The suspect list can also be loaded from “Load from Emission results” which will load the top 15 spots recorded in the Emission Results table at the result of a scan.
- If no spots are listed in the Emission Results table, the following warning message is shown when the **Load from Emission results** button is clicked.



- After selecting Single or Continuous in the Inspect Suspect Frequencies display, the Inspect results in Discrete mode will be shown and the results are then compared with the respective Comparison Levels. Failures are shown in red.


Inspect Suspect Frequencies								
<div> <div>Single</div> <div>Continuous</div> </div>			Settings		Clear			
Index	Freq (Hz)	RBW (Hz)	Detector1: CISPR QPk		Detector2: Avg (VRMS)		Detector3: +Peak	
			Abs	Delta from 11.0 dBuV/m	Abs	Delta from 40.0 dBuV/m	Abs	Delta from 40.0 dBuV/m
1	10.689 MHz	9.000 kHz	20.1 dBuV...	9.13 dBuV...	20.7 dBuV...	-19.3 dBu...	31.0 dBuV...	-9.00 dBu...
2	45.625 MHz	120.000 kHz	14.6 dBuV...	3.62 dBuV...	12.2 dBuV...	-27.8 dBu...	21.2 dBuV...	-18.7 dBu...
3	63.912 MHz	120.000 kHz	14.4 dBuV...	3.37 dBuV...	12.3 dBuV...	-27.7 dBu...	22.2 dBuV...	-17.7 dBu...
4	82.010 MHz	120.000 kHz	17.3 dBuV...	6.32 dBuV...	14.3 dBuV...	-25.7 dBu...	23.7 dBuV...	-16.3 dBu...


In the Inspect Suspect Frequencies display, all detector results are held between acquisitions, unlike the scan results, which are computed with every scan. When the **Clear** button is clicked, all detectors results will be cleared. This will allow you to set a smaller dwell time, even for detectors such as CISPR Quasi Peak, and build stable results over acquisitions, resulting in faster analysis/updating.

## Level Target

Level target is an indicator on the display that can be set by you. You can move it with a mouse. It can also be set at the Peak of the active waveform. This tool is available on four displays (EMC-EMI, Spectrum, DPX, and Spurious). The Level Target will change in other displays when changed in the active display.


You can use Level Target to assign it to the peak of a scan and retain the level for comparison for the next scan and see how it compares with the new scan results.

1. Click **Setup > EMC > Level Target** from the Main menu bar, or click  (Level Target) on the Favorites bar. This will open the Spectrum display and place the Level Target in the display. If the Spectrum display is already open, then hitting Level Target toggles visibility of Level Target.
2. Click the **To Peak** button located on the left side of the Spectrum display to move the Level Target to the peak of the trace. You can also click the **To Peak** button that appears in the Prefs tab of the Spectrum Settings control panel when the **Show Level Target** check box is checked. To hide the Level Target indicator, uncheck the box.




## Compare Traces

This troubleshooting tool can be used to compare traces of different scan results. It can be used to compare as many as 2 Live Scan traces, 3 Spot traces, 5 Recalled traces and a Math Trace (which is the result of subtracting any two traces). Legends for these traces will also appear in the graph.


Click **Setup > EMC > Compare Traces** from the Main menu bar or click  (Compare Traces) on the Favorites toolbar (see page 864) to open the [Traces tab](#) (see page 514) in the EMC Settings control panel.





The control panel is divided into the following three areas:


### Live traces area



- This area includes the traces that are shown on screen after a Scan or Spot re-measurement.
- Include up to a maximum of 2 scan traces and up to a maximum of 3 spot detector results.
- Function is available for Scan traces. This allows you to select to Max-hold or Average multiple acquisition results.
- The **Save Selected Trace As** button is only available if a live trace is selected. This button is disabled if no Live trace is selected.
- The check boxes in the Show column control the visibility of the trace in the main graph display.


### Using Quick Save for Compare button.

- You can compare scan results of two or more successive scan tests using this button.
- This button is only visible when one of the Live traces is selected.
- When you click this button, the selected Live trace is saved automatically in your drive and recalled into one of the rows in Recalled Traces. It will be automatically recalled into a row (Recall1 through Recall 5, in that order) depending on which one is free. The following timed pop-up message will appear indicating the Recall Trace in which it is available for comparison.




- If none of the Recalled Traces are free, then clicking this button will save the trace in your drive and recall the trace as Recall 1 (replacing the earlier recalled trace in Recall 1). However, the files replaced can be browsed for and recalled using the Recall to Selected Trace control.
- All traces saved with this button are saved in the *C:\SignalVu-PC Files* directory.

### Recalled traces area



- Select any Recall trace (Recall 1 to Recall 5) to recall a saved trace.
- The **Recall to Selected Trace** button is only available if a Recall trace is selected.
- Once a trace is successfully recalled, the trace will be displayed in the graph for the chosen frequency range (set in the Ranges & Limits tab of the EMC Settings control panel). Here is an example. The recalled trace is green:



- The recalled trace will be compared with the Limit lines (in the Ranges & Limits control settings) and the Emission results table will be populated. Here is an example:

Emission Results								
Select Spot	Spot #	Range	Freq (Hz)	Scan CISPR +Pk		Recall Trace		
				Ampl	Delta(Limit1)	Ampl	Delta(Limit1)	
<input type="checkbox"/>	1	C	945.801 MHz	17.10 dBuV	-5.90 dBuV	18.57 dBuV	-4.43 dBuV	
<input type="checkbox"/>	2	C	560.226 MHz	-- dBuV	-- dBuV	18.49 dBuV	-4.51 dBuV	
<input type="checkbox"/>	3	C	99.719 MHz	-- dBuV	-- dBuV	22.89 dBuV	-0.11 dBuV	

## Math trace area


Math Trace is a feature that allows you to obtain the subtraction result of any two traces. Two traces must be chosen from the Traces tab and the difference trace will be shown in the graph. The Math trace is done only for log units in Y-axis and the difference trace is calculated by subtraction of the dB values. The Math trace can also be saved (**Save Trace As** button) and recalled (check **Show recalled trace** box).

**Math Trace:**

☒ Show ☐ Freeze

Scan1  minus Recall1  ☐ Show recalled trace


Math Trace allows you to check if emission components still exist from one scan trial to another or even to check if a live scan trace has additional emission components as compared to the emission results obtained from [Ambient](#) (see page 467) (with EUT turned off). The following image shows two traces and a Math trace. You can see that emission components 1 and 2 are emission components that are present in Scan1, but not present in Recall1 (therefore it shows up in Math trace); however, the emission component at the far end is present both in Scan1 and Recall1 (hence cancelled out in the Math trace).



## Persistence Display

This troubleshooting tool launches the DPX Spectrum display. This has the capability to show a persistence view over multiple acquisitions. The speed of DPX allows you to select even transient emissions.

Click **Setup > EMC > Persistence Display** from the Main menu bar, or click **Persistence Display** (Persistence Display) on the Favorites bar, to open the DPX Spectrum display.



**TIP.** You can read more about the [DPX Spectrum display](#) (see page 74) [here](#).

## EMC-EMI display

To show the EMC-EMI display:



1. Double click the **EMCVu** icon on the Desktop to launch EMCVu. This automatically opens the EMC-EMI display.
2. Alternatively, from the analyzer:
  - a. Click the **Displays** button or select **Setup > Displays**.
  - b. From the Measurements box, select **EMC Analysis**.
  - c. Double-click the **EMC-EMI** icon in the **Available displays** box. This adds the EMC-EMI icon to the **Selected displays** box (and removes it from the Available displays box). Alternatively, you can click the EMC-EMI icon and then click the Add button to select EMC-EMI for display.
  - d. Click the **OK** button.

The EMC-EMI display window has three main areas:

1. Graph
2. Emission Results table
3. Inspect suspect frequency display



0720-017

Item	Display element	Description
1	dB/ div	Sets the vertical scale value per division. The maximum value is 20.00 dB/division.
2	Units	Sets the global Amplitude units for all the views in the analysis window. This will change the Amplitude selection in the Units tab of the Analysis Settings control panel.
3	Vert Position	Sets the top of graph value. This is only a visual control for panning the graph. The Reference Level is adjusted in the toolbar and the Ampl Settings control panel. By default, Vert Position = Ref Level.
4	Pass / Fail readout	Indicates whether one or more frequencies have exceeded a limit specified on the <b>Settings &gt; Limits</b> tab. The readout will show as Fail even if a single Spot (either from Scan or Spot Re-measurement) exceeds the Limit line. The Fail criteria can be modified to include Margin from the Prefs tab.
5	Selected trace	Indicates the selected or active trace.
6	Show	Controls whether the selected trace is visible or not. When trace is Off, the box is not checked.
7	Trace function	Indicates the trace processing method. If Average or Max Hold is selected, this readout displays the number of traces being processed (averaged or compared for the Max Hold value).
8	Clear	Restarts multi-trace functions (Average, Max Hold).
9	Stop	Adjusts the graph stop frequency. This setting affects only visual scaling, not measurement parameters.
10	Emission results table	Displays Emission results. See the <a href="#">Emission Results (see page 487)</a> image and table that follow for details.
11	Start	Adjusts the graph start frequency. This setting affects only visual scaling, not measurement parameters.
12	Autoscale	Adjusts the Vertical and Horizontal scaling to display the entire trace on screen. Selects Multi-range display mode.
13	Bottom of graph readout	Indicates the amplitude at the bottom of the graph. This value changes with the dB/div and Vertical Position settings.
14	Green bar	Indicates the range that is selected on the Settings > Ranges and Settings > Limits tabs.
(Not shown)	Inspect suspect frequencies	This portion of the display appears to the right of the EMC-EMI graph when <b>Inspect</b> is selected from the EMC related items on the Favorites toolbar. See the <a href="#">Inspect Suspect Frequencies (see page 487)</a> image and table that follow for more information about this display.

## Emission Results table elements

Emission Results										
Select Spot	Spot #	Range	Freq (Hz)	Scan CISPR +Pk		Spot CISPR QPk		Spot CISPR Avg		
				Ampl	Delta(Limit1)	Ampl	Delta(Limit1)	Ampl	Delta(Limit1)	
<input checked="" type="checkbox"/>	1	A	70.000 MHz	20.8 dBuV...	-0.165 dB...	7.72 dBuV...	-13.3 dBu...	0.452 dBu...	-20.5 dBu...	
<input checked="" type="checkbox"/>	2	B	669.862 MHz	13.0 dBuV...	-4.98 dBu...	9.86 dBuV...	-8.14 dBu...	2.51 dBuV...	-15.5 dBu...	
<input type="checkbox"/>	3	B	820.012 MHz	4.42 dBuV...	-13.6 dBu...	-- dBuV/m	-- dBuV/m	-- dBuV/m	-- dBuV/m	

Column	Description
Select spot	Selects the spot frequency for Re-measurement. Is shown in the graph too with white indicator.
Spot #	A number that identifies a spot in the graph area. The instrument can display a maximum of 999 spots.
Range	The letter representing the frequency range where the spot is located.
Freq (Hz)	The failed frequency at which the spot occurs.
Ampl (Scan)	The amplitude of the spot identified in scan.
Delta (Scan)	Specifies the difference between Amplitude in scan and specified Limit line.
Ampl (Spot)	The amplitude of the spot for chosen detector.
Delta (Spot)	Specifies the difference between Amplitude and specified Limit line for the chosen detector.

- You can rearrange the order of the columns in the Emission Results table. To move a column, click on the column heading and drag it to the desired position.
- You can sort the rows in the Emission Results table by clicking on the column heading. For example, if you click on the Freq, the results in the Emission Results table will be sorted by frequency. If you click on Range, the rows will be sorted by range. Clicking a second time on the same heading reverses the order.
- There can be as many as 2 Scan results (Ampl and Delta for each) and as many as 3 Spot Re-measure results (Ampl and Delta for each) in the Emission results table.
- In addition to that, the Emission results table will also have columns for Recall trace (Amplitude and Delta with Limit 1) and Ambient measurement results (Amplitude and Delta with Scan results).

## Elements of Inspect Suspect Frequencies display

This section of EMC-EMI display shows the results of the Inspect Suspect Frequencies troubleshooting tool. This measurement has the following two modes:

- Harmonic

Inspect Suspect Frequencies

Single

Continuous

Settings

Clear

Index	Fundame... Freq (Hz)	Harmonic Factor	Freq (Hz)	RBW (Hz)	Detector1: CISPR QPk		
					Abs	Delta from 11.0 dBuV/m	
1	50.000 MHz	1/4	12.500 MHz	9.000 kHz	16.0 dBuV...	5.02 dBuV...	
2	50.000 MHz	1/2	25.000 MHz	9.000 kHz	-6.70 dBu...	-17.7 dBu...	
3	50.000 MHz	2	100.000 MHz	120.000 kHz	10.4 dBuV...	-0.575 dB...	
4	50.000 MHz	3	150.000 MHz	120.000 kHz	11.7 dBuV...	0.653 dBu...	
5	35.000 MHz	1	35.000 MHz	120.000 kHz	10.1 dBuV...	-0.927 dB...	
6	35.000 MHz	2	70.000 MHz	120.000 kHz	10.2 dBuV...	-0.836 dB...	

#### ■ Discrete

Inspect Suspect Frequencies									
Single		Continuous		Settings		Clear			
Index	Freq (Hz)	RBW (Hz)	Detector1: CISPR QPk		Detector2: Avg (VRMS)		Detector3: +Peak		
			Abs	Delta from 11.0 dBuV/m	Abs	Delta from 40.0 dBuV/m	Abs	Delta from 40.0 dBuV/m	
1	10.689 MHz	9.000 kHz	20.1 dBuV...	9.13 dBuV...	20.7 dBuV...	-19.3 dBu...	31.0 dBuV...	-9.00 dBu...	
2	45.625 MHz	120.000 kHz	14.6 dBuV...	3.62 dBuV...	12.2 dBuV...	-27.8 dBu...	21.2 dBuV...	-18.7 dBu...	
3	63.912 MHz	120.000 kHz	14.4 dBuV...	3.37 dBuV...	12.3 dBuV...	-27.7 dBu...	22.2 dBuV...	-17.7 dBu...	
4	82.010 MHz	120.000 kHz	17.3 dBuV...	6.32 dBuV...	14.3 dBuV...	-25.7 dBu...	23.7 dBuV...	-16.3 dBu...	

Setting	Description
Single	Selects the spot frequency for Re-measurement. Is shown in the graph too with white indicator.
Continuous	A number that identifies a spot in the graph area. The instrument can display a maximum of 999 spots.
Settings	The letter representing the frequency range where the spot is located.
Clear	The failed frequency at which the spot occurs.



Column	Description
Index	Suspect frequencies numbered in the order in which they are defined.
Fundamental Frequency (Hz) (Harmonic mode only)	Shows the fundamental frequency (Hz).
Harmonic Factor (Harmonic mode only)	Shows the harmonic factor.
Frequency (Hz)	Shows the frequency (Hz).
RBW	The RBW you set in the <a href="#">Ranges &amp; Limits tab (see page 460)</a> of the EMC Settings control panel is shown in here.
Detector	Detector results are shown in two columns (Abs and Delta) from comparison level for each detector.
Abs	
Delta	

---

**TIP.** Read the [Inspect \(see page 476\)](#) topic in the Troubleshooting section for more information about this tool.

---

## EMC-EMI settings

Main menu bar: Setup > Settings

Favorites toolbar: 

The following tabs are available for the EMC-EMI display from the EMC Settings control panel.

### Common controls for RF measurement displays


Settings tab	Description
<a href="#">Parameters (see page 490)</a>	Allows you to specify whether the graph displays one range or multiple ranges. You can also specify whether all <a href="#">spurs/spots (see page 889)</a> are shown or only spurs/spots over specified limits and margins.
<a href="#">Emission Type (see page 491)</a>	Enables you to specify conducted or radiated emissions for the EMI test.
<a href="#">Accessories (see page 492)</a>	Enables you to select, edit, load, and save accessories for conducted and radiated emissions tests.
<a href="#">Ranges &amp; Limits (see page 506)</a>	Allows you to specify the start and stop frequencies for ranges, the parameters that define a spot (for listing in the Emission Results table), and Pass/Fail parameters for limit testing.
<a href="#">Measurement Type (see page 511)</a>	Allows you to define the detectors for scan and spot measurement.
<a href="#">Traces (see page 514)</a>	Provides controls for live traces, recalled traces, and Math trace.
<a href="#">Ambient (see page 518)</a>	settings related to Ambient measurement and Ambient trace control. Ambient measurement can be triggered by selecting Setup > EMC > Measure Ambient or clicking on Measure Ambient in EMC Toolbar. The settings in the Ambient tab of Settings control panel apply only to measurements done by selection of "Measure Ambient" This measurement is useful for capturing emissions caused by environment or the Spectrum analyzer equipment. Before an Ambient scan is done, the EUT must be switched off/or completely removed from the setup. Note - For workflow of this measurement can be done, refer Measure Ambient section in the Pre-compliance section
<a href="#">Scale (see page 520)</a>	Allows you to change the vertical and horizontal scale settings.
<a href="#">Prefs (see page 521)</a>	Allows you to change the parameters of the EMC-EMI display.

**TIP.** Access to a subset of the above settings is available in the [EMC Project Setup Wizard \(see page 452\)](#).

## Parameters tab - EMC

Favorites toolbar: 

This tab is available for the EMC-EMI display from the EMC Settings control panel. It allows you to specify settings that control the EMC Spurious measurement.




Setting	Description
<b>Frequency Ranges</b>	
Multi	Sets the analyzer to display all enabled ranges in the graph.
Single	Limits the graph to display only the first range. Trace is shown only if this range is selected.
<b>List Spots</b>	
All Spots	Displays all frequency peaks that exceed the threshold values set in the Ranges & Limits tab.
Over Limit	Displays frequency peaks that exceed the threshold values and the chosen Limit lines set in the Ranges & Limits tab.
Over limit with margin	Displays frequency peaks that exceed both the threshold values and the margin (corresponding to the chosen limit line).

## Emission Type tab - EMC

### Favorites toolbar:

This tab is available for the EMC-EMI display from the EMC Settings control panel. It allows you to specify the emission type for the EMI test you want to perform. This selection affects the list of accessories available for selection in the Accessories tabs of the EMC Setup wizard and the EMC Settings control panel.




Setting	Description
Conducted	Select when conducted emission tests are to be done. Conducted emission tests measure the radio disturbance voltage at the mains terminal of the equipment under test (EUT) using LISN.
Radiated	Select when radiated emission tests are to be done. Radiated emission tests measure the radio disturbance field strength emitted by the equipment under test (EUT) using an antenna.

## Accessories tab - EMC

### Favorites toolbar:

This tab is available for the EMC-EMI display from the EMC Settings control panel. It allows you to select, edit, load, and save accessories. You can also view a gain/loss plot. More accessories settings are available from the [Accessories \(see page 454\)](#) tab in the [EMC Project Setup Wizard \(see page 452\)](#).



Setting	Description
Accessory name and drop down list	Shows the names of the six selected accessories. You can select from the associated drop down list. The content of the list is determined by the selected emission type. Check the box next to an accessory to select it for a test. You can see a table of all of the available accessories, by emission type, in the <a href="#">Accessories tab (see page 454)</a> topic.
Edit	Click to open a window that allows you to edit the details of the associated accessory. See the <a href="#">Add and/or edit individual accessories (see page 457)</a> topic for detailed information about how to use this window.
View Plot	Click to view a gain/loss plot. This will also show the combined gain/loss as a net impact of all the accessories. You can read more about this in the <a href="#">Combined impact of gains/losses (see page 500)</a> topic.
Load All Accessories	Click to load a complete accessories setup from a saved file. This is faster than loading accessories one by one if you have many.
Save All Accessories	Click to save a complete accessories setup to a file for reuse. Details about all of the accessories will be saved.

---

**TIP.** Read about setting up accessories in the [Accessories setup \(see page 493\)](#) topic.

---



---

**TIP.** Read about available accessories from Tektronix in the [EMC accessories \(see page 419\)](#) topic.


---

## Accessories setup

Accessories can be set up for EMI test using the Accessories tab in the EMC Project Setup Wizard and the one in the EMC Settings control panel. These tabs allow you to set up the accessories required for a test and view a graph showing the combined impact of accessories gains and losses. The final measurement reading is corrected based on these accessory contributions before it is shown in the display. The correction is calculated by negating the combined impact of all of the accessory gains/losses you entered.

When any accessory is selected, its contribution will impact the final measurement results shown in the display. “Ext corrections enabled for traces” is the message you will see in the status bar and display. This message can be suppressed from **Tools > Options > Prefs**.

**TIP.** See the [Accessories tab \(see page 492\)](#) topic for information about the tab in the EMC Settings control panel.



**See these topics about accessories setup:**

- [Available accessories in the drop-down lists \(see page 494\)](#)
- [Combined impact of gains/losses \(see page 500\)](#)
- [Edit accessory contributions \(see page 494\)](#)
- [External correction in DPX \(see page 506\)](#)
- [Loading accessories from a file \(see page 497\)](#)
- [Two types of mismatch issues when recalling the csv file \(see page 497\)](#)
- [Changing accessory details \(see page 496\)](#)

## Available accessories in the drop-down lists

A total of six accessories can be included in the test setup, as shown on the right side of the following image. Accessories can be selected using the drop down lists. The content of these lists depends on the selected emission type, as show in the following table.

Emission type	Available accessories
Conducted	LISN, Cable, Limiter, Amplifier, Attenuator, Filter, Others
Radiated	Antenna, Near field probe, Cable, Amplifier, Limiter, Attenuator, Filter, Others

---

**TIP.** Loss factors of Tektronix supported accessories can be quickly loaded by clicking the [Load Tektronix provided accessories gains/losses \(see page 455\)](#) button.

---

## Edit accessory contributions

Accessories specific information and details like Model no, Serial no, Asset tag, calibration due date can be edited using Edit option. A window such as the one shown below will open. The following images show examples for Amplifier and Antennas (Factor and isotropic gain).

**Edit Amplifier**

Model:

Serial:

Asset Tag:

Cal Due Date:  ☐ Disable Cal Due Date

Select Gain/Loss Format

☐ Constant Gain/Loss

☒ Amplifier Gain/Loss Table

Frequency Interpolation

☒ Linear

☐ Log

Amplifier Gain/Loss (Gain > 0, Loss < 0)

	Freq (Hz)	Gain/Loss (dB)
1	300.000M	35.32441
2	325.000M	35.25395
3	350.000M	35.12368
4	375.000M	34.93034
5	400.000M	34.80666
6	425.000M	34.68036
7	450.000M	34.49289
8	475.000M	34.75072
9	500.000M	34.74375

Add Delete Delete All Rows

Load Save As OK Cancel

**Edit Antenna**

Model:

Serial:

Asset Tag:

Cal Due Date:  ☒ Disable Cal Due Date

Distance:

Select Gain/Loss Format

☐ Constant Gain/Loss

☐ Antenna Gain/Loss Table

☒ Antenna Factor

Frequency Interpolation

☒ Linear

☐ Log

Antenna Factor

	Freq (Hz)	Factor (dB/m)
1	300.000M	13.16621255
2	350.000M	21.03568044
3	400.000M	14.86559991
4	450.000M	16.69212514
5	500.000M	17.41470004
6	550.000M	18.34362689
7	600.000M	19.7365125
8	650.000M	19.54413357
9	700.000M	20.1259804

Add Delete Delete All Rows

Load Save As OK Cancel

**Edit Antenna**

Model:

Serial:

Asset Tag:

Cal Due Date:  ☒ Disable Cal Due Date

Distance:

Select Gain/Loss Format

☐ Constant Gain/Loss

☒ Antenna Gain/Loss Table

☐ Antenna Factor

Frequency Interpolation

☒ Linear

☐ Log

Antenna Gain/Loss (Gain > 0, Loss < 0)

	Freq (Hz)	Gain/Loss (dB)
1	25.000M	-12.82189983
2	30.000M	-12.15827491
3	35.000M	-10.63933911
4	40.000M	-8.369500173
5	45.000M	-6.136449724
6	50.000M	-5.141299913
7	55.000M	-4.73344621
8	60.000M	-4.197674992
9	65.000M	-4.852432867

Add Delete Delete All Rows

Load Save As OK Cancel

Setting	Description
Model	Specify the Model Name/number of the accessory.
Serial	Specify the Serial Number of the accessory.
Asset Tag	Specify any user-specific Asset tag id for the accessory
Cal Due Date	Specify the Calibration due date of the accessory. It can be disabled by checking the check box if not required.
Distance	Specify the Distance between EUT and Antenna (Applies only when accessory is antenna).

Setting	Description
Select Gain/Loss format	Choose between the options available below. A) Constant Gain/Loss, B) Gain/Loss Table. For Antenna, you will have a third selection available C) Antenna Factor
Constant Gain/Loss	Specify the loss value which is constant for the complete frequency range. The Gain/ Loss will be entered in dB. Gain values are entered as positive dB value and Loss as negative.
Gain Loss Table (Corresponds to the accessory selected)	Specify the loss values at specific frequency points. The Gain/ Loss values in these tables will be entered in dB. Gain values are entered as positive dB value and Loss as negative. The values in between the frequency points are interpolated with frequency axis treated as Linear/Log based on the Frequency interpolation selection. Note- For Antenna, this table will be entered in dBi (isotropic Gain values) as shown in the snapshot above
Antenna Factor	Applicable only for Antenna. Antenna factors are given in dB/m. These values are typically available in vendor data sheets. You can also load the typical values from Example Files if you have purchases them from Tektronix.
Frequency Interpolation	Specifies the frequency interpolation method used for interpolating Gain/Loss values or Antenna factors. The frequency axis points are either taken as Linear or Log values based on this choice. Linear interpolation is followed but x axis values can be either in Log or Linear as per this selection.
Load	Click to load a saved Accessory details from a file. This will recall all parameters seen in this window.
Save As	Click to save the Accessory details to a file. (All details shown above)
OK	Click OK to give confirmation of the entered details.
Cancel	Click Cancel to ignore the edit window and exit. This will discard any changes that you might have made before OK is pressed.

## Changing accessory details

To change the accessories details, click on the Edit button present against the antenna which needs to be edited.

1. A dialogue box pop up is displayed which contains the parameters of the accessory to be edited and updated.
2. Parameters to be updated are like Model No, Serial No, Asset Tag, Calibration due date, polarization, Distance, Loss Factor and Frequency Interpolation.
3. Details which are updated can be saved for future analysis by clicking Save all Accessories button which saves the details to a file.
4. Click OK button to load all the updated details of the accessory.



## Loading accessories from a file

### Tek supported accessories

Tektronix supports some of accessories namely Antenna, Amplifier, Near field probe and LISN with their detailed information embedded in a .csv file which is readily available for the user as a part of the software in *C:\SignalVu-PC Files\EMC Accessories*.

### Non-Tek supported accessories

Details of Non - Tek supported accessories can be loaded by preparing a .csv file manually by the user. (You can also build it using the UI by adding a row for each frequency)

The Gain/Loss table values are usually found from the datasheet or graphs and accessory supported documents provided by the vendor when purchased.

You can build a csv file with only two columns (Freq column and Gain/Loss column) without headers and you can load the file into this User interface through Load button. You can also add more frequency rows by editing the csv file. Once you load such a csv file, you can enter the other details like Model, Serial number etc and save the file again and another csv file with all additional details and with appropriate headers would get saved.

---

**TIP.** See the [Two types of mismatch issues when recalling the .csv file \(see page 497\)](#) topic.


---

## Two types of mismatch issues when recalling the .csv file

### Emission type mismatch (for Load All)


When Load All Accessories is used, the complete setup which is saved for a specific emission type can be recalled only when emission type matches. If the Emission type has been changed and if a recall is attempted, “Emission type mismatch” error is shown.

For example, if the setup saved in conducted emission type mode, it cannot be recalled into radiated emission type mode.




### Header type mismatch

If the right type of csv file is not loaded in the Edit Accessory section, then the below error message is shown. For example, if the csv file header line is modified externally, the error message will be shown when an attempt is made to load the csv in the Edit Accessory section.



### Emission Type mismatch (for individual accessories)

When the accessory is specific to Radiated (Near Field Probe or Antenna) or Conducted (LISN) emission type and an attempt is made to Load the accessory information under a different emission type, the following error message is shown. For example, if the Emission Type is Radiated, the error message will be shown if you attempt to load LISN Accessory information in the Edit Accessory section.




## Sorting the Freq column in the Loss Table

- You can sort the Freq column in the Loss table by clicking on the column heading. For example, if you click on the Freq (Hz) header, the results in the loss table will be sorted by frequency. Clicking a second time on the same heading reverses the order.
- When a new row is added, the column is sorted automatically based on the frequency value entered in the new row.
- When an existing frequency value is edited, then the column is sorted automatically based on the frequency value edited.
- When OK is clicked in the edit window of an antenna automatic sorting of loss column is happened.

---


**NOTE.** Duplicate entries of frequency is not allowed either manually or through csv file. Duplicate entry results in an error message stating the row numbers of the duplicate frequencies.

---




## Combined impact of gains/losses


Details of the contribution of each accessory and the combined impact of gains/losses can be viewed in the Impact of Accessories Gains/Losses plot in the Accessories tab. You can select to **Show Points** on the plot and to view the plot in the log or linear frequency scale (shown on the bottom left of the display shown below).



Individual contributions from Antenna, Amplifier, and Cable, and the combined impact, are shown in the above plot.



Individual contribution and combined Gain/Loss factors of LISN and a cable (for conducted emission) are shown in the above plot.




---

**TIP.** Read more about combined impact in the [Calculation of combined impact of accessories gains/losses \(see page 502\)](#) topic.


---

## Calculation of combined impact of accessories gains/losses


### Case 1: non-antenna accessories

Combined gain/loss is calculated by combining the individual gains/losses of individual accessories. Except for Antenna, all accessory gains/losses are in dB (Gain >0, Loss <0). So, the combined gain/loss is calculated by adding all the individual contributions. The plot shows the combined effect in dB.

This combined impact of accessories gains/losses is negated to arrive at the correction factors. Correction factors are applied to the actual spectrum analyzer reading before it is shown in the respective displays.



The Combined impact is calculated only for common frequency range. If there are individual accessories that have different frequency ranges, only the common range is chosen for calculation of combined gain/loss. An example is shown below. The combined loss range matches only that of near field probe, although Cable and Amplifier gain/loss information entered for a wider frequency range.




It is this combined impact that is negated to arrive at correction factors which is eventually applied to the measured trace before it is shown in the displays.

## Case 2: antenna accessories

In case of Antenna, you can enter the accessory contribution either as isotropic gain values or as Antenna factors (both of which is commonly available in vendor data sheets). Isotropic gain should be entered as any other accessory contribution (Gain >0, Loss <0) and Antenna factors is expected to be entered as you would see the factors in any data sheet in dB/m.





**Antenna factors are used to adjust the final reading as follows.** *Corrected Reading (dBuV/m) = Spectrum analyzer Reading (dBuV) + Antenna Factor (dB/m)*

- When you have an Antenna as one of the accessories, the results are also shown in field strength units dBuV/m. Note that the above image has a note that says Antenna factor and Combined Impact are in dB/m.

As mentioned earlier, the combined impact of all accessories are negated to arrive at correction factors. However, as Antenna factors are used as it is given in data sheet for correction of results, Antenna factors are negated before calculating Combined Impact of all Accessories Gains/Losses in the above plot. That is the reason you would observe the combined impact follows the inverse of Antenna factors in the above figure.

**The combined impact in the above case would be as follows.** *Combined Impact (dB/m) = Amplifier Gain (dB) + Cable effect (dB) – Antenna Factor (dB/m)* (Note that the cable effect is entered as Gain >0 and Loss <0.)

And the combined impact is eventually subtracted from:

$$\text{Corrected Reading (dBuV/m)} = \text{Spectrum Analyzer reading (dBuV)} - \text{Combined Impact (dB/m)}$$

Even when the user enters the antenna contribution as isotropic gain, they are converted to antenna factors before presenting in the Combined Impact plot.

$$\text{Antenna Factor (dB/m)} = (20 * \log_{10}(f \text{ (in MHz)}) - 29.7707) - \text{Isotropic Gain}$$

Therefore, in the plot, you will always see the antenna factor contribution and the combined impact is calculated as explained above before it is finally negated to be employed as correction factors to the measured readings.

## Warning when frequency range of scan does not match

A warning message is shown in the plot when the frequency range of the Correction factors (-1\*Combined Impact) is smaller than the frequency range of the scan. When a scan is attempted beyond the frequency range of the Correction factors, the following warning message is shown “Scan range exceeds range of Combined accessories. Reduce scan range”

## External correction in DPX

If external correction due to these accessories are to be applied on the DPX display then this can be done only by selecting All acquired data (filter method).

---


**TIP.** Read more about external gain correction for [DPX \(see page 760\) here](#).

---

## Ranges & Limits tab - EMC

Favorites toolbar: 

This tab is available for the EMC-EMI display from the EMC Settings control panel. It allows you to specify the start and stop frequencies for ranges, the parameters that define a spot (for listing in the Emission Results table), and Pass/Fail parameters for limit testing.



Setting	Description
Expand	Displays the Ranges & Limits table in a new, resizable window.
Table	Shows the ranges and limits for the test. You can edit values in the table directly. You may have to scroll the table to access all settings when multiple ranges are selected. You can reorder columns in the table by dragging the columns to a new position. See the <a href="#">Ranges &amp; Limits table (see page 507)</a> topic below this table for more information.
Reset layout	Returns the column order in the Ranges & Limits table to the factory default order.
Load	Click to load a saved Ranges & Limits table from a file. The default directory is the last folder to which you saved a .csv file.
Save	Click to save the current Ranges & Limits table to a file. The default directory is the last folder to which you saved a .csv file.
Limit 2	Check to set and Limit 2.
Limit 3	Check to set and Limit 3.
Margin	Set the margin value.
Load From Standard	Loads a Ranges & Limits table as defined by a Standard.
Edit Limit Label	Allows you to edit the Limit Label.

## Ranges & Limits table elements

	On	Start (Hz)	Stop (Hz)	RBW (Hz)	Auto	VBW (Hz)	VBW On	Thrshld (dBuV)	Excrsn (dB)	Limit1 Start (dBuV)	Limit1 Stop (dBuV)	Limit1 Same	
A	✓	150.0000...	500.0000...	9.000k	✓	1M		100.00	6.0	130.00	130.00	✓	1
B	✓	500.0000...	5.000000M	9.000k	✓	1M		95.00	6.0	125.00	125.00	✓	1
C	✓	5.000000M	30.000000M	9.000k	✓	1M		85.00	6.0	115.00	115.00	✓	1
D		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
E		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
F		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
G		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
H		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
I		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
J		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
K		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
L		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
M		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
N		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
O		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
P		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
Q		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5
R		0.000000	0.000000	200.000	✓	1M		56.99	6.0	56.99	56.99		5

☒ Limit 2  
☐ Limit 3

Reset Layout  
 Load  
 Save  
 Done

Setting	Description
On	Specifies whether the measurements are taken in the specified range or not.
Start (Hz)	Readout of the start frequency for the selected range.
Stop (Hz)	Readout of the stop frequency for the selected range.
RBW (Hz)	Specifies the Resolution Bandwidth (RBW) used for the selected range.
Auto	Sets the RBW automatically. For CISPR standards, the frequency range determines the RBW.
VBW (Hz)	Adjusts the VBW (Video Bandwidth) value. VBW Maximum: RBW current value VBW Minimum: 1/10,000 RBW setting
VBW On	Specifies whether the VBW filter is applied or not.
Threshold (dBuV or dBuV/m)	Specifies the level that must be exceeded for a signal peak to be recognized as a Spot. A signal peak must also exceed the excursion setting to be considered a Spot.
Excursion (dB)	Specifies the peak to peak magnitude that must be exceeded for a signal peak to be recognized as a Spot. A signal transition must also exceed the threshold setting to be considered a Spot. A Spot requires the amplitude to drop by the excursion amount between Spots.
Limit 1/2/3 Start (dBuV or dBuV/m)	Specifies the limit at the start frequency. The limit values for the frequency range are calculated by linear interpolating between Limit Start and Limit Stop. The frequency start and stop values are taken in Linear or Log, based on the scale choice.
Limit 1/2/3 Stop (dBuV or dBuV/m)	Specifies the limit at the stop frequency. The limit values for the frequency range are calculated by linear interpolating between Limit Start and Limit Stop. The frequency start and stop values are taken in Linear or Log, based on the scale choice.
Limit 1/2/3 Same	Sets the starting and stopping frequencies for Limit 1, Limit 2, and Limit 3 to the same value.
Limit 2	Set and display Limit 2.
Limit 3	Set and display Limit 3.
Margin	Set the margin value.
Rest layout	Returns the column order in the Ranges & Limits table to the factory default order.
Done	Saves changes and closes the Ranges & Limits table expanded window.
Save	Saves the current Ranges & Limits table to a file.
Load	Loads a saved Ranges & Limits table from a file.

#### See these related Ranges & Limits topics:

- [Change range Start and Stop frequencies \(see page 509\)](#)
- [Specify Spot requirements \(see page 509\)](#)
- [Set limits \(see page 510\)](#)

- [Perform Pass/Fail testing \(see page 510\)](#)
- [Load from a Standard \(see page 460\)](#)

## Change range Start and Stop frequencies

To change the range start and stop frequencies from the Ranges & Limits tab edit the Start and Stop frequencies in the table as follows.

1. Click the **Expand** button on the Ranges & Limits tab. This displays the Ranges and Limits table.
2. Check the On box for the ranges that you want to measure.
3. Click on the Start or Stop frequency setting to change it. Type in a number for the frequency and a letter as a multiplier. You can use k, m, or g to set the frequency multiplier.
4. Click **Done** to save your changes.

---

**TIP.** You can read about settings in the [Ranges & Limits tab \(see page 506\)](#) topic.

---

## Specify Spot requirements

A Spot is a signal peak that exceeds both the Threshold and Excursion settings in the Ranges and Limits table. The Threshold and Excursion settings are specific to the selected range. If you want to use different settings for Spots in different ranges, you must set the values separately for each range. The Excursion control is used to avoid interpreting a single spot as multiple narrower spots by requiring the amplitude to drop by the Excursion amount between spots. Raising the Threshold value means that fewer, larger signals will be identified as spots.

Specify the Spot requirements for a range as follows:

1. Click the **Expand** button on the Ranges & Limits tab. This displays the Ranges and Limits Table.
2. Select the **Range** (A–T) for which you want to specify the Spot requirements.
3. Set the **Thrshld** value
4. Set the **Excrsn** value.

Spot specification is also dependent on the **List Spots** selection in the [Parameters \(see page 490\)](#) tab. By default, this selection is All Spots, in which case all frequency peaks above the Threshold (subject to Excursion violation) are classified as Spots for listing in the Emission Results table. If this selection is Over Limit, then only those frequency peaks above the limit line classify as a Spot for listing in the Emission Results table. The third selection is **Over Limit with Margin**, which will only classify frequency peak that violate limit lines with margin included in them.

---

**TIP.** You can read about settings in the [Ranges & Limits tab \(see page 506\)](#) topic.

---

## Set limits

Use the Limits settings in the Ranges & Limits table to specify the [pass/fail \(see page 510\)](#) parameters for the EMC-EMI measurement.

- When the Mask setting is set to any value except off, the analyzer identifies any signal peak that exceeds the specified limits as a violation and displays **Fail** on the screen. If no signal peak exceeds the limits, the analyzer displays **Pass** on the screen.
- The Margin control lets you set the buffer that you want around the limit line.
- The frequency peaks that violate the limit lines are shown in red both in the graph and Emission Results section. If they violate only the limit line, then they are shown in orange.

---

**TIP.** You can read about settings in the [Ranges & Limits tab \(see page 506\)](#) topic.

---

## Perform Pass/Fail testing

Set up Pass/Fail EMI testing using the Ranges & Limits tab and table. All the following parameters can be set manually or loaded from a file or from a specified Standard.

1. Click the **Expand** button on the Ranges & Limits tab. This displays the Ranges and Limits Table.
2. Adjust the Start and Stop frequencies as required for each range you want to test.
3. Verify that the On box is checked for ranges that you want to test.
4. Set the limits in the Start, Stop.
5. Set the required RBW and VBW.
6. Verify that the **Thrshld** and **Excrsn** values are set as required. These are the values that define a Spot.
7. Click **Done** to save your changes and close the Range and Limits table window.
8. Click **Run** to begin testing.

---

**TIP.** You can read about setting limits using the Ranges & Limits tab in the [Set limits \(see page 510\)](#) topic.

---

---


**TIP.** You can read about settings in the [Ranges & Limits tab \(see page 506\)](#) topic.

---

## Measurement Type tab - EMC

Favorites toolbar: 

This tab is available for the EMC-EMI display from the EMC Settings control panel. It allows you to define the detectors for scan and spot measurement.



This tab is divided into the following three areas:

- [Measurements \(see page 511\)](#)
- [Scan Settings \(see page 513\)](#)
- [Spot Measurement Setup \(see page 514\)](#)

The results of Scan and Spot re-measurements are tabulated in the Emission Results table (shown below). This table is accessed from the [EMC-EMI display \(see page 484\)](#).

Emission Results										
Select Spot	Spot #	Range	Freq (Hz)	Scan CISPR +Pk		Spot CISPR QPk		Spot CISPR Avg		
				Ampl	Delta(Limit1)	Ampl	Delta(Limit1)	Ampl	Delta(Limit1)	
<input checked="" type="checkbox"/>	1	A	70.000 MHz	20.8 dBuV...	-0.165 dB...	7.72 dBuV...	-13.3 dBu...	0.452 dBu...	-20.5 dBu...	
<input checked="" type="checkbox"/>	2	B	669.862 MHz	13.0 dBuV...	-4.98 dBu...	9.86 dBuV...	-8.14 dBu...	2.51 dBuV...	-15.5 dBu...	
<input type="checkbox"/>	3	B	820.012 MHz	4.42 dBuV...	-13.6 dBu...	-- dBuV/m	-- dBuV/m	-- dBuV/m	-- dBuV/m	

## Measurements

There are three Measurement settings:


### Pre-scan + Manual Spot

Select to perform a scan with the chosen detector(s) for the selected ranges. The scan will populate the Emission Results table with Spots (frequency peaks that are above Threshold or Limit lines). The application then waits for you to select Spots from the Emission Results table for Re-measurement.

This measurement type is useful for Standard recommended detectors that require longer measurement/dwell time. A quick Pre-scan with Peak detector can be done in such cases. As a second step,




Spots (frequencies that fail Threshold or Limit lines) can be chosen for re-measurement with detectors recommended by the Standard. For example, if the Standard recommends usage of CISPR QP and CISPR Avg detectors, then a pre-scan is performed CISPR +Peak. After the scan, you can choose the Spot(s) for performing Spot Re-measurement using CISPR QP and CISPR Avg detectors (max 3 detectors). The RBW for Spot measurement is chosen based on the ranges and limits set for the scan.



The screenshot shows a window titled "Measurements" with three radio button options. The first option, "Pre-scan + Manual Spot", is selected, indicated by a filled blue circle. The other two options, "Pre-scan + Auto Spot" and "Complete Scan", are unselected, indicated by empty circles.

### Pre-scan + Auto Spot


Select to perform a scan with the chosen detector(s) for the selected ranges. The scan will populate the Emission Results table with Spots (frequency peaks that are above Threshold or Limit lines). The application then automatically triggers a Spot re-measurement for the number of Spots chosen by you. You can control the number of spots to be automatically re-measured under Max Spots, which is visible only when Pre-scan + Auto Spot is selected.



The screenshot shows a window titled "Measurements" with three radio button options. The second option, "Pre-scan + Auto Spot", is selected, indicated by a filled blue circle. The other two options, "Pre-scan + Manual Spot" and "Complete Scan", are unselected, indicated by empty circles.

### Complete Scan

Performs a scan using detector(s) specified by you. You can also choose to load the detector choice from a Standard by clicking the **Load from Standard** button located on the far left side of the Ranges & Limits tab (above the Restore Defaults button) in the EMC Settings control panel. You can also access this button on the Ranges & Limits tab in the EMC Project Setup Wizard.



The screenshot shows a window titled "Measurements" with three radio button options. The third option, "Complete Scan", is selected, indicated by a filled blue circle. The other two options, "Pre-scan + Manual Spot" and "Pre-scan + Auto Spot", are unselected, indicated by empty circles.



When the detector choices are loaded from the standard, Complete Scan will show the actual detectors recommended by the standard and the results will be compared against appropriate limit lines. When the Pre-scan measurement type is chosen, a first scan is done with Peak detector and the actual detectors recommended by the standard and the corresponding limit lines are set in the Spot Measurement setup.

Although you are free to change the detector choice after choosing a measurement type (Pre-scan +Manual Spot, Pre-scan + Auto Spot, and Complete Scan), changing the measurement type will re-load the detectors recommended by the standard, and a detector you added will not be remembered. For example, assume the standard recommends only CISPR QPk for Complete Scan and you choose to add an additional detector in CISPR Avg. If you then change to Pre-scan mode, and then change back to Complete Scan mode, the detector choice will be CISPR QPk, because that is the detector recommended by the standard. Your addition of CISPR Avg is not remembered when the measurement mode is changed.

However, when a setup file is saved, or a project file is saved in EMC Project Setup Wizard, only the detector choices of the chosen measurement type are saved.

## Scan Settings

The following settings are available in the Scan Settings area of the Measurement Type tab.

Scan Setup			
<input checked="" type="checkbox"/>	Detector 1	CISPR QPk	Limit: Limit1
<input checked="" type="checkbox"/>	Detector 2	CISPR Avg	Limit: Limit2
Dwell Time:		2.0 s	<input checked="" type="checkbox"/> Auto

Setting	Description
Detector	<p>Set the detection method using the drop down list. This will be loaded automatically when Load from Standard is chosen from the Ranges &amp; Limits tab of the EMC Settings control panel or EMC Project Setup Wizard.</p> <p>Available detection methods are:  Avg(VRMS), + Peak, MIL +Peak, DEFSTAN Avg, CISPR QPk, CISPR Pk, CISPR Avg, Avg (of logs), and CISPR Avg (of logs).</p>
Limit	<p>Set the limit lines (drop down list shows enabled limit lines) that will be used for comparison for the chosen detector result. As many as 3 limit lines can be defined in the Ranges &amp; Limits tab of the EMC Settings control panel or EMC Project Setup Wizard.</p> <p>When ranges and limits are loaded from a Standard, the Standard typically recommends separate limit lines for each detector type. The limit lines that are loaded as Limit 1/2/3 are mapped to the appropriate detector here.</p> <p>You can also customize your own limit line into one of the three limit lines available and map it to a detector from the drop down for limit lines here.</p>
Dwell Time	Shows the duration of the measurement. When the <b>Auto</b> check box is checked, it sets the Dwell Time automatically based on detector choice.

## Spot Measurement Setup

The following settings are available in the Spot Measurement Setup area of the Measurement Type tab.


Spot Measurement Setup					
<input checked="" type="checkbox"/>	Detector 1	CISPR QPk	Limit:	Limit1	
<input checked="" type="checkbox"/>	Detector 2	CISPR Avg	Limit:	Limit2	Dwell Time: 2.0 s <input checked="" type="checkbox"/> Auto
<input type="checkbox"/>	Detector 3	CISPR QPk	Limit:	Limit1	Max Spots: 10 <input type="checkbox"/> All

Setting	Description
Detector	<p>Set the detection method using the drop down list. This will be loaded automatically when Load from Standard is chosen from the Ranges &amp; Limits tab of the EMC Settings control panel or EMC Project Setup Wizard.</p> <p>Available detection methods are: Avg(VRMS), + Peak, MIL +Peak, DEFSTAN Avg, CISPR QPk, CISPR Pk, CISPR Avg, Avg (of logs), and CISPR Avg (of logs).</p>
Limit	<p>This is the same limit as for Scan Setup, but it is used for Spot re-measurement comparison. You can set the limit lines (drop down list shows enabled limit lines) that will be used for comparison for the chosen detector result. As many as 3 limit lines can be defined in the Ranges &amp; Limits tab of the EMC Settings control panel or EMC Project Setup Wizard.</p> <p>When ranges and limits are loaded from a Standard, the Standard typically recommends separate limit lines for each detector type. The limit lines that are loaded as Limit 1/2/3 are mapped to the appropriate detector here.</p> <p>You can also customize your own limit line into one of the three limit lines available and map it to a detector from the drop down for limit lines here.</p>
Dwell Time	Shows the duration of the measurement. When the <b>Auto</b> check box is checked, it sets the Dwell Time automatically based on detector choice.
Max Spots (Only available when Pre-scan + Auto Spot is selected)	<p>Specifies the maximum number of top Spots in the Emission Results table (resulting from a scan) that will be selected for re-measurement.</p> <p>Check the <b>All</b> check box to include all Spots in the Emission Results table for re-measurement.</p>

## Traces tab — EMC

### Favorites toolbar:

This tab is available for the EMC-EMI display from the EMC Settings control panel. It provides information and controls for the trace results from Scan and Re-measure Spot measurement results. It provides controls for live traces, recalled traces, and Math trace.



Setting	Description
Live Traces	Traces shown here are the trace results for the last Scan or re-measure Spot measurements.
Selected	Selecting a trace makes it the active trace. The active trace shows on the top of the graph and is useful when there are multiple traces viewed together. You can also select a trace from the top of the EMC-EMI display.
Show	Shows / hides the selected live trace.
Trace Name	Specifies the name of the trace. For live traces, these names are set by appending the detector choice with the measurement (Scan vs Spot based on whether scan is done or Re-measure Spot is done). The number after Scan or Spot is based on the number of detectors chosen for Scan and Re-measure spot measurements in the Measurement Type tab of the EMC Settings control panel.
Function	Specifies the function performed on the trace. Applicable only for scan trace in Live Traces.
Count	Specifies the count value for Function when Function is not Normal (Max Hold, Average etc.). When Function is Normal, this control is not editable because the Count is 1.
Quick Save for Compare	<p>Click this button to automatically save the selected Live Trace in your drive and recall it into one of the rows in Recalled Traces, depending on which one is free. The search is done from Recall1 through Recall 5, in that order. There will be a timed pop-up message indicating the Recall trace in which it is available for comparison.</p> <p>If none of the Recalled traces are free, then clicking this button will save the trace in your drive and recall the trace as Recall 1 (replacing the earlier recalled trace in Recall 1). However, the files replaced can be browsed for and recalled using the Recall to Selected Trace function. All traces saved with this button are saved in the <i>C:\SignalVu-PC Files</i> directory.</p> <p>See the <a href="#">Compare Traces (see page 480)</a> topic for additional information.</p>
<a href="#">Save Selected Trace As (see page 516)</a>	Saves the selected live trace to a file for later recall and analysis. This button is active only when a live trace is selected and saved.
Recalled Traces	
Selected	<p>Selecting a trace makes it the active trace. The active trace shows on the top of the graph and is useful when there are multiple traces viewed together.</p> <p>The Emission Results table will be populated with Spots based on the comparison of the selected recalled trace with Limit 1.</p>
Show	Shows / hides the selected recalled trace.
Trace Name	Shows the name of the saved trace.
Trace File Path	Shows the path of the saved trace file to be recalled.
<a href="#">Recall to Selected Trace (see page 516)</a>	Recalls the trace for analysis into the Recalled Traces table.
<a href="#">Math Trace (see page 517)</a>	
Show	Shows / hides the selected Math trace.

Setting	Description
Freeze	Halts updates to the Math trace.
Save Trace As	Saves the selected trace to a file for later recall and analysis.
Show recalled trace	Displays a saved Math trace instead of a live trace. When a Math trace is recalled, controls such as Show, Freeze and selections of traces for Math will be disabled.
Trace selections for Math	The Math trace is the result of subtracting one trace from another. Choose the traces for the difference operation from the two drop down menus. Trace 1 – Trace 2 is performed at every trace point.

### Save a live trace

Live Traces:

	Selected	Show	Trace Name	Function	Count
	<input checked="" type="radio"/>	<input checked="" type="checkbox"/>	Scan1 CISPR +Pk	Normal	1
	<input type="radio"/>	<input type="checkbox"/>	Spot1 CISPR QPk		
	<input type="radio"/>	<input type="checkbox"/>	Spot2 CISPR Avg		

Quick Save for Compare

Save Selected Trace As

To save a live trace for later analysis:

1. Select the **Save Selected Trace As** button. This displays the Save As dialog box.
2. Navigate to the desired folder or use the default.
3. Type a name for the saved trace and click **Save**.

### Recalling Traces

You can recall a previously saved trace for analysis or comparison to a live trace. To select a trace for recall:


1. Select a trace from the Recalled Traces table in the Traces tab and check the **Show** check box next to it. This will be the trace to which you will recall a previously saved trace.

Recalled Traces:

	Selected	Show	Trace Name	Trace File Path
	<input checked="" type="radio"/>	<input checked="" type="checkbox"/>	Recall1	C:\Scan1 CISPR +Pk-201...
	<input type="radio"/>	<input type="checkbox"/>	Recall2	
	<input type="radio"/>	<input type="checkbox"/>	Recall3	
	<input type="radio"/>	<input type="checkbox"/>	Recall4	

Recall to Selected Trace

2. Click the **Recall to Selected Trace** button to display the Open dialog box.
3. Navigate to the desired file or use the default.
4. Select the appropriate trace to be opened and click **Open**.
5. The recalled trace will be plotted on the graph and comparison with Limit 1 will be done. Results will be shown in the Emission Results table.



## Math Trace

The Math trace is a mathematically-derived trace defined as the difference between two traces. You can select the two traces for the difference calculation from the Live Traces, Recalled Traces, and the Ambient Traces.

1. Select any trace from the two drop-down lists provided. Traces can either be live Scan traces, any of the 5 recalled traces, or an Ambient trace.

The difference between the two traces will be derived from the operation Trace1 minus Trace 2.

**Math Trace:**


☒ Show ☐ Freeze

Scan1  minus Recall1  ☐ Show recalled trace

2. Check the **Show** check box to set the Math trace as the active trace on the graph. You can also check the Freeze check box to halt updates of the trace on the graph.
3. Save the Math trace to a file using the **Save Trace As** button.
4. A saved trace can be recalled for analysis as follows:
  - a. Click the ... button.

☐ Show recalled trace

- b. Navigate to the desired file and click Open. The path will appear in the field next to the ....
- c. Check the **Show recalled trace** check box to show the recalled trace. When a trace is recalled under Math, controls such as Show, Freeze, and selections of traces for Math will be disabled.



- The Math function is done for each range set in the Ranges & Limits tab of the EMC Settings control panel.
- If the span or trace points for any range does not match, then an error message will appear for Math traces. For example:
  - “No Math trace: Unmatched trace X range”
  - “No Math trace: Unmatched trace lengths”
- The Math trace is done only for log units in Y axis and the difference trace is calculated by mere subtraction of the dB values.

---

**TIP.** See the [Compare Traces \(see page 480\)](#) topic for more information about using traces for [EMC troubleshooting \(see page 474\)](#).

---

## Ambient tab - EMC

Favorites toolbar: 

This tab is available for the EMC-EMI display from the EMC Settings control panel. It provides settings related to the Ambient measurement and Ambient trace control. These settings only apply to measurements performed when **Measure Ambient** is clicked from the EMC related items on the Favorites toolbar (or **Setup > EMC > Measure Ambient**). This measurement is useful for capturing emissions caused by the environment or the spectrum analyzer equipment.

EMC Settings

Parameters Emission Type Accessories Ranges & Limits Measurement Type Traces Ambient Scale Prefs

☐ Show ☐ Freeze  Dwell Time:  ☒ Auto

Detection:   Delta Threshold:

Function:


Setting	Description
Show	Shows / hides the ambient trace in the graph. Also controls the visibility of the ambient results in the Emission Results table (Amplitude and Delta values). <i>See the <a href="#">Measure Ambient (see page 467)</a> topic for more information about ambient results and how to perform a scan.</i>
Freeze	Halts updates to the ambient trace.
Detection	Sets the detection method. Ambient trace comparison results with Scan will not be shown in the Emission Results table if the detector type of Ambient and Scan do not match. Available detection methods are: Avg(VRMS), + Peak, MIL +Peak, CISPR QPk, CISPR Pk, CISPR Avg, Avg (of logs), CISPR Avg (of logs).
Function	Selects the ambient trace processing method. Available settings are: Normal, Max Hold, Avg (VRMS), and Avg (of logs).
Count	Sets the number of traces averaged to generate the displayed trace. Only available when Function is set to anything other than Normal. When Function is Normal, this control is not editable because the count is 1.
Save Trace As	Saves the selected ambient trace and selected detector to a file for later recall and analysis. Traces are saved along with the selected detector for help in comparing Scan trace with Ambient trace A save performed from the Traces tab saves only the trace. The detector type is not saved.
Show recalled trace	Shows the recalled ambient trace information and the saved selected detector. When this check box is checked, the detection control is loaded with the saved detector result and is not available for selection. Function, Freeze, and Dwell Time controls are also disabled when Show recalled trace is selected. Traces that were saved from the Traces tab can also be recalled into the Ambient tab. However, those recalled traces will not contain saved detector selections. In these cases, you must manually select the detector type before recalling such a trace.
Dwell Time	Shows the duration of the measurement. When the <b>Auto</b> check box is checked, it sets the Dwell Time automatically based on the frequency range set in the Ranges & Limits tab of the EMC Settings control panel.
Delta Threshold	Shows the threshold difference. If the absolute difference between a Scan trace and an Ambient trace is less than the Delta Threshold, then those Spot Ambient results are shown in blue. This threshold setting allows you to <a href="#">quickly check (see page 467)</a> if the peaks/spots obtained are due to ambient interference or the equipment.

**TIP.** *See the [Measure Ambient \(see page 467\)](#) topic for more information about ambient measurements.*

## Scale tab — EMC

Favorites toolbar: 

This tab is available for the EMC-EMI display from the EMC Settings control panel. It allows you to change the vertical and horizontal scale settings. Changing the scale settings changes how the trace appears on the display but does not change control settings such as Center Frequency. In effect, these controls operate like pan and zoom controls.



EMC Settings

Parameters Emission Type Accessories Ranges & Limits Measurement Type Traces Ambient **Scale** Prefs

**Vertical**

Scale: 30.0 dB

Position: 107 dBuV/m

Autoscale

Reset Scale

**Horizontal**

Start: 30.00 MHz

Stop: 1.000 GHz

☐ Log

Autoscale

Restore Defaults


Setting	Description
Vertical	Controls the vertical scale and position of the trace display.
Scale	Changes the vertical scale units. It is 10* dB/div setting on the display.
Position	Sets the value for the top of the display.
Autoscale	Resets the scale of the vertical axis to contain the complete trace.
Horizontal	
Start	Sets the Zoom Start frequency. This only affects the start frequency shown on the graph.
Stop	Sets the Zoom Stop frequency. This only affects the stop frequency shown on the graph.
Log	Sets the display to show the frequency axis in a logarithmic scale. The Limit lines are also interpolated with x-axis in Log scale when this is selected.
Autoscale	Resets the scale of the horizontal axis to contain the complete trace.
Reset Scale	Resets all settings to their default values.



## Prefs tab — EMC

### Favorites toolbar:

This tab is available for the EMC-EMI display from the EMC Settings control panel. It allows you to change the parameters of the EMC-EMI display.



Setting	Description
Show Limit Legends and Label	Shows or hides limit legends and label. Label can be edited in the Ranges & Limits tab.
Show graticule	Shows or hides the graticule in the display.
Show trace legend	Shows or hides the trace legend.
Trace points (per Range)	Sets the number of trace points used for showing scan results. Default value is 8001.
Show Marker readout in graph (selected marker)	Shows or hides the readout for the selected marker in the graph area.
Show Limits	Set how limits are shown: <b>Shaded:</b> Shows limits using a shaded area. <b>Line Only:</b> Shows limits using only a line. <b>Off:</b> No lines or shading are used to indicate limits in the graph.
Include Margin (Pass/Fail Status)	Sets Pass/Fail status to be based on Limit line with margin and not just Limit line.
Show Spot Indicator	Three types of Spot indicators are there (based on whether a Spot violates limit lines, limit lines with margin, or just threshold).
Show Level Target	Shows or hides Level Target in the EMC-EMI display.
To Peak (Only available when Show Level Target is enabled)	Sets the Level target at peak of the trace.
Show Setup Wizard on EMC-EMI display startup	Shows or hides the EMC Project Setup Wizard when launching the EMC-EMI display.



# APCO P25 Analysis

## Overview

The Association of Public Safety Communication Officials (APCO) P25 Compliance Testing and Analysis option allows you to evaluate radio signals to ensure they meet the standards set for the public safety communications community for interoperable LMR equipment. This complete set of push-button Telecommunication Industry Association TIA-102 standard-based transmitter measurements includes modulation measurements, power measurements, and timing measurements. These measurements are also compared with the limits that best fit the signal for which the standard applies to provide pass/fail results.

The P25 measurements available with this option can be made on signals defined by the Phase 1 (C4FM) and Phase 2 (HCPM, HDQPSK) P25 standards. With this test suite, test engineers can simplify the execution of a number of transmitter tests while still allowing for controls to modify signal parameters for signal analysis. The analysis results give multiple views of P25 signal characteristics to allow the diagnosis of signal imperfections and impairments quickly and easily. Display controls allow you to selectively display the analysis results to help locate trouble-spots in the signal.

## P25 Topics

The following information about the P25 Analysis option is available:

- [Reference Table of Supported P25 Measurements \(see page 523\)](#)
- [P25 Standards Presets \(see page 524\)](#)
- [P25 Displays \(see page 525\)](#)
- [P25 Settings \(see page 555\)](#)
- [P25 Measurements \(see page 526\)](#)
- [P25 Test Patterns \(see page 534\)](#)

## Reference Table of Supported P25 Measurements

TIA-102 transmitter measurement	Tektronix measurement display(s) (value name if different from TIA-102 measurement name)	Phase 1	Phase 2
RF output power	P25 Summary P25 Power vs Time	Yes	Yes
Operating frequency accuracy	P25 Summary (Operating Freq Accuracy)	Yes	Yes
Modulation emission spectrum	SEM (The SEM display can be found in Select Displays > RF Measurements)	Yes	Yes
Unwanted emissions: Non spurious adjacent channel power ratio	MCPR (The MCPR display can be found in Select Displays > P25 Analysis)	Yes	Yes

TIA-102 transmitter measurement	Tektronix measurement display(s) (value name if different from TIA-102 measurement name)	Phase 1	Phase 2
Frequency deviation	P25 Summary (Freq Dev)	Yes	HCPM
Modulation fidelity	P25 Summary P25 Constellation	Yes	Yes
Symbol rate accuracy	P25 Summary	Yes	Yes
Transmitter power and encoder attack time	P25 Summary (Phase1 Tx Attack Time) P25 Power vs Time (Power Attack Time and Encoder Attack Time)	Yes	N/A
Transmitter power and encoder attack time with busy/idle operations	P25 Summary (Phase1 Tx Attack Time (Busy/Idle)) P25 Power vs Time (Power Attack Time Busy Idle and Encoder Attack Time Busy Idle)	Yes	N/A
Transmitter throughput delay	P25 Summary (Phase1 Tx Throughput Delay)	Yes	N/A
Transient frequency behavior	P25 Freq Dev vs. Time	Yes	N/A
HCPM transmitter logical channel peak adjacent channel power ratio	P25 Summary (HCPM Tx Logic Ch Pk ACPR)	N/A	HCPM
HCPM Transmitter logical channel off slot power	P25 Power vs Time (Off Slot Power) P25 Summary (HCPM Tx Logic Ch Off Slot)	N/A	HCPM
HCPM Transmitter logical channel power envelope	P25 Power vs Time (Power Info) P25 Summary (HCPM Tx Logic Ch Pwr Env Limits)	N/A	HCPM
HCPM Transmitter logical channel time alignment	P25 Summary (HCPM Tx Logic Ch Time Alignt)	N/A	HCPM

## P25 Standards Presets

The P25 standards preset allows you to access displays preconfigured for the P25 standards you select. You can read more about how Presets work [here](#).

The P25 standards preset allows you to access displays preconfigured for the P25 standards you select. You can read more about how Presets work [here \(see page 25\)](#).


The following table shows the bandwidth, modulation type, and displays that are automatically loaded for each of the listed standards. MCPR masks are also loaded and are explained [here \(see page 525\)](#).

**Table 4: P25 standards, modulation type, bandwidth, and displays**

Standard	Modulation type	Bandwidth (kHz)	Displays loaded with preset
Phase 1	C4FM	12.5	MCPR, Time Overview, P25 Constellation, P25 Summary
Phase 2	HCPM (inbound)	12.5	MCPR, Time Overview, P25 Constellation, P25 Summary
	HDQPSK (outbound)	12.5	

## Retain Current Center Frequency

This setting becomes available when P25 is the selected preset in the Standards Preset window. You can access this window by selecting **Presets > Standards** and then selecting **P25** from the **Preset** drop down menu. To activate the **Retain current Center Frequency Setting**, check the box. This setting allows you to retain the previously used center frequency. By default, the box is unchecked and therefore the four P25 preset displays will load with a center frequency of 850 MHz.



The default adjacent channels table for MCPR is different for RF frequencies in the range of 769 to 806 MHz (called 700 MHz band) and for frequency ranges outside it. The option of retaining center frequency in Standards Preset is therefore useful if you want to load the default table for center frequencies in the 700 MHz band.

**MCPR channel and limit parameters.** The MCPR (ACPR) standard channel and limit parameters that are applied to the P25 signal depend on the standard you select when you configure the preset. Once you select a standard and center frequency, the application will automatically load the parameters and default limits recommended for best performance comparison by the Standard document. All channel and limit parameters are derived from the TIA-102 standard and loaded for you. This provides you the assurance that you are evaluating the signal with the most appropriate parameters.

---

**NOTE.** *Changing analysis and display parameters recalculates the measurement results, but does not affect acquisitions.*

---

## P25 Displays

The displays in P25 Analysis (Setup > Displays > Measurements: P25 Analysis) are:

- [MCPR](#)
- [P25 Constellation \(see page 537\)](#)

- [P25 Power vs Time \(see page 543\)](#)
- [P25 Eye Diagram \(see page 540\)](#)
- [P25 Frequency Dev Vs Time \(see page 552\)](#)
- [P25 Symbol Table \(see page 548\)](#)
- [P25 Summary \(see page 545\)](#)
- [Time Overview \(see page 89\)](#)

## P25 Measurements

The following topics contain important information you should know about specific P25 measurements.

### RF Output Power (Phase 1 and Phase 2)

This is a measure of RF output power when the transmitter is connected to the standard load during defined duty cycle. This measurement is presented as a scalar result in the P25 Summary display. Power variation is shown in the P25 Power vs Time display.

Information of note about this measurement:

- For bursty HCPM (Phase 2 Inbound) signals, the RF Output Power is measured only during the on slot regions centered at the middle of the on slot.
- The result shown in the P25 Summary Display is the average RF Output Power of all the bursts selected in the analysis window.
- If only one on slot region is chosen in the analysis window, then the RF Output Power of only the chosen on slot is reported.
- For non-bursty data, the entire duration of analysis window is considered to obtain RF Output Power.
- The result shown in the P25 Summary display does not account for any attenuation introduced by a user. Ensure that this attenuation is accounted for when you enter limits for comparison.
- The Limits tab in the P25 Summary Settings control panel allows you to compare the results against limits set for Pass/Fail.
- This measurement result is not shown in the P25 Summary display when Trigger Measurements are selected.

---

**NOTE.** Read about important information related to HCPM bursty data measurements [here \(see page 536\)](#).

---

### Operating Frequency Accuracy (Phase 1 and Phase 2)

The Operating Frequency Accuracy is the ability of the transmitter to operate on its assigned frequency. This measurement is presented as a scalar result in the P25 Summary display.

- For bursty HCPM (Phase 2 Inbound) signals, the operating frequency accuracy is measured only during the on slot regions centered at the middle of the on slot.
- The result shown in the P25 Summary display is the average of all the bursts selected in the analysis window.
- If only one on slot region is chosen in the analysis window, then the operating frequency accuracy of only the chosen on slot is reported.
- For non-bursty data, the entire duration of the analysis window is considered to obtain the operating frequency accuracy.
- The Limits tab in the P25 Summary Settings control panel allows you to compare the results against limits set for Pass/Fail.

In Operating Frequency Error, double sided operating frequency error is converted to one sided error and compared against the Absolute Limit.

- This measurement result is not shown in the P25 Summary display when Trigger Measurements are selected.

### Unwanted Emissions (ACPR) (Phase 1 and Phase 2)

This measurement is the ratio of the total power of a transmitter under prescribed conditions and modulation to that of the output power that falls within a prescribed bandwidth centered on the nominal frequency of adjacent channels. This measurement is shown in the MCPR display.

- For HCPM signals, Adjacent Channel Power Ratio analysis is only done on the first on slot region. When the Modulation Type is set to HCPM from any P25 display or from Standards Presets, there will be a search for bursts before ACPR analysis is done. If a burst is found, then analysis is done only on first burst. If a burst is not found, it will show the results of the entire analysis length. The Main Preset will remove the HCPM modulation Type setting, allowing MCPR to work in its regular mode.
- The MCPR display will only have one Main channel for P25 signals in addition to relevant adjacent channels.
- The default adjacent channels table for Unwanted Emissions (ACPR) as suggested by the standard can be loaded by using the P25 Standards Preset option (for which MCPR is one of the four displays).
- The default adjacent channels table for MCPR is different for RF frequencies in the range of 769 to 806 MHz (called 700 MHz band) and for frequency ranges outside it.
- To load the default adjacent channels table of a 700 MHz band, first set the center frequency. Next, select **Presets > Standards** to view the Standards Preset window. Lastly, check the **Retain current Center Frequency Setting** box.
- By default, the Retain Center Frequency box is unchecked and therefore the four P25 preset displays will load with a center frequency of 850 MHz and load the adjacent channels table for non-700 MHz band.
- By default, only six adjacent channels (on either side) will be shown when 700 MHz band is analyzed in P25 (for visual clarity). However, analysis is done for all the ten channels and results will be available in the table just under the display. You can zoom out to see the remaining bands.

## Frequency Deviation (Phase 1 (C4FM) and Phase 2 (HCPM))

This measurement shows the amount of frequency deviation that results for a Low Deviation and High Deviation test pattern. This measurement is shown in the P25 Summary display.

- This measurement only applies to HCPM and C4FM signals and High Deviation or Low Deviation test patterns. If this measurement is run for any other test patterns or for HDQPSK signals, comparisons for limits (set in the Limits tab of the control panel) will result in N/A being shown, as the measurement will not be valid.
- This measurement is done using a FM demodulator without any filter. As a result, it will not be exactly the same as the result given in the P25 Frequency Deviation vs Time display. That display shows the frequency deviation after complete demodulation and might use relevant shaping filters.
- The Low pass filter cut off frequency can be set from the Analysis Params tab of the Settings Control panel. The default value of the cut off frequency is 5 kHz.
- Measurement results are only available when High Deviation, Low Deviation, or Symbol Rate test pattern is selected.
- The scalar result in the P25 Summary display will be shown as f1 (Positive Peak) and f2 (Negative Peak) when analyzing the High Deviation test pattern (or the Symbol Rate test pattern for C4FM signals).
- The scalar result in the P25 Summary display will be shown as f3 (Positive Peak) and f4 (Negative Peak) when analyzing the Low Deviation test pattern.
- The scalar results in the P25 Summary display do not have a corresponding graphical view. A closely representative display would be the FM display (Setup > Displays > Analog Modulation).
- The Limits tab in the P25 Summary Settings control panel allows you to compare the results against limits set for Pass/Fail.

## Modulation Fidelity (Phase 1 and Phase 2)

This measures the degree of closeness to which the modulation follows the ideal theoretical modulation determined by the rms difference between the actual deviation and the expected deviation for the transmitted symbols. This measurement is shown in the P25 Summary and P25 Constellation displays.

- This measurement is done on the first on slot region in the analysis window for bursty HCPM data. The analysis is done on 160 symbols centered at the burst.
- This measurement is done on all of the data chosen in the analysis window for non-bursty modulation types. A warning message is issued if the data is less than 164 symbols (the standard recommends at least 164 symbols be present for the measurement of non-bursty signals).
- This measurement is done by performing the frequency demodulation after taking the signal through relevant shaping filters and comparing it with expected frequency deviation points.
- The Limits tab in the P25 Summary Settings control panel allows you to compare the results against limits set for Pass/Fail.



- This measurement result is not shown in the P25 Summary display when Trigger measurements are selected.
- HDQPSK-P25 filter attempts to remove the Inter Symbol Interference before symbol detection.

---

**NOTE.** Read about important information related to HCPM bursty data measurements [here \(see page 536\)](#).

---

### Symbol Rate Accuracy (Phase 1 and Phase 2)

Symbol Rate Accuracy measures the ability of the transmitter to operate at the assigned symbol rate (4.8 kHz for Phase 1, 6 kHz for Phase 2). It is a scalar result shown in the P25 Summary display.

- This measurement result appears in the P25 Summary display and only applies to High Deviation or Low Deviation test patterns. Test patterns are selected in the Test Patterns tab in the Settings control panel.
- The Limits tab in the P25 Summary Settings control panel allows you to compare the results against limits set for Pass/Fail.
- This measurement only applies to High Deviation or Low Deviation test patterns. If this measurement is run for any other test patterns, comparisons for limits will result in N/A being shown, as the measurement will not be valid.

### Common Trigger Related Measurements

The measurements covered in this subsection have some common information. These measurements are:

- **Transmitter Power and Encoder Attack Time (Phase 1):** This measurement is the time required for a transmitter to prepare and transmit information on the radio channel after changing state from standby to transmit (applies to conventional mode). This measurement result can be seen in the P25 Summary display. A graphical representation of these results can be seen in the P25 Power vs Time display.
- **Transmitter Power and Encoder Attack Time with Busy/Idle Operations (Phase 1):** This measures the time required for a transmitter to prepare and transmit information on the radio channel after the receiving channel changes state from busy to idle. Transmission is inhibited until a status symbol indicates an idle channel. This measurement result can be seen in the P25 Summary display. A graphical representation of these results can be seen in the P25 Power vs Time display.
- **Transmitter Throughput Delay (Phase 1):** This measures the time it requires for audio changes in the microphone to be encoded and transmitted over the air. A calibrated receiver with a known receiver throughput delay is used to monitor the transmitted signal. The aggregate delay of the transmitter under test and calibrated receiver is measured and the desired transmitter throughput delay is then the aggregate delay less the delay of the calibrated receiver. A calibrated Receiver throughput delay from the UI is needed. This measurement result can be seen in the P25 Summary display.
- **Transient Frequency Behavior (Phase 1):** This is a measure of difference of the actual transmitter frequency and assigned transmitter frequency as a function of time when the RF output power is switched on or off. This measurement appears in the P25 Freq Dev vs Time display.
- **HCPM Tx Logical Channel Time Alignment (Phase 2 HCPM):** This measures the ratio of total transmitter power under prescribed conditions and modulation to the peak power that falls in a

prescribed bandwidth centred on the nominal frequency of the adjacent channel during the transmitter power ramping interval. This applies only to inbound signals. This measurement result appears in the P25 Summary display.

---

**NOTE.** *The following information is important when trigger measurements are taken with SignalVu-PC interfaced with an RSA306B, RSA500A Series, RSA600A Series, RSA7100A, or MDO4000B/C Series instrument: 1) The RF signal should be connected to the RF Input of the instrument. 2) For the MDO, one of the 4 analog channels can be set as Trigger input. (Refer to the Trigger Setup section on how to set a channel as trigger in the MDO manual.) 3) In SignalVu-PC, set Triggered mode in the Setup > Acquisition control panel.*

---


**Common information.** The following information applies to all of the measurements in the previous list.

- Select the relevant Trigger measurement from the Trig Meas tab of the control panel.
- When this measurement is chosen from the Trig Meas tab of the control panel, only this result will be populated in the P25 Summary display and everything else will have no result.
- The Time Zero Reference under the Analysis Time tab in the control panel is forced to Trigger.
- Align the Trigger to the RSA/MDO4000B/C as described in the measurement methods standard document.
- When a trigger measurement is chosen from the Trig Meas tab of the control panel, the following status message will appear: *P25: Set instrument in Triggered Mode.*
- Use the Acquisition control panel to select enough acquisition length to ensure that sufficient data is available when the acquisition is triggered.
- This measurement operates in Single Acquisition mode as the acquisition is triggered.
- You can select to do the same experiment multiple times and this measurement will produce an average result of the last 10 single acquisitions. Clicking the **Clear** button on the P25 Summary display will clear the results and start a new measurement.

**Transmitter Power and Encoder Attack Time and Transmitter Power and Encoder Attack Time with Busy/Idle Operations (Phase 1).** The following information is specific to these two measurements.

- The Transmitter Power Attack Time analysis is done by measuring the time taken from the trigger point to the point where the transmitter output power will reach 50% of its maximum value.
- For Encoder Attack Time, the initial frame synchronization word is searched in the demodulated output and the time taken from trigger to the start of the synchronization word is reported as the result.
- When a clear power ramp up is not available, the analysis will report the following error, indicating that no power ramp was received as expected: *Input data too short.* When the synchronization word is not found, the analysis will report the following error: *IQ Processing error.*

- The Limits tab in the P25 Summary Settings control panel allows you to compare the results against limits set for Pass/Fail.
- The P25 Power vs Time display shows marking from trigger point to 50% ramp point and also up to the Synchronization word for Transmitter Power and Encoder Attack Time. Frequency Dev vs Time can also be used to check for the synchronization word. The following image shows this measurement.




**Transmitter Throughput Delay (Phase 1).** The following information is specific to this measurement.

- Select Tx Throughput Delay from the Trig Meas tab of the Settings control panel to get this measurement.
- The original noise source is connected as input to this trigger and the acquisition is triggered when the input from the noise source exceeds the trigger level set by the user.
- The actual input to the RSA/MDO4000B/C comes after the noise signal from the source has passed through the DUT and calibrated receiver as shown in the setup for this measurement in the measurement methods standard document.
- The level in the Trigger control panel set by the user is used for analysis to determine that input to the RSA/MDO4000B/C (after it has gone through the DUT and calibrated receiver) has hit the power levels desired.
- The time difference between the trigger point and the point when the input to the RSA/MDO4000B/C has exceeded the level set by the user for triggering is calculated.
- The calibrated receiver throughput delay entered by the user in the Trig Meas tab in the Settings control panel (this option appears when Throughput Delay is selected) is subtracted from the calculated time difference and reported as Throughput Delay.
- A limit comparison can be performed by selecting the appropriate limits from the Limits tab in the Settings control panel.

**Transient Frequency Behavior (Phase 1).** The following information is specific to this measurement.

- Select Transmitter Frequency Behavior from the Trig Meas tab of the Settings control panel to get this measurement.
- This measurement can be done for On to Off and Off to On behaviors. Select which behavior to measure by selecting the desired behavior from the Transient Frequency drop down list that appears when the Transient Frequency Behavior measurement is selected in the Trig Meas tab of the Settings control panel.
- Select enough acquisition length (from the Acquisition control panel) to ensure that sufficient data is available when the acquisition is triggered. For a transient frequency behavior, there is a need for  $t_1+t_2$  amount of time after  $t_{on}$  as defined in the measurement methods standard document. Approximately 100 ms of data after trigger should ensure that all cases are taken care of as suggested by the standard.  $t_1$ ,  $t_2$ , and  $t_3$  durations are fetched based on the RF frequency range.
- The identification of  $t_{on}$  is done by looking for a significant frequency deviation after a certain power level has been achieved. A manual override for the  $t_{on}$  is also provided in the Trigger Meas tab of the Settings control panel when a Transient Frequency Behavior measurement is chosen. This allows you to manually override the  $t_{on}$  that is calculated (by releasing the Auto Option) and place it appropriately based on the P25 Freq Dev vs Time display. The same is true for  $t_{off}$  when the measurement is being done for the On to Off behavior.
- $t_1$  and  $t_2$  regions are identified after  $t_{on}$  and  $t_3$  before  $t_{off}$  (for the On to Off behavior).
- The mean and max frequency deviation is reported in the regions identified.
- A Pass or Fail is also reported by comparing the Mean frequency deviation with the recommended values given in the standard. A red band is shown if a particular region's result is less than the performance recommendation. The following image shows this measurement.



**HCPM Tx Logical Channel Time Alignment (Phase 2 HCPM).** The following information is specific to this measurement. This result can be viewed in P25 Summary and P25 Power vs Time displays.

- This measurement is done in two steps: First by calculating tOB\_sync using HDQPSK data (the ISCH pattern is looked for) and then by using the result to calculate tIB\_sync using HCPM data (the SACCH pattern is looked for).

The first step is done by choosing Time Alignment (tOB\_sync measurement) in the Trig Meas tab in the Settings control panel.

When the second step, Time Alignment (t\_error\_0 calculation) or (t\_error\_1 calculation) is selected in the Trig Meas tab of the control panel, there is an option to override the tOB\_sync value calculated in the first step.

- When this measurement is chosen, only this result is provided in the P25 Summary display.
- You must provide the ultraframe boundary to the trigger of the analyzer.
- An autocorrelation of the input RF signal with the reference patterns is performed to get the peak that will determine tOB\_sync (measured) and t\_error\_0 or t\_error\_1 from the trigger point.

### HCPM Tx Logical Channel Peak ACPR (Phase 2 HCPM)

This measures the ratio of total transmitter power under prescribed conditions and modulation to the peak power that falls in a prescribed bandwidth centred on the nominal frequency of the adjacent channel during the transmitter power ramping interval. This applies only to inbound signals. This measurement result appears in the P25 Summary display.

- This measurement is done by calculating power in the adjacent channels for the entire duration of data chosen by the user, including the power ramp up and ramp down portions. The standard recommends 360 ms of data for this measurement, unlike the other ACPR measurements for which the analysis is done only for the on slot region.
- The higher and lower adjacent channel power is reported in the P25 Summary display under Power Measurements.
- The two results are then subtracted from the calculated RF output power and the minimum of the two results is presented as the Min Pk ACPR in the P25 Summary display.
- This measurement is only done for bursty HCPM data and not for High Deviation or Low Deviation test patterns.
- The Limits tab in the P25 Summary Settings control panel allows you to compare the results against limits set for Pass/Fail.
- This measurement result is not shown in the P25 Summary display when trigger measurements are chosen.

---

**NOTE.** Read about important information related to HCPM bursty data measurements [here \(see page 536\)](#).

---

### HCPM Transmitter Logical Channel Off Slot power (Phase 2 HCPM)

This measures the power of a TDMA transmitter during the off portion of the TDMA pulse. This measurement only applies to inbound signals. This result can be viewed in P25 Summary and P25 Power vs Time displays.

- The measurement is done as suggested by the standard to calculate  $P_{ONREL}$  and  $P_{OFFREL}$ .  $P_{ONREL}$  is the maximum level observed in the interval 1 ms to 29 ms and  $P_{OFFREL}$  is the maximum level observed in 30.2 ms to 59.8 ms.
- $P_{TX}$  is the rated carrier power and can be set by the user from the Analysis Params tab in the Settings control panel.
- The absolute level of the off slot power is then calculated as  $P_{OFF} = P_{TX} - (P_{ONREL} - P_{OFFREL})$  dBm
- This measurement is only done for bursty HCPM data and not for High Deviation or Low Deviation test patterns.
- The Limits tab in the P25 Summary Settings control panel allows you to compare the results against limits set for Pass/Fail.
- This measurement result is not shown in the P25 Summary display when trigger measurements are chosen.

---

**NOTE.** Read about important information related to HCPM bursty data measurements [here \(see page 536\)](#).

---

### HCPM Transmitter Logical Channel Power Envelope (Phase 2 HCPM)

This is a measure of how well a portable radio controls the transmitter power as it inserts an inbound HCPM TDMA burst into a frame on a voice channel. This measurement applies to inbound signals only.

- All scalar results relevant to this measurement are shown both in P25 Power vs Time display and the P25 Summary display.
- The measurement results and the duration in which the measurements are made are shown graphically in P25 Power vs Time display. The results are grouped under Power Info and Time Info in the table at the bottom of the display.
- This measurement is only done for bursty HCPM data and not for High Deviation or Low Deviation test patterns.
- The Limits tab in the P25 Summary Settings control panel allows you to compare the results against limits set for Pass/Fail.
- This measurement result is not shown in the P25 Summary display when trigger measurements are chosen.

---

**NOTE.** Read about important information related to HCPM bursty data measurements [here \(see page 536\)](#).

---

## P25 Test Patterns

A variety of test patterns are specified in the TIA-102 documents for use in performance testing of transmitters. These test patterns allow the software to compare the measurement result to the standards limit. Test engineers can select from the test patterns described in the following tables.

**NOTE.** Although this table gives the test patterns for measurements as recommended by the Standard, other measurement results are also be provided as additional information for a given test pattern. For example, Modulation Fidelity results can also be provided for High Deviation and Low Deviation test patterns.

**Table 5: P25 test patterns, Phase 1 C4FM**

TIA-102 Phase 1 C4FM test pattern	Phase 1 (C4FM) measurement
Standard transmitter	RF Output Power
	Operating Frequency Accuracy
	Modulation Emission Spectrum
	Unwanted Emissions (Adjacent Channel Power Ratio)
	Modulation Fidelity
	Transmitter Power and Encoder Attack Time
Standard Busy	Transmitter Power and Encoder Attack Time (With Busy/Idle Operations)
Low Deviation	Operating Frequency Accuracy
	Transient Frequency Behavior
	Frequency Deviation
Standard Idle	Transmitter Power and Encoder Attack Time (With Busy/Idle Operations)
Standard Transmitter Symbol Rate (Same as High Deviation test pattern)	Symbol Rate Accuracy
	Frequency Deviation
C4FM Modulation Fidelity	Modulation Fidelity
Standard Tone	Can be used for measurements such as RF Output Power, Operating Frequency Accuracy, Modulation Fidelity, and ACPR
Other (User created test pattern)	Can be used for measurements such as RF Output Power, Operating Frequency Accuracy, Modulation Fidelity, and ACPR

**Table 6: P25 test patterns, Phase 2 Inbound and Outbound**

TIA-102 Phase 2 test pattern	Phase 2 measurement
Standard Transmitter (Inbound and Outbound)	RF Output Power
	Operating Frequency Accuracy
	Modulation Emission Spectrum
	Unwanted Emissions (Adjacent Channel Power Ratio)
	Modulation Fidelity
Inbound Standard Tone Ch0	Can be used for measurements such as RF Output Power, Operating Frequency Accuracy, Modulation Fidelity, and ACPR

**Table 6: P25 test patterns, Phase 2 Inbound and Outbound (cont.)**

TIA-102 Phase 2 test pattern	Phase 2 measurement
Inbound Standard Tone Ch1	Can be used for measurements such as RF Output Power, Operating Frequency Accuracy, Modulation Fidelity, and ACPR
Outbound Standard Tone	Operational Frequency Accuracy
Inbound Symmetrical Time Slot	RF Output Power
	Modulation Emission Spectrum
	Modulation Fidelity
	HCPM (Peak ACPR)
	HCPM (Off slot power)
	HCPM (Power envelope)
Low Deviation (Inbound)	Unwanted Emissions (Adjacent Channel Power Ratio)
	Frequency deviation for HCPM
Low Deviation (Outbound)	Symbol Rate Accuracy
	Symbol Rate Accuracy
High Deviation (Inbound and Outbound)	Symbol Rate Accuracy
Other (User created test pattern)	Can be used for measurements such as RF Output Power, Operating Frequency Accuracy, Modulation Fidelity, and ACPR

### Analysis of HCPM Bursty Data

It important to take into account the following information when analyzing HCPM bursty data.

- It is mandatory that at least one complete on slot and off slot region (including the ramp up and ramp down portion) have to be included in the analysis window for HCPM measurement results to be analyzed.
- If HCPM is the chosen standard in Standards Presets, then a minimum length of 94 ms is set for the analysis window. This is to ensure that a full on slot and off slot region is available irrespective of the selected analysis offset.
- Do not use the High Deviation or Low Deviation test patterns for bursty signals. Test patterns are selected in the P25 Settings control panel on the Test Patterns tab. If selected, analysis would look for a bursty pattern. High Deviation and Low Deviation test patterns are not bursty and therefore do not have the above analysis length restriction.

If you try to set the analysis length to less than 94 ms, the following status message will display:  
*P25:HCPM:Minimum Analysis Length should be  $\geq$  94 ms.*

- Most measurements that are required to be done on on slot regions are done centered at the on slot region of HCPM bursty data.

HCPM Pilot symbols are not displayed in the P25 Symbol Table.



It is mandatory that at least one complete on slot and off slot region (including the ramp up and ramp down portion) have to be included in the analysis window for HCPM measurement results to be analyzed.

The analysis module does not analyze two active adjacent slots (28 ms each) if they do not have the off slot (power off) region between them.

When HCPM bursty data is analyzed, the following status message will appear on all relevant displays:  
*P25:HCPM modulation analysis is done only on on slot regions.*

---

**NOTE.** *The test patterns, except for High Deviation and Low Deviation, do not impact the HCPM pattern analysis for other selected test patterns, such as Standard Transmitter Test Pattern, Inbound Standard Tone Test Pattern Ch0, Inbound Standard Tone Test Pattern Ch1, Inbound Symmetrical Time Bound Test Pattern, and Others.*

---

## P25 Constellation Display


The P25 Constellation Display shows the P25 signal modulation amplitude. For the HCPM and HDQPSK standards, you can view this display as frequency deviation or as I and Q. For the C4FM standard, only the frequency deviation applies.

To show the P25 Constellation display you can select **Presets > Standards > P25** or do the following:


1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **P25 Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **P25 Constellation** icon or select the icon and click **Add**. The P25 Constellation icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the P25 Constellation display.
6. Select **Setup > Settings** to display the control panel.
7. Select the **Modulation Params** tab. Set the Standard, Modulation Type, and Measurement and Reference filters as appropriate for the input signal.
8. For Phase 2 signals, select the **Trace** tab and set the **Trace Type** to Freq Dev or IQ.
9. Select the **Test Patterns** tab and select the desired test pattern as appropriate for the input signal.
10. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

### Elements of the Display

The following image shows the P25 Constellation display set to IQ for a HDQPSK signal.



The following image shows the same signal as the previous image, but with the display set to Frequency Deviation.



Item	Display element	Description
1	Marker Readout	Located to the left of the constellation plot or below it, depending on the size of the window. If markers are enabled, the marker readout will show frequency deviation results or IQ results (time, mag, phase, symbol marker and symbol value) of the point with the selected marker.
2	Measurement results readout	These readouts are located to the left or below of the Constellation plot, depending on the window size. The readout shows Modulation Fidelity (%) and Frequency Error (Hz).  The second readout can either be Freq Error where the result is followed by Auto or it could be Freq Offset where the result is followed by Manual. This choice between Freq Error and Freq Offset is made from the Analysis Params tab in the Settings control panel.
3	Plot	Shown as either I vs Q or as Frequency Deviation. The trace type is controlled from the <b>Settings &gt; Trace</b> tab.

## P25 Constellation Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The P25 Constellation Settings control panel provides access to settings that control parameters of the Constellation Display.

Settings tab	Description
<a href="#">Modulation Params (see page 556)</a>	Specifies the input signal standard and additional user-settable signal parameters.
<a href="#">Analysis Params (see page 559)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Analysis Time (see page 559)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) and Time Zero Reference (Trigger or Acquisition Start) for P25 Analysis displays.
<a href="#">Test Patterns (see page 561)</a>	Specifies the type of test pattern being used. Some analysis differs based on the selected test pattern. Available test patterns vary depending on the selected standard and modulation type.
<a href="#">Trace (see page 562)</a>	Specifies the trace type (Vectors, Points, and Lines), the number of points per symbol when chosen to view as Vectors or Lines, and to control the view as Freq Dev or IQ.
<a href="#">Prefs (see page 565)</a>	Specifies the radix of the marker readout and whether elements of the graphs are displayed.
<a href="#">Trig Meas (see page 564)</a>	Enables you to select from several different trigger measurements.

## P25 Eye Diagram Display


The P25 Eye Diagram display shows a digitally modulated signal overlapped on itself to reveal variations in the signal.

To show the P25 Eye Diagram display:


1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. From the **Measurements** box, select **P25 Analysis**.
4. Double-click the **P25 Eye Diagram** icon in the **Available Displays** box. This adds the P25 Eye Diagram icon to the **Selected displays** box.
5. Click **OK** button. This displays the P25 Eye Diagram view.
6. Select **Setup > Settings** to display the control panel.
7. Select the **Modulation Params** tab. Set the Standard, Modulation Type, and Measurement and Reference filters as appropriate for the input signal.
8. For Phase 2 signals, select the **Trace** tab and set the **Trace Type** to Freq Dev or IQ.
9. Select the **Test Patterns** tab and choose a test pattern appropriate for the input signal.
10. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

### Elements of the Display

The following image shows the P25 Eye display with Trace Type set to IQ.



The following image shows the P25 Eye display with Trace Type set to Freq Dev.



Item	Display element	Description
1	Top of graph	The vertical scale is normalized with no units (for IQ) and with Hz (for Freq dev).
2	Position	Specifies the value shown at the center of the graph display.
3	Bottom Readout	Displays the value indicated by the bottom of graph.
4	Autoscale	Adjusts the vertical and horizontal settings to provide the best display.
5	Position	Displays the horizontal position of the trace on the graph display.
6	Scale	Adjusts the span of the graph in symbols.
7	Freq Error	Displays the difference between the maximum and minimum measured values of the signal frequency during the Measurement Time. The readout can either be Freq Error where the result is followed by Auto or it could be Freq Offset where the result is followed by Manual. This choice between Freq Error and Freq Offset is made from the Analysis Params tab in the Settings control panel.

## P25 Eye Diagram Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the P25 Eye Diagram display are shown in the following table.

Settings tab	Description
<a href="#">Modulation Params (see page 556)</a>	Specifies the input signal standard and additional user-settable signal parameters.
<a href="#">Analysis Params (see page 559)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Analysis Time (see page 559)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for P25 Analysis displays.
<a href="#">Trig Meas (see page 564)</a>	Enables you to select from various trigger measurements. The trigger selections vary by signal type.
<a href="#">Test Patterns (see page 561)</a>	Specifies the type of test pattern being used. Some analysis differs based on the selected test pattern. Available test patterns vary depending on the selected standard and modulation type.
<a href="#">Trace (see page 562)</a>	Specifies the trace type (Vectors, Points, and Lines), the number of points per symbol when chosen to view as Vectors or Lines, and to control the view as Freq Dev or IQ.
<a href="#">Scale (see page 562)</a>	Defines the vertical and horizontal axes.
<a href="#">Prefs (see page 565)</a>	Specifies the radix of the marker readout and whether elements of the graphs are displayed.


## P25 Power vs Time Display

The P25 Power vs Time display shows the signal power amplitude versus time. In HCPM bursty data, the Regions A, B and C are shown based on the middle of the burst and not based on the pilots.

To show the P25 Power vs Time display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **P25 Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **P25 Power vs Time** icon or select the icon and click **Add**. The P25 Power vs Time icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the P25 Power vs Time display.
6. Select **Setup > Settings** to display the control panel.
7. Select the **Modulation Params** tab. Set the Standard, Modulation Type, and Measurement and Reference filters as appropriate for the input signal.
8. Select the **Test Patterns** tab and choose a test pattern appropriate for the input signal.
9. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

### Elements of the Display



Item	Display element	Description
1	Top of graph, first setting	Sets the Power level that appears at the top of the graph, in dBm. This is only a visual control for panning the graph.
2	Units	Sets the global amplitude units for all the views in the analysis window. This will change the amplitude selection in the Units tab of the Amplitude control panel.
3	Top of graph, second setting	Sets the vertical Scale of the graphs, in dB/div. This is only a visual control for panning the graph.
4	View (Only available for bursty HCPM data.)	<p>Selects the specific view of the packet burst within the display:</p> <p>Full Burst displays the entire packet, with vertical lines indicating Power ramp up, On Slot, Power ramp down, and Off slot regions.</p> <p>Ramp Up zooms the display into the interval around the packet rising edge.</p> <p>Ramp Down zooms the display into the interval around the packet falling edge.</p>
5	Bottom of graph readout	Shows the Power level at the bottom of the graph in dBm.
6	Autoscale	Adjusts the vertical and horizontal settings to provide the best display.
7	Bottom of graph, left side	Sets the starting time of the graph in seconds
8	Bottom of graph, right side	Sets the scale (width) of the graph in seconds
9	Table below graph	<p>This table shows the following results.</p> <p>For non-bursty signals: RF output power</p> <p>For bursty signals: Power Info (Offslot Power and Power Envelope results) and Time Info.</p>

## P25 Power vs Time Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the P25 Power vs Time display are shown in the following table.



Settings tab	Description
<a href="#">Modulation Params (see page 556)</a>	Specifies the input signal standard and additional user-settable signal parameters.
<a href="#">Analysis Params (see page 559)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Analysis Time (see page 559)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for P25 Analysis displays.
<a href="#">Trig Meas (see page 564)</a>	Enables you to select from various trigger measurements. The trigger selections vary by signal type.
<a href="#">Test Patterns (see page 561)</a>	Specifies the type of test pattern being used. Some analysis differs based on the selected test pattern. Available test patterns vary depending on the selected standard and modulation type.
<a href="#">Scale (see page 562)</a>	Defines the vertical and horizontal axes.
<a href="#">Prefs (see page 565)</a>	Specifies the radix of the marker readout and whether elements of the graphs are displayed.

## P25 Summary Display

The P25 Summary display shows a summary of all the scalar measurements done on the acquired test pattern. The summary display and contents will vary according to the selected standard.

Pass/Fail information is also provided in this display for all enabled scalar measurements. You can set limits and choose which measurement to compare for Pass/Fail from the Limits tab in the P25 Summary Settings control panel. The default limits come from the performance recommendation limits given by the Standard document. The default limits can be reloaded by selecting the P25 Standards Preset option or by loading the default limits table.

To show the P25 Summary display you can select **Presets > Standards > P25** or do the following:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **P25 Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **P25 Summary** icon or select the icon and click **Add**. The P25 Summary icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the P25 Summary display.
6. Select **Setup > Settings** to display the control panel.
7. Select the **Modulation Params** tab. Set the Standard, Modulation Type, and Measurement and Reference filters as appropriate for the input signal.

8. Select the **Test Patterns** tab and select a test pattern. The available test patterns in the drop down list depend of the standard and modulation type you have selected.
9. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

## P25 Summary Display

The Modulation Measurements, Power Measurements, and Trigger Measurements components of this display vary depending on which modulation type is selected.


The following image shows an example of the display for a Phase 1 C4FM signal.

Standard: Phase1		Bandwidth: 12.5 KHz		Modulation Type: C4FM		Clear	
<b>Modulation Measurements</b>							
Modulation Fidelity:	0.465 %			PASS			
Operating Freq Accuracy:	0 ppm			PASS			
Symbol Rate Accuracy:	-- ppm			N/A			
<b>Frequency Deviation</b>							
Positive Peak:	-- Hz			N/A			
Negative Peak:	-- Hz			N/A			
<b>Power Measurements</b>							
RF Output Power:	10.00 dBm			PASS			
<b>Trigger Measurements</b>							
<b>Phase1 Tx Attack Time</b>							
Avg Tx Pwr Attack	---			N/A			
Avg Tx Encoder Attack	---			N/A			
				--- of 10			
<b>Phase1 Tx Attack Time (Busy/Idle)</b>							
Avg Tx Pwr Attack	---						
Avg Tx Encoder Attack	---						
				--- of 10			
<b>Phase1 Tx Throughput Delay:</b> ---							
				--- of 10			


The following image shows an example of the display for a Phase 1 C4FM High Deviation signal.

Standard: Phase1		Bandwidth: 12.5 KHz		Modulation Type: C4FM		Clear	
<b>Modulation Measurements</b>							
Modulation Fidelity:	0.030 %			PASS			
Operating Freq Accuracy:	0 ppm			PASS			
Symbol Rate Accuracy:	0.00 ppm			PASS			
<b>Frequency Deviation (Symbol Rate Pattern)</b>							
f1 Positive Peak:	2768.93 Hz			PASS			
f2 Negative Peak:	-2865.77 Hz			PASS			
<b>Power Measurements</b>							
RF Output Power:	10.00 dBm			PASS			
<b>Trigger Measurements</b>							
<b>Phase1 Tx Attack Time</b>							
Avg Tx Pwr Attack	---						
Avg Tx Encoder Attack	---						
				--- of 10			
<b>Phase1 Tx Attack Time (Busy/Idle)</b>							
Avg Tx Pwr Attack	---						
Avg Tx Encoder Attack	---						
				--- of 10			
<b>Phase1 Tx Throughput Delay:</b> ---							
				--- of 10			

The following image shows an example of the display for a Phase 2 HCPM (Inbound) signal.



The following image shows an example of the display for a Phase 2 HDQPSK (Outbound) signal.



For more information about specific measurement results, see the P25 Measurements section [here \(see page 573\)](#).

## Elements of the Display

Element	Description
Standard	Display of the standard selected on the Setup > Settings > Modulation Params tab.
Bandwidth	Display of the channel bandwidth which is set based on the standard and modulation type.
Modulation Type	Display of the modulation type selected on Setup > Settings > Modulation Parameters tab.
Clear	Click button to reset measurement. Clears all values.
Modulation Measurements	Shows the modulation measurements associated with the signal.
Power Measurements	Shows the power measurements associated with the signal.
Trigger Measurements	Shows the trigger measurements associated with the signal.

## P25 Summary Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the P25 Summary display are shown in the following table.

Settings tab	Description
<a href="#">Modulation Params (see page 556)</a>	Specifies the input signal standard and additional user-settable signal parameters.
<a href="#">Analysis Params (see page 559)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Analysis Time (see page 559)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for P25 Analysis displays.
<a href="#">Trig Meas (see page 564)</a>	Enables you to select from various trigger measurements. The trigger selections vary by signal type.
<a href="#">Test Patterns (see page 561)</a>	Specifies the type of test pattern being used. Some analysis differs based on the selected test pattern. Available test patterns vary depending on the selected standard and modulation type.
<a href="#">Limits (see page 566)</a>	Load and define P25 measurement limits for Pass/Fail comparison. You can save defined limits as a .csv file and also load previously saved .csv files.

## P25 Symbol Table Display

The P25 Symbol Table display shows decoded data values for each data symbol in the analyzed signal packet.

To show the P25 Symbol Table display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **P25 Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **P25 Symbol Table** icon or select the icon and click **Add**. The P25 Symbol icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the P25 Symbol Table display.
6. Select **Setup > Settings** to display the control panel.
7. Select the **Modulation Params** tab. Set the Standard, Modulation Type, and Measurement and Reference filters as appropriate for the input signal.
8. Select the **Test Patterns** tab and select a test pattern. The available test patterns in the drop down list depend on the standard and modulation type you have selected.
9. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

### P25 Symbol Table

The following image shows the P25 Symbol Table for HCPM (bursty) signals. For this signal type, the symbols are arranged as Bursts vs Symbols. The analysis is done only on the on slot regions of the bursty HCPM data and 160 symbols (centered at the middle of the burst) are reported on the symbol table for every on slot region. You can read more about specific measurements [here \(see page 573\)](#).

	B1	B2
0	1	3
1	3	1
2	2	1
3	1	0
4	2	3
5	3	3
6	0	0
7	3	1
8	2	3
9	1	2
10	0	3
11	2	2
12	3	0
13	1	3
14	2	2
15	2	2
16	0	1
17	0	3
18	0	2
19	3	3
20	2	3
21	1	0
22	3	0
23	1	0

The following image shows the P25 Symbol Table for C4FM (non-bursty) signals. For this signal type and for HDQPSK, there is no grouping into bursts and all symbols that are analyzed are shown.

0	3	2	0	0	0	2	1	1	3	2	2	3	0	2	2	1
16	1	3	3	1	1	3	0	2	2	0	0	3	0	0	0	3
32	3	2	0	2	0	0	0	3	1	2	0	3	1	0	3	2
48	3	2	3	3	3	1	3	1	3	1	0	0	1	1	2	3
64	2	1	2	3	3	3	3	0	2	1	0	2	3	3	3	1
80	0	1	3	3	0	1	3	1	0	1	2	3	1	1	2	2
96	0	2	0	0	3	0	1	3	2	3	0	0	2	2	0	3
112	3	2	3	3	1	0	3	3	2	0	3	0	2	0	0	2
128	1	2	2	1	2	2	2	0	3	1	1	2	2	2	1	2
144	3	1	3	1	3	2	2	0	2	1	1	1	2	0	0	3
160	3	2	2	0	2	3	1	1	3	0	2	2	0	2	3	0
176	2	1	1	0	0	0	3	2	1	1	3	1	3	3	3	2
192	3	1	0	3	1	2	2	2	1	3	3	0	3	0	3	0
208	2	3	3	2	1	3	0	3	1	2	2	2	0	0	0	1
224	0	2	1	0	1	0	1	3	2	3	2	2	3	1	2	0
240	3	2	2	0	2	3	2	1	0	1	3	3	2	1	2	0
256	1	2	3	2	0	0	2	0	0	0	1	0	1	1	0	3
272	3	2	0	2	1	3	3	0	0	3	2	0	3	0	3	3
288	3	2	3	0	2	1	1	1	2	0	1	1	1	2	1	3
304	1	2	3	0	1	0	1	3	1	2	2	1	1	3	3	2
320	1	1	3	2	3	2	0	0	1	0	0	0	3	3	2	1

Marker: MR      Symbol: 152  
Time: 39.578 ms      Value: 2

### Elements of the Display

Element	Description
Marker	Displays the selected marker label.
Time	Displays the time in ms or in Symbols based on the Units chosen in the Analysis Time tab of the Settings Control panel.
Symbol	The value shown here reflects the symbol you have selected (highlighted) in the display.
Value	Displays the value of the selected symbol.

## P25 Symbol Table Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the P25 Symbol Table display are shown in the following table.

Settings tab	Description
<a href="#">Modulation Params (see page 556)</a>	Specifies the input signal standard and additional user-settable signal parameters.
<a href="#">Analysis Params (see page 559)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Analysis Time (see page 559)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for P25 Analysis displays.
<a href="#">Trig Meas (see page 564)</a>	Enables you to select from various trigger measurements. The trigger selections vary by signal type.
<a href="#">Test Patterns (see page 561)</a>	Specifies the type of test pattern being used. Some analysis differs based on the selected test pattern. Available test patterns vary depending on the selected standard and modulation type.
<a href="#">Prefs (see page 565)</a>	Specifies the radix of the marker readout.

## P25 Frequency Dev vs Time Display

The P25 Frequency Deviation vs. Time Display shows how the signal frequency varies with time.


To display the P25 Frequency Dev vs. Time Display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Select the **Displays** button or **Setup > Displays**.
3. In the **Select Displays** dialog, select **P25 Analysis** in the **Measurements** box.
4. In the **Available displays** box, double-click the **P25 Frequency Dev vs. Time** icon or select the icon and click **Add**. The P25 Frequency Dev vs. Time icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to display the Freq Dev vs. Time display.
6. Select the **Modulation Params** tab. Set the Standard, Modulation Type, and Measurement and Reference filters as appropriate for the input signal.
7. Select the **Test Patterns** tab and select a test pattern. The available test patterns in the drop down list depend of the standard and modulation type you have selected.
8. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.


### Elements of the Display

The following image shows the P25 Freq Dev vs Time display for Phase 1 C4FM (non-bursty) High Deviation signals.





The following image shows the P25 Freq Dev vs Time display for Phase 2 HCPM (bursty) signals.



---

**NOTE.** For bursty HCPM signals, frequency deviation analysis is done only on 160 symbols centered at every on slot region in the chosen analysis window and not on off slot regions. That is why there is no information shown during off slot regions. You can read more specific information about P25 measurements [here \(see page 526\)](#).

---

### Elements of the Display

Item	Display element	Description
1	Top of graph adjustment	Adjust the frequency range displayed on the vertical axis.
2	Position (center)	Adjust the frequency shown at the center of the display.
3	Autoscale button	Adjusts the offset and range for both vertical and horizontal to provide the best display.
4	Position	Displays the horizontal position of the trace on the graph display.
5	Scale	Adjust the horizontal scale (time).

[Changing Frequency vs Time Display Settings \(see page 554\)](#)

## P25 Frequency Dev Vs Time Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The Setup settings for P25 Frequency Dev vs. Time are shown in the following table.

Settings tab	Description
<a href="#">Modulation Params (see page 556)</a>	Specifies the input signal standard and additional user-settable signal parameters.
<a href="#">Analysis Params (see page 559)</a>	Specifies parameters used by the instrument to analyze the input signal.
<a href="#">Analysis Time (see page 559)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for P25 Analysis displays.
<a href="#">Trig Meas (see page 564)</a>	Enables you to select from various trigger measurements. The trigger selections vary by signal type.
<a href="#">Test Patterns (see page 561)</a>	Specifies the type of test pattern being used. Some analysis differs based on the selected test pattern. Available test patterns vary depending on the selected standard and modulation type.
<a href="#">Trace (see page 562)</a>	Specifies the trace type (Vectors, Points, and Lines), the number of points per symbol when chosen to view as Vectors or Lines, and to control the view as Freq Dev or IQ.
<a href="#">Scale (see page 562)</a>	Defines the vertical and horizontal axes.
<a href="#">Prefs (see page 565)</a>	Specifies the radix of the marker readout and whether elements of the graphs are displayed.

## P25 Analysis Shared Measurement Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The control panel tabs in this section are shared between the displays in P25 Analysis (Setup > Displays). Some tabs are shared by all the displays, some tabs are shared by only a subset of displays. The settings available on some tabs change depending on the selected display.

**Common controls for P25 analysis displays**

Settings tab	Description
<a href="#">Modulation Params (see page 556)</a>	Specifies the input signal standard and additional user-settable signal parameters.
<a href="#">Analysis Params (see page 559)</a>	Specifies parameters used by the application to analyze the input signal.
<a href="#">Analysis Time (see page 559)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for P25 Analysis displays.
<a href="#">Trace (see page 562)</a>	Specifies the trace type (Vectors, Points, and Lines), the number of points per symbol when chosen to view as Vectors or Lines, and to control the view as Freq Dev or IQ.
<a href="#">Scale (see page 562)</a>	Defines the vertical and horizontal axes.
<a href="#">Test Patterns (see page 561)</a>	Enables you to select from eight different test patterns.
<a href="#">Trig Meas (see page 564)</a>	Enables you to select from various trigger measurements. The trigger selections vary by signal type.
<a href="#">Prefs (see page 565)</a>	Specifies the radix of the marker readout and whether elements of the graphs are displayed.

## Modulation Params Tab - P25

The Modulation Params tab specifies the type of modulation used by the input signal and other parameters that define the signal format.

The screenshot shows the 'Modulation Params' tab selected in a software interface. The tab bar at the top includes 'Modulation Params', 'Analysis Params', 'Analysis Time', 'Trig Meas', 'Test Patterns', and 'Prefs'. The main area contains several controls:

- Standard:** A dropdown menu set to 'Phase2'.
- Measurement Filter:** A dropdown menu set to 'None'.
- Symbol Rate:** A text field displaying '6 kHz'.
- Channel Bandwidth:** A text field displaying '12.5 KHz'.
- Reference Filter:** A dropdown menu set to 'None'.
- Modulation Type:** A dropdown menu set to 'HCPM (Inbound)'.

Settings	Description
Standard	Specifies the standard used for the input signal: Phase 1, Phase 2.
Channel Bandwidth	This readout shows the nominal channel bandwidth based on the standard.
Modulation Type	Specifies the modulation type of the input signal. Choices vary depending on the selected standard. Modulation types for Phase 2 are HCPM (Inbound) and HDQPSK (Outbound). Phase 1 has only C4FM as the modulation type selection.
Measurement Filter	Specifies the filter used as a measurement.
Reference Filter	Specifies the filter used as a reference.
Filter Parameter	Enter a value used for defining the Reference Filter. (Not present for some filter types)
Symbol Rate	This is a readout that shows the symbol rate for demodulating digitally modulated signals based on the standard. This rate is always 4.8 kHz for Phase 1 signals and 6 kHz for Phase 2 signals.

### Symbol Rate

Specifies the symbol rate for demodulating digitally modulated signals based on the standard. The symbol rate and the bit rate are related as follows:

$$(\text{Symbol rate}) = (\text{Bit rate}) / (\text{Number of bits per symbol})$$

The bit rate used for Phase 1 (C4FM) is 9600 bps. For Phase 2 (HCPM and HDQPSK) it is 12000 bps. There are two bits per symbol for all above mentioned modulation types. Therefore, the symbol rate is 4800 Hz for Phase 1 and 6000 Hz for Phase 2.

### Measurement and Reference Filters

The available measurement and reference filters depend on the selected modulation type. The following table shows the recommended filters for the specified modulation types.



**CAUTION.** Although there are other filter types listed in the drop down menu, if you select any filter other than that which is recommended, the measurement results may not be accurate.

Modulation type	Measurement filters	Reference filters
HDQPSK	HDQPSK-P25	None
HPCM	None	None
C4FM	C4FM-P25	RaisedCosine (Filter parameter 0.2)

The measurement filter is applied before the demodulation bit is detected and the ideal reference is calculated.

The reference filter is applied to the internally generated ideal reference signal before the modulation fidelity is calculated.

## How to Select Filters

In a signal transmitter/receiver system, the baseband signal might be filtered for bandwidth limiting or for another kind of necessary shaping that needs to be applied. Normally, a filter in the transmitter ( $F_t$ ) and a filter in the receiver ( $F_r$ ) are applied.

The Measurement Filter setting in the analyzer corresponds to the baseband filter in the receiver ( $F_r$ ): This setting tells the analyzer what filter your receiver uses. When the analyzer is set to the same filter used by the receiver, the analyzer sees the signal as your receiver would. The Measurement Filter setting should be the same as the filter used in the receiver under normal operation (as opposed to testing).

The Reference Filter setting in the analyzer corresponds to the baseband filter in the transmitter-receiver combination ( $F_r * F_t$ ). The baseband filter for the transmitter-receiver combination is often referred to as the *System Filter*. This filter is called the reference filter because it is used to recreate a reference signal that is compared to the received signal. This recreated reference signal is the *ideal signal* with  $F_r * F_t$  applied; differences between this *ideal signal* and the received signal enables the determination of signal quality, such as modulation fidelity measurements.

## Filter Parameter (C4FM only)

The filter parameter specifies the alpha for the Raised Cosine filter when selected as the Reference filter. Some filter types have a fixed parameter value that is specified by industry standard, while other filter types by definition have no filter parameter. For filter types with no filter parameter, there is no filter parameter control present in the control panel. The recommended Reference filter for C4FM is Raised Cosine and the corresponding filter parameter for C4FM is 0.2.

## Analysis Params Tab - P25

The Analysis Params tab contains parameters that control the analysis of the input signal.

P25 Summary Settings

Modulation Params Analysis Params Analysis Time Trig Meas Test Patterns Limits

Frequency Error: 0.0000 Hz ☒ Auto PTX: 30.00 dBm

Measurement BW: 38.40 kHz Auto ☒

Low pass cut off frequency (only for Frequency Deviation): 5.000 kHz

Standard Presets

Settings	Description
Frequency Error	When the Auto box is checked, the analysis determines the Frequency Error and the measured Frequency Error is displayed. When the Auto box is unchecked, the entered value is used by the analysis as a fixed frequency offset. This is useful when the exact frequency offset of the signal is known.
Measurement BW	Specifies the bandwidth about the center frequency at which measurements are made. Select Manual, Auto, or Link to Span.
PTX	Specifies the RF Output Power as recommended for transmitters. This is only used in the computation of off slot power in HCPM modulated signals.
Low Pass cut off frequency (only for frequency deviation)	Specifies the filter cut off frequency for Frequency deviation measurement. This setting will only affect the scalar results Frequency Deviation (Positive and Negative Peak f1,f2,f3, and f4) in the Summary display. This selection is only visible when High or Low Deviation or Standard Transmitter Symbol Rate Pattern is chosen from the Test Patterns tab of the Settings Control panel.

## Analysis Time Tab - P25

The Analysis Time tab contains parameters that define how the signal is analyzed in the P25 Analysis displays.

Modulation Params Analysis Params Analysis Time Test Patterns Prefs Trig Meas

Analysis Offset: -204.800 us ☒ Auto Time Zero Reference: Trigger

Analysis Length: 94.000 ms ☐ Auto Units: Seconds

Available: 31.816 ms

Settings	Description
Analysis Offset	Specifies the location of the first time sample to use in measurements.
Auto	When enabled, causes the instrument to set the Analysis Offset value based on the requirements of the selected display.
Analysis Length	Specifies the length of the analysis period to use in measurements. Length is specified in either symbols or seconds, depending on the Units setting.
Auto	When enabled, causes the instrument to set the Analysis Length value based on the requirements of the selected display.
Actual	This is a displayed value, not a setting. It is the Analysis Length (time or symbols) being used by the analyzer, this value may not match the Analysis Length requested (in manual mode).
Time Zero Reference	Specifies the zero point for the analysis time.
Units	Specifies the units of the Analysis Length to either Symbols or Seconds.

### Analysis Offset

Use analysis offset to specify where measurements begin. Be aware that you cannot set the Analysis Offset outside the range of time covered by the current acquisition data. (all time values are relative to the Time Zero Reference).

You can set the Analysis Length so that the requested analysis period falls partly or entirely outside the current range of acquisition data settings. When the next acquisition is taken, its Acquisition Length will be increased to cover the new Analysis Length, as long as the Sampling controls are set to Auto. If the Sampling parameters are set to manual, or if the instrument is analyzing saved data, the actual analysis length will be constrained by the available data length, but in most cases, measurements are able to be made anyway. The instrument will display a notification when measurement results are computed from less data than requested. Range: 0 to [(end of acquisition) - Analysis Length)]. Resolution: 1 effective sample (or symbol).

### Analysis Length

Use the analysis length to specify how long a period of time is analyzed. As you adjust this value, the actual amount of time for Analysis Length, in Symbol or Seconds units, is shown below the control in the "Actual" readout. This setting is not available when Auto is checked. Range: minimum value depends on modulation type. Resolution: 1 symbol.

### Time Zero Reference


All time values are measured from this point (such as marker position or horizontal position (in Y vs Time displays). Choices are: Acquisition Start or Trigger. When a trigger measurement is chosen from the Trig Meas tab of the Settings control panel, Time Zero Reference is forced to Trigger.

Parameter	Description
Acquisition Start	Time zero starts from the point at which acquisition begins.
Trigger	Time zero starts from the trigger point.



## Test Patterns Tab - P25

Test patterns allow the software to compare the measurement result to the standards limit. The list of available test patterns varies depending on which standard and modulation type is selected.




Settings	Description
Test Patterns	Use this drop-down list to select an appropriate test pattern. The list varies depending on which standard and modulation type is selected.

You can read more about test patterns [here \(see page 534\)](#).

## Trace Tab - P25

The Trace tab allows you to set the trace display characteristics of the P25 trace display. The selections vary depending on the selected display.

The following image shows the tab for the Constellation and Eye Diagram displays. For the other trace displays, the Trace Type setting is not available.



Setting	Description
Trace (P25 Constellation and P25 Eye Diagram displays only)	Select the trace to display. P25 Constellation display only: Select the trace that is hidden or displayed based on whether or not Show is selected.
Show (P25 Constellation and P25 Eye Diagram displays only)	Specifies whether the trace selected by Trace is displayed or hidden.
Freeze (P25 Constellation display only)	Halts updates to the trace selected by the Trace setting. Present for the Constellation display only.
Points/Symbol	Select how many points to use between symbols when connecting the dots. Values: 1, 2, 4, 8.
Content (P25 Constellation and P25 Freq Dev & Time displays only)	Select whether to display the trace as vectors (points connected by lines), points (symbols only without lines), or lines (lines drawn between symbols, but no symbols are displayed). The choices available depend on the display.
Trace Type (P25 Constellation and P25 Eye Diagram displays only)	Select to specify whether the plots in the Constellation and Eye Diagram displays are shown as I vs Q or as Frequency Deviation.

## Scale Tab - P25

The Scale tab allows you to change the scale settings that control how the trace appears on the display but does not change control settings such as Measurement Frequency. There are three versions of the Scale tab for P25 displays.

Scale tab for the P25 Eye Diagram display

Scale tab for the P25 Power vs Time display

Scale tab for the P25 Freq Dev vs Time display

Settings	Description
Vertical	Controls the vertical position and scale of the trace display.
Scale	Changes the vertical scale of the graph.
Position	Adjusts the reference level away from top of the graph.
Autoscale	Resets the scale of the vertical axis to contain the complete trace.
Horizontal	Controls the span of the trace display and position of the trace.
Horizontal Full Burst	
Scale	Allows you to, in effect, change the span.
Position	Allows you to pan a zoomed trace without changing the Measurement Frequency.
Autoscale	Resets the scale of the horizontal axis to contain the complete trace.
Auto	When Auto is checked, the scale and position values for the Symbols graph are automatically adjusted to maintain the optimal display.
Reset	Resets the vertical and horizontal settings.

---


**NOTE.** The Units used for the horizontal scale can be either Seconds or Symbols. To set the units for the horizontal scale, display the Analysis Time tab. On the tab, select the appropriate units from the Units drop-down list.

---


## Trig MeasTab - P25

The Trig Meas tab enables you to choose a trigger measurement. The available measurements in the drop-down menu depend on the standard and modulation type selected in the Modulation Params tab. The Trig Meas tab is not available for Phase 2 HDQPSK (Outbound) signals. You can read more about P25 trigger related measurements [here \(see page 529\)](#).

The following image shows the tab for Phase 1 (C4FM) signals.




The following image shows the tab for Phase 1 (HCPM Inbound) signals.



Settings	Description
Trigger Measurements	Select the trigger measurement test.

## Prefs Tab - P25

The Prefs tab enables you to change appearance characteristics of the P25 Analysis displays. Not all settings on the Prefs tab shown below appear for every P25 display. The Summary display does not have a Prefs tab.



Modulation Params Analysis Params Analysis Time Test Patterns Trace Scale Prefs Trig Meas


Radix: Binary

☒ Show graticule ☒ Show Marker readout in graph (selected marker)

Setting	Description
Show graticule	Shows or hides the graticule.
Show Marker readout in graph (selected marker)	Shows or hides the readout for the selected marker in the graph area.
Radix	Specifies how symbols are displayed in the Symbol Table display and in the Marker readout in the display. There are three choices for Radix: Binary (00,01,10,11), Quaternary (0,1,2,3), and Modulation Symbols (+1,+3,-1,-3).

## Limits Tab - P25

The Limits tab is only available for the P25 Summary display. It enables you to load an existing limits table, save a limits table, or edit limits values.



Setting	Description
Load	Click to load a saved Limits table from a .csv file.
Save	Click to save the current Limits table to a .csv file.

### Edit Limits

To directly edit measurement limits in the table, click on the value in the Limit column that you want to change.

The following table describes the parameters that are set in the Limits Table.

#### Limits Table Settings

Setting	Description
On	Click on the cell in the On column next to the measurement to specify whether or not measurements are selected for limit comparison to indicate Pass or Fail.. A check mark means the measurement will be taken. An empty box means it will not be taken.
Measurement Name	Specifies the name of the measurement related to the limit. (Not editable.)
Limit	Specifies the value of the limit to the related measurement. When the cell is selected, the value is shown along with the units.

# LTE Analysis

## Overview

The Long Term Evolution (LTE) Downlink RF Measurements Analysis option allows you to evaluate RF signals to ensure that they meet 3GPP measurements. These are described in the TS 36.104 Base Station (BS) radio transmission and reception and test specifications TS36.141 Base Station (BS) conformance testing documents version 12.5. This analysis option supports both LTE TDD and LTE FDD frame structures. This analysis option supports the following measurements.

- Channel Power
- Occupied Bandwidth
- Adjacent Channel Leakage Ratio (ACLR)
- Spectral Emission Mask (Operating Band Unwanted Emission)
- Cell ID
- For TDD LTE Transmitter Off Power
- Reference Signal Power

These measurements are also compared with the limits provided by the standard to give pass/fail results (except for Channel Power and OBW).

More detailed information about these measurements is available in the [LTE measurements](#) section and the supported measurements [table](#).

You can also select these measurements from four LTE preset test setups. The test setups load pre-configured displays and control setting as suggested by the standard to accelerate the test setup of the analyzer. The following four test setups are available for this analysis option.

- Cell ID
- ACLR
- Channel Power and TDD Toff Power
- SEM

More detailed information about these test setups is available [here](#).

With the LTE downlink RF Measurement Analysis test suite, test engineers can simplify the execution of a number of transmitter tests while still enabled to modify signal parameters for in-depth signal analysis. The analysis results give multiple views of LTE signal characteristics to allow the diagnosis of signal imperfections and impairments quickly and easily. Display controls allow you to selectively display the analysis results to help locate trouble spots in the signal.

## LTE topics in this Help

The following information about the LTE Analysis option is available:

- [Reference table of supported LTE measurements](#)
- [LTE measurements](#)
- [LTE Standards preset test setups](#)
- [LTE displays](#)
- [LTE measurement control settings](#)

## Supported LTE measurements

The following table gives a brief description of the available LTE measurements. More detailed information can be found here. [LTE measurements](#)

LTE measurement	LTE standard(s)	Description
Cell ID detection	TDD FDD	The Cell ID is detected from the input LTE signal.
Adjacent Channel Leakage Ratio (ACLR)	TDD FDD	The Adjacent Channel integrated power is calculated and shown. The relative power compared to the reference signal is also computed. The computed power is compared against limits suggested by the selected standard and pass/fail is reported. The appropriate settings for this measurement are loaded with the ACLR test setup (Presets>Standards>LTE).
Channel Power	TDD FDD	The channel power is calculated in the channel bandwidth.
Occupied Bandwidth	TDD FDD	The Occupied bandwidth is calculated as bandwidth containing 99% of the total integrated power in the selected span around the selected center frequency.
Operating Band Unwanted Emission	TDD FDD	The power in the offset regions is calculated and presented and compared against limits set in the offset and limits table and pass/fail is reported. The appropriate settings for this measurement are loaded with the SEM test setup (Presets>Standards>LTE).
Toff	TDD	The power in off-slot region is computed and compared against selected limits.
Reference Signal Power	TDD FDD	Measures the power of cell specific reference signals.

## LTE Standards preset test setups


**Presets > Standards**




The LTE Standards preset allows you to access displays preconfigured for the test setup you select. The test setups load the displays and control setting options suggested by the LTE standard to perform the measurements. You can read more about how Presets work [here](#).

There are four test setups for LTE:


■ **Cell ID**




■ **ACLR**



## ■ Channel Power and TDD Toff Power



## ■ SEM



The following table shows what automatically loads with each test setup.

**Table 7: LTE preset test setups**

Test setup		Displays loaded with preset
Cell ID	Frame structure: - Downlink FDD - Downlink TDD (Default is Downlink FDD.)	Spectrum, Time Overview, LTE Constellation
	Channel bandwidth: 1.4, 3, 5, 10, 15, 20 MHz (Default is 1.4 MHz.)	
ACLR	Frame structure: - Downlink FDD - Downlink TDD (Default is Downlink FDD.)	LTE ACLR
	Channel bandwidth: 1.4, 3, 5, 10, 15, 20 MHz (Default is 1.4 MHz.)	
	Base station category: - Wide Area Cat A - Wide Area Cat B — Option 1 - Home Area (P-rated $\leq 20$ dBm) - Local Area (P-rated $\leq 24$ dBm) - Medium Area (P-rated $\leq 38$ dBm) (Default is Wide Area Cat A.)	
	Adjacent channel type: - UTRA - E-UTRA (Default is UTRA.)	
	UTRA chip rate. 1.28 Mcps 3.84 Mcps 7.68 Mcps	
	Chip rate is only displayed under the following conditions: TDD is frame structure Adjacent channel type selected is UTRA Channel bandwidth is $>3$ MHz (Default chip rate is 3.84 Mcps.)	
Channel Power and TDD Toff Power	Frame structure: - Downlink FDD - Downlink TDD (Default is Downlink FDD.)	Time Overview (TDD only), LTE Channel Spectrum, LTE Power vs Time (TDD only)
	Channel bandwidth: 1.4, 3, 5, 10, 15, 20 MHz (Default is 1.4 MHz.)	

Table 7: LTE preset test setups (cont.)


Test setup	Displays loaded with preset
SEM Frame structure: - Downlink FDD - Downlink TDD (Default is Downlink FDD.) Channel bandwidth: 1.4, 3, 5, 10, 15, 20 MHz (Default is 1.4 MHz.) Base station category: - Wide Area Cat A - Wide Area Cat B — Option 1 - Home Area ( $2 \text{ dBm} \leq P \leq 20 \text{ dBm}$ ) - Local Area - Medium Area ( $P \leq 31 \text{ dBm}$ ) (Default is Wide Area Cat A.)	SEM

### Retain current center frequency and reference level settings

The **Retain current Center Frequency setting** appears when the LTE Standards Preset is chosen. This setting allows you to retain the previously used center frequency. By default, the Center Frequency setting box is unchecked and the LTE preset displays will load with 1.96 GHz for FDD and 1.9 GHz for TDD.

The **Retain current Ref Level setting** appears when the LTE Standards Preset is chosen. This setting allows you to retain the previously used reference level. By default, the Ref Level setting box is checked.


To activate these settings, check the box next to the desired setting. The following image shows the **Retain current Ref Level setting** box checked.



## LTE displays

The displays in LTE Analysis (Setup > Displays > Measurements: LTE Analysis) are:

- [LTE Channel Spectrum](#)
- [LTE ACLR](#)
- [LTE Constellation](#)
- [LTE Power vs Time](#)
- [SEM](#) (This display is not an LTE specific display, but is available when RF Measurements is selected from the Select Displays dialog (Setup > Displays) (see the following image).)



## LTE measurements

LTE Analysis enables RF measurements and detection of Cell ID in the transmitted signal for both TDD and FDD frame structure LTE signals. For TDD signals, the analysis will also do the  $T_{\text{OFF}}$  measurement. The following topics contain important information you should know about specific LTE measurements. You can view a table with all of the available measurements [here](#).

### Channel Power and Occupied Bandwidth (TDD and FDD)

The Channel Power measurement is done by calculating the power in the LTE signal based on the selected channel bandwidth option. The Occupied Bandwidth measurement calculates the frequency range over which 99% of the power is contained in the acquired signal. This measurement is done for the selected channel bandwidth option.

More information about this measurement:

- Select the Channel Power and TDD Toff Power test setup from Presets > Standards > LTE to perform the measurement. This will load the displays found in the [LTE preset test setups table](#).
- This test setup allows you to choose the frame structure and the channel bandwidth.
- The Channel Spectrum display will contain the results of Channel Power and Occupied Bandwidth. The result gives the power in the LTE signal (calculated over the channel bandwidth).
- Results are presented as scalar and are located below the display.
- For TDD signals, the channel power and the occupied bandwidth measurement are done on the on-slot region. If the valid on-slot region is not found, the measurement is done in the selected analysis length.

### ACLR (FDD and TDD)

The Adjacent Channel specification and limits for comparison are set based on selected frame structure, adjacent channel and base station types from Standards Presets. It calculates the integrated power in the different adjacent regions and also indicates pass/fail based on comparison with absolute and relative limits in LTE ACLR display.

More information about this measurement:

- Select the ACLR test setup from Presets > Standards > LTE to perform the measurement. This will load the displays found in the [LTE preset test setups table](#).
- This test setup allows you to select the frame structure, channel bandwidth, base station type, and adjacent channel type with the following restrictions:
  - Frame Structure can be TDD or FDD
  - Channel Bandwidth can be 1.4, 3, 5, 10, 15, or 20 MHz
  - Base station type can be Wide Area Cat A, Wide Area Cat B- Option 1, Home Area (P-rated  $\leq 20$  dBm), Local Area (P-rated  $\leq 24$  dBm), Medium Area (P-rated  $\leq 38$  dBm)
  - Adjacent Channel type can E-UTRA or UTRA
  - UTRA chip rate can be 1.28, 3.84, or 7.68 Mcps

Default rate is 3.84 Mcps for all UTRA adjacent channels of FDD and when channel bandwidth is 1.4 or 3 MHz.

However, you can choose other rates when the frame structure is TDD and when the bandwidth is more than 3 MHz. Otherwise, the standard recommends use of 3.84 Mcps.

- Based on the settings you select from Standards Preset, the offset and bandwidth of the adjacent channels are set in the Offset and Limits tab of the control panel. The settings are different for paired and unpaired spectrum.
- The settings also include the absolute power limit for comparison based on the base station type. The standard recommends the settings in dBm/MHz for each base station type. The power limits are appropriately scaled with the integration bandwidth and presented in dBm in the Offset and Limits table of the display. The integrated power in each adjacent band is compared with the absolute and relative limits as recommended by the standard. The absolute limits are dependent on this choice of

base station type because they apply to different power levels (as the P-rated levels in the drop down menu indicate). The relative limit is also set.

- The results are presented in both tabular and display format. In the tabular display, the reference channel power and the offset, bandwidth, integrated power, and relative power of the adjacent channels are presented. An expanded view format is also available.
- The integrated power in the display is shaded blue in each adjacent channel region.
- Each adjacent channel is clearly shown. Interadjacent channel gaps are shown in gray.
- The limit lines are shown in different colors. Based on the Mask option chosen in the Offset & Limits table, failures in the different bands are shown in red on violation. By default for LTE Standards Presets, the Mask option is Abs & Rel, so the failure is shown only when the calculated power violates both relative and absolute power limits.
- The respective rows that violate both absolute and relative limits are also shown in red. Pass/fail information appears in the top left corner of the display.
- This measurement can be performed in Real Time or Non-Real Time mode. In Real Time mode, a single acquisition required for the entire span needed for this measurement is taken and the measurement is done. In the Non-Real Time mode, a separate acquisition for each adjacent channel region is taken and analyzed.

Non-real time mode is also useful when the bandwidth offered by the instrument does not support the span requirement for this measurement. The span requirement comes from the choice of adjacent channel type and channel bandwidth. In such cases, Non-Real Time mode can be used.

- For UTRA adjacent channels, filtering of the adjacent channels with an RRC filter of the same bandwidth is employed, as suggested by the standard. The chip rate is set to 3.84 Mcps for FDD and when the channel bandwidth is 1.4 or 3 MHz. For TDD, when the channel bandwidth is more than 3 MHz, you can choose the UTRA chip rate from the ACLR test setup (Presets > Standards > LTE). The options are 1.28, 3.84, and 7.68 Mcps.
- The standard recommends this measurement be done on the transmitter ON period when the signal being analyzed is TDD. An on slot detection module in the analysis helps you to do the measurement in the transmitter ON period.
  - If you are doing the measurement in Real Time, you can also load the Time Overview display, which will indicate to you the region in which the measurement is done (a purple line at the bottom). You can see the measurement is done only on the valid transmitter ON period. However, when a bursty data is not available, the measurement is done on the available analysis length.

---

**NOTE.** Real-Time mode can be set from the [Parameters tab](#) of the Settings control panel of the LTE ACLR display. Disabling Real-Time mode is the non-Real-Time setting.

---

- When the measurement is done in non-Real Time mode, separate acquisitions are obtained for each adjacent channel band. In such cases, it cannot be ensured that all the adjacent channel acquisitions are done on the transmitter ON period. It is recommended that you use either Real time mode or an external trigger from the source (when used with non-Real-Time mode) to do the measurement. An external trigger from the source can ensure that all the acquisitions are done just

after the rising edge of the burst. A status message in the display indicates when to use Real-Time mode or external trigger for TDD signals. The status message that is displayed in the LTE ACLR display is "Signal must be triggered or measurement in Real-Time". This message is displayed when TDD is chosen from Standard Presets, when Real-Time is not enabled from the Parameters tab of the control panel, and when the instrument is in Free Run mode.

## Operating Band Unwanted Emission (FDD and TDD)

This measurement finds the power in the offset regions recommended by the standard. The offset channel specification and limits for comparison are set based on the selected channel bandwidth, frame structure, and base station types in Standards Preset. It calculates the integrated power in the different offset regions and also indicates pass/fail information based on comparison with absolute and relative limits in the SEM display.

More information about this measurement:

- Select the SEM test setup from Presets > Standards > LTE to perform the measurement. This will load the displays found in the [LTE preset test setups table](#).
- This test setup allows you to select the frame structure, channel bandwidth, and base station type with the following restrictions:
  - Frame Structure can be TDD or FDD
  - Channel Bandwidth can be 1.4, 3, 5, 10, 15, or 20 MHz
  - Base station type can be Wide Area Cat A, Wide Area Cat B - Option 1, Home Area ( $2 \text{ dBm} \leq P \leq 20 \text{ dBm}$ ), Local Area, Medium Area ( $P \leq 31 \text{ dBm}$ )
- Based on the settings chosen by the user from Standards Presets the offset and bandwidth of the offset channels are set in the Offset and Limits tab of the control panel of SEM display.
- The settings also include the absolute power limit for comparison based on the base station type. The standard recommends the settings in dBm/MHz for each base station type. The power limits are appropriately scaled with the integration bandwidth and presented in dBm in the Offset and Limits table of the display. The integrated power in each adjacent band is compared with the absolute and relative limits as suggested by the standard. The absolute limits are dependent on this choice of base station type as they apply to different power levels (as the P-rated levels in the drop down menu indicate). The relative limit is also set.
- The results are presented both in tabular and display form.
- The Pass/ Fail information is also shown in the top left corner of the display.
- For TDD signals, a detection module in the analysis helps you to do the measurement in the transmitter ON period.
  - If you are doing the measurement in Real Time, you can also load the Time Overview display, which will indicate to you the region in which the measurement is done (a purple line at the bottom). You can see the measurement is done only on the valid transmitter ON period. However, when a bursty data is not available, the measurement is done on the available analysis length.



---

**NOTE.** *Real-Time mode can be set from the [Parameters tab](#) of the Settings control panel of the SEM display. Disabling Real-Time mode is the non-Real-Time setting.*

---

- When the measurement is done in non-Real Time mode, separate acquisitions are obtained for each adjacent channel band. In such cases, it cannot be ensured that all the adjacent channel acquisitions are done on the transmitter ON period. It is recommended that you use either Real-Time mode or an external trigger from the source (when used with non-Real Time mode) to do the measurement. An external trigger from the source can ensure that all the acquisitions are done just after the rising edge of the burst. A status message in the display indicates when to use Real Time mode or external trigger for TDD signals. The status message that is displayed in the LTE SEM display is "Signal must be triggered or measurement in Real-Time". This message is displayed when TDD is chosen from Standard Presets, when Real-Time is not enabled from the Parameters tab of the control panel, and when the instrument is in Free Run mode.

- Settings for all tables provided in the base station conformance testing document (3GPP TS 36.141 v12.5 – for Release 12) has been incorporated from Standards Presets.
  - Wide Area and Local area settings from standard presets are provided as per the standard document.
  - Home Area base station settings loaded from standard presets correspond to Reference power levels between 2 to 20 dBm.
  - Medium Area base station settings loaded from standard presets correspond to reference power levels less than 31 dBm.
- The following settings are provided in a \*.csv file that you can load. These files will be available in the installed directory (Example Files\LTE).
  - Wide Area category B Option 2 (for specific bands specified by the standard). There are three csv files based on operating band and channel bandwidth for Wide Area.
    - LTE\_SEM\_1.4MHz\_CatB\_optn2\_bands\_3\_8.csv
    - LTE\_SEM\_3MHz\_CatB\_optn2\_bands\_3\_8.csv
    - LTE\_SEM\_5to20Hz\_CatB\_optn2\_bands\_1\_3\_8\_32\_33\_34.csv
  - Home Area base station for power level less than 2 dBm. There are six csv files based on operating band and channel bandwidth for Home Area.
    - LTE\_SEM\_1\_4MHz\_above3GHz\_Home2P.csv
    - LTE\_SEM\_1\_4MHz\_below3GHz\_Home2P.csv
    - LTE\_SEM\_3MHz\_above3GHz\_Home2P.csv
    - LTE\_SEM\_3MHz\_below3GHz\_Home2P.csv
    - LTE\_SEM\_5to20MHz\_above3GHz\_Home2P.csv
    - LTE\_SEM\_5to20MHz\_below3GHz\_Home2P.csv
  - Medium Area base station for reference power level between 31 to 38 dBm. There are six csv files based on operating band and channel bandwidth for Medium Area.
    - LTE\_SEM\_1\_4MHz\_above3GHz\_Medium31P38P.csv
    - LTE\_SEM\_1\_4MHz\_below3GHz\_Medium31P38.csv
    - LTE\_SEM\_3MHz\_above3GHz\_Medium31P38.csv
    - LTE\_SEM\_3MHz\_below3GHz\_Medium31P38.csv
    - LTE\_SEM\_5to20MHz\_above3GHz\_Medium31P38.csv
    - LTE\_SEM\_5to20MHz\_below3GHz\_Medium31P38.csv
  - Additional requirements given in Section 6.6.3.5.3 in 3GPP TS 36.141 v12.5 standard document. There are 14 csv files based on the requirements in the standard document. The files are named based on the table numbers of Section 6.6.3.5.3 of the standard document (3GPP TS 36.141 V12.5.0 (2014-09)).

### Cell ID (TDD and FDD)

The dominant Cell ID in the transmitted LTE signal is detected and presented in the Constellation display. Along with the Cell ID scalar results, the group and sector ID are also presented. The constellation of the Primary and Second Synchronization signals are presented too.

More information about this measurement:

- Select the Cell ID test setup from Presets > Standards > LTE to perform the measurement. This will load the displays found in the [LTE preset test setups table](#).
- This test setup allows you to select the frame structure and channel bandwidth with the following restrictions:
  - Frame Structure can be TDD or FDD
  - Channel Bandwidth can be 1.4, 3, 5, 10, 15, or 20 MHz
- Analysis of the LTE signals is done based on the settings you choose in the Standards Presets.
- The constellation for PSS and SSS (Primary and Secondary Synchronization Signals) are shown. You can optionally select to view only the PSS or SSS constellation (selection is made in the Trace tab).
- Equalization based on PSS (Primary Synchronization Signal) data can be enabled using the "Enable Equalization" option (available in the Analysis Params tab of the Settings Control panel.) This Equalization is based on PSS data and applied on other parts of the OFDM symbol.

### Reference Signal Power (TDD and FDD)

Reference Signal Power measures the power of cell specific reference signals. Reference signals are spread across time and frequency. Reference signal position is dependent on the Cell ID, bandwidth, and antenna ports. For Downlink TDD (frame structure type 2), the position of reference signals is also dependent on uplink-downlink and special subframe configurations.

### Toff (TDD)

The Toff measurement is done only for the TDD signal. It is a measure of the off slot power in a LTE TDD signal.

More information about this measurement:

- Select the Channel Power and TDD Toff Power test setup from Presets > Standards > LTE to perform the measurement. This will load the displays found in the [LTE preset test setups table](#).
- This test setup allows you to select the frame structure and channel bandwidth with the following restrictions:
  - Frame Structure can be TDD or FDD
  - Channel Bandwidth can be 1.4, 3, 5, 10, 15, or 20 MHz
- Analysis of the LTE signals is done based on the settings you choose in the Standards Presets.

- By default, the Toff measurement is the average of several non-overlapping and adjoining 70  $\mu$ s windows in the off slot region. This measurement is done only on the 70  $\mu$ s window in the center of the off slot region, when the **Average over entire offslot region** option is disabled.
- The scalar result is presented in dBm/MHz.
- The result is compared against limits that can be defined using the Limits tab of the control panel. By default, these limits are set based on the Base Station conformance testing document (3GPP TS 36.141 v12.5 – for Release 12). Pass/fail is shown in the top left corner of the LTE Power vs Time display.

## LTE Status Messages

The following status messages may appear. Each message indicates the related condition (Description) shown in the following table.

Status message	Description
LTE Analysis: Signal must be triggered or measured in Real Time	Shown in the display and status bar when the user attempts to make the ACLR measurement and SEM measurement for TDD signals in non-Real-Time mode and when the instrument is in free run.  Since the standard recommends the ACLR measurement to be done in transmitter ON periods only, either the measurement has to be done in Real-Time mode (in which a detection module ensures the measurement is done on the transmitter ON period) or has to be externally triggered if in non-Real-Time mode.
LTE Analysis: Recovery done on PSS/SSS on the center 62 carriers	Shown in the status bar to indicate that the constellation of PSS and SSS shown in the LTE constellation is done based on analysis of PSS and SSS signals in the center 62 carriers of the corresponding OFDM symbols.  Therefore, you may see the correct constellation and Cell ID even when a different channel bandwidth is chosen from the control panel because the analysis for PSS and SSS is done only on the center carriers.
LTE Analysis: Analysis Failure - Synchronization Sequence not found	Shown in the status bar to indicate that a valid Cell ID (from PSS and SSS) is not detected.

## LTE ACLR display

The LTE Adjacent Channel Leakage Ratio (ACLR) display shows the ratio of the mean power centered on the assigned channel frequency to the mean power centered on an adjacent channel frequency. In the 3GPP specification, both the main channel and adjacent channels are required to be filtered with RRC (Root Raised Cosine) filters.

To show the LTE ACLR display you can select **Presets > Standards > LTE**.


**NOTE.** Loading the LTE ACLR display from the **Presets > Standards > LTE** menu is recommended. This loads the control settings based on the selected options.

You can also load the LTE ACLR display as follows:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** window, select **LTE Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **LTE ACLR** icon or select the icon and click **Add**. The LTE ACLR icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click the **OK** button to show the display.
6. Select **Setup > Settings** to display the control panel.
7. Select **Replay/Run** to take measurements on the acquired data.
8. If you are analyzing a data file, click the **Replay** button to take measurements on the recalled acquisition data file.


## Elements of the Display

The following image shows the LTE ACLR display.



Item	Display element	Description
A	Pass/Fail	Indicates Pass or Fail based on Absolute and Relative limits set by the user. The failure condition is set by Mask in the Offset and Limits Table tab of the Settings control panel. By default, the mask is set to Abs & Rel, meaning failure is reported only when both absolute and relative results fail against the respective limits.
B	Ref Detection	Set to Avg (VRMS) or +Peak based on the choice made in Processing tab of the Settings control panel.
C	Normal	Indicates how the result is presented over multiple sweeps. This selection is made in the Processing tab of the control panel. Displays Average Count if Avg (VRMS) is checked in the Processing tab in the Settings control panel.
D	Clear	Resets measurement. Clears all values.
E	Plot	Shows the reference channel and adjacent channels and the regions in between them. The Absolute and Relative limit lines are also shown. The integrated power is shown as a band. Scalar results are also shown.
F	Span	Adjust the span of the graph in symbols.
G	Results Table	Tabulates the results in each adjacent band. Table shows the offset, bandwidth, Integrated Absolute and Relative power in the upper and lower adjacent channel regions.
H	CF	Center Frequency at which the measurement is performed.
I	Ref Total Power	Gives the power in the Reference channel.
J	Autoscale	Adjusts the vertical and horizontal settings so that the entire trace fits in the graph.
K	Bottom readout	Displays the value indicated by the bottom of graph.
L	dB / div	Shows the dB per each division in the Y axis of the plot.
(not shown)	Units	Sets the global Amplitude units for all the views in the analysis window. This will change the amplitude selection in the Units tab of the Amplitude control panel.
M	Top of graph	The vertical scale is normalized with appropriate power units.
N	Expand button	Shows the results table in its own window with larger font size.

Clicking on the **Expand** button allows you to view the results table in a separate window, as shown in the following image.



Channel	Freq Offset	Bandwidth	Lower Abs	Lower Rel	Upper Abs	Upper Rel
AL&AU	7.50 MHz	3.84 MHz	-61.53 dBm	-46.95 dB	-61.11 dBm	-46.53 dB
BL&BU	12.50 MHz	3.84 MHz	-61.53 dBm	-46.95 dB	-61.32 dBm	-46.73 dB

## LTE ACLR Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The LTE ACLR Settings control panel provides access to settings that control parameters of the LTE ACLR display.

Settings tab	Description
<a href="#">Channels (see page 590)</a>	Allows you to control how the measurement is performed. When in Real Time, the RBW and VBW settings apply for all channels (including offset regions) and the other parameters apply only for the reference channel. When Non-Real Time mode is selected, all information in this tab, including RBW and VBW, only applies to the reference channel.
<a href="#">Parameters (see page 592)</a>	Specifies several characteristics that control how the measurement is made. These parameters are used by the instrument to analyze the input signal.
<a href="#">Processing (see page 594)</a>	Specifies settings for detection on the reference channel and the offsets. Specifies the function setting on how calculations are done across multiple sweeps.
<a href="#">Offsets &amp; Limits Table (see page 595)</a>	Allows you to select the characteristics of offsets and mask limits.
<a href="#">Scale (see page 596)</a>	Specifies the vertical and horizontal scale settings.
<a href="#">Prefs (see page 598)</a>	Allows you to select to show or hide the graticule, power level, limits, and marker readouts.

## LTE Channel Spectrum display

The LTE Channel Spectrum display shows the spectrum of the input signal across one channel. Channel power measures the average power within the selected bandwidth and is expressed in dBm. Other units can be selected from the Units tab of the Analysis control panel. The measured occupied bandwidth is calculated as the bandwidth containing 99% of the total integrated power within the selected span around the selected center frequency.


To show the LTE Channel Spectrum display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. From the **Measurements** box, select **LTE Analysis**.
4. Double-click the **LTE Channel Spectrum** icon in the **Available Displays** box. This moves the LTE Channel Spectrum icon to the **Selected displays** box.
5. Click **OK** button to view the display.

6. Select **Setup** > **Settings** to display the control panel.
7. Select Replay/Run to take measurements on the acquired data.
8. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

## Elements of the Display

The following image shows the LTE Channel Spectrum display.





Item	Display element	Description
A	Normal	Displays Average Count if Average is turned on (set to Time Domain or Frequency Domain) from the Measurement Params tab in the Settings control panel.
B	Clear	Resets measurement. Clears all values.
C	Plot	Specifies the value shown at the center of the graph display.
D	Scale	Adjust the span of the graph.
E	Position	Displays the horizontal position of the trace on the graph display.
F	Scalar results	Shows the Channel Power and Occupied Bandwidth measurement results.
G	Autoscale	Adjusts the vertical and horizontal settings so that the entire trace fits in the graph.
H	Bottom readout	Displays the value indicated by the bottom of graph.
I	dB / div	Shows the dB per each division in the Y axis of the plot.
(not shown)	Units	Sets the global Amplitude units for all the views in the analysis window. This will change the amplitude selection in the Units tab of the Amplitude control panel.
J	Top of graph	The vertical scale is normalized with appropriate power units.

## LTE Channel Spectrum Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the LTE Channel Spectrum display are shown in the following table.

Settings tab	Description
<a href="#">Freq &amp; RBW (see page 601)</a>	Allows you to specify the frequency and resolution bandwidth used for the measurement.
<a href="#">Measurement Params (see page 602)</a>	Allows you to set averaging (Time Domain, Off, or Frequency Domain) and to set the number value associated with the Average setting.
<a href="#">Channels (see page 590)</a>	Allows you to set the Channel BW for the Channel Power measurement.
<a href="#">Scale (see page 596)</a>	Allows you to specify the horizontal and vertical scale settings.
<a href="#">Prefs (see page 598)</a>	Allows you to select to show or hide certain display elements.

## LTE Constellation display


The LTE Constellation display shows the constellation of Primary (PSS) and Secondary (SSS) Synchronization Signals. Scalar results include Cell ID, Group ID, Sector ID, and frequency error.

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.

3. In the **Select Displays** dialog, select **LTE Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **LTE Constellation** icon or select the icon and click **Add**. The LTE Constellation icon will be added to the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the display.
6. Select **Replay/Run** to take measurements on the acquired data.
7. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

## Elements of the Display


The following image shows the LTE Constellation display.



Item	Display element	Description
1	Scalar results	Gives results of Cell ID, Group and Sector ID information along with Frequency error.
2	Marker readout	Shows marker type, magnitude, phase and subcarrier number.
3	Status message	Shows relevant status messages. (You can read about status messages <a href="#">here</a> .)
4	Plot	Displays PSS and SSS (Primary and Second Synchronization Signal) constellation.

## LTE Constellation Settings

Main menu bar: **Setup > Settings**

Favorites toolbar: 

The settings for the LTE Constellation display are shown in the following table.

Settings tab	Description
<a href="#">Modulation Params (see page 603)</a>	Specifies the frame structure and channel bandwidth.
<a href="#">Analysis Params (see page 604)</a>	Allows you to enable Equalization based on PSS (Primary Synchronization Signal).
<a href="#">Analysis Time (see page 604)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) and Time Zero Reference (Trigger or Acquisition Start) for LTE Analysis displays.
<a href="#">Trace (see page 606)</a>	Allows you to set the display characteristics of the traces.
<a href="#">Scale (see page 596)</a>	Specifies the vertical and horizontal scale settings.

## LTE Power vs Time display

The LTE Power vs Time display shows the filtered power of the data and marks where the  $T_{OFF}$  measurement is done. The  $T_{OFF}$  scalar results are also shown.

You can select **Presets > Standards > LTE** to view the display.

---

**NOTE.** Loading the LTE Power vs Time display from the **Presets > Standards > LTE** menu is recommended. This loads the control settings based on the selected options.

---


You can also load the LTE Power vs Time display as follows:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.

3. In the **Select Displays** dialog, select **LTE Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **LTE Power vs Time** icon or select the icon and click **Add**. The LTE Power vs Time icon will be added to the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the display.
6. Select **Replay/Run** to take measurements on the acquired data.
7. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

## Elements of the Display

The following image shows the LTE Power vs Time display.



Item	Display element	Description
A	Pass / Fail	Shows Pass or Fail based on whether the $T_{OFF}$ measurement (off slot power) is below the recommended limit set in the Limit tab of the Settings control panel or not. The Pass/Fail information is displayed only when the chosen frame structure is TDD and if a valid off slot is found.
B	Plot	Displays the filtered signal in case of TDD and the region in which the off slot power is measured is graphically shown. When the frame structure is chosen as FDD, the power in the input signal is displayed.
C	Scale	Adjust the span of the graph in symbols.
D	Analysis Start	Gives the start of analysis region.
E	Toff	The $T_{OFF}$ (off slot power) is measured and displayed here when a valid off slot is found for a TDD signal.
F	Autoscale	Adjusts the vertical and horizontal settings so that the entire trace fits in the graph.
G	Bottom readout	Displays the value indicated by the bottom of graph.
H	dB / div	Shows the dB per each division in the Y axis of the plot.
(not shown)	Units	Sets the global Amplitude units for all the views in the analysis window. This will change the amplitude selection in the Units tab of the Amplitude control panel.
I	Top of graph	The vertical scale is normalized with appropriate power units.

## LTE Power vs Time Settings

Main menu bar: Setup > Settings

Favorites toolbar: 

The settings for the LTE Power vs Time display are shown in the following table.

Settings tab	Description
<a href="#">Modulation Params (see page 603)</a>	Specifies the frame structure and channel bandwidth.
<a href="#">Analysis Time (see page 604)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) and Time Zero Reference (Trigger or Acquisition Start) for LTE Analysis displays.
<a href="#">Prefs (see page 598)</a>	Allows you to select to show or hide the graticule and marker readouts.
<a href="#">Scale (see page 596)</a>	Specifies the vertical and horizontal scale settings.
<a href="#">Limit (see page 606)</a>	Specifies the mask limits.

## LTE Analysis Measurement Settings

Main menu bar: Setup > Settings

## Favorites toolbar:

The control panel tabs in this section are shared between the displays in LTE Analysis (Setup > Displays). Some tabs are shared by all the displays and some tabs are shared by only a subset of displays. The settings available on some tabs change depending on the selected display.

### Controls for LTE Analysis displays

Settings tab	Description
<a href="#">Modulation Params (see page 603)</a>	Allows you to set the frame structure and channel bandwidth. <i>Available for these displays: LTE Power vs Time, LTE Constellation.</i>
<a href="#">Analysis Params (see page 604)</a>	Allows you to enable Equalization based on PSS (Primary Synchronization Signal).
<a href="#">Analysis Time (see page 604)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for LTE Analysis displays. <i>Available for these displays: LTE Power vs Time, LTE Constellation.</i>
<a href="#">Trace (see page 606)</a>	Specifies the trace type (Vectors, Points, and Lines), the number of points per symbol when chosen to view as Vectors or Lines, and to control the view as Freq Dev or IQ. <i>Available for the LTE Constellation display only.</i>
<a href="#">Prefs (see page 598)</a>	Allows preferences with Radix display and marker readouts. <i>Available for these displays: LTE Power vs Time, LTE ACLR, LTE Channel Spectrum, SEM.</i>
<a href="#">Scale (see page 596)</a>	Defines the vertical and horizontal axes. <i>Available for all LTE displays.</i>
<a href="#">Offsets &amp; Limits Table (see page 595)</a>	<b>NOTE.</b> <i>Available for the LTE ACLR display only.</i>
<a href="#">Freq &amp; RBW (see page 601)</a>	Specifies the frequency and resolution bandwidth used for the measurement. <b>NOTE.</b> <i>Available for the LTE Channel Spectrum display only.</i>
<a href="#">Parameters (see page 592)</a>	Specifies several characteristics that control how the measurement is made.
<a href="#">Processing (see page 594)</a>	Specifies settings for detection on the reference channel and the offsets. Specifies the function setting on how calculations are done across multiple sweeps.
<a href="#">Limit (see page 606)</a>	Allows you to define limits for pass/fail comparison with calculated values. The default values are as recommended in the test specification.
<a href="#">Channels (see page 590)</a>	Specifies the Channel BW for the Channel Power measurement. Allows you to set RBW, VBW, power reference, as well. <i>Available for these displays: LTE ACLR, LTE Channel Spectrum.</i>
<a href="#">Measurement Params (see page 602)</a>	Allows you to set averaging (Time Domain, Off, or Frequency Domain) and to set the number value associated with the Average setting.

## Channels tab - LTE

The Channels tab allows you to control how the measurement is performed.

The following image shows the Channels tab for the LTE ACLR display. When in Real Time, the RBW and VBW settings apply for all channels (including offset regions) and the other parameters such as Power Reference, Channel Width, and Integrated bandwidth apply only to the reference channel. When Non-Real Time mode is selected, all information in this tab, including RBW and VBW, only applies to the reference channel.

LTE ACLR settings

Channels Parameters Processing Offsets & Limits Table Scale Prefs

Reference

Power Reference: 0.00 dBm ☒ Auto

Channel width: 1.400 MHz RBW: 51.000 kHz

Integration BW: 1.095 MHz ☐ VBW:

Standard Presets

Settings	Description
Reference	
Power Reference	The value used to calculate relative measurements. When Auto is selected, the calculated reference channel power is displayed. When Auto is unchecked, you can enter a value for the reference power, and the measured reference power is not used or displayed.
Channel Width	Specifies the width of the reference channel.
Integration BW	Specifies the integration bandwidth used to compute the total power in the reference channel.
All Channels (displayed for Real-Time mode)	
Reference Channel (displayed for Non-Real Time mode)	
RBW	Sets the RBW
VBW	Enables/disables the Video Bandwidth filter. VBW is used in traditional swept analyzers to reduce the effect of noise on the displayed signal. The VBW algorithm in the analyzer emulates the VBW filters of traditional swept analyzers. When the check box next to VBW is not checked, the VBW filter is not applied.  The maximum VBW value is 10 times the current RBW setting. The minimum VBW value is 1/10,000 of the RBW setting.

The following image shows the Channels tab for the LTE Channel Spectrum display. This tab allows you to set the channel bandwidth, which in turn sets the span for LTE Channel Spectrum.

LTE Channel Spectrum Settings

Freq & RBW Measurement Params Channels Scale Prefs

Channel Bandwidth: 5 MHz

Standard Presets

Settings	Description
Channel Bandwidth	Specifies the Channel Bandwidth, which in turn sets the span of the LTE Channel Spectrum.

## Parameters tab - LTE

The Parameters tab enables you to specify several parameters that control the LTE ACLR measurements are made.

LTE ACLR settings

Channels Parameters Processing Offsets & Limits Table Scale Prefs

Meas Freq: 1.00000 GHz Filter shape: Gaussian

Step: 2.0000 MHz ☒ Auto

☐ Real-Time

Standard Presets Measure Noise Floor ☐ Apply noise correction

Parameters Processing Channels Offsets & Limits Table Scale Prefs

Meas Freq: 5.5700 GHz Measurement Type: Peak

Step: 20.0000 MHz ☒ Auto Offset definition: Ref center to OS center

☒ Real-Time Filter shape: Gaussian


Measure Noise Floor ☒ Apply noise correction



Setting	Description
Meas Freq	Specify the frequency of the signal to be measured.
Step	Sets the increment size when changing the Frequency using the knob or mouse wheel. Auto: When Auto is enabled, the step size is adjusted automatically based on the span setting.
Real-Time	When Real-Time mode is enabled, the entire LTE ACLR span is measured using a real-time/contiguous acquisition. Not all described parameters are available in Real-Time mode.  When Real-Time is disabled (non-Real-Time mode), a separate acquisition for each region is taken and analyzed. Non-Real-Time mode is also useful when the bandwidth offered by the instrument does not support the span requirement for this measurement. The span requirement is guided by the choice of adjacent channel type and channel bandwidth selected in LTE Standards Presets.
Measure Noise Floor	Takes preliminary acquisitions to measure the instrument noise floor. This initiates a noise correction. A noise correction signal is created by switching off the RF input and performing acquisitions of the instrument's internal noise. Fifty acquisitions are averaged to create the noise reference signal. The noise reference signal is measured for the Reference channel and each Offset is defined by the measurement settings.
Apply noise correction	This item is enabled and the check box automatically checked after the noise reference signal is taken when the Measure Noise floor button is clicked. This initiates noise reference subtraction from the incoming signal power for each region to create the corrected result. All calculations are performed in Watts and then converted to the desired units.  The amount of noise correction is limited to 20 dB to avoid the possibility of a negative power measurement. This is a rare condition that could occur if the subtraction of the reference power from the channel power results in a negative value (or "infinite" dBm). The noise reference for a region is subtracted from each trace point in the channel, rather than offsetting the entire region by a single amount. This produces a smooth trace with no discontinuities at the region edges.  <b>NOTE.</b> If any relevant settings (such as reference level, frequency, span, RBW) are changed once the noise reference is measured, the following warning message will be displayed to notify you that Noise Correction was not applied: Noise correction not applied - select Measure Noise Floor for new noise correction.
Filter shape	Specifies the shape of the filter determined by the window that is applied to the data record, in the spectrum analysis, to reduce spectral leakage. 3GPP specifies a Gaussian window shape be applied to the reference channel measurements.  <b>Gaussian:</b> This filter shape provides optimal localization in the frequency domain. <b>Rectangular:</b> This filter shape provides the best frequency, worst magnitude resolution. This is essentially the same as no window.

## Processing tab - LTE

The Processing tab controls the detection settings for the Reference Channel and Offsets, as well as selecting the function for the LTE ACLR display.




Setting	Description
Detection (in each sweep)	
Reference Channel	Specifies the Detection method used for the Reference Channel. Detection is used to produce the desired measurement result (peak or average) and to reduce the results of a measurement to the desired number of trace points.
Avg (VRMS)	For each sweep, each point of the trace is the result of determining the RMS voltage value for the last 'n counts' of the collected traces for the same point. When 'n count' has not been reached, partial averaging results are displayed.
+Peak	Selects the +Peak detection method. With this method, the highest value is selected from the results to be compressed into a trace point.
Offsets	Specifies the detection method used for the offsets.
Avg (VRMS)	Selects the Average Vrms detection method. With this method, each point on the trace in each offset is the result of determining the RMS Voltage value for all of the results values it includes.
+Peak	Selects the +Peak detection method. With this method, the highest value is selected from the results to be compressed into a trace point.
Function (across multiple sweeps)	
Normal	When a new trace has been computed, it replaces the previous trace.
Max Hold	With each sweep, each trace point in the new trace is compared to the point's value in the old trace and the greater value is retained for display and subsequent comparisons.
Avg (VRMS)	For each sweep, each point on the trace is the result of determining the RMS Voltage value for all of the collected traces' values for the same point.
Count	Enter the Avg (VRMS) value. Displayed only when Avg (VRMS) is selected.


## Offsets and Limits Table tab - LTE

The Offsets and Limits Table tab is used to specify parameters that define Offsets and masks for the LTE ACLR display. The following images show the tab and expanded view of the tab, respectively.

The following image shows the Offsets and Limits Table tab when Real-Time is selected in the Parameters tab.



The following image shows the Offsets and Limits Table tab when Real-Time is not selected in the Parameters tab (referred to as non-Real-Time mode).



The following image shows the expanded view of the Offsets and Limits Table (click the **Expand** button to view).



Setting	Description
<b>Buttons</b>	
Expand (button)	Displays the Offsets and Limits Table in a new, resizable window.
Reset Layout	Allows you to reorder columns in the Offsets & Limits Table by dragging the columns to a new position. Clicking Reset Layout returns the column order to the factory default order.
Load	Click to load a saved Offsets & Limits table from a file.
Save As	Click to save the current Offsets & Limits table to a file.
Done	When the table is expanded, click Done when you have finished editing the table to save your changes and close the expanded table display.
<b>Table columns</b>	
On	Specifies whether or not measurements are taken in the specified offset.
Freq Offset (Hz)	Specifies the frequency offset for the offset region (adjacent channel region) from the Center frequency of the Reference Channel. This offset is always specified from the center frequency of the Reference Channel to the center frequency of the Offset region.
Start (Hz)	Start Frequency of the selected offset.
Stop (Hz)	Stop Frequency of the selected offset.
Bandwidth (Hz)	Specifies the bandwidth of the Offset region.
Side	Specifies whether the specified range appears on both side of the carrier frequency or just one side (left or right).
RBW (Hz)	Specifies the RBW for the selected range.
n(RBWS)	An integer value that specifies how many times to multiply the RBW to set the Filter bandwidth.
Filter BW (n x RBW)	Displays the Filter BW. Filter BW is the equivalent BW of each point in the offset. When $n > 1$ , an integration technique is used to achieve the Filter BW using narrower RBWs.
VBW (Hz)	Adjusts the VBW (Video Bandwidth) value. VBW Maximum: RBW current value; VBW Minimum: 1/10,000 RBW setting.
VBW (On)	Specifies whether the VBW filter is applied.
Mask	Select the type of limits used for Pass/Fail testing. Signal excursions that exceed the mask settings are considered violations. The available choices are Abs, Rel and Abs & Rel.
Abs Limit (dBm)	The offset region integrated power is compared against the Abs Limit value mentioned here.
Rel Limit (dB)	The offset region integrated power relative to the reference channel integrated power is compared with this limit.

## Scale tab - LTE

The Scale tab allows you to change the scale settings that control how the trace appears on the display but does not change control settings. In effect, these controls operate like pan and zoom controls. The Scale tab values are unique to each display. Also, note that each display uses horizontal and vertical units that are appropriate for that display. There are three versions of the Scale tab for LTE displays.

The following image shows the Scale tab for the LTE Power vs Time display.

LTE Power vs Time Settings

Modulation Params Analysis Time Prefs **Scale** Limit

Vertical

Scale: 100.00 dB

Position: 0.00 dBm

Reset

Horizontal Full Burst

Start: 100.000 us

Stop: 0.000 s

Reset

Standard Presets

Settings	Description
Vertical	Controls the vertical position and scale of the trace display.
Scale	Changes the vertical scale units.
Position	Adjusts the reference level away from top of the graph.
Reset	Resets the scale of the vertical axis to default values.
Horizontal Full Burst	Controls the horizontal span.
Start	Specifies the horizontal axis start point.
Stop	Specifies the horizontal axis end point.
Reset	Resets the scale of the horizontal axis to default values.

The following image shows the Scale tab for the LTE Channel Spectrum and LTE ACLR displays.

LTE Channel Spectrum Settings

Freq & RBW Measurement Params Channels **Scale** Prefs

Vertical

Scale: 100.00 dB

Position: 0.00 dBm

Reset Scale

Autoscale

Horizontal

Scale: 6.27 MHz


Position: 1.00000 GHz

Autoscale

Standard Presets

Settings	Description
Vertical	Controls the vertical position and scale of the trace display.
Scale	Changes the vertical scale units.
Position	Adjusts the reference level away from top of the graph.
Autoscale	Resets the scale of the vertical axis to contain the complete trace.
Horizontal	Controls the horizontal span of the trace display and position of the trace.
Scale	Specifies the frequency range displayed in the graph
Position	Specifies the frequency shown at the center of the graph.
Autoscale	Resets the scale of the horizontal axis to optimize the display of the trace.
Reset Scale	Resets all settings to their default values.

The following image shows the Scale tab for the LTE Constellation display.



Settings	Description
Zoom	
Scale	Zooms in and out of the constellation. As the scale is increased, it will zoom out.
Vertical Position	Adjusts the vertical position.
Horizontal Position	Adjusts the horizontal position.

## Prefs tab - LTE

The Prefs tab enables you to change parameters of the measurement display. The parameters available on the Prefs tab vary depending on the selected display, but include such items as enabling/disabling Marker Readout and switching the graticule display on/off. Some parameters appear with most displays, while others appear with only one display.

The following image shows the Prefs tab for the LTE ACLR display.

The screenshot shows the 'LTE ACLR settings' window with the 'Prefs' tab selected. The window has a sidebar with 'Standard Presets' and a main area with the following controls:

- Max Trace points: 801 (per range)
- ☒ Show graticule
- ☒ Show Marker readout in graph (selected marker)
- ☒ Show Power Levels In Graph
- Show limits: Line only

The following image shows the Prefs tab for the LTE Channel Spectrum display.

The screenshot shows the 'LTE Channel Spectrum Settings' window with the 'Prefs' tab selected. The window has a sidebar with 'Standard Presets' and a main area with the following controls:

- Trace points: 801
- Trace detection: +Peak
- ☒ Show graticule
- ☒ Show Marker readout in graph (selected marker)

The following image shows the Prefs tab for the LTE Power vs Time display.

The screenshot shows the 'LTE Power vs Time Settings' window with the 'Prefs' tab selected. The window has a sidebar with 'Standard Presets' and a main area with the following controls:

- ☒ Average over offslot
- ☒ Show graticule
- ☒ Show marker readout

Setting	Description
Show graticule	Shows or hides the graticule.
Trace / Max Trace points	When the spectrum analysis produces more than the selected maximum number of points, the method specified in Detection control is used to decimate the result. This setting applies to both the reference channel and offsets.
Show Marker readout in graph (selected marker)	Shows or hides the readout for the selected marker in the graph area.
Show Power Levels In Graph	This display the power level (calculated integrated power in the offset region) in the graph.
Show limits	
Shaded	Shows limits using a shaded area. Absolute limit and Relative limit shading colors can be set under Presets > Options.
Line only	Shows limits using only a line. Absolute limit and Relative limit line colors can be set under Presets > Options.
None	No lines or shading are used to indicate limits in the graph. Violations of the mask are still identified by red shading.
Average Over Offslot	Enables for averaging of offslot power in non-overlapping 70 $\mu$ s windows in the entire offslot region. If this option is disabled, the off slot power is measured only in the center 70 $\mu$ s window of the offslot region.



## Freq and RBW tab - LTE


The Freq and RBW tab specifies frequency parameters for the Channel Power and ACPR measurements and the MCPR measurement. It is available for the LTE Channel Spectrum display.

The screenshot shows the 'LTE Channel Spectrum Settings' dialog box with the 'Freq & RBW' tab selected. The 'Meas Freq' is set to 1.00000 GHz. The 'RBW' is set to 3.000 kHz with an 'Auto' checkbox. The 'Step' is set to 2.0000 MHz with an 'Auto' checkbox. There is also a 'VBW' checkbox. A 'Standard Presets' button is located on the left side of the dialog.

Settings	Description
Meas Freq	Specifies the center/measurement frequency
RBW	<p>Select Auto or Manual. Adjusts the RBW for the entire measurement. This setting is Independent of the Spectrum view's RBW setting.</p> <p>Auto: When Auto is enabled, the step size is adjusted automatically based on the span setting.</p>
Step	<p>The Step control sets the increment/decrement size for the adjustment of the center frequency. If Auto is enabled, the analyzer will adjust the Step size as required.</p> <p>Auto: When Auto is enabled, the step size is adjusted automatically based on the span setting.</p>
VBW	<p>Adjusts the Video Bandwidth value.</p> <p>The maximum VBW value is 10 times the current RBW setting. The minimum VBW value is 1/10,000 of the RBW setting.</p>

# Measurement Params tab - LTE

The Measurement Params tab allows you to set parameters that control the ACPR and MCPR measurements. This is available for the LTE Channel Spectrum display.



Settings	Description
Average	
Off	
Frequency-domain	This setting takes the average linear value of the traces (so that RMS values are preserved). The number of averages is user-defined. Frequency domain averaging is available in spans larger (or smaller) than the maximum real time bandwidth. This is the mode to use unless you need to extract maximum dynamic range from an ACPR measurement.
Time-domain	This setting takes the average linear value of the traces. It is useful if you need to extract maximum dynamic range from an ACPR measurement. The number of traces is user defined, however, the signals must be triggered and repeating (meaning the signal needs to be exactly the same for each acquisition). When this condition is met, each waveform contains the same signal, but the random noise changes from acquisition to acquisition and the average value of the random noise is lowered, while the signal value remains constant. Time domain averaging is not available in spans wider than the maximum real-time bandwidth.

## Modulation Params tab - LTE


The Modulation Params tab specifies the type of modulation used by the input signal and other parameters that define the signal format. This tab is available for the LTE Constellation and Power vs Time displays.

The screenshot shows the 'Modulation Params' tab in the LTE Analysis software. The interface includes a 'Modulation Params' tab, with sub-tabs for 'Analysis Time', 'Prefs', 'Limit', and 'Scale'. The 'Frame Structure' dropdown is set to 'Downlink FDD'. The 'Auto detect' checkbox is unchecked. The 'Channel Bandwidth' dropdown is set to '5 MHz'. The 'Cyclic Prefix' dropdown is set to 'Normal'. The 'Antenna Ports' section shows 'Total Antenna Ports' set to 1 and 'Chosen Port' set to 0. A 'Standard Presets' button is visible on the left.

Settings	Description
Frame Structure	Select the frame structure to set how the demodulation is done.
Downlink FDD	Downlink Frequency Division Duplexing
Downlink TDD	Downlink Time Division Duplexing
Auto Detect	If checked, Channel Bandwidth and Cyclic Prefix are automatically detected. It will also detect the TDD Configuration when Downlink TDD is the selected frame structure.
Channel Bandwidth	Select from 6 bandwidths: 1.4, 3, 5, 10, 15, 20 MHz (If Auto Detect is checked, the channel bandwidth is automatically calculated.)
Cyclic Prefix	Select Normal or Extended.
TDD Configuration	
Uplink-Downlink	Select from 0 to 6. The configuration determines the appropriate downlink to uplink switch periodicity.
Special Subframe	Select from 0 to 9. This configuration determines the number of downlink pilots, guard period, and uplink pilots between uplink to downlink switch.
Antenna Ports	
Total Antenna Ports	Select from 1 to 4. This is the total number of antenna ports.
Chosen Port	Select the antenna port from which the signal is captured.

# Analysis Params tab - LTE


The Analysis Params tab allows you to enable equalization on the demodulated LTE packet. The equalization is based on PSS (Primary Synchronization Signal). This tab is only available for the LTE Constellation display.



Settings	Description
Enable Equalization	Allows you to enable Equalization based on PSS (Primary Synchronization Signal).

# Analysis Time tab - LTE

The Analysis Time tab contains parameters that define how the signal is analyzed in the LTE Analysis displays. This tab is available for the LTE Constellation and Power vs Time displays.



Settings	Description
Analysis Offset	Specifies the location of the first time sample to use in measurements.
Auto	When enabled, causes the instrument to set the Analysis Offset value based on the requirements of the selected display.
Analysis Length	Specifies the length of the analysis period to use in measurements. Length is specified in either symbols or seconds, depending on the Units setting.
Auto	When enabled, causes the instrument to set the Analysis Length value based on the requirements of the selected display.
Actual	This is a displayed value, not a setting. It is the Analysis Length (time or symbols) being used by the analyzer. This value may not match the Analysis Length requested (in manual mode).
Time Zero Reference	Specifies the zero point for the analysis time.
Units	Specifies the units of the Analysis Length to either Symbols or Seconds.

### Analysis Offset

Use analysis offset to specify where measurements begin. Be aware that you cannot set the Analysis Offset outside the range of time covered by the current acquisition data. (All time values are relative to the Time Zero Reference.)

You can set the Analysis Length so that the requested analysis period falls partly or entirely outside the current range of acquisition data settings. When the next acquisition is taken, its Acquisition Length will be increased to cover the new Analysis Length, as long as the Sampling controls are set to Auto. If the Sampling parameters are set to manual, or if the instrument is analyzing saved data, the actual analysis length will be constrained by the available data length, but in most cases, measurements are able to be made anyway. The instrument will display a notification when measurement results are computed from less data than requested. Range: 0 to [(end of acquisition) - Analysis Length]. Resolution: 1 effective sample (or symbol).

### Analysis Length

Use the analysis length to specify how long a period of time is analyzed. As you adjust this value, the actual amount of time for Analysis Length, in Symbol or Seconds units, is shown below the control in the "Available" readout. This setting is not available when Auto is checked. Range: minimum value depends on the standard. Resolution: 1 symbol.


### Time Zero Reference

All time values are measured from this point (such as marker position or horizontal position (in Y vs Time displays). Choices are: Acquisition Start or Trigger.

Parameter	Description
Acquisition Start	Time zero starts from the point at which the acquisition begins.
Trigger	Time zero starts from the trigger point.

## Trace tab - LTE


The Trace tab allows you to set the trace display characteristics of the LTE Constellation display.



Setting	Description
>	The arrow indicates which measurement name is active so that you can check it (on) or uncheck it (off).
On	Check the box next the measurement name you want to turn on.
Measurement Name	Selections are PSS (Primary Synchronization Signal) or SSS (Secondary Synchronization Signal)

## Limit tab - LTE

The Limit tab is only available for the LTE Power vs Time display. It enables you to specify the limit used for comparison against measured values of Toff measurement.



Setting	Description
Toff psd	Specifies the limit that is used for comparison against measured values of Toff measurement. Pass/ Fail is determined with this limit.

# Bluetooth Analysis

## Overview

There are two Bluetooth Analysis options: Bluetooth (SV27) and Bluetooth 5 (SV31). These options allow you to evaluate short range RF signals to ensure that they meet Bluetooth standard per Bluetooth Special Interests Group (SIG) Test Specifications for version 5. This analysis option enables measurements and supports detection, demodulation, and decoding of packet information for the following three standards: Basic Rate, Low Energy (LE), and Enhanced Data Rate (EDR).

- Basic Rate with uncoded data at 1 Mb/s
- Low Energy (the following three variants are supported):
  - Low Energy 1M (LE 1M), with uncoded data at 1 Mb/s
  - Low Energy 2M (LE 2M), with uncoded data at 2 Mb/s (Requires Option SV31NL or SV31FL)
  - Low Energy Coded (LE Coded) with S=2 (500 Kb/s) or S=8 (125 Kb/s) (Requires Option SV31NL or SV31FL)
- Enhanced Data Rate (EDR) with 2 Mb/s or 3 Mb/s

You can also select from three RF test presets for the Low Energy standard and four test presets for the Basic Rate standard. This analysis option includes modulation, power, carrier drift, and spectral measurements as mentioned in the Radio Frequency test specification document by the Bluetooth SIG. These measurements are also compared with the limits provided by the standard to give pass/fail results. (There are no pass/fail results for EDR.)

With the Bluetooth Analysis test suite, test engineers can simplify the execution of a number of transmitter tests while still enabled to modify signal parameters for in-depth signal analysis. The analysis results give multiple views of Bluetooth signal characteristics to allow the diagnosis of signal imperfections and impairments quickly and easily. Display controls allow you to selectively display the analysis results to help locate trouble spots in the signal.

## Bluetooth topics in this Help

The following information about Bluetooth Analysis is available:

- [Bluetooth key features \(see page 608\)](#)
- [Reference table of supported Bluetooth measurements](#)
- [Bluetooth measurements and test setups \(see page 612\)](#)
- [Bluetooth status messages \(see page 617\)](#)
- [Bluetooth Standards presets \(see page 609\)](#)
- [Bluetooth displays \(see page 611\)](#)
- [Bluetooth Settings \(see page 644\)](#)

## Bluetooth key features

- Modulation/Carrier Drift/Output Power test setup in Bluetooth Standards Preset that will calculate results and compare against recommended or user defined limits for Basic Rate, LE 1M, LE 2M, and LE coded.
- In-band Emission measurement preset with capability to compare results against recommended or user defined limits for Basic Rate, LE 1M, LE 2M, and LE coded.
- 20 dB Bandwidth and Frequency Range measurement preset with capability to compare results against recommended or user defined limits for Basic Rate.
- Appropriate masks for Out-of-band Spurious measurements for ETSI and FCC specifications.
- Enhanced Data Rate (EDR) demodulation of GFSK and PSK data and relative power measurement preset.
- [Automatic detection of standards \(see page 608\).](#)
- Automatic detection of test pattern.
- Automatic determination of packet type.
- Summary display with decoded preamble, access code, packet header, payload header, and CRC packet information along with other scalar measurements.
- Symbol Table display with color coding to show different regions in the packet.
- Freq Dev vs Time display with zoomed Octet viewing to help you understand how the modulation characteristics measurement is done.
- CF Offset & Drift display with offset (calculated in preamble and 10 bit intervals in payload) and drift results in a tabular view.
- Summary display that allows you to edit pass/fail limits for comparison with actual results. (Default is recommended limits from the Bluetooth SIG Radio Frequency test specification document.)

**Automatic detection of standards.** This function can be enabled from the Standard Parameters control panel. This automatically detects whether the Bluetooth standard is Basic Rate, Low Energy, or Enhanced Data Rate (EDR). This function is not available as a test setup from the Standards Presets window.

## Supported automated Bluetooth measurements

Bluetooth measurement	Bluetooth standard(s)
Modulation characteristics	Basic Rate
	LE 1M, LE 2M, LE coded
Carrier frequency offset and drift	Basic Rate
	LE 1M, LE 2M, LE coded
Output power	Basic Rate
	LE 1M, LE 2M, LE coded
In-band emission /ACPR	Basic Rate
	LE 1M, LE 2M, LE coded



Bluetooth measurement	Bluetooth standard(s)
Out-of-band spurious emission	Basic Rate LE 1M, LE 2M, LE coded
20 dB bandwidth	Basic Rate
Frequency range	Basic Rate
Power density	Basic Rate
Relative power	Enhanced Data Rate (EDR)

## Bluetooth Standards presets

### Presets > Standards

The Bluetooth Standards preset allows you to access displays preconfigured for the Bluetooth standard and test setup you select. The test setups load the displays and control setting options suggested by the standard to perform the measurements. You can read more about how Presets work [here](#).

There are four test setups for the LE 1M, LE 2M, and LE coded standard and eight test setups for the Basic Rate standard. There is one preset (no test setups) for the EDR standard.

The following table shows the set of Preset displays that load when the specified standards and test setups are selected.

**Table 8: Bluetooth standards, test setups, and Preset displays**

Standard	Test setup	Displays loaded with preset
LE 1M	Modulation/Frequency Offset/Drift/Output Power	BT Eye Diagram, BT Freq Dev vs Time, BT Summary, BT CF Offset and Drift, Spectrum, Time Overview
	In-band Emissions	BT InBand Emission, Spectrum, Time Overview
	Non-compliance	BT Freq Dev vs Time, BT Constellation, BT Summary, Spectrum, Spectrogram, Time Overview
LE 2M LE Coded (Requires Option SV31NL or SV31FL)	Modulation/Frequency Offset/Drift/Output Power	BT Eye Diagram, BT Freq Dev vs Time, BT Summary, BT CF Offset and Drift, Spectrum, Time Overview
	In-band Emissions	BT InBand Emission, Spectrum, Time Overview
	Non-compliance	BT Freq Dev vs Time, BT Constellation, BT Summary, Spectrum, Spectrogram, Time Overview

Table 8: Bluetooth standards, test setups, and Preset displays (cont.)


Standard	Test setup	Displays loaded with preset
Basic Rate	Modulation/Frequency Offset/Drift/Output Power	BT Eye Diagram, BT Freq Dev vs Time, BT Summary, BT CF Offset and Drift, Spectrum, Time Overview
	In-band Emissions	BT InBand Emission, Spectrum, Time Overview
	Tx Output Spectrum — 20dB Bandwidth	Bluetooth 20 dB BW, Spectrum, Time Overview
	Non-compliance	BT Freq Dev vs Time, BT Constellation, BT Summary, Spectrum, Spectrogram, Time Overview
Enhanced Data Rate (EDR)	Generic	BT Eye Diagram, BT Constellation, BT Summary, BT Symbol Table, Spectrum, Time Overview

### Retain current center frequency and reference level settings

The **Retain current Center Frequency setting** appears when the Bluetooth Standards Preset is chosen. This setting allows you to retain the previously used center frequency.

The **Retain current Ref Level setting** appears when the Bluetooth Standards Preset is chosen. This setting allows you to retain the previously used reference level.

To activate these settings, check the box next to the desired setting.



By default, the Ref Level setting box is checked.

By default, the Center Frequency setting box is unchecked and the Bluetooth preset displays will load with one of the center frequency values shown in the following table.

Table 9: Default center frequencies for Bluetooth test setups

Standard	Test setup	Center frequency
Basic Rate	Modulation/Frequency Offset/Drift/Output Power	2.441 GHz
LE 1M		
LE 2M		
LE Coded		
Basic Rate	In-band Emissions	2.441 GHz
LE 1M		
LE 2M		
LE Coded		
Basic Rate	Out-of-band Spurious Emissions	2.441 GHz
LE 1M		
LE 2M		
LE Coded		
Basic Rate	Tx Output Spectrum — 20dB Bandwidth	2.441 GHz
Basic Rate	Tx Output Spectrum — Power Density	2.441 GHz
Basic Rate	Non-compliance	2.441 GHz
LE 1M		
LE 2M		
LE Coded		
Basic Rate	Tx Output Spectrum — Frequency Range Lower	2.402 GHz
Basic Rate	Tx Output Spectrum — Frequency Range Higher	2.480 GHz
Enhanced Data Rate	Generic	2.441 GHz

**NOTE.** Changing analysis and display parameters recalculates the measurement results, but does not affect acquisitions.

## Bluetooth displays

The displays in Bluetooth Analysis (Setup > Displays > Measurements: Bluetooth Analysis) are:

- [Bluetooth 20dB Bandwidth](#)
- [Bluetooth Center Frequency Offset and Drift](#)
- [Bluetooth Constellation](#)
- [Bluetooth Eye Diagram](#)
- [Bluetooth Frequency Dev vs Time](#)
- [Bluetooth InBand Emission](#)
- [Bluetooth Summary](#)

- [Bluetooth Symbol Table](#)
- [Time Overview](#)

## Bluetooth measurements and test setups

A variety of measurements and test setups are provided by the Bluetooth Analysis option for use in performance testing of transmitters. These test setups allow the analyzer to compare the measurement result to the standards limit. Test engineers can select from the test setups and measurements described here. The following topics contain important information you should know about specific Bluetooth measurements and test setups.

---

**NOTE.** *Although the following information describes test setups for measurements recommended by the standard document, other measurement results may also be provided as additional information for a given measurement. For example, carrier frequency offset and drift results may be provided for modulation characteristics test setups.*

---

### Modulation characteristics (Basic Rate, LE 1M, LE 2M, LE Coded)

This measurement verifies that the modulation characteristics of the transmitted signal are correct. The Bluetooth test specification recommends this measurement be done using fixed frequency, also known as *hopping off*, and can be done in Direct Tx mode. This measurement can only be done if the payload has the bit pattern 10101010 or 11110000 for Basic Rate, LE 1M, and LE 2M; and 11001100 or 11110000 for LE Coded. This measurement and test setup are set to Free Run mode by default. However, you can set the analyzer to Triggered mode (Setup > Trigger) to do the measurements.

More information about this measurement:

- Select the Modulation/Frequency Offset/Drift/Output Power test setup from Presets > Standards to perform modulation characteristics measurements. This will load the displays found in the [Bluetooth standards, test setups, and Preset displays table](#). Additionally, you can choose to load the BT Symbol Table and BT Constellation displays, which can provide useful information.
- The Bluetooth Analysis splits the frequency deviation results in the payload region into octets (8 bit intervals). If the payload pattern is 10101010 for LE 1M and LE 2M, and 11001100 for LE Coded, then the maximum frequency deviation is calculated in every bit interval within an octet and recorded as  $\Delta f_{max}$ . The  $\Delta f_{max}$  results are averaged to give  $\Delta f_{2avg}$ . The percentage of  $\Delta f_{max}$  values greater than recommended lower limit is also found.
- If the payload is 11110000, the average frequency deviation is found in 4 bit intervals (2, 3, 6 and 7) and the average of these values is calculated as  $\Delta f_{1avg}$ . The ratio of  $\Delta f_{2avg}$  and  $\Delta f_{1avg}$  is also found.
- BT Freq Dev vs Time display has an octet view (zoomed view of the 8 bit intervals in Payload) and also shows the bit intervals in which the  $\Delta f_{max}$  values are computed. The octet view option also allows you to see the regions in which the calculations are done.

---

**NOTE.** *The octet view option is only available when Preamble is detected.*

---

- Specify an octet to view by entering a value in the Octet # field in the BT Freq Dev vs Time display. This also shows the maximum number of octets used for analysis. The start and end point for every octet can be clearly seen using the octet view.
- In the Summary display, the scalar results ( $\Delta f_{1avg}$ ,  $\Delta f_{2avg}$ , Ratio, Percentage of  $\Delta f_{max}$  values greater than a limit) averaged over the last 10 packets analyzed are shown along with the packet count. These averaged results can be compared against limits set in the Limits tab of the Settings control panel.
- The Points/symbol option in the Trace tab can be used to control how many samples per symbol should be used for computation of these measurements. The standard recommends 32 samples per symbol for Low Energy and 4 samples per symbol for Basic Rate. These are the default values provided for the respective standards in the Bluetooth Standards presets.

### Carrier frequency offset and drift (Basic Rate, LE 1M, LE 2M, LE Coded)

This measurement verifies that the carrier frequency offset and carrier drift of the transmitted signal is within the specified limits for the specified standard. The Bluetooth test specification recommends this measurement be done using fixed frequency, also known as *hopping off*, and can be done in Direct Tx mode. This test can be done only if the payload contains 10101010 bit pattern. This measurement and test setup are set to Free Run mode by default. However, you can set the analyzer to Triggered mode (Setup > Trigger) to do the measurements.

More information about this measurement:

- Select the Modulation/Frequency Offset/Drift/Output Power test setup from Presets > Standards to perform carrier frequency offset and drift measurements. This will load the displays found in the [Bluetooth standards, test setups, and Preset displays table](#). Additionally, you can choose to load the BT Symbol Table and BT Constellation displays, which can provide useful information.
- This measurement calculates the following:
  - Frequency offset in Preamble (initial Carrier Frequency Offset). Calculated in 8 bits for LE 1M ( $f_0$ ), 16 bits for LE 2M ( $f_0$ ) and 80 bits for LE Coded. For LE Coded the 80 bits preamble is split into five 16 bits parts ( $f_0$ - $f_4$ ).
  - For LE Coded there is an option to select only first 8 bits of  $f_4$ . (Selection available in Analysis Params). This will ensure that frequency offset computed in the interval  $f_4$  is not biased.
  - Frequency offset in Payload (calculated in 10 bit intervals for LE 1M, 20 bits for LE 2M, and 16 bits for LE Coded in payload).
  - Drift (the difference in frequency offset calculated in Payload from that calculated in Preamble).
  - The drift is measured by taking the difference in frequency offset between two fixed intervals. For LE 1M, the interval length is 10 bits and the difference between intervals is 50  $\mu$ s (5 intervals away). For LE 2M, the interval length is 20 bits and the interval difference is 50  $\mu$ s (5 intervals away). For LE Coded, the interval length is 16 bits and the interval difference is 48  $\mu$ s (3 intervals away).
- The BT CF Offset and Drift display shows all results in a table.

- The measurements shows the following scalar results:
  - Preamble frequency offset (initial carrier frequency offset).
  - Maximum frequency offset in Payload (along with the index number at which the offset is at maximum).
  - Drift of frequency offset from Preamble to first 10 bit interval in Payload ( $f_1 - f_0$ ).
  - Maximum drift between Payload and Preamble ( $f_n - f_0$ ) (along with index number at which the drift is maximum).
  - Drift between two 10 and 20 bits intervals is denoted as  $f_n - f_{n-5}$  for LE 1M and LE 2M. For LE Coded, it is denoted as  $f_n - f_{n-3}$ , which is 48  $\mu$ s away. The Maximum interval difference at which these values occur is shown in Frequency Drift display.
- The Preamble region in which the Preamble offset is calculated is shown in the BT Freq Dev vs Time display along with markings to show the region in which maximum drift occurred. Maximum drift between Payload and Preamble is shown from the end of Preamble to the end of 10 bit interval in Payload in which maximum drift occurred. Maximum drift in payload (in 50  $\mu$ s duration) is also shown.
- In the Summary display, the scalar results (mentioned above) averaged over the last 10 packets are shown along with the packet count. The results are compared against recommended limits. You can set these limits in the Limits tab of the Settings control panel.

### In-band Emissions (Basic Rate, LE 1M, LE 2M, LE Coded)

This measurement verifies that the in-band spectral emissions are within limits. The standard document recommends that this measurement be done with Hopping off, finding the integrated power in 1 MHz band (with RBW 100 kHz) in 80 channels starting from 2401 MHz to 2481 MHz. The test can be done in Direct Tx mode. The integrated power values calculated in the adjacent channels are compared against recommended limits (except the three channels around transmitted frequency). This measurement is referred to as ACPR in the Radio Frequency Test Specification for Basic Rate. It is recommended to do this measurement in Free Run mode (set in Setup > Trigger) if the analyzer does not support the required BW (80 MHz). The measurement internally searches for burst and aligns the measurement to the on-slot region.

---

**NOTE.** For analyzers with limited bandwidth, this measurement will be done over multiple acquisitions to generate the data required for the entire span. Therefore, it is important for the user to set an analysis length that will ensure that on slot region is always included.

---

More information about this measurement:

- Select the In-band Emissions test setup from Presets > Standards to perform the in-band emissions measurements. This will load the displays found in the [Bluetooth standards, test setups, and Preset displays table](#).
- The In-band Emissions display will set the Center Frequency to 2.441 GHz by default. When the Retain CF option is not enabled from Standards Presets, 80 bands (each of bandwidth 1 MHz) are analyzed and the integrated power is found (indicated by Blue lines in the plot).

- The integrated power is compared against limits for comparison (shown by white masks) in all bands except the three channels around the transmitted frequency. If any band fails, that band is shown in red color. If more than three channels fail to meet the recommended limits, a FAIL is shown in the top left corner of the display.
- The table below the plot shows the integrated power and also the limit for comparison.
- The limits for comparison are set to the values given by the standard by default, but you can manually set them from the Limits tab of the Settings control panel.
- This measurement is done only on the on slot region if a ramp-up and ramp-down portions are available. However, the measurement is done on the complete analysis region if a ramp up or ramp down is not available. It is recommended that a complete packet is included in the analysis region.
- When the analyzer does not support the 80 MHz bandwidth requirement, multiple acquisitions are taken in different bands and stitched together. This measurement is therefore best done in Free Run mode (set in Setup > Trigger) as Triggered mode might not find a proper edge in an acquisition taken for stitching purposes.

### Output Power (Basic Rate, LE 1M, LE 2M, LE Coded)

This test verifies the maximum peak and average power emitted from the EUT. The standards document recommends this test be done for a PRBS payload pattern. Also, the measurement must be done over the duration of a burst starting at preamble position. The Bluetooth test specification recommends this measurement be done using fixed frequency, also known as *hopping off*, and can be done in Direct Tx mode.

More information about this measurement:

- Select the Modulation/Frequency Offset/Drift/Output Power test setup from Presets > Standards to perform carrier frequency offset and drift measurements. This will load the displays found in the [Bluetooth standards, test setups, and Preset displays table](#).
- Calculates the average power and peak power for any Bluetooth signal. The peak power is the peak power value in the chosen on slot region.
- The measurement is done only on preamble detection; otherwise, it is invalid.
- The BT Summary display shows the averaged result over 10 packets.

### 20dB Bandwidth (Basic Rate)

This measurement verifies if the emissions inside the operating frequency range are within limits. This measurement is done with Hopping off. The difference between frequency points at which the power level drops to 20 dB below the peak power of the emission is found at 20 dB Bandwidth.

More information about this measurement:

- Select the 20dB Bandwidth test setup from Presets > Standards to perform the 20 dB emissions measurements. This will load the displays found in the [Bluetooth standards, test setups, and Preset displays table](#).
- The BT 20 dB BW display allows you to set the relative power level (x dB BW) compared to the peak power at which the frequency points are to be found.

- When you select the 20dB Bandwidth test setup, the center frequency (CF), span, and relative bandwidth (RBW) are set as recommended by the standard document.
- It is recommended this measurement be done over three different center frequencies. You can do this by changing the center frequency as needed.
- From the Params tab of the Settings control panel, you can select that the search for the x dB relative power (20 dB in this case) be performed in one of two modes: from the edges towards the peak power (inwards) or vice versa (outwards). The default for this setting is Inwards (from edges to peak power) when this measurement is chosen from the Standards Preset menu, as recommended.
- The blue markings in the plot indicate the 20 dB bandwidth and the frequency points at which the power level drops down by 20 dB from the peak power.
- The resulting 20 dB bandwidth is compared with the limits recommended by the standard document and Pass/Fail is shown in the top left corner of the plot. This is not user defined.

If the highest power value measured in step d) is equal or higher than 0 dBm:  $f = |f_H - f_L| \leq 1.0 \text{ MHz}$ .

If the highest power value measured in step d) is lower than 0 dBm:  $f = |f_H - f_L| \leq 1.5 \text{ MHz}$ .

### Frequency Range (Basic Rate)

These measurements verify if the emissions inside the operating frequency range are within limits. These measurements are done with Hopping off in two steps. The first measurement is done at the lower frequency spectrum of the Bluetooth band. (Start – 2399 MHz and Stop 2405 MHz). The second is done at the higher frequency spectrum of the Bluetooth band (Start -2475 MHz and Stop at 2485 MHz). The difference between the frequency point at which the power level drops to -30 dBm from the center frequency is measured.  $f_L$  is the difference on the lower side from the center frequency when the lower end of the spectrum is being analyzed.  $f_H$  is the difference from the center frequency on the higher side when the higher end of the spectrum is analyzed.  $f_H - f_L$  is the Frequency Range.

More information about these measurements:

- The BT 20dB BW display allows you to set the absolute power level (x dBm level) from the Parameters tab of the Settings control panel. The Bluetooth SIG Radio Frequency test specification document suggests that this value be set to -30 dBm for doing the Frequency Range measurement. If you chose to set up this measurement using start and stop frequencies and RBW, those should be set as recommended by the standard. Separate start and stop frequencies are given for the two steps of this measurement.
- You can select for the analysis to find the x dBm frequency difference from the center frequency either on the lower side, higher side, or both sides. This option (Meas Range) can be set from the Params tab of the Settings control panel.
- The blue marking indicates the frequency difference from the center frequency based on the Meas Range option choice. You can set this option to Low while analyzing in the lower range of the frequency spectrum, and set it to High when analyzing the higher range of the frequency spectrum.

### Power Density (Basic Rate)

This measurement verifies the maximum RF output power density.



More information about this measurement:

- This measurement can be done using the Spectrum display (Displays > Measurements > General Signal Viewing) and by setting appropriate parameters as recommended in the Bluetooth SIG Radio Frequency test specification document.
- The Bluetooth test specification recommends this measurement be done using fixed frequency, also known as *hopping off*, and can be done in Direct Tx mode.

### Out-of-band Spurious Emission (Basic Rate, LE 1M, LE 2M, LE Coded)

This measurement can be done for FCC or ETSI masks using the [Spurious](#) display.

### Relative Power (Enhanced Data Rate)

This measurement calculates the relative power in the GFSK and PSK part of the Enhanced Data Rate (EDR) signal. This measurement is supported only when an EDR signal is detected.

Select the Enhanced Data Rate standard from Presets > Standards to perform the measurement. This will load the displays found in the [Bluetooth standards, test setups, and Preset displays table](#).

## Bluetooth Status Messages

The following status messages may appear. Each message indicates the related condition (Description) shown in the following table.

Status message	Description
Bluetooth Analysis: Preamble Not Detected	Shown in the display and status bar when no valid Sync and Preamble are found for the chosen standard. Also shown when no preamble is found for any of the standards in Automatic Standard Detection mode.
Bluetooth Analysis: LE 1M Sequence Detected	Shown in the status bar when the LE 1M standard is detected in Automatic Standard Detection mode.
Bluetooth Analysis: LE 2M Sequence Detected	Shown in the status bar when the LE 2M standard is detected in Automatic Standard Detection mode.
Bluetooth Analysis: LE Coded Sequence Detected	Shown in the status bar when the LE Coded standard is detected in Automatic Standard Detection mode.
Bluetooth Analysis: Basic Rate Sequence Detected	Shown in the status bar when the Basic Rate standard is detected in Automatic Standard Detection mode.
Bluetooth Analysis: EDR Signal Detected	Shown in the status bar when the EDR standard is detected in Automatic Standard Detection mode.
Bluetooth Analysis: EDR Sync Word Not Detected	Shown in the display and status bar when EDR Sync Word is not found (when EDR standard is selected).
Bluetooth Analysis: Not enough payload data for Bluetooth measurements	Shown in the display and status bar when Preamble and Access Address/Sync Word is detected but there is not enough payload data for Modulation Characteristics and CF Offset and Drift measurement.
Bluetooth Analysis: Meas BW may be too low	Shown in the InBand Emission display and in status bar when Measurement Bandwidth is too low.
Bluetooth Analysis: BT x dB BW detection failed	Shown in the BT 20 dB BW display when x dB measurement detection fails.
Bluetooth Analysis: BT x dBm BW detection failed	Shown in the BT 20 dB BW display when x dBm measurement detection fails.

## Bluetooth Constellation display

The BT Constellation display shows a digitally modulated signal in constellation form. The constellation can be viewed either as IQ or Freq Dev. The default view is Freq Dev. The frequency deviation result that is shown in the Constellation display is compensated for the frequency error (shown as readout).

To show the BT Constellation display you can select **Presets > Standards > Bluetooth** or do the following:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** window, select **Bluetooth Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **BT Constellation** icon or select the icon and click **Add**. The BT Constellation icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click the **OK** button to show the display.
6. Select **Setup > Settings** to display the control panel.

7. Select the **Standard Params** tab. Set the Standard, Power class (if required), and Measurement and Reference filters as appropriate for the input signal. You can also check the **Auto Detect Standard** box.
8. Select the **Trace** tab and set the **Trace Type** to Freq Dev or IQ, as required.
9. Select Replay/Run to take measurements on the acquired data.
10. If you are analyzing a data file, click the **Replay** button to take measurements on the recalled acquisition data file.


## Elements of the Display

The following image shows the BT Constellation display of QPSK data in an EDR signal. Trace Type is set to IQ.



Item	Display element	Description
A	Trace	Select and enable a trace.
B	Trace Type	Specifies Trace type (choice between Freq Dev and IQ). This option appears only when EDR signal is detected.
C	Freq Error / Freq Offset / marker readouts	<p>The Freq Error, Freq Offset, and marker readout values appear here or below the plot, depending on the display view and size.</p> <p>The Freq Error value is the difference between the maximum and the minimum values of signal frequency during the measurement time. The Freq Error (Auto) value is displayed when the Auto check box is selected in the <b>Analysis Params</b> tab in the Settings control panel.</p> <p>The Freq Offset (Manual) value is displayed when the Auto check box is unselected in the <b>Analysis Params</b> tab in the Settings control panel.</p> <p>When markers are enabled, marker information (including time, magnitude, phase, symbol, and value) is displayed.</p>
D	Avg Dev	Shows the average deviation result at every symbol point.
E	Plot	Bluetooth constellation graph. Shown as either IQ or as Frequency Deviation. The trace type is controlled from the <b>Settings &gt; Trace</b> tab.
F	Show Vectors	Specifies whether to show or hide the selected trace.

The following image shows the BT Constellation display of GFSK data in a Basic Rate signal. Trace Type is set to Freq Dev.



## BT Constellation Settings

Main menu bar: Setup > Settings

Favorites toolbar: 

The BT Constellation Settings control panel provides access to settings that control parameters of the Constellation Display.

Settings tab	Description
<a href="#">Standard Params</a>	Select the standard, measurement filters, reference filters, and power class (when applicable). You can also set the analyzer to auto detect the standard.
<a href="#">Analysis Params</a>	Specifies frequency error, frequency offset, measurement BW, and test patterns. You can also select to auto detect test patterns. These parameters are used by the instrument to analyze the input signal.
<a href="#">Analysis Time</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) and Time Zero Reference (Trigger or Acquisition Start) for Bluetooth Analysis displays.
<a href="#">Traces</a>	Allows you to select the trace to view, the trace type (IQ or Freq Dev), the number of points per symbol (when trace content is set to Vectors or Lines), and to show or freeze the selected trace.
<a href="#">Prefs</a>	Allows you to select to show or hide the graticule and marker readouts.

## Bluetooth Eye Diagram display


The BT Eye Diagram display shows a digitally modulated signal overlapped on itself to reveal variations in the signal.

To show the BT Eye Diagram display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. From the **Measurements** box, select **Bluetooth Analysis**.
4. Double-click the **BT Eye Diagram** icon in the **Available Displays** box. This adds the BT Eye Diagram icon to the **Selected displays** box.
5. Click **OK** button. This displays the BT Eye Diagram view.
6. Select **Setup > Settings** to display the control panel.
7. Select the **Standard Params** tab. Set the Standard, Power class (when appropriate), and Measurement and Reference filters as appropriate for the input signal. You can also check the **Auto Detect Standard** box.
8. Select the **Trace** tab and set the **Trace Type** to Freq Dev or IQ, as required..
9. Select **Replay/Run** to take measurements on the acquired data.
10. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.


### Elements of the Display

The following image shows the BT Eye display of a basic rate signal with Trace Type set to IQ.



Item	Display element	Description
A	Freq Error / Freq Offset	The Freq Error value is the difference between the maximum and the minimum values of signal frequency during the measurement time. The Freq Error (Auto) value is displayed when the Auto check box is selected in the <b>Analysis Params</b> tab in the Settings control panel. The Freq Offset (Manual) value is displayed when the Auto check box is unselected in the <b>Analysis Params</b> tab in the Settings control panel.
B	Top of graph	The vertical scale is normalized with no units (for IQ) and with Hz (for Freq Dev).
C	Position	Specifies the value shown at the center of the graph display.
D	Bottom Readout	Displays the value indicated by the bottom of graph.
E	Autoscale	Adjusts the vertical and horizontal settings to provide the best display.
F	Position	Displays the horizontal position of the trace on the graph display.
G	Scale	Adjusts the span of the graph in symbols.
H	Plot	Displays the input signal.

The following image shows the BT Eye display of a Basic Rate signal with Trace Type set to Freq Dev.



## BT Eye Diagram Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the BT Eye Diagram display are shown in the following table.

---

**NOTE.** You might save time configuring the BT Eye Diagram display by selecting the Standard Presets button in the Bluetooth Eye Diagram Settings control panel. This allows you to select a preset optimized for the selected standard.

---

Settings tab	Description
<a href="#">Standard Params</a>	Select the standard, measurement filters, reference filters, and power class (when applicable). You can also set the analyzer to auto detect the standard.
<a href="#">Analysis Params</a>	Specifies frequency error, frequency offset, measurement BW, and test patterns. You can also select to auto detect test patterns. These parameters are used by the instrument to analyze the input signal.
<a href="#">Analysis Time</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) and Time Zero Reference (Trigger or Acquisition Start) for Bluetooth Analysis displays.
<a href="#">Traces</a>	Allows you to select the trace to view, the trace type (IQ or Freq Dev), the number of points per symbol (when trace content is set to Vectors or Lines), and to show the selected trace.
<a href="#">Scale</a>	Allows you to specify the horizontal and vertical scale settings.
<a href="#">Prefs</a>	Allows you to select to show or hide the graticule and marker readouts.

## Bluetooth Carrier Frequency Offset and Drift display

The BT CF (Carrier Frequency) Offset and Drift display shows the frequency offset preamble, payload regions, and the drift result values are shown in this display. You can also view the values of frequency offset calculated in every ten bit interval in the payload and look for excursions.

To show the BT CF (Carrier Frequency) Offset and Drift display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **Bluetooth Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **BT CF Offset and Drift** icon or select the icon and click **Add**. The BT CF Offset and Drift icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the display.
6. Select **Setup > Settings** to display the control panel.
7. Select the **Standard Params** tab. Set the Standard, Power class (when appropriate), and Measurement and Reference filters as appropriate for the input signal. You can also check the **Auto Detect Standard** box.
8. Select the **Limits** tab and set the limits , as required.
9. Select **Replay/Run** to take measurements on the acquired data.
10. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.



## Elements of the Display

The following image shows the frequency offset and drift values of a basic rate (first image) and LE Coded signal in the BT Freq Offset and Drift display.

Interval#	Frequency offset (Hz)	Drift from f0 (Hz)	Drift - 50us (Hz)
	Limits fn (-150.0kHz to +150.0kHz)	Limits fn-f0 (-40.0kHz to +40.0kHz) f1-f0 (-20.0kHz to +20.0kHz)	Limits fn-f(n-5) (-20.0kHz to +20.0kHz)
► 0 (Preamble)	6434.094		
1	6422.583	-11.51074	
2	5296.85	-1137.244	
3	6478.38	44.28564	
4	6880.799	446.7051	
5	5173.156	-1260.938	
6	5455.798	-978.2959	-966.7852
7	5832.239	-601.855	535.3892
8	6631.489	197.395	153.1094
9	5221.211	-1212.883	-1659.588
10	4814.595	-1619.499	-358.5605
11	6111.346	-322.748	655.5479
12	6569.333	135.2388	737.0938
13	4871.332	-1562.763	-1760.158

Freq Offset Preamble: 6.434 kHz  
 Max Freq Offset (Payload): 7.826 kHz @ 131

Drift f1-f0: -11.51 Hz  
 Max Drift fn-f0: -4.080 kHz @ 115

Max Drift fn-f(n-5): 3.696 kHz @ 208

Interval#	Frequency offset (Hz)	Drift from f0 (Hz)	Drift - 48us (Hz)
	Limits fn (-150.0kHz to +150.0kHz)	Limits fn-f0 (-50.0kHz to +50.0kHz)	Limits f0-f3 (-19.2kHz to +19.2kHz) f1-f4 (-19.2kHz to +19.2kHz) fn-f(n-3) (-19.2kHz to +19.2kHz)
► 0 (Preamble)	258.2126		
1 (Preamble)	-74.10534	-332.318	
2 (Preamble)	-289.2607	-547.4733	
3 (Preamble)	233.2176	-24.99501	24.99501
4 (Preamble)	15082.45	14824.24	-15156.55
5	-67.59009	-325.8027	
6	18.36853	-239.8441	
7	-228.1871	-486.3997	
8	-197.742	-455.9546	-130.1519
9	-47.53453	-305.7472	-65.90306
10	164.5431	-93.66956	392.7302
11	-333.5484	-591.7611	-135.8065
12	285.7397	27.5271	333.2743
13	-131.973	-390.1856	-296.5161
14	41.5774	-216.6353	375.1258
15	-388.7002	-646.9128	-674.4399
16	205.0563	-53.15637	337.0293
17	8.140196	-250.0724	-33.4372
18	-203.3326	-461.5452	185.3676
19	-213.4553	-471.668	-418.5116
20	63.34568	-194.867	55.20549
21	2.224886	-255.9878	205.5575

Freq Offset Preamble: 3.042 kHz  
 Max Freq Offset (Payload): 2.947 kHz @ 122

Max Drift f1-f0: 14.82 kHz @ 4  
 Drift f0-f3: 24.995 Hz

Drift f1-f4: -15.157 kHz  
 Max Drift fn-f(n-3): -15.16 kHz @ 4

Display element	Description
Column 1	Indicates ten bit interval numbers. Zero indicates preamble region and the non-zero number indicate the ten bit intervals in payload.
Column 2	Shows the calculated frequency offset in the preamble and the ten bit intervals in the payload.
Column 3	Shows the drift of offset from the preamble and over a 50 $\mu$ s for LE 1M, LE 2M and 48 $\mu$ s for LE Coded duration.
Column 4	Shows the drift of offset over a 50 $\mu$ s for LE 1M, LE 2M and 48 $\mu$ s for LE Coded duration.
—	Results that do not meet the limits are shown with a red colored background, indicating failure. (Limits can be set in the Limits tab from the Settings control panel.)
Scalar results	<p>The scalar results show below the table. They are as follows:</p> <p>Freq Offset Preamble</p> <p>Max Freq Offset (Payload)</p> <p>For LE 1M, LE 2M:</p> <p>Drift <math>f_1-f_0</math></p> <p>Max Drift <math>f_n-f</math></p> <p>Max Drift <math>f_n-f_{(n-5)}</math></p> <p>For LE Coded:</p> <p>Drift <math>f_0-f_3</math></p> <p>Max Drift <math>f_1-f_4</math></p> <p>Max Drift <math>f_n-f_{(n-3)}</math></p>

## BT CF Offset and Drift Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the BT CF Offset and Drift display are shown in the following table.

Settings tab	Description
<a href="#">Standard Params</a>	Select the standard, measurement filters, and power class (when applicable). You can also set the analyzer to auto detect the standard.
<a href="#">Analysis Params</a>	Specifies frequency error, frequency offset, measurement BW, and test patterns. You can also select to auto detect test patterns. These parameters are used by the instrument to analyze the input signal.
<a href="#">Analysis Time</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) and Time Zero Reference (Trigger or Acquisition Start) for Bluetooth Analysis displays.
<a href="#">Limits</a>	Allows you to load and define Bluetooth measurement limits for Pass/Fail comparison. You can save defined limits as a .csv file and also load previously saved .csv files. These limits also apply to the Settings control panel Limits tab of the BT Summary display.

## Bluetooth Summary display

The BT Summary display shows a summary of all the scalar measurements done on the acquired test pattern. The summary display and contents will vary according to the selected standard.

Pass/Fail information is also provided in this display for all enabled scalar measurements. You can set limits and choose which measurement to compare for Pass/Fail from the Limits tab of the BT Summary Settings control panel. The default limits come from the performance recommendation limits given by the Standards document. The default limits can be reloaded by selecting the Bluetooth Standards Preset option.

The results presented in the BT Summary display include scalar results of modulation characteristics, frequency offset and drift and, output power measurements (these are averaged over the last 10 acquired packets). The display also shows packet related information for the current acquired packet.

To show the BT Summary display you can select **Presets > Standards > Bluetooth** or do the following:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **Bluetooth Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **BT Summary** icon or select the icon and click **Add**. The BT Summary icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the display.
6. Select **Setup > Settings** to display the control panel.
7. Select the **Standard Params** tab. Set the Standard, Power class (when appropriate), and Measurement and Reference filters as appropriate for the input signal. You can also check the **Auto Detect Standard** box.
8. Select the **Limits** tab and set the limits , as required.

9. Select Replay/Run to take measurements on the acquired data.
10. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

### Elements of the display

The following image shows all average scalar results and packet information for a Basic Rate signal in the BT Summary display. Modulation characteristics, carrier frequency offset and drift, and power measurements, along with packet information, are shown. The packet information will vary depending on the chosen or detected standard. For more information about specific measurement results, see the Bluetooth measurements and test setups section [here \(see page 573\)](#).

**Standard:** Basic Rate
 Class3
 Clear

**Modulation Characteristics [10 packet-average]**

$\Delta F_{1avg}$ (00001111):	-- Hz	-- of 10	N/A
$\Delta F_{2avg}$ (10101010):	144.8 kHz		
$\Delta F_{2Max\%} \geq 115$ kHz:	100.0 %	1 of 10	PASS
$\Delta F_{2avg}/\Delta F_{1avg}$ :	--		N/A
Modulation Index:	--		

**Frequency Offset and Drift [10 packet-average]**

Freq Offset (Preamble):	6.434 kHz	PASS
Max Freq Offset:	7.826 kHz	PASS
Drift f1-f0:	-11.51 Hz	PASS
Max Drift fn-f0:	-4.080 kHz	PASS
Max Drift fn-f(n-5):	3.696 kHz	PASS

**Output Power [10 packet-average]**

Peak Power Ppk:	-20.77 dBm	PASS
Average Power Pavg:	-21.04 dBm	PASS

**Packet Information**

Packet Type	DH5
Preamble (4 bits)	0101
Sync Word (64 bits)	0x4F36F2CEE85390CB
Packet Header (18 bits)	
LT_ADDR (3 bits)	001
Type (4 bits)	1111
Flow (1 bit)	1
ARQN (1 bit)	0
SEQN (1 bit)	1
HEC (8 bits)	00110001
PayLoad Length	0101010011
CRC (16 bits)	0x273D

Element	Description
Standard	Display of the selected standard or the detected standard (if the Auto Detect Standard setting is chosen in the Standard Params tab of the Settings control panel).
Power class	Display of the Power class in the Standard Params tab of the Settings control panel. Only available when Basic Rate is the selected or detected standard.
Clear	Click button to reset measurement. Clears all values and all results in the queue used for average computation.

Element	Description
Modulation characteristics (ten packet average)	<p>Display of a group of scalar results related to Modulation Characteristics measurements. These scalar results are only populated in the BT Summary display if preamble is detected in the acquired data. The four scalar results are:</p> <p><math>\Delta f1_{avg}</math> is calculated when analyzed test pattern (payload) is 11110000.</p> <p><math>\Delta f2_{avg}</math> and the percentage of <math>\Delta f2_{max}</math> value (greater than a given limit) are calculated only when analyzed test pattern (payload) is 10101010 for LE 1M and LE 2M, and 11001100 for LE Coded.</p> <p>The ratio of <math>\Delta f2_{avg}</math> and <math>\Delta f1_{avg}</math> is calculated provided both the results are available (or have been done before).</p> <p>All the results given are averaged over the last ten packets. The scalar results can be compared with pass/fail limits set in the Limits tab of the Settings control panel.</p> <p>More information can be found <a href="#">here (see page 573)</a>.</p>
Modulation index	<p>The Modulation index denotes if the transmitter of a BLE Packet is Stable or Standard. If it is Stable, the modulation index will be between 0.495 and 0.505. If it is Standard, the modulation index will be between 0.475 and 0.525. If neither of these conditions is satisfied, then no text is shown.</p>
Frequency offset and drift (ten packet average)	<p>Display of a group of five scalar results related to the carrier frequency offset and drift measurement. These scalar results are only populated in the BT Summary display if preamble is detected and if the test pattern payload is a 10101010 pattern. All the results given are averaged over the last ten packets. The scalar results can be compared with pass/fail limits set in the Limits tab of the Settings control panel.</p> <p>The eight scalar results are:</p> <p>Preamble offset.</p> <p>Maximum offset in Payload (calculated over 10 bit intervals for LE 1M, 20 bit intervals for LE 2M, and 16 bit intervals for LE Coded).</p> <p>Drift (<math>f_1-f_0</math>)</p> <p>Max Drift (<math>f_n-f_0</math>).</p> <p>Max Drift (<math>f_n-f_n-5</math>) for LE 1M, LE 2M</p> <p>Drift (<math>f_0-f_3</math>)</p> <p>Max Drift (<math>f_1-f_4</math>)</p> <p>Max Drift (<math>f_n-f_n-3</math>) for LE Coded</p> <p>For more information about this measurement, see the <a href="#">Carrier frequency offset and drift (Basic Rate, LE 1M, LE 2M, LE Coded) (see page 613)</a> topic in <i>Bluetooth Measurements and test setups</i>.</p>
Output power	<p>Display of Average Power and Peak Power scalar results for Output Power. All the results given are averaged over the last ten packets. The scalar results can be compared with pass/fail limits set in the Limits tab of the Settings control panel.</p> <p>For Enhanced Data Rate signals, the relative power in GFSK and PSK regions is measured.</p> <p>For more information about this measurement, see the <a href="#">Output Power (Basic Rate, LE 1M, LE 2M, LE Coded) (see page 579)</a> topic in <i>Bluetooth Measurements and test setups</i>.</p>
Packet information	<p>The Packet information includes the Packet type, Preamble, Synchronization Word or Access Code, Packet Header, Payload length, and CRC details. The decoded bits are shown for the current analyzed packet.</p>

The following image shows all average scalar results and packet information for a LE 1M< LE 2M, and LE Coded signal in the BT Summary display.

**Standard:** LE 1M Clear

Modulation Characteristics [10 packet-average]		
$\Delta F_{1avg}$ (00001111):	-- Hz	-- of 10 <span>N/A</span>
$\Delta F_{2avg}$ (10101010):	229.1 kHz	
$\Delta F_{2Max\%} \geq 185$ kHz:	100.0 %	2 of 10 <span>PASS</span>
$\Delta F_{2avg}/\Delta F_{1avg}$ :	--	<span>N/A</span>
Modulation Index:	--	

Frequency Offset and Drift [10 packet-average]		
Freq Offset (Preamble):	158.1 Hz	<span>PASS</span>
Max Freq Offset:	57.43 Hz	<span>PASS</span>
Drift $f_1-f_0$ :	-100.7 Hz	<span>PASS</span>
Max Drift $f_n-f_0$ :	-160.2 Hz	<span>PASS</span>
Max Drift $f_n-f_{(n-5)}$ :	-57.43 Hz	2 of 10 <span>PASS</span>

Output Power [10 packet-average]		
Peak Power Ppk:	-29.51 dBm	<span>FAIL</span>
Average Power Pavg:	-30.00 dBm	2 of 10 <span>FAIL</span>

Packet Information	
Packet Type	BLE_TEST
Preamble (8 bits)	01010101
Access Address (32 bits)	0x71764129
PDU Header (16 bits)	
Length (8 bits)	00100101
PDU Type (4 bits)	0010
ChSel (1 bit)	--
Tx Address (1 bit)	--
Rx Address (1 bit)	--
CRC (24 bits)	0x555555

The following image shows all average scalar results and packet information for an EDR signal in the BT Summary display.

**Standard:** EDR Clear

Modulation Characteristics [10 packet-average]		
$\Delta F_{avg}$ :	-- Hz	0 of 10

Frequency Offset and Drift [10 packet-average]		
Freq Offset (Preamble):	-- Hz	<span>N/A</span>
Max FreqOffset:	-- Hz	
Drift $f_1-f_0$ :	-- Hz	
Max Drift $f_n-f_0$ :	-- Hz	
Max Drift $f_n-f_{n-5}$ :	-- Hz	-- of 10 <span>N/A</span>

Output Power [10 packet-average]		
POWER GFSK:	-28.42 dBm	
POWER DPSK:	-28.51 dBm	1 of 10

Packet Information	
Packet Type	EDR_2DH1
Preamble (4 bits)	0101
Sync Word (64 bits)	0x4F36F2CEE85390CB
Packet Header (18 bits)	
LT_ADDR (3 bits)	001
Type (4 bits)	0100
Flow (1 bit)	1
ARQN (1 bit)	0
SEQN (1 bit)	1
HEC (8 bits)	11010111
PayLoad Length	110110
CRC (16 bits)	--

## BT Summary Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the BT Summary display are shown in the following table.

Settings tab	Description
<a href="#">Standard Params</a>	Select the standard, measurement filters, reference filters, and power class (when applicable). You can also set the analyzer to auto detect the standard.
<a href="#">Analysis Params</a>	Specifies frequency error, frequency offset, measurement BW, and test patterns. You can also select to auto detect test patterns. These parameters are used by the instrument to analyze the input signal.
<a href="#">Analysis Time</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) and Time Zero Reference (Trigger or Acquisition Start) for Bluetooth Analysis displays.
<a href="#">Limits</a>	Allows you to load and define Bluetooth measurement limits for Pass/Fail comparison. You can save defined limits as a .csv file and also load previously saved .csv files. The frequency offset and drift limits set here also apply to the CF Offset and Drift display.

## Bluetooth Symbol Table display

The BT Symbol Table display shows decoded data values for each data symbol in the analyzed signal packet. It is like the BT Constellation display except that a text table is used to display data instead of a graph.

To show the BT Symbol Table display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **Bluetooth Analysis** in the **Measurements** box.
4. In the Available displays box, double-click the **BT Symbol Table** icon or select the icon and click **Add**. The BT Symbol Table icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the display.
6. Select **Setup > Settings** to display the control panel.
7. Select the **Standard Params** tab. Set the Standard, Power class (when appropriate), and Measurement and Reference filters as appropriate for the input signal. You can also check the **Auto Detect Standard** box.

8. Select the **Limits** tab and set the limits , as required.
9. Select Replay/Run to take measurements on the acquired data.
10. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

### Regions of the Display

The BT Symbol Table is color coded to indicate different regions of the packet. The legend at the bottom of the symbol table lists the packet contents in their associated colors. The following image shows values for a Basic Rate signal.

Bluetooth Symbol Table																	
0	1	0	1	0	1	1	0	1	0	0	1	1	0	0	0	0	
16	1	0	0	1	1	1	0	0	1	0	1	0	0	0	0	1	
32	0	1	1	1	0	1	1	1	0	0	1	1	0	1	0	0	
48	1	1	1	1	0	1	1	0	1	1	0	0	1	1	1	1	
64	0	0	1	0	0	0	0	0	0	0	0	0	0	1	1	1	
80	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0	
96	0	0	1	1	1	0	0	0	0	0	0	0	0	0	1	1	
112	1	1	1	1	0	0	0	0	0	0	1	1	1	1	1	0	
128	0	1	0	1	0	1	0	0	0	0	1	1	1	1	0	0	
144	0	0	1	1	1	1	0	0	0	0	1	1	1	1	0	0	
160	0	0	1	1	1	1	0	0	0	0	1	1	1	1	0	0	
176	0	0	1	1	1	1	0	0	0	0	1	1	1	1	0	0	
192	0	0	1	1	1	1	0	0	0	0	1	1	1	1	0	0	
208	0	0	1	1	1	1	0	0	0	0	1	1	1	1	0	0	
Preamble				Packet Header				Payload									
Synchronization/Access Address				Payload Header				MIC/CRC									
Marker:				Time:				Symbol:				Value:					



Packet standard	Associated regions
Basic rate	4-bit preamble 64-bit access code 4-bit trailer 54-bit packet header 8- or 16-bit payload header based on packet type Variable length payload data 16-bit CRC (Cyclic Redundancy Check)
LE 1M	8-bit preamble 32-bit access address / synchronization word 16-bit payload header Variable length payload data (2–257 bytes) 24-bit CRC (Cyclic Redundancy Check)
LE 2M	8-bit preamble 32-bit access address / synchronization word 16-bit payload header Variable length payload data (32–257 bytes) 24-bit CRC (Cyclic Redundancy Check)
LE Coded	80-bit preamble 256-bit access address / synchronization word 16-bit payload header Variable length payload data (16–2057 bytes) 24-bit CRC (Cyclic Redundancy Check)
Enhanced Data Rate (EDR)	4-bit preamble 64-bit access code 4-bit trailer (if present, shown in black) 54-bit packet header Guard region (shown as X) EDR sync sequence (QPSK or 8PSK symbols) 16-bit payload header (QPSK or 8PSK symbols) Variable length payload data (QPSK or 8PSK symbols) 16-bit CRC (Cyclic Redundancy Check) (QPSK or 8PSK symbols)

The following image shows values for a Low Energy signal.

Bluetooth Symbol Table

0	1	0	1	0	1	0	1	0	1	0	0	1	0	1	0	0
16	1	0	0	0	0	0	1	0	0	1	1	0	1	1	1	0
32	1	0	0	0	1	1	1	0	0	1	0	0	0	0	0	0
48	1	0	1	0	0	1	0	0	0	1	0	1	0	1	0	1
64	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1
80	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1
96	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1
112	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1
128	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1
144	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1
160	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1
176	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1
192	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1
208	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1
224	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1
240	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1
256	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1
272	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1
288	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1
304	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1
320	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1

Preamble

Synchronization/Access Address

Packet Header

Payload Header

Payload

MIC/CRC

Marker: MR    Time: 30.529 us    Symbol: 27    Value: 0

The following image shows values for an EDR signal.

Bluetooth Symbol Table

data from warm-up period

0	1	0	1	0	1	1	0	1	0	0	1	1	0	0	0	0
16	1	0	0	1	1	1	0	0	1	0	1	0	0	0	0	1
32	0	1	1	1	0	1	1	1	0	0	1	1	0	1	0	0
48	1	1	1	1	0	1	1	0	1	1	0	0	1	1	1	1
64	0	0	1	0	1	0	1	0	1	1	1	0	0	0	0	0
80	0	0	0	0	0	0	0	1	1	1	0	0	0	1	1	1
96	0	0	0	1	1	1	1	1	1	1	1	1	1	1	1	0
112	0	0	1	1	1	0	0	0	1	1	1	1	1	1	X	X
128	X	X	X	0	1	3	1	3	1	3	3	1	1	1	2	2
144	3	1	2	0	0	0	1	1	1	1	1	1	1	1	1	1
160	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
176	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
192	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
208	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
224	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
240	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
256	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
272	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
288	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
304	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
320	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1

Preamble (GFSK)

Access Address (GFSK)

Packet Header (GFSK)

EDR Sync Sequence (PSK)

Payload (PSK)

MIC/CRC (PSK)

Marker:Time:Symbol:Value:

**Markers and the BT Symbol Table.** Markers are indicators in the display that you can position on a trace to measure values such as frequency, power, and time. A Marker always displays its position and, if the Delta Marker (M1-M4) readout is enabled, will display the difference between its position and that of the

Marker Reference (MR). In the BT Symbol Table, colored cells indicate the location of markers. The selected Marker is highlighted with a light green background. All other markers are highlighted with a light gray background. In the BT Symbol Table, the marker readout below the table shows the marker location in time, symbol numbers and symbol value.

## BT Symbol Table Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the BT Symbol Table display are shown in the following table.

Settings tab	Description
Standard Params	Select the standard, measurement filters, reference filters, and power class (when applicable). You can also set the analyzer to auto detect the standard.
Analysis Params	Specifies frequency error, frequency offset, measurement BW, and test patterns. You can also select to auto detect test patterns. These parameters are used by the instrument to analyze the input signal.
Analysis Time	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) and Time Zero Reference (Trigger or Acquisition Start) for Bluetooth Analysis displays.
Prefs	Allows you to select to show or hide the marker readouts and set the radix of shown symbols.

## Bluetooth Frequency Dev vs Time display

The BT Freq Dev vs. Time display shows how the signal frequency varies with time.


To display the BT Freq Dev vs. Time display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Select the **Displays** button or **Setup > Displays**.
3. In the **Select Displays** dialog, select **Bluetooth Analysis** in the **Measurements** box.
4. In the **Available displays** box, double-click the **BT Freq Dev vs. Time** icon or select the icon and click **Add**. The BT Freq Dev vs. Time icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the display.
6. Select the **Standard Params** tab. Set the Standard, Power class (when appropriate), and Measurement and Reference filters as appropriate for the input signal. You can also check the **Auto Detect Standard** box.
7. Select the **Trace** tab and set the **Content** to Vectors or Points, as required.

8. Select Replay/Run to take measurements on the acquired data.
9. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

### Elements of the Display


The following image shows the frequency deviation of the complete packet of a Basic Rate signal in the BT Freq Dev vs. Time display.




Item	Display element	Description
A	Top of graph	The vertical scale is normalized with Hz.
B	View	<p>(This option is visible only when Preamble is detected.)</p> <p>Select one of the following:</p> <p>Packet: view frequency deviation for an entire packet.</p> <p>Octet: view frequency deviation for a specified octet duration (8 <math>\mu</math>s). The Octet is specified in the Octet # field.</p>
C	Octet # (xx of total)	<p>(This option is visible only when Preamble is detected and Octet is selected as the View.)</p> <p>Specifies the Octet number. (The total number of octets is also indicated.)</p> <p>When View is set to Octet, you can enter a particular octet in the Octet # field for zoom view. The plot will show only 8 <math>\mu</math>s of information corresponding to the octet number chosen in the payload. The regions that are used for doing the exact measurements are highlighted in the Octet View. For F0F0 (Low Deviation) pattern in payload, bit intervals 2,3,6,7 regions are highlighted. For 10101010 LE 1M and LE 2M, and 11001100 for LE Coded (high deviation) pattern, all bit regions are highlighted with appropriate results. The offset calculated for every octet region (f1ccf or f2ccf) are also shown.</p>
D	Position (center)	Adjust the frequency shown at the center of the display.
F	Autoscale button	Adjusts the offset and range for both vertical and horizontal to provide the best display.
G	Position	Displays the horizontal position of the trace on the graph display.
H	Scale	Adjusts the horizontal scale (time).
I	Plot	Displays the last analyzed complete packet or the selected octet (Octet zoom view) of the signal.
J	Scalar results	<p>The Scalar results for Modulation Characteristics and Frequency Offset and Drift measurements are captured here. These results are from the last analyzed packet and therefore could be different from the Averaged Scalar results shown in the BT Summary display.</p> <p>For Drift results, the index is also shown where the maximum drift occurred. The Drift results are shown only when the preamble is detected and the test pattern payload detected is 10101010 for LE 1M and LE 2M, and 11001100 for LE Coded. <math>\Delta F1_{avg}</math> or <math>\Delta F2_{avg}</math> is shown only when the detected test pattern payload is (10101010) for LE 1M and LE 2M or (11001100) for LE Coded.</p>

**NOTE.** *This display shows the frequency deviation results without compensating for the frequency error.*

The following image shows the frequency deviation of the first octet in the payload of a Basic Rate signal (high deviation).



The following image shows the frequency deviation of the first octet in the payload of a Basic Rate signal (low deviation).



## BT Frequency Dev Vs Time Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The Setup settings for BT Freq Dev vs. Time are shown in the following table.

Settings tab	Description
Standard Params	Select the standard, measurement filters, reference filters, and power class (when applicable). You can also set the analyzer to auto detect the standard.
Analysis Params	Specifies frequency error, frequency offset, measurement BW, and test patterns. You can also select to auto detect test patterns. These parameters are used by the instrument to analyze the input signal.
Analysis Time	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) and Time Zero Reference (Trigger or Acquisition Start) for Bluetooth Analysis displays.
Trace	Allows you to select the number of points per symbol, content, and to choose between entire packet view or zoom Octet view for a chosen octet number in a packet.
Scale	Allows you to specify the horizontal and vertical scale settings.
Prefs	Allows you to select to show or hide the graticule and marker readouts.

## Bluetooth 20dB Bandwidth display

The BT 20dB BW display shows the results of two Bluetooth measurements: 20dB Bandwidth and Frequency Range. When the xdB BW is chosen, the display shows the x dB bandwidth from the peak power. More detailed information about this measurement is available [here \(see page 573\)](#).


To display the BT 20dB BW display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Select the **Displays** button or **Setup > Displays**.
3. In the **Select Displays** dialog, select **Bluetooth Analysis** in the **Measurements** box.
4. In the **Available displays** box, double-click the **BT 20dB BW** icon or select the icon and click **Add**. The BT 20dB BW icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the display.
6. Select the **Standard Params** tab. Set the Standard, Power class (when appropriate), and Measurement and Reference filters as appropriate for the input signal. You can also check the **Auto Detect Standard** box.

7. Select the **Trace** tab and set the **Content** to Vectors or Points, as required.
8. Select Replay/Run to take measurements on the acquired data.
9. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

### Elements of the Display

The following image of the BT 20dB BW display shows a Basic Rate signal that would allow you to measure 20 dB bandwidth.





Item	Display element	Description
A	PASS / FAIL	Indicates Pass or Fail for the 20 dB BW measurement.
B	Autoscale	Adjusts the vertical and horizontal settings so that the entire trace fits in the graph.
C	Normal / MaxHold	Indicates whether the measurement is done with a MaxHold or a Normal condition.
D	Clear	Resets count for Average and MaxHold functions. Enabled only when Averaging or MaxHold is enabled. Pressing Clear will clear the trace and, if acquisition is running, restart the averaging or hold process.
E	Main results area	Shows the xdBm and xdB results. The requested dB or dBm value can be set in the controls below the result readout. Use the two radio buttons to select which of the two results are illustrated in the graph with the blue lines and arrows. RBW also can be set using the control. VBW enables the VBW (Video Bandwidth) filter. Displays current VBW filter setting. See Setup > Settings > Freq & RBW tab.
F	Position and dB/div Units (not shown)	Position sets the top of graph value. The dB/div setting is the vertical scale value.  Set the global Amplitude units for all the views in the analysis window using the drop down menu that appears when you click on the box. This will change the amplitude selection in the Units tab of the Amplitude control panel.
G	Bottom readout	Displays the value indicated by the bottom of graph.
H	Position	Displays the horizontal position of the trace on the graph display.
I	Scale	Adjust the span of the graph in symbols.
J	Detailed results	Displays the following additional measurements results:  <b>Freq Error:</b> The frequency difference between the measured carrier frequency of the signal and the user-selected center frequency of the analyzer.  <b>x dB BW Ref Power:</b> The peak power measured within the measurement bandwidth.
K	Grid divider	Determines the portion of the display allocated to the graph and detailed results area. You can move the grid divider all the way to the top or bottom and any position in between.
L	Blue lines	Indicates the measurement positions.
M	Plot	Displays the input signal. Shaded areas indicate the measurement bandwidth (Settings > Parameters tab > Measurement BW).

## BT 20dB BW settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The Setup settings for BT 20dB BW are shown in the following table.

Settings tab	Description
Freq & RBW	Allows you to specify the frequency, resolution bandwidth (RBW), step, and VBW used for the MCPR measurements.
Parameters	Allows you to specify the x dB level, Measurement Direction, Measurement BW, xdBm level, xdBm Range, count, and to enable averaging and the Max Hold function.
Scale	Allows you to define the vertical and horizontal axes.
Prefs	Allows you to select show or hide the graticule and marker readouts.

## Bluetooth InBand Emission display


The BT InBand Emission display verifies whether the emissions inside the operating frequency range are within limits. The power in adjacent channels of 1 MHz bandwidth around the frequency of transmission are calculated and compared against limits. The integrated power in the 1 MHz band for the adjacent channels is shown in a table below the plot.

To display the BT InBand Emission display:

1. If you are analyzing a stored data file, recall the data file now. Otherwise, go to the next step.
2. Select the **Displays** button or **Setup > Displays**.
3. In the **Select Displays** dialog, select **BT Inband Emission** in the **Measurements** box.
4. In the **Available displays** box, double-click the **BT Inband Emission** icon or select the icon and click **Add**. The BT Inband Emission icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK** to show the display.
6. Select the **Standard Params** tab and select the appropriate standard.
7. Select the **Measurement Params** tab and turn on averaging, if desired.
8. Select the **Limits** tab and set the desired limits.
9. Select **Replay/Run** to take measurements on the acquired data.
10. If you are analyzing a data file, press the **Replay** button to take measurements on the recalled acquisition data file.

### Elements of the Display

The following image shows the BT Inband Emission display of a Basic Rate signal operating at 2.441 GHz (showing 80 adjacent bands).



Item	Display element	Description
A	PASS / FAIL	Indicates Pass or Fail based on the number of adjacent channels that are below an upper limit. A maximum of 3 adjacent channels can have integrated power higher than an upper limit (Pass); otherwise, Fail is reported.
B	Normal	Displays Average Count if Average is turned on (set to Time Domain or Frequency Domain) from the Measurement Params tab in the Settings control panel.
C	Clear	Resets measurement. Clears all values.
D	Top of graph	The vertical scale is normalized with appropriate power units.
(not shown)	Units	Sets the global Amplitude units for all the views in the analysis window. This will change the amplitude selection in the Units tab of the Amplitude control panel.
E	dB/div	The vertical scale value.
F	Bottom readout	Displays the value indicated by the bottom of graph.
G	Autoscale	Adjusts the vertical and horizontal settings so that the entire trace fits in the graph.
H	Position	Displays the horizontal position of the trace on the graph display.
I	Scale	Adjust the span of the graph in symbols.
J	Plot	Divides the spectrum into different adjacent channels (each of 1 MHz bandwidth) as suggested in the standard document. You can select to show integrated power by checking the <i>Show power levels in graph</i> box in the Prefs tab in the Settings control panel). The integrated power level is shown in blue and the prescribed limits for comparison (set in the Limits tab of the Settings control panel) are shown in white. The region around the frequency of transmission is shown in a different color.
K	Results table	Reports the integrated power results (Channel frequency, Integrated power, and Limits) from the display in a table.

## Bluetooth Analysis Measurement Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The control panel tabs in this section are shared between the displays in Bluetooth Analysis (Setup > Displays). Some tabs are shared by all the displays, some tabs are shared by only a subset of displays. The settings available on some tabs change depending on the selected display.

## Common controls for Bluetooth Analysis displays

Settings tab	Description
<a href="#">Standard Params (see page 645)</a>	Specifies the input signal standard and additional user-settable signal parameters.
<a href="#">Analysis Params (see page 648)</a>	Specifies parameters used by the application to analyze the input signal.
<a href="#">Analysis Time (see page 648)</a>	Specifies parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Symbols or Seconds) for Bluetooth Analysis displays.
<a href="#">Trace (see page 652)</a>	Specifies the trace type (Vectors, Points, and Lines), the number of points per symbol when chosen to view as Vectors or Lines, and to control the view as Freq Dev or IQ.
<a href="#">Prefs (see page 654)</a>	Allows preferences with Radix display and marker readouts.
<a href="#">Scale (see page 651)</a>	Defines the vertical and horizontal axes.
<a href="#">Parameters (see page 655)</a>	Specifies parameters used to analyze the signal.
<a href="#">Freq RBW (see page 657)</a>	Allows you to set Frequency and RBW settings for the BT 20 dB BW display.
<a href="#">Limits (see page 650)</a>	Allows you to define limits for pass/fail comparison with calculated values. The default values are as recommended in the test specification.
<a href="#">Measurement Params (see page 658)</a>	Allows you to set average (Time Domain, Off, or Frequency Domain) and to correct for noise floor.

## Standard Params tab - BT

The Standard Params tab allows you to specify the standard, measurement and reference filters, power class (for some standards), and set standard auto detect.

The following image shows the tab for all of the Bluetooth displays except for the BT InBand Emission display. The Power Class menu only appears when Basic Rate is the selected standard.

Standard Params Analysis Params Analysis Time Limits

Standard: Basic Rate   
☐ Auto Detect

Measurement Filter: None

Reference Filter: None

Power Class: 3

The following image shows the tab for the BT InBand Emission display.

The screenshot shows the 'Standard Params' tab selected. Below the tab headers, there is a 'Standard:' label followed by a dropdown menu currently displaying 'Basic Rate'.

Settings	Description
Standard	Select the appropriate standard: Basic Rate, LE 1M, LE 2M, LE Coded, or Enhanced Data Rate.
Auto Detect Standard	Check box to enable automatic detection of the Bluetooth standard (Basic Rate, Low Energy, or Enhanced Data Rate). A status message will appear indicating which of the three standards is detected and the result will show as Standard selection.
Measurement Filter	Specifies the filter used for measurement. The default filters for the Low Energy and Basic Rate standards are LE-Recommended and BR-Recommended, respectively.
Reference Filter	Specifies the filter used as a reference.
Power Class (only available for Basic Rate)	Select one out of three available power classes. This sets the default limits for comparison (set in the Limits tab of the Settings control panel) for Average and Peak power measurements.

### Power class for the Basic Rate standard

The power class for Basic Rate is the reference receive power range as specified by the standard. It sets the default limits for comparison in the Limits tab of the control panel for Average and Peak power measurements. The power classes are specified as follows:

**Class 1:** max power 20 dBm (100 mW) with mandatory power control.

**Class 2:** max power 6 dBm (4 mW) with optional power control.

**Class 3:** max power 0 dBm (1 mW) with optional power control.

### Recommended measurement and reference filters

The available measurement and reference filters depend on the selected standard. You can use the filters recommended by the standard (shown in following table) or load your own filters by selecting one of the User defined filters from a file.

The measurement filter is applied before the demodulation bit is detected and the ideal reference is calculated.

The reference filter is applied to the internally generated ideal reference signal.



**CAUTION.** Although there may be other filter types listed in the drop down menu, if you select any filter other than that which is recommended, the measurement results may not be accurate.

Standard	Measurement filters	Reference filters
Basic Rate	BR-Recommended	None
LE 1M	LE-Recommended	None
LE 2M	LE-Recommended	None
LE Coded	LE-Recommended	None
Enhanced Data Rate	BR-Recommended	None

### How to select filters

In a signal transmitter/receiver system, the baseband signal might be filtered for bandwidth limiting or for another kind of necessary shaping that needs to be applied. Normally, a filter in the transmitter (Ft) and a filter in the receiver (Fr) are applied.

The Measurement Filter setting in the analyzer corresponds to the baseband filter in the receiver (Fr): This setting tells the analyzer what filter your receiver uses. When the analyzer is set to the same filter used by the receiver, the analyzer sees the signal as your receiver would. The Measurement Filter setting should be the same as the filter used in the receiver under normal operation (as opposed to testing).

## Analysis Params tab - Bluetooth

The Analysis Params tab contains parameters that control the analysis of the input signal. The Test Patterns menu only appears when the Auto Detect Test Pattern is not checked. This tab is available for all displays except for the BT 20dB BW and the BT InBand Emission displays.

Settings	Description
Frequency Error	When the Auto box is checked, the analysis determines the Frequency Error and the measured Frequency Error is displayed. When the Auto box is unchecked, the entered value is used by the analysis as a fixed frequency offset. This is useful when the exact frequency offset of the signal is known.
Measurement BW	Specifies the bandwidth about the center frequency at which measurements are made. Select Manual, Auto, or Link to Span.
Auto Detect Test Pattern	When this box is checked, automatic detection of the test pattern is enabled. When this box is unchecked (Manual mode), automatic detection is disabled and you can select the test pattern and specify the $\Delta f_{avg}$ for the other pattern for ratio computation.
Test Pattern	Allows you to select the test pattern to be analyzed. This choice is available only when Auto Detect Test Pattern is disabled.
Use 8 bits for f4 preamble interval	This option allows you to select only the first 8 bits of f4 for LE Coded. This ensures that the frequency offset computed in the interval f4 is not biased.

## Analysis Time tab - Bluetooth

The Analysis Time tab contains parameters that define how the signal is analyzed in the Bluetooth Analysis displays. This tab is available for all displays except for the BT 20dB BW and the BT InBand Emission displays.



Settings	Description
Analysis Offset	Specifies the location of the first time sample to use in measurements.
Auto	When enabled, causes the instrument to set the Analysis Offset value based on the requirements of the selected display.
Analysis Length	Specifies the length of the analysis period to use in measurements. Length is specified in either symbols or seconds, depending on the Units setting.
Auto	When enabled, causes the instrument to set the Analysis Length value based on the requirements of the selected display.
Available	This is a displayed value, not a setting. It is the Analysis Length (time or symbols) being used by the analyzer. This value may not match the Analysis Length requested (in manual mode).
Time Zero Reference	Specifies the zero point for the analysis time.
Units	Specifies the units of the Analysis Length to either Symbols or Seconds.

### Analysis Offset

Use analysis offset to specify where measurements begin. Be aware that you cannot set the Analysis Offset outside the range of time covered by the current acquisition data. (All time values are relative to the Time Zero Reference.)

You can set the Analysis Length so that the requested analysis period falls partly or entirely outside the current range of acquisition data settings. When the next acquisition is taken, its Acquisition Length will be increased to cover the new Analysis Length, as long as the Sampling controls are set to Auto. If the Sampling parameters are set to manual, or if the instrument is analyzing saved data, the actual analysis length will be constrained by the available data length, but in most cases, measurements are able to be made anyway. The instrument will display a notification when measurement results are computed from less data than requested. Range: 0 to [(end of acquisition) - Analysis Length]. Resolution: 1 effective sample (or symbol).

### Analysis Length

Use the analysis length to specify how long a period of time is analyzed. As you adjust this value, the actual amount of time for Analysis Length, in Symbol or Seconds units, is shown below the control in the "Available" readout. This setting is not available when Auto is checked. Range: minimum value depends on the standard. Resolution: 1 symbol.

### Time Zero Reference

All time values are measured from this point (such as marker position or horizontal position (in Y vs Time displays). Choices are: Acquisition Start or Trigger.


Parameter	Description
Acquisition Start	Time zero starts from the point at which the acquisition begins.
Trigger	Time zero starts from the trigger point.

## Limits tab - Bluetooth


This tab is only available for the BT CF Offset and Drift, BT InBand Emission, and BT Summary displays. It enables you to load an existing limits table, save a limits table, or edit limits values. The content under Measurement Name varies based on the chosen standard and power class.

Some measurements are done only when a specific test pattern is detected. If the specific pattern is not detected, then N/A appears in blue in the BT Summary display because the measurement is not done. If the measurement is done, Pass or Fail is shown in the BT Summary display.

The following image shows the Limits tab for the BT CF Offset and Drift and BT Summary displays.



The following image shows the Limits tab for the BT InBand Emission display.



Settings	Description
Load	Click to load a saved Limits table from a .csv file.
Save	Click to save the current Limits table to a .csv file.

### Edit limits

To directly edit measurement limits in the table, click on the value in the Limit column that you want to change. The following table describes the parameters that are set in the Limits Table.

Settings	Description
On	Click on the cell in the On column next to the measurement to specify whether or not measurements are selected for limit comparison to indicate Pass or Fail. A check mark means the measurement will be taken. An empty box means it will not be taken.
Measurement Name	Specifies the name of the measurement related to the limit. (Not editable.) The content under Measurement Name varies based on the chosen standard and power class.
Limit	Specifies the value of the limit to the related measurement. When the cell is selected, the value is shown along with the units.

## Scale tab - Bluetooth

The Scale tab allows you to change the scale settings that control how the trace appears on the display but does not change control settings such as Measurement Frequency. In effect, these controls operate like pan and zoom controls. The Scale tab values are unique to each display. Also, note that each display uses horizontal and vertical units that are appropriate for that display. There are three versions of the Scale tab for Bluetooth displays.

The following image shows the Scale tab for the BT 20dB BW and BT InBand Emission displays.

The screenshot shows the 'Scale' tab in a software interface. It has two main sections: 'Vertical' and 'Horizontal'. The 'Vertical' section has a 'Scale' field set to '200.00 dB' and a 'Position' field set to '0.00 dBm'. The 'Horizontal' section has a 'Scale' field set to '79.550000 MHz' and a 'Position' field set to '2.441000000 GHz'. There are 'Autoscale' buttons for both sections and a 'Reset Scale' button in the center.

The following image shows the Scale tab for the BT Eye Diagram display.

The screenshot shows the 'Scale' tab for an Eye Diagram. The 'Vertical' section has a 'Scale' field set to '100 GHz' and a 'Position' field set to '0.000 Hz'. The 'Horizontal' section has a 'Scale' field set to '2 Symbol' and a 'Position' field set to '0 Symbol'. Both sections have 'Autoscale' buttons.

The following image shows the Scale tab for the BT Freq Dev vs Time display.

The screenshot shows the 'Scale' tab for a Frequency Deviation vs Time display. The 'Vertical' section has a 'Scale' field set to '100 GHz' and a 'Position' field set to '0.000 Hz'. The 'Horizontal' section has a 'Scale' field set to '0.000 s' and a 'Position' field set to '0.000 s'. There is an 'Auto' checkbox checked and an 'Autoscale' button in the horizontal section.


Settings	Description
Vertical	Controls the vertical position and scale of the trace display.
Scale	Changes the vertical scale of the graph.
Position	Adjusts the reference level away from top of the graph.
Autoscale	Resets the scale of the vertical axis to contain the complete trace.
Horizontal	Controls the horizontal span of the trace display and position of the trace.
Scale	Allows you to, in effect, change the horizontal span.
Position	Allows you to pan a zoomed trace without changing the frequency.
Autoscale	Resets the scale of the horizontal axis to contain the complete trace.
Auto	When Auto is checked, the scale and position values for the Symbols graph are automatically adjusted to maintain the optimal display.
Reset Scale	Resets all settings to their default values.

**NOTE.** The Units used for the horizontal scale for the BT Freq Dev vs Time display can be either Seconds or Symbols. To set the units for the horizontal scale, display the Analysis Time tab. On the tab, select the appropriate units from the Units drop-down list.

## Traces tab - Bluetooth

The Traces tab allows you to set the trace display characteristics of the BT Constellation, BT Eye Diagram, and BT Freq Dev vs Time displays. The selections vary depending on the selected display.

The following image shows the tab for the BT Constellation display.



The following image shows the tab for the BT Eye Diagram display.

Standard Params Analysis Params Analysis Time **Traces** Scale Prefs

Trace: I ☐ Show

Points/Symbol: 8 Trace Type: IQ

The following image shows the tab for the BT Freq Dev vs Time display.

Standard Params Analysis Params Analysis Time Prefs Scale **Traces**

Points/symbol: 4


Content: Points

Setting	Description
Trace	Select the trace to display.
Show	Shows / hides the selected by trace.
Freeze	Halts updates to the selected trace.
Points/Symbol	Select how many points to use between symbols when connecting the dots. Values: 1, 2, 4, 8, 16, and 32.
Content	Select whether to display the trace as vectors (points connected by lines), points (symbols only without lines), or lines (lines drawn between symbols, but no symbols are displayed). The choices available depend on the display.
Trace Type	Select to specify whether the plot is shown as IQ or as Frequency Deviation.
View	Allows you to see the full packet or only the chosen Octet.
Octet # (of xx)	Allows you to view the specified octet. You can also select from the list of the available number of Payload octets in the packet.

### Comparing two traces in the BT Constellation display

You can use the Traces tab to enable the display of a second trace. The second trace is a version of the current acquisition. You can choose to freeze a trace in order to display the current live trace to an earlier version of itself, you can display the trace as a second trace, or you can choose to display both traces frozen in order to compare the trace to itself at different times.

To display a second trace in the BT Constellation display:


1. If more than one display is present, select the BT Constellation display to ensure it is the selected display.
2. Click .
3. Select the Trace tab.
4. Select Trace 2 from the Trace drop-down list.
5. Click the Show check box so that it is checked.
6. Specify the Content as desired.

The Trace 2 lines will appear in blue to help you distinguish Trace 2 from Trace 1.


## Prefs tab - Bluetooth

The Prefs tab enables you to change appearance characteristics of some of the Bluetooth Analysis displays.

The following image shows the Prefs tab for the BT 20dB BW, BT Freq Dev vs Time, BT Eye Diagram, and BT Constellation displays.



The following image shows the Prefs tab for the BT InBand Emission display.



The following image shows the Prefs tab for the BT Symbol Table display.

Standard Params Analysis Params Analysis Time Prefs

Radix: Binary

☒ Show Marker readout in graph (selected marker)

Setting	Description
Show graticule	Shows or hides the graticule.
Show Marker readout in graph (selected marker)	Shows or hides the readout for the selected marker in the graph area.
Radix	Specifies how symbols are displayed in the Symbol Table display and in the Marker readout in the display. There are three choices for Radix: Binary (0,1) and Modulation Symbols (+1,-1). When EDR is detected, the symbol table will always show results in Hex for the PSK region (after guard).
Trace detection	<b>+Peak:</b> Shows the peak power in a bin (of chosen RBW) if there are multiple points to choose from within a bin. <b>Avg (VRMS):</b> Shows the average power in a bin (of chosen RBW) if there are multiple points to choose from within a bin.
Show power levels graph	Displays the calculated power levels in graph in each band.

## Parameters tab - Bluetooth

The Parameters tab enables you to specify several parameters that control signal acquisition in the BT 20dB BW display.

Freq & RBW Parameters Scale Prefs

x dB level: -26.0 dB x dBm level: -26.0 dBm ☐ Max Hold spectral data

Meas Direction: Inwards Meas Range: Lower

Measurement BW: 10.00 MHz ☐ Average results Count: 10

Setting	Description
x dB level	x dB level defines the x dB BW level search threshold.
Meas Direction	Specifies which way the search for the x dB level is done. Selecting <b>Inwards</b> directs the search for x dB from the edges towards maximum power. Selecting <b>Outwards</b> directs the search for x dB from maximum power (x dB ref power) to edges.
x dBm level	x dBm level defines the x dBm BW level search threshold.
x dBm range	Specifies the search direction for the x dBm level. The choices are Lower, Higher, or Both.
Measurement BW	Specifies the frequency range used by the measurement.
Max Hold spectral data	Enables the Max Hold function.
Average results	Enables/disables results average across acquisitions. (This is averaging of the results, not of the trace.)
Count	Specifies the number of results averaged to calculate the Occupied BW. Range: 2 to 10,000.

### x dB level

The x dB level determines the x dB bandwidth. The analyzer analyses the spectrum trace to locate the frequencies at which the level is x dB down from the peak level, calculated over the measurement bandwidth. The frequency difference between the upper and lower crossing thresholds is the x dB BW.

**Range:** -80.0 to -1.0 dB; **Resolution:** 0.1%; Inc/dec small: 0.1%, large: 1%; **Default:** -20 dB

### Meas Direction

The search for the x dB level or x dBm level can be done by selecting Inwards or Outwards in Meas Direction. Selecting Inwards directs the search from the edges towards maximum power. Selecting Outwards directs the search from maximum power (x dB ref power or CF for x dBm) to edges.

### x dBm level

The x dBm level determines the x dBm bandwidth. The analyzer analyzes the spectrum trace to locate the frequencies at which the level is x dBm down from the Center frequency. The frequency range is calculated based on the choice of x dBm Range. The value of x dBm is set to -30 dBm when the BT 20dB BW display is launched from the Bluetooth Standards Presets.

### Meas Range (Higher, Lower, Both)

This determines the search range for the x dB level. The options are as follows:

- **Lower:** Indicates the frequency range from center to the lower frequency at which the power level drops to x dBm.
- **Higher:** Indicates the frequency range from center to the higher frequency at which power level drops to x dBm.
- **Both:** Indicates the frequency between the upper and the lower crossing thresholds at which the power level drops to x dBm.



### Max Hold spectral data

Max Hold displays the maximum value in the acquisition record for each display point. Each new trace display point is compared to the previous maximum value and the greater value is retained for display and subsequent comparisons.

## Freq & RBW tab - Bluetooth

The Freq & RBW tab allows you to specify the bandwidth parameters used for setting measurement bandwidth in the BT 20dB BW display. This determines what acquisition bandwidth the measurement will request.

The screenshot shows the 'Freq & RBW' tab with the following settings:

- Meas Freq: 2.44100 GHz
- RBW: 30 kHz (Auto checked)
- Step: 1.0000 MHz (Auto checked)
- VBW: (unchecked)

Setting	Description
Meas Freq	Specifies the measurement frequency.
RBW	Select Auto or Manual. Adjusts the resolution bandwidth for the entire measurement. This setting is independent of the Spectrum display's RBW setting.
Step	Sets the increment/decrement size for the adjustment of the center frequency. If Auto is enabled, the analyzer will adjust the step size as required.
VBW	Adjusts the video bandwidth.

## Measurement Params tab - Bluetooth

The Measurement Params tab is only available for the BT InBand Emission display. It allows you to select the average domain.

The screenshot shows the 'Bluetooth InBand Emission Settings' dialog box. On the left is a sidebar with a 'Standard Presets' button. The main area has a tabbed interface with 'Standard Params', 'Freq & RBW', 'Measurement Params' (selected), 'Scale', 'Prefs', and 'Limits'. In the 'Measurement Params' tab, there are two settings: 'Average:' with a dropdown menu set to 'Frequency Domain' and 'Number:' with a text input field containing '10'.

Setting	Description
Average	Specify the average domain (Time Domain, Frequency Domain) or set Average to Off. If a domain is selected, then you can also specify the number.
Number	Specify the number value associated with the Average setting.

## Overview

Audio Analysis (Option SVNL-SVPC or SVFL-SVPC) measures basic time- and frequency-domain parameters of analog audio signals modulated on a carrier (AM, FM and PM modulation) or unmodulated (non-carrier) audio signals (Direct).

For modulated signals, the measurement analysis first demodulates the signal to provide the *Audio signal* waveform. Direct input signals bypass the demodulation step. For FM and PM demodulation, the carrier frequency error is estimated during demodulation.

The Audio signal waveform excursions are then measured to determine the Peak and RMS waveform parameters. Next, the analysis detects the highest-amplitude frequency component within the audio bandwidth, and makes a high-accuracy frequency measurement of the frequency component. This value is called the *Audio Frequency*.

A spectral analysis of the Audio signal waveform is performed to determine the presence and level of harmonically- and/or non-harmonically-related narrowband spurs and wideband noise. The Audio signal, harmonic and non-harmonic spurs, and noise level data are combined to produce signal summary parameters including SINAD, Modulation Distortion, Signal-to-Noise, Total Harmonic Distortion, and Total Non-Harmonic Distortion.

Controls are provided to allow the user to select audio filters of Low Pass, High Pass, FM De-emphasis, or Standard-defined response, as well as completely user-definable filter response. Filtering can be applied as needed to modify the audio spectrum result before measurement to remove unwanted spurs or noise.

Flexible control parameters are provided to allow setting the Audio Bandwidth for analysis, the Resolution Bandwidth (RBW) and RBW filter type of the spectral analysis, and number and level qualifications for Harmonic and Non-harmonic spur detection. Multiple-spectrum averaging can be enabled to provide a smoothed spectrum for results with less variability than single-spectrum results.

The Audio Spectrum display shows the frequency spectrum waveform with detected harmonic and non-harmonic components identified by markers, and a corresponding table of frequency and level values for the spur components. The markers and table provide easy visualization of the significant spurs and their relation to the fundamental Audio frequency signal.

## Audio Spectrum Display


The Audio Spectrum display shows audio modulation characteristics. You can choose to show just the spectrum of the audio signal or show the audio spectrum of the signal and the results of distortion measurements. The Audio Spectrum display can show a table listing the frequency of a Harmonic Distortion (HD) and Non-Harmonic Distortion (NHD) and its level. The Spectrum graph indicates these harmonics and non-harmonics with special markers.

To display the Audio Spectrum display:

1. Recall an appropriate acquisition data file.
2. Press the **Displays** button or select **Setup > Displays**. This shows the **Select Displays** dialog box.

3. From the **Measurements** box, select **Audio Analysis**.
4. Double-click the **Audio Spectrum** icon in the **Available Displays** box. This adds the Audio Spectrum icon to the **Selected displays** box.
5. Click the **OK** button. This shows the Audio Spectrum display.
6. Press the **Replay** button to take measurements on the recalled acquisition data file.

### Elements of the Audio Spectrum Display



Item	Display element	Description
1	Vertical position	Sets the top of graph value.
2	dB/div	Sets the vertical scale value. The maximum value is 20.00 dB/division.
3	Audio BW	Specifies the measurement bandwidth of the Audio Spectrum display, which in turn can influence the acquisition bandwidth.
4	Table	Displays a table that shows the distortion measurement results and displays indicators on the graph that highlight the location of the harmonics on the trace.
5	Bottom of graph readout	Displays the bottom of graph value.
6	Non-harmonic threshold indicator	Displays the threshold for detecting non-harmonic components.
7	Analysis results	Display of the audio analysis results.

## Audio Spectrum Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The measurement settings for the Audio Spectrum display are shown in the following table.


Settings tab	Description
<a href="#">Params1 Tab (see page 663)</a>	Specifies signal type, Audio Bandwidth, RBW, RBW filter, and Ref Audio Frequency.
<a href="#">Params2 Tab (see page 666)</a>	Specifies Harmonics and Non-Harmonics measurement parameters.
<a href="#">Audio Filters Tab (see page 666)</a>	Specifies the audio filter characteristics.
<a href="#">Scale Tab (see page 193)</a>	Sets vertical and horizontal scale and position parameters.
<a href="#">Prefs Tab (see page 672)</a>	Specifies vertical units, and whether or not some features are displayed in the graph.

## Audio Summary Display

To display the Audio Summary display:

1. Press the **Displays** button or select **Setup > Displays**. This shows the **Select Displays** dialog box.
2. From the **Measurements** box, select **Audio Analysis**.
3. Double-click the **Audio Summary** icon in the **Available Displays** box. This adds the Audio Summary icon to the **Selected displays** box.
4. Click the **OK** button. This shows the Audio Summary display.

### The Audio Summary Display



### Audio Summary Displayed Measurements

Table 10: Audio Summary Measurements

Signal type	Item	Description
AM, FM, PM	Carrier Power	Average power of the carrier signal with modulation removed.
Direct	Signal Power	Average power of the input signal
FM, PM	Carr Freq Err	Carrier frequency error

Table 10: Audio Summary Measurements (cont.)

Signal type	Item	Description
AM, FM, PM. Direct	Audio Freq	Fundamental audio frequency
	+Peak	+Peak modulation excursion (where the modulation excursion readout depends on the signal type) <sup>1</sup>
	-Peak	-Peak modulation excursion (where the modulation excursion readout depends on the signal type) <sup>1</sup>
	Peak-Peak/2	Half peak-peak modulation excursion (where the modulation excursion readout depends on the signal type) <sup>1</sup>
	RMS	RMS modulation excursion (where the modulation excursion readout depends on the signal type) <sup>1</sup>
	SINAD	Signal to noise and distortion
	Mod Distor	Modulation distortion
	S/N	An estimate of the Signal level to Noise (only) level, with the HD and NHD components removed
	THD	Total harmonic distortion
	TNHD	Total non-harmonic distortion
	Ref	Ref is the RMS modulation value stored when the <b>Capture Reference</b> button is pressed. (Displayed only when Hum & Noise is enabled.)
	Diff	Diff is the difference between the current RMS mod value and the Ref value captured previously. (Displayed only when Hum & Noise is enabled.)

<sup>1</sup> For AM signal types, modulation excursion is "% Modulation Depth". For FM signal types, modulation excursion is "Frequency Deviation". For PM signal types, modulation excursion is "Phase Deviation". For Direct, there is no modulation excursion, it is actually "signal excursion".

## Audio Summary Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The measurement settings for the Audio Summary display are shown in the following table.

Settings tab	Description
<a href="#">Params1 Tab (see page 663)</a>	Specifies signal type, Audio Bandwidth, RBW, RBW filter, and Ref Audio Frequency.
<a href="#">Params2 Tab (see page 666)</a>	Specifies Harmonics and Non-Harmonics measurement parameters.
<a href="#">Audio Filters Tab (see page 666)</a>	Specifies the audio filter characteristics.
<a href="#">Hum Noise Tab (see page 671)</a>	Specifies whether or not Hum & Noise is measured and enables the capture of a signal to be used as a reference of the Hum & Noise measurement.

## Audio Analysis Measurement Settings


The control panel tabs in this section are shared by the displays in the Audio Analysis folder (Setup > Displays).

### Common controls for Audio Analysis displays

Settings tab	Description
<a href="#">Params1 Tab (see page 663)</a>	Specifies characteristics about the audio signal and how measurements are made.
<a href="#">Params2 Tab (see page 666)</a>	Specifies parameters that control how measurements are made on harmonics.
<a href="#">Audio Filters Tab (see page 666)</a>	Specifies characteristics of filters applied to the signal before measurements are taken.
<a href="#">Scale Tab (see page 193)</a>	Sets vertical and horizontal scale and position parameters.
<a href="#">Prefs Tab for Audio Analysis (see page 672)</a>	The Prefs tab enables you to change appearance characteristics of the Audio Analysis displays.

## Params1 Tab

The Params1 tab is used to specify characteristics of the audio signal to be measured and how the signal will be measured.



Params1 Params2 Audio Filters Hum & Noise

Signal Type:

Audio BW:  RBW:  ☒ Auto

Ref Audio Freq:  ☒ Auto RBW Filter:

Params1 tab for AM signal types

Setting	Description
Signal Type	Specifies the type of signal to be analyzed. The available choices are AM, FM, PM, and Direct.
Audio BW	Specifies the bandwidth used for audio analysis.
Ref Audio Freq	A measured value when Auto is selected. If you want to specify the reference audio frequency, uncheck Auto and enter a value manually. If Ref Audio Freq is set manually, be aware that the automated detection is still performed, but it is limited to a frequency range of $\pm 1\%$ of the Audio BW centered around the manually specified value.
Carrier Freq Error / Carrier Freq Offset	(FM and PM only) A measured value, when Auto is selected. If Auto is unchecked, you can specify the Carrier Frequency Offset.
RBW	Displays the Resolution Bandwidth for Audio measurements. This value is automatically set by default to 1/500 of the measurement bandwidth. To manually specify the RBW, uncheck Auto. The minimum RBW value is limited to the larger of 1 Hz or AudioBW/10000. The maximum is limited to AudioBW/100.
RBW Filter	Specifies the windowing method used for the transform.

### Setting Frequency for Direct Signal Types

Direct (unmodulated) signal analysis is only possible with the instrument Frequency control set to 0 Hz. You will receive a warning to set Frequency to 0 Hz when Direct signal type is selected, if you haven't already done so. Modulated signal types may be selected with Frequency set to 0 Hz, but results are not meaningful in that case. For modulated signals, Frequency should always be set to a value  $\geq$  Audio Bandwidth to avoid self-interference of the signal due to spectral folding.

### Setting Audio Bandwidth

For AM, FM and PM, the Audio Bandwidth control sets not only the demodulated signal bandwidth, but also determines the pre-demodulation bandwidth. Set it to a value at least half the pre-demodulation signal bandwidth, as in this equation:

$$\text{Audio BW} \geq \text{Signal Bandwidth} / 2$$

**NOTE.** When performing audio analysis, you should allow the Audio BW control to automatically set the acquisition bandwidth, rather than manually adjusting the Acq BW control on the Sampling Parameters tab of the Acquire control panel. The audio measurement will cause the Acq BW setting to be  $\geq$  Audio BW (Direct) or  $\geq 2 \times$  Audio BW (AM, FM, PM).

For Direct signals, set Audio Bandwidth large enough to include any significant harmonics/non-harmonics or other signal component of interest. For example, to measure up to the 10th harmonic of a signal with a 5 kHz fundamental component, set Audio Bandwidth to  $10 \times 5 \text{ kHz} = 50 \text{ kHz}$ .

For modulated signals, Audio Bandwidth must be set wide enough to include all significant signal modulation components in addition to the desired audio analysis bandwidth. For AM this is similar to Direct. For example, to measure up to the 10th harmonic of an AM signal with 3 kHz fundamental component, set Audio Bandwidth to  $10 \times 3 \text{ kHz} = 30 \text{ kHz}$ . This ensures that the bandwidth of the data provided by the system to the measurement will be at least of 60 kHz ( $2 \times 30 \text{ kHz}$ ) which is sufficient for this signal and analysis requirement.



FM and PM are more complex. For FM, the analysis bandwidth needs to be at least twice as wide as the the sum of peak Frequency Deviation and the Fundamental Frequency (Carsons rule). This is a parallel condition along with setting Audio Bandwidth large enough for the maximum audio bandwidth to analyze. Therefore, for FM, Audio Bandwidth should be:

$$\text{AudioBW (FM)} = \text{MAX}(\text{MaxAudioAnalysisFreq}, \text{FreqDeviation} + \text{FundamentalFreq})$$

where MaxAudioAnalysisFreq is the highest audio frequency desired in the analysis. For example, for an FM signal with fundamental signal of 5 kHz and peak frequency deviation (one-sided) of 10 kHz, Acquisition Bandwidth should be at least  $(2 \times (10\text{k} + 5\text{k})) = 30\text{ kHz}$ , or an Audio Bandwidth of 15 kHz. Also if the analysis should extend to the 8th harmonic, then the Audio Bandwidth needs to be at least  $8 \times 5\text{ kHz} = 40\text{ kHz}$ . So Audio Bandwidth should be set to 40 kHz. Using the equation:

$$\text{AudioBW(FM)} = \text{MAX}(8 \times 5\text{kHz}, (10 + 5)\text{kHz}) = \text{MAX}(40\text{ kHz}, 15\text{kHz}) = 40\text{ kHz}$$

The formula for PM is:

$$\text{AudioBW (PM)} = \text{MAX}(\text{MaxAudioAnalysisFreq}, \text{PMFreqDeviation} + \text{FundamentalFreq})$$

where

$$\text{PMFreqDeviation} = \text{PMPhaseDeviationInRadians} \times \text{FundamentalFreq}$$

### RBW Filter Shape

Select Kaiser in most cases for best measurement performance. Select Flattop only if you want to use standard markers to measure signal amplitude with highest accuracy.

## Params2 Tab

The Params2 tab is used to specify how the signal harmonics are measured and to control spectrum averaging.

The screenshot shows the Params2 tab with the following settings:

- No. of Harmonics:** 12
- No. of Non-Harmonics:** 12
- Averaging:** ☐ Averaging: 10
- Non-Harmonics only:**
  - Ignore region:** 0.0 Hz
  - Threshold:** -65.0 dBc
  - Excursion:** 6.0 dB

Setting	Description
No. of Harmonics	Specifies the number of harmonics to detect. The detected harmonics are tagged with a number on the spectrum trace. The available range is 1–20.
No. of Non-Harmonics	Specifies the number of non-harmonics to detect. The detected non-harmonics are tagged with a number on the spectrum trace. The available range is 0–20.
Averaging	Specifies the number of averages used to compute the results. Range: 2–100.
Ignore region	Specifies the region about the signal frequency where the instrument will ignore non-harmonics.
Non-Harmonic Threshold	Specifies the level which a spectrum peak must exceed to be declared a non-harmonic signal component.
Non-Harmonic Excursion	Specifies the difference in level between a spectrum peak and the average noise level that must be exceeded for the peak to be declared a non-harmonic signal component.

### About Averaging In Audio Analysis Displays

Analysis averaging is implemented using a “block” method. This means that the entire record required for multiple spectrum computations is acquired and analyzed within one analysis cycle. The result of each analysis update is a complete, independent result from a set of N spectrums averaged together, where N is the Averaging control value.. Since each update is a fully averaged result, no partially averaged results are output before a final result is available, so each output is fully valid. However, with large Averaging values, acquisition record sizes and measurement times may become large, so care should be taken to select the minimum amount of averaging needed.

## Audio Filters Tab

The Audio Filters tab is used to specify filters to be applied to the acquired audio signal before measurements are taken. You can select from pre-defined filters or use a filter you define in a text file. You can also specify the de-emphasis time constant applied to the audio signal and the telecom weighting filters used to measure noise.

The screenshot shows the 'Audio Filters' tab with the following settings:

- Pre-defined Filters** (selected)
- LPF** (checked): 300 Hz
- HPF** (unchecked): 50 Hz
- De-emphasis** (unchecked): 25 µsec
- Standard** (unchecked): CCITT
- File** (button)

## Pre-defined Filters

You can specify low-pass filter (LPF) and high-pass filter (HPF) settings, a de-emphasis time constant and/or a telecom weighting filter to match the response of your receiver. Alternatively, you can create a text file to specify the frequency response points.

To use pre-defined filters:

1. Select the **Pre-defined Filters** option button.
2. Select the LPF, HPF, De-emphasis and Standard check boxes as appropriate.
3. Select the desired filter parameter from the drop-down list for each of the enabled filters or select User from the list if you wish to use a custom value. For LPF and HPF, the listed frequencies represent the 3dB cutoff point of the filter.
4. If you select **User** from the drop-down list, enter a value in the text entry box that appears.

To disable all filtering:

1. Select the **Pre-defined Filters** option button.
2. Deselect all four filter check boxes.

**Table 11: Predefined audio filters**

Filter type	Available settings
LPF (Low Pass Filter) (5th-order Butterworth response)	300 Hz
	3 kHz
	15 kHz
	30 kHz
	80 kHz
	300 kHz
	User <sup>1</sup>
HPF (High Pass Filter) (5th-order Butterworth response)	20 Hz
	50 Hz
	300 Hz
	400 Hz
	User <sup>1</sup>

Table 11: Predefined audio filters (cont.)

Filter type	Available settings
De-emphasis (FM only)	25 $\mu$ s
	50 $\mu$ s
	75 $\mu$ s
	750 $\mu$ s
	User. Range: 25 $\mu$ s to 10 ms
Standard	CCITT
	C-message

<sup>1</sup> User-entered values are restricted to maximum of 0.9 \* Audio BW, and will automatically adjust downward to meet this limit (if required) when AudioBW is decreased.

**Standard.** Use this setting to specify the telecom weighting filter. The characteristics of these filters are described in ITU-T Recommendation O.41, Psophometer for Use on Telephone-type Circuits.

### Using Custom Audio Filters

If you want to use audio filters that have a different response shape than the pre-defined filters, you can create a custom audio filter using a text or CSV file to specify the desired filter frequency response.

To use a custom audio filter:

1. Verify that Audio Spectrum or Audio Summary is the selected display.
2. Click the Settings icon or select **Setup > Settings**.
3. Select the **Audio Filters** tab.
4. Click the **File** button.
5. Click the ... button and navigate to the location of the custom audio filter file you wish to use. Select the file you want to use and click Open.
6. Acquire a new trace or replay a saved file to see the effect of the custom filter.

**Creating a Custom Audio Filter.** A custom audio filter file is either a plain text file or a CSV format file. The file contains frequency (in Hz) and amplitude (in dB) value pairs which specify the filter frequency response shape. Each pair must be on a separate line. The filter response between the points is interpolated using a cubic spline fit.

The following table shows the first few lines of a custom audio filter text file.

0,	-100
16.66,	-85
50,	-63
100,	-41
200,	-21
300,	-10.6

400,	-6.3
500,	-3.6
600,	-2
700,	-0.9
800,	0
...	...

Format and rule-checking on custom audio filter files is performed as follows:

- The maximum number of frequency and amplitude pairs is 1000.
- Column 1 (frequency values in Hertz).
  - Non-negative values only (zero is allowed).
  - Strictly increasing order of frequencies (frequency value on each line > frequency value on previous line).
  - There is no upper limit on the frequency value.
- Column 2 (amplitude values in dB units, where gain is a positive value and attenuation is a negative value).
  - Values are restricted to the range -200 to +20 dB.

## Scale Tab


The Scale tab allows you to change the vertical and horizontal scale settings. Changing the scale settings changes how the trace appears on the display but does not change acquisition control settings. In effect, these controls operate like pan and zoom controls.



Setting	Description
Vertical	
Scale	Changes the range shown between the top and bottom of the graph.
Position	Adjusts the level shown at the top of the graph for linear units or the top of the graph for log units (for example, dBm).
Autoscale	Resets the Position so that the highest trace points are in the graph. For linear units (Volts, Watts), the Autoscale also adjusts Scale.
Horizontal	
Left	Changes the frequency shown at the left side of the graph.
Right	Changes the frequency shown at the right side of the graph.
Autoscale	Resets the Left and Right settings to show the entire trace.
Log	Sets the graph horizontal axis to a logarithmic scale.
Reset Scale	Resets the Vertical and Horizontal settings to their default values.

## Hum & Noise Tab

Hum & Noise (available only when the Audio Summary display is the active display) is useful for comparing residual power or modulation if the Ref value is captured when the Signal is On (Direct) or modulated (AM/FM/PM). When the signal is turned off (Direct) or modulation turned off (AM/FM/PM), Diff indicates how much residual Hum and Noise are still present in the measurement value.



To display Hum & Noise measurement:

1. Select **Setup > Displays**.
2. In the Select Displays window, select the **Audio Analysis** folder.
3. Double-click the **Audio Summary** icon so that it appears in the **Selected displays** box.
4. Click **OK**
5. With the Audio Summary display selected, select **Setup > Settings**.
6. Select the **Hum & Noise** tab. Click on the **Measure Hum & Noise** checkbox so that it is checked.  
The Hum & Noise values appear at the bottom list of measurements in the Audio Summary display.
7. Acquire an appropriate signal.
8. While the analyzer is analyzing a signal you want to use as a reference, click the **Capture reference now** button to save a reference value.

The Hum & Noise measurement compares the value of a specific signal quantity captured by the **Capture reference now** button with the current measured value of that quantity. For Direct signal types (set on the Params1 tab), the Signal Level is captured and compared. The Diff measurement is:

$$\text{SignalLevel}(\text{current}) - \text{SignalLevel}(\text{Ref})$$

in dB.


For AM, FM, and PM signal types, the RMS modulation value (related to Modulation Depth, Frequency Deviation or Phase Deviation) is captured and compared. The Diff measurement is:

$$20 \times \log_{10} (\text{RMS}(\text{current})/\text{RMS}(\text{Ref}))$$

in dB.

# Prefs Tab

The Prefs tab enables you to change appearance characteristics of the Audio Spectrum display.




Setting	Description
Units:	Specifies the vertical scale units. The units available depend on the signal type selected.
Show graticule	Select to display or hide the graticule.
Trace points	Sets the number of trace points used for marker measurements and for results export.
Show Marker readout in graph (selected marker)	Shows or hides the readout for the selected marker in the graph area.
Show Non-Harm Threshold	Shows or hides the non-harmonic threshold line.



## Audio Demodulation

**Main menu bar:** Setup > Audio

**Favorites toolbar:** 


Selecting **Audio** displays the Audio demodulation control panel.

This panel is only available when SignalVu-PC is connected to an RSA306, RSA306B, RSA500A series, or RSA600A series instrument.

---

**NOTE.** *Audio Demodulation is available only in real-time acquisition mode (not swept acquisition), and the Trigger mode must be set to Free Run (not Triggered).*

---



Setting	Description
Demodulation	Sets both the demodulation type and bandwidth.
Run	Starts and stops the live audio demodulation process.
Volume	Adjusts the volume of the demodulated audio signal played out through the PC speakers.
Mute	Inhibits the audio from playing out through the PC speakers
Stream to File	These controls allow you to stream the demodulated audio file directly to disc. The audio file is saved as a .WAV file.
File:	Displays the current location where the audio file is saved.
Browse:	Use the Browse... button to navigate to a location to save the audio file.
Activate	This enables the Stream to File function. When checked, anytime the Run button is pressed, the audio stream-to-file begins.



## Overview

The displays in General Purpose (GP) Digital Modulation (Displays > Measurements > GP Digital Modulation) are:

- Constellation
- Demod I & Q vs Time
- EVM vs Time
- Eye Diagram
- Frequency Deviation vs Time
- Magnitude Error vs Time
- Phase Error vs Time
- Signal Quality
- Symbol Table
- Trellis Diagram

The General Purpose Digital Modulation Analysis (Option 21) provides vector signal analyzer functionality. A wide variety of modulation types are supported, allowing you to view your signals in Constellation, Eye and Trellis diagrams, measure the quality of the modulation, display time-domain waveforms for demodulated I & Q signals, EVM, Phase Error, Magnitude Error, and more.

### Modulation Measurements

---

**NOTE.** *A maximum of approximately 163,800 samples can be analyzed by the General Purpose Digital Modulation measurements (the actual value varies with modulation type).*

---

Measurement	Description
EVM	The normalized RMS value of the error vector between the measured signal and the ideal reference signal over the analysis length. The EVM is generally measured on symbol or chip instants and can be reported in units of percent or dB. EVM is usually measured after best-fit estimates of the frequency error and a fixed phase offset have been removed.
Phase Error	The RMS phase difference between the measured signal and the ideal reference signal.
Magnitude Error	The RMS magnitude difference between the measured signal and the ideal reference signal.
IQ Origin Offset	The magnitude of the DC offset of the signal measured at the symbol times. It indicates the magnitude of the carrier feed-through signal.
Gain Imbalance	The gain difference between the I and Q channels in the signal generation path. Constellations with gain imbalance show a pattern with a width that is different from height.
Rho p	The normalized correlated power of the measured signal and the ideal reference signal. Like EVM, Rho is a measure of modulation quality. The value of Rho is less than 1 in all practical cases and is equal to 1 for a perfect signal measured in a perfect receiver.
Frequency Error	The frequency difference between the measured carrier frequency of the signal and the user-selected center frequency of the analyzer.
Quadrature Error	The orthogonal error between the I and Q channels. The error shows the phase difference between I and Q channels away from the ideal 90 degrees expected from the perfect I/Q modulation. Constellations with quadrature error will show some leakage of I into Q and vice versa.


## Constellation Display

The Constellation Display shows a digitally-modulated signal in constellation form.

To show the Constellation Display:

1. Recall an appropriate acquisition data file.
2. Select the **Displays** button or select **Setup > Displays**. This shows the **Select Displays** dialog box.
3. From the **Measurements** box, select **GP Digital Modulation**.
4. Double-click the **Constellation** icon in the **Available Displays** box. This adds the Constellation icon to the **Selected displays** box.
5. Click the **OK** button. This shows the Constellation display.
6. Press the **Replay** button to take measurements on the recalled acquisition data file.

## Elements of the Constellation Display



Item	Display element	Description
1	Check mark indicator	The check mark indicator in the upper, left-hand corner of the display shows when the Constellation display is the optimized display.  <b>NOTE.</b> When Best for multiple windows is selected in the Amplitude control panel's RF & IF Optimization control, none of the measurement displays shows a checkmark, as there is not a single optimized measurement.
2	Marker Readout	Located to the left of the constellation plot or below it, depending on the size of the window. If markers are enabled, the marker readout shows the time, mag, phase, symbol marker and symbol value of the point with the selected marker.
3	EVM Readouts	The EVM readouts are located below the Constellation plot. The readout shows EVM Peak (%) and location, RMS (%).
4	Plot	Constellation graph.

[Changing Constellation Settings \(see page 677\)](#)

## Constellation Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the Constellation view are shown in the following table.

**NOTE.** You might be able to save time configuring the Constellation display by pressing the *Standard Settings* button from the *Settings* control panel. This allows you to select a preset optimized for a standard from the *Select Standard* dialog box. See [Standard Settings Button. \(see page 702\)](#)

Settings tab	Description
<a href="#">Modulation Params (see page 703)</a>	Specifies the type of modulation, symbol rate, and filters to be used in demodulating the input signal.
<a href="#">Freq &amp; BW (see page 708)</a>	Sets values for frequency error/offset, measurement bandwidth, and frequency deviation (not every control is present for every modulation type).
<a href="#">Equalizer Tab (see page 709)</a>	Enable the Equalizer and adjust its parameters.
<a href="#">Advanced Params (see page 711)</a>	Specifies additional parameters that are less frequently used.
<a href="#">Find (see page 714)</a>	Used to set parameters for finding a burst within the data record and for entering a Synch word.
<a href="#">Analysis Time (see page 715)</a>	Contains parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Seconds or Symbols) for the GP Digital Modulation displays.
<a href="#">Trace (see page 716)</a>	Allows you to set the trace display characteristics.
<a href="#">Prefs (see page 719)</a>	Enables you to set characteristics of the measurement display.


## Demod I & Q vs Time Display

The Demod I & Q vs Time displays demodulated I and Q vs. Time. You can choose to display I only, Q only, or both.

### Elements of the Display

To show the Demod I & Q vs Time display:

1. Recall an appropriate acquisition data file.
2. Select the **Displays** button or select **Setup > Displays**. This shows the **Select Displays** dialog box.
3. From the **Measurements** box, select **GP Digital Modulation**.
4. Double-click the **Demod I&Q vs Time** icon in the **Available Displays** box. This adds the Demod I&Q vs Time icon to the **Selected displays** box.
5. Click the **OK** button. This shows the Demod I&Q vs Time display.
6. Press the **Replay** button to take measurements on the recalled acquisition data file.



Item	Element	Description
1	Check mark indicator	The check mark indicator in the upper, left-hand corner of the display shows when the Demod I & Q vs Time display is the optimized display.  <b>NOTE.</b> When Best for multiple windows is selected in the Amplitude control panel's RF & IF Optimization control, none of the measurement displays shows a checkmark, as there is not a single optimized measurement.
2	Top of Graph	Sets the I and Q amplitude value indicated at the top of the graph. Changing the top value affects the bottom of graph readout. Also, note that the top of graph setting interacts with the internal vertical scale setting (which is not user settable) such that the range between the top and bottom of the graph increases or decreases automatically.
3	Position	Specifies the I and Q amplitude value shown at the center of the graph display.
4	Bottom Readout	Displays the I and Q amplitude value shown at the bottom of graph.
5	Autoscale	Adjusts the vertical and horizontal settings to provide the best display.
6	Position	Specifies the horizontal position of the trace on the graph display.
7	Scale	Adjusts the span of the graph. By decreasing the scale (time per division), the graph essentially becomes a window that you can move over the acquisition record by adjusting the offset.
8	Freq Error	This readout can show Freq Error or Freq Offset. When it displays Freq Error, it shows the difference between the instrument Frequency setting and the measured value of the signal's carrier frequency. When it displays Freq Offset, it shows the frequency offset specified on the <a href="#">Settings &gt; Freq &amp; BW</a> (see page 708) tab. If Freq Error is displayed, it also indicates that the Carrier frequency detection setting is Auto. If Freq Offset is displayed, it indicates that the Carrier frequency detection setting is manual.

[Changing Demod I&Q Settings. \(see page 680\)](#)

## Demod I & Q vs Time Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the Demod I & Q vs Time display are shown in the following table.

---

**NOTE.** You might be able to save time configuring the Demod I & Q display by pressing the Standard Settings button from the Settings control panel. This allows you to select a preset optimized for a standard from the Select Standard dialog box. See [Standard Settings Button. \(see page 702\)](#)

---

Settings tab	Description
<a href="#">Modulation Params (see page 703)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Freq &amp; BW (see page 708)</a>	Specifies settings for frequency error, measurement BW and Frequency Deviation. Each of these settings is set internally when set to Auto. Alternatively, you can specify values appropriate for specific measurement needs.
<a href="#">Equalizer Tab (see page 709)</a>	Enable the Equalizer and adjust its parameters.
<a href="#">Advanced Params (see page 711)</a>	Specifies additional parameters.
<a href="#">Find (see page 714)</a>	Used to set parameters for finding a burst within the data record and for entering a Synch word.
<a href="#">Analysis Time (see page 715)</a>	Contains parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Seconds or Symbols) for the GP Digital Modulation displays.
<a href="#">Trace (see page 716)</a>	Allows you to set the trace display characteristics.
<a href="#">Scale (see page 718)</a>	Specifies the horizontal and vertical scale settings.
<a href="#">Prefs (see page 719)</a>	Enables you to set characteristics of the measurement display.

## EVM vs Time Display

The EVM vs. Time Display shows the Error Vector Magnitude plotted over Time.

---

**NOTE.** A maximum of approximately 80,000 samples can be analyzed by the General Purpose Digital Modulation measurements (the actual value varies with modulation type).


---

To show an EVM vs. Time display:



1. Recall an appropriate acquisition data file.
2. Press the **Displays** button or select **Setup > Displays**. This shows the **Select Displays** dialog box.
3. From the **Measurements** box, select **GP Digital Modulation**.
4. Double-click the **EVM vs. Time** icon in the **Available Displays** box. This adds the EVM vs. Time icon to the **Selected displays** box.
5. Click the **OK** button. This displays the EVM vs. Time view.
6. Press the **Replay** button to take measurements on the recalled acquisition data file.

### Elements of the EVM vs Time Display



Item	Display element	Description
1	Top of graph adjustment	Use the knob to adjust the vertical scale.
2	Position	Adjusts the vertical position.
3	Autoscale	Adjusts the Horizontal and Vertical scale to show the entire trace.
4	Peak and RMS value readout	Shows the maximum result, the time it occurred, and the RMS of the result over the entire analysis length.
5	Scale	Sets the length of time shown in the graph.

[Changing the EVM vs Time Display Settings \(see page 681\)](#)

## EVM vs Time Settings

**Main menu bar: Setup > Settings**

### Favorites toolbar:

The settings for the EVM vs. Time display are shown in the following table.

**NOTE.** You might be able to save time configuring the EVM vs. Time display by pressing the *Standard Settings* button from the *Settings* control panel. This allows you to select a preset optimized for a standard from the *Select Standard* dialog box. See [Standard Settings Button. \(see page 702\)](#)

Settings tab	Description
<a href="#">Modulation Params (see page 703)</a>	Specifies the type of modulation used in the input signal and other parameters that controls the demodulation of the input signal.
<a href="#">Freq &amp; BW (see page 708)</a>	Specifies settings for frequency error, measurement BW and Frequency Deviation. Each of these settings is set internally when set to Auto. Alternatively, you can specify values appropriate for specific measurement needs.
<a href="#">Equalizer Tab (see page 709)</a>	Enable the Equalizer and adjust its parameters.
<a href="#">Advanced Params (see page 711)</a>	Specifies Freq Offset, Magnitude normalization parameters, and enables swapping I and Q.
<a href="#">Find (see page 714)</a>	The Find tab is used to set parameters for finding bursts within the data record.
<a href="#">Analysis Time (see page 715)</a>	The Analysis Time tab contains parameters that define how the signal is analyzed in the general purpose digital modulation displays.
<a href="#">Trace (see page 716)</a>	Specifies the display characteristics of the displayed trace.
<a href="#">Scale (see page 718)</a>	Specifies the horizontal and vertical scale settings.
<a href="#">Prefs (see page 719)</a>	Specifies whether certain display elements are visible.


## Eye Diagram Display

The Eye Diagram Display shows a digitally modulated signal overlapped on itself to reveal variations in the signal.

To show an Eye Diagram display:

1. Recall an appropriate acquisition data file.
2. Press the **Displays** button or select **Setup > Displays**. This shows the **Select Displays** dialog box.
3. From the **Measurements** box, select **GP Digital Modulation**.
4. Double-click the **Eye Diagram** icon in the **Available Displays** box. This adds the Eye Diagram icon to the **Selected displays** box.
5. Click the **OK** button. This displays the Eye Diagram view.
6. Press the **Replay** button to take measurements on the recalled acquisition data file.

## Elements of the Display



Item	Element	Description
1	Check mark indicator	The check mark indicator in the upper, left-hand corner of the display shows when the Frequency Deviation vs Time display is the optimized display.  <b>NOTE.</b> When Best for multiple windows is selected in the Amplitude control panel's RF & IF Optimization control, none of the measurement displays shows a checkmark, as there is not a single optimized measurement.
2	Top of Graph	The vertical scale is normalized with no units (except for nFSK and C4FM modulation types where the vertical units are Hz).
3	Position	Specifies the value shown at the center of the graph display.
4	Bottom Readout	Displays the value indicated by the bottom of graph.
5	Autoscale	Adjusts the vertical and horizontal settings to provide the best display.
6	Position	Displays the horizontal position of the trace on the graph display.
7	Scale	Adjusts the span of the graph in symbols.
8	Freq Error	Displays the difference between the maximum and minimum measured values of the signal frequency during the Measurement Time. The displayed frequency error is followed by either <b>Auto</b> or <b>Manual</b> . This indicates the selected carrier frequency detection method (see Settings > Freq & BW).

[Changing Eye Diagram Settings \(see page 684\)](#)

## Eye Diagram Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the Eye Diagram display are shown in the following table.

**NOTE.** You might be able to save time configuring the Eye Diagram display by pressing the *Standard Settings* button from the *Settings* control panel. This allows you to select a preset optimized for a standard from the *Select Standard* dialog box. See [Standard Settings Button. \(see page 702\)](#)

Settings tab	Description
<a href="#">Modulation Params (see page 703)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Freq &amp; BW (see page 708)</a>	Specifies settings for frequency error, measurement BW and Frequency Deviation. Each of these settings is set internally when set to Auto. Alternatively, you can specify values appropriate for specific measurement needs.
<a href="#">Advanced Params (see page 711)</a>	Specifies additional parameters.
<a href="#">Find (see page 714)</a>	Used to set parameters for finding a burst within the data record and for entering a Synch word.
<a href="#">Analysis Time (see page 715)</a>	Contains parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Seconds or Symbols) for the GP Digital Modulation displays.
<a href="#">Trace (see page 716)</a>	Allows you to set the trace display characteristics.
<a href="#">Scale (see page 718)</a>	Specifies the horizontal and vertical scale settings.
<a href="#">Prefs (see page 719)</a>	Enables you to set characteristics of the measurement display.

## Frequency Deviation vs Time Display

To show a Frequency Deviation vs Time display:

1. Recall an appropriate acquisition data file.
2. Press the **Displays** button or select **Setup > Displays**. This shows the **Select Displays** dialog box.
3. From the **Measurements** box, select **Frequency Deviation vs Time**.
4. Double-click the **Frequency Deviation vs Time** icon in the **Available Displays** box. This adds the Frequency Deviation vs Time icon to the **Selected displays** box.

- Click the **OK** button. This displays the Frequency Deviation vs Time view.
- Press the **Replay** button to take measurements on the recalled acquisition data file.

## Elements of the Display



Item	Element	Description
1	Check mark indicator	The check mark indicator in the upper, left-hand corner of the display shows when the Frequency Deviation vs Time display is the optimized display.  <b>NOTE.</b> When Best for multiple windows is selected in the Amplitude control panel's RF & IF Optimization control, none of the measurement displays shows a checkmark, as there is not a single optimized measurement.
2	Top of Graph	Sets the frequency deviation value indicated at the top of the graph. Changing the top value affects the bottom of graph readout. Also, note that the top of graph setting interacts with the internal vertical scale setting (which is not user settable) such that the range between the top and bottom of the graph increases or decreases automatically.
3	Position	Specifies the frequency deviation value shown at the center of the graph display.
4	Bottom Readout	Displays the value of the frequency deviation value shown at the bottom of graph.
5	Autoscale	Adjusts the vertical and horizontal settings to provide the best display.
6	Position	Specifies the horizontal position of the trace on the graph display.
7	Scale	Adjusts the span of the graph. By decreasing the scale (time per division), the graph essentially becomes a window that you can move over the acquisition record by adjusting the offset.
8	Freq Error	Displays the difference between the maximum and minimum measured values of the signal frequency during the Measurement Time. The displayed frequency error is followed by either <b>Auto</b> or <b>Manual</b> . This indicates the selected carrier frequency detection method (see Settings > Freq & BW).

[Changing Frequency Deviation vs Time Settings \(see page 686\)](#)

## Frequency Deviation vs Time Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The Setup settings for Frequency Deviation vs. Time are shown in the following table.

**NOTE.** You might be able to save time configuring the Frequency vs. Time display by pressing the Standard Settings button from the Settings control panel. This allows you to select a preset optimized for a standard from the Select Standard dialog box. See [Standard Settings Button. \(see page 702\)](#)

Settings tab	Description
<a href="#">Modulation Params (see page 703)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Freq &amp; BW (see page 708)</a>	Specifies settings for frequency error, measurement BW and Frequency Deviation. Each of these settings is set internally when set to Auto. Alternatively, you can specify values appropriate for specific measurement needs.
<a href="#">Equalizer Tab (see page 709)</a>	Enable the Equalizer and adjust its parameters.
<a href="#">Advanced Params (see page 711)</a>	Specifies additional parameters.
<a href="#">Find (see page 714)</a>	Used to set parameters for finding a burst within the data record and for entering a Synch word.
<a href="#">Analysis Time (see page 715)</a>	Contains parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Seconds or Symbols) for the GP Digital Modulation displays.
<a href="#">Trace (see page 716)</a>	Allows you to set the trace display characteristics.
<a href="#">Scale (see page 718)</a>	Specifies the horizontal and vertical scale settings.
<a href="#">Prefs (see page 719)</a>	Enables you to set characteristics of the measurement display.

## Magnitude Error vs Time Display

The Magnitude Error displays the magnitude of the symbol error. The amplitude appears on the vertical axis while time is plotted along the horizontal axis.

---


**NOTE.** *A maximum of approximately 80,000 samples can be analyzed by the General Purpose Digital Modulation measurements (the actual value varies with modulation type).*

---

To display Magnitude Error vs. Time:

1. Recall an appropriate acquisition data file.
2. Select the **Displays** button or **Setup > Displays**. This displays the Select Displays dialog box.
3. Select **GP Digital Modulation** in the **Measurements** box.
4. Double-click the **Mag Error vs. Time** icon or select the icon and click **Add**. The icon will appear in the **Selected displays** box and will no longer appear under Available displays.
5. Click **OK**.
6. Press the **Replay** button to take measurements on the recalled acquisition data file.

## Elements of the Display



Item	Display element	Description
1	Top of graph adjustment	Use the knob to adjust the value of the vertical scale.
2	Position	Adjusts the level shown at the bottom of the display.
3	Autoscale button	Adjusts the vertical and horizontal settings to provide the best display.
4	Horizontal Position	Adjusts the horizontal position of the signal. Units can be either Symbols or Seconds (Settings > Analysis Time tab > Units).
5	Peak and RMS value readout	Displays the Peak value of the magnitude error, the RMS value of the magnitude error, and the time at which it occurs within the acquisition. Units can be either Symbols or Seconds (Settings > Analysis Time tab > Units).
6	Horizontal Scale	Sets the time spanned by the graph. Units can be either Symbols or Seconds (Settings > Analysis Time tab > Units).
7	Freq Error	Freq Error is the difference between the Center Frequency and the measured frequency of the signal being tested. This readout will be Freq Offset if the Freq Offset parameter on the Settings > <a href="#">Advanced Params (see page 711)</a> tab is set to Manual.

[Changing Magnitude Error vs Time Display Settings \(see page 688\)](#)

## Magnitude Error vs Time Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 



The Setup settings for Magnitude Errors vs. Time are shown in the following table.

**NOTE.** You might be able to save time configuring the Magnitude vs. Time display by pressing the Standard Settings button from the Settings control panel. This allows you to select a preset optimized for a standard from the Select Standard dialog box. See [Standard Settings Button. \(see page 702\)](#)

Settings tab	Description
<a href="#">Modulation Params (see page 703)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Freq &amp; BW (see page 708)</a>	Specifies settings for frequency error, measurement BW and Frequency Deviation. Each of these settings is set internally when set to Auto. Alternatively, you can specify values appropriate for specific measurement needs.
<a href="#">Equalizer Tab (see page 709)</a>	Enable the Equalizer and adjust its parameters.
<a href="#">Advanced Params (see page 711)</a>	Specifies additional parameters.
<a href="#">Find (see page 714)</a>	Used to set parameters for finding a burst within the data record and for entering a Synch word.
<a href="#">Analysis Time (see page 715)</a>	Contains parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Seconds or Symbols) for the GP Digital Modulation displays.
<a href="#">Trace (see page 716)</a>	Allows you to set the trace display characteristics.
<a href="#">Scale (see page 718)</a>	Specifies the horizontal and vertical scale settings.
<a href="#">Prefs (see page 719)</a>	Enables you to set characteristics of the measurement display.

## Phase Error vs Time Display

The Phase Error vs. Time display shows the phase angle of the symbol error over time. The phase is plotted along the vertical axis while time is plotted along the horizontal axis.


**NOTE.** A maximum of approximately 80,000 samples can be analyzed by the General Purpose Digital Modulation measurements (the actual value varies with modulation type).

To show the Phase Error display:

1. Recall an appropriate acquisition data file.
2. Press the **Displays** button or select **Setup > Displays**.
3. In the **Select Displays** dialog, select **GP Digital Modulation** in the **Measurements** box.
4. In the **Available displays** box, double-click the **Phase Error** icon or select the icon and click **Add**. The Phase Error icon will appear in the **Selected displays** box and will no longer appear under Available displays.

- 5. Click **OK** to display the Phase Error.
- 6. Press the **Replay** button to take measurements on the recalled acquisition data file.

Elements of the Phase Error vs Time Display




Item	Display element	Description
1	Freq Error	Freq Error is the difference between the Center Frequency and the measured frequency of the signal being tested. This readout will be Freq Offset if the Freq Offset parameter on the Settings > <a href="#">Advanced Params (see page 711)</a> tab is set to Manual.
2	Top of graph adjustment	Adjusts the phase angle shown at the top of the graph.
3	Position	Adjusts the vertical offset.
4	Autoscale	Adjusts the vertical and horizontal settings so that the entire trace fits in the graph.
5	Offset	Adjusts the horizontal offset.
6	Peak and RMS readouts	Displays the Peak value of the phase error and the time at which it occurred. Also displays the RMS value over the analysis length.
7	Scale	Sets the time spanned by the graph.

[Changing the Phase Error vs Time Display Settings \(see page 690\)](#)

Phase Error vs. Time Settings

Main menu bar: Setup > Settings

Favorites toolbar: 

The settings for the Phase Error vs. Time display are shown in the following table.

---


**NOTE.** You might be able to save time configuring the Phase Error vs. Time display by pressing the Standard Settings button from the Settings control panel. This allows you to select a preset optimized for a standard from the Select Standard dialog box. See [Standard Settings Button. \(see page 702\)](#)

---

Settings tab	Description
<a href="#">Modulation Params (see page 703)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Freq &amp; BW (see page 708)</a>	Specifies settings for frequency error, measurement BW and Frequency Deviation. Each of these settings is set internally when set to Auto. Alternatively, you can specify values appropriate for specific measurement needs.
<a href="#">Equalizer Tab (see page 709)</a>	Enable the Equalizer and adjust its parameters.
<a href="#">Advanced Params (see page 711)</a>	Specifies additional parameters.
<a href="#">Find (see page 714)</a>	Used to set parameters for finding a burst within the data record and for entering a Synch word.
<a href="#">Analysis Time (see page 715)</a>	Contains parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Seconds or Symbols) for the GP Digital Modulation displays.
<a href="#">Trace (see page 716)</a>	Allows you to set the trace display characteristics.
<a href="#">Scale (see page 718)</a>	Specifies the horizontal and vertical scale settings.
<a href="#">Prefs (see page 719)</a>	Enables you to set characteristics of the measurement display.


## Signal Quality Display

The Signal Quality display shows several measurements of signal quality. The measurements displayed depend on the modulation type. There is a set of measurements displayed for all modulation types except nFSK and C4FM. There is a second set of measurements displayed for nFSK and C4FM modulation types.




	<i>RMS</i>	<i>Peak</i>	<i>Location</i>
EVM:	47.893 %	97.092 %	4.14 kSym
	-6.395 dB	-0.256 dB	
Phase Error:	25.803 °	46.376 °	4.26 kSym
Mag Error:	18.943 %	54.693 %	848.00 Sym
<hr/>			
MER (RMS):	6.395 dB	Rho:	0.783798
IQ Origin Offset:	-48.637 dB	Frequency Error:	-542.2 kHz
Gain Imbalance:	-0.019 dB	Quadrature Error:	0.211 °

Signal Quality display for all modulation types except nFSK, C4FM, OQPSK, and SOQPSK




	<i>RMS</i>	<i>Peak</i>	<i>Location</i>
EVM:	0.213 %	0.562 %	161.50 Sym
	-53.426 dB	-45.012 dB	
Offset EVM:	0.197 %	0.398 %	65.00 Sym
	-54.106 dB	-47.996 dB	
Phase Error:	0.131 °	0.422 °	161.50 Sym
Mag Error:	0.139 %	0.380 %	160.00 Sym
<hr/>			
MER (RMS):	53.426 dB	Rho:	0.999991
IQ Origin Offset:	-70.413 dB	Frequency Error:	-401.5 Hz
Gain Imbalance:	-0.014 dB	Quadrature Error:	0.012 °

Signal Quality display for OQPSK and SOQPSK modulation types



Signal Quality display for nFSK modulation type



Signal Quality display for C4FM modulation type

## Elements of the Display

### Measurements for all modulation types except nFSK, C4FM, OQPSK and SOQPSK

Measurement	Description
EVM	The normalized RMS value of the error vector between the measured signal and the ideal reference signal over the analysis length. The EVM is generally measured on symbol or chip instants and is reported in units of percent and dB. EVM is usually measured after best-fit estimates of the frequency error and a fixed phase offset have been removed. These estimates are made over the analysis length. Displays RMS and Peak values with location of Peak value.
Phase Error	The RMS phase difference between the measured signal and the ideal reference signal. Displays RMS and Peak values with location of Peak value.
Mag Error	The RMS magnitude difference between the measured signal and the reference signal magnitude. Displays RMS and Peak values with location of Peak value.
MER (RMS)	The MER is defined as the ratio of I/Q signal power to I/Q noise power; the result is indicated in dB.
IQ Origin Offset	The magnitude of the DC offset of the signal measured at the symbol times. It indicates the magnitude of the carrier feed-through signal.
Frequency Error	The frequency difference between the measured carrier frequency of the signal and the user-selected center frequency of the instrument.
Gain Imbalance	The gain difference between the I and Q channels in the signal generation path. Constellations with gain imbalance show a pattern with a width that is different from height.
Quadrature Error	The orthogonal error between the I and Q channels. The error shows the phase difference between I and Q channels away from the ideal 90 degrees expected from the perfect I/Q modulation. Not valid for BPSK modulation type.
Rho	The normalized correlated power of the measured signal and the ideal reference signal. Like EVM, Rho is a measure of modulation quality. The value of Rho is less than 1 in all practical cases and is equal to 1 for a perfect signal measured in a perfect receiver.

**Measurements for QPSK and SQPSK modulation types**

Measurement	Description
EVM	The normalized RMS value of the error vector between the measured signal and the ideal reference signal over the analysis length. The EVM is generally measured on symbol or chip instants and is reported in units of percent and dB. EVM is usually measured after best-fit estimates of the frequency error and a fixed phase offset have been removed. These estimates are made over the analysis length. Displays RMS and Peak values with location of Peak value.
Offset EVM	Offset EVM is like EVM except for a difference in the time alignment of the I and Q samples. For EVM, I and Q samples are collected at the same time, for every symbol decision point (twice the symbol rate for offset modulations). For Offset EVM, the I and Q symbol decision points are time-aligned before collecting the I and Q samples. In this case, one I and one Q sample is collected for each symbol (half as many samples as the same number of symbols for (non-offset) EVM).
Phase Error	The RMS phase difference between the measured signal and the ideal reference signal. Displays RMS and Peak values with location of Peak value.
Mag Error	The RMS magnitude difference between the measured signal and the reference signal magnitude. Displays RMS and Peak values with location of Peak value.
MER (RMS)	The MER is defined as the ratio of I/Q signal power to I/Q noise power; the result is indicated in dB.
IQ Origin Offset	The magnitude of the DC offset of the signal measured at the symbol times. It indicates the magnitude of the carrier feed-through signal.
Frequency Error	The frequency difference between the measured carrier frequency of the signal and the user-selected center frequency of the instrument.
Gain Imbalance	The gain difference between the I and Q channels in the signal generation path. Constellations with gain imbalance show a pattern with a width that is different from height.
Quadrature Error	The orthogonal error between the I and Q channels. The error shows the phase difference between I and Q channels away from the ideal 90 degrees expected from the perfect I/Q modulation. Not valid for BPSK modulation type.
Rho	The normalized correlated power of the measured signal and the ideal reference signal. Like EVM, Rho is a measure of modulation quality. The value of Rho is less than 1 in all practical cases and is equal to 1 for a perfect signal measured in a perfect receiver.

**Measurements for nFSK modulation types**

Measurement	Description
Peak FSK err	Peak value of the frequency deviation error at the symbol point.
RMS FSK Err	RMS value of the frequency deviation error at the symbol point.
Peak Mag Err	The Peak magnitude difference between the measured signal and the reference signal magnitude.
RMS Mag Err	The RMS magnitude difference between the measured signal and the reference signal magnitude.
Freq Error	The frequency difference between the measured carrier frequency of the signal and the user-selected center frequency of the instrument.
Freq Deviation	Frequency distance from the center frequency at the symbol point.
Symbol Rate Error	This compares the user-entered symbol rate to the instrument calculated symbol rate of the analyzed signal.
Symbol Rate	When in Auto-symbol rate, the instrument calculates the symbol rate of the signal and the instrument calculates the error between the user entered value and the instrument calculated value.

**Measurements for C4FM modulation type**

Measurement	Description
RMS Error Magnitude	RMS value of the frequency deviation error at the symbol point.
Carrier Frequency Error	Frequency difference between averaged signal frequency and the center frequency.
Deviation	Frequency distance from the center frequency at the symbol point.
Length	Number of symbols in the analysis area.

[Changing the Signal Quality Display Settings \(see page 696\)](#)

## Signal Quality Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The Setup settings for Signal Quality are accessible only when the Signal Quality display is selected.

---

**NOTE.** You might be able to save time configuring the Signal Quality display by pressing the Standard Settings button from the Settings control panel. This allows you to select a preset optimized for a standard from the Select Standard dialog box. See [Standard Settings Button. \(see page 702\)](#)

---




Settings tab	Description
<a href="#">Modulation Params (see page 703)</a>	The Modulation tab specifies the type of modulation used for the input signal and other parameters.
<a href="#">Freq &amp; BW (see page 708)</a>	Specifies settings for frequency error, measurement BW and Frequency Deviation. Each of these settings is set internally when set to Auto. Alternatively, you can specify values appropriate for specific measurement needs.
<a href="#">Equalizer Tab (see page 709)</a>	Enable the Equalizer and adjust its parameters.
<a href="#">Advanced Params (see page 711)</a>	The Advanced Params tab specifies frequency offset, magnitude normalization method and allows you to swap the I and Q signals.
<a href="#">Find (see page 714)</a>	Find tab is used to set parameters for finding bursts within the data record.
<a href="#">Analysis Time (see page 715)</a>	The Analysis Time tab contains parameters that define the portion of the acquisition record that is used for analysis.
<a href="#">Prefs (see page 719)</a>	The Prefs tab enables you to set characteristics of the measurement display.

## Symbol Table Display

The Symbol Table Display is like the Constellation Display except that a text table is used to display data bits at a symbol rather than a graph. The Synch Word characters, if used, are in bold font.

To display the Symbol Table:

1. Recall an appropriate acquisition data file.
2. Select the **Displays** button or select **Setup > Displays**. This displays the **Select Displays** dialog box.
3. From the **Measurements** box, select **GP Digital Modulation**.
4. Double-click the **Symbol Table** icon in the **Available Displays** box. This adds the Symbol Table icon to the **Selected displays** box.
5. Click the **OK** button. This displays the Symbol Table view.
6. Press the **Replay** button to take measurements on the recalled acquisition data file.



0	10	01	11	10	00	10	01	10	11	00	00	11	01	11	01	11
16	01	10	00	01	10	11	10	00	01	10	10	00	00	01	10	11
32	10	00	01	11	01	10	10	00	11	00	00	10	00	11	10	01
48	11	10	01	01	11	11	11	01	01	00	11	00	00	11	01	11
64	01	01	11	11	10	11	10	01	10	10	10	00	10	01	11	
80	10	10	00	11	11	01	01	01	00	00	00	10	10	10	01	
96	10	11	11	01	11	01	11	10	01	00	00	00	00	11	00	01
112	01	01	10	00	11	01	01	01	10	11	01	01	10	11	11	01
128	01	00	11	00	11	10	00	01	01	01	01	10	01	11	01	10
144	01	10	00	10	11	10	00	01	10	11	10	10	01	01	00	10
160	11	10	10	11	00	00	11	10	00	00	11	00	10	10	01	11
176	10	01	10	11	11	00	10	10	11	10	11	01	01	00	00	10
192	00	11	11	00	00	00	11	00	00	10	10	00	11	00	10	00
208	11	10	01	11	10	10	01	11	11	00	01	10	11	11	10	11
224	10	00	10	10	00	10	10	10	11	01	10	10	10	11	00	01
240	11	00	11	00	01	01	01	11	11	10	10	10	10	01	00	10

Marker: M1      Symbol: 0  
Time: 0.00 Sym      Value: 10

## Using Markers

Markers are indicators in the display that you can position on a trace to measure values such as frequency, power, and time. A Marker always displays its position and, if the Delta readout is enabled, will display the difference between its position and that of the Marker Reference. Within the Symbol Table, colored cells indicate the location of markers. The selected Marker is highlighted with a light green background. All other markers are highlighted with a light gray background. In the Symbol Table, the marker readout below the table shows the marker location in time, symbol numbers and symbol value.

[Changing the Symbol Table Display Settings \(see page 698\)](#)

## Symbol Table Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The Setup settings for the Symbol Table view are shown in the following table.

---

**NOTE.** You might be able to save time configuring the Symbol Table display by pressing the *Standard Settings* button from the *Settings* control panel. This allows you to select a preset optimized for a standard from the *Select Standard* dialog box. See [Standard Settings Button. \(see page 702\)](#)

---


Settings tab	Description
<a href="#">Modulation Params (see page 703)</a>	The Modulation tab specifies the type of modulation used for the input signal and other parameters.
<a href="#">Freq &amp; BW (see page 708)</a>	Specifies settings for frequency error, measurement BW and Frequency Deviation. Each of these settings is set internally when set to Auto. Alternatively, you can specify values appropriate for specific measurement needs.
<a href="#">Equalizer Tab (see page 709)</a>	Enable the Equalizer and adjust its parameters.
<a href="#">Advanced Params (see page 711)</a>	The Advanced Params tab specifies additional parameters.
<a href="#">Find (see page 714)</a>	Find tab is used to set parameters for finding bursts within the data record.
<a href="#">Analysis Time (see page 715)</a>	The Analysis Time tab contains parameters that define the portion of the acquisition record that is used for analysis.
<a href="#">Prefs (see page 719)</a>	The Prefs tab enables you to set characteristics of the measurement display.

## Trellis Diagram Display

To show an Trellis Diagram display:

1. Recall an appropriate acquisition data file.
2. Press the **Displays** button or select **Setup > Displays**. This shows the **Select Displays** dialog box.
3. From the **Measurements** box, select **GP Digital Modulation**.
4. Double-click the **Trellis Diagram** icon in the **Available Displays** box. This adds the Trellis Diagram icon to the **Selected displays** box.
5. Click the **OK** button. This displays the Trellis Diagram view.
6. Press the **Replay** button to take measurements on the recalled acquisition data file.

## Elements of the Display



Item	Element	Description
1	Check mark indicator	The check mark indicator in the upper, left-hand corner of the display shows when the Frequency Deviation vs Time display is the optimized display.  <b>NOTE.</b> When Best for multiple windows is selected in the Amplitude control panel's RF & IF Optimization control, none of the measurement displays shows a checkmark, as there is not a single optimized measurement.
2	Top of Graph	Sets the phase value indicated at the top of the graph. Changing the top value affects the bottom of graph readout. Also, note that the top of graph setting interacts with the internal vertical scale setting (which is not user settable) such that the range between the top and bottom of the graph increases or decreases automatically.
3	Position	Specifies the phase value shown at the center of the graph display.
4	Bottom Readout	Displays the value of the phase value shown at the bottom of graph.
5	Autoscale	Adjusts the vertical and horizontal settings to provide the best display.
6	Position	Displays the horizontal position of the trace on the graph display.
7	Scale	Adjusts the span of the graph in symbols.
8	Freq Error	Displays the difference between the maximum and minimum measured values of the signal frequency during the Measurement Time. The displayed frequency error is followed by either <b>Auto</b> or <b>Manual</b> . This indicates the selected carrier frequency detection method (see Settings > Freq & BW).

[Changing the Trellis Diagram Settings \(see page 701\)](#)

## Trellis Diagram Settings

**Main menu bar:** Setup > Settings

**Favorites toolbar:** 

The settings for the Trellis Diagram display are shown in the following table.

---

**NOTE.** You might be able to save time configuring the Trellis Diagram display by pressing the *Standard Settings* button from the Settings control panel. This allows you to select a preset optimized for a standard from the *Select Standard* dialog box. See [Standard Settings Button. \(see page 702\)](#)

---

Settings tab	Description
<a href="#">Modulation Params (see page 703)</a>	Specifies the type of modulation used for the input signal and other parameters.
<a href="#">Freq &amp; BW (see page 708)</a>	Specifies settings for frequency error, measurement BW and Frequency Deviation. Each of these settings is set internally when set to Auto. Alternatively, you can specify values appropriate for specific measurement needs.
<a href="#">Equalizer Tab (see page 709)</a>	Enable the Equalizer and adjust its parameters.
<a href="#">Advanced Params (see page 711)</a>	Specifies additional parameters.
<a href="#">Find (see page 714)</a>	Used to set parameters for finding a burst within the data record and for entering a Synch word.
<a href="#">Analysis Time (see page 715)</a>	Contains parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Seconds or Symbols) for the GP Digital Modulation displays.
<a href="#">Trace (see page 716)</a>	Allows you to set the trace display characteristics.
<a href="#">Scale (see page 718)</a>	Specifies the horizontal and vertical scale settings.
<a href="#">Prefs (see page 719)</a>	Enables you to set characteristics of the measurement display.

## GP Digital Modulation Shared Measurement Settings

The displays in the GP Digital Modulation folder (Setup > Displays) are each a different format for presenting the results of a single underlying analysis. For this reason, all controls that affect the analysis parameters are shared by all the displays in the GP Digital Modulation folder.

Changing a setting on one tab changes that setting for all the GP Digital Modulation displays. For example, if you change the Modulation Type for the Constellation Display, it also changes the Modulation type setting for the Signal Quality display. There are some controls that affect only the way an individual display presents its results, such as graph scaling.

**Common controls for GP digital modulation displays**

Settings tab	Description
<a href="#">Modulation Params (see page 703)</a>	Specifies the type of modulation, symbol rate, and filters to be used in demodulating the input signal.
<a href="#">Freq &amp; BW (see page 708)</a>	Sets values for frequency error/offset, measurement bandwidth, and frequency deviation (not every control is present for every modulation type).
<a href="#">Equalizer Tab (see page 709)</a>	Enable the Equalizer and adjust its parameters.
<a href="#">Advanced Params (see page 711)</a>	Specifies additional parameters that are less frequently used.
<a href="#">Find (see page 714)</a>	Used to set parameters for finding a burst within the data record and for entering a Synch word.
<a href="#">Analysis Time (see page 715)</a>	Contains parameters that define the portion of the acquisition record that is used for analysis. Also allows you to specify the Units (Seconds or Symbols) for the GP Digital Modulation displays.
<a href="#">Trace (see page 716)</a>	Allows you to set the trace display characteristics.
<a href="#">Prefs (see page 719)</a>	Enables you to set characteristics of the measurement display.

## Standard Settings Button

On every GP Digital Modulation control panel there is a button labeled **Standard Settings**. This button is used to recall settings optimized for analyzing the selected standard. See the following table for a list of the standards for which standard settings are available. Choosing a standard from the dialog box changes only settings for GP Digital Modulation displays.

All of the presets in the Standard Settings Dialog make the following settings:

- Analysis Length: Auto
- Points per Symbol: 4
- Data Differential: No
- Burst Mode: Off
- Burst Detection Threshold: -10 dBc

## Parameter values set by presets in the standard settings dialog

Standard	Modulation	Symbol Rate	Meas. Filter	Reference Filter	Filter Parameter	Other
802.15.4	OQPSK	1e6	None	Half sine	NA	
SBPSK-MIL	SBPSK	2.4e3	None	SBPSK-MIL	NA	
SOQPSK-MIL	SOQPSK	2.4e3	None	SOQPSK-MIL	NA	<sup>1</sup>
CPM-MIL	CPM	19.2e3	None	None	NA	
SOQPSK-ARTM Tier 1	SOQPSK	2.5e6	None	SOQPSK-ARTM	NA	<sup>1</sup>
Project25 Phase 1	C4FM	4.8e3	C4FM-P25	RC	0.2	
CDMA2000–Base	QPSK	1.2288e6	IS-95 TXE-Q_MEA	IS-95 REF	NA	
W-CDMA	QPSK	3.84e6	RRC	RC	0.22	

<sup>1</sup> Center Symbol Position, Half Shift Removed

## Modulation Params Tab

### Menu bar: Setup > Settings > Modulation Params

The Modulation Params tab specifies the type of modulation on the input signal and other parameters that control the demodulation of the input signal.

The screenshot shows the 'Modulation Params' tab selected in a menu bar. Below the menu bar are several sub-tabs: 'Freq & BW', 'Advanced Params', 'Find', 'Analysis Time', 'Trace', 'Scale', and 'Prefs'. The 'Modulation Params' sub-tab is active, displaying the following settings:

- Modulation type: QPSK (dropdown menu)
- Measurement Filter: Root raised cosine (dropdown menu)
- Symbol Rate: 40 kHz (text input field)
- Reference Filter: Raised cosine (dropdown menu)
- Filter Parameter: 0.300 (text input field)

Parameter	Description
Modulation type	Specifies the type of modulation on the input signal.
Symbol Rate	Specifies the symbol rate in Hertz.
Measurement Filter	Specifies the filter used for measurements.
Reference Filter	Specifies the filter used as a reference.
Filter Parameter	Enter a value used for defining the Reference Filter. (Not present for some filter types)
Modulation index	(Present only for CPM modulation type)

### Modulation Type

The modulation types that can be demodulated and analyzed are:

Modulation type	Description
QPSK	Quadrature Phase Shift Keying
8PSK	8-Phase Shift Keying
D8PSK	Differential Eight Phase Shift Keying
D16PSK	Differential Sixteen Phase Shift Keying
PI/2DBPSK	Pi/2 Differential Binary Phase Shift Keying
DQPSK	Differential Quadrature Phase Shift Keying
PI/4DQPSK	Pi/4 Differential Quadrature Phase Shift Keying
BPSK	Binary Phase Shift Keying
OQPSK	Offset Quadrature Phase Shift Keying
16QAM	16-state Quadrature Amplitude Modulation
32QAM	32-state Quadrature Amplitude Modulation
64QAM	64-state Quadrature Amplitude Modulation
128QAM	128-state Quadrature Amplitude Modulation
256QAM	256-state Quadrature Amplitude Modulation
MSK	Minimum Shift Keying
2FSK	2-Frequency Shift Keying
4FSK	4-Frequency Shift Keying
8FSK	8-Frequency Shift Keying
16FSK	16-Frequency Shift Keying
CPM	Continuous Phase Modulation
SOQPSK	Shaped Offset Quadrature Phase Shift Keying
SBPSK	Shaped Binary Phase Shift Keying
C4FM	Constant Envelope 4-Level Frequency Modulation
32APSK	32-symbol Amplitude Phase Shift Keying

### Symbol Rate

Specifies the symbol rate for demodulating digitally modulated signals. The symbol rate and the bit rate are related as follows:

$$(\text{Symbol rate}) = (\text{Bit rate}) / (\text{Number of bits per symbol})$$

For example, the number of bits per symbol is 3 for 8PSK.

### Measurement and Reference Filters

The available measurement and reference filters depend on the selected modulation type. If a particular filter is not practical for a selected modulation type, it is not presented as an available filter. To determine which filters are available, make certain that your desired modulation type is selected. See the following table.



Modulation type	Measurement filters	Reference filters
BPSK	None	None
PI/2DBPSK	RootRaisedCosine	RaisedCosine
8PSK	RaisedCosine	Gaussian
D8PSK	Gaussian	User
DQPSK	User	Rectangular (freq)
PI/4DQPSK	Rectangular (freq)	IS-95REF
16QAM	IS-95TX_MEA	
32QAM	IS-95TXEQ_MEA	
64QAM		
128QAM		
256QAM		
QPSK		
16APSK		
32APSK		
MSK	None	None
	Root Raised Cosine	Gaussian
	RaisedCosine	User
	Gaussian	
	User	
	Rectangular (freq)	
OQPSK	None	None
	RootRaisedCosine	Half sine
	User	RaisedCosine
	IS-95TX_MEA	User
	IS-95TXEQ_MEA	IS-95REF
HDQPSK	HDQPSK-P25	None
		RaisedCosine
		Gaussian
		User
		Rectangular (freq)
SOQPSK	None	SOQPSK-MIL
	User	SOQPSK-ARTM
		User
CPM	None	None
	User	User

Modulation type	Measurement filters	Reference filters
2FSK	None	None
4FSK	Gaussian	Gaussian
8FSK	RootRaisedCosine	RaisedCosine
16FSK	RaisedCosine	User
	Rectangular (freq)	
	User	
C4FM	C4FM-P25	RaisedCosine
		User
SBPSK	None	SBPSK-MIL
	User	User

The measurement filter is applied before the demodulation bit is detected and the ideal reference is calculated.

The reference filter is applied to the internally generated ideal reference signal before the EVM is calculated.

### Measurement BW

The measurement BW (reported on the Settings > Freq & BW tab) is computed based on the Modulation Type, the Symbol Rate (SR), the Reference Filter type, and the Filter Parameter (alpha). The following table shows the formulas used, where SR= symbol rate, and  $\alpha$  = filter parameter.

Modulation type	Measurement filter	Measurement bandwidth
QPSK, 8PSK, D8PSK, DQPSK, PI/4DQPSK, BPSK, PI/2DBPSK, QAM16-256, APSK	Raised Cosine	$SR * (1 + \alpha)$
	None / Rectangular	$SR * 16$
	All others	$SR * 2$
D16PSK	Raised Cosine	$SR * (1.5 + \alpha)$
	None / Rectangular	$SR * 16$
	All others	$SR * 2.5$
OQPSK	Raised Cosine	$SR * 2$
	Half Sine	$SR * 12$
	None / Rectangular	$SR * 16$
	All others	$SR * 2$
GMSK	Gaussian	$SR * 12 * \alpha$
	None / Rectangular	$SR * 4$
	All others	$SR * 4$
GFSK, FSKn, C4FM	All	$SR * 8$

## How to Select Filters

In a signal transmitter/receiver system, the baseband signal might be filtered for bandwidth limiting or for another kind of necessary shaping that needs to be applied. Normally, a filter in the transmitter ( $F_t$ ) and a filter in the receiver ( $F_r$ ) are applied.

The Measurement Filter setting in the analyzer corresponds to the baseband filter in the receiver ( $F_r$ ): This setting tells the analyzer what filter your receiver uses. When the analyzer is set to the same filter used by the receiver, the analyzer sees the signal as your receiver would. The Measurement Filter setting should be the same as the filter used in the receiver under normal operation (as opposed to testing).

The Reference Filter setting in the analyzer corresponds to the baseband filter in the transmitter-receiver combination ( $F_r * F_t$ ). The baseband filter for the transmitter-receiver combination is often referred to as the *System Filter*. This filter is called the reference filter because it is used to recreate a reference signal that is compared to the received signal. This recreated reference signal is the *ideal signal* with  $F_r * F_t$  applied; differences between this *ideal signal* and the received signal enables the determination of signal quality, such as EVM measurements.

The following is an example of a hypothetical signal that is transmitted into a vector signal analyzer for analysis:

Assume that a signal is transmitted using a baseband filter ( $F_t$ ). It then travels through a transmission medium (air/cable/etc) where it may be affected by the communication channel ( $F_c$ ). The signal is received and filtered by the receiver's filter ( $F_r$ ). At this point, the signal has passed through  $F_t$  and  $F_r$ , and in addition, the communication channel might have affected it (so:  $F_t * F_r * F_c$ ). This double-filtered signal is demodulated as it was received to determine the symbols/bits in it. The obtained bits are used to regenerate a baseband ideal signal that can be compared against the received signal to determine signal quality. However, to determine the effect of the environment on the signal quality, the ideal signal must be filtered by the REFERENCE FILTER ( $F_t * F_r$ ), so that the ideal signal and the filtered signal differ only by the effect of the environment. So, the received signal is the ideal signal filtered by  $F_t * F_r * F_c$  and the reference signal is the ideal signal filtered by  $F_t * F_r$ , since they only differ by the effect of  $F_c$ , the comparison will show the effect of the communication channel on the signal. The communication channel can also include the hardware path the signal follows after (Tx) or before (Rx) digitizing; this would account for Tx/Rx hardware linear and non-linear distortion.

Common examples of how these filters are used are shown below:

- For Transmit Filter = Root Raised Cosine (RRC), Measurement Filter = RRC, the Reference Filter =  $\text{RRC}^2$  = Raised Cosine
- For Transmit Filter = Raised Cosine (RC), Measurement Filter = None, the Reference Filter = Raised Cosine (When the Measurement Filter = None, the Reference Filter = Transmit Filter)
- For Transmit Filter = Gaussian, Measurement Filter = None, the Reference Filter = Gaussian

## Filter Parameter

The filter parameter specifies the alpha for the Root Raised Cosine or Raised Cosine filter, or the bandwidth-time product (BT) for the Gaussian filter, when selected as the Reference filter. Some filter types have a fixed parameter value that is specified by industry standard, while other filter types by definition have no filter parameter. For filter types with no filter parameter, there is no filter parameter control present in the control panel.

## Freq & BW Tab

The Freq & BW tab specifies a group of settings that affect how measurements are made.

Modulation Params | **Freq & BW** | Advanced Params | Find | Analysis Time | Trace | Scale | Prefs

Frequency Error:  ☒ Auto

Measurement BW:  Auto ▼

Frequency Deviation:  ☒ Auto

Freq & BW tab with nFSK or C4FM modulation type selected and Frequency Error readout enabled (Auto selected)

Modulation Params | **Freq & BW** | Advanced Params | Find | Analysis Time | Trace | Scale | Prefs

Frequency Error:  ☒ Auto

Measurement BW:  Auto ▼

Freq & BW tab with SOQPSK modulation type selected and Frequency Offset enabled (Auto deselected)

Setting	Description
Frequency Error / Frequency Offset	When Auto is enabled, this readout displays frequency error and the measurement is made at the calculated frequency. When Auto is disabled, this setting changes to Frequency Offset. When set to Frequency Offset, this setting is used to demodulate a signal that is not at the center frequency. The measurement is made at the user-entered offset. The Measurement Filter (if any, specified on the Modulation Params tab) is applied about the offset frequency whether set automatically or manually.
Measurement BW	This setting allows you to override the automatic bandwidth calculation and directly enter a bandwidth value. If you enter a value for the measurement bandwidth, be aware that the actual bandwidth of data provided to the measurement will be at least as wide as the value you request and may be as much as two times wider than requested. This override of the selected measurement bandwidth is done so that the instrument uses sufficient bandwidth relative to the chosen symbol rate to ensure good signal quality measurements.
Frequency Deviation	For nFSK modulation types, this setting specifies the frequency deviation. Select Auto to make the instrument do this automatically. Deselect Auto to enter a value manually. This setting is present for only nFSK and C4FM modulation types.

## Equalizer Tab

The Equalizer tab enables you to apply an adaptive equalizer to a digitally modulated signal to compensate for linear distortions in the signal. The Equalizer is available only for displays in the GP Digital Modulation folder (Select Displays window). The analyzer implements a decision directed, feed-forward FIR filter to correct linear distortion in the input signal.

Parameter	Description
Enable Equalization	This setting turns the Equalizer on and off.
Reset Equalization	Initializes the equalizer filter for training.
Enable EQ Export	Exports a text file with equalizer taps in I/Q pairs.
Mode	Specifies whether the equalizer is in learning (Train) mode or analysis (Hold) mode.
Convergence	Specifies the update rate. Maximum value: 0.002. Default value: 0.0005
Taps/Symbol	The number of filter coefficients per symbol used by the filter. Available choices are 1, 2, 4, and 8.
Taps	The number of filter coefficients. Range: 3 to 100 (you can set a higher number, but 100 is the practical limit).
Length	Specifies the number of symbols analyzed (or filter length).

### Selecting the Mode

When enabled, the Equalizer is in either Train mode or Hold mode. When the equalizer is in Train mode, it will update internal filter parameters whenever you adjust the Convergence, Taps/Symbol, Taps, or Length values. When it is in Hold mode, the Equalizer uses the parameter values (both internal and the values accessible on the Equalizer tab) in effect when it was placed into Hold mode.

**NOTE.** The Equalizer does not need to be retrained if the modulation type is changed. You can train the Equalizer by using a simpler modulation type (such as QPSK), place the Equalizer into Hold mode and can then measure more complex modulation types such as QAM.

### Training the Equalizer

To obtain the desired results using the Equalizer, you must first train the Equalizer. This is an iterative process where you adjust some filter parameters (and the analyzer adjusts internal parameters) to achieve the lowest error possible on the acquired signal.

To configure the Equalizer:

1. Press the **Displays** button or select **Setup > Displays**.
2. In the **Select Displays** window, select **GP Digital Modulation** from **Measurements**.
3. Add **Signal Quality** to the **Selected Displays** and select **OK**.
4. With the Signal Quality display selected, select **Setup > Settings**.
5. Select the **Modulation Params** tab set the parameters as necessary for the signal.
6. Select the **Equalizer** tab.
7. Set the **Convergence** value to 0.0005.
8. Set **Taps/Symbol** to 2.
9. Click the **Reset Equalization** button to reset the equalizer.
10. Set the **Mode** to **Train**.
11. Click **Enable Equalization** so it is checked.
12. On the Signal Quality display, examine the value for EVM.
13. Change the Convergence, Taps/Symbol, and Taps values iteratively to achieve a minimum EVM value.

---

**NOTE.** *Changing the Taps/symbol or Taps values resets the equalizer.*

---

## Using the Equalizer

To use the equalizer:

1. Select and configure a **GP Digital Modulation** display.
2. Select **Setup > Settings**.
3. Select the **Equalizer** tab.
4. Select **Enable Equalization** so it is checked.
5. Verify that Mode is set to **Hold** if you have previously trained the Equalizer. If you have not previously trained the Equalizer, [train the Equalizer \(see page 709\)](#) and then set the Mode to Hold.

## Exporting EQ Files

If the **Enable EQ Export** box is checked, the following outputs files are automatically generated to these locations after each measurement update cycle if the EQ coefficients change: *c:\temp\EqTaps.txt* and *c:\temp\EqTapsHdr.txt*. These files have EQ taps in I/Q pairs (one pair per row).

The *Hdr* version file has a five line header before the EQ tap data. Each line in the five line header of the *Hdr* version file has two data values, with the second one always being "0":


```
<line1>Number_of_Header_Lines 0
```

<line2>EQ\_Sample\_Rate\_Hz 0  
 <line3>Demod\_Symbol\_Rate\_Sps 0  
 <line4>EQ\_Samples\_per\_Symbol 0  
 <line5>Number\_of\_EQ\_Taps\_Following 0


## Exporting EQ Files

# Advanced Params Tab


The Advanced Params tab specifies additional parameters that control the demodulation of the signal.



Advanced Params tab for all modulation types except nFSK and C4FM



Advanced Params tab for modulation type nFSK



Advanced Params tab for modulation type C4FM

Advanced Params tab for modulation type APSK

Parameter	Description
Mag Normalize (not present for nFSK or C4FM modulation types)	Select RMS Symbol Magnitude or Max Symbol Magnitude. This setting applies to Mag Error and EVM.
Swap I and Q	When enabled, the I and Q data are exchanged before demodulating.
APSK Parameters (Present only for APSK modulation types)	Sets Constellation display parameters for APSK modulation types.
Symbol rate search (Present only for nFSK modulation types)	Determines whether to automatically detect or manually set the symbol rate. When selected, automatically detects the symbol rate to perform analysis. The calculated symbol rate is displayed in the Signal Quality display. The Symbol Rate Error is also calculated and displayed when Symbol rate search is enabled.
User Symbol Map (per Modulation Type)	Enables the use of custom symbol maps. This enables you to specify the location of symbols in the display. This control can be set independently for each of the modulation types.

## Mag Normalize

Specifies whether Magnitude Normalization uses the RMS Symbol Magnitude or the Maximum Symbol Magnitude as the basis for normalization. Use RMS Symbol Magnitude on QPSK modulations (equal magnitude symbol locations), and use Maximum Symbol Magnitude for signals that have a large difference in magnitude among the symbol locations (such as 128QAM). It prevents the instrument from using the very low magnitude center symbols when normalizing the constellation. The outer symbols are a better normalization reference than the center in this case.

## Swap I and Q

Use the Swap I and Q control to correct a signal sourced by a downconverter that inverts the frequency of the signal under test.

## APSK Parameters

Three parameters can be set for Constellation display of APSK modulation types.



Parameter	Description
Ring	Use to select which ring the radius and rotation values are being specified for. Values are 0 and 1 for 16APSK. 0, 1, and 2 for 32APSK.
Radius	Sets the Ring ratio relative to Ring 0 (inner most ring). Set after selecting the appropriate Ring setting.
Rotation	Sets the rotation value from the I axis. Set after selecting the appropriate Ring setting.

## User Symbol Map

A User Symbol Map is a text file that specifies the location of symbols in the display. The symbol map is unique for each modulation type. The easiest way to create a custom symbol map is to start with the default symbol map and modify it. The default symbol map file is located at C:\SignalVu-PC\ExampleFiles. The default symbol map file is named **DefaultSymbolMaps.txt**. See [Symbol Maps \(see page 719\)](#) for illustrations of the default symbol mapping.

To specify a user symbol map:

1. Click the ... button.
2. Navigate to the directory containing the user symbol text file you want to use.
3. Select the desired file in the Open window and click **Open**.
4. Select **User Symbol Map** to enable the user symbol map.

**Editing the User Symbol Map.** The symbol map is a plain text file and can be edited with any plain text editor.



**CAUTION.** *Whenever you reinstall the program software, the existing DefaultSymbolMaps.txt file will be overwritten. To create a custom symbol map, you should make a copy of the default symbol map file, edit the copy to suit your needs, and save it with a new name. Guidance on how to edit the symbol map file is contained within the default symbol map file.*

The following excerpt from the default symbol map file explains the structure of the file and how to edit it.

```
## Symbol Mapping Definitions
## Version 1.2

## This file defines the mapping of modulation states to symbol values.
##
## File Format :
## -----
## 1. Comments begin with '##' and may appear after the last field in a line
## 2. A symbol map begins and ends with a line containing the name of the
## modulation type. These names must exactly match the name of one of the
## modulation types in the RSA software
## 3. Empty cells may be included to preserve the constellation shape.
## 4. Blank lines are ignored.
## 5. A modulation type which does not match the name of an existing
## type will be ignored.
```


```
##
## Usage :
## -----
## 1. The file is intended to be edited with Notepad or similar text editor
```

The following text is an example of a symbol map.

```
## Symbol Map for 32 QAM
## (Resembles the shape of the constellation)
          32QAM
    00011 00010 00001 00000
01001 01000 00111 00110 00101 00100
01111 01110 01101 01100 01011 01010
10101 10100 10011 10010 10001 10000
11011 11010 11001 11000 10111 10110
    11111 11110 11101 11100
          32QAM
```

## Find Tab

The Find tab is used to set parameters for finding bursts within the data record. This is a post-acquisition operation. Synch Word search controls are also on this tab.



Setting	Description
Burst Detection: Mode	<p>Select whether to analyze bursts</p> <ul style="list-style-type: none"> <li>- Auto: If a burst is found, analyze just that burst period. If a burst is not found, analyze the whole analysis length.</li> <li>- On: If a burst is found, analyze just that burst period. If a burst is not found, display an error message.</li> <li>- Off: Analyze the whole analysis length.</li> </ul> <p>If the signal isn't adequate for demodulation, an error message is shown.</p>
Burst Detection: Threshold	Sets the level required for the signal to qualify as a burst. Enter a value in dBc down from top of the signal.
Use Synch Word	When enabled, specifies the string of symbols to look for. Enter the search string with external keyboard or the on-screen keyboard.
Clear	Blanks the search string field.

## Analysis Time Tab

The Analysis Time tab contains parameters that define how the signal is analyzed in the general purpose digital modulation displays.

Modulation Params | Freq & BW | Equalizer | Advanced Params | Find | **Analysis Time** | Trace | Scale | Prefs

Analysis Offset:  ☒ Auto Time Zero Reference:

Analysis Length:  ☒ Auto Units:

Actual: 128 Sym

The settings values on this tab are the same as those on the main Analysis control panel for the instrument with the only difference being that Analysis Length can be set in either Seconds or Symbols in this location.

Setting	Description
Analysis Offset	Specifies the location of the first time sample to use in measurements.
Auto	When enabled, causes the instrument to set the Analysis Offset value based on the requirements of the selected display.
Analysis Length	Specifies the length of the analysis period to use in measurements. Length is specified in either seconds or symbols, depending on the Units setting. For most modulation types, the Analysis Length set when Auto is enabled is 128 symbols. For some modulation types, a longer length is used.
Auto	When enabled, causes the instrument to set the Analysis Length value based on the requirements of the selected display.
Time Zero Reference	Specifies the zero point for the analysis time.
Actual	This is a displayed value, not a setting. It is the Analysis Length (time or symbols) being used by the analyzer; this value may not match the Analysis Length requested (in manual mode).
Units	Sets the units of the Analysis Length to either Symbols or Seconds.

### Analysis Offset

Use analysis offset to specify where measurements begin. Be aware that you cannot set the Analysis Offset outside the range of time covered by the current acquisition data. (all time values are relative to the Time Zero Reference).

You can set the Analysis Length so that the requested analysis period falls partly or entirely outside the current range of acquisition data settings. When the next acquisition is taken, its Acquisition Length will be increased to cover the new Analysis Length, as long as the Sampling controls are set to Auto. If the Sampling parameters are set to manual, or if the instrument is analyzing saved data, the actual analysis length will be constrained by the available data length, but in most cases, measurements are able to be made anyway. The instrument will display a notification when measurement results are computed from less data than requested. Range: 0 to [(end of acquisition) - Analysis Length]. Resolution: 1 effective sample (or symbol).

## Analysis Length

Use the analysis length to specify how long a period of time is analyzed by a measurement. As you adjust this value, the actual amount of time for Analysis Length, in Symbol or Seconds units, is shown below the control in the "Actual" readout. This setting is not available when Auto is checked. Range: minimum value depends on modulation type. Resolution: 1 symbol. A maximum of approximately 80,000 samples can be analyzed (the actual value varies with modulation type).

## Time Zero Reference

All time values are measured from this point (such as marker position or horizontal position (in Y vs Time displays). Choices are: Acquisition Start or Trigger.

Parameter	Description
Acquisition Start	Offset is measured from the point at which acquisition begins.
Trigger	Offset is measured from the trigger point.

## Trace Tab

### Menu Bar: Setup > Settings > Trace

The Trace tab allows you to set the trace display characteristics of the selected display.

The screenshot shows the 'Traces' tab in the software interface. The tabs at the top are: Modulation Params, Freq & BW, Equalizer, Advanced Params, Find, Analysis Time, Traces (selected), and Prefs. The main area contains the following settings:

- Trace: Trace 2 (dropdown)
- Show: ☒ (checked)
- Freeze: ☒ (checked)
- Content: Lines (dropdown)
- Q Offset: Use shared Pref (dropdown)
- All GP Digital Modulation displays:
  - Points/symbol: 4 (dropdown)
  - Symbol point location: Center (dropdown)

Example traces tab for constellation display set to SOQPSK modulation type

Note that some settings are not present for all modulation types and some settings are not present for all displays.

The screenshot shows the 'Traces' tab in the software interface for CPM modulation. The tabs at the top are: Modulation Params, Freq & BW, Equalizer, Advanced Params, Find, Analysis Time, Traces (selected), and Prefs. The main area contains the following settings:

- Trace: Trace 1 (dropdown)
- Show: ☒ (checked)
- Freeze: ☐ (unchecked)
- Content: Vectors (dropdown)
- Phase multiplier: 1 (dropdown)
- All GP Digital Modulation displays:
  - Points/symbol: 4 (dropdown)

Example trace tab for constellation display set to CPM modulation type

Modulation Params	Freq & BW	Equalizer	Advanced Params	Find	Analysis Time	Trace	Scale	Prefs
Trace: <span>I</span> <input checked="" type="checkbox"/> Show Points/symbol: <span>8</span> Content: <span>Points</span> Symbol point location: <span>Center</span>								

Example trace tab for Demod I&amp;Q display

Setting	Description
Trace	Selects the trace that is hidden or displayed based on whether or not Show is selected.
Show	Specifies whether the trace selected by Trace is displayed or hidden.
Freeze	Halts updates to the trace selected by the Trace setting. Present for the Constellation display only.
Content	Selects whether to display the trace as vectors (points connected by lines), points (symbols only without lines), or lines (lines drawn between symbols, but no symbols are displayed). The choices available depend on the display.
Q Offset	For traces with offset modulation (OQPSK and SOQPSK), this setting enables the trace to be displayed with Q offset or without Q offset. Choices available are <b>Remove Q offset</b> , <b>Include Q Offset</b> , and <b>Use Shared Pref</b> . Selecting Use Shared Pref causes the analyzer to add or remove Q offset according to the <b>Remove Q Offset</b> setting located on the Prefs tab. Setting the Q Offset on the Traces tab changes the Q offset only for the Constellation display. If other GP Digital Modulation displays are shown, they will use the use the Remove Q Offset setting on the Prefs tab regardless of the Q Offset setting on the traces tab for the Constellation display. The Q Offset setting is available only when the modulation type is set to OQPSK or SOQPSK.
Points/symbol	Select how many points to use between symbols when connecting the dots. Values: 1, 2, 4, 8.
Symbol point location	Selects whether to evaluate the symbol value at the center or the end of the eye opening. This control is only present for some of the supported modulation types.
Phase Multiplier	Sets the multiplication constant for the phase multiplication display: ×1 (default), ×2, ×4, ×8, ×16, or ×32. The phase multiplication display facilitates observation of noisy CPM signals by multiplying measurement signal phase by the constant to reduce the number of phase states and expand the phase difference between adjacent symbols.

## Comparing Two Traces in the Constellation Display

When the Constellation display is the selected display, you can use the Traces tab to enable the display of a second trace. The second trace is a version of the current acquisition. You can choose to freeze a trace in order to display the current live trace to an earlier version of itself, you can display the trace as a second trace with or without Q Offset, or you can choose to display both traces frozen in order to compare the trace to itself at different times.

To display a second trace in the Constellation display:

1. If more than one display is present, select the Constellation display to ensure it is the selected display.
2. Click the settings icon or select **Setup > Settings** from the menu bar.

3. Select the **Traces** tab.
4. Select **Trace 2** from the **Trace** drop-down list.
5. Click the **Show** checkbox so that it is checked.
6. Specify the **Content** as desired. Trace 2 lines appear in blue to aid in distinguishing Trace 2 from Trace 1.

## Scale Tab

The Scale tab allows you to change the vertical and horizontal scale settings. Changing the scale settings changes how the trace appears on the display but does not change control settings such as Measurement Frequency.


Setting	Description
Vertical	Controls the vertical position and scale of the trace display.
Scale	Changes the vertical scale units.
Position	Position adjusts the reference level away from top of the graph.
Autoscale	Resets the scale of the vertical axis to contain the complete trace.
Horizontal	Controls the span of the trace display and position of the trace.
Scale	Allows you to, in effect, change the span.
Position	Allows you to pan a zoomed trace without changing the Measurement Frequency. Position is only enabled when the span, as specified by Freq/div, is less than the acquisition bandwidth.
Autoscale	Resets the scale of the horizontal axis to contain the complete trace.
Auto	

## A Note About Units

The Units used for the horizontal scale can be either Seconds or Symbols. To set the units for the horizontal scale, display the **Analysis Time** tab. On the tab, select the appropriate units from the **Units** drop-down list.

## Prefs Tab

The Prefs tab enables you to change appearance characteristics of the GP Digital Modulation displays.



Setting	Description
Show graticule	Shows or hides the graticule.
Show Marker readout in graph (selected marker)	Shows or hides the readout for the selected marker in the graph area.
Radix	Specifies how symbols are displayed in the Symbol Table display and in the Marker readout in the Constellation display.
Remove Q offset	The I and Q data traces are displayed with an offset of half a symbol when the modulation type is set to SOQPSK or OQPSK. You can remove this offset by selecting <b>Remove Q offset</b> . (Which is only present when the modulation type is set to OQPSK or SOQPSK.)
Show EVM and Offset EVM results	Adds EVM results in the display when enabled (Offset EVM is always displayed). Present only in Signal Quality display and with SOQPSK and OQPSK modulation types only

## Symbol Maps

This topic shows the symbol mapping for each digital modulation technique.

QPSK		OQPSK		SOQPSK	
1	3	01	11	01	11
0	2	00	10	00	10

0109-018

8PSK

Left

3

Right

1

6

0

7

4

5

0169-009

BPSK

1

0

SBPSK

1

0

0169-019

D8PSK

Phase shift (radians)	Symbol value (binary)
0	000
$\pi/4$	001
$\pi/2$	011
$3\pi/4$	010
$\pi$	110
$5\pi/4$	111
$3\pi/2$	101
$7\pi/4$	100

Pi/2 DBPSK

Phase shift (radians)	Symbol value (binary)
$+\pi/2$	0
$-\pi/2$	1



**DQPSK**

Phase shift (radians)	Symbol value (binary)
0	00
$\pi/2$	01
$\pi$	11
$3\pi/2$	10

**Pi/4 DQPSK**

Phase shift (radians)	Symbol value (binary)
$+\pi/4$	00
$+3\pi/4$	01
$-\pi/4$	10
$-3\pi/4$	11

**MSK**

Phase shift direction	Symbol value (binary)
-	0
+	1

**16QAM**

Left		Right	
3	2	1	0
7	6	5	4
B	A	9	8
F	E	D	C

0100-010

**32QAM**

Left			Right		
	3	2	1	0	
9	8	7	6	5	4
F	E	D	C	B	A
15	14	13	12	11	10
1B	1A	19	18	17	16
	1F	1E	1D	1C	

0169-011

**64QAM**

Left				Right			
7	6	5	4	3	2	1	0
F	E	D	C	B	A	9	8
17	16	15	14	13	12	11	10
1F	1E	1D	1C	1B	1A	19	18
27	26	25	24	23	22	21	20
2F	2E	2D	2C	2B	2A	29	28
37	36	35	34	33	32	31	30
3F	3E	3D	3C	3B	3A	39	38

0169-012

**128QAM**

		5D	5F	4F	4D	1A	1B	0B	0A		
		5C	5E	4E	4C	18	19	09	08		
4A	48	54	56	46	44	10	11	15	14	1C	1D
4B	49	55	57	47	45	12	13	17	16	1E	1F
5B	59	51	53	43	41	02	03	07	06	0E	0F
5A	58	50	52	42	40	00	01	05	04	0C	0D
6D	6C	64	65	61	60	20	22	32	30	38	3A
6F	6E	66	67	63	62	21	23	33	31	39	3B
7F	7E	76	77	73	72	25	27	37	35	29	2B
7D	7C	74	75	71	70	24	26	36	34	28	2A
		68	69	79	78	2C	2E	3E	3C		
		6A	6B	7B	7A	2D	2F	3F	3D		

0169-017

**256QAM**

Left

Right

EF	FD	EB	F9	E7	F5	E3	F1	0F	3F	4F	7F	8F	BF	CF	FF
CE	DC	CA	D8	C6	D4	C2	D0	0C	3C	4C	7C	8C	BC	CC	FC
AF	BD	AB	B9	A7	B5	A3	B1	0B	3B	4B	7B	8B	BB	CB	FB
8E	9C	8A	98	86	94	82	90	08	38	48	78	88	B8	C8	F8
6F	7D	6B	79	67	75	63	71	07	37	47	77	87	B7	C7	F7
4E	5C	4A	58	46	54	42	50	04	34	44	74	84	B4	C4	F4
2F	3D	2B	39	27	35	23	31	03	33	43	73	83	B3	C3	F3
0E	1C	0A	18	06	14	02	10	00	30	40	70	80	B0	C0	F0
E1	D1	A1	91	61	51	21	11	01	13	05	17	09	1B	0D	1F
E2	D2	A2	92	62	52	22	12	20	32	24	36	28	3A	2C	3E
E5	D5	A5	95	65	55	25	15	41	53	45	57	49	5B	4D	5F
E6	D6	A6	96	66	56	26	16	60	72	64	76	68	7A	6C	7E
E9	D9	A9	99	69	59	29	19	81	93	85	97	89	9B	8D	9F
EA	DA	AA	9A	6A	5A	2A	1A	A0	B2	A4	B6	A8	BA	AC	BE
ED	DD	AD	9D	6D	5D	2D	1D	C1	D3	C5	D7	C9	DB	CD	DF
EE	DE	AE	9E	6E	5E	2E	1E	E0	F2	E4	F6	E8	FA	EC	FE

0169-013

**2FSK**

Left

Right

0	1
---	---

**4FSK**

Left

Right

0	1	3	2
---	---	---	---

0169-014

**8FSK**

Left

Right

0	1	2	3	7	6	5	4
---	---	---	---	---	---	---	---

0169-015

**16FSK**

Left

Right

0	1	2	3	4	5	6	7	15	14	13	12	11	10	9	8
---	---	---	---	---	---	---	---	----	----	----	----	----	----	---	---

0100-010

**C4FM**

Left

Right

11	10	00	01
----	----	----	----

0100-010

**CPM**

Phase shift (h = modulation index)	Symbol value (binary)
-3h	11
-h	10
+h	01
+3h	00

## Overview: User Defined Measurement and Reference Filters

The Modulation Parameters control tab for GP Digital Modulation displays enables you to load custom measurement and reference filters. If the existing filters do not meet your requirements, you can create your own filters for use in the measurement and reference settings. This section describes the structure of user filters and provides two examples of customized filters. See [User Filter File Format \(see page 726\)](#).

### Loading a User Measurement Filter

To load a your own measurement filter:

1. From the Modulation Params control tab (Settings > Modulation Params), click on the drop-down list for **Measurement Filter**.
2. Select one of the filter names that starts with **User**. This displays the **Manage user filters** window.
3. Enter a name for the filter in one of the **Name (editable)** boxes. This name will appear in the drop-down list on the Modulation Params tab, prefaced with **User**. The maximum number of characters for the filter name is 20.

4. Click the **Browse** button and navigate to the directory containing the filter you want to load. Select the filter and click **Open**. If you wish to use a filter that is not in the list, select **User other** and locate and open the file you wish to use.
5. Click **OK** to load the filter and return to the Modulation Params page.

## User Filter File Format

The filter file is selected on the Modulation Params control panel tab used by the GP Digital Modulation displays (Option 21 only). It stores the user-defined measurement or reference filter coefficient data in CSV format. The following figure shows the file structure.

```
# Rate
10
# FilterI,FilterQ
0.97321,0.01947
0.89559,0.04051
0.77497,0.05942
0.62333,0.07202
0.45524,0.07438
0.28614,0.06354
...
0.13045,0.01947
```

} Oversampling rate of the filter (samples/symbol)

} IQ pairs (1 to 1024) of the filter coefficient in time domain

0169-023

User filter file structure

A filter file is a plain text file, in comma-separated-variable format. The file extension must be CSV.

The filter file contains the following variables:

**Rate.** Specifies the oversampling rate (the number of samples per symbol). The filter coefficient data will be interpolated by the specified rate.

**FilterI,FilterQ.** Specifies IQ pairs (1 to 1024) of the filter coefficient in time domain.

### Rules for Creating a Filter File

- A line beginning with “#” is a comment line.
- Enter a positive value for the oversampling rate.
- A decimal number can be expressed by fixed point or floating point. For example, 0.01 and 1.0E-2 are both valid.
- “0” (zero) and “,0” (comma zero) can be omitted. For example, “1.5,0”, “1.5,”, and “1.5” are equivalent.
- Lines with only a comma and blank lines are skipped.

**Example filters.** For your reference, two example filters, Raised Cosine and Gaussian, are shown here. Both filters contain 65 data points with an oversampling rate of 8.

**Raised Cosine ( $\alpha = 0.3$ )**

(Row 1 to 18)	(Row 19 to 36)	(Row 37 to 54)	(Row 55 to 68)
# Rate	0.0383599,0	0.973215,0	0.0743803,0
8	0,0	0.895591,0	0.0720253,0
# FilterI,FilterQ	-0.047715,0	0.774975,0	0.0594205,0
0,0	-0.0984502,0	0.623332,0	0.0405144,0
-0.0062255,0	-0.143898,0	0.455249,0	0.0194761,0
-0.0136498,0	-0.174718,0	0.286147,0	0,0
-0.0209294,0	-0.181776,0	0.130455,0	-0.0151973,0
-0.0263419,0	-0.157502,0	0,0	-0.0246357,0
-0.0280807,0	-0.0971877,0	-0.0971877,0	-0.0280807,0
-0.0246357,0	0,0	-0.157502,0	-0.0263419,0
-0.0151973,0	0.130455,0	-0.181776,0	-0.0209294,0
0,0	0.286147,0	-0.174718,0	-0.0136498,0
0.0194761,0	0.455249,0	-0.143898,0	-0.0062255,0
0.0405144,0	0.623332,0	-0.0984502,0	0,0
0.0594205,0	0.774975,0	-0.047715,0	
0.0720253,0	0.895591,0	0,0	
0.0743803,0	0.973215,0	0.0383599,0	
0.063548,0	1,0	0.063548,0	

**Gaussian (BT = 0.5)**

(Row 1 to 18)	(Row 19 to 36)	(Row 37 to 54)	(Row 55 to 68)
# Rate	0.00191127,0	0.978572,0	0.000401796,0
8	0.00390625,0	0.917004,0	0.000172633,0
# FilterI,FilterQ	0.00764509,0	0.822878,0	7.10E--05,0
2.33E-10,0	0.0143282,0	0.707107,0	2.80E-05,0
9.11E-10,0	0.0257149,0	0.581862,0	1.06E-05,0
3.42E-09,0	0.0441942,0	0.458502,0	3.81E-06,0
1.23E- 08,0	0.0727328,0	0.345977,0	1.32E-06,0
4.21E-08,0	0.114626,0	0.25,0	4.37E-07,0
1.39E-07,0	0.172989,0	0.172989,0	1.39E-07,0
4.37E-07,0	0.25,0	0.114626,0	4.21E-08,0
1.32E-06,0	0.345977,0	0.0727328,0	1.23E-08,0
3.81E-06,0	0.458502,0	0.0441942,0	3.42E-09,0
1.06E-05,0	0.581862,0	0.0257149,0	9.11E-10,0
2.80E-05,0	0.707107,0	0.0143282,0	2.33E-10,0
7.10E-05,0	0.822878,0	0.00764509,0	
0.000172633,0	0.917004,0	0.00390625,0	
0.000401796,0	0.978572,0	0.00191127,0	
0.000895512,0	1,0	0.000895512,0	



# Using Markers

Markers are indicators in the display that you can position on a trace to measure values for the X and Y axes, such as frequency, power, and time. A Marker always displays its position and, if enabled, will display the difference between its position and that of the Marker Reference (MR).

You can display up to five markers including the reference marker. Markers can all be placed on the same trace or they can be placed on different traces. There are three types of Markers: Reference, Delta, and Power Markers. The Marker Reference (labeled MR in the graph) makes absolute measurements and is also used for calculating differences when Delta or Power readouts are enabled. The Delta Markers (labeled M1 to M4 in the graph) are used to measure other points on the trace or the difference between the Marker Reference and the Delta marker. The Power Markers (labeled M1 to M4 in the graph) function the same way as the Delta Markers, except they show power density and integrated power density (dBm/Hz) instead of power level (dBm).

The following two tables show the appearance of the four types of marker readouts.


Marker Reference Readout	Absolute Marker Readout	Power Marker Readout	Delta Marker Readout
<div><p>Reference Marker label</p><p>Power level at marker</p><p>MR: -10.00 dBm</p><p>1.004 GHz</p><p>Frequency at marker</p></div>	<div><p>Absolute Marker label</p><p>Power level at marker</p><p>M1: -40.54 dBm</p><p>999 MHz</p><p>Frequency at marker</p></div>	<div><p>Power density at Power Marker</p><p>M1: -64.97 dBm/Hz</p><p>Delta: 10 MHz</p><p>IntPowerM1: -9.92 dBm</p><p>PowerDensity: -79.98 dBm/Hz</p><p>Difference in frequency between Power Marker and Reference Marker</p><p>Integrated power value from points between and including Reference Marker to Power Marker</p></div>	<div><p>Delta Marker label</p><p>Difference in power level between Delta Marker and Marker Reference</p><p>ΔM1: -30.54 dB</p><p>-5 MHz</p><p>Difference in frequency between Delta Marker and Marker Reference</p></div>

The following table shows the appearance of the marker indicators as they appear on the trace. Whichever marker is active will appear as a solid diamond.

Marker Reference	Absolute, Delta, and Power Marker
<div><p>MR</p></div>	<div><p>M1</p></div>

# Controlling Markers with the Right-Click Actions Menu

In addition to controlling the marker actions from the menu controls, you can use the right-click actions menu to move markers or add and delete markers. Some items are not available for certain displays.




You display the Right-click Action menu by clicking the right mouse button.

Menu item	Description
Marker to peak	Moves the selected marker to the highest peak. If no marker is turned on, this control automatically adds a marker.
Next Peak	Moves the selected marker to the next peak. Choices are Next left, Next right, Next lower (absolute), and Next higher (absolute).
Add marker	Defines a new marker located at the horizontal center of the graph.
Delete marker	Removes the last added marker.
All markers off	Removes all markers.

### Markers Context Menu


The Markers context menu appears when you right-click (or touch and hold) on a marker. The Markers context menu enables you to assign a marker to a different trace and pan the trace to place the marker at the measurement frequency.



## Measuring Frequency and Power in the Spectrum Display

To measure the frequency and power at a point on a Spectrum trace:

1. Select **Markers > Define Markers**.
2. Select the **Marker Properties** tab.
3. Click **Add**. This displays a drop-down list under **MR** (Marker Reference), found inside the **Reference** box. The first marker defined is always designated the Marker Reference. Subsequently defined markers are Delta Markers for which readouts can be selected for Delta, Power, or Absolute. You can also select and adjust markers by clicking on an existing marker on a trace.
4. From the drop-down list, select the trace to which you want to assign the marker.



5. Click the close control panel button to remove the Define Markers control panel.
6. Click on the marker on the trace to activate that marker.
7. Drag the marker in the graph using a mouse to move the marker to the desired location on the trace. You can also click on the marker location text box in the Markers toolbar at the bottom of the screen and adjust it with your mouse wheel. The Peak button in the Markers toolbar and the arrow buttons to the right of it control marker peak searching on the trace.
8. Read the frequency and power level of the marker position on the display.
9. Read the signal density, frequency, and power level of the marker position on the display.
10. If Power markers are selected, read the point power density and the integrated power density.

## Marker Action Controls

Controls for enabling and moving markers and for initiating marker peak searches are found in several locations. There are buttons for a few of the most common marker activities on the front panel of the instrument, used along with the knob for adjusting marker positions. The Markers menu contains selections for peak searches. Each graph display has a Marker button on the status bar that provides access to the Markers toolbar. The Markers toolbar has buttons for peak searches, centering, and defining markers.

## Peak

Selecting **Peak** from the Markers menu moves the selected marker to the highest level peak within the acquisition record.

## Next Peak

Selecting Next Peak displays a submenu that enables you to move the selected marker to the next peak.

Setting	Description
Next Left	Moves the selected marker to the next peak to the left of the current marker position.
Next Right	Moves the selected marker to the next peak to the right of the current marker position.
Next Lower (absolute)	Moves the selected marker to the lower level peak (in absolute terms) on the trace.
Next Higher (absolute)	Moves the selected marker to the higher level peak (in absolute terms) on the trace.

## Marker to Center Frequency

Changes the center frequency to match the frequency of the selected marker.


## Enabling Markers and Setting Marker Properties

The Define Markers Control Panel is used to enable markers and set their properties. You can set up to five markers including the marker reference. Markers are shown in most displays.

Markers have three types of on-screen readouts: Absolute, Delta, and Power. When **Readouts** is set to **Absolute**, each readout displays only the marker's position on the trace. In Frequency displays, this means the marker readout shows the frequency and power of the trace at the marker position. When **Readouts** is set to **Delta**, each delta marker (M1-M4) readout displays both the marker's position on the trace and the difference between its position and the position of the Reference Marker (MR). When **Readouts**

is set to **Power**, each delta marker (M1-M4) readout displays the marker's position on the trace, the difference between its position and the position of the Reference Marker (MR), the point power density, and the integrated power density.

## Defining Markers



1. Click the **Markers** button on the basic control toolbar to view the Markers toolbar.
2. Click the **Define** button on the Markers toolbar to open the Define Markers control panel.
3. In the Marker Properties tab, select **Add** to turn on the next marker. A drop-down list under the marker label allows you to assign the marker to a trace.

---


**NOTE.** The first marker defined will always be **MR**. The MR marker is the reference for delta marker readouts.

---

4. Select the trace to which the marker should be attached from the drop-down list.
5. Click **Add** to add additional markers.
6. Click on the **Readouts** drop down menu to select the readout to view. If you select Delta from the drop down menu, you can check the **dBc/Hz** box to measure noise in dBc/Hz and show that for the delta value. Checking this box if other readouts are selected will force the readout to Delta. You can read more about marker noise (dBc/Hz) mode [here \(see page 735\)](#).
7. Click the close button to remove the Define Markers control panel.

## Defining Peaks

You can specify two amplitude values that define peaks. For the DPX display, you can also define peaks based on signal density characteristics.



**NOTE.** The settings shown in the DPX Signal Density section of the Define Peaks tab are not used by SignalVu-PC.

#### Amplitude


Peak Threshold	Peak Threshold specifies the level that the signal must exceed to be considered a peak.
Minimum Excursion	Minimum Excursion specifies how much the signal must decrease and then increase before another peak can be declared.

#### DPX Signal Density

Density Threshold	Density Threshold specifies the signal density (number of hits per displayed pixel) that the DPX bitmap must exceed to be considered a trigger event.
Minimum Excursion	Minimum Excursion specifies how much the signal density must decrease and increase again before another peak can be declared.
Smoothing (pixels squared)	Smoothing specifies the number of pixels around the marker that are averaged together to reduce "noise" in the readout of signal density. The value of this control is the number of pixels on each side of the square area used for averaging. With Smoothing = 1, no averaging is done and the marker z-axis readout is the hit count (density) of a single pixel. Use this control to characterize how wide or narrow a range of pixels should be averaged to determine the signal density.

1. Select **Markers > Define Markers** to display the Define Markers control panel.
2. Select the **Define Peaks** tab.
3. To define the level for Peak Threshold, enter a value in the Peak Threshold number entry box.
4. To define the amount the trace must dip, enter a value in the Peak Excursion number entry box.
5. Click the close button to remove the Define Markers control panel.

## Using the Markers Toolbar












**Favorites toolbar:** 

#### Status bar: Markers button

Select **Markers** to display or hide the Markers toolbar at the bottom of the application window. The Markers toolbar enables you to operate existing markers or define new markers.



Enabling a marker or adjusting the position of a marker automatically opens the Markers toolbar.

Icon / Readout	Description
	Opens the Define Markers control panel.
 <b>M1</b>	Selected marker readout. This readout shows which marker is selected. The pop-up menu allows you to choose the selected marker, add markers, and turn all markers off.
 1.5 GHz	Marker position controls. For frequency displays, this readout shows the marker position in Hertz. For time displays, this readout shows the marker position in seconds. The position of the selected marker can be changed by selecting the numeric readout and using the knob to adjust the value.
	Changes the analyzer's Center Frequency to the frequency of the selected marker. Not selectable for time markers.
	Moves the marker to the highest peak on the signal. On displays that scale about zero on the vertical axis (for example, Magnitude Error, EVM, and Frequency vs. Time), the highest peak selected by the Peak button is an "absolute value", therefore, negative peaks are included in the search for the highest peak.
	Moves the selected marker to the next peak to the <b>left</b> of the current position.
	Moves the selected marker to the next peak to the <b>right</b> of the current position.
	Moves the selected marker to the next <b>lower</b> peak value. The peak value here refers to the numeric value of the peak amplitude. Thus, when repeatedly moving the marker, it can move to the right or left depending on the location of the next lower value.
	Moves the selected marker to the next <b>higher</b> peak value. The peak value here refers to the numeric value of the peak amplitude. Thus, when repeatedly moving the marker, it can move to the right or left depending on the location of the next higher value.
	Displays/hides the marker table from the display.
	Removes the Markers toolbar from the display.

## Measuring Noise Using Delta Markers in the Spectrum Display


In the Spectrum display, you can set Markers to dBc/Hz to measure noise on the trace. Markers in this mode operate just as they do in normal mode, but the readouts for the markers are in dBm/Hz and dBc/Hz.

dBm/Hz is the power in milliwatts referenced to a 1 Hz bandwidth. To make this measurement, the analyzer assumes that the measured signal is random noise. It then converts the measured power (made at any RBW) to the power that would be measured had a 1 Hz filter been applied for the measurement.


dBc/Hz represents dBm/Hz referenced to a carrier. Here, it is assumed that the carrier is a CW signal, and its signal level does not change when the RBW is changed, so the Reference Marker measurement on the carrier is unchanged from any other marker measurement. However, the delta marker values are converted to dBm/Hz, and then a difference value, in dBc/Hz, is calculated between each delta measurement and the reference.

### Measuring Noise

To measure noise on a Spectrum trace:


1. Select **Markers > Define** to display the Markers control panel.
2. Click **Add**. The first marker defined is always designated the Marker Reference. Subsequently defined markers are Delta Markers for which readouts can be selected for Delta, Power, or Absolute. You can also select and adjust markers by clicking on an existing marker on a trace.
3. Click **Add** again so that there are at least two markers defined.
4. Check that **Readouts** is set to Delta and check the **dBc/Hz** box.
5. If you have more than one trace defined, use the drop-down list for each marker to set it to the trace on which you want to measure noise.
6. Notice that Detection is set to **Average** for the trace you are using for this measurement.
7. Check that the Amplitude units are set to dBm (that is the default). If they are not, click the  (Analysis) icon, select the **Units** tab, and select **dBm**.
8. Click the Close button to remove the control panel.
9. Move the markers to the desired locations on the trace.
10. Read the frequency and power level for the selected marker in the upper corners of the display. To display the delta measurement in dBc/Hz, select the delta marker (M1, M2, M3 or M4) by clicking on it or by selecting it in the drop-down marker list in the Markers toolbar.

The following image shows the Spectrum display with a Delta Marker.



The following image shows the Spectrum display with Power Markers.








## The Mask Test Tool

You can specify pass/fail and mask parameter conditions for the Spectrum, Spurious, Gain, Frequency Settling Time and Phase Settling Time displays. When these conditions are met, the instrument can perform actions such as stopping acquisitions or saving data.

## Mask Test Settings

### Menu Bar: Tools > Mask Test

Selecting **Mask Test** displays the Mask Test control panel. These settings define test parameters and specify actions to be performed when the test conditions are met. Checking the **Enable Test** box sets the application to perform the test once the conditions are defined.




Setting	Description
Enable Test	Select to perform a test, then set the test conditions.
<a href="#">Define (see page 739)</a>	Specifies which result to test and what to test for.
<a href="#">Actions (see page 744)</a>	Specifies the action to take when the test condition is met.


## Define Tab (Mask Test)

The Define tab sets the parameters for tests. From this tab, you specify which result to test and what kind of violation to test for.

The following image shows the Define tab with *is great than* selected. After you select that test, you will enter the desired signal level. The procedure is the same if you select *is less than*.



The following image shows the Define tab with *is outside mask* selected. After you select that test, you need to click the Edit limits button and set the desired test limits. The procedure is the same if you select *is inside mask*.




Setting	Description
Search in	Specifies which result to test.
Test for	Specifies what to test for. You can specify a test based on a signal level ("is greater than", "is less than") or a mask ("is outside mask", "is inside mask"). Options for Spurious and Settling Time are Pass and Fail.

Search In

The possible choices for **Search in** include traces from Spectrum, DPX, Noise Figure, Spurious, and Setting Time displays. The available choices are Trace 1, Trace 2, Trace 3, Math , Spectrogram Trace, Spurious, and Settling Time. The available choices include only results from displays that are currently open.

**NOTE.** If you select a result that is not the selected trace or result in the target display, you will not see the results of the test. To see the results, select the trace from the drop-down menu in the target measurement display and check the Show box:



Test For

The **Test for** setting has selections that vary based on which display's results you are testing.


Pass/Fail Tests for Spurious and Settling Time

The Frequency Settling Time, Phase Settling Time measurements, and Spurious measurements test functions provide pass/fail results.

Greater Than/Less Than Tests for Spectrum


If you select a greater than/less than test, you also specify the level that defines a violation. When you select either **is greater than** or **is less than**, a text entry box appears to the right of the drop-down list. Use the text entry box to specify the signal level you wish to test for. While not as flexible as mask testing, this type of test is quicker to set up.

The following figure shows the results of an **is greater than** test. The vertical red bar highlights results that match the test definition.




### Outside/Inside Mask Tests

If you specify a mask-based test, then you need to edit the mask to specify the levels that define a violation. When you select **is outside mask** or **is inside mask**, an **Edit limits** button is displayed. Click the **Edit limits** button to display the Mask Test Editor window.




**To set up and save mask test limits for a test.** Perform the following procedure to set up a test using the mask limits.


1. After choosing the desired **Search in** and **Test for** items, click **Edit limits** to display the Mask Test Editor window.
2. Click the **New** button to create a table. This clears the existing points and loads the default table. You can also click **Open** to open an existing table.
3. To edit values, add points, or delete points in a table:
  - a. To edit an existing value, double-click on the cell you want to edit and enter the desired value. The active point shows as a red point on the plot.



- b. To add a new point, check the box next to the target mask (located below the **Auto draw** button).
- c. Select **Add points** located below the **Open** button.
- d. Select the target mask (Upper Mask Table or Lower Mask Table) from the drop-down menu.
- e. Click in the desired location on the plot to add the point.



- f. To use the auto draw feature to automatically place points on the chosen mask, enable the desired mask from the drop-down menu and then click the **Auto draw** button.




---

**NOTE.** Units may be changed for measurements other than Noise Figure in Setup > Analysis > Units.

---

4. To delete a point from the table, select the point to be removed, and click the **X** button.
5. To save the mask to a file for later recall, click **Save As**.
6. From the Save As dialog, name the file and save it in the desired location.

---

**NOTE.** Masks are saved in XML format with a .msk extension.

---

7. To dismiss the Mask Test Editor window, click **Done**.


### Mask Test Result Example

The following figure shows the results of a Spectrum **is outside mask** test with Upper Mask enabled. The vertical red bar highlights results that have exceeded the test limits. The shaded region shows the mask area.



# Actions Tab

The Actions tab allows you to trigger the application when a signal in the frequency domain violates the mask.



Setting	Description
During Run or Replay	Actions specified here will occur in either Run mode or Replay mode. (Run actions not available in SignalVu-PC.)
Beep	The analyzer beeps when the test condition is met.
Stop	The analyzer stops when the test condition is met.
During Run Only	Actions specified here are taken only during Run mode (while acquiring live data).
Save acquisition data	Saves acquisition data to a file when the test condition is met. Use the drop-down list to specify the format of the saved data. The available file formats are: <a href="#">TIQ</a> , <a href="#">CSV</a> , and <a href="#">MAT</a> (see page 833).
Save trace	Saves Trace data to a file when the test condition is met.
Save picture	Saves a screen capture to a file when the test condition is met. Use the drop-down list to specify the format of the saved picture. The available file formats are: <a href="#">PNG</a> , <a href="#">JPG</a> , and <a href="#">BMP</a> (see page 833). Note that no trace will be saved if the tested trace isn't a saveable trace type. For example, a Spurious trace is not saveable.
Max files	Specifies the number of times a test action stores a file. After this limit is reached, no more files are saved. The instrument will continue to run, but no additional files are saved when test conditions are met.  Keep in mind when setting this number that picture files are counted as part of the total number of files. For example, if you set Max files to 100, the instrument will save 100 acquisitions if only acquisitions are saved or only pictures are saved. But, if both acquisitions and pictures are saved, then 50 acquisitions and 50 pictures will be saved.

## AutoSave File Naming

When one of the AutoSave actions is enabled, the name of the saved file is automatically incremented even if the **Automatically generate filenames** option (Tools > Options > Save and Export) is not enabled. When the file is saved, it will be saved to *C:\<instrument name>Files\*.




## Analysis Settings

**Menu Bar:** Setup > Analysis

**Favorites toolbar:** 


The Analysis control panel provides access to settings that are used by all displays. These settings affect only post processing and they do not control hardware settings.



Setting	Description
<a href="#">Analysis Time (see page 745)</a>	Specifies the length of time to use in measurements.
<a href="#">Spectrum Time (see page 747)</a>	Specifies whether the Spectrum Analysis display uses the same Analysis Time parameters as all the other displays or if it uses a different Offset and Length.
<a href="#">Frequency (see page 747)</a>	Specifies the measurement frequency (center frequency).
<a href="#">Units (see page 750)</a>	Specifies the Power units for all displays.

## Analysis Time Tab

The Analysis Time tab contains parameters that define the portion of the acquisition record that is used for analysis.



Setting	Description
Analysis Offset	Specifies the location of the first time sample to use in measurements.
Auto	When enabled, causes the instrument to set the Analysis Offset value based on the requirements of the selected display.
Analysis Length	Specifies the length of time to use in measurements.
Auto	When enabled, causes the instrument to set the Analysis Length value based on the requirements of the selected display.
Time Zero Reference	Specifies the zero point for the analysis time.
Actual	This is a displayed value, not a setting. It is the Analysis Length (time) being used by the analyzer; this value may not match the Analysis Length requested (in manual mode).

### Analysis Offset

Use analysis offset to specify where measurements begin. Range: 0 to [(end of acquisition) - Analysis Length)]. Resolution: 1 effective sample (or symbol).

### Analysis Length

Use the analysis length to specify how long a period of time is analyzed by a measurement. After you enter a value, this box changes to show the actual value in use, which is constrained by Acquisition Time. This setting is not available when Auto is checked. Range: minimum value depends on modulation type to Acquisition Length. Resolution: 1 effective sample (or symbol).

### Time Zero Reference

The analysis offset is measured from this point. Choices are: Acquisition Start or Trigger Point.

Parameter	Description
Acquisition Start	Offset is measured from the point at which acquisition begins.
Trigger Point	Offset is measured from the trigger point.

## Spectrum Time Tab


This tab controls whether the Spectrum display uses the same Analysis Time parameters as all the other views or uses a different Offset and Length.

Settings	Description
<b>Spectrum Time Mode</b>	
Independent	Causes the spectrum analysis views to use the settings unique to those displays.
Use Analysis Time settings	Causes the spectrum analysis views to use the settings on the Analysis Time tab.
<b>Spectrum Time (only available when <i>Independent</i> is selected)</b>	
Spectrum Offset	Sets the beginning of Spectrum Time with respect to the selected time reference point (selectable in the Analysis Time tab as either Acquisition Start or Trigger).
Spectrum Length	The amount of data, in terms of time, from which spectrum traces are computed.
Auto	When enabled, causes the instrument to set the Spectrum Length value based on the RBW setting.
Actual	This is a displayed value, not a setting. It is the Spectrum Length (time) being used by the analyzer; this value may not match the Spectrum Length requested (in manual mode). The actual spectrum length is always an integer multiple of the time needed to support the RBW value.


## Frequency Tab

The Frequency tab specifies two frequency values: the Measurement Frequency and the Spectrum Center Frequency. The Measurement Frequency is the frequency at which most displays take measurements. The Spectrum Center Frequency is the center frequency used by the Spectrum, DPX Spectrum, Spectrogram and Time Overview displays.


The following screen capture shows a display with both the Measurement Frequency and the Spectrum Center Frequency locked together.



Normally, the Measurement Frequency and the Spectrum Center Frequency are locked together so that both have the same setting. But in some situations, for example, where a signal contains a set of channels, it is useful to unlock the Measurement Frequency from the Spectrum Center Frequency. When the Spectrum Center Frequency is unlocked from the Measurement Frequency, you can adjust the Measurement Frequency so that measurements can be taken at different frequencies without resetting the center frequency. The following screen capture shows the magenta-colored measurement frequency indicator still located at the center frequency.



The following screen capture shows the measurement frequency indicator located at 2.0402 GHz while the Spectrum Center Frequency is still located at 2.0000 GHz.



You can drag the Measurement Frequency indicator on the screen to set the measurement frequency. Note the base of the Measurement Frequency indicator. The width of the box indicates the widest measurement bandwidth in use among the open displays. You can see how the width of this box changes with the measurement bandwidth by, in this example, adjusting the Measurement BW setting for the Constellation

display (Settings > Freq & BW tab). As you adjust the setting, you will see how the width of the box at the base of the Measurement Frequency Indicator changes.

The Measurement Frequency indicator is useful for interpreting system behavior when MeasFreq is unlocked. If a measurement has a wide bandwidth relative to the spectrum span, and the Measurement Frequency is far from spectrum center, the measurement is likely to fail because its required frequency range exceeds the frequency range of the available data. In such a case, the navigation control will show that the measurement bandwidth extends outside the Spectrum's span.


There are interactions between frequency unlocking and RF & IF Optimization (see the [Amplitude control panel \(see page 759\)](#)). When **Best for multiple displays** is the selected optimization, the instrument is allowed to use its full bandwidth to meet the needs of all open displays. This is the most user-friendly optimization because it decreases the number of **Acq BW too small** errors, but it can increase noise and slightly decrease measurement accuracies. For all other optimization types, the instrument optimizes the acquisition bandwidth for the selected display, improving measurement quality somewhat, but reducing concurrent measurement capability.

There are also interactions with trigger settings. When the Spectrum Center Frequency is unlocked from Measurement Frequency, the RF triggers (Trigger Source = RF Input) can tune to either Spectrum Center Frequency or Measurement Frequency. When a spectrum display is selected, the trigger frequency is the same as the Spectrum Center Frequency. When one of the other displays that uses Measurement Frequency is selected, the trigger is tuned to the Measurement Frequency also. This allows you to trigger on the signal you are measuring. But, there is an exception: when the selected RF & IF Optimization is **Best for multiple displays**, the trigger is always tuned to the Spectrum Center Frequency.

The reason the trigger frequency is affected by Measurement Frequency and RF & IF Optimization, is that these functions control how the acquisition is tuned. The optimization **Best for multiple displays** keeps the acquisition centered about the Spectrum Center Frequency at all times. To accommodate off-center Measurement Frequencies, it just widens the acquisition bandwidth. Other optimizations tune the acquisition frequency to match that of whichever display is currently selected. The RF trigger module receives the same acquisition data as all the measurements, tuned to the center of the current acquisition bandwidth.

## Units Tab

The Units tab specifies the global Amplitude units for all the views in the analysis window.



## Replay Overview

The Replay function enables you to reanalyze data with different settings and even different measurements. You can replay all the acquisitions in memory, a single acquisition, a single frame within an acquisition (if Fast Frame is enabled or was enabled when the waveform file was saved), or any contiguous set of data records from acquisition history.


### Displaying the Replay Control Panel

To display the Replay control panel:

1. Select **View** from the main menu bar.
2. Select **Replay Toolbar** in the menu. The toolbar will appear near the bottom of the display.



3. Click the **Define** button to open the Replay control panel.




---

**TIP.** You can read more about the other toolbar buttons [here](#).

---

### Selecting the Data Type to Replay

You can choose to replay either acquisition data or DPX spectra (providing DPX Spectra were saved in the waveform file). Choose **Acq Data** to replay any acquisitions except DPXogram acquisitions. Choose **DPX Spectra** to replay a DPXogram acquisition.

### Select Data Records Tab

The Select data records tab is used to select which data records to replay. A data record is the smallest unit that can be replayed. Note that what constitutes a data record can vary. If FastFrame is not enabled, a data record consists of a single acquisition. If FastFrame is enabled, each acquisition can contain multiple frames, and a data record consists of a single frame.

Select data records	Acquisition Info	Replay Speed
<b>Select acquisitions</b> <input type="button" value="Select All"/>		
1 : 7/25/2011 17:39:29.72		
Start: 1	7/25/2011 17:39:29.72	
Stop: 304	7/25/2011 17:39:33.79	
304 : 7/25/2011 17:39:33.79		

Without FastFrame enabled

Select data records	Acquisition Info	Replay Speed
<b>Select acquisitions</b> <input type="button" value="Select All"/>		
1 : 3/10/2010 4:47:40.22		
Start: 1	3/10/2010 4:47:40.22	
Stop: 1	3/10/2010 4:47:40.22	
1 : 3/10/2010 4:47:40.22		
<b>Select frames</b> <input type="button" value="Select All"/>		
1 : 3/10/2010 4:47:40.22		
Start: 1	3/10/2010 4:47:40.22	
Stop: 10	3/10/2010 4:47:51.74	
10 : 3/10/2010 4:47:51.74		

With FastFrame enabled

**Date and Time Stamps.** The line that appears above each Start box (one for acquisitions and one for frames when FastFrame is enabled) is a date stamp that displays the date and time the first record in the current acquisition was acquired. The line that appears below each Stop box is a date stamp that displays the date and time the last record in the current acquisition was acquired.

The line that appears to the right of each Start box displays the date and time the selected acquisition or frame was acquired. The line that appears to the right of each Stop box displays the date and time the selected record or frame in the current acquisition was acquired.

**Select All button.** Selecting Select All resets the Start and Stop values. The Start value is reset to the first acquisition or frame of the current acquisition. The Stop value is reset to the last acquisition or frame in the current acquisition.

## Select DPX Spectra Tab

The Select DPX Spectra tab is used to select which DPXogram spectra to replay. A spectra is the smallest DPXogram unit that can be replayed. It is equivalent to one line in the DPXogram display.

Select data records	Select DPX Spectra	Acquisition Info	Replay Speed
<b>Select spectra</b> <input type="button" value="Select All"/>			
1 : 9/29/2011 17:36:53.05			
Start: 1	9/29/2011 17:36:53.05		
Stop: 602	9/29/2011 17:37:7.82		
602 : 9/29/2011 17:37:7.82			



**Date and Time Stamps.** The line that appears to the right of each Start box displays the date and time the selected DPX Spectra was acquired. The line that appears to the right of each Stop box displays the date and time the selected DPX Spectra in the current acquisition was acquired.

**Select All button.** Selecting Select All resets the Start and Stop values. The Start value is reset to the first DPX Spectra of the current acquisition. The Stop value is reset to the last DPX Spectra in the current acquisition.

### Acquisition Info Tab

Displays information about acquisition settings and sets the number of decimal places used for displaying the time stamp.

The screenshot shows the 'Acquisition Info' tab selected. It contains a 'Timestamp decimal places' input field set to '2'. There are two buttons: 'Delete all Acq data' and 'Delete all DPX spectra'. Below these are two columns of acquisition parameters:

Acq Center Freq:	1.90 GHz	Preamplifier:	Off
Acq Bandwidth:	85.0 MHz	RF Atten:	15.00 dB
Sampling Rate:	150 MHz	Ref Level:	0.00 dBm
Dither:	On	Acq Length:	5.19 us

### Replay Speed Tab

Sets the speed at which data records are replayed.

The screenshot shows the 'Replay Speed' tab selected. It features a horizontal slider control with 'Slow' on the left and 'Fast' on the right. The slider is currently positioned towards the 'Fast' end.

## Replay Menu

The Replay menu provides controls that let you choose how to replay acquisitions. The replay function enables you to, in effect, “rerun” an analysis while applying different measurements to the same set of acquisition data.

Menu item	Description
Acq Data	Select Acq Data to replay acquisitions.
DPX Spectra	Select DPX Spectra to replay a DPXogram display.

Menu item	Description
Replay all selected records	Replays the sequence of records specified by Start and Stop on the Select data records tab.
Loop overall selected records	Replays the sequence of records specified by Start and Stop on the Select data records tab continuously.
Replay current record	Replays the currently selected acquisition (or frame).
Replay from selected	Displays a submenu that you use to specify which records are to be replayed.
First record	Replays the first record within the selected set.
Previous	Replays the previous record within the selected set.
Next	Replays the next record within the selected set.
Last record	Replays the last record within the selected set.
Pause	Suspends replay of the data records as soon as the current record's replay action is completed. Press Pause again to begin replay with the next record in the sequence.
Stop	Halts the replay of acquisitions. If replay is started after Stop has been selected, replay starts from the first acquisition.
Select all	Selects all acquisitions for replay.
Select records from history	Displays the Select data records tab of the Replay control panel. Use the Select data records tab to specify which acquisitions and frames you would like to replay.
Replay toolbar	Displays or hides the Replay toolbar.

## Acq Data

Selecting **Acq Data** selects acquisition data as the source for replay. Selecting Acq Data does not start replay, it only selects the type of acquisition data that will be replayed.

## DPX Spectra

Selecting **DPX Spectra** selects DPX spectra as the source for replay. Selecting DPX Spectra does not start replay, it only selects the type of acquisition data that will be replayed.

## Replay All Selected Records

Selecting **Replay all selected records** replays all the selected data records. The set of selected records may comprise a single record, all records in acquisition history, or a subset of the records in history.

## Replay Current Record

Selecting **Replay current record** replays the current data record. You can identify the current acquisition record by looking at the Replay toolbar. The first number to the right of the Select button identifies the current data record. For example, if the number is 2:10, it means the current record is the tenth frame of the second acquisition in history.

## Replay from Selected

Select **Replay from selected** to replay records as selected from the submenu. The records replayed can be from the acquisition memory (history) or from a saved acquisition data file that has already been recalled as the current acquisition data.

## Pause

Select Pause to suspend playback. Selecting Pause again restarts the replay at the point it was paused.

## Stop

Select **Stop** to halt the replay of data. Selecting any Replay action restarts replay of records from the beginning.

## Select All

Select **Select all** to select all data records for replay.

## Select Records from History











Selecting **Select records from history** displays the **Select data records** tab of the **Replay** control panel. The Select data records tab allows you to specify which records in the acquisition history will be used when the Replay button is selected.


# Replay Toolbar

Displays or hides the Replay toolbar that appears below the main tool bar.



Replay toolbar

Item	Description
Replay	Selects data type to be replayed. Select DPX Spectra to replay a DPXogram. Select Acq Data for all other types of replay.
	Replays the first record in the selected set.
	Replays the previous record in the selected set.
	Replays the current record in the selected set.
	Replays the next record in the selected set.
	Replays the last record in the selected set.
	Replays all records in the selected set.
	Replays all records in the selected set continuously until stopped.
	Pauses replay. Pressing pause suspends replay with the current record. Selecting pause again starts Replay with the next record.
	Stops replay. Starting any replay action after pressing stop starts a new Replay action rather than continuing from the record at which the previous replay action was stopped.
	Clicking <b>Select All</b> selects all records in history for replay. Selecting Select all resets the <b>Start</b> and <b>Stop</b> values on the Select data records tab of the Replay control panel.

Item		Description
		<p>Clicking the <b>Define</b> button displays the Define Replay control panel. The Acquisition Info tab displays information about the acquisition data such as acquisition bandwidth, sampling rate and acquisition length. All data records in the acquisition history were acquired with identical parameters. When any of these parameters are changed, all records in history are deleted as soon as the first record acquired under the new parameter values is received.</p> <p>You can also view and use the Select data records tab, Select DPX Spectra tab, and Replay Speed tab.</p>
1:10	3/10/2010 4:47:51.74	This readout shows information about the data record being replayed. The information displayed shows the acquisition and frame number and time stamp for the current data record.




## Amplitude Settings

**Main menu Bar:** Setup > Amplitude

**Favorites toolbar:** 


The Amplitude control panel provides access to power-related settings that are used by all displays within the SignalVu-PC application.



Setting	Description
<a href="#">Internal Settings (see page 759)</a>	Sets the parameters that control the acquisition of the signal.
<a href="#">External Gain/Loss Correction (see page 760)</a>	Specifies whether a correction is applied to the signal to compensate for the use of external equipment.

## Internal Settings Tab

When connected to an RSA500A Series, RSA600A Series, or RSA7100A, the Internal Settings tab is available from the Amplitude Settings control panel. From this tab, you can specify the Reference Level for the signal analyzer's RF front end. Depending on which instrument is connected, you may also be able to access the settings for the internal attenuator, and enable/disable the optional internal preamp. The following image shows the tab as it appears when an RSA500A Series instrument is connected.



### Ref Level

The reference level can be set for the RF Input of the connected instrument.

### Internal Attenuator

The Internal Attenuator setting can be set to Auto or Manual. When Auto mode is enabled, the attenuation setting is displayed but is not adjustable. When Auto is disabled, the attenuator operates in manual mode, allowing you to set the internal attenuation. The internal attenuation setting range varies depending on the instrument in use.

### Internal Preamp

Use this setting to switch the preamp on or off.

---

**NOTE.** *To ensure the best accuracy, thermally stabilize before taking critical measurements.*

---

## External Gain/Loss Correction Tab

The External Gain/Loss Correction tab allows you to apply a correction to a signal to compensate for the use of external equipment, such as an amplifier or attenuator. You can specify whether the corrections on this tab apply to all acquired data or only to a set group of displays. You can also apply external corrections to traces in the Spectrum, Spectrogram, Spurious, and Amplitude vs Time displays.

### External Gain Value

Use the External Gain Value setting to apply a flat gain/loss correction to the signal. Positive values represent a gain and negative values represent a loss. The range is –80 to +50 dB. Resolution is 0.1 dB.

---

**NOTE.** *Selecting Preset clears the check box, but it does not change the value.*

---

### Apply External Corrections To

Use the two selections to specify how the enabled external loss tables are applied.



1. **All acquired data (filter method):** This selection applies corrections to all acquired data.
2. **Traces in applicable displays:** This selection applies corrections only to traces in the Spectrum, Spectrogram, Spurious, and Amplitude vs Time displays. Note that the loss at the center frequency is the correction applied to the Amp vs Time display.

When choosing whether to correct sample data or traces, keep the following in mind:

- If sample data is acquired while data correction is enabled, that data record is permanently corrected. If the acquisition is saved and recalled, the recalled acquisition includes corrections. Corrections are not saved separately from the raw data; they are used during the acquisition process to adjust the data values.
- Trace corrections can be applied at any time, as they are part of the measurement's computations. Using Replay will apply trace corrections to a trace if this control is enabled (and an external loss table is specified and enabled).
- Be aware that if you recall acquisition data that was saved with data corrections and you use Replay with trace corrections selected and an external loss table enabled, the trace will be calculated using corrected data and also corrected with trace corrections. This probably creates incorrect traces.
- Triggering operates on uncorrected acquisition data. Frequency masks and trigger level lines in the displays are also not corrected, so there is a visual discrepancy between data traces and trigger indicators in the graphs under this condition.

### Trace Corrections Versus Data Corrections

Because of the real-time nature of the analyzer and desire to frequently reanalyze stored acquisitions, it is possible to apply amplitude corrections in real time. Applying real-time corrections to the incoming data means that, the correction factors present during the acquisition are already part of the data when the data is stored and then reanalyzed. This also allows the DPX display to maintain its update rate while presenting an amplitude-corrected display.

Real-time gain/loss factors are applied by creating a correction filter that is applied by the same digital signal processing used to correct for calibration and alignment factors in the instrument. This process does have limitations. In creating a digital filter to represent the gain/loss table, a limited number of filter taps are used in order for the filter to be practically realizable. If your amplitude corrections contain discontinuities or extremely sharp transitions, the filter used will contain errors and ringing.

If the above is the case, we recommend that you use trace corrections. These are very similar to a conventional spectrum analyzer, and may be applied to the Spectrum, Spectrogram, Spurious search and Amplitude vs. Time displays. These traces may contain transitions of any type within the maximum and minimum correction values allowed in the tables.

## External Loss Tables

Use an External Loss Table to apply a frequency dependent gain/loss correction to the signal. When an External Loss Table is selected, the analyzer adjusts the signal according to the values in the table. An external loss table allows you to compensate the signal level for variations in cable loss, antenna frequency response or preamp frequency response.

You can create external loss tables from the analyzer application and save them as files. External loss tables are saved as plain text files in CSV (Comma Separated Value) format. The tables have a CSV file extension.

You can change the title for each table. However, note that the title is only a label. It is not tied to the file name of any table you may have loaded or saved.

---

**NOTE.** *If you are using an External Loss Table for antenna corrections, be sure to set the Amplitude units (Setup > Analysis > Units) to dBuA/m or dBuV/m.*


---

## Creating an External Loss Table

You can create an external loss table with the analyzer application. No external application is required.

To create an external loss table:

1. Click **Edit.** to display the Table Editor.



2. Click **New Table** to create a table. This clears all entries in the existing table and loads the default table.

3. To edit values in the table:

- a. To edit an existing value, double-click on the cell you want to edit.
- b. To add a new point to the table, click on **Add Point**. Edit the values as required.
- c. Click **Apply** if you want to test your table without closing the editor (the table must be enabled with the check box in the control panel and measurements must already be running).

To specify a frequency multiplier, you can type K, M, or G.

4. To delete a point from the table, select the point to be removed, and click **Delete**.

5. Select the Frequency Interpolation method:
  - Select Linear when the frequency scale of the spectrum or spurious measurements are linear.
  - Select Log when the frequency scale of the spectrum is logarithmic.
6. When you have entered all the necessary values, click **Save As** (to save the table in a file) or click **OK**.
7. From the Save As dialog, name the file and save it in the desired location.

External loss tables are saved in CSV (Comma Separated Value) format.

### Loading an External Loss Table

To load an external loss table file:

1. Click **Edit** to display the Table Editor.
2. Click **Load** to display the Open dialog box.
3. Navigate to the location of the desired file, select it and click Open.
4. Click **OK**.



## Continuous Versus Single Sequence

**Menu Bar:** Run > Single Sequence / Continuous

---

**NOTE.** *SignalVu-PC must be connected to an instrument to display the Run menu.*

---

Selecting **Single Sequence** sets the acquisition mode so that when you press Run, a single acquisition sequence is performed and the instrument stops once the acquisition sequence is completed. Selecting **Continuous** sets the acquisition mode so that an acquisition sequence is started as soon as you select Continuous and as one acquisition sequence completes, another begins.

Note that an acquisition sequence can require more than one acquisition. For example, in a spectrum view, the trace function might be set to Average 100 acquisitions. Thus, a complete acquisition sequence would consist of 100 acquisitions that are averaged together to create the trace that is displayed.

## Run

**Menu Bar:** Run > Run

**Favorites Bar:** Run

Selecting **Run** begins a new acquisition/measurement cycle.

---

**NOTE.** *SignalVu-PC must be connected to an instrument to display the Run menu.*

---

## Resume

**Favorites Bar:** Run > Resume

Restarts data acquisition, but does not reset accumulated results, such as Average or MaxHold. This allows you to stop acquisitions temporarily, then continue. If the accumulation is already complete, for example, 10 acquisitions or 10 averages have already been completed, each subsequent Resume command will cause one more acquisition to be taken, and its results added to the accumulation. Not available if instrument settings have been changed.

---

**NOTE.** *SignalVu-PC must be connected to an instrument to display the Run menu.*

---

# Abort

**Favorites Toolbar:** Run > Abort

Selecting **Abort** immediately halts the current acquisition/measurement cycle. In-process measurements and acquisitions are not allowed to complete. Visibility and accuracy of results is unspecified after an abort.


**NOTE.** *SignalVu-PC must be connected to an instrument to display the Run menu.*

# Acquire

**Main menu:** Setup > Acquire

**Favorites Toolbar:** 

Selecting **Acquire** displays the Acquire control panel. The tabs available on this panel vary depending on the connected instruments. This panel enables you to change sampling parameters, view sample rate, view record length, configure frequency reference and timing reference.



**Signal Input.** The Signal Input control can be used when an instrument is connected. The I & Q and Diff I & Q input selections are only valid when an MDO4000B/C is connected.

Setting	Description
<a href="#">IQ Sampling Parameters (see page 767)</a>	Enables you to set the controls for real-time acquisition.
<a href="#">Acquisition Data (see page 768)</a> (Only available when an instrument is not connected)	Displays the sample rate and record length reported by the analyzer.
<a href="#">Advanced (see page 772)</a> (Only available when an RSA7100A is connected)	Enables you to set the preselector state to control image suppression.

Setting	Description
<a href="#">Frequency Reference (see page 770)</a> (Only available when an instrument is connected)	Specifies the source for the frequency reference.
<a href="#">Timing Reference (see page 772)</a> (Only available when an RSA7100A with Option GPS and an IRIG-B connector is connected)	Specifies the source for the timing reference (GPS, PPS, System, IRIG-B AM, or IRIG-B DC).

## IQ Sampling Parameters

The IQ Sampling Parameters tab enables you to set the controls for real-time acquisition. Normally, the best results are achieved by leaving the Adjust control set to the recommended setting of All Auto. This allows the settings to be automatically adjusted for selected measurements.

Depending on the setting chosen for Adjust, two additional parameters can be set.

Acquire

Signal Input: RF

**IQ Sampling Parameters** | Acquisition Data

Adjust: All Auto (recommended)

Acq BW: 2.00 MHz

Acq Length: 406.036 us

Samples: 2.03 kSamples

5.00 MS/s  
200 nsec/Sample

Capacity: 0 s  
0.000 Samples

Using: 406 us, 2.03 kSamples, --- % of capacity

☐ FastFrame

Max frames: 1

Actual: 0

Adjust	User Sets	Analyzer Calculates
All Auto	N /A	N /A
Acq BW / Acq Samples	Acq BW	Acq Samples
Acq BW / Acq Length	Acq BW	Acquisition Length

### Acquisition Memory Usage

The center portion of the tab shows how the acquisition memory is used.

Readout	Description
Samples/s, sec/Sample	Readout of the acquisition sample rate and sample period.
Capacity	The maximum period of time and number of samples that can be acquired with the current sampling parameters.
Using	The total amount of acquisition memory that will be used based on the current settings.

## Fast Frame

Fast Frame is a feature that allows you to segment the acquisition record into a series of frames, or data records. A typical use of Fast Frame is to record data samples around signal events of interest, while not wasting memory on irrelevant data between these events. Fast Frame is only valid for real-time acquisitions. If any measurement is configured for swept acquisitions, the following error message is displayed: *Disabled: Fast Frame does not support swept settings.*

**NOTE.** Fast Frame is only available when an RSA7100A is connected.

The screenshot shows the 'Acquire' window with the 'Fast Frame' sub-window open. The 'Fast Frame' checkbox is checked. The 'Max frames' is set to 1, and the 'Actual' value is 1. The 'Acquire' window also shows 'Run: Single' and 'Acquire' parameters: Adjust: All Auto (recommen...), Acq BW: 40.00 MHz, Acq Length: 225.002 us, Samples: 14.1 kSamples. The 'Fast Frame' window also displays: 62.5 MS/s, 16.0 nsec/Sample, Capacity: 0 s, 0.000 Samples, and Using: 225 us, 14.1 kSamples, --- % of capacity.

Setting	Description
Fast Frame	Enables Fast Frame acquisition mode when box is checked.
Max frames	Specifies the maximum number of frames to record in a single acquisition process.
Actual	Shows the actual number of frames that will be acquired into the acquisition memory. This number changes based on the Acq BW, Acq Samples, and Acq Length values. This number will never be greater than the value set by Max frames.

## Acquisition Data

The Acquisition Data tab lists the Sample Rate and Record length of the recalled acquisition data file. This tab is only available when not connected to an instrument.


The screenshot shows the 'Acquire' window with the 'Acquisition Data' tab selected. The 'Signal Input' is set to 'RF'. The 'Sample Rate' is displayed as '-- S/s' and the 'Record Length' is displayed as '-- Samples'.



## Advanced

The Advanced tab is available only when an RSA7100A is connected. It contains the preselector setting. The preselector uses input filters for image suppression when the span of the instrument allows for their use.

Two methods of preselection are used in the RSA7100A: a fixed low-pass filter (LPF) and a tunable bandpass filter (BPF). Due to the narrow-band nature of the tuned BPF, it is necessary to bypass this filter for wideband analysis of signals with bandwidth >50 MHz. The tuned BPF preselector is enabled depending on the acquisition mode (swept or real-time), frequency range, and user selection of preselector state (Auto, On, Off). The LPF preselector is naturally wideband, so that filter is always present, even when the preselector Off mode is manually selected.



Preselector setting	Description
Auto	<p>This setting balances maximizing acquisition bandwidth with image suppression. The analyzer will operate up to its maximum acquisition bandwidth and may turn off the uWave preselector to accommodate this. When the requested span exceeds the acquisition bandwidth, the uWave preselector is engaged and the step size used is 50 MHz/step.</p> <p>This is the default setting.</p>
On	<p>This setting sets the preselector to always be on, independent of span. When the span exceeds 50 MHz, the instrument is stepped in frequency to create the display.</p>
Off	<p>This setting bypasses the preselector filters (except for the LPF, which is always present) when the span is greater than the allowed acquisition bandwidth. The maximum available real time span is equal to the maximum available acquisition bandwidth at the selected frequency. When the span of the analysis exceeds the available acquisition bandwidth for the selected frequency, the step size of the sweep is set to 320 MHz.</p>

The following table shows the preselector state by acquisition mode.

Acquisition mode	Auto	On	Off
Swept, 50 MHz steps	On	On	CF $\leq$ 3.6 GHz: On CF > 3.6 GHz: Off
Swept, 320 MHz steps	Not applicable	Not applicable	CF $\leq$ 3.41 GHz: On CF > 3.41 GHz: Off
Real time span $\leq$ 50 MHz	On	On	CF $\leq$ 3.6 GHz: On CF > 3.6 GHz: Off
Real time span > 50 MHz	CF $\leq$ 3.41 GHz: On CF > 3.41 GHz: Off	Not applicable	CF $\leq$ 3.41 GHz: On CF > 3.41 GHz: Off

## Frequency Reference

This tab is only available when an RSA306B, RSA500A series, RSA600A series, or RSA7100A instrument is connected. Available selections depend on which instrument is connected.


The screenshot shows the 'Frequency Reference' tab selected. Below the tab name is a 'Source' section with four radio button options: 'Internal' (which is selected), 'External (10 MHz)', 'GNSS', and 'User: No Valid Data'. To the right of the 'GNSS' and 'User' options is a 'Set User' button.


Setting	Description
Internal	Uses the internal 10 MHz clock of the connected instrument as the reference frequency.
External	<p>For the RSA306, RSA306B, and RSA7100A instruments, 10 MHz is the only allowed reference.</p> <p>For the RSA500A series and RSA600A series instruments, a broad selection of external reference frequencies are allowed. If you select External, the instrument will auto-detect the external reference and attempt to lock to this reference if it falls within acceptable accuracy range of the "defined" frequencies. If no external signal is detected, or the instrument cannot lock to the connected signal, it will revert back to Internal reference after displaying a dialog box indicating it could not lock.</p>
GNSS (Only available when an RSA500A series, RSA600A series, or RSA7100A instrument is connected.)	<p>Selectable when GNSS is enabled from Setup &gt; <a href="#">GNSS/Antenna (see page 795)</a>.</p> <p>When selected, the analyzer will use timing signals from the internal GNSS receiver to align the internal 10 MHz clock frequency to GNSS reference. Clock frequency adjustment status is shown as one of the following states:</p> <ul style="list-style-type: none"> <li>- Acquiring: Waiting for GNSS receiver lock and performing initial clock frequency adjustment.</li> <li>- Tracking: Updating clock frequency adjustment while GNSS receiver is locked.</li> <li>- Holding: Maintaining last clock frequency adjustment when GNSS receiver is unlocked.</li> </ul> <p>If Frequency Reference is changed to another selection, the GNSS-derived clock adjustment is discarded and will restart from the original value if GNSS is reselected.</p> <p>When the GNSS status is Tracking or Holding, click the Set User button to store the current GNSS-derived clock adjustment information in the User setting. The User setting can then be selected as the Frequency Reference source at any time.</p> <p>In Tracking state, the status also includes the quality of the clock correction relative to GNSS timing, as indicated by the following:</p> <ul style="list-style-type: none"> <li>- Low: Clock error is greater than <math>\pm 200 \times 10^{-9}</math></li> <li>- Medium: Clock error is less than <math>\pm 200 \times 10^{-9}</math></li> <li>- High: Clock error is less than <math>\pm 25 \times 10^{-9}</math></li> </ul> <p>Once the status is Holding, a date/time stamp will show next to User (see following setting) and that setting will become selectable.</p>
User (Only available when an RSA500A series or RSA600A series instrument is connected.)	Selectable when a GNSS frequency reference setting has been saved with the Set User button. The date and time at which the setting was saved are displayed. This setting is the default setting for this tab if a valid User setting has been saved. The User setting information is stored on the PC and so will not be available if the device is connected to a different PC.
Set User button (Only available when an RSA500A series or RSA600A series instrument is connected.)	This button is available when a GNSS acquired frequency reference has been acquired after selecting GNSS. Clicking this button saves the frequency reference and enables the User setting.

**TIP.** See the [Features by product \(see page 14\)](#) topic for more information about which features are available with which connected analyzers.

## Timing Reference

The Timing Reference tab is part of the Acquire control panel. It is only available when an RSA7100A with Option GPS is connected (units with an IRIG-B connector). This tab allows you to specify the following sources for the timing reference.



Setting	Description
GPS	Specifies the timing reference for GPS from the <b>GPS/Antenna</b> connector on the instrument front panel.  Click the  icon or select <b>Setup &gt;GNSS/Antenna</b> from the Main menu bar of the SignalVu-PC application to access the GNSS and Antenna tabs in the GNSS/Antenna control panel. From there you can set GNSS source and baud rate and antenna settings.
PPS	Specifies the timing reference for PPS (Pulse Per Second) from the <b>1 PPS</b> connector on the instrument front panel. The time code of that signal is used to set the time of SignalVu-PC.
System	Set the timing reference to local PC time. This is the default setting.
IRIG-B AM	When an IRIG-B signal is connected to the instrument using the <b>IRIG-B</b> connector on the front panel, the system first checks if an IRIG-B AM signal is present. If detected, the time code of that signal is used to set the time of SignalVu-PC.
IRIG-B DC	When an IRIG-B signal is connected to the instrument using the <b>IRIG-B</b> connector on the front panel, the system first checks if an IRIG-B DC signal is present. If detected, the time code of that signal is used to set the time of SignalVu-PC.

### Time stamps and timing reference sources

- The default timing reference source upon launch of SignalVu-PC is system time.
- If you change the source in the Timing Reference tab in the UI from default to one of the externally generated sources (GPS, PPS, IRIG-B) without a valid signal, the time will remain system time.
- If you set the source to GPS, PPS, or IRIG-B after launch of SignalVu-PC (thus changing the time from the default system time), and then disconnect from that source or otherwise lose the lock to that source, the time used will be that of the previous externally generated source. This will remain so until you set a different source with a valid signal.

GPS, PPS, and IRIG-B sources will update the xmrk file to include the following parameters: timestamp\_source to indicate last valid signal type, event\_code to indicate software\_marker, and each signal pulse to be noted with a time and sample number. All other event codes, such as triggers and acquisition status events, will reference the last valid external timing reference signal.

### Stored information

When recording with the XCOM format selected, a marker file (.xmrk) is generated that lists time, location (GPS only), and the time stamp of the GPS, PPS, or IRIG-B event during recording. You can read more about file formats and what they contain in the [Saved File Types \(see page 840\)](#) and the [Record Setup \(see page 774\)](#) topics.

### IRIG-B signals

You can use the IRIG-B connector on the RSA7100A to connect to an IRIG-B signal generator. SignalVu-PC allows you to select one of two IRIG-200-04 standard signals to use for timing reference. IRIG-B is the standard for 1 kHz IRIG signals with frame lengths of 1 second. SignalVu-PC can detect IRIG-B AM and DC signals.

- IRIG-B detection is only available on RSA7100A units with Option GPS and an **IRIG-B** connector.
- When switching from any time reference to IRIG-B, it takes several seconds for the time to update with a valid signal.

### PPS signals

A PPS (Pulse Per Second) source can be used as a timing reference to sync multiple devices. You can use the 1 PPS connector on the RSA7100A to sync the RSA7100A to a source.

- The PPS selection is only available on RSA7100A units with Option GPS and a **1 PPS** connector.

## The Recording Control Panel

**Main menu:** Setup > Recording

**Favorites toolbar:** 

Selecting **Recording** displays the Recording control panel. This panel contains tabs that allow you to access the functions in the following table. You can play back recorded files with an optional playback feature. Playback can only play files that were recorded using the Formatted data structure, although you can use other applications, such as MATLAB, to read files recorded in any of the file formats..

Playback of recorded files is available for the RSA7100A when using an external application. The Playback feature described in this topic is not available for use with the RSA7100A. You can read more about file formats used by the RSA7100A [here](#).

You can purchase Option SV56-SVPC to enable the Playback tab when connected to the RSA306, RSA306B, and RSA500A and RSA600A series instruments.

Tab	Description
<a href="#">Record Setup (see page 774)</a>	Enables you to define the save location, base filename, and data structure of the recording.
<a href="#">Record (see page 777)</a>	Records the acquisition data directly to a file.
<a href="#">Playback (see page 780)</a> (Requires Option SV56-SVPC) (Not available on the RSA7100A.)	Plays the saved files recorded with the Record feature. Playback only plays .r3f file formats.

**TIP.** See the [Features by product \(see page 14\)](#) topic for more information about which features are available with which connected analyzers.

## Record Setup

The above image shows the Record Setup tab when a RSA306B, RSA500A Series, or RSA600A Series is connected.



The above image shows the Record Setup tab when a RSA7100A is connected.

The Record Setup tab allows you to set the following:

#### Setting

Location	Sets the destination folder or directory for the recorded file(s).
Base file name	Enter a base name that will be used for all recorded files. This base name is appended with additional information, creating unique file names.
File format (Only available when a RSA is connected)	Choose the output data file format. Files created with the Recording feature: Raw recordings contain instrument setting and other information in a separate file from the raw ADC samples. Formatted recording files contain all information in a single file. If you are using the RSA306, RSA306B, RSA500A series, or RSA600A series, the API programming manual has more detailed information about the data files created with the Recording feature.
Formatted (R3F) (Not available for the RSA7100A)	Formatted files for IF data are created, ending with a .r3f suffix, and contain a single Header info block, followed by blocks of data and status information. Each data block is called a frame which is 16384 bytes (16 kB) in size. Formatted files can only contain complete frames.
Raw (R3H+R3A) (Not available for the RSA7100A)	Unformatted files for IF data are created. Raw recordings contain instrument setting and other information in a separate file from the raw ADC samples. Two files are created for each recording, a header file (.r3h) and the raw data file (.r3a). Raw data files contain only ADC samples. The samples are contiguous, with all transport frame information removed before storage. The header file, if available, contains the Config data which can be used to interpret and scale the ADC data samples for further processing.
XCOM (RSA7100A only)	Generates 3 output files (all with the same file name) for each recording run. The files are as follows: <b>.xdar</b> : sample data file containing binary IQ samples in normal (16 bit integer) or packed (12-bit integer) data type. <b>.xhdr</b> : header file containing instrument setup information in XML format. <b>.xmkr</b> : marker file in XML format containing time, location (GPS only), and the time stamp of the GPS, PPS, or IRIG-B event during recording.

**Setting**

Midas 2.0 (CDIF)	<p>Generates a combined file (.cdif) containing header and data samples in Midas 2.0 (Platinum BLUE) format. Uncorrected IF samples are stored by the RSA306B, RSA500A and RSA600A. Corrected IQ samples are stored by the RSA7100A.</p> <p>When using the RSA7100A, recordings cannot be saved as CDIF for acquisition bandwidths above 320 MHz with the packed data setting on.</p> <p>See the <a href="#">Midas recording choices</a> table for more information.</p>
Midas 2.0 Detached (CDIF+DET)	<p>Generates separate header (.cdif) and sample data (.det) files in Midas 2.0 (Platinum BLUE) format. Uncorrected IF samples are stored by the RSA306B, RSA500A and RSA600A. Corrected IQ samples are stored by the RSA7100A.</p> <p>When using the RSA7100A, recordings for acquisition bandwidths above 320 MHz with the packed data setting on will generate a .cdif and a .det12 file.</p> <p>See the <a href="#">Midas recording choices</a> table for more information.</p>
Acq BW	<p>Shows the current acquisition bandwidth. Check the Auto box to automatically set this value. Uncheck the Auto box to set it manually.</p>
Data packed at 12 bits/sample for 800 MHz BW (RSA7100A only)	<p>For acquisition bandwidths above 320 MHz, data is packed at 12 bits/sample to avoid gaps in the streamed recording. If you require 16-bit samples, uncheck the box.</p> <p>You can convert 12-bit data to 16 bits/sample using the <a href="#">unpacking utility</a>. Streaming unpacked data at 800 MHz bandwidth may result in occasional small gaps in the recording.</p>

**NOTE.** You can read about the formatted data structure (.xcom) for files recorded using the RSA7100A in the [Data Settings and Picture File Formats](#) topic.

**Midas recording choices table**

Acquisition bandwidth	Sample bitwidth	Combined file	Detached file
≤320 MHz	16b	Yes (.cdif)	Yes (.cdif + .det)
800 MHz	16b	Yes (.cdif)	Yes (.cdif + .det)
(> 320 MHz (CF > 3.6 GHz, RSA7100A only)	12b	No	Yes (.cdif + .det12) <sup>1</sup>


<sup>1</sup> Use the unpacking utility to convert a 12-bit .det12 file to a 16-bit .det file.

**Unpacking saved files to RAID in the RSA7100A**

You can convert 12 bits/sample data to 16 bits/sample using the unpacking utility.

1. Open a command prompt in Windows from the CTRL7100A.
2. Type the location of the file you want to unpack.
3. Type **unpack** after the command prompt. You will then see a usage command with arguments after it.





4. After the next command prompt, type the following:
  - a. **unpack**
  - b. Input file name (the file you want to unpack). For example, **packed.xdat**.
  - c. Enter a space using the spacebar.
  - d. Output file name (the unpacked file you are saving). For example, **unpacked.xdat**. This must be an .xdat file type. You can also specify a location to which the file is saved.
5. If desired, enter an output file size. If the output size is smaller than the input size, the output file will contain the first portion of the input file up to the specified file size.
6. Press the Enter key to execute the command.
7. Navigate to the location to the unpacked file.


## Record

The recording feature lets you record the acquisition data directly to a file. Selections on this tab vary depending on the connected instrument.


---

**NOTE.** *SignalVu-PC does not accept changes while recording is active. Stop the current recording session to change settings. Changing settings during streaming will result in start of a new streaming file.*


---



The above image shows the Record tab when Record Time is selected (when the RSA500A series, RSA600A series, or RSA306B is connected).



The above image shows the Record tab when Record Time is not selected (when the RSA500A series, RSA600A series, or RSA306B is connected).



The above image shows the Record tab when the RSA7100A is connected.


The Record tab allows you to set the following:

#### Setting

##### Record to disk:

Record now	<p>Data recording starts immediately when the Start button is pressed. Data is continuously recorded until either stopped by the Start (Stop) button or the Record Time condition is met.</p> <p>If Record Time is enabled, then pressing the Start button will result in creating the specified number of files (Files per run), each of the specified length (Record Time).</p> <p>If Record Time is disabled, only one file is saved and recording continues until the Stop button is pressed (or the specified save location runs out of space).</p>
Record on trigger	<p>Data recording starts when an appropriate trigger signal is received (triggering must be separately enabled in the Trigger control panel).</p> <p>If Record Time is enabled, then pressing the Start button will result in creating one file per trigger for the specified number of files (Files per run), each of the specified length (Record Time).</p> <p>If Record Time is disabled, only one file is saved and recording continues until the Stop button is pressed (or the specified save location runs out of space).</p>
Start	<p>The Start button is enabled when the Record to disk is set to Record now or when Triggering is enabled and Record to disk is set to Record on Trigger. Pressing Start begins the data recording. The button changes to Stop and recording continues until pressed or the Record Time condition is met.</p>

**Setting**

Files per run	<p>This determines how many files are created of the specified Record Time length.</p> <p>If Record Time is disabled, then this setting is ignored and only one file is recorded when Start is pressed.</p> <p>Maximum number of files per run is 1 million.</p>
RAID system health (RSA7100A only)	<p>Launches an application that allows you to view the % life remaining (i.e., number of writes left to the drive) in each installed RAID drive. This application must be run as an Administrator. When the application launches, click the Query System Health button to run the query and view the results.</p>  <p>Click on an Identify button to light the LED next to the specific drive on the CTRL7100A.</p>
Record Time:	<p>Record Time is enabled by default. This determines how much data (time in milliseconds, seconds, or minutes) is recorded after recording starts.</p> <p>Disabling Record Time allows the recording to continue until the Stop button is pressed (or the specified save location runs out of space).</p>
File size	<p>Indicates the size of each recorded file. This item is only displayed when Record Time is enabled.</p>
Max Record Time	<p>Indicates the maximum length of the record time based on available disk space. This setting indicates the longest Record Time possible with current acquisition settings and Available Disk Space.</p> <p>This item is only displayed when Record Time is disabled.</p>
Available Disk Space	<p>Indicates the amount of disk space available for recording.</p>
<b>Status</b>	
(RSA7100A only)	
Progress	<p>Indicates the current progress of the recording.</p>
Files recorded	<p>Indicates how many of the selected number of files to record per run have been recorded.</p>
Dropped Frame	<p>Indicates a missed frame has been detected in the recording.</p> <p>The Marker file (.xmrk) indicates the sample in which the Dropped Frame is detected. If the recording is done using the unpack data format and the acquisition bandwidth is equal to 800 MHz, you can select the packed data format to reduce Dropped Frame.</p>
Input Overload	<p>Indicates if an overload has been detected in the record.</p> <p>The Marker file (.xmrk) indicates the sample in which the Input Overload is detected. You can increase the reference level to avoid Input Overload.</p>

---

**NOTE.** The record feature is best suited for PCs using a solid-state drive (SSD) to achieve the read/write speeds necessary for best performance. Recording performance will be degraded on PCs with slower drives.

---

## Playback


Playback lets you play acquisition files that were recorded with SignalVu-PC's recording feature. Recorded files for the RSA306, RSA306B, RSA500 series, and RSA600 series have a .r3f file extension and only these file types can be played with the Playback feature (Option SV56-SVPC).

The Playback option described in this topic is not available for use with the RSA7100A, though playback of recorded files from the RSA7100A can be done using an external application. You can read more about file formats used in recording with the RSA7100A [here](#).

---

**NOTE.** The playback feature is best suited for PCs using a solid-state drive (SSD) to achieve the read/write speeds necessary for best playback performance. Playback performance will be degraded on PCs with slower drives.


---

If an instrument is connected through the Connect feature, you must first click the Stop button on the Playback tab to enable Playback. SignalVu-PC acquires and analyzes the data of a recorded file as if it were obtaining data from an instrument. Therefore, once you enable Playback, SignalVu-PC disconnects the currently connected instrument. However, the connection indicator will still display as green (  ) because the analyzer treats the playback file as live data acquisition. The Run/Stop toolbar remains active, allowing you to stop and start the playback of the selected file (like the Stop and Play button in the Playback screen).

---

**NOTE.** Most controls in the Playback tab are not active while acquiring live data from a connected instrument. The only control available is the Stop button, which will halt the acquisition of data from the connected instrument. Once acquisition has stopped, the Playback controls become active.

---



The screenshot shows the 'Playback' tab of the SignalVu-PC software interface. At the top, there are three tabs: 'Record Setup', 'Record', and 'Playback'. The 'Playback' tab is selected. Below the tabs, there is a 'Location:' label followed by a text field containing a file path. To the right of the text field is a button with three dots. Below the 'Location' field, there are two rows of controls. The first row has 'Skip:' followed by a text field with '0', 'Units:' followed by a dropdown menu showing 'µs', and a checkbox labeled 'Live rate'. The second row has a checkbox labeled 'Loop file'. To the right of these controls, there is a 'Progress' bar at 0%, a 'Range (%)' slider, and two input fields for 'Begin' (0) and 'End' (100). At the bottom, there are two buttons: 'Play' and 'Exit Playback'.

<b>Setting</b>	
Location:	Navigate to the location of the recorded file(s).  <b>NOTE.</b> You can also use the File > Recall menu to navigate to recorded files. You must set the file type (to search for) to ADC sample data (.r3f).
Skip:	Defines the amount of time skipped between frames of the playback data.  For long recordings, this allows you to skip portions of the data, allowing you to perform a coarser analysis, but much quicker.  The amount of skip cannot be less than the defined acquisition length. The resolution for setting the skip is one USB frame (73 $\mu$ s).
Units:	Defines the units of the Skip setting ( $\mu$ sec, msec, seconds).
Live rate	This setting forces SignalVu_PC to attempt to play the file at the same rate as when it was acquired, making the playback operation appear to be identical to having the instrument connected.  This setting is very useful when listening to audio.
Loop file	When selected, the file selected for playback continues to loop until playback is stopped.  If only a portion of the file is selected for playback (with the Begin and End sliders) only that portion is looped.
<b>Playback fields</b>	
Progress	Provides an indication of the current status of the file being played.
Begin	Use the Begin slider to choose a starting point within the recorded file to begin playback.
End	Use the End slider to choose an end point within the recorded file to stop the playback.
Stop/Play	This button toggles between Stop and Play.  <b>NOTE.</b> The Run/Stop toolbar in the SignalVu-PC application also performs the same functions as the Stop/Play button in the Playback screen.
Stop	Stop is displayed while a recorded data file is being played. Pressing Stop halts the playback operation.  Stop is also displayed if SignalVu-PC is currently connected to an instrument. Pressing Stop stops the acquisition of data from the instrument.  No changes can be made to playback while Stop is displayed.
Play	Pressing Play starts payout of the file defined in the Location field.  If SignalVu-PC is connected to an instrument, acquisition of data from the instrument is stopped before the file starts to play.
Exit Playback	Exits the playback mode, disconnecting the recorded file (and the connected status indicates no connection).  After you exit playback, you can replay the currently selected file, choose another file to play, or reestablish a connection to an instrument.

## Triggering

Triggering is available in SignalVu-PC when connected to an RSA306, RSA306B, RSA500A series, RSA600A series, and RSA7100A Spectrum Analyzers or an MDO4000 Series oscilloscope. The analyzer has two triggering modes: Free Run and Triggered.

## Free Run

In Free Run mode, the instrument initiates acquisitions without considering any trigger conditions. It is a fast and easy way to see the signals. Free Run is usually adequate for the Spectrum display unless you need to specify a particular time at which to collect the data record.

## Triggered

In the Triggered mode, the instrument initiates an acquisition when a trigger event is recognized. The conditions that define a trigger event depend on the selected trigger source (RF Input, External, or Internal Time (Internal Time source not available on MDO4000 Series)). If RF Input is the selected trigger source, you can select from several trigger types (selections depend on connected instrument model). If other trigger sources are selected, you can set their trigger event qualification parameters.

**Power triggering.** Power triggering triggers the instrument on time-domain signal transitions. The incoming data is compared to a user-selected level in dBm. You can trigger on the rising or falling edge.

**Frequency mask triggering.** Frequency Mask Triggering allows you to trigger the instrument when a signal in the frequency domain violates the mask. You can draw a mask to define the conditions within the real-time bandwidth that will generate the trigger event. It allows you to trigger on weak signals in the presence of strong signals. This triggering is also useful for capturing intermittent signals.

**DPX Density triggering.** DPX Density triggering uses characteristics of the DPX display to specify trigger parameters. When using DPX Density triggering, the percentage of time the signal falls within the measurement box is used to define a trigger event. The measurement box is defined by frequency and amplitude values.


## Save on Trigger

An additional feature of the triggering capability is to save acquisition data when a trigger event occurs. When the analyzer is run in Triggered mode, you can configure the instrument to save acquisition data to a file. You can also set the instrument to save a picture of the screen when the trigger event occurs. See [Action Tab \(Triggering\) \(see page 794\)](#) for details on configuring Save on trigger.

## Setting Up Triggering

To set up triggering, use the Trigger control panel. To display the Trigger control panel:

- Click  on the Favorites toolbar or select **Setup > Trigger** to access the Trigger control panel.



Trigger

Event Advanced Actions

☐ Free Run

☒ Triggered

Force Trigger

☒ Save acq data on Trigger: TIQ (1 complete acquisition, not valid when swept)

☐ Save picture on Trigger: PNG

☐ Max total files saved per Run: 100

### Using Free Run

To set Triggering to Free Run:

- Click the **Free Run** option button.

The signal analyzer will acquire a signal without regard to any triggering conditions.

### Using Power Trigger

To trigger acquisitions based on the power of the signal:

1. Click the **Triggered** option button.
2. Select **RF Input** from the Source drop-down list.
3. Select **Power** from the **Type** drop-down list.
4. For further information on setting the power level parameters, see [Event Tab \(Triggering\)](#). (see [page 788](#))

### Using Frequency Mask Triggering

To trigger acquisitions based on violations of a user-defined mask:

1. Click the **Triggered** option button.
2. Select **RF Input** from the **Source** drop-down list.
3. Select **Frequency Mask** from the **Type** drop-down list.

For further information on setting the frequency mask parameters, see [Event Tab \(Triggering\)](#) (see [page 788](#)) and [Mask Editor](#) (see [page 784](#)). If Frequency Mask triggering is installed, you can change the resolution bandwidth of the frequency transform used to compare to the trigger mask. The standard FMT uses a fixed length FFT for frequency transforms.

### Using DPX Density Triggering

To trigger acquisitions based on the density of the DPX Bitmap trace, do the following.

1. Click the **Triggered** option button.
2. Select **RF Input** from the Source drop-down list.
3. Select **DPX Density** from the **Type** drop-down list.
4. Set the DPX Density parameters as appropriate. You can do this one of the following ways:
  - Check the **Show measurement** box in the Density tab of the DPX Settings control panel to view the measurement box in the display. Enter the Frequency and Amplitude in the Density tab.
  - Check the **Show measurement** box in the Density tab of the DPX Settings control panel to view the measurement box in the display. Use the mouse to move and size the measurement box that appears on the display to set the values for Frequency and Amplitude.

---

**NOTE.** *If the Amplitude units (Setup > Analysis > Units) is set to Watts or Volts, you cannot move the measurement box using a mouse. Set the amplitude units to any unit other than Watts or Volts to move or resize the measurement box.*

---

For further information on setting the power level parameters, see [Event Tab \(Triggering\) \(see page 788\)](#).

## Frequency Mask Trigger

The frequency mask trigger monitors all changes in frequency occupancy within the capture bandwidth (3.6 GHz or 26.5 GHz).

The following topics describe the frequency mask trigger controls:

[Event tab \(see page 788\)](#): explains how to configure frequency mask triggering parameters.

[Mask Editor \(see page 784\)](#): explains how to create and edit frequency masks.


[Triggering \(see page 781\)](#): explains how to initiate frequency mask triggering.

## Mask Editor (Frequency Mask Trigger)

The Mask Editor is used to create masks that are used by the Frequency Mask Trigger function. The Frequency Mask Trigger ( FMT ) function is used to define trigger events to capture signal anomalies based on their frequency and amplitude.

### Displaying the Mask Editor

To display the Mask Editor:

1. Click  on the Favorites toolbar or select **Setup > Trigger** to access the Trigger control panel.
2. Select the **Event** tab.
3. Set **Source** to **RF Input**.
4. Set **Type** to **Frequency Mask**.
5. Select **Mask Editor**.

### Creating a Mask


The simplest way to create a mask is to use the **Auto draw** function.

To create a new mask using **Auto draw**:



1. Select the trace on which to base the mask from the **Reference trace** drop-down list. (Only traces that are shown can be selected from the drop-down list. To show a trace that isn't currently in the list, open its display and enable the trace of interest.)
2. Specify the margins to be applied between the mask and the reference trace. Enter values for the X Margin and the Y Margin.
3. Click **Auto draw**.

The following screen shows a mask created with Auto draw.



To create a new mask without using Auto draw:

- Click the **New** button.

## Changing a Mask

A mask is a collection of points specified by their frequency (defined by their offset from the center frequency) and their amplitude. You can change a mask by adding (or removing) points and editing points.

---

**NOTE.** When placing points in the frequency mask, keep in mind that in most cases, the Frequency Mask Trigger has a range of 80 dB below Reference Level. However, for values of Reference Level lower than -50 dBm, this range decreases as the RefLevel decreases. The FMT range is also reduced when the Acquisition Bandwidth contains frequencies near 0 Hz. In both these situations, the underlying reason the trigger range is reduced is because the instrument is using various amounts of "digital gain" in addition to hardware gain. You are not prevented from placing mask points outside the usable range of the instrument, but at the time the mask is applied, the instrument adjusts its range. When the mask is adjusted, you can see this in the Spectrum display and the Mask Editor. The mask's shaded fill shows the usable vertical range. Points outside this range are shown, but will not cause a trigger.

---

## Adding Points

To add a point to a mask:

1. Click the **Add points** option button. (Alternatively, you can right-click on the desired point location (or left-click and hold for about a second) and release.)
2. Click in the graph area where you want the new point added to the mask.

You can also add a point to the mask while it is in Edit Points mode:

- Right-click in the graph area where you wish to add a point to the mask. You can also left-click and hold the button down for one second.

If you add a point by accident, click **Undo**. You can click Undo until the Undo button is grayed out.

## Editing Points

When you edit a point, you change its offset from the center frequency and/or its amplitude. There are two ways to edit the offset and amplitude of a point on a mask. First, you can drag a point to the desired position. Second, you can double-click on the offset or amplitude value in the table and enter a new value.

To edit a point on a mask:

1. Click the **Edit Points** option button.
2. Click on the point you wish to change.
3. Change the position of the point using the following methods:
  - a. Dragging it with the mouse to the desired position.
  - b. Clicking the arrow keys in the Mask Editor window to move the point to the desired position. Use the left/right keys to change the frequency offset. Use the up/down arrow keys to change the amplitude.
4. To edit another point, click **Next**.

You can also edit a point by double-clicking on the value in the table that you want to change and typing in a new value.

## Deleting Points

To delete points from the mask:

1. Click the **Edit Points** option button.
2. Click on the point to be removed and click the **X** button to delete the point.

You can also delete a point by clicking on the point in the table that you want to delete and clicking the **X** button.

If you delete a point by accident, click **Undo**. You can click Undo until the Undo button is grayed out.

### Saving a Mask

To save a mask:

- Click the **Save** button.

To save an edited mask under a new name:

- Click the **Save As** button.

### Opening an Existing Mask

To open an existing mask:

1. Click on **Open**. This displays the Open dialog box.
2. Navigate to the location of the mask file.
3. Select the desired file and click **Open**.

## Trigger Settings

**Main menu bar:** Setup > Trigger

**Favorites toolbar:** 

The Trigger control panel allows you to set the parameters that define trigger events and how the analyzer responds to them.

### Trigger Modes

There are two trigger modes: Free Run and Triggered.

Mode	Description
Free Run	Acquires and displays the signal without triggering.
Triggered	Acquires a data record after the defined trigger event is recognized.


### Trigger Tabs

Use the Trigger tabs to access controls for setting the different trigger parameters.

Tab	Description
<a href="#">Event (see page 788)</a>	Sets parameters that control triggering on the selected trigger source.
<a href="#">Advanced (see page 793)</a>	Sets controls for triggering in swept acquisitions.
<a href="#">Actions (see page 794)</a>	Sets parameters for Save on trigger function.

# Event Tab

The Event tab is used to set the parameters that define trigger events. The parameters that appear on the Event tab change depending on the selected Trigger source and type.



## Source


Source specifies the source of the signal to be monitored for a trigger event. The choices available are: RF Input, External, and Internal Time. The Source drop-down list is always visible on the Event tab.

## Type

Type defines the trigger type as Power, Frequency Mask, or DPX Density. The Type selection is only present when Source is set to RF Input.

- When Type is set to Power, a transition through an adjustable level of the selected source determines a trigger event.
- When Type is set to Frequency Mask, where and how the input signal crosses or fails to cross the edge of the mask defines a trigger event.

Source = RF input.



The following table describes the settings for each triggering type available when Source is set to RF Input. Type specifies what type of violation will define a trigger event.

Table 12: Trigger types when Source is RF input

Event Type	Setting	Description
Power		For the Power setting, if the RF input signal crosses the specified level (in the direction set by Slope), a trigger event occurs. A trigger event does not occur if the power level of the signal simply exceeds the level setting, there must be a power level transient that crosses the specified level.
	Slope	The slope control determines whether the signal analyzer finds the trigger point on the rising or falling edge of the RF input signal.
	Level	The Level setting determines the power level that will be recognized as a trigger event. The Level is indicated in the Amplitude vs Time and Time Overview displays with a dark cyan colored-line.
	Trigger BW	Time-domain BW is a filter used to process the trigger input signal before the trigger system analyzes the signal. The frequency edge trigger point must lie within the range of time domain bandwidth. This makes the range of the frequency edge trigger = Center Frequency $\pm(0.5 \times \text{Time Domain Bandwidth})$
Frequency Mask (RSA7100A only)		For the Frequency Mask setting, events where the trace crosses the edge of the mask when it should not or when the trace does not cross the edge of the mask when it should define the trigger event.
	Violation	Specifies the type of transition that defines a violation.
	RBW	Specifies the resolution bandwidth.
	Auto	Specifies whether the RBW is adjusted automatically or manually.
	Mask Editor	Displays the Mask Editor so that you can create and edit Frequency Masks.  You can read more about using this tool in the <a href="#">Mask Editor (Frequency Mask Trigger)</a> topic.
	Load from file	Opens the Open dialog for selecting a previously saved frequency mask file.

Source = Internal Time.

Event

Advanced

Actions

Source:

Internal Time

Trigger Time:

9:13:24.6438013

Repeat Interval:

1 s


The Internal Time trigger source generates a trigger event at one or more time points based on the analyzer system internal time. The time points are local time zone wall-clock times (e.g., 14:45:13.566 corresponding to 2:45:13.566 pm). A single trigger event, or multiple repeated trigger events, can be specified by clicking **Trigger Time** or **Repeat Interval** in the Event tab and then using the **Configure Internal Time Trigger** dialog.

These dialog controls specify how internal time is used to generate trigger events. Changes to these settings take effect only after you have clicked **OK**. Click **Cancel** to discard changes.

---

**NOTE.** Trigger system time is initialized with the PC system clock when initial connection to the device is done. If the connected device has an internal GPS/GNSS receiver, enabling it and allowing it to lock to GNSS signals automatically aligns the trigger system time to GPS time. This supports high-precision, time-based triggering in these devices.


---



The dialog box is titled "Configure Internal Time Trigger" and has a close button in the top right corner. It displays the "Instrument current time" as 4:03:18, with a button labeled "Set Trigger Time To This". Below this, there are three radio button options: "Trigger Time", "Repeat Interval", and "Both". The "Both" option is selected. The "Trigger Time" section shows a time picker with "hr" (03), "min" (55), and "sec" (59.83967). The "Repeat Interval" section shows a text box with the value "1.0". At the bottom, there is a yellow highlighted message that says "Requested trigger time occurs on the next day", and two buttons labeled "OK" and "Cancel".

Setting	Description
Trigger Time	<p>Click on the field next to Trigger Time in the Event tab to open the Configure Internal Time Trigger dialog. You can then set the instrument to trigger one measurement acquisition at the specified time. Time values are in 24-hour format. For example, a Trigger Time of 12:34:56.123456 causes one acquisition to be triggered at 123456 <math>\mu</math>sec after 12:34:56 PM.</p> <p>The minimum resolution of the time value is 1 <math>\mu</math>sec. If the time value occurs before the current time, the trigger event will be scheduled for that time on the following day and a warning message displayed. When setting the Trigger Time, it is recommended to set the time value at least 5 seconds after the current time to allow the analyzer to set up for the acquisition. After the single trigger acquisition completes, SignalVu-PC is set to Stop state.</p>
Repeat Interval	<p>Click on the field next to Repeat Interval in the Event tab to open the Configure Internal Time Trigger dialog. You can then set the instrument to continuously trigger measurement acquisitions at the specified time intervals. Initial triggering starts as soon as you close the dialog box. For example, a Repeat Interval of 0.5 seconds with an Acquisition Length of 1.1 seconds will result in acquisitions at 1.5 second intervals (or 2.0, 2.5, etc. seconds, if acquisition and processing take more time).</p> <p>Trigger events will be generated at each time point that is an integer multiple of the Repeat Interval value following the arbitrary start point. Minimum setting value and is 1 <math>\mu</math>sec and the maximum is 600 seconds. Acquisitions will only be taken at trigger times at which the system is armed and ready for a new acquisition. Repeat trigger events continue occurring until triggering is reconfigured or the analyzer is set to Stop state.</p>
Both	<p>This option in the Configure Internal Time Trigger dialog allows you to specify an initial Trigger Time to begin trigger events and a trigger Repeat Interval following the initial trigger time. Once the initial trigger time is reached, further trigger events will be generated similar to Repeat Interval behavior.</p>
Set Trigger Time To This	<p>Click to copy the current time value into the Trigger Time field. This can help with configuring the time setting. When setting the Trigger Time, it is recommended to set the time value at least 5 seconds after the current time to allow the analyzer to set up for the acquisition.</p>

**Violation.** Violations are state changes (or a sequence of state changes) defined by whether a point on the signal falls within the frequency mask or outside the frequency mask. A True violation occurs if even a single point on the trace falls inside the mask (above the mask's lower edge). Conversely, a False violation occurs if no points on a signal fall inside the mask (all trace points are below the mask's lower edge).



A trigger event is initiated based on the type of violation that occurs and the sequence of violations that occur.

Violation	Description
T	Only one state is required to initiate a trigger event. The signal has at least one data point inside (above) the mask. The trigger event occurs when the instrument detects the first signal with a point violating the mask. A trigger event could occur on the first acquisition.
F	Only one state change is required to initiate a trigger event. The signal has all data points outside (below) the mask. The trigger event occurs when the instrument has detected the first spectral waveform that lies completely below (outside) the mask. A trigger event could occur on the first acquisition.
T - F (Out)	Two states are required to initiate a trigger event. The signal must be inside the mask and then passes out of the mask. The trigger event occurs when the first non-violating waveform is detected.
F - T (In)	Two states are required to initiate a trigger event. The signal must be outside the mask and then passes into the mask. The trigger event occurs when the first non-violating waveform is detected.
T - F - T (Out & In)	Three states are required to initiate a trigger event. The signal starts inside the mask and then passes out of the mask. Next, the signal must pass into the mask. The trigger event occurs at the second transition where the signal passes back into the mask.
F - T - F (In & Out)	Three states are required to initiate a trigger event. The signal starts outside the mask and then passes into the mask. Next, the signal must pass back outside the mask. The trigger event occurs at the second transition where the signal passes back out of the mask.


**Mask Editor.** Launches the [Mask Editor \(see page 784\)](#) that enables you to create and edit Frequency Masks.

**Load from File.** Enables you to load an existing frequency mask for use with Frequency Mask Trigger.




## Advanced Tab (Triggering)

**Menu Bar: Setup > Trigger > Advanced**


Favorites toolbar: 

Allows you to set the following parameters. Available parameters vary depending on the trigger selections and settings in the Events tab.



Event Advanced Actions

Trigger Position: 50 % ☒ Auto ☒ Trigger each segment of Swept acquisitions



Event Advanced Actions

Position: 13 % ☒ Auto ☐ Trigger each segment of Swept acquisitions

☐ Holdoff: 0.000 s

Advanced tab when Source is set to Internal Time on the RSA7100A

Setting	Description
Position	Sets the point along the acquisition record the trigger event should occur.
Auto	Enables the instrument to set the position of the trigger event. To manually specify the position of the trigger event, unselect Auto.
Holdoff	Prevents triggers until there have been no trigger events for at least the specified time. Range: 20 ns-10 s.
Trigger each frequency segment in Swept acquisition mode	Sets the analyzer to wait for a trigger for each acquisition in a swept spectrum or other measurement requiring multiple acquisitions worth of span.

## Actions Tab (Triggering)

The Actions tab sets parameters for the Save on trigger function. The Save on trigger function allows you to save an acquisition data file and/or a screen capture when a trigger event occurs.

Trigger events are defined on the [Event \(see page 788\)](#) tab.

The screenshot shows the 'Actions' tab with the following settings:

- ☒ Save acq data on Trigger: TIQ (1 complete acquisition, not valid when swept)
- ☐ Max total files saved per Run: 100
- ☐ Save picture on Trigger: PNG

### Action tab settings

Setting	Description
Save acq data on Trigger	<p>Enables the Save on Trigger function. The list box to the right of the <b>Save acq data on Trigger</b> check box specifies the format of the saved file. Acquisition data files can be saved in TIQ (native) format, CSV format, and MAT (MATLAB) format. For descriptions of these file formats, see <a href="#">Data, Settings and Picture File Formats (see page 840)</a>.</p> <p>When TIQ is the selected file type, a file is saved after a complete acquisition, which can include multiple frames. When CSV or MAT is the selected file type, a separate file is saved for each frame.</p> <p>Files are saved in the last location a file was saved. If <b>Automatically increments filename/number</b> is enabled (see <a href="#">Save and Export</a>), files will be saved without user interaction. If Automatically increments filename/number is not enabled, you will be prompted for a filename when a trigger event occurs.</p>
Save picture on Trigger	<p>Enables saving a picture of the display when a trigger event occurs. Files can be saved in PNG, JPG, and BMP format. For descriptions of these file formats, see <a href="#">Data, Settings, and Picture File Formats (see page 840)</a>.</p>
Max total files saved per Run	<p>Specifies the number of times a Save on Trigger action stores a file. After this limit is reached, no more files are saved. The instrument will continue to run, but no additional files are saved when a trigger event occurs.</p> <p>Keep in mind when setting this number that picture files are counted as part of the total number of files. For example, if you set Max total files to 100, the instrument will save 100 acquisitions if only acquisitions are saved or only pictures are saved. But, if both acquisitions and pictures are saved, then 50 acquisitions and 50 pictures will be saved.</p>


## How to set up GNSS

The combined use of the GNSS, Antenna, and Map It features allows you to capture and map location coordinates when using an antenna and a GNSS receiver. The Map It feature requires that the optional MAP application license be installed.

You can use the GNSS and Map It features to connect a Global Navigation Satellite System (GNSS) receiver to a communication (COM) port on your PC to capture the timing and positioning data of the receiver for a measurement from a satellite or constellation of satellites. The receiver must output navigation messages using NMEA 0183 serial data format, and the messages must include at least one of these sentence types: RMC, GGA or GNS.


The RSA7100A with Option GPS, the RSA500A series, and the RSA600A series instruments have an internal GNSS receiver.

### How to access the GNSS/Antenna control panel

Click the  icon or select **Setup > GNSS/Antenna** from the Main menu bar to view the GNSS/Antenna control panel.


### GNSS settings

The following images and table show the GNSS tab of the GNSS/Antenna control panel and its contents.



GNSS		Antenna
Source	External	
COM Port	8	
Baud Rate	4800	
		GNSS Status Off Time Longitude Latitude Altitude Satellites HDOP


The above image shows the GNSS tab as it appears when the GNSS selection is External, None, or Simulator.



GNSS		Antenna														
Source	RSA device	<input type="checkbox"/> Antenna Power														
COM Port	8															
Baud Rate	4800															
Satellite System	GPS, GLONASS															
		<table border="1"> <tbody> <tr> <td>GNSS Status</td> <td>Unlocked</td> </tr> <tr> <td>Time</td> <td>2016-08-24 14:14:17</td> </tr> <tr> <td>Longitude</td> <td>0.000000 °</td> </tr> <tr> <td>Latitude</td> <td>0.000000 °</td> </tr> <tr> <td>Altitude</td> <td>0.0 m</td> </tr> <tr> <td>Satellites</td> <td>0</td> </tr> <tr> <td>HDOP</td> <td>0.00</td> </tr> </tbody> </table>	GNSS Status	Unlocked	Time	2016-08-24 14:14:17	Longitude	0.000000 °	Latitude	0.000000 °	Altitude	0.0 m	Satellites	0	HDOP	0.00
GNSS Status	Unlocked															
Time	2016-08-24 14:14:17															
Longitude	0.000000 °															
Latitude	0.000000 °															
Altitude	0.0 m															
Satellites	0															
HDOP	0.00															

The above image shows the GNSS tab as it appears when the GNSS selection is RSA Device. This selection is only available when an RSA7100A (with Option GPS), RSA500A series, or RSA600A series instrument is connected.

Setting	Description
Source	<p>Select the GNSS source as None, RSA Device (GPS), or External.</p> <p>None disables use of GNSS data.</p> <p>RSA Device selects the internal GNSS receiver in the connected analyzer.</p> <p>External selects a user-provided GNSS receiver in the PC with SignalVu-PC installed, or it may be one you connect through USB or some other method.</p> <p><b>NOTE.</b> When recording with XCOM format, a marker file (.xmkr) is generated that lists GPS data, such as time, location, and the time stamp of the GPS event during recording. You can read more about file formats in the <a href="#">Saved File Types (see page 840)</a> topic.</p>
Antenna Power	<p>This item appears when RSA Device is the GNSS selection. Check this box to supply power to an attached antenna. Power is provided as a DC voltage on the connector center conductor. Unchecking the box turns power to the antenna off. Changing the selection from RSA Device to any other selection also turns the power to the antenna off.</p>
COM Port	<p>This list is auto-populated with the COM ports on your PC, as well as a simulation port. This selection is not available when RSA Device is selected.</p> <p><b>NOTE.</b> You must first select the COM port to which the antenna is connected before an antenna connection can be established.</p>
Baud rate	<p>Select a baud rate. Selection of this rate will depend on your GNSS receiver and COM port specifications. Options are 4800, 9600, 19200, and 38400.</p> <p>This selection does not apply when RSA Device is selected.</p>
Satellite System	Select a satellite system: GPS, GLONASS; GPS, BeiDou; GPS; GLONASS, BeiDou.
GNSS readout	This readout shows the status of the GNSS connection and time, location, and satellite information. Each item is described below.
GNSS Status	GNSS receiver connection status: Off, Comm error, Unlocked, Locked.
Time	Date (yyyy-mm-dd) and time (hh:mm:ss).
Longitude	East-west position (shown in degrees), where the prime meridian is 0°. Positive numbers indicate East and negative numbers indicate West.
Latitude	North-south position between the poles (shown in degrees), where the equator is 0°. Positive numbers indicate North and negative numbers indicate South.
Altitude	Elevation from sea level (shown in meters).
Satellites	Number of GNSS satellites currently tracked by the GNSS receiver.
HDOP	Horizontal Dilution of Precision (HDOP). This value indicates the quality of the satellite signal using the relative geometry of the satellite to receiver. An ideal value is <1. The lower the value, the better the positional precision.
Speed	Speed of receiver (shown in km/s).
Course	Compass bearing (shown in degrees).

The icon  appears in the right corner of the Status Bar. It is green when GNSS is locked, yellow if unlocked, and red if there is a communication error.

### How to set up the GNSS feature with an external GNSS receiver

1. Install a GNSS receiver to a COM port on your PC.
2. Select **Setup > GNSS/Antenna** from the Main menu bar to view the GNSS/Antenna control panel.
3. Select **External** from the drop-down menu in the GNSS tab.
4. From the COM Port drop-down list, select the COM port to which the GNSS receiver is connected.

You can also select RSA Device as your GNSS source if you are using an RSA500A or RSA600A series, or RSA7100A instrument.

---

**NOTE.** You can select *Simulation Port* to run a simulation when no GNSS receiver is present. Copy the file *GnssSimCom19* from *C:/RSAMap Files/Example Files* and place it in the Windows *C:/Temp* directory, then select *Simulation Port* from the *COM Port* drop down menu.

---

5. Set the Baud Rate as appropriate for the connected GNSS receiver. The default is 4800, which is a typical rate.

The screenshot shows the 'GNSS/Antenna' control panel. On the left, there are three settings: 'GNSS' set to 'External', 'COM Port' set to '9 - Prolific USB-to-Serial Comm Port', and 'Baud Rate' set to '4800'. On the right, there is a status area with a table of data:

GNSS Status	Locked
Time	2015-11-11 15:17:08
Longitude	-122.823183 °
Latitude	45.499185 °
Altitude	76.1 m
Satellites	11
HDOP	0.70

When the GNSS receiver is communicating with the analyzer, the readouts in the right portion of the GNSS panel (status area) will update to display current location information and GNSS receiver status. Lock times will vary depending on the receiver and receiving conditions.

#### See also:

[How to use the Antenna feature](#)

[How to use Map It](#)

[Frequency Reference tab and GNSS settings \(see page 770\)](#)

[Timing Reference tab and GNSS settings \(see page 772\)](#)

## How to use the Antenna feature


The antenna feature allows you to connect to an Alaris DF-A0047 USB-connected antenna that reports bearing/azimuth data over USB. In conjunction with a GNSS receiver, you can capture location and azimuth data using the [Map It](#) feature. If you do not use an Alaris DF-A0047 antenna, you can use the manual controls to enter an azimuth.

Explore the following topics in this section:

**NOTE.** A USB driver is installed for the Alaris antenna with SignalVu-PC. However, Windows will search for new drivers if the PC is connected to the internet. The first time you plug an antenna into the port, it may take several minutes for the driver to be installed (when connected to the internet).


- [Antenna settings.](#)
- [How to set up the Antenna feature with an antenna.](#)
- [How to use the antenna Simulator.](#)
- [How to use the Alaris function button](#)

## How to access the Antenna control panel

Click  or select **Setup > GNSS/Antenna** from the Main menu bar to view the GNSS/Antenna control panel. Then click on the **Antenna** tab in the control panel.

## Antenna settings

Following is an image and a description of the Antenna tab of the GNSS/Antenna control panel.



Setting	Description
Antenna	Select the antenna. Choices are None, Alaris DF-A0047, and Simulator. The Simulator simulates an antenna connection and readouts for demonstration purposes.
Manual Azimuth	Enter a value here to force the azimuth (compass direction in degrees) to be a specific value. The azimuth is the angle measured clockwise between the reference meridian (geographic north) and the current antenna direction. It can range from 0 to 360°.
Force Manual Azimuth	Check this box to force the analyzer to read the azimuth at the entered value instead of the antenna generated value.
Show Compass	Check this box to view a visual, qualitative representation of the bearing (a virtual compass). To remove the compass, uncheck the box. To adjust the compass size, click and drag from the bottom right corner.
Configure...	This button opens the Antenna Setup window. In this window you can enter the antenna serial number and set the following antenna related parameters: baud rate, data bits, stop bits, and parity.

Setting	Description
Connect	Click this button to connect to the antenna or to start the antenna simulator.  <b>NOTE.</b> You must first select the COM port to which the antenna is connected before a connection can be established. Use the Windows Device Manager to find the port used by your antenna.
Manual Declination	Enter a value here to force the declination (angle in degrees between magnetic (true) north and geographic north) to be a specific value.
Force Manual Declination	Check this box to force the analyzer to use the manually entered declination value. Otherwise, the analyzer will assume that geographic north and magnetic north are the same and use 0°.
Antenna readout	This readout field will contain some or all of the following readings, depending on your setup.
Amplifier	Shows Off or On depending on whether or not you have enabled the amplifier on the antenna.
Freq Band	The current operating frequency band of the antenna. For the Alaris DF-A0047, this value can be one of the following: A (0.009 - 20 MHz) B (20 - 50 MHz) C (50 - 8500 MHz)
Uncorrected Compass Bearing	Shows the azimuth reading from geographic north.
Declination	Shows the declination.
True North Azimuth	Shows the azimuth reading after declination is applied.
Elevation	Shows the antenna elevation.
Roll	Shows the antenna roll.

### How to set up the Antenna feature with an antenna


1. Install the Alaris DF-A0047 driver. The driver can be copied from the SignalVu-PC Software and Documentation USB stick supplied with the RSA306, RSA306B, RSA500A series, and RSA600A series instruments. It can also be download from [www.Tek.com/downloads](http://www.Tek.com/downloads).
2. Connect an Alaris DF-A0047 antenna to the PC.

**NOTE.** Connecting an RSA306, RSA306B, RSA500A series, or RSA600A series is not required, but provides increased functionality of this feature.

**NOTE.** A USB driver is installed for the Alaris antenna with SignalVu-PC. However, Windows will search for new drivers if the PC is connected to the internet. The first time you plug an antenna into the port, it may take several minutes for the driver to be installed (when connected to the internet).

3. Select **Setup > GNSS/Antenna** to open the GNSS/Antenna control panel.
4. Select **Alaris DF-A0047** from the Antenna drop-down menu. Selections also include None (default) and Simulator.


5. Click the **Configure...** button to launch the Antenna Setup window.



6. Do the following in the Antenna Setup window:
  - a. Enter the serial number of the antenna, if desired.
  - b. Select the COM port to which the antenna is connected. You can see a list of COM ports for your PC in the Microsoft Windows Control Panel. Use the Windows Device Manager to find the port used by your antenna.
  - c. You can change the following parameters; however, the default values are set for the Alaris DF-A0047 antenna. If you change these parameters, you may lose communication with the Alaris antenna: baud Rate, data bits, stop bits, and parity.
8. Click **OK** to save the changes and close the Antenna Setup window.
9. You can now choose to manually set the declination, if desired. To do this, check the box next to **Force Manual Declination** in the Antenna tab of the GNSS/Antenna control panel and then enter the desired value. Notice that the value you enter will appear in the antenna readout to the right of the Connect button. The True North Azimuth reading is the sum of the Uncorrected Compass Bearing and the Declination.


You can also check the box next to **Force Manual Azimuth** and enter a desired value if you want to force the azimuth or are using an antenna that does not report azimuth.

When you select to manually force the declination and/or azimuth, those values will not change in the readout, even if the antenna direction changes.



10. Check the **Show Compass** box to view a visual, qualitative representation of the bearing. As you move the antenna, the compass needle will move.






**TIP:** You can adjust the size of the compass by clicking on the right bottom corner and dragging it.

11. Click the **Connect** button to connect to the antenna. Connection may take about 10 seconds. Once connected, the antenna readout will reflect the antenna direction and other readings.

### How to use the antenna Simulator

1. Select **Setup > GNSS/Antenna** to open the GNSS/Antenna control panel.
2. Select **Simulator** from the Antenna drop-down menu. Selections also include None (default) and Alaris DF-A0047.
3. Click the **Connect** button to launch the Smart Antenna Control Form.




4. Click on the various areas of the Smart Antenna window to adjust azimuth, roll, or elevation. You can also enter the values directly in the Azimuth, Elevation, and Roll Angle fields. This Smart Antenna window simulates a physical antenna, except that there is no amplification available (the Passive/Active switch in non-functional).
5. Click the **Button1** button to capture the GNSS information. (See the [How to use Map It](#) topic for more information on capturing data.)


- You can now choose to manually set the declination, if desired. To do this, check the box next to **Force Manual Declination** in the Antenna tab of the GNSS/Antenna control panel and then enter the desired value. Notice that the value you enter will appear in the antenna readout to the right of the Connect button. The True North Azimuth reading is the sum of the Uncorrected Compass Bearing and the Declination.

You can also check the box next to **Force Manual Azimuth** and enter a desired value if you want to force the azimuth or are using an antenna that does not report azimuth.

When you select to manually force the declination and/or azimuth, those values will not change in the readout, even if the antenna direction changes.



- Check the **Show Compass** box to view a visual, qualitative representation of the bearing. As you move the antenna, the compass needle will move.



**TIP:** You can adjust the size of the compass by clicking on the right bottom corner and dragging it.

### How to use the Alaris function button

The Alaris antenna has a function button that allows you to make Band and Mode selections. These can be selected using the rotary encoder and push button located on the front of the Alaris antenna grip.

#### To select a frequency:

- Turn the rotary switch either to the left or right.
- Watch the LEDs on the back of the grip. The LEDs indicate which frequency band is selected. Selections are:
  - Top LED, Band A: 9 kHz – 20 MHz
  - Middle LED, Band B: 20 MHz – 500 MHz
  - Bottom LED, Band C: 500 MHz – 8500 MHz

**To select an amplifier mode:**

1. Push the button on the front of the antenna grip.
2. Watch the LED on the back of the grip. It indicates the mode status as:
  - LED on: Active mode (amplifier on)
  - LED off: Bypass mode (amplifier off)

**To take a measurement using the button:**

1. Hold the button down for two seconds.
2. Release the button. The measurement is transferred and stored via the Map It function of SignalVu-PC.

**See also:**

[How to set up GNSS \(see page 795\)](#)

[How to use Map It \(see page 803\)](#)

## How to use Map It

Select **View > Map It Toolbar** from the Main menu bar to open the Map It toolbar.


Once you have set up the GNSS receiver as shown [here](#), perform the following steps to capture the data. A Map It file includes trace data, measurement data, time, and location information for use in the RSA Map program.

---

**NOTE.** *The Map It feature requires that the optional MAP application license be installed.*


---

1. Check that at least one of the following displays is active: Spectrum, DPX, Spectrogram, Amplitude vs Time, Channel Power, or Occupied Bandwidth.
2. If an RSA306, RSA306B, RSA500A series, RSA600A series, or RSA7100A is not currently connected to the PC, you can connect one now, if desired.
3. Select **View > Map It Toolbar** from the main menu bar to view the Map It toolbar. Notice that the current GNSS location and time information are shown on the toolbar.



4. Click the **Edit...** button to open the Map It Editor window.

5. In the Map It Editor window, click the **Capture** button to capture data. If you prefer, you can click the **Capture** button on the Map It toolbar first, and then click **Edit...** to open the Map It Editor window to view the result.
6. You can now import, export, or recall captured data using the related buttons at the bottom of the Map It Editor window. If you export a file, you can then open it using the RSAMap application (open from the Tools menu).



### Importing and exporting Map It files

The information you capture can be zipped and stored as a single file with multiple captures. Recalling results will recall the trace data and settings stored with Map It. Make sure to uncheck the Show box in the traces menu of the selected display when you have completed examination of the Map It data.

The Map It zip file is structured as follows:

```

\ (root)
|
+ Readme.txt = This document.
|
+ \Data = Contains all exported comma-separated trace data and image captures.
  Also contains a measurement summary file.
  |
  + Measurements.csv
  + <Timestamp>_Result.csv
  + <Timestamp>_Picture.png
|
+ \Mifmid = Contains exported .mif and .mid files.
  |
  + <ArchiveFilename>.mif
  + <ArchiveFilename>.mid
|
+ \KMZ = Contains the exported .kmz file.
  |
  + <ArchiveFilename>.kmz
|
+ \RSA = Contains RSA trace files for all measurements.
|
+ \Tek = Contains files for use by RSA Map.
|
+ \Map = Contains files and data for the map used with this archive.
|

```

### Viewing live updates after viewing an imported file

When you want to view live updates again in a Spectrum, DPX, or Spectrogram display, you must go into the Traces tab of the Settings control panel and uncheck the **Show recalled trace** box. If you are using a DPX display, do this twice, once each for Bitmap and Trace 1.

#### See also:


[How to use the Antenna feature](#)

[How to set up GNSS](#)




## IQ Streaming overview


IQ streaming with SignalVu-PC and the RSA7100A allows you to use the analyzer as a down-converter and then pass the down-converted baseband I/Q signals to external equipment or locations for either additional processing or storage. Connection to an RSA7100A with one of the following options installed is required: 05 (LVDS), STREAM (40 GbE), and CUSTOM-API (API).



The Configure In/Out menu allows you to access the IQ Streaming control panel with its related features. Select **Setup > Configure In/Out** from the Main menu to access the IQ Streaming control panel.



You can set the system to continuously stream IQ data from the device to one or more clients from the tabs on the IQ Streaming control panel.




### IQ Streaming control panel features

Tab	Description
<a href="#">API (see page 808)</a>	Stream IQ data to your custom application.
<a href="#">Ethernet (see page 809)</a>	Stream IQ data to the 40 GbE card on a client controller.
<a href="#">LVDS (see page 810)</a>	Stream IQ data through the LVDS interface to a client controller.

## IQ Streaming API

SignalVu-PC uses IQ block streaming. The API commands enable IQ data blocks to be streamed to a user program. You can specify to send the IQ data block and/or the Trigger time stamp using an API command. The Auxiliary data block is always sent. The **API** tab allows you to stream the specified IQ data to your custom application. This feature requires a RSA7100A with Option CUSTOM-API.

Select **Setup > Configure In/Out** from the Main menu to access the IQ Streaming control panel and the **API** tab.





### How to use the IQ Streaming API feature

1. Run your custom application.
2. Click the **Start** button in the Streaming API tab in SignalVu-PC. The button will change to a Stop button when the data is streaming.
3. Check that the acquisition of data in your custom application is occurring.
4. Click the **Stop** button when you want to stop the streaming.

### API tab functions

Item	Description
Start button	Starts the streaming of recorded data to your custom application.
Dropped Frame	Indicates a missed frame has been detected in the streaming data. The Marker file (.xmrk) indicates the sample in which the Dropped Frame is detected. If the recording is done using the unpack data format and the acquisition bandwidth is equal to 800 MHz, you can select the packed data format to reduce Dropped Frame.
Input Overload	Indicates if an overload has been detected in the record. The Marker file (.xmrk) indicates the sample in which the Input Overload is detected. You can increase the reference level to avoid Input Overload.

## 40 GbE IQ Streaming Ethernet

Select **Setup > Configure In/Out** from the Main menu to access the IQ Streaming control panel and the **Ethernet** tab. This feature allows you to stream IQ data using 40 GbE on a host PC (CTRL7100 running SignalVu-PC) to a 40 GbE receiver on a client PC. This feature requires a RSA7100A with Option STREAM.

IQ Streaming

API

Ethernet

LVDS

Start

Address: "30.0.0.1"

Port: 21005

Dropped Frame: ☒

Input Overload: ☒

### How to use the 40 GbE IQ streaming feature

1. Open a command prompt on the receiver PC. This is the PC on which you will run your application to receive the data.
2. Type `ipconfig` to query all addresses associated with an Ethernet connection.

3. Copy the IP address associated with the 40 GbE card.

---

**TIP.** If needed, you can open the Network & Sharing Center in Windows 7 to view connection properties. The 40 GbE card is labeled Mellanox ConnectX-3 Ethernet Adapter.

---


4. Run your application using the IP address and valid port number. For example, you would type `AppCustom.exe 33.0.0.1 21505` in the command prompt and then Enter.
5. In the SignalVu-PC application on the host PC (CTRL7100A)
6. Click the **Start** button in the Streaming Ethernet tab in SignalVu-PC. The button will change to a Stop button when the data is streaming.
7. Check that the acquisition of data in your custom application is occurring.
8. Click the **Stop** button when you want to stop the streaming.

### Ethernet tab functions

Item	Description
Start button	Starts the stream of 40 GbE data from the host PC (CTRL7100A running SignalVu-PC) to a receiver (a PC running your custom application).
Address	Enter the IP address associated with the 40 GbE card in the receiver (PC running your custom application).
Port	Enter the valid port number of the receiver 40 GbE card.
Dropped frame	Indicates a missed frame has been detected in the streaming data. The Marker file (.xmrk) indicates the sample in which the Dropped Frame is detected. If the recording is done using the unpack data format and the acquisition bandwidth is equal to 800 MHz, you can select the packed data format to reduce Dropped Frame.
Input overload	Indicates if an overload has been detected in the stream. The Marker file (.xmrk) indicates the sample in which the Input Overload is detected. You can increase the reference level to avoid Input Overload.


## IQ Streaming LVDS

Select **Setup > Configure In/Out** from the Main menu to access the IQ Streaming control panel and the **LVDS** tab. This feature allows you to stream IQ data through the LVDS interface to a client controller. This feature requires a RSA7100A with Option 05.



### How to use the LVDS IQ streaming feature

1. While the system is powered off, connect the LVDS cable to the rear panel of the CTRL7100A controller hosting SignalVu-PC.



2. Connect other end of the cable to the LVDS port in the client side of the system.
3. Turn on the host system.
4. Launch SignalVu-PC and select **Setup > Configure In/Out** from the Main menu to access the IQ Streaming control panel and the **LVDS** tab.
5. If you want to test the LVDS device is functioning before streaming the IQ data, click **Test (Counting Pattern)** and check that data is being received in the client side application.

6. When you ready to stream the IQ data, click **On** to start streaming of IQ data through the LVDS.
7. You can now view data in your client side application.

**LVDS tab functions**

Item	Description
Off	Stops streaming of IQ data through the LVDS.
On	Turns on streaming of IQ data through the LVDS.
Test (Counting Pattern)	Validates that the LVDS in the device is functioning.

## How to use the Signal Database

Select **Tools > Signal Database** to open the Signal Database window. Here you can select which signal standards and types are listed (and selectable) in the Channel Navigation toolbar and/or the Define Survey control panel.


### Signal standards and signal types defined

The analyzer uses the following definitions of signal standards and signal types to populate the Signal Database.

- **Signal standard:** A group of channels that adheres to the parameters and characteristics of a given signal type. These channels could include both uplink and downlink frequencies.
- **Signal type:** Parameters and characteristics (bandwidth, spectral shape) common to a given signal. A signal type can be shared by multiple signal standards.

### How to select signal standards in the database window

The following image is of the Signal Database window with the Signal Standards tab selected. The table describes the fields and buttons of the tab. The standards selected here show in the Define Survey control panel and the [Channel Navigation](#) toolbar.



Setting	Description
Signal Standards Supported	List of all available signal standards. Click a standard to select it or click and drag to select a contiguous range of standards.
Add >>	Adds (moves) selected items from the <b>Signal Standards Supported</b> list to the <b>Signal Standards selected</b> list.

Setting	Description
< < Delete	Deletes (moves) selected items from the <b>Signal Standards selected</b> list to the <b>Signal Standards Supported</b> list.
Signal Standards selected	List of selected signal standards that will be made available in the Channel Navigation toolbar and the Region tab of Define Survey control panel. To delete items, select one or more signal standards and click the <b>Delete</b> button.
Factory Reset	Sets the supported and selected fields to the factory-specified signal standards.
Channel Nav Toolbar check box	Check box to open the Channel Navigation toolbar. The Signal Database window stays open. You can read more about the Channel Navigation toolbar <a href="#">here</a> .
Signal Survey Toolbar check box	Check box to open the Signal Survey toolbar. The Signal Database window stays open. You can read more about the Signal Survey toolbar <a href="#">here</a> .


### How to merge the H500 signal database with SignalVu-PC default database

You can merge all user-defined signal types and signal standards from the Tektronix H500 instrument into the default SignalVu-PC signal database. This provides the advantages the new items introduced in SignalVu-PC without losing your user-defined additions. Merge databases as follows:

1. Close SignalVu-PC.
2. Make a copy of \BuiltInDisk\NetTekApps\Database\sst\_db file to a USB memory stick from the H500 instrument.
3. Rename the copy of the sst\_db file to SignalDatabase.rsadb.
4. On the PC with SignalVu-PC installed, overwrite the *C:\SignalVu-PC Files\SignalDatabase\Signal-Database.rsadb* file with that you made in step 3.
5. Start SignalVu-PC.
6. Verify all H500 user-defined signal standards and signal types are now available in SignalVu-PC.

### How to select signal types in the database window


The following image is of the Signal Database window with the Signal Types tab selected. The table describes the fields and buttons of the tab. The types selected here show in the Define Survey control panel.



Item	Description
Signal Types supported	List of all available signal types. Click a type to select it or click and drag to select a contiguous range of types.
Add > >	Adds (moves) selected items from the <b>Signal Types Supported</b> list to the <b>Signal Types selected</b> list.
< < Delete	Deletes (moves) selected items from the <b>Signal Types selected</b> list to the <b>Signal Types Supported</b> list.
Signal Types selected	List of selected signal types made available in the Region tab of the Define Survey control panel. To delete items, select one or more signal types and tap the Delete button.
Factory Reset	Sets the supported and selected fields to the factory-specified signal types.
Channel Nav Toolbar check box	Check box to open the Channel Navigation toolbar. The Signal Database window stays open. You can read more about the Channel Navigation toolbar <a href="#">here</a> .
Signal Survey Toolbar check box	Check box to open the Signal Survey toolbar. The Signal Database window stays open. You can read more about the Signal Survey toolbar <a href="#">here</a> .

### How to select channels in the database window

The following image is of the Signal Database window with the Channel Table tab selected. The table describes the fields and buttons of the tab. The channels selected here are included in the Signal Channel Selection window. (See the [Channel Navigation toolbar](#) section for information about channel selection.)



Item	Description
Selected Signal Standard	Drop down list allows you to select the signal standard, the channels of which will populate the channel table. This list is taken from the enabled standards in the Signal Standards tab.
Enabled column checkboxes	Enables/disables the channel in the row.
Mark All	Selects all channels in the table to enable them.
Unmark All	Deselects all channels in the table to disable them.
Hide unmarked checkbox	Hides any deselected channels so that you can view only the enabled channels in the table.
Factory Reset	Sets each channel to the factory-specified enabled/disabled state.
Channel Nav Toolbar checkbox	Check box to open the Channel Navigation toolbar. The Signal Database window stays open. You can read more about the Channel Navigation toolbar <a href="#">here</a> .
Signal Survey Toolbar checkbox	Check box to open the Signal Survey toolbar. The Signal Database window stays open. You can read more about the Signal Survey toolbar <a href="#">here</a> .

## Channel Navigation toolbar


Select **View > Chan Nav Toolbar** to view the Channel Navigation toolbar. This toolbar allows you to navigate easily from channel to channel in any measurement display. It provides the following capabilities:

- Select a channel for enabled standards (only standards selected in the Signal Database).
- Select the channel direction, if applicable (uplink or downlink).
- Access the Signal Channel Selection window, which allows you to select from a list of enabled channels.

The following image shows the toolbar and the following table describes how it functions.



Chan Nav    Signal Standard 1xEV-DO N.A. Cellular    Channel ≈721 Select Channel    Uplink Downlink X

Item	Description
Signal Standard	Drop down list allows you to select the signal standard, the channels of which will populate the Channel field to the right . This list is taken from the enabled standards in the Signal Standards tab of the Signal Database.
Channel	<p>This field shows the channel number of the currently selected signal standard that the instrument is currently tuned to. An entry of "--" indicates that the current instrument frequency does not match that of any of the currently enabled channels.</p> <p>Clicking in this field allows for direct channel number entry. To select the next or previous channel, you can use the up and down arrow keys on your keyboard or the arrows in the Numeric Keypad (in the View menu, check the Numeric Keypad box). Note that this applies to enabled channels only.</p> <p>If you see a ≈ in front of the channel number, it means that the current instrument frequency is close to, but not exactly equal to, the currently selected channel. It means that the current instrument frequency does not exactly match the currently selected channel frequency, but that it is within the current channel bandwidth.</p> <p>You cannot directly enter or use the arrow keys to select non-numeric channel names for signal standards You must use the <b>Select Channel</b> button.</p>
Select Channel	<p>Opens the Signal Channel Selection window. This window shows a table of enabled channels for the selected standard. Click on the channel you want to view in the plot and then click the OK button. This window also allows you to access the Signal Database window (using the Enabled Channels button) so that you can enable different channels or change standards or types, if desired.</p> <div></div>
Uplink	Click to select the uplink channels for the currently selected signal standard.
Downlink	Click to select the downlink channels for the currently selected signal standard.

### See also:

[How to use the Signal Database. \(see page 813\)](#)



## Signal Classification

With the SV54 optional application license for SignalVu-PC installed, you can use the signal classification toolset to help you classify signals. You will first define areas of interest as regions anywhere on a Spectrum or DPX waveform. You can then use our Signal Database tool to compare the spectral shape of the selected signal area to known signal types, and the center frequency of the selected signal area to known signal standard channels. Finally, you can assign classification labels to regions, record related notes, and save all defined regions to a region survey file. This toolset also allows you to import and export survey files. The following information and procedures are available to help you find, navigate through, and use the signal classification tools to classify a signal.

- [Step by step procedures for classifying a signal.](#) These procedures walk you through the classification process from start to finish using the analyzer's signal classification tools. Examples are included.
- [How to use the Signal Survey toolbar. \(see page 827\)](#) Once launched, this toolbar allows you to access the Create/Edit, Define, and Classify tools. These tools allow you to create a new survey/region, import and export surveys, define region signal standards and types, navigate quickly through regions in a survey, and classify a signal in a region.
- [How to use the Signal Survey Editor window. \(see page 828\)](#) This window is accessed through a Signal Survey toolbar button. It allows you to create and edit regions or import or export a survey.
- [How to use the Define Survey control panel. \(see page 829\)](#) This panel is accessed through a Signal Survey toolbar button. It allows you to select signal standards and types from the Standards Database; see bandwidth, frequency, and channel information; view all regions and related information in a survey in a table; and select and view a spectral profile (most signal types have an available profile).

### How to classify a signal

The following procedure shows you how to use the signal classification tools to classify a signal. It is divided into four main tasks.

---

**NOTE.** Before you proceed, you will need to select a list of enabled signal standards, signal types, and channels in the [Signal Database](#). You do not need to perform this setup each time you classify a signal. Once set up, this list does not change unless you reset to default or change the selections.


---


1. [Create](#) areas of interest as regions (center frequency and frequency span) anywhere on the signal.
2. [Define](#) a survey (a region or collection of regions) by comparing the bandwidth of the unknown signal to that of known signal types, and the center frequency of the unknown signal to that of known signal standard channel frequencies.
3. [Classify](#) the signal by assigning classification labels and notes to a defined region.
4. [Export or import](#) a region survey file.

## Create a region

The first step in classifying a signal is to create a region that defines the portion of the signal you want to use.

1. Open a Spectrum or DPX display to view the signal you want to classify.
2. Select **View** from the analyzer menu bar and select (check) **Signal Survey Toolbar**. The toolbar will appear near the bottom of the screen.
3. Click the **Create/Edit...** button in the Signal Survey tool bar to open the Signal Survey Editor window.




4. Check that the selected reference trace is correct in the Reference dropdown list which is located to the right of the **Export As...** button. Note that for a trace to be in the list, it must be enabled in the Spectrum or DPX display.
5. Click the **Add Region** button.
6. By default, **Click and drag on plot** is selected for the add region method. Click and drag on the plot around the signal area of interest to define the width (span) of the region. The analyzer will draw a box on the plot that is outlined in gray, indicating that the region is as yet undefined. Click on the  icon at the bottom of the region to change the CF. You can also click and drag on the left or right edge of the region rectangle to change its span. The amplitude of the signal does not need to be totally enclosed in the region box.
7. If you want to manually enter the center frequency and span parameters to create a region, select **Manual entry**, enter the values in the New Region Location fields, and then click the **Add Region** button.
8. Create more than one region, if needed.

---

**NOTE.** A maximum of two regions can overlap at any given frequency. If you try to create a new region that contains any frequency point that is already shared by two other regions, an error message is displayed stating that too many regions overlap.

---

9. If you want to edit a region, then you can use the same tools as when you first created the region (click, drag, ). If you want to delete a region, select the desired region and then click the **Delete Region** button. You can also click **Delete All Regions** to delete all regions in the display.

When Manual entry is selected in the On Add area, you can manually edit the Frequency and Span.

10. Click the **OK** button when you are finished creating and editing regions. Clicking the **Cancel** button will result in all additions/changes made during the current edit session (as long as the Signal Survey Editor dialog has been open) being discarded.

#### See also:

[How to use the Signal Survey Editor window.](#)

[How to use the Signal Survey toolbar.](#)

[How to use the Define Survey control panel.](#)

[What region color codes mean.](#)

[Using the Signal Database.](#)

#### Define a region using known standards


The next step after creating a region is to define it by comparing the unknown signal's bandwidth and frequency to the known signal standards and signal types. Doing this allows you to potentially find a match and classify the unknown signal. You can also use known signal standard channel frequencies to match against a region's center frequency.

---

**NOTE.** You can also define a region using a known signal standard channel frequency and match it against the center frequency of a region.

---

1. Click the **Define** button to open the Define Survey panel.
2. Do one of the following to select a region:
  - Click on a region (shown as a horizontal bar along the top edge of the plot) in the Spectrum or DPX display. When selected, the region will expand to a rectangular box around the signal.



- Click on a row in the Survey Summary tab table of the Define Survey panel. This table is scrollable and contains summary information about all of the regions in the current display (called

a survey). Clicking on a row in the table selects the region in the display. Information in the rows is not editable.


Region	Survey Summary	Preferences			
	Frequency	Span	Classification	Type	Standard
▶ 5	893.07038 MHz	1.3 MHz	None	CDMA2000 1xEV-DO	1xEV-DO N.A. Cellular
6	899.963038 MHz	962.026 kHz	None	Bluetooth 1Mbps	Bluetooth (LE)
7	904.614684 MHz	2.43038 MHz	Unauthorized	Not Set	Not Set
8	908.583544 MHz	1.392404 MHz	None	Not Set	Not Set

- Use the left or right arrows on the Signal Survey toolbar to navigate to the desired region. Notice that this will highlight the row number in the Survey Summary tab table of the associated region, and thus select the region in the display.


Signal Survey    Selected Region:  9 of 10

**NOTE.** Only one region can be active at a time. Inactive regions are shown as horizontal bars along the top edge of the signal. An active region is shown as a box drawn around the signal.

- In the Define Signal panel, select the Region tab and click to view the drop-down list under the Signal Type Bandwidth. In the below image, you can see that in the list, the Bluetooth signal type has a star next to it. The degree and darkness of the shading of a star indicates how close of a bandwidth match the given signal type is to the unknown signal. (You can read about how the star indicator works in [The Define Survey control panel \(see page 829\)](#) topic.)



- You now want to select from this list of known signal types and associated bandwidths. Once selected, a spectral profile (shown as a green waveform in the example image) will be overlaid on the portion of the signal in the region. The spectral profile is used to compare against the signal in the region. If the profile and the signal match, then there is a good chance the signal is that given signal type.




---

**NOTE.** Most, but not all, signal database signal types have spectral profiles.

---

5. Click on the Prefs tab in the Define Survey panel to set the spectral profile to do one of the following:

- **Snap to Channel Frequency:** Use this option if you want to verify the frequency of the signal is aligned with the selected signal standard channel frequency. If the selected signal standard channel frequency is within the selected region, then the spectral profile will center on that channel frequency. If the channel frequency is outside of the selected region, then the spectral profile will revert to being centered within the region.
- **Snap to Center of Region:** Use this option if you know that the frequency you are viewing has no defined signal standard channels in the database.
- **Off:** Use this option if you want to view the signal in the region without the spectral profile overlaid on the signal.

**See also:**

[How to use the Signal Survey Editor window](#)

[How to use the Signal Survey toolbar](#)

[How to use the Define Survey control panel.](#)


[What region color codes mean](#)

[Signal Database](#)

## Classify a region

After you have created a region, you can classify it by assigning classification labels and notes to it.

1. Select a region.
2. Click the **Classify** button in the Signal Survey toolbar to view the Declare Region window.



The 'Declare Region' dialog box is shown. It has a 'Classification' dropdown menu set to 'Unknown'. Below it is a 'Description' text box containing 'Bluetooth'. To the right is a 'Comments' text area with the text 'Intermittent signal observed, did not have time to investigate further.' At the bottom, there are two sections: 'Signal' and 'Region'. The 'Signal' section has 'Type: Bluetooth' and 'Standard: Bluetooth (LE)'. The 'Region' section has 'Span: 962.026 kHz' and 'Center Frequency: 899.963038 MHz'. At the bottom right are 'OK' and 'Cancel' buttons.


3. Select a Classification state from the drop-down list and enter a Description and Comments for the region.

**Classification state and region color coding.** Each region's outline is colored according to its classification state:

- Gray = None
- Yellow = Unknown
- Orange = Unauthorized
- Blue = Permitted


4. Click **OK** to save the classification information as a survey and close the window. Once a region has been classified, the signal type and signal standard used for classification are locked. To apply different signal types and standards to the region, set the classification to **None**.

The following example survey is of a portion of the TV broadcast band. Seven regions have been declared as either Permitted, Unknown, or Unauthorized, as indicated by the color bars for each region.





The illustration below shows a detailed portion of one of the declared regions. Since we have declared this to be an ATSC video signal, the spectral profile for the ATSC signal is shown overlaid in the region. The signal is a close match to the spectral profile, including the vestigial carrier at the lower side of the signal, characteristic of ATSC broadcasts.



### See also:

[How to use the Signal Survey Editor window](#)

[How to use the Signal Survey toolbar](#)

[How to use the Define Survey control panel.](#)

[How to use the Declare Region window](#)

[Signal Database](#)

### Export or import a survey file

The application does not enforce a hard limit on the total number of regions you can create. However, as the number of regions increase, system performance decreases. A good rule of thumb is to keep the total number of regions under 500. If more than that are required, create and save separate surveys, each with no more than 500 regions.

**Export a file.** To export a region or set of regions in a file, do the following:

1. Click the **Create/Edit...** button in the Signal Survey toolbar to open the Signal Survey Editor window.
2. Click the **Export As...** button in the Signal Survey Editor window.
3. Navigate to the location you want to save the file.

4. From the Save as type drop down list in the Save As window, select one of the following:
  - \*.Survey – survey in an internal format
  - \*.txt – survey in a tab separated format
  - \*.csv – survey in a comma separated format
5. Enter the file name and click **Save** to save the file.

#### Survey Import/Export file format notes.

- All lines starting with a "#" character are treated as a comment line.
- All blank lines are ignored.
- Lines starting with "Signal Classification: Number of Regions" are ignored (in order to be compatible with H500/SA2500 survey import/export files).
- The only required fields are the region center frequency and region bandwidth all other fields can be left blank.

**Survey file field definitions.** You can create your own .txt and .csv Survey files using software applications such as Excel or Notepad, and then import them. The following information will help you do this. You can also refer to the *SurveyImportFileExample.txt* sample import/export file installed with SignalVu-PC in the *C:\SignalVu-PC Files\Example Files\SignalClassification* directory.

- **#** - Region number. Note that the value specified is not used during import (regions are renumbered as necessary)
- **Freq (Hz)** - Center frequency of the region
- **Span (Hz)** - Bandwidth of the region
- **Description** - Short description of the region
- **Classification** - Declared region classification (None, Unknown, Permitted, or Unauthorized)
- **Type** - Declared region signal type ("Not Set", "Unknown" or any currently defined signal type name)
- **Standard** - Declared region signal standard ("Not Set", "Unknown" or any currently defined signal standard name)
- **Channel** - Declared region channel number (channel number from the specified signal standard; "----" can be used to denote no channel number specified)
- **Ch Freq (Hz)** - Declared region channel frequency (for the specified channel number; "----" can be used to denote no channel frequency specified)
- **Comments** - Declared region comments

**Import a file.** To import a region or survey file, do the following:

---

**NOTE.** *If a problem is found with the format of the file being imported, a dialog will be displayed indicating the file line number where the problem was found and a short description of the problem. For example, "Survey Import failed: Syntax Error near line 10: Invalid span value".*

---

2. Click the **Create/Edit...** button in the Signal Survey toolbar to open the Signal Survey Editor window.
3. Click the **Import...** button in the Signal Survey Editor window.
4. Navigate to the location of the saved file and select to import one of the following file types:
  - \*.Survey – survey in an internal format
  - \*.txt – survey in a tab separated format
  - \*.csv – survey in a comma separated format
5. Click **Open** to open the selected file.

**Importing guidelines.** If you try to import a survey when regions are already defined, an Import Regions dialog will appear and prompt you to select one of the following import options:

1. Delete all existing regions prior to import.
2. Attempt to merge the imported regions with the existing regions.
3. Cancel the import.

If an import and merge action does not successfully merge all regions, the "Warning: not all regions were successfully merged" message will be displayed in the informational area of the Signal Survey Editor dialog.

## Signal Survey toolbar

Select **View > Signal Survey Toolbar** to view the Signal Survey toolbar. It allows you to create, edit, define, and classify a signal. It also allows you to navigate from one region to another in the DPX or Spectrum display and to delete the selected region. This topic describes the toolbar and all of its related windows and functions.




Item	Description
Create/Edit...	Opens the <a href="#">Signal Survey Editor window</a> that allows you to create and edit regions and import and export region survey files.
Define	Opens the <a href="#">Define Survey</a> control panel. This panel allows you to view a survey summary, select how to view spectral profiles, and to specify a signal type and signal standard channel for each region.
Classify	Opens the <a href="#">The Declare Region window (classify)</a> (see page 831) that allows you to classify a region.

Item	Description
Selected Region	Click the arrows to navigate from region to region.
Delete	Click to delete a selected region.

## The Signal Survey Editor

Click the **Create/Edit...** button on the Signal Survey toolbar to access the Signal Survey Editor window. Following is an image of the window and a table describing it.



**NOTE.** If you change which waveforms are enabled in the DPX or Spectrum display after the Signal Survey Editor window is open, the Reference list in the Editor will no longer be accurate. You must close and then reopen the Editor to refresh the list.

Item	Description
Import	Click this button to import a survey from a file.
Export	Click this button to save changes made to a previously saved survey file. This button is only available for previously saved surveys. This function is like the common Save function.
Export As...	Click this button to export all of the region information to a survey file. This function is like the common Save As function.
Reference	This drop down list shows all active traces from the currently displayed Spectrum and/or DPX measurement displays. When you first open the Editor, the displayed reference trace will be the trace in the currently selected Spectrum or DPX measurement display.
Delete All Regions	Click this button to delete all regions on the plot.
Add Region	Click the Add Region button to enable the plot to allow you to add a region by clicking and dragging or entering the values manually, depending on the selected On Add setting.
On Add:	Select to add a region manually or by clicking and dragging on the plot.

Item	Description
New Region Location	When Manual entry is selected in the On Add area, the New Region Location area appears. Here you can manually enter the Frequency and Span.
Status message area	Shows informational and error messages.
Region table	Shows regions and the related frequency and span. These are editable in the table for regions that have not yet been classified.
Measurement display	Interactive view of the active measurement plot (DPX or Spectrum). You can click and drag on the plot to create a region and left-click in the display area to select the current click/drag mode. Allowable modes are Select, Span Zoom, and CF Pan. You can also adjust the area of the signal within the region using the following:
dB/div	Shows the dB per division on the y-axis of the plot.
CF	Shows the current region center frequency. Click on the field to enter a new value.
Span	Shows the current region span. Click on the field to enter a new value.
Classification	Shows the classification label of the selected region: Unknown, Unauthorized, or Permitted. If it has not been classified, this field reads None.
Signal Type	Shows the signal type of the selected region, if the signal in the region has been classified. If it has not been classified, this field reads Not Set.
Signal Standard	Shows the signal standard of the selected region, if the signal in the region has been classified. If it has not been classified, this field reads Not Set.
Delete Region	Click this button to delete the selected region.

**See also:**

The [Create a region \(see page 820\)](#) topic to see how the Signal Survey Editor works when creating/editing a region.

## The Define Survey control panel

Click the **Define** button on the Signal Survey toolbar to access the Define Survey control panel. The following images and tables describe the Define Survey control panel and its tabs.

### Region tab

Region | Survey Summary | Preferences

Signal Type: CDMA2000 1xEV-DO Bandwidth: 1.23 MHz

Note: Selections are disabled when a region is declared.

Signal Standard: 1xEV-DO N.A. Cellular Frequency: 893.07 MHz Channel: 769

Item	Description
Signal Type	For classified regions, this field is not editable. For unclassified regions, this field is a drop-down list of all enabled signal types (set in the Signal Database). The types that best match the signal are starred in this list. See <a href="#">here</a> for star rating definitions.
Bandwidth	Shows the bandwidth of the selected signal type.
Notification area	Notes may appear between the Signal Type and Signal Standard fields.
Signal Standard	For classified regions, this field is not editable. For unclassified regions, this field is a drop-down list of all enabled signal standards (set in the Signal Database) and standards for which channels are enabled. The standards and their channels that best match the center frequency of the region are starred in this list. See <a href="#">here</a> for star rating definitions.
Frequency	Shows the channel frequency of the selected signal standard.
Channel	Shows the channel number for the selected signal standard. .

### Criteria for signal standard and type star ratings.


Criteria		
Star	Signal standards	Signal types
★	The region center frequency matches the selected signal standard channel frequency and the selected signal standards database signal type matches that of the selected signal type.	The region bandwidth exactly matches the selected signal type bandwidth.
★	The region center frequency matches the selected signal standard channel frequency.	The region bandwidth is within $\pm 5\%$ of the selected signal type bandwidth and does not exceed the defined min/max matching bandwidth range of the selected signal type.
★	A large portion of the region start/stop frequency overlaps the selected signal standard channel frequency.	The region bandwidth is within the defined min/max matching bandwidth range of the selected signal type.
★	A small portion of the region start/stop frequency overlaps the selected signal standard channel frequency.	Not applicable.
No star	No portion of the region start/stop frequency overlaps the selected signal standard channel frequency.	The region bandwidth is outside the defined min/max matching bandwidth range of the selected signal type.

### Survey Summary tab

Region	Survey Summary	Preferences			
	Frequency	Span	Classification	Type	Standard
▶ 1	876.2 MHz	4.0 MHz	Permitted	WCDMA	WCDMA 850
2	879.210653 MHz	267.342 kHz	Permitted	GSM	GSM 850
3	879.78 MHz	280.0 kHz	Permitted	GSM	GSM 850
4	885.19443 MHz	9.012658 MHz	Unknown	Not Set	Not Set
5	893.07038 MHz	1.3 MHz	Permitted	CDMA2000 1xEV-DO	1xEV-DO N.A. Cellular

Item	Description
Summary table of all of the regions in the active plot	Each region is identified by a number.
	The center frequency of the region.
	The span of the region.
	The classification of the signal in the region.
	The signal type of the signal in the region, if it has been set. Otherwise, this field reads Not Set.
	The signal standard and channel of the signal in the signal in the region, if it has been set. Otherwise, this field reads Not Set.

### Preferences tab



Item	Description
Spectral Profile	<b>Off</b> turns the spectral profile off so that it does not appear on the plot. Use this option if you want to view the signal in the region without the spectral profile overlayed on the signal.
	<b>Snap to Center of Region</b> aligns the spectral profile to the center of the region. Use this option if you know that the frequency you are viewing has no defined signal standard channels in the database.
	<b>Snap to Channel Frequency</b> aligns the spectral profile with the specified signal standard channel frequency of the signal. Use this option if you want to check that the channel frequency of the spectral profile matches the signal frequency you are looking at. If the selected signal standard channel frequency is within the selected region, then the spectral profile will center on that channel frequency. If the channel frequency is outside of the selected region, then the spectral profile will snap to the center of the region.

### See also:

[Define a region using known standards.](#)

## The Declare Region window (classify)

Click the **Classify...** button on the Signal Survey toolbar to access the Declare Region window. Once a region is classified, you can no longer change the signal type or signal standard in the Region tab of the [Define Survey control panel](#). The following image and table describe the Declare Region window.

**Declare Region**

Classification: Permitted

Description: Probably permitted

Comments: Not 100% sure this GSM-850 channel 181

**Signal**

Type: GSM  
Standard: GSM 850

**Region**

Frequency: 879.78 MHz  
Span: 280.0 kHz

OK Cancel

Item	Description
Classification	Lists classification types to assign to the current region. Each classification has a unique color that is assigned to the region box: None: Gray Unknown: Yellow Unauthorized: Orange Permitted: Blue
Description	Enter a brief description to identify the region.
Comment/Notes	Enter additional comments to provide needed information regarding the region.
Signal	Lists the selected signal type and signal standard of the selected region.
Region	Lists the span and center frequency of the selected region.

---

**NOTE.** If a region is classified, you need to change the classification to "None" before you can make any changes to that region.

---



## Saving and Recalling Data, Settings, and Pictures

You can save different types of data for later recall and analysis.

Data type	Description	Save as type
Setup files	Saves all of the setup information for all displays, except those settings that are not part of Preset.	Setup (.Setup)
Picture of Selected Display (PNG/JPG/BMP)	Saves a capture of the screen in the specified format. This option is useful for including the graphic in reports or other applications. Marker readouts and other information are included.	Picture (.BMP, .PNG, .JPG)
Results Export files	Saves the trace and numeric data for the selected display. The trace and numeric data are saved as CSV files.	Results export (various)
Measurement Settings	Saves a list of settings relevant to the selected measurement to a text file. This option is useful for including the measurement settings in reports.	Measurement settings export (TXT)
Trace	Saves a trace for later recall into the display from which it was saved.	Selected trace (various)
Data	Saves data for reanalysis later or as data to use with external software (either CSV (comma-separated value) or MAT (MATLAB format)).	Acquisition data with setup (TIQ); or Acquisition data export (CSV or MAT)

### Saving Files

Saving files follows the same procedure regardless of the type of data being saved. To save setups (including application presets), pictures, results, or acquisition data:

1. If you are going to save DPX Spectra (DPXogram) acquisition data, stop acquisitions.  
Saving while running is allowed by the analyzer, but data files saved while running will not contain any DPX spectral data.
2. Select **Save As** from the **File** menu to open the **Save As** dialog box.
3. Navigate to the folder where you want to save the setups, or use the default location.
  - To save setups so that they appear in the Application Presets window, save your setup in the folder **C:\SignalVu-PC Files\User Presets**. The saved setup will appear in the Application Presets window with the name you give the file.
4. Enter a file name.
5. Select the type of file to save from the **Save as type** drop-down list.
6. Click **Save**.

## Recalling Files

You can recall three types of files: Setup files, Selected Trace, and Acquisition data with setup. Recalling data follows the same procedure regardless of the type of data being recalled.

1. Select **Recall** from the **File** menu to open the **Open** dialog box.
2. Navigate to the folder containing the file you want to recall.
3. Select the type of file to recall from the **Files of type** drop-down list. This selection determines the files that appear in the Open dialog box.
4. Select the file to recall.
5. Click **Open**.

## Recalling waveforms with SignalVu-PC

SignalVu-PC can recall waveform files saved by Tektronix oscilloscopes and spectrum analyzers. It can also read files saved in MATLAB Level 5 format. Waveform files can be recalled two ways: as Data and setup, and as Data only.

The following tables lists the supported file formats and includes notes about using the files.

**Table 13: RSA5000/RSA6000/SPECMON file formats supported by SignalVu-PC**

Generated by			RSA5000/ RSA6000/ SPECMON	
File type			.tiq	.mat
File description			Contains corrected I and Q time-domain data, all settings and measurement setup	Contains I and Q time-domain data, center frequency, sample rate
What SignalVu-PC can do with this format	Open with settings	All Settings and Measurements are Recalled	✓	✓
	Open as data only	Uses settings from SignalVu-PC when opened	✓	✓
Notes			This is the native format for SignalVu-PC. It contains all information needed to open and analyze all displays available, plus system information not used in analysis.	Contains all information needed to open and analyzer files with SignalVu-PC. Can be opened by MATLAB.

**Table 14: RSA3000 and WCA200 file formats supported by SignalVu-PC**

Generated by			RSA3000, WCA200	
File type			.iqt	.mat

Table 14: RSA3000 and WCA200 file formats supported by SignalVu-PC (cont.)

File description		Contains I and Q time-domain data, center frequency, sample rate, amplitude and phase corrections		Contains I and Q time-domain data, center frequency, sample rate	
What SignalVu-PC can do with this format	Open with settings	All Settings and Measurements are Recalled			
		Automatically Sets Span, Center Frequency	✓		✓
	Open as data only	Uses settings from SignalVu-PC when opened	✓		✓
Notes		Recommend saving as .tiq file after opening		Recommend saving as .tiq file after opening	

Table 15: WCA300 file formats supported by SignalVu-PC

Generated by		WCA300			
File type		.iq			
File description		Contains I and Q time-domain data, center frequency, sample rate, amplitude and phase corrections			
What SignalVu-PC can do with this format	Open with settings	All Settings and Measurements are Recalled			
		Automatically Sets Span, Center Frequency	✓		
	Open as data only	Uses settings from SignalVu-PC when opened	✓		
Notes		Recommend saving as .tiq file after opening			

Table 16: SignalVu on oscilloscopes file formats supported by SignalVu-PC

Generated by		SignalVu on oscilloscopes			
File type		.tiq		.mat	
File description		.tiq format as used by SignalVu, all versions, includes I and Q time domain data, all settings and measurement setup		Contains I and Q time-domain data, center frequency, sample rate	

**Table 16: SignalVu on oscilloscopes file formats supported by SignalVu-PC (cont.)**

What SignalVu-PC can do with this format	Open with settings	All Settings and Measurements are Recalled	✓	✓
		Automatically Sets Span, Center Frequency		✓
	Open as data only	Uses settings from SignalVu-PC when opened	✓	✓
Notes			This is the native format for SignalVu-PC. It contains all information needed to open and analyze all displays available	Recommend saving as .tiq file after opening

**Table 17: Performance Oscilloscope (without SignalVu) file formats supported by SignalVu-PC**

Generated by		MSO/DPO/DSA5000/7000/70000		
File type		.wfm		
File description		Amplitude vs. Time, includes sample rate information		
What SignalVu-PC can do with this format	Open with settings	All Settings and Measurements are Recalled		
		Automatically Sets Span, Center Frequency		
	Open as data only	Uses settings from SignalVu-PC when opened	✓	
Notes		Prior to opening: Preset SignalVu-PC. Set span and center frequency. After opening, save as .tiq file. Reopen the .tiq file for further changes to the measurement settings and opening additional displays		

**Table 18: Bench Oscilloscope file formats supported by SignalVu-PC**

Generated by		MSO/DPO 2000, 3000, 4000		
File type		.isf		
File description		Amplitude vs. Time, includes sample rate information		

**Table 18: Bench Oscilloscope file formats supported by SignalVu-PC (cont.)**

What SignalVu-PC can do with this format	Open with settings	All Settings and Measurements are Recalled	
		Automatically Sets Span, Center Frequency	
	Open as data only	Uses settings from SignalVu-PC when opened	✓
Notes		Prior to opening: Preset SignalVu-PC. Set span and center frequency. After opening, save as .tiq file. Reopen the .tiq file for further changes to the measurement settings and opening additional displays	

**Table 19: MDO4000B/C mixed domain oscilloscope file formats supported by SignalVu-PC**

Generated by		MDO4000B/C, RF channel	
File type		.tiq	
File description		Contains I and Q time domain data. Opens with spectrum analyzer and time overview.	
What SignalVu-PC can do with this format	Open with settings	All Settings and Measurements are Recalled	
		Automatically Sets Span, Center Frequency	
	Open as data only	Uses settings from SignalVu-PC when opened	✓
Notes		Native format for SignalVu-PC. Opens with Time Overview and Spectrum Display active	

**Table 20: H500 and SA2500 file formats supported by SignalVu-PC**

Generated by		RF Hawk	
File type		.iqt	.mat
File description		Contains I and Q time-domain data, center frequency, sample rate	Contains I and Q time-domain data, center frequency, sample rate

Table 20: H500 and SA2500 file formats supported by SignalVu-PC (cont.)

What SignalVu-PC can do with this format	Open with settings	All Settings and Measurements are Recalled		
		Automatically Sets Span, Center Frequency	✓	✓
	Open as data only	Uses settings from SignalVu-PC when opened	✓	✓
Notes			Recommend saving as .tiq file after opening	Recommend saving as .tiq file after opening

Table 21: User generated (including Agilent 89601 software) file formats supported by SignalVu-PC

Generated by		User generated (including Agilent 89601 software)		
File type		.mat		
File description		MATLAB Level 5 format, must contain at least InputCenter, InputZoom, Xdelta, and Y		
What SignalVu-PC can do with this format	Open with settings	All Settings and Measurements are Recalled		
		Automatically Sets Span, Center Frequency	✓	
	Open as data only	Uses settings from SignalVu-PC when opened	✓	
Notes			Recommend saving as .tiq file after opening	

To recall a acquisition data file, see [Recalling Files \(see page 834\)](#) above.

**Opening .iqt files saved by RSA3000 and WCA300 analyzers.** To open a .iqt file:

1. Select **File > Preset (Main)**.
2. Select **File> Recall** and select **Acq Data with Settings (IQT) (\*.iqt)** in the Open dialog. Select the desired file and click **OK** to open the file.
3. Save the file by selecting **File > Save As** and set the file type to **Acq data with setup (TIQ) (\*.tiq)**. Save the file by clicking **OK**.

Saving the file in .tiq format preserves all of the settings in the analyzer and associates them with the data set. After saving the file in .tiq format, recall the saved .tiq file and add measurements and change settings.

The .iqt file format contains I and Q waveforms plus instrument amplitude/phase correction data, analysis bandwidth and center frequency. When SignalVu-PC opens an .iqt file, the amplitude and phase

corrections are applied to the IQ data to produce a corrected data set. The span and center frequency information present in the .iqt file are used to set the SignalVu-PC span and center frequency. However, no information about analysis length, offset or type is preserved in the .iqt file.

**Opening .mat files saved by RSA5000/6000/SPECMON series and third party waveforms.** To open a .mat file from these instruments:

1. Select **File > Preset (Main)**.
2. Select **File> Recall** and select **Acq Data with Setup (MAT) (\*.mat)** in the Open dialog. Select the desired file and click **OK** to open the file

If you choose to save the file in .mat format, SignalVu-PC automatically adds all of the SignalVu-PC settings needed for your analysis into the stored .mat file.

**Opening files saved with oscilloscopes.** Oscilloscopes acquire and store data in an amplitude vs. time format that must be converted by SignalVu-PC into an IQ format for further processing. Sample-rate and amplitude information is available in these files, but no other information is available to SignalVu-PC.

To open files stored in either .ISF or .WFM format saved by Tektronix oscilloscopes, use the following procedure:

1. Preset SignalVu-PC. This resets the analysis so that only the spectrum analyzer display is present, with a center frequency of 250 MHz and a span of 200 MHz.
2. Set the Span of SignalVu-PC to  $0.2 \times \text{Sample Rate}$  of the acquisition.

How to determine the maximum available span for your .ISF or .WFM file: The maximum span is calculated to be  $0.4 \times \text{Sample Rate}$ . For example, a waveform sampled at 1 GSample/second will have a maximum span of  $0.4 \times (109) = 400$  MHz. This represents the Nyquist bandwidth of the sampling system plus an allowance for filter bandwidth. Note that this span may exceed the bandwidth of the oscilloscope used, and results at frequencies higher than the oscilloscope bandwidth will be attenuated.

When processing the waveform, SignalVu-PC automatically sets the bandwidth to twice the entered span to allow for increasing the span in later analysis. Set the span of the spectrum analyzer to  $\frac{1}{2}$  the calculated maximum span. In the case of the example of above, this is  $\frac{1}{2} \times 400$  MHz, or 200 MHz.

3. Set the center frequency to  $\frac{1}{2}$  of the span. This puts the analysis frequency within the first Nyquist zone to prevent aliasing of the signal.
4. Open the .ISF or .WFM file with the settings above.
5. Set the span to the calculated maximum (in the example above,  $0.4 \times \text{Sample Rate} = 400$  MHz) and reanalyze.
6. Save the results as a .TIQ file. This preserves all of the settings in the analyzer and associates them with the data set.

## Setup Files

You can set up the instrument as desired and then save the settings in a setup file. This enables you to quickly setup the instrument by recalling previously saved setups.

## Exporting Results

Save for further analysis of results in other programs, such as MATLAB or Excel.

## Pictures of the Selected Display

You can save pictures of the instrument display for documentation purposes. When saving pictures of the display, you can select from three file types: BMP, JPG, or PNG.

## Measurement Settings

You can save a list of settings relevant to the selected display to a file for documentation purposes. The exported file uses tab characters to separate values. The settings included in the file depend on the selected display. The contents of the file are the same as a Results export except it does not include the results.

## Saving Acquisition Data with Setup

Save for later analysis with the analyzer. The setup is saved as part of the acquisition data file so you can choose when recalling data whether or not to also recall the associated acquisition and analysis parameters.

## Saving Acquisition Data Export in CSV Format

Save for examining results in other programs, such as MATLAB or Excel.

# Data, Settings, and Picture File Formats

You can save different types of data for later recall and analysis.

## Saved File Types

File type	File extension	Description
Setup files	.setup	Setup files enable you to save instrument settings for later recall. Using these files saves setup time and ensures consistent measurements.
Picture	.png/.jpg/.bmp	Screen capture of SignalVu-PC application window. They are useful for documenting results in test reports.
Results Export	.csv	Results files contain the trace points and numeric values that were produced by the selected measurement. The header of a Results file includes key acquisition and analysis settings to aid in the interpretation of the data. The file is saved as a plain text file, but the contents are formatted as CSV (comma-separated values). Results files can be opened from applications such as Microsoft Excel and MATLAB.



File type	File extension	Description
Measurement Settings	.txt	Measurement settings files contain a list of settings that describe how the instrument is set up for the selected measurement. The list contains measurement settings (for example, Span), trace settings (for example, whether or not a trace is selected) and global settings (for example, Frequency and Reference Level). The list of settings contained in the file varies depending on which display is selected.
Selected Trace	Varies with display	Trace files contain the trace results data in binary format. These files are only readable by the SignalVu-PC application. Several of the instrument's measurements allow you to recall a Trace file for visually comparing a saved trace to a live trace.
Acquisition Data with Setup	.tiq	These files contain the acquisition data record and complete instrument setup (in binary format). Use these files to save data for later recall and analysis. When you save an Acquisition Data file, the current Setup is always saved with the file. At the time of recall, you will be asked whether you want to restore only the acquisition data or both data and setup. If the instrument is already set up for a specific measurement, you will probably want to recall only the acquisition data. Recalling both data and setup returns the instrument to the same state it was in at the time you saved the file. GNSS time locked with GPS enabled.
Acquisition Data	.csv	These files contain IQ sample data before it has been processed by a measurement. The acquisition data points are saved as IQ pairs. Use this format to import the acquisition data into Microsoft Excel for further analysis.
Acquisition Data	.mat	These files contain IQ sample data before it has been processed by a measurement. The acquisition data points are saved as IQ pairs. Use this format to import the acquisition data into MATLAB for further analysis.  These files also contain instrument setting information. You do not have to use the settings information. To remove it, you can load all information to MATLAB, then write out is a .mat file without the settings information. (See the <a href="#">Acquisition Data Files (.mat)</a> (see page 844) topic for required .mat format.)
Range file	.csv	These files contain a list of settings that describe how the instrument is set up for the Spurious measurement. The file contains the number of ranges enabled, the start and stop frequencies for each enabled range, the limits for each enabled range, the mask type and more.
Recorded file (RSA500A series, RSA600A series, and RSA306B only)	.r3f	These files contain acquisition data that was recorded directly to a file from an RSA306B, RSA500A series, RSA600A series spectrum analyzer.  These files can be played back using the Playback feature located in the Acquisition control panel (with Option SV56-SVPC).
Recorded file (When connected to an RSA)	.cdif	This combined file contains header and IF samples (IQ samples for the RSA7100A) in Midas 2.0 (Platinum BLUE) format. These files contain acquisition data that was recorded directly to a file from an RSA306B, RSA500A series, RSA600A series, or RSA7100A spectrum analyzer.

File type	File extension	Description
Recorded file (When connected to an RSA)	.cdif + .det (or .det12)	<p>This is a separate header (.cdif) file and an IF sample (IQ sample for RSA7100A) data (.det or .det12) file in Midas 2.0 (Platinum BLUE) format.</p> <p>When using the RSA7100A, recordings at 800 MHz bandwidth with the packed data setting on will generate a .cdif and a .det12 file. (See the <a href="#">Midas recording choices</a> table for more information about the .det12 file type.)</p>
Recorded file (RSA7100A only)	xdat, .xhdr, .xmkr	<p>These 3 files (all with the same file name) are generated when XCOM is the selected format for recording. They can be played back using an external application. GNSS time locked with GPS enabled.</p> <p><b>.xdat:</b> sample data file containing binary IQ samples in normal (16 bit integer) or packed (12-bit integer) data type.</p> <p><b>.xhdr:</b> header file containing instrument setup information in XML format.</p> <p><b>.xmkr:</b> marker file in XML format containing time, location (GPS only), and the time stamp of the GPS, PPS, or IRIG-B event during recording.</p> <p>See the <a href="#">Record Setup (see page 774)</a> topic for more information.</p>

## Results Export File Format

The Results Export format contains trace points and/or scalar results produced by the measurement. The file contains general information about the measurement settings at the top of the file and the results data in the second part of the file. Groups of settings or results are headed with [text], as described below.

At the top of the file is the measurement name and the date and time data was acquired.

The first group of settings is [Global Parameters]. These settings include the Measurement Frequency, Acquisition Data, Reference Level and others.

The second group of settings is [Parameters]. These settings are specific parameters which vary depending on the measurement.

The next group is [Trace Parameters], which may not be present, depending on the measurement. Within this group, there are parameters specific to a trace. There will be a Trace Parameters group for each trace shown on the display.

The next group is [Results]. These are scalar results for the measurement.

Next is [Traces]. The Traces group consists of one or more [Trace] groups. There is one Trace group for each trace. Each [Trace] group contains background information about the trace (units, number of points, x scaling, and others depending on the measurement) at the top of the group, followed by the trace points.

## Acquisition Data with Setup File (.tiq) Format

The file consists of two parts: the header that is in XML and the data that is in binary format.

**Header.** The header consists entirely of the DataFile element. This element is broken down into sub-elements.

1. DataSetsCollection
2. Setup
3. GNSS data

The GnssData group starts at byte location 612,312. GNSS data is bracketed as `<GnssData></GnssData>`. Each GNSS parameter is bracketed by its name. For example, `<PositionX>76.854334</PositionX>`.

In order of occurrence:

- Status
- Position X
- Position Y
- Altitude
- Timestamp
- Speed
- Course
- Satellites Locked

**DataSetsCollection.** The DataSetsCollection contains a DataDescription element, a DataSet element, and a ProductSpecific element.

**Binary data.** Binary data is a sequence of Int32 values, which are IQ pairs (I,Q,I,Q, ...) in binary Little Endian format.

To convert these values to volts, multiply the individual values by the Scaling value in the DataDescription.

The binary data starts at an offset into the file == the "offset" attribute in the DataFile element. This offset number will always start at the 19th character into the file (starting with 1), and will always be 9 characters long.

---

**NOTE.** *Modifying the XML header will change the offset to the start of the binary data.*

---

### Acquisition Data Files (.csv)

The acquisition data files have two sections. At the top of the file is the following information:

- SamplingFrequency - The sampling frequency in Hertz.
- NumberSamples - The number of IQ samples in the file.
- DateTime - When the data was acquired.
- Frequency - The center frequency in Hertz.
- AcquisitionBandwidth - The acquisition bandwidth Hz.

Following the AcquisitionBandwidth are the data. The data are IQ pairs, in volts.

Groups of settings or results are headed with [some text].

The first thing in the file is the measurement name and the date/time when the acquisition was taken.

The first group [Parameters] are global parameters. Measurement Bandwidth in this group is the measurement bandwidth used by the General Signal Viewing measurements (Spectrum, Amplitude vs. Time, etc). It also includes some source settings, like Acq BW, Dither, Preamp, and RF Attenuation.

The second group [Parameters] are measurement-specific parameters.

Another group which can occur is [Trace Parameters]. Within this group, there will be a set of parameters, one for each trace that is currently shown.

Another group is [Results]. These are scalar results for the measurement.

Another group is [Traces]. It has [Trace] groups under it, one for each trace. Each [Trace] group has some background information about the trace (units, number of points, x scaling, etc), and the trace points themselves.

### Acquisition Data Files (.mat)

The acquisition data files saved in MATLAB format contain the following MATLAB variables:

- InputCenter - The center frequency in Hertz.
- XDelta - The sample period in seconds.
- Y - A complex array containing IQ pairs.
- InputZoom - The acquisition bandwidth in Hertz.

The MATLAB format used to save acquisition data has the following properties and limitations:

- Files are stored in MATLAB Level 5 format.
- MATLAB Level 5 file size is limited to 2 GB.

## Printing Screen Shots

You can print screen shots (screen captures) two ways: use File > Print or save a picture file and print the file using a separate graphics program. Printing a screen capture is the same as printing with any windows program. For details on the available file formats for saving a screen capture, refer to [Data, Settings, and Picture File Formats \(see page 840\)](#). For details on saving a picture to a file, see [Saving and Recalling Data, Settings, and Pictures \(see page 833\)](#).

To print a screen shot:

1. Select **File > Print**.
2. Select **File > Print Preview** if you wish to review the screen shot before sending it to the printer.
3. Select **File > Print** to print the file to a printer.


## Application Help

### Menu Bar: Help > User Manual

This menu item displays this Help. It is a standard Windows help system. The Help menu item is the only method available to display the help; there are no other links to the help within the software.

## About the Vector Signal Analysis Software

This window displays information about the SignalVu-PC software.



### Version

At the top of the window is a line that displays the version of the SignalVu-PC software.

### Installed Options

This text box lists the software options installed.

### Hardware Information

This text box lists the serial number of the software and information about connected instruments.

## Copy Info


The Copy Info button copies the information to the Windows clipboard, which you can then paste into a document. This information may be useful if you need to contact Tektronix about the software.

## Mapping Measurements

The RSA Map software lets you record measurements on a geo-referenced map or a bitmap map for documentation purposes. If an external GPS receiver is connected to the analyzer, measurements can be mapped at the GPS coordinates where the measurement was taken. Using an external GPS receiver, RSA Map can perform repeat measurements using either time or distance to initiate measurements. RSA Map software can also save results for future reference or analysis.

To map measurements:




- Select Tools > RSA Map. This launches the RSAMap software in a separate window.



Full documentation on how to use RSA Map is provided in the RSA Map Help. In RSA Map, select **Help > User Manual**.

## Main menu overview

The main menus are:

Menu	Description
	<p>The display icon indicates which display is currently active in the application. Right click on this icon to view the following drop-down menu. These options allow you to control the individual measurement window view.</p> 
Favorites bar toggle 	This icon allows you to toggle to hide or show the <a href="#">Favorites bar</a> . The Favorites bar is located just below the Main Menu bar, is editable, and provides icons for quick and easy access to functions and menus.
<a href="#">File (see page 848)</a>	Select measurements, open and save files, print documents, and preset.
<a href="#">View (see page 852)</a>	Change display size, display the Marker toolbar and Status bar.
<a href="#">Run (see page 856)</a>	Start, stop and abort acquisitions, select single or continuous acquisition mode. Only available when connected to an RSA306, RSA306B, RSA500A series, and RSA600A series spectrum analyzer or an MSO4000B/C oscilloscopes.
<a href="#">Replay (see page 753)</a>	Replay measurements; select which record(s) to play, Replay/Stop/Pause, or enable continuous loop.
<a href="#">Markers (see page 857)</a>	Search for signal peaks, center the display to a marker, and access the Define Marker panel.
<a href="#">Setup (see page 857)</a>	Change settings for acquisition, analysis, and measurements.
<a href="#">Presets (see page 25)</a>	Load and configure presets.
<a href="#">Tools (see page 858)</a>	Perform searches and configure user preferences.


Menu	Description
<a href="#">Connect (see page 862)</a>	Connect and disconnect from instruments.
<a href="#">Window (see page 862)</a>	Controls the size and layout of displays within the SignalVu-PC application.

## File Menu

Command	Description
<a href="#">Recall (see page 848)</a>	The Recall dialog enables you to recall saved data, setups and traces.
<a href="#">Save (see page 849)</a>	Saves a file without asking for a file parameters (based on most recent settings).
<a href="#">Save As (see page 849)</a>	Displays the Save dialog enabling you to specify the parameters of the save operation.
<a href="#">Save on trigger (see page 794)</a>	Displays the Actions tab of the Trigger control panel which allows you to configure the Save on Trigger function. This is only available when connected to an RSA306, RSA306B, RSA500A series, and RSA600A series or MDO4000B/C.
<a href="#">Acquisition save options (see page 34)</a>	Displays the Save and Export tab of the Options control panel which allows you to specify how much data is saved in acquisition files.
<a href="#">Acquisition data info (see page 753)</a>	Displays the <a href="#">Acquisition Info tab (see page 753)</a> of the Replay control panel. The info on this tab describes such acquisition parameters as acquisition bandwidth, sampling rate, RF attenuation, and acquisition length.
<a href="#">Measurement Data Info (see page 851)</a>	Displays the characteristics of the most recently analyzed record in the display.
<a href="#">Print (see page 852)</a>	Prints the selected display.
<a href="#">Print Preview (see page 852)</a>	Displays a preview of the print output.
Exit	Closes the SignalVu-PC application.

## Recall

**Main menu bar:** File > Recall


**Favorites toolbar:** 

Use the Recall command to load previously saved acquisition data, setups or trace data.

### To Recall Data or Setups

1. Select **File > Recall**. This displays the **Open** dialog box.





2. Select the file type to be recalled and click **Open**.

## Save / Save As

### Menu Bar: File > Save / Save As

Use Save / Save As to store acquisition data, setups, and traces. Save is also used to export traces, results and pictures of the display for use in other programs.

### Difference Between Save and Save As

Use Save As to specify what kind of data you want to save and where the data should be saved. Use Save to quickly save the same data as you saved the last time you executed a Save, without having to specify the data type and location.

For example, suppose you want to save a picture of a spectrum trace each time you adjust a circuit to document how the adjustments affect the output of the circuit. The first time you want to save a picture of the display, you will need to select Save As. From the Save As dialog box, you specify the type of data you want to save (Picture of Selected Display) and specify the location of the saved file. As long as the [Save and Export option](#) is set to automatically name saved files, the next time you want to save a picture of the display, you can just press Save on the front panel and a picture of the selected display will be saved without requiring you to type a file name or the location of the file to be saved.

## What Data Types Can Be Saved

Data type	Description
Acquisition Data	Acquisition data previously recalled can be exported with different settings. Data is saved in a format readable only by SignalVu-PC, oscilloscopes running SignalVu software, or RSA6100/RSA5100/SPECMON Series instruments.
Setup	Configuration information detailing instrument settings. Data can be saved in a format readable only by SignalVu-PC, oscilloscopes running SignalVu software, or RSA6100/RSA5100/SPECMON Series instruments.
Selected Trace	Saves the selected trace for later analysis by the analyzer. Data is saved in a format readable only by SignalVu-PC, oscilloscopes running SignalVu software, or RSA6100/RSA5100/SPECMON Series instruments.
Exported Traces and Numeric Results	Save traces and results in a file format that can be used by other programs.
Pictures of the Display	Save screen images in graphic image file formats that can be used in other programs.
Exported Acquisition Data	Save acquisition data records in a file format that can be used by other programs. Acquisition data can be saved in either comma-separated-variable format or MATLAB format.


[Data, Settings, and Picture File Formats \(see page 840\).](#)

## Options for Saving Pictures of the Display

Option	Setting	Description
Image Format	PNG	Saves exported screen captures in Portable Network Graphics format.
	JPG	Saves exported screen captures in Joint Photographic Experts Group (JPEG) format.
	BMP	Saves exported screen captures in Windows bitmap format.


## Measurement Data Info

The Measurement Data Info command in the File menu displays a listing of acquisition-related information about the last data analyzed by the selected measurement. The last data can be from the current acquisition or it could be from a recalled data file.



## Acquisition Data

The Acquisition Data tab displays the sample rate and record length of the data received from the oscilloscope or from a recalled oscilloscope waveform file.



# Print

**Menu Bar:** File > Print

Print displays the Windows Print dialog box for printing a screen capture of the display. To save ink when printing, use the Colors tab to set the color scheme. See [Options Settings](#) .


# Print Preview



**Menu Bar:** File > Print Preview

Print Preview shows how a print out will appear when it is printed.

# View Menu

The View menu enables you to control the display of views and toolbars in the application window.

Command	Description
<a href="#">Full Screen (see page 853)</a>	Toggles all views between full-screen size and user-selected size.
<a href="#">Navigator View (see page 92)</a>	Selecting Navigator View adds the Time Overview display to the existing measurement displays to provide a better perspective of the signal.  When the Navigator View is enabled, the Time Overview display is always located above any other measurement displays and uses the maximum horizontal resolution of the display area, regardless of the Window Tile setting.
Numeric Keypad	When selected, any time you place the cursor within a control or setting that takes a numeric value, you are presented with a dialog box to easily enter a value.  For instance, placing the cursor in the Frequency setting, displays the following dialog screen. <div data-bbox="561 1352 1039 1665"></div>
	Use the arrow buttons to change the value.  Press the calculator icon to display a keypad that allows you to enter values and suffixes.
<a href="#">Chan Nav Toolbar (see page 816)</a>	Check to view the Channel Navigation toolbar. Uncheck to hide it. Detailed information about this toolbar is available in the Channel Navigation toolbar topic.

Command	Description
<a href="#">Signal Survey Toolbar (see page 827)</a>	Check to view the Signal Survey toolbar. Uncheck to hide it. Detailed information about this toolbar is available in the Signal Survey toolbar topic.
<a href="#">Map It Toolbar (see page 803)</a> (Only available with optional MAP application license.)	Check to view the Signal Survey toolbar. Uncheck to hide it. Detailed information about this toolbar is available in the How to use Map It topic.
<a href="#">Replay Toolbar (see page 756)</a>	Check to view the Replay toolbar. Uncheck to hide it.
Traces Toolbar	Check to view the Traces toolbar. Uncheck to hide it. This toolbar can also be accessed from the Basic Controls Toolbar. It allows quick access to the trace controls of the selected measurement display. This example is the Spectrum trace toolbar. 
<a href="#">Markers Toolbar (see page 734)</a>	Check to view the Markers toolbar. Uncheck to hide it. This toolbar can also be accessed from the Basic Controls Toolbar. It enables you to define Markers and perform Peak searches. Click the Define button on the toolbar to define markers. See the <a href="#">Define Markers menu</a> topic for detailed information.
Basic Controls Toolbar	The Basic Controls toolbar is defaulted to on and is located just above the Status Bar. It allows quick access to controls and settings of the selected measurement display. This example is the Spectrum Basic Controls toolbar.  It contains the following: <ul style="list-style-type: none"> <li>■ Name of selected measurement window</li> <li>■ Frequency: The center frequency in the active display. To change the value, click the text and enter a value with a keyboard or the numeric keypad. For fine adjustments, you can use the mouse wheel.</li> <li>■ Reference: Reference level in the active display. To change the value, click the text and enter a value with a keyboard or the numeric keypad.</li> <li>■ Span: The span in the active display. To change the value, click the text and enter a value with a keyboard or the numeric keypad. For fine adjustments, you can use the mouse wheel.</li> <li>■ Res BW: The resolution bandwidth (RBW) in the active display. To change the value, click the text and enter a value with a keyboard or the numeric keypad. For fine adjustments, you can use the mouse wheel.</li> <li>■ Show or hide the Markers toolbar</li> <li>■ Show or hide the Traces toolbar</li> <li>■ Show or hide the Settings Control Panel</li> </ul>
<a href="#">Status Bar (see page 854)</a>	The Status bar is defaulted to on and is located at the bottom of the application window.

## Full Screen

**Menu Bar: View > Full Screen**

When unchecked, clicking **Full Screen** resizes the application window to fill the screen. Full Screen mode maximizes the application window, and turns off the application title bar.




When checked, clicking **Full Screen** restores the application window to its previous size. The application title bar is restored.

## Status Bar

The Status Bar displays information on specific instrument settings. It contains only status information; it does not display any error information. The Status bar has no controls. It can not be hidden.



## Elements of the Status Bar

Area within Bar	Description
Run status	Displays the running state. For example, some run states are Arm, Ready, Triggered, Analyzing, or Stopped.
Status message area	Displays status messages (for example, ADC Overrange). When there no status messages to report, displays current acquisition parameters (for example, Acq Length: 22.320 us).
Acquisition mode	Displays either Real Time or Swept. Indicates how the next acquisition will be acquired.
Trigger settings (Shows only when connected to an RSA)	Displays Trigger settings. For example, you will see Free Run, Power, Trig In (front), Frequency Mask and others.
Frequency Reference setting	Indicates whether the internal or external reference source is selected. Displays Ref: Int or Ref: Ext.
Attenuation settings (Shows only when connected to an RSA)	Displays the setting of the internal attenuator.
Preamplifier setting (Shows only when connected to an RSA)	If the optional preamp is installed, this indicates whether the preamp is on or off. If the preamp is on, displays Preamp: ON, 3 GHz max. as a reminder that the input frequency range is restricted when using the preamp.
TG (tracking generator) status (Shows only when connected to an RSA500 or RSA600 with Option 04 installed)	Indicates whether the tracking generator is on or off.
Battery status (Shows only when connected to an RSA500)	Shows a battery status icon when connected to an RSA500 instrument. See the <a href="#">Battery Status (see page 860)</a> topic for details.
Connection status (Shows only when connected to an RSA)	<p> indicates a GNSS connection status (a green, yellow, or red icon indicates locked, unlocked, or COM error, respectively).</p> <p> indicates the application is connected to an instrument;  indicates the application is not connected to an instrument.</p> <p>See the <a href="#">Connect menu (see page 862)</a> topic for details.</p>

## Run Status Indicators

Indicator	Description
Acquiring	SignalVu-PC is capturing the signal from a connected MDO4000B/C series oscilloscope or RSA306, RSA306B, RSA500A series, RSA600A series, or RSA7100A spectrum analyzer.
Analyzing	SignalVu-PC is processing the signal record from a connected MDO4000B/C series oscilloscope or an RSA306, RSA306B, RSA500A series, RSA600A series, or RSA7100A spectrum analyzer.
Replaying	SignalVu-PC is analyzing recalled waveform or acquisition records.
Stopped	If Stopped is displayed, no analysis being performed. This can occur because the Stop button has been pressed (when Replay is set to Loop) or because the software has just been launched and no analysis has been performed yet.
Triggered	If Triggered is displayed, the analyzer has recognized a valid trigger and is filling the posttrigger portion of the signal record.

## Run Menu

(The Run menu is available only when connected to an RSA306, RSA306B, RSA500A series, RSA600A series, or RSA7100A spectrum analyzer or an MDO4000B/C instrument.)

The Run menu provides access to commands that control the signal acquisition.



Command	Description
<a href="#">Run Single (see page 765)</a>	Sets the acquisition mode to Single and runs one measurement/acquisition cycle. If acquisition mode is already Single, selecting Run Single begins a new measurement/acquisition cycle. If acquisition mode is Continuous, selecting Run Single halts the current measurement/acquisition cycle after it completes.
<a href="#">Run Continuous (see page 765)</a>	Sets the acquisition mode to Continuous and starts the measurement/acquisition cycle. If acquisition mode is already Continuous, selecting Run Continuous toggles the measurement/acquisition cycle between Run and Stop.
<a href="#">Resume (see page 765)</a>	Restarts data acquisition, but does not reset accumulated results, such as Average or MaxHold. This allows you to stop acquisitions temporarily, then continue. If the accumulation is already complete, for example, 10 acquisitions or 10 averages have already been completed, each subsequent Resume command will cause one more acquisition to be taken, and its results added to the accumulation. Resume is not available if instrument settings have been changed.
<a href="#">Abort (see page 766)</a>	Immediately halts the current measurement/acquisition cycle.

## Replay Menu

The [Replay Menu \(see page 753\)](#) allows you to run measurements using the data in a recalled acquisition data file. You can use this to compute new results for old data after you change settings or measurements.

## Markers Menu

The Markers menu provides to settings that define and control the location of markers.

Setting	Description
<a href="#">Peak (see page 732)</a>	Moves the selected marker to the highest peak on the trace.
Next Peak >	Moves the selected marker to next peak depending on the setting chosen.
Marker to Center Frequency	Sets center frequency to the frequency of the selected marker.
<a href="#">Define Markers (see page 732)</a>	Displays the Define Marker control panel.

## Setup Menu

The Setup menu provides access to control panels that specify parameters for numerous signal analyzer functions.

Command	Description
<a href="#">Displays (see page 41)</a>	Displays the Select Displays window.
<a href="#">Settings (see page 872)</a>	Displays the Settings control panel for the selected display.
<a href="#">Trigger (see page 787)</a> (Available when connected to an RSA306, RSA306B, RSA500A series, RSA600A series, RSA7100A, or MDO4000B/C)	Displays the Trigger control panel.
<a href="#">Acquire (see page 766)</a>	Displays the Acquire control panel.
<a href="#">Analysis (see page 745)</a>	Displays the Analysis control panel.
<a href="#">Amplitude (see page 759)</a>	Displays the Amplitude control panel.
<a href="#">GNSS/Antenna (see page 795)</a>	Displays the GNSS/Antenna control panel.
<a href="#">Audio (see page 673)</a> (Available when connected to an RSA306, RSA306B, RSA500A series, or RSA600A series)	Displays the Audio demodulation control panel.
<a href="#">Recording (see page 773)</a>	Displays the Recording control panel, providing access to record file and playback file functions.
<a href="#">Configure In/Out and IQ Streaming (see page 807)</a>	Displays the IQ Streaming control panel. This panel provides access to some IQ streaming features, allowing you to stream IQ data using API, 40 GbE Ethernet, and LVDS.

## Presets Menu

The Presets menu provides you access to instrument presets and preset options.

Command	Description
<a href="#">Main (see page 25)</a>	Resets the instrument to factory defaults. Acquisition data and settings that have not been saved will be lost.
DPX	Recalls the DPX presets.
<a href="#">Standards Presets</a>	Recalls the Standards presets.
<a href="#">Application (see page 30)</a>	Recalls the Application presets.
<a href="#">User (Favorites) (see page 27)</a>	Recalls the User (Favorites) presets.
<a href="#">Preset Options (see page 25)</a>	Displays a control panel where you can configure options for Presets.

## Tools Menu


Provides access to several utilities for controlling instrument functions.

Command	Description
<a href="#">Mask Test (see page 739)</a>	Enables you to locate and highlight specified signal levels in specified displays.
<a href="#">Alignments (see page 859)</a>	Runs an alignment. If the analyzer is already aligned and you select Align Now, nothing will appear to happen because it is already aligned.
<a href="#">Licenses (see page 8)</a>	Used to activate SignalVu-PC optional application licenses (options).
Licenses > Legacy > Manage...	Used to activate a demo license or deactivate a license (used to move the license between PCs).
<a href="#">Options (see page 33)</a>	Displays the Options control panel.
<a href="#">Signal Database (see page 813)</a>	Allows you to select which signal standards and types are listed (and selectable) in the Channel Navigation toolbar and/or the Define Survey control panel.
RSAMap	Launches the optional MAP application.
<a href="#">Battery Status (see page 860)</a>	Provides battery status information if a RSA500 series instrument is connected.

## Alignments

### Menu Bar: Tools > Alignments

When SignalVu-PC is connected to an RSA300 series, RSA500 series, RSA600 series, or RSA7100A, this menu option is available. The analyzer can adjust itself, optimizing the internal signal path used to acquire the signal you measure. Alignment optimizes the analyzer to take more accurate measurements based on the ambient temperature. The Alignments dialog enables you to specify when alignments occur, either automatically or only when manually initiated.



**TIP.** Running an alignment during the warm-up period may result in a failed alignment. If this occurs, wait for the complete warm-up period of 20 minutes before performing an alignment.







### Elements of the Alignments Dialog

Setting	Description
Automatically align as needed	Specifies that alignments run as ambient conditions require.
Run alignments only when Align Now button is pressed.	Specifies that alignments will never run unless manually initiated.
Align Now	Use to manually initiate an alignment.  If the instrument is already aligned and you click the Align Now button, nothing will appear to happen. This is not an error of failure, but means that the instrument is already aligned the specified temperature range.
Close	Closes the Alignments dialog box.

## Battery Status tab

### Menu Bar: Tools > Battery Status

The Battery Status option in the Tools menu is only visible if you have an RSA500 series instrument connected. It opens the Battery Status tab. This tab displays the following details about the instrument's battery.

Item	Description
State	Shows the battery state as one of the following, along with the corresponding icon.
	<p>AC Present, No Battery</p> <p>A battery icon with a red circle and line through it indicates that no battery is detected and that power is being supplied through the power cord.</p>
	<p>Fully Discharged</p> <p>An empty battery icon indicates the battery is 0% charged.</p>
	<p>In Use</p> <p>A green battery icon with varying degrees of fill indicates the battery is in use and at the following % charged: 20%, 30%, 40%, 50%, 60%, 70%, 80%, 90%, 100%</p>
	<p>In Use</p> <p>A red battery icon with varying degrees of fill indicates the charge is getting critically low and you should charge the battery. This icon appears at the following % charged: 5%, 10%</p>
	<p>AC Present, Charging</p> <p>A green battery with a lightning bolt icon indicates that power is being supplied through the power cord and that the battery is charging.</p>
	<p>AC Present, Charged</p> <p>A green battery with a plug icon indicates power is being supplied through the power cord and that the battery is fully charged.</p>
Charge	Shows the current state of the battery charge status in %.
Manufactured	Shows the battery manufactured date.
Serial number	Shows the battery serial number.
Charge cycles	Shows how many charge cycles the battery has had.
Temperature	<p>Shows the current temperature of the battery.</p> <p>The internal charging circuit monitors the internal battery temperature. Normal charging is allowed when the battery temperature is between 0° C and 46° C. If the battery temperature falls outside of this range, charging will be suspended. Battery charging may resume once the battery temperature falls within this range.</p>

---

**TIP.** The battery will charge at a faster rate when the instrument is turned off. Charging the battery while the instrument is running will require a longer time to reach a full charge.

---

## Connect menu

Connect allows you to connect your PC (with SignalVu-PC installed) to the following instruments:

- MDO4000B/C Series instruments using USB, wireless, or LAN (SignalVu-PC with option CON required)
- RSA306, RSA306B, RSA500A series, and RSA600A series using USB

By connecting to one of these instruments, you are able to view and analyze waveforms in real time using the SignalVu-PC software.

You can find instructions for connecting to an instrument [here \(see page 35\)](#).

### Elements of the Connect Menu

Menu item	Description
Search for instruments	<p>An RSA306, RSA306B, RSA500A series, and RSA600A series connected via USB is automatically recognized by the software and automatically establishes a connection, so you do not need to search for the instrument.</p> <p>When connecting to an MDO4000B/C series instrument, use this menu to activate TekVISA to search for MDO4000B/C instruments that are connected by USB or through a LAN network.</p> <p>This menu is disabled if a connection to an instrument has been established.</p>
Connect to instrument	<p>Select to view a list of currently connected instruments or to manually look for an instrument.</p> <p>This menu is disabled if a connection to an instrument has been established.</p>
Manually look for LAN instrument	<p>(Available with option CON.) Select to open a dialog window that allows you to enter the IP address of an instrument to connect to.</p>
Disconnect from instrument	<p>Select to disconnect from the currently connected instrument. This is only available when you are connected to an instrument.</p>

## Window menu

Use the Window menu to arrange how windows are displayed. Displays can be set to appear full screen (one display at a time) or with all (selected) displays visible at once. When all displays are visible at once, you can rearrange the displays by dragging the title bar of a window (deselect Window > Lock Windows to move displays around).

Command	Description
Close View	Closes the selected view.
Cascade	Positions windows in a cascade view (not available when Lock Windows is selected).
Tile Horizontally	Positions widows in a horizontal orientation (top to bottom).
Tile Vertically	Positions widows in a vertical orientation (side by side).
Lock Windows	Locks the windows into their current position, preventing them from being moved. If the windows are locked, the Cascade arrangement is not selectable.
(List of windows)	A numbered list of open windows.

## Help Menu

The Help menu provides access to the Help and version information about SignalVu-PC.

Command	Description
User Manual	Displays a navigable, searchable Help tool.
User Manual (PDF)	Displays a PDF version of the Help.
Application Reference (PDF)	Displays a PDF version of the RSA Application Manual.
Quick Start Manual (PDF)	Displays a PDF version of the SignalVu-PC Quick Start User Manual.
<a href="#">PI Command Search (see page 863)</a>	Displays a navigable, searchable PI command search tool.
About Tektronix Real Time Signal Analyzer Software	Displays information about the SignalVu-PC software and installed options.

## PI Command Search tool

The PI Command search tool allows you to search for programming commands by typing the syntax or key words into the search text box.

For a quick search, do the following:

1. Select the **Search** tab from the dialog box.
2. Type in the syntax or key word you are looking for in the text box.
3. Click on **List Topics**.

TO obtain an updated version of the PI commands manual, do the following:


1. Download the latest PI manual .CHM file from [www.Tek.com/downloads](http://www.Tek.com/downloads).
2. Copy the downloaded *PICommandSearch.chm* file into the installer path *C:\Program Files\Tektronix\SignalVu-PC\RSA*.



**CAUTION.** Do not change the file name *PICommandSearch.chm* or the file will not be found by the application.

## Favorites bar menus



Menu	Description
Icons	The icons on the Favorites bar are detailed in the <a href="#">Specific areas of the application window (see page 21)</a> topic.
Preset	Recalls the <a href="#">Main</a> preset.
<a href="#">Replay (see page 753)</a>	Replay measurements; select which record(s) to play, Replay/Stop/Pause, or enable continuous loop.
<a href="#">Run (see page 856)</a>	Start, stop and abort acquisitions, select single or continuous acquisition mode. Only available when connected to an RSA306, RSA306B, RSA500A series, RSA600A series, RSA7100A spectrum analyzer or an MSO4000B/C oscilloscope.
⋮	Click this icon to view the Edit Favorites menu: 

(Audio demodulation icon is not available when connected to the RSA7100A.)

## Error and Information Messages

The following list describes some of the common error and information messages that might appear during instrument operation. Messages that apply specifically to one or more measurements appear in the displays. Messages that pertain globally, such as those about hardware status, are shown in the Status Bar at the bottom of the analyzer application window.



**Acq BW too small for current setup**

The display needs a wider acquisition bandwidth than what the current data record contains. This can be due to any of the following reasons:

- The sampling parameters are being manually controlled.

In the Acquire control panel > Sampling Parameters tab, set the Adjust control to All Auto to allow the software to pick the sample rate and record length that it needs.

- A display other than the one you intended has been selected. The selected display has requested a smaller acquisition bandwidth to achieve a better accuracy or dynamic range for its particular measurement.

Select the display that contains the message. Click Run if the instrument is not already acquiring data.

- Acquisitions are not running and the measurement now requests a wider bandwidth than the last acquisition.

Click Run to perform a new acquisition with a wider bandwidth.

- The data is from a recalled TIQ file.

There is no way to increase the acquisition bandwidth for saved IQ data. You must adjust the measurement settings so that less bandwidth is required.

**Analysis failure: <description of error>**

The instrument is unable to complete a measurement due to difficulty in characterizing the signal. For example, due to either the signal or settings, the instrument may not be able to recognize a pulse so it can compute the pulse measurements.

- Try changing settings to improve analysis. For example, when Pulse Trace is displayed, try changing the settings on the Settings > Params.

**Analysis failure: Carrier detection failed**

The instrument was unable to locate a carrier signal. Try adjusting the Carrier Threshold or Integration BW values, if the measurement has these controls.

**Analysis Length was limited**

This message appears if the "Results Length", the time over which the measurement computed its results, is less than the Actual Analysis Length reported in the Analysis Time control panel tab and the Time Overview display. The Results Length is indicated by the magenta line below the Time Overview graph. This can occur because the acquisition contained more data samples than a measurement can process (for example, digital demodulation is limited to 80,000 samples) or the measurement had to use some of the first and last samples for pre-measurement processes.

**Analysis length too small for current setup**

Increase the Analysis Length or decrease the RBW (Spectrum, ACPR, MCPR).

**Avg Tx not available in Volts units**

The Average Transmitted Power measurement is not defined for Volts.

**Can't get acquisition data record**

No acquisition record currently exists in memory (run an acquisition or recall a file), or an error has occurred. Repeat the acquisition.

**Can't replay data from swept acq**

The measurement could not produce results because it is a real-time only measurement but was asked to reanalyze (Replay) an acquisition taken in swept mode.

**Can't replay. Live data needed for swept settings**

The measurement could not produce results because it was asked to reanalyze (Replay) the acquisition but it is in Swept acquisition mode. Swept-mode measurements cannot analyze recalled data.

**CISPR accuracy limited by acq memory. Adjust RBW or freq range**

The CISPR function was applied, but the available data did not represent a long enough time to satisfy CISPR requirements. Increasing RBW reduces the amount of time needed for analysis. Reducing frequency range (for example, by reducing Span), decreases sample rate, allowing the available memory to cover a longer time period.

If this data is from a saved file, the error cannot be cleared.

If this data is from a saved file, this error cannot be cleared.

This data was acquired when the input signal contained peaks greater than 6 dB above the Reference Level setting.

If the data is from a file, this error cannot be cleared.

**Data from unaligned instrument**

The acquisition data was captured when the instrument was not aligned. This message refers to the acquisition data currently being analyzed, but not necessarily to the current status of the instrument. Measurements made on this data might not be accurate.

**Data from warm-up period**

This data was acquired while the analyzer was warming up. The warm-up period is 20 minutes. Until this warm-up period is completed, the analyzer is considered uncalibrated.

**Disabled: data is from swept acquisition**

The display needs to run in real-time mode. The display associated with this message cannot run now because it is not the selected display, and the selected display is performing multiple acquisitions (it is in swept mode).

- Change the settings of the selected display so it is performing real-time acquisitions.
- Select the associated display to make it the selected display. When it is selected, it will force the acquisition parameters to change to meet its own needs.

**Frequency exceeds preamp range**

This is a warning that signals below the minimum preamp operating frequency are likely to be severely attenuated (this is 100 kHz for option 51, 1 MHz for option 50).

**Needs swept acq or larger AcqBW - Acquire data while display is selected**

The display is not running because it needs to perform multiple acquisitions (it must be in swept mode) but it is not the selected display. Only the selected display can perform multiple acquisitions.

- Select the display showing this message to give it control of acquisitions parameters.

Sometimes, only one display can work and the others will be blank and show errors. This happens when different displays have conflicting demands on the acquisition data record.

#### **Export failure: file not saved**

An error occurred while exporting Results. The file was not created.

- Export the results again.

#### **Export failure: unable to open results file for export. File not saved.**

The Export Results file could not be opened for writing, so the export of results was not completed.

- Verify that there is sufficient free space on hard disk.

#### **Insufficient data for CISPR. Acquire while display is selected**

This message appears when a measurement is not the selected measurement and CISPR filters are selected. Set the measurement to be the selected measurement and reacquire the signal.

#### **IQ Processing Error: 8012**

This message occurs in GP Digital Modulation displays. The most likely cause for this message is that there are not enough symbols to analyze. This can happen if:

- The Analysis Length is set too short. Increase the Analysis Length on the Analysis Time tab.
- The Analysis Offset has pushed the Analysis Time so far out that the actual Analysis Length is too short, even though the user-requested Analysis Length would have been long enough without the excessive offset. Decrease the Analysis Offset on the Analysis Time tab.
- The input signal is bursted, and the burst does not contain enough symbols.

#### **Needs swept acq or larger Acq BW - Acquire data while display is selected**

The display has one of two problems: It is not the selected display, which prevents it from controlling the hardware acquisition parameters, and setting the acquisition mode to Swept; or its settings require a wider data bandwidth.

- Select the display that you are interested in and it will change the acquisition to meet its own needs.
- Increase the acquisition bandwidth manually or by changing the selected display's settings to cause the wider bandwidth.

#### **No Math trace: unmatched trace lengths**

A math trace could not be produced because the traces selected to generate the math trace do not have the same number of points. This can easily happen if both traces are recalled, but were saved under different "Points" settings. This can also occur if one of the selected traces is a live trace and the other trace is a recalled trace.

- In a Spectrum display, as long as one trace is live, you can change the "Points" setting (Setup > Settings > Freq & Span tab) to match the recalled trace.

- If you are using two recalled traces to generate the Math trace. You must recreate at least one of the traces.

**No burst detected**

The [Burst Detection Mode \(see page 714\)](#) is On, but no burst was detected in the signal.

- Check that the Threshold setting is properly set.

**Not enough samples for current setup**

The measurement was not able to run because the combination of analysis length, offset, and measurement bandwidth relative to acquisition bandwidth, were such that not enough samples were available for the measurement to analyze. This can occur when two or more displays are shown and one display requires a wide acquisition bandwidth and another display requires a much narrower bandwidth. The display requiring the much narrower bandwidth must decimate and filter the acquisition record which can result in too few samples left for the measurement.

- Increase the Analysis Length to provide more samples.
- Close any displays you don't currently need.

**Not enough samples – try increasing MeasBW**

The measurement was not able to run because there are not enough samples available for the measurement to analyze. The Settling Time measurement requires at least 256 samples. This can occur when two or more displays are shown and one display requires a wide acquisition bandwidth and another display requires a much narrower bandwidth. The display requiring the much narrower bandwidth must decimate and filter the acquisition record which can result in too few samples left for the measurement.

- Increase the Analysis Length to provide more samples.
- Close any displays you don't currently need.

**No FFT (not all pulses have results)**

If a pulse cannot be measured (because its shape is too indistinct or it does not meet the [parameters that define a pulse \(see page 402\)](#)), its results will be “- -” for every measurement on that pulse. The instrument cannot compute an FFT.

**No pulses found**

The instrument was unable to find any complete pulses in the signal.

- Make sure the [analysis length \(see page 745\)](#) includes at least one complete pulse cycle, from before one rising edge until after the next rising edge.

**Pulse Detection Error**

The instrument was unable to detect a pulse.

- The pulse [Measurement Filter \(see page 402\)](#) needs to be smaller. Try reducing the bandwidth and/or selecting the Gaussian filter.
- Detection threshold is not set to the proper level for the signal. Adjust the [Power threshold to detect pulses \(see page 402\)](#).

- The pulse interval is too long for the current settings. Try decreasing the [filter bandwidth \(see page 402\)](#), as this may reduce the number of data points to a manageable quantity.

**RBW conflict. Increase Span or Analysis Length**

The measurement is not running because the actual RBW used by the measurement is too large for the current acquisition span. Typically, the analysis length is too short as well.

- Either increase the span or increase the Analysis Length.

**RBW decreased**

The current span or acquisition bandwidth is too small to allow a wider RBW filter.

- Increase the span or acquisition bandwidth if the decreased RBW is not acceptable.

**RBW increased**

The current Spectrum Length (or Analysis Length if Spectrum Length is not Independent) is too small to allow the requested RBW.

- Increase the Spectrum Length (or Analysis Length) if the increased RBW is not acceptable.

**RBW limited by AcqBW to: XX Hz**

The requested RBW is too close to the acquisition BW. Increase the frequency range of the measurement (for example, Span).

**RBW too small/large for current Acq BW**

If the RBW is set manually, it is possible for the acquisition bandwidth to be incompatible with the RBW setting.

- Change the RBW setting.
- Adjust the Acq BW setting, either directly (Setup > Acquire > Sampling Params: select on of the manual modes) or by adjusting the measurement bandwidth of the selected display (Setup > Acquire > Sampling Params: All Auto).

**Recall error: Setup not completely restored**

An error occurred while recalling a Setup file. Thus, the current setup may be a combination of settings from the Setup file and the previous Setup.

- Recall the setup again.

**Recall failure: problem with file or file contents**

An error occurred while recalling a Setup, Trace or Data file. This can occur because of a problem opening the file (operating system error) or because of a problem with the contents of the file.

- Recall the file again.

**Restoring acquisition data**

This is a status message displayed while data is being restored from a file.

**Save failure: file not saved**

An error occurred while saving a Setup or Data file.

- Save the file again.

### **Saving acquisition data**

This is a status message displayed while data is being saved to a file.

### **Selected VBW does not use full Spectrum Length**

This message can occur when the Spectrum Length is greater than required for the VBW filter. If you look at the Time Overview display, the Magenta line for Results Length indicates the part of the Spectrum Length that was actually used. The measurement results are correct, but don't include some of the data in the selected Spectrum Length. To clear this message, you can set the Spectrum Length to Auto.

### **Setup error: <description of error>**

When this message appears, it includes text that explains the problem. For example, the ACPR display might show: "Setup error: channels can't overlap". Setup errors are the result of conflicts in instrument settings. These types of errors occur when a user makes manual changes to settings. In the example above, the channel settings in the Channel Power and ACPR display have been set so that the channels overlap in frequency.

- Adjust the instrument settings, or change a setting back to Auto, to eliminate the error.

### **Setup error: Integration BW exceeds Measurement BW**

When this message appears, it includes text that explains the problem. Setup errors are the result of conflicts in instrument settings. These types of errors occur when a user makes manual changes to settings.

- Adjust the instrument settings, or change a setting back to Auto, to eliminate the error.

### **Setup error: Measurement time for Freq & Phase results**

The [Measurement time for Freq & Phase results \(see page 404\)](#) specifies how far across the pulse top the instrument should wait before measuring the Phase Difference and Frequency Difference for each pulse. If this value is set too large for any of the pulses in the signal, the measurement point ends up on the falling edge or during the pulse off time.

- Decrease the Measurement time for Freq & Phase results setting (Settings > Define tab).

### **Unexpected software error. Please cycle power and try again. If the problem persists, contact your Tektronix Service Center.**

An unrecoverable error has occurred, and the instrument application software will shut down.

- Relaunch the SignalVu-PC application.

### **VBW not applied - Acq BW too small**

Increase VBW or measurement bandwidth. Make sure Sampling Parameters are set to Auto.

### **VBW not applied - Spectrum Length too short**

This message occurs when the requested VBW can't be produced because the Spectrum Length is too short.


To clear this problem, set the Spectrum Length to Auto or manually increase the Spectrum Length (see Setup > Analysis > Spectrum Time tab). If Spectrum Length is coupled to Analysis Length, set Analysis Length to Auto or manually increase it (see Setup > Analysis > Analysis Time tab).

## Displaying the Windows Event Viewer

When the analyzer generates an error message, information about the error is logged to the Windows Event Viewer.

To display the Windows Event Viewer:

1. Select Start > Control Panel.
2. Select Administrative Tools. (If your instrument displays control panels in Category View, select System and Security, and then select Administrative Tools.)
3. Double-click **Event Viewer**.
4. From the Event Viewer window, select **Windows Logs**, then select **Application**. This displays a list of all errors that have been reported to the operating system from applications.



Errors reported to the Event Viewer from the analyzer application appear under Source as TekRSA.

5. Double-click the last error reported for TekRSA to see details on the most recently reported error. Please note that many items reported as “errors” are simply informational and do not mean that your instrument is impaired. Contact the Tektronix Customer Support Center or Service Center if you

are concerned about an error shown in the Event Viewer. Do not send an instrument out for repair based solely on these event reports.

## How to Find Out if Software Upgrades are Available

Software upgrades might be available can be downloaded from the Tektronix Web site. To see if a software upgrade is available for your product, use your browser to go to [www.tektronix.com/software](http://www.tektronix.com/software). Search by the product model number.


To add additional software options or features, you will need an option key from Tektronix. In some instances, you may need to upgrade the product software before adding the new option key. Follow the installation instructions provided with your software option.

## Settings


**Main menu bar: Setup > Settings**

**Favorites toolbar:** 

The Settings menu item enables access to control panels that allow you to change settings for the selected display. The control panel that appears when you select **Settings** depends on the selected display. The Settings control panel for the Spectrum display is shown in the following figure.



The control panel for the CCDF display is shown in the following figure.



### Settings Control Panels

[ACPR Settings \(see page 154\)](#)

[Acquire \(see page 766\)](#)

[AM Settings \(see page 128\)](#)



[Amplitude vs Time Settings \(see page 106\)](#)

[Analysis Settings \(see page 745\)](#)

[Audio Spectrum Settings \(see page 660\)](#)

[Audio Summary Settings \(see page 662\)](#)

[Bluetooth 20dB BW settings \(see page 641\)](#)

[Bluetooth CF Offset and Drift Settings \(see page 626\)](#)

[Bluetooth Constellation Settings \(see page 620\)](#)

[Bluetooth Eye Diagram Settings \(see page 623\)](#)

[Bluetooth Frequency Dev Vs Time Settings \(see page 639\)](#)

[Bluetooth Summary Settings \(see page 631\)](#)

[Bluetooth Symbol Table Settings \(see page 635\)](#)

[CCDF Settings \(see page 192\)](#)

[Channel Power and ACPR Settings \(see page 154\)](#)

[Constellation Settings \(see page 677\)](#)

[DPX Settings \(see page 80\)](#)

[EVM vs Time Settings \(see page 681\)](#)

[Eye Diagram Settings \(see page 684\)](#)

[FM Settings \(see page 135\)](#)

[Frequency Deviation vs Time Settings \(see page 686\)](#)

[Frequency vs Time Settings \(see page 108\)](#)

[LTE ACLR Settings \(see page 583\)](#)

[LTE Channel Spectrum Settings \(see page 585\)](#)

[LTE Constellation Settings \(see page 587\)](#)

[LTE Power vs Time Settings \(see page 589\)](#)

[Magnitude Error Settings \(see page 688\)](#)

[MCPR Settings \(see page 168\)](#)

[Occupied Bandwidth Settings \(see page 178\)](#)

[OFDM Channel Response Settings \(OFDM \(see page 357\)\) \(WLAN \(see page 168\)\)](#)

[OFDM Constellation Settings \(see page 359\)](#)

[OFDM EVM Settings \(see page 361\)](#)

[OFDM Magnitude Error Settings \(see page 363\)](#)

[OFDM Phase Error Settings \(see page 367\)](#)  
[OFDM Power Settings \(see page 369\)](#)  
[OFDM Summary Settings \(see page 371\)](#)  
[OFDM Symbol Table Settings \(see page 373\)](#)  
[Phase Error vs Time Settings \(see page 690\)](#)  
[Phase vs Time Settings \(see page 110\)](#)  
[PM Settings \(see page 143\)](#)  
[Pulse Statistics Settings \(see page 399\)](#)  
[Pulse Table Settings \(see page 394\)](#)  
[Pulse Trace Settings \(see page 396\)](#)  
[RF I Q vs Time Settings \(see page 112\)](#)  
[Mask Test Limits Settings \(see page 739\)](#)  
[Settling Time Settings \(see page 207\)](#)  
[Signal Quality Settings \(see page 696\)](#)  
[Spectrogram Settings \(see page 101\)](#)  
[Spectrum Settings \(see page 97\)](#)  
[Symbol Table Settings \(see page 698\)](#)  
[Time Overview Settings \(see page 90\)](#)  
[Trellis Diagram Settings \(see page 701\)](#)

## Accuracy

The closeness of the indicated value to the true value.

## ACLR

Adjacent Channel Leakage power Ratio is the ratio of the RRC (Root Raised Cosine) filtered mean power centered on the assigned channel frequency to the RRC filtered mean power centered on an adjacent frequency (defined in 3GPP).

## ACPR Measurement

Adjacent Channel Power Ratio (ACPR) is the ratio of the mean power centered on the assigned channel frequency to the mean power centered on an adjacent channel frequency. In the 3GPP specification, it is called ACLR (Adjacent Channel Level Ratio) and both the main channel and adjacent channels are required to be filtered with RRC (Root Raised Cosine) filters.

## Acquisition

A series of time-contiguous frames. This is also called a Block.

## Analysis Length

The length of time in the Analysis Time.

## Analysis Time

The portion of the acquisition record over which one or more measurements are calculated.

## ASK

Acronym for Amplitude Shift Keying. The process, or result of a process, in which the amplitude of the carrier is varied in accordance with the state of a digital input signal.

## Block

An integer number of time-contiguous frames. See also: Acquisition.

## Calibrator

A signal generator producing a specified output used for calibration purposes.

## Carrier

The RF signal upon which modulation resides.

## Carrier Frequency

The frequency of the CW component of the carrier signal.

## Carrier Signal

The electrical signal, typically a sine wave, upon which modulation is impressed.

## Carrier-to-Noise Ratio (C/N)

The ratio of carrier signal power to average noise power in a given bandwidth surrounding the carrier; usually expressed in decibels.

## CCDF - Complimentary Cumulative Distribution Function

The Complementary Cumulative Distribution Function (CCDF) represents the probability that the peak power above average power of a measured signal exceeds a threshold.

CCDF is a plot of the percent of time that a signal's power value exceeds its average value versus the amount by which it exceeds the average. The CCDF plot has a log of probability on the Y-axis (100% at the top) and dB above average amplitude on the X-axis (0 at the left).

## CDMA

Acronym for Code Division Multiple Access.

## Center Frequency

The frequency corresponding to the center of a frequency span of the analyzer display.

## Check Mark Indicator

The check mark indicator in the upper-left corner of the display indicates the display for which the acquisition hardware is optimized. When you have more than one display open, the display with the check mark indicator has control over the acquisition hardware. To give a display priority over any others, click its title bar.

When *Best for multiple windows* is selected in the Amplitude control panel's RF & IF Optimization control, none of the measurement displays shows a checkmark, as there is not a single optimized measurement.

## CISPR

International special committee on radio interference. (Comité international spécial des perturbations radioélectriques)

## CW

Acronym for Continuous Wave.

## CW Signal

Continuous wave signal - a sine wave.

## DANL

Acronym for Displayed Average Noise Level. See [Sensitivity \(see page 888\)](#).

## dBfs

A unit to express power level in decibels referenced to full scale. Depending on the context, this is either the full scale of the display screen or the full scale of the analog-to-digital converter (ADC).

## dBm

A unit of expressed power level in decibels referenced to 1 milliwatt.

## dBmV

A unit to express voltage levels in decibels referenced to 1 millivolt.

## dBuV

A unit to express voltage levels in decibels referenced to 1 microvolt.

## Decibel

Ten times the logarithm of the ratio of one electrical power to another.

## Detection

The process by which a long waveform is decimated (reduced) down to the desired number of trace points, by dividing the waveform into intervals and choosing a single value to represent each interval in the trace.

## Display Reference Level

A designated vertical position representing a specified input level. The level may be expressed in dBm, volts, or any other units.

## Distortion

Degradation of a signal, often a result of nonlinear operations, resulting in unwanted signal components. Harmonic and intermodulation distortion are common types.

## Dynamic Range

The maximum ratio of the levels of two signals simultaneously present at the input which can be measured to a specified accuracy.

## EVM

Acronym for Error Vector Magnitude.

## Export

Save data to a file in a format other than application-native.

## FastFrame

FastFrame segments the acquisition record into a series of frames and then captures acquisitions as single frames. You can then view and measure each frame individually.

## FFT

Fast Fourier Transform - a mathematical process to calculate the frequency spectrum of a discrete number of time domain sample points.

## Filter

A circuit that separates electrical signals or signal components based on their frequencies.

## FM

Acronym for Frequency Modulation.

## Frame

A series of time-contiguous samples, long enough in duration and at a sufficient sample rate to produce a spectrum view of a specified span and RBW.

## Frequency

A series of time-contiguous samples, long enough in duration and at a sufficient sample rate to produce a spectrum view of a specified span and RBW.

## Frequency Band

The continuous range of frequencies extending between two limiting frequencies, expressed in hertz.

## Frequency Domain View

The representation of the power of the spectral components of a signal as a function frequency; the spectrum of the signal.



## Frequency Drift

Gradual shift or change in displayed frequency over the specified time due to internal changes in the analyzer, where other conditions remain constant. Expressed in hertz per second.

## Frequency Range

The range of frequencies over which the performance of the instrument is specified.

## Frequency Span

A continuous range of frequencies extending between two frequency limits.

## Frequency Settling Time

The time measured from a reference point to when the signal of interest settles to within user-defined tolerance.

## GPIB

Acronym for General Purpose Interface Bus, the common name for the communications interface system defined in IEEE Std. 488.

## Graticule

The calibrated grid overlaying the display screen of analyzers, oscilloscopes, and other test instruments.

## Grayed Out

An on-screen control is “Grayed Out” if it is not adjustable.

## I/Q

Acronym for In-phase / Quadrature.

## IF

Acronym for Intermediate Frequency.

## Import

Bring data into the application from a file of some format other than application-native.

## Impulse Response

The Impulse Response trace display shows normalized power on the vertical axis and time on the horizontal axis.

## Input Impedance

The impedance at the desired input terminal. Usually expressed in terms of VSWR, return loss, or other related terms for low impedance devices and resistance-capacitance parameters for high impedance devices.

## LISN

Acronym for Line Impedance Stabilization Network.

## Local Oscillator (LO)

An oscillator which produces the internal signal that is mixed with an incoming signal to produce the IF signal.

## Marker

A visually identifiable point on a waveform trace, used to extract a readout of domain and range values represented by that point.

## Max Hold

Digitally stored display mode which, at each frequency address, compares the incoming signal level to the stored level and retains the greater level. In this mode, the display indicates the peak level at each frequency after several successive acquisitions.

## MCPR (Multiple Carrier Power Ratio)

The ratio of the signal power in the reference channel or group of channel to the power in adjacent channels.

## Min Hold

Digitally stored display mode which, at each frequency address, compares the incoming signal level to the stored level and retains the lower level. In this mode, the display indicates the minimum level at each frequency after several successive sweeps.

## Modulate

To regulate or vary a characteristic of a signal, typically in order to transmit information.

## Modulating Signal

The signal which modulates a carrier. The signal which varies or regulates some characteristic of another signal.

## Modulation

The process of varying some characteristic of a signal with a second signal.

## Noise

Unwanted random disturbances superimposed on a signal which tend to obscure it.

## Noise Bandwidth (NBW)

The exact bandwidth of a filter that is used to calculate the absolute power in dBm/Hz.

## Noise Floor

The noise intrinsic to a system that represents the minimum limit at which input signals can be observed; ultimately limited by thermal noise (kTB). The analyzer noise floor appears as a “grassy” baseline in the display, even when no signal is present.

## Open (Recall)

Bring data into the application from a file of application-native format.

## OQPSK

Acronym for Offset QPSK (Quadrature Phase Shift Keying).

## Phase Settling Time

The time measured from a reference point to when the signal of interest settles to within user-defined tolerance.

## PM

Acronym for Phase Modulation.

## Primary Marker

The marker displayed in the Single Marker mode whose frequency and/or position is changed when tuning with the general purpose knob.

## PSK

Acronym for Phase Shift Keying. The process, or result of a process, in which the carrier phase is varied discretely in accordance with a digital code.

## QAM

Acronym for Quadrature Amplitude Modulation. The process, or result of a process, in which the amplitude and phase of the carrier are varied concurrently by synthesizing two orthogonal ASK waves (see ASK).

## Real-Time Analysis

Measurement technique based on triggering on an RF signal, seamlessly capturing it into memory, and analyzing it in the frequency, time, and modulation domains.

## Real-Time Bandwidth

The frequency span over which real-time seamless capture can be performed, which is a function of the digitizer and the IF bandwidth of a Real-Time Signal Analyzer.

## Real-Time Seamless Capture

The ability to acquire and store an uninterrupted series of time domain samples that represent the behavior of an RF signal over a long period of time.

## Reference Level

The signal level represented by the uppermost graticule line of the analyzer display.

## Residual FM (Incidental FM)

Short term displayed frequency instability or jitter due to instability in the analyzer local oscillators. Given in terms of peak-to-peak frequency deviation and expressed in hertz or percent of the displayed frequency.

## Residual Response


A spurious response in the absence of an input signal. (Noise and zero pip are excluded.)

## RBW

The RBW determines how well the analyzer can resolve or separate two or more closely spaced signal components.

## Ripple

The Ripple measurement result is displayed in either Watts or Volts. The amplitude units selected on the Setup > Analysis > Units tab determine whether the measurement is presented in Watts or Volts. Volts are shown for linear units (for example, volts or amps); Watts are shown for non-linear units (for example, watts or dBm).



The Ripple measurement, in Watts, is calculated as follows:

$$\%Ripple (Watts) = 100 \times (RatioPos + RatioNeg)$$

Where:

$$RatioNeg = \left( \left( \left( \frac{DelNeg}{RefNeg} \right) + 1 \right)^2 \right) - 1$$

$$RatioPos = \left( \left( \left( \frac{DelPos}{RefPos} \right) + 1 \right)^2 \right) - 1$$

- DelPos = Delta Positive in Volts
- RefPos = Reference Positive in Volts
- DelNeg = Delta Negative in Volts (this is a positive value)
- RefNeg = Reference Negative in Volts

The Ripple measurement, in Volts, is calculated as follows:

$$\%Ripple (Volts) = 100 \times (RatioPosV + RatioNegV)$$

Where:

- RatioPosV = DelPos/RefPos
- RatioNegV = DelNeg/RefNeg

## Secondary Marker

The “second” marker displayed only in the Delta Marker mode.

## Sensitivity

Measure of a analyzer's ability to display minimum level signals, usually expressed as displayed average noise level ([DANL \(see page 878\)](#)).

## Shape Factor (Skirt Selectivity)

The ratio of the frequency separation of the two (60 dB/3 dB) down points on the response curve to the static resolution bandwidth.

## Signal

As used in this help, the signal refers to the input signal before it is processed. The signal is an input.

## Signal Strength

Signal Strength locates the direction of a signal using a directional antenna and an audio tone and a visual display.

## Span

Span is the range of frequencies displayed in a spectrum window. Span, start frequency and stop frequency are related by the following equation:  $\text{Span} = (\text{stop frequency}) - (\text{start frequency})$ . The settings for center, start and stop frequencies are related to the setting for span; when one parameter is changed, the others are changed automatically.

## Span Per Division (Span/Div)

Frequency difference represented by each major horizontal division of the graticule.



## Spectrogram

Frequency vs. time vs. amplitude display where the frequency is represented on the x-axis and time on the y-axis. The power level is indicated by variations in color.

## Spectrum

The frequency domain representation of a signal showing the power distribution of its spectral component versus frequency.

## Spectrum Analysis

The technique or process of determining the frequency content of an RF signal.

## Spectrum Analyzer

A device for determining the frequency components of a signal.

## Spectrum Time

Analysis Time for spectrum analysis views. Spectrum time can be the same as Analysis Time, but it can be different.

## Spur/Spot

A spur is a signal peak that exceeds a user-definable threshold (See Spurious > Settings > Ranges) and excursion setting. A spur that also exceeds a limit (either Absolute or Relative) specified on the Settings > Limits tab is considered a violation. This is called a spot in the EMC-EMI display.

## Spurious Response

A response to a analyzer wherein the displayed frequency is not related to the input frequency.

## Time Measurement

This is the time in seconds relative to the time reference point in the first acquisition record in the data set.

## Time Reference

The point in time during the acquisition record used as the zero point for counting time. The time reference can be set to either the start of the acquisition record or the trigger point.

## Trace

As used in this help, trace refers to the displayed signal. The displayed signal can be a processed version of the input signal (for example, it may be averaged.) The trace is a result or output.

## Vector Signal Analyzer

Like a spectrum analyzer, a device for determining the frequency components of a signal. However, unlike a standard spectrum analyzer, the vector signal analyzer is optimized for analyzing digitally modulated RF signals.

## Vertical Scale Factor, Vertical Display Factor

The number of dB, volts, etc., represented by one vertical division of a spectrum analyzer display screen.

## Violation

A violation is a spur that exceeds either an Absolute or Relative limit (depending on the selected mask) specified on the Settings > Limits tab. A spur is a signal peak that exceeds a user-definable threshold (See Spurious > Settings > Ranges) and excursion setting.

# Index

## Symbols and Numbers

- 6dB RBW (MIL) Filter shape
  - Spectrum display BW
    - tab, 119
- 20 dB bandwidth
  - Bluetooth, 50
- 20dB Bandwidth display
  - Bluetooth, 639
- 3-D Spectrogram display, 99
- 3-D Waterfall
  - Spectrogram/DPXogram, 103
- 802.11ad Constellation display, 333
- 802.11ad displays, 333
- 802.11ad EVM vs Time display, 337
- 802.11ad measurements, 332
- 802.11ad Standards presets, 329
- 802.11ad Summary display, 341
- 802.11ad Symbol Table display, 339

## A

- Abort acquisition, 766
- About the Software, 845
- Abs
  - Ranges and Limits table, 189
- Abs & Rel
  - Ranges and Limits table, 189
- Abs OR Rel
  - Ranges and Limits table, 189
- Abs Same
  - Ranges and Limits table, 189
- Abs Start (dBm)
  - Ranges and Limits table, 189
- Abs Stop (dBm)
  - Ranges and Limits table, 189
- Absolute Frequency, 52
- Accessories setup
  - EMC, 493

- Accessories tab, 455
  - EMC-EMI display
    - settings, 492
- Accessories tab plot, 500
- accuracy, 875
- ACLR, 875
  - LTE, 50
- ACLR measurement, 154
- ACPR measurement, 875
- Acq Data
  - Replay menu, 753
- Acq Data/DPX Spectra, 751
- Acquire control panel, 766
  - Playback, 780
- acquisition, 875
- acquisition data
  - saving, 833
- Acquisition data files, 34
- Acquisition Data tab, 851
- Acquisition Info tab, 753
- Acquisition memory usage, 767
- Actions tab
  - Search, 744
  - Triggering, 794
- Activate
  - option key, 8
  - optional legacy application
    - licenses, 8
- adaptive equalizer, 709
- Adjacent Channel Power
  - measurement, 154
- Adjacent Channel Power Ratio, 43
- Advanced Params tab
  - OFDM Analysis
    - displays, 375
- Advanced Params Tab
  - GP Digital Modulation
    - displays, 711
- Advanced tab
  - Triggering, 793
- Alaris
  - antenna function button, 802
- Alignments, 859

- +AM, 48
  - AM display, 48
- AM
  - AM display, 48
- AM display, 127
- AM measurements, 48
- Ambient tab
  - EMC-EMI display
    - settings, 518
- Amplitude control panel, 759
- Amplitude vs. Time display, 105
- Amplitude vs. Time display
  - Settings, 106
- Analysis
  - 802.11ad, 332
- Analysis control panel, 745
- analysis length, 875
- Analysis Params tab
  - Bluetooth, 648
  - LTE, 604
  - P25 Analysis displays, 559
  - WLAN Analysis
    - displays, 320
- Analysis tab
  - Pulse-Ogram display, 411
- analysis time, 875
- Analysis Time tab
  - Bluetooth, 648
  - GP Digital Modulation
    - displays, 715
  - LTE, 604
  - OFDM Analysis
    - displays, 376
  - Options control panel, 33
  - P25 Analysis displays, 559
  - WLAN Analysis
    - displays, 323
- Analysis Time tab (Analysis control panel), 745
- Antenna, 797
  - Alaris function button, 802
  - control panel, 798
  - how to set up, 799
  - settings, 798

- Antenna Power, 796
- APCO P25 measurements, 49
- API
  - IQ streaming, 808
- Application
  - moving a license, 7
- Application Help, 845
- Application preset
  - modulation analysis, 30
  - pulse analysis, 30
  - spectrum analysis, 31
  - Time-Frequency analysis, 32
- application presets
  - saving, 833
- Application presets, 25
- Applications
  - how to purchase, 3
  - install, 5
  - list of available options, 11
  - uninstall, 6
- Apply ampl corrections, 405
- APSK, 705
- APSK parameters, 712
- APSK Parameters, 712
- Arm trigger status light, 782
- arranging windows, 862
- ASK, 876
- Attenuator settings, 759
- Audio BW, 664
  - setting, 664
- Audio Demod tab, 673
- audio filters
  - custom, 668
- Audio Filters tab
  - Audio Analysis displays, 666
- Audio Freq
  - Audio Summary display, 662
- Audio Spectrum display, 659
- Audio Spectrum settings, 660
- Audio Summary settings, 662
- Auto
  - Ranges and Limits table, 188
- automatically generate
  - filenames, 33
- Automatically increment
  - filename/number, 34
- Autosave acquisition on
  - Trigger, 793

- Average Channel Power
  - measurement, 154
- Average ON Power, 381
- Average Transmitted Power, 381
- Averaging
  - Audio Analysis displays, 666
  - Params2 tab, 666

## B

- Base software, 3
- Basic Controls Toolbar, 853
- Battery, 860
- Battery status
  - Tools menu, 860
- Bitmap trace
  - Traces tab, 81
- black text
  - settling time
    - measurements, 202
- Blackman-Harris 4B Filter Shape
  - Spectrum display BW
    - tab, 119
- Blizzard color scheme, 34
- block, 876
- Blue background (cells), 179
- Bluetooth
  - Analysis Params tab, 648
  - Analysis Time tab, 648
  - BT 20dB Bandwidth
    - display, 639
  - BT InBand Emission, 642
  - Freq & RBW tab, 657
  - Frequency Dev vs Time (BT)
    - display, 635
  - Limits tab, 650
  - Measurement Params
    - tab, 658
  - Parameters tab, 655
  - Power class, 646
  - Prefs tab, 654
  - Scale tab, 651
  - Trace tab, 652
- Bluetooth measurements, 49
- BT 20dB BW Settings, 641
- BT CF Offset and Drift
  - display, 624
  - settings, 626

- BT Constellation
  - display, 618
  - settings, 621
- BT Eye Diagram
  - display, 621
  - settings, 623
- BT limits, 627
- BT Summary
  - display, 627
  - settings, 631
- BT Symbol Table
  - display, 631
  - settings, 635
- Burst detect threshold, 137
- BW (Hz)
  - Ranges and Limits table, 188
- BW Tab
  - Amplitude vs. Time
    - display, 107
  - DPXOgram display, 119
  - Spectrum display, 119

## C

- C4FM modulation type
  - measurements, 48
- C4FM signal quality
  - measurements, 696
- Cable loss, 44
- Cable Loss display settings, 260
- calibrator, 876
- Carr Freq Err
  - Audio Summary display, 661
- carrier, 876
- carrier frequency, 876
- Carrier frequency detection, 144
- Carrier Frequency Error, 48
- Carrier frequency offset and drift
  - Bluetooth, 49
- Carrier Power
  - Audio Summary display, 661
- carrier signal, 876
- carrier-to-noise ratio (C/N), 876
- CCDF, 43
- CCDF - Complimentary
  - Cumulative Distribution
    - Function, 877
- CCDF display, 191
- CDMA, 877

- Cell ID detection
  - LTE, 50
- center frequency, 877
- Change start and stop freq
  - EMC Range & Limits table, 509
- Channel direction, 817
- Channel Navigation toolbar, 816
- Channel Power, 43
  - LTE, 50
- Channel Power and ACPR
  - (Adjacent Channel Power Ratio) display, 151
- Channel Power and ACPR Settings control panel, 154
- Channel Power measurement, 154
- Channel Response
  - OFDM, 44
  - WLAN, 45
- Channels
  - how to enable, 817
  - in signal database, 815
  - tune to, 816
- Channels tab
  - Channel Power & ACPR display, 155
  - LTE Analysis displays, 590
  - Signal Strength display, 162
- Channels tab (MCPR), 173
- check mark indicator, 877
- Check mark indicator, 21
- CISPR, 877
- CISPR Filter shape
  - Spectrum display BW tab, 119
- Classic color scheme, 34
- Classify a signal, 831
- Combined impact
  - gains/losses, 500
- Compare traces
  - EMC troubleshooting, 480
- Configure
  - accessories, 455
- Configure In/Out in Setup menu, 807
- Connect, 862
  - Connect to instruments
    - LAN, USB, 862
  - Connect to MDO
    - Connect, 862
  - Connect to RSA306
    - Connect, 862
  - Connection
    - LAN or wireless to an MDO4000B/C, 38
    - PCIe to a RSA7100A, 35
    - to an RSA306, RSA306B, RSA500A series, RSA600A series, RSA7100A, 35
    - USB to an MDO4000B/C, 36
    - USB to RSA306, RSA306B, RSA500A series, RSA600A series, 35
  - Connectivity, 35
    - Connect, 862
  - Constellation
    - 802.11ad, 45
    - OFDM, 44
    - WLAN, 45
  - Constellation display, 676
    - displaying a second trace, 717
  - Constellation display settings, 677
  - Convergence
    - Equalizer tab, 709
  - correction tables, 760
  - Create a region (Signal Classification), 820
  - creating a mask, 784
  - Creating presets, 25
  - Cumulative Histogram display
    - settings, 385
  - Cumulative Statistics Table
    - display, 387
  - Cumulative Statistics Table
    - settings, 390
  - CW, 877
  - CW signal, 878
- D**
  - DANL, 878
  - Data file formats, 840
  - Data properties
    - File menu, 851
  - Data Range tab
    - OFDM Analysis displays, 376
    - WLAN Analysis displays, 322
  - Database
    - how to select channels, 815
    - how to set up signal types, 814
    - how to set up standards, 813
    - of signal standards, 813
  - dBfs, 878
  - dBm, 878
  - dBmV, 878
  - dBuV, 878
  - De-emphasis
    - Audio Filters tab, 668
  - deactivating options, 11
  - decibel, 878
  - Declare a signal, 831
  - Default
    - BT limits table, 627
    - P25 limits table, 545
  - default settings, restore, 25
  - Define a region (Signal Classification), 820
  - Define Markers, 732
  - Define Peaks tab, 733
  - Define tab, 739
    - Pulsed RF displays, 404
    - Settling Time displays, 208
  - Delay
    - Triggering, 793
  - Delta Markers, 732
  - Demod I&Q vs Time display
    - settings, 680
  - Demodulation
    - audio, 673
  - Density tab, 88
  - detect
    - AM display, 131
    - FM display, 138
    - General Signal Viewing displays, 116
    - Time Overview, 93

- Detect
    - PM display, 146
  - detection, 879
    - AM display, 131
    - FM display, 138
    - General Signal Viewing displays, 116
    - Time Overview, 93
  - Detection
    - DPX display, 83
    - PM display, 146
  - detector
    - AM display, 131
    - FM display, 138
    - General Signal Viewing displays, 116
    - Time Overview, 93
  - Detector
    - PM display, 146
    - Ranges and Limits table, 189
  - Deviation, 48
  - Diff
    - Audio Summary display, 662
  - Digital Phosphor Spectrum, 74
  - Disconnect from instruments
    - Connect, 862
  - Display
    - EMC-EMI, 484
    - Pulse Statistics, 396
  - display reference level, 879
  - Displays
    - 802.11ad, 333
    - 802.11ad Constellation, 333
    - 802.11ad EVM vs Time, 337
    - 802.11ad Summary, 341
    - 802.11ad Symbol Table, 339
    - arranging, 41
    - BT CF Offset and Drift, 624
    - BT Constellation, 618
    - BT Eye Diagram, 621
    - BT Summary, 627
    - BT Symbol Table, 631
    - Cumulative Histogram, 383
    - Cumulative Statistics Table, 387
    - EMC Analysis, 445
    - Frequency Settling Time, 199
    - interactions between, 41
    - LTE ACLR, 580
    - LTE Channel Spectrum, 583
    - LTE Constellation, 585
    - OFDM Channel Response, 355
    - OFDM Constellation, 358
    - OFDM EVM, 359
    - OFDM Mag Error, 363
    - OFDM Phase Error, 365
    - OFDM Power, 367
    - OFDM Spectral Flatness, 361
    - OFDM Summary, 369
    - OFDM Symbol Table, 372
    - P25 Constellation, 537
    - P25 Eye Diagram, 540
    - P25 Power, 543
    - P25 Summary, 545
    - P25 Symbol Table, 548
    - Phase Settling Time, 199
    - selecting, 41
    - SEM (Spectrum Emission Mask), 215
    - WLAN Channel Response, 295
    - WLAN Constellation, 298
    - WLAN EVM, 300
    - WLAN Mag Error, 302
    - WLAN Phase Error, 304
    - WLAN Power, 306
    - WLAN Spectral Flatness, 309
    - WLAN Summary, 311
    - WLAN Symbol Table, 316
  - Distance to fault (DTF), 44
  - distortion, 879
  - Documentation, 14
  - Done
    - Ranges and Limits table, 189
  - Downlink, 817
  - DPX Density, 88
  - DPX Density Trigger, 788
  - DPX display
    - DPXogram, 74
    - Frequency, 74
    - Phase, 74
    - Spectrum, 74
    - Zero Span, 74
  - DPX Spectra
    - Replay menu, 753
  - DPX Spectra/Acq Data, 751
  - DPX Spectrum settings, 80
  - DPXogram
    - DPX display, 74
    - Traces tab, 81
  - Droop, 51
  - Droop dB, 51
  - DTF/Return Loss display settings, 272
  - Duty Factor (%) measurement, 381
  - Duty Factor (Ratio) measurement, 51
  - dynamic range, 879
- ## E
- Elements of the display, 21
  - EMC
    - accessories setup, 493
    - Analysis option, 443
    - key features, 444
    - pre-compliance testing, 444
    - standards, 443
    - troubleshooting, 444
  - EMC Analysis
    - displays, 475
    - troubleshooting tools, 474
  - EMC Analysis tool
    - how to open, 445
  - EMC reports
    - generating, 472
    - saving, 470
  - EMC-EMI display, 484
  - EMC-EMI display settings
    - Accessories tab, 492
    - Ambient tab, 518
    - Emission Type tab, 491
    - Measurement Type tab, 511
    - Parameters tab, 490
    - Prefs tab, 521
    - Ranges & Limits tab, 506
    - Scale tab, 520
    - Traces tab, 514
  - EMCVu
    - how to open, 445
  - Emission Type tab
    - EMC-EMI display settings, 491

- Enable EQ Export
  - Equalizer tab, 709
- Enable Equalization
  - Equalizer tab, 709
- Equalizer tab
  - GP Digital Modulation displays, 709
- error message
  - Windows Event Viewer, 871
- Error messages, 864
- Ethernet 40 GbE
  - IQ streaming, 809
- Evaluation mode
  - for options, 10
- Event tab (Triggering), 788
- Event Viewer, 871
- EVM, 879
  - 802.11ad, 45
  - OFDM, 44
  - WLAN, 45
- EVM tab
  - WLAN Analysis displays, 327
- EVM vs. Time display, 680
- EVM vs. Time Settings, 681
- Excrsn (dB)
  - Ranges and Limits table, 189
- Expand
  - Ranges and Limits Tab, 188
- export, 879
- External Gain value, 760
- External Gain/Loss Correction tab, 760
- External Loss Tables, 760
- Eye Diagram display settings, 684

## F

- Fall Time, 51
- Fast Frame, 768
- FastFrame, 879
- FFT, 880
- File formats, 840
- file formats supported
  - waveform, 834
- File Menu, 848
- File types, 840
- filter, 880
- Filter Parameter
  - GP Digital Modulation displays, 703
- Filter Shape
  - Ranges and Limits table, 188
  - Spectrum display BW tab, 119
- Find tab
  - GP Digital Modulation displays, 714
- finding bursts in data
  - GP Digital Modulation displays, 714
- Flatness
  - OFDM, 44
  - WLAN, 45
- FlatTop (CW ampl) Filter Shape
  - Spectrum display BW tab, 119
- FM, 880
- FM display, 133
- FM measurements, 48
- FMT (Frequency Mask Trigger), 788
- Formatted data structure, 774
- frame, 880
- Free trial
  - for options, 10
- Freq & BW tab
  - RF I & Q vs Time display, 113
- Freq & BW Tab
  - GP Digital Modulation displays, 708
- Freq & RBW tab
  - Bluetooth, 657
- Freq & Span tab
  - General Signal Viewing displays, 114
- Freq and RBW tab
  - LTE, 601
- Freq Deviation, 52
- Freq Diff, Phase Diff, Freq Abs settings, 406
- Freq Error, 48
- Freq Estimation tab
  - Pulsed RF displays, 410
- Freq, Span & RBW tab
  - Channel Power & ACPR display, MCPR display, 170
  - RF Measurements displays, 227
  - Signal Strength display, 160
- Freq-domain Linearity
  - setting, 404
- frequency, 880
- Frequency
  - DPX display, 74
- frequency band, 880
- Frequency Dev vs Time (BT) display
  - Bluetooth, 635
- Frequency Dev vs Time (P25) display, 552
- Frequency Dev vs. Time (BT) Settings, 639
- Frequency Dev vs. Time (P25) Settings, 554
- Frequency deviation
  - P25, 49
- Frequency Deviation vs. Time settings, 686
- frequency domain view, 880
- frequency drift, 881
- Frequency Edge triggering, 791
- Frequency Error, 46
  - GP Digital Modulation displays, 708
- Frequency Mask Trigger (FMT), 784
- Frequency Offset
  - GP Digital Modulation displays, 708
- frequency range, 881
- Frequency range
  - Bluetooth, 50
- Frequency Reference, 770
- Frequency scale
  - linear, 500
  - log, 500
- frequency settling time, 881
  - measuring, 204
- Frequency Settling Time display, 199



Frequency Settling Time  
settings, 207

frequency span, 881

Frequency tab, 747

Frequency vs. Time display, 107

Frequency vs. Time Settings, 108

Full Screen, 853

## G

Gain Imbalance, 46

GNSS, 795

control panel, 795

how to set up, 797

RSA source, 797

Simulation, 797

GPIO, 881

GPS

time stamp, 773

graticule, 881

Graticule On/Off

RF Measurements

displays, 232

Signal Strength display, 164

grayed out, 881

## H

H500 signal database, 814

Hanning Filter Shape

Spectrum display BW

tab, 119

Harmonic markers

EMC troubleshooting, 475

HCPM transmitter logical channel

time alignment

P25, 49

Help Menu, 863

Hide sensitive readouts, 33

Hide Sensitive readouts, 33

Histogram readout

Pulsed RF displays, 416

Holdoff

Triggering, 793

HPF

Audio Filters tab, 667

Hum & Noise

Audio Summary display, 671

hysteresis, 791

## I

I/Q, 882

IF, 882

Ignore Region

Params2 tab, 666

import, 882

Impulse Response Ampli-  
tude, 382

Impulse Response setting, 405

Impulse Response Time, 382

In-band emission / ACPR

Bluetooth, 50

InBand Emission

Bluetooth, 642

Information messages, 864

input impedance, 882

Inspect suspect frequencies

EMC troubleshooting, 476

Install SignalVu-PC, 3

Internal Attenuator

Internal Settings tab, 759

Internal attenuator (Internal

Settings tab), 759

Internal Preamp

Internal Settings tab, 760

Internal Settings tab, 759

IQ Origin Offset, 46

IQ Sampling Parameters tab, 767

IQ streaming, 810

IQ vs. time view, 111

IRIG-B, 773

time stamp, 773

is greater than (Test), 740

is greater than mask, 739

is inside mask, 739

is inside mask (Test), 741

is less than (Test), 740

is less than mask, 739

is outside mask, 739

is outside mask (Test), 741

## K

Kaiser (RBW) Filter Shape

Spectrum display BW

tab, 119

Keep-out time, 405

Keypad, 852

## L

LAN connection

Connect, 862

Launch EMC Analysis tool, 445

Length, 48

Equalizer tab, 709

Level target

EMC troubleshooting, 480

Levels tab

Pulsed RF displays, 409

license

deactivating, 11

License

activating legacy, 8

install, 5

moving an application, 7

return, 6

trial, 5

uninstall, 6

Licensed software, 3

Licenses, 3

available application

options, 11

how to view, 4

Limit lines, 739

Limits

BT default, 627

P25 default, 545

Spurious display, 190

Limits tab

Bluetooth, 650

P25 Analysis displays, 566

Linear frequency scale, 500

Link to Span, 113

LISN, 882

Load

Ranges and Limits Tab, 188

Ranges and Limits table, 189

local oscillator (LO), 882

Lock Center Frequency of

Spectrum displays, 747

Lock Center Frequency of

Spectrum displays to

Measurement Frequency

Frequency tab, 748

Log

Audio Spectrum display, 670



- Log (Horizontal)
    - Spectrum display, 98
  - Logarithmic frequency scale, 500
  - Loop over all selected records
    - Replay menu, 754
  - LPF
    - Audio Filters tab, 667
  - LTE
    - Analysis Params tab, 604
    - Analysis Time tab, 604
    - Channels tab, 590
    - Freq and RBW tab, 601
    - Measurement Params tab, 602
    - Modulation Params tab, 603
    - Offsets and Limits Table tab, 595
    - Parameters tab, 592
    - Prefs tab, 598
    - Processing tab, 594
    - Scale tab, 596
    - Trace tab, 606
    - VBW (Channels tab), 591
    - VBW (Freq & RBW tab), 601
  - LTE ACLR
    - display, 580
    - settings, 583
  - LTE Channel Spectrum
    - display, 583
    - settings, 585
  - LTE Constellation
    - display, 585
  - LTE measurements, 50
  - LVDS
    - IQ streaming, 810
- M**
- Mag Error, 46
    - OFDM, 44
    - WLAN, 45
  - Magnitude Error vs. Time
    - display, 687
  - Magnitude Error vs. Time
    - settings, 688
  - Main
    - presets, 25
  - Manuals, 14
  - Map It, 795
    - how to use, 803
    - toolbar, 803
  - marker, 883
  - Marker noise mode, 735
  - Marker noise mode (dBc/Hz), 732
  - Marker Properties tab, 732
  - Marker to Center Frequency, 732
  - Markers, 734
    - in the BT Symbol Table, 634
    - Marker Toolbar, 734
    - Using Markers, 729
    - Using Markers in Noise Mode, 735
  - Markers menu, 857
  - Markers Toolbar, 853
  - Mask
    - Ranges and Limits table, 189
  - Mask Editor, 784
  - Mask tab
    - Settling Time displays, 211
  - Mask Test, 739
    - is greater than mask, 739
    - is inside mask, 739
    - is less than mask, 739
    - is outside mask, 739
  - mask testing
    - settling time
      - measurement, 195
  - Math trace
    - Traces tab, 81
  - MATLAB file format, 840
  - Max Freq Error, 382
  - max hold, 883
  - Max number of pulses
    - Pulse Table display, 402
  - Max Number of Pulses
    - Params tab, 403
  - Max Phase Error, 52
  - Max total files saved per Run, 794
  - Max trace points, 105
    - Settling Time displays, 215
  - MCPR (multiple carrier power ratio), 883
  - MCPR display, 164
  - MCPR settings, 168
  - Meas BW
    - Frequency Settling Time, 208
  - Meas Frequency
    - Frequency Settling Time, 208
  - Measurement BW, no filter, 113
  - Measurement Filter
    - GP Digital Modulation
      - displays, 703
    - Params tab, 402
  - Measurement Frequency, 747
    - Frequency tab, 748
  - Measurement Length
    - Time Params tab, 210
  - Measurement Params tab
    - Bluetooth, 658
    - Channel Power & ACPR
      - display, MCPR
      - display, 170
    - LTE, 602
    - Signal Strength display, 160
  - Measurement point, 406
  - Measurement settings export, 833
  - Measurement Type tab
    - EMC-EMI display
      - settings, 511
  - Measurements, 43
    - 802.11ad, 332
    - APCO P25, 49
    - Bluetooth, 49
    - LTE, 50
  - Measurements tab, 401
  - measuring settling time, 204
  - Menus, 846
  - MER (RMS), 695
  - min hold, 883
  - Min Settled Duration
    - Time Params tab, 210
  - Minimum off time between pulses
    - Params tab, 403
  - Mod Distor
    - Audio Summary display, 662
  - Mode
    - Equalizer tab, 709
  - modulate, 883
  - modulating signal, 883
  - modulation, 884
  - Modulation analysis
    - application presets, 30
  - Modulation characteristics
    - Bluetooth, 49

- Modulation fidelity
  - P25, 49
- modulation measurements, 675
- Modulation measurements, 46
- Modulation Params tab
  - GP Digital Modulation
    - displays, 703
  - LTE, 603
  - OFDM Analysis
    - displays, 374
  - P25 Analysis displays, 645
  - WLAN Analysis
    - displays, 319
- Modulation types supported, 703
- moving windows, 862
- Multi-Carrier Power Ratio, 43
- Multiple Carrier Power Ratio, 168

## N

- Navigator View, 852
- nFSK modulation type
  - measurements, 48
- nFSK signal quality
  - measurements, 695
- No. of Harmonics
  - Params2 tab, 666
- No. of Non-Harmonics
  - Params2 tab, 666
- noise, 884
- noise bandwidth (NBW), 884
- noise floor, 884
- Noise markers, 735
- Non-Harmonic Excursion
  - Params2 tab, 666
- Non-Harmonic Threshold
  - Params2 tab, 666
- Numeric keypad, 852

## O

- OBW Level Left/Right, 175
- OBW Ref Power, 175
- Occupied bandwidth
  - LTE, 50
- Occupied Bandwidth, 178
- Occupied Bandwidth
  - settings, 178
- Occupied BW display, 175

- OFDM Channel Response
  - display, 355
  - settings, 355
- OFDM Constellation
  - display, 358
  - settings, 359
- OFDM EVM
  - display, 359
  - settings, 361
- OFDM Mag Error
  - display, 363
  - settings, 365
- OFDM Phase Error
  - display, 365
- OFDM Power
  - display, 367
  - settings, 369
- OFDM Spectral Flatness
  - display, 361
  - settings, 363
- OFDM Summary
  - display, 369
  - settings, 371
- OFDM Symbol Table
  - display, 372
  - settings, 373
- Off
  - Ranges and Limits table, 189
- Offset & Limits Table tab
  - SEM display, 222
- Offset EVM, 695
- Offsets and Limits Table tab
  - LTE, 595
- On
  - Ranges and Limits table, 188
- open (recall), 884
- Open EMC Analysis tool, 445
- Operating band unwanted
  - emission
    - LTE, 50
- Operating frequency accuracy
  - P25, 49
- Optimization
  - Channel Power & ACPR
    - display, MCPR
    - display, 170
  - Signal Strength display, 160

- option
  - activate with Internet, 8
  - activate without Internet, 8
- Option key
  - activate, 8
- Optional software, 3
- options
  - deactivating, 11
  - deactivating legacy, 11
  - moving to another PC, 11
- Options
  - how to purchase, 3
  - list of available, 11
  - transferring an application
    - license, 7
- Options control panel, 33
- OQPSK, 884
- OQPSK and SOQPSK modulation
  - type measurements, 47
- Out-of-band spurious emission
  - Bluetooth, 50
- Output power
  - Bluetooth, 50
- Overlap, 101
- Overshoot, 382
  - dB, 382
- Overshoot dB, 382
- Overshoot settings, 407

## P

- P25
  - presets, 29
- P25 Constellation
  - display, 537
  - settings, 539
- P25 Eye Diagram
  - display, 540
  - settings, 542
- P25 limits, 545
- P25 measurements, 49
- P25 Power vs Time
  - display, 543
  - settings, 544
- P25 Summary
  - display, 545
  - settings, 548
- P25 Symbol Table
  - display, 548

- settings, 551
- Parameters tab
  - AM display, 129
  - Bluetooth, 655
  - CCDF display, 194
  - EMC-EMI display
    - settings, 490
  - FM display, 137
  - LTE, 592
  - Occupied BW display, 179
  - PM display, 144
  - SEM display, 219
  - Spurious display, 185
- Params tab
  - Pulsed RF displays, 402
- Params1 tab
  - Audio Analysis displays, 663
- Params2 tab
  - Audio Analysis displays, 666
- Pass /Fail readout
  - SEM display, 217
- Pass/Fail Limit Testing
  - Spurious display, 190
- Pass/fail testing
  - EMC Range & Limits
    - table, 510
- Pass/Fail tests, 740
- Pause
  - Replay menu, 754
- +Peak
  - Audio Summary display, 662
- Peak
  - Audio Summary display, 662
- Peak Excursion, 732
- Peak FSK err, 48
- Peak Mag Err, 48
- Peak Power, 50
- Peak Threshold, 732
- Peak/Avg Ratio, 43
- Peak-Peak/2
  - Audio Summary display, 662
- Persistence display, 484
- Phase
  - DPX display, 74
- Phase Deviation, 382
- Phase Difference, 382
- Phase Error, 695
  - OFDM, 44
  - WLAN, 45
- Phase Error vs. Time display, 689
- Phase Error vs. Time settings, 690
- phase settling time, 884
  - measuring, 204
- Phase Settling Time display, 199
- Phase Settling Time settings, 203
- Phase vs. Time display, 109
- Phase vs. Time settings, 110
- pictures
  - saving, 833
- +Pk
  - FM display, 48
  - PM display, 49
- Pk
  - FM display, 48
  - PM display, 49
- Pk-Pk
  - FM display, 48
  - PM display, 49
- Pk-Pk/2
  - FM display, 48
- Playback, 780
  - Define skip, 781
  - Exit playback, 781
  - Live rate, 781
  - Location, 781
  - Loop file, 781
  - Progress bar, 781
- Plot
  - Accessories tab, 500
- PM, 885
- PM measurements, 49
- Position
  - Triggering, 793
- Power
  - OFDM, 44
- Power class
  - Bluetooth, 646
- Power density
  - Bluetooth, 50
- Power Markers, 732
- power measurements, 151
- Power measurements, 43
- Power Threshold to Detect Pulses
  - Params tab, 402
- Power vs Time
  - WLAN, 45
- PPS, 773
  - time stamp, 773
- Pre-defined Filters
  - Audio Filters tab, 667
- Prefs tab
  - AM display, 133
  - Bluetooth, 654
  - EMC-EMI display
    - settings, 521
  - FM display, 141
  - General Signal Viewing
    - Displays, 122
  - GP Digital Modulation
    - displays, 719
  - LTE, 598
  - OFDM Analysis
    - displays, 380
  - Options control panel, 33
  - P25 Analysis displays, 565
  - PM display, 149
  - Pulsed RF displays, 416
  - RF Measurements
    - displays, 232
  - Settling Time displays, 215
  - Signal Strength display, 164
  - WLAN Analysis
    - displays, 328
- Presets, 833
  - 802.11ad, 329
  - Application, 25
  - Main, 25
  - P25, 29
  - recalling, 27
  - Standards, 25
  - User, 25
  - WLAN, 25
- Presets tab
  - Options control panel, 33
- primary marker, 885
- Print, 852
- Print Preview, 852
- Processing tab
  - LTE, 594
  - SEM display, 221
- Product documentation, 14
- PSK, 885
- Pulse analysis
  - application presets, 30

- Pulse measurements, 50
- Pulse Statistics display, 396
- Pulse Statistics display
  - settings, 399
- Pulse Table display, 392
- Pulse Table display settings, 394
- Pulse Trace display, 394
- Pulse Trace display settings, 396
- Pulse Width, 51
- Pulse-Ogram settings, 392
- Pulse-Pulse Frequency
  - Difference, 52
- Pulse-Pulse Phase Difference, 52
- Pulse-ref Freq Difference, 382
- Pulse-ref Phase Difference, 382
- pulses
  - how many can be analyzed, 403

## Q

- QAM, 885
- Quadrature Error, 46

## R

- Range file, 840
- Ranges & Limits tab
  - EMC-EMI display settings, 506
- Ranges and Limits Tab
  - Spurious display, 187
- Raw data structure, 774
- RBW, 886
  - Channel Power & ACPR display, MCPR display, 170
  - Signal Strength display, 160
- Ready trigger status light, 782
- real-time analysis, 885
- real-time bandwidth, 885
- real-time seamless capture, 886
- Recalling Presets, 27
- Record, 773
- Record control panel
  - Record, 777
- Record setup
  - formatted data structure, 774
  - raw data structure, 774

- Record to disk, 778
- Recording, 774
- Recording control panel, 773
- Red background (cells), 179
- red text
  - settling time measurements, 202
- Ref
  - Audio Summary display, 662
- Ref Channel tab
  - SEM display, 222
- Ref level (Internal Settings tab), 759
- Reference Filter
  - GP Digital Modulation displays, 703
- reference level, 886
- Reference tab
  - Spurious display, 185
- Rel
  - Ranges and Limits table, 189
- Rel Same
  - Ranges and Limits table, 189
- Rel Start (dB)
  - Ranges and Limits table, 189
- Rel Stop (dB)
  - Ranges and Limits table, 189
- Relative power
  - Bluetooth, 50
- Repeat, 765
- Repetition Interval, 51
- Repetition Rate, 381
- Replay all selected records
  - Replay menu, 754
- Replay control panel, 751
- Replay current record
  - Replay menu, 754
- Replay from selected
  - Replay menu, 754
- Replay menu, 753
- Replay Speed tab, 753
- Replay toolbar, 756
  - Replay menu, 754
- Reports
  - EMC Analysis, 466
  - generate EMI test, 472
  - save EMI test results, 470

- Reset Equalization
  - Equalizer tab, 709
- Reset layout
  - Ranges and Limits Tab, 188
- residual FM (incidental FM), 886
- residual response, 886
- results
  - saving, 833
- Resume, 765
- Return loss (RL), 44
- Return loss measurements, 44
- RF Channel Power
  - measurement, 153
- RF I & Q vs. Time display, 111
- RF I & Q vs. Time settings, 112
- RF output power
  - P25, 49
- Rho, 46
- Ripple, 382
- Ripple dB, 382
- ripple measurement
  - calculation, 886
- Ripple settings, 407
- Rise Time, 381
- RMS
  - Audio Summary display, 662
  - FM display, 48
  - PM display, 49
- RMS Error Magnitude, 48
- RMS Freq Error, 51
- RMS FSK Err, 48
- RMS Mag Err, 48
- RMS Phase Error, 382
- RSA Device, 796
- Run, 765
- Run menu, 856

## S

- S/N
  - Audio Summary display, 662
- Save
  - Ranges and Limits Tab, 188
- Save acq data on Trigger, 794
- Save and Export tab, 33
  - Options control panel, 34
- Save As
  - Ranges and Limits table, 189
- Save on trigger, 794

- Save picture on Trigger, 794
- saved file types, 833
- saving
  - acquisition data, 833
  - pictures, 833
  - results, 833
  - setups, 833
- Saving
  - presets, 25
- Saving and Recalling Data, 833
- Scale tab
  - AM display, 132
  - Audio Analysis displays, 669
  - Bluetooth, 651
  - CCDF display, 193
  - DPX Spectrum display, 85
  - EMC-EMI display
    - settings, 520
  - FM display, 140
  - General Signal Viewing
    - displays, 121
  - GP Digital Modulation
    - displays, 718
  - LTE, 596
  - OFDM Analysis
    - displays, 378
  - P25 Analysis displays, 562
  - PM display, 148
  - Pulsed RF displays, 414
  - RF Measurements
    - displays, 231
  - SEM display, 225
  - Settling Time displays, 214
  - Signal Strength display, 163
  - Spectrogram display, 103
  - Spectrum display, 98
  - WLAN Analysis
    - displays, 325
- Search control panel, 744
- Search for instruments
  - Connect, 862
- Search In, 740
- secondary marker, 887
- Security tab, 33
  - Options control panel, 34
- Select all
  - Replay menu, 754
- Select data records tab, 751
- Select records from history
  - Replay menu, 754
- SEM display, 215
- sensitivity, 888
- Set limits
  - EMC Range & Limits
    - table, 510
- Set to max BW, 113
- Settings, 872
  - AM display, 128
  - Audio Spectrum display, 660
  - Audio Summary display, 662
  - BT 20dB BW, 641
  - BT CF Offset and Drift, 587
  - BT Constellation, 621
  - BT Eye Diagram, 623
  - BT Frequency Dev vs. Time, 639
  - BT Summary, 631
  - BT Symbol Table, 635
  - Cable Loss display, 260
  - CCDF display, 192
  - Constellation display, 677
  - Cumulative Histogram
    - display, 385
  - Cumulative Statistics Table
    - display, 390
  - Demod I&Q vs Time
    - display, 680
  - DPX Spectrum, 80
  - DTF/Return Loss
    - display, 272
  - EVM vs. Time display, 681
  - Eye Diagram display, 684
  - FM display, 135
  - Frequency Deviation vs. Time, 686
  - Frequency Settling Time, 207
  - Frequency vs. Time, 108
  - LTE ACLR, 583
  - LTE Channel Spectrum, 585
  - Magnitude Error vs. Time, 688
  - MCPR, 168
  - Occupied Bandwidth, 178
  - OFDM Channel
    - Response, 355
  - OFDM Constellation, 359
- OFDM EVM, 361
- OFDM Flatness, 363
- OFDM Mag Error, 365
- OFDM Phase Error, 367
- OFDM Power, 369
- OFDM Summary, 371
- OFDM Symbol Table, 373
- Options control panel, 33
- P25 Constellation, 539
- P25 Eye Diagram, 542
- P25 Frequency Dev vs. Time, 554
- P25 Power vs Time, 544
- P25 Summary, 548
- P25 Symbol Table, 551
- Phase Error vs. Time, 690
- Phase Settling Time, 203
- Phase vs. Time, 110
- Pulse Statistics display, 399
- Pulse Table display, 394
- Pulse Trace display, 396
- Pulse-Ogram display, 392
- restoring defaults, 25
- RF I & Q vs. Time, 112
- Signal Quality, 696
- Spectrogram display, 101
- Spectrum display, 97
- Spectrum Emission
  - Mask, 219
- Spurious display, 184
- Symbol Table display, 698
- Time Overview display, 90
- Trellis Diagram display, 701
- Trigger, 787
- WLAN Channel
  - Response, 295
- WLAN Constellation, 299
- WLAN EVM, 301
- WLAN Mag Error, 303
- WLAN Phase Error, 305
- WLAN Power vs Time, 308
- WLAN Spectral Flatness, 310
- WLAN Summary, 315
- WLAN Symbol Table, 318
- Settled Frequency
  - definition, 195
- Settled Phase
  - definition, 195



- settling time
    - measuring, 204
  - Settling Time, 195
    - definition, 195
  - Settling Time decimal places
    - Settling Time displays, 215
  - settling time measurement
    - text color, 202
  - Setup Menu, 857
  - setups
    - saving, 833
  - shape factor (skirt selectivity), 888
  - Show graticule
    - General Signal Viewing Displays, 122
    - Pulsed RF displays, 416
    - Settling Time displays, 215
  - Show Marker Readout in Graph
    - General Signal Viewing Displays, 122
    - Pulsed RF displays, 416
    - RF Measurements displays, 232
    - Settling Time displays, 215
    - Signal Strength display, 164
  - Show points, 500
  - Show recalled trace, 115
    - AM display, 130
    - FM display, 138
    - PM display, 145
    - Time Overview display, 93
  - signal, 888
  - Signal Classification
    - create a region, 820
    - define a region, 820
  - Signal database, 813
    - merge the H500 database, 814
  - Signal Power
    - Audio Summary display, 661
  - Signal Quality display, 691
  - Signal quality measurements, 694
  - Signal Quality settings, 696
  - Signal standards, 813
  - signal strength, 888
  - Signal Strength display, 157
  - Signal Strength Settings control panel, 158
  - Signal types, 813
  - Simulation
    - GNSS, 797
  - SINAD
    - Audio Summary display, 662
  - span, 888
  - span per division, 888
  - Span/RBW Ratio
    - Spectrum display BW tab, 119
  - spectrogram, 889
  - Spectrogram display, 99
  - Spectrogram display settings, 101
  - spectrum, 889
  - Spectrum
    - DPX display, 74
    - Traces tab, 81
  - spectrum analysis, 889
  - Spectrum analysis
    - application presets, 31
  - spectrum analyzer, 889
  - Spectrum Center Frequency, 747
    - Frequency tab, 748
  - Spectrum display, 95
  - Spectrum display settings, 97
  - Spectrum Emission Mask
    - display, 215
    - settings, 219
  - Spectrum Monitor
    - Spectrogram, 104
  - spectrum time, 889
  - Spectrum Time tab, 747
  - Spectrums/line, 101
  - Split
    - DPX display, 74
  - spot, 889
  - Spot requirements
    - EMC Range & Limits table, 509
  - spur, 889
  - Spur
    - defining, 190
  - Spurious, 179
  - Spurious display settings, 184
  - spurious response, 889
  - Standard
    - Audio Filters tab, 667
  - Standard Settings button, 702
  - Standard software, 3
  - Standards
    - 802.11ad, 329
    - database, 813
    - how to set up database, 813
    - presets, 25
  - Standards presets
    - P25, 29
    - WLAN, 29
  - Start (Hz)
    - Ranges and Limits table, 188
  - Status bar, 853
  - Status Bar, 854
  - Stop
    - Replay menu, 754
  - Stop (Hz)
    - Ranges and Limits table, 188
  - Streaming
    - IQ data 40 GbE, 809
    - IQ data through LVDS, 810
    - IQ data with API, 808
  - Summary
    - 802.11ad, 45
    - WLAN, 45
  - supported file formats
    - waveform, 834
  - symbol maps, 719
  - Symbol Rate, 48
  - Symbol rate accuracy
    - P25, 49
  - Symbol Rate Error, 48
  - Symbol Table
    - 802.11ad, 45
    - WLAN, 45
  - Symbol Table display, 697
  - Symbol Table display
    - settings, 698
- ## T
- Taps
    - Equalizer tab, 709
  - Taps/Symbol
    - Equalizer tab, 709
  - Target Reference
    - Frequency Settling Time, 209
  - Test For, 740
  - Test Patterns tab
    - P25 Analysis displays, 561

- Test using a mask, 741
  - THD
    - Audio Summary display, 662
  - Threshld (dBm)
    - Ranges and Limits table, 189
  - Thunderstorm color scheme, 34
  - Time, 382
  - Time & Freq Scale tab
    - Spectrogram display, 103
  - time measurement, 890
  - Time Overview, 89
  - Time Overview display
    - settings, 90
  - Time Params tab
    - Settling Time displays, 210
  - time reference, 890
  - time scale status readout, 101
  - Time stamp, 773
    - GPS, PPS, IRIG-B, 773
  - Time-Frequency analysis
    - application presets, 32
  - TIQ acquisition data files, 34
  - TIQ acquisition data files
    - parameters, 33
  - TNHD
    - Audio Summary display, 662
  - TOFF
    - LTE, 50
  - Tolerance (+/-)
    - Frequency Settling Time, 209
  - Tools menu
    - battery status, 860
  - Tools Menu, 858
  - Total AM
    - AM display, 48
  - Touch-screen Actions, 19
  - trace, 890
  - Trace 2
    - Constellation display, 717
  - Trace tab
    - AM display, 130
    - Bluetooth, 652
    - FM display, 138
    - GP Digital Modulation displays, 716
    - LTE, 606
    - OFDM Analysis displays, 378
    - P25 Analysis, 562
    - PM display, 145
    - Settling Time displays, 211
    - Time Overview display, 93
    - WLAN Analysis displays, 324
  - Traces tab
    - DPX display, 81
    - EMC-EMI display settings, 514
    - General Signal Viewing displays, 115
    - Pulse-Ogram display, 413
    - RF Measurements display, 228
    - Spectrogram display, 102
    - WLAN Channel Response display, 324
  - Traces tab - Math Trace
    - General Signal Viewing displays, 119
  - Traces Toolbar, 853
  - Transform Window
    - Spectrum display BW tab, 119
  - Transmission Gain, 44
  - Transmitter frequency behavior
    - P25, 49
  - Transmitter power and encoder
    - attack time P25, 49
  - Transmitter power and encoder
    - attack time with busy/idle P25, 49
  - Transmitter throughput delay
    - P25, 49
  - Trellis Diagram display
    - settings, 701
  - Trial license, 7
  - Trial licenses, 10
  - Trig Meas tab
    - P25 Analysis displays, 564
  - Trig'd trigger status light, 782
  - Trigger On This, 783
  - Trigger settings, 787
    - Advanced tab, 793
    - Event tab, 788
  - trigger status lights, 782
  - triggering
    - frequency mask trigger, 781
  - Troubleshooting tools
    - EMC Analysis, 474
  - Troubleshooting tools EMC
    - compare traces, 480
    - harmonic markers, 475
    - inspect suspect frequencies, 476
    - level target, 480
    - persistence display, 484
  - Tune to a channel, 816
  - Tutorials
    - YouTube videos, 17
  - Types
    - how to set up signal database, 814
- ## U
- Uniform (None) Filter Shape
    - Spectrum display BW tab, 119
  - Units tab, 750
  - Unwanted emissions (ACPR)
    - P25, 49
  - Uplink, 817
  - USB connection
    - Connect, 862
  - User Filters
    - file format, 726
    - loading, 725
  - User presets, 25
  - User Symbol Map, 713
- ## V
- VBW, 95
    - LTE, 591
    - RF Measurements displays, 227
    - Spectrum display BW tab, 119
  - VBW (Hz)
    - Ranges and Limits table, 189
  - VBW On
    - Ranges and Limits table, 189
  - vector signal analyzer, 890

vertical scale factor, vertical  
display factor, 890

Video tutorials, 17

View

Basic Controls Toolbar, 853

Full Screen, 852

Markers Toolbar, 853

Navigator View, 852

Numeric keypad, 852

Replay Toolbar, 853

Status Bar, 853

Traces Toolbar, 853

View Menu, 852

violation, 890

violation (frequency mask  
trigger), 791

VSWR, 44

## W

Waterfall

Spectrogram/DPXogram, 103

waveform file formats  
supported, 834

Window menu, 862

Windows Event Viewer, 871

WLAN

presets, 25

video tutorials, 17

WLAN Channel Response

display, 295

settings, 295

WLAN Constellation

display, 298

settings, 299

WLAN EVM

display, 300

settings, 301

WLAN Mag Error

display, 302

settings, 303

WLAN Phase Error

display, 305

WLAN Power vs Time

display, 306

settings, 308

WLAN Spectral Flatness

display, 309

settings, 310

WLAN Summary

display, 311

settings, 315

WLAN Symbol Table

display, 316

settings, 318

## X

x dB BW Ref Power, 175

x dB Level, 179

## Y

YouTube

Tektronix channel, 17

## Z

Zero Span

DPX display, 74