

**Read This First**

**Tektronix**

**Bootable Floppy Disk Instructions**

**071-0608-00**

## Read This First

This floppy disk is not a bootable floppy disk. You must make this floppy disk bootable before you can use it.

To make this floppy disk bootable, follow these instructions:

1. Move the write protect tab on the floppy disk to the Write position.
2. Insert the floppy disk into the floppy disk drive.
3. On your Windows 95 or Windows 98 desktop, double click the **My Computer** icon.
4. Double click the **3 ½ Floppy (A:)** icon.
5. Select **File** → **Format...**
6. In the Format dialog box select **Copy System Files Only**.
7. Select **Start**.
8. Select **Close**.
9. Remove the floppy disk from the floppy disk drive.
10. Move the write protect tab on the floppy disk to the Write Protect position.

The floppy disk is now a bootable floppy disk.