

本文主要讲述 KickStart 软件许可证如何生成，本文适用于 KickStart 2.4.0 及以上版本，主要内容如下：

1. TEK AMS 账户设置	2
1.1. TEK.COM 账号	2
1.2. TEK AMS 账号	3
2. 许可证生成及安装	3
2.1. 许可证生成	3
2.2. Host ID	5
2.3. 许可证安装	6
3. 许可证转移到新电脑/修改许可证有效期	7
3.1. 生成 exit 文件	7
3.2. 重新生成许可证	7
4. 许可证到期处理	8
5. 纸质许可证提取	9

1. TEK AMS 账户设置

泰克通过 TEK AMS 资产管理系统管理选件许可证，要访问 TEK AMS 系统必须在 TEK.COM 注册账号

1.1. TEK.COM 账号

购买软件后，会收到包含许可证管理的权限提取码的邮件，如邮件 1 所示，需要注意的是此提取码有效期 1 年，如果邮箱没有注册过泰克账号，请点击邮件链接 <http://www.tek.com/user/my-profile> 注册账号，注册时请使用购买软件时相同的邮箱，个人单位、地址等信息用英文或者拼音填写，如已注册过泰克账号，无需重复注册，记住提取码即可。

邮件 1

Tektronix/Keithley License Management System

Dear [REDACTED]

Thank you for your order number [REDACTED] of 1 new software licenses for your Tektronix/Keithley products. Included in this email are instructions on how to obtain those license keys.

Here is a list of the products purchased on this order:

1 - [REDACTED] License; TekBench software; Floating

To manage the Check In and Check Out process, we have developed TekAMS, a free, web-based application available using any web-connected computer. However, to access the application, you must be a registered user on tek.com. To become a registered user, use this URL:

<http://www.tek.com/user/my-profile>

Then click the "Register Now" link and use the email address in this message.

Once you have registered, access TekAMS at the following URL: <http://www.tek.com/ams> and login to TekAMS using your tek.com user name and password.

After you login, enter the License application by clicking on the "Software Licenses" link at the top of the page, then click on the "Redeem a Claim Check" link on the page and enter your personalized code:

EReUqu (case-sensitive)

This claim check is only good for 1 year and is specific to a tek.com account with the user name of [REDACTED]. Please redeem your claim check [REDACTED].


After you have redeemed your claim check, you will have full access to check out and check in your licenses using this TekAMS application.

For questions, please refer to <https://www.tek.com/products/product-license>. If you need further assistance, contact your local Technical Support team (<https://www.tek.com/support>)

Thanks for buying Tektronix!

1.2. TEK AMS 账号

拥有 TEK.COM, 即可登陆 TEK AMS 系统 <http://www.tek.com/products/product-license>, 点击 许可证, 在 许可证库存, 输入提取码, 点击 Submit, 即可看到您单位信息 (如果账号已经是其他单位许可证管理员, 登陆之后需要点击右上角 齿轮图标进入 设置, 才可输入新提取码; 在 设置菜单, 可以切换单位)



HOME SOFTWARE LICENSES CATALOG HELP/FAQ

- No Active Customer Relationship | [Icon] | [Icon] | [Icon] OFF | Log Off

tektronix.com / License Manager Inventory

INVENTORY IN USE HISTORY ORDERS TRIALS / PROMOS CERTIFICATES EXTENSIONS EXPIRATIONS

License Inventory

① You have claim checks that have not yet been redeemed. [Click here to re-send those claim checks to partner_higha@partnerstest.com](#) or enter them below:


Enter the case-sensitive claim check you received:

SUBMIT

ADD FILTER +

Name	Type	Purchased	Inuse	Available	Action
There were no results.					

至此, TEK AMS 账号设置完毕



HOME SOFTWARE LICENSES CATALOG HELP/FAQ

tektronix.com / License Manager Settings

MY CUSTOMERS MY PREFERENCES NOTIFICATIONS USER MANAGER MY ACCOUNT

Customer Relationships

① Your active customer has been changed to: [Redacted]

Activate	Customer	Drop Relationship
Current	[Redacted]	N/A

2. 许可证生成及安装

2.1. 许可证生成

TEK AMS 账号设置完成后, 进入库存 许可证库存, 可以看到采购的许可证类型、可用、使用中的许可证数量

许可证库存

添加过滤器 +

FL:浮动许可证
NL:节点锁定许可证

名称	类型	已订购	使用中	可用	操作
KICKSTARTFL-BASE KickStartFL-BASE for all base apps of KickStart 2.0; Floating	FL Permanent	1	0	1	许可操作

点击 许可证操作 下拉菜单，点击 签出

名称	类型	已订购	使用中	可用	操作
KICKSTARTFL-BASE KickStartFL-BASE for all base apps of KickStart 2.0; Floating	FL/Permanent	1	0	1	^ 许可操作 查看技术规格 签出 查看订单

输入主机 ID (HostID, 查看方法参考下图文字, 或 2.2 图示), 点击验证单位

签出至 PC/平板电脑

You must first identify the device you are installing the license to. All fields are required

许可证 * KICKSTARTFL-BASE

兼容软件下载

- KICKSTART INSTRUMENT CONTROL SOFTWARE VERSION 2.4.0 (WINDOWS 10, 8, 7 COMPATIBLE) - 转到下载页面
- KickStart Instrument Control Software Version 2.3.0 (Windows 10, 8, 7 compatible) - 转到下载页面
- KickStart Instrument Control Software Version 2.2.1 (Windows 10, 8, 7 compatible) - 转到下载页面
- KickStart Instrument Control Software Version 2.2.0 (Windows 10, 8, 7 compatible) - 转到下载页面

主机 ID *

主机 ID *

- Host ID can be obtained from the application itself.
 - For SignalVu-PC users, the Host ID is located under the "Tools -> Licenses -> Manage" Menu
 - For SourceXpress users will find the Host ID in the "select Help->About" Menu. For AWG 70000A users, the Host ID is located under the Utilities Tab under "About my AWG."
 - For TekScope Anywhere users, the Host ID is located in the "Help -> Install Options" Menu.
 - For Kickstart users, if you are installing KICKSTARTFL-BASE, open the application and click on the Gear icon in the upper right corner. Then click on Manage Licenses.
 - If you are installing "KICKSTARTFL-HRMA", open the application and click on the "key" icon in the upper right corner. On the subsequent license page, copy the Host ID.
 - For "DataVu-PC" users, the Host-ID is located in the License Manager menu.
 - For 4/5/6 Series MSO instruments, the Model, Serial Number, and Host ID is available in the instrument's Help-> About menu near the top of the window.

验证单位 取消

根据实际采购许可证类型和有效期选择 许可证有效期，， 点击 确认签出

名称	类型	已订购	使用中	可用	操作
KICKSTARTFL-BASE KickStartFL-BASE for all base apps of KickStart 2.0; Floating	FL/Permanent	1	0	1	许可操作

签出详细信息

主机 ID *

许可证类型 *

许可证有效期 *

Permanent

12

Months

The duration of a floating license is your choice. It can be as short as 4 hours, or as long as 4 years.

可添加客户信息，非必须

确认签出 取消

ADD END USER INFORMATION

即可完成许可证生成，点击文件 即可下载许可证文件,拓展名为.lic

tektronix.com / 许可证管理器库存

库存	使用中	历史	订单	试用/促销	证书	EXTENSIONS	EXPIRING SOON
----	-----	----	----	-------	----	------------	---------------

名称	类型	已订购	使用中	可用	操作
KICKSTARTFL-BASE KickStartFL-BASE for all base apps of KickStart 2.0; Floating	FL/Permanent	1	1	0	许可操作

使用中的许可证


型号	序列号	主机 ID	许可证	到期日期 (GMT)	文件	谁	操作
①			KICKSTARTFL-BASE				使用中操作

签出详细信息

① Checkout Complete.


2.2. Host ID

安装并打开 kickstart 软件，点击 钥匙图标，即可进入许可证管理，点击 Host ID 后面字符即可复制 host ID



2.3. 许可证安装


打开 kickstart 软件，依次点击**钥匙图标**，install license 即可安装



3. 许可证转移到新电脑/修改许可证有效期

3.1. 生成 exit 文件

打开 kickstart 软件，点击**钥匙图标**、选择要卸载的许可证，点击 **remove license** 卸载许可证，保存生成的卸载文件（以 EXIT 结尾的.lic 文件）



3.2. 重新生成许可证

登录 TEK AMS 系统，选择 许可证-使用中-上传退出密钥



选择 **exit** 文件，点击 **签入**，

tektronix.com / 使用中的许可证

库存	使用中	历史	订单	试用/促销	证书	EXTENSIONS	EXPIRING SOON
----	-----	----	----	-------	----	------------	---------------

使用中的许可证

添加过滤器 +

上传退出密钥

退出密钥:

选择文件

未选择任何文件

签入

取消

型号	序列号	主机 ID	许可证	到期日期 (GMT)	文件	谁	操作
----	-----	-------	-----	------------	----	---	----

tektronix.com / 使用中的许可证

库存	使用中	历史	订单	试用/促销	证书	EXTENSIONS	EXPIRING SOON
----	-----	----	----	-------	----	------------	---------------

签出详细信息

① Check In Complete

操作完成后，此许可证会返回到库存，然后就重新生成许可证了。

tektronix.com / 许可证管理器库存

库存	使用中	历史	订单	试用/促销	证书	EXTENSIONS	EXPIRING SOON
----	-----	----	----	-------	----	------------	---------------

许可证库存

添加过滤器 +

名称	类型	已订购	使用中	可用	操作
KICKSTARTFL-BASE KickStartFL-BASE for all base apps of KickStart 2.0; Floating	FL/Permanent	1	0	1	许可操作

4. 许可证到期处理

在软件选件有效期内，单个 **license** 文件快到期的时候，webmaster@tek.com 邮箱会发送一封提醒邮件告知您具体将要过期的许可证，并提供两个解决办法

If you wish to continue using this license, you have two choices.

1. Allow the key to expire on the date listed above. When that happens you may visit TekAMS and check out a new license key.
2. Generate an exit key today from the instrument, and check that back in to TekAMS. Then you may check out a new key.

1. 让许可证自动过期，过期后会自动退回 AMS 系统，重新在 AMS 系统生成
2. 过期之前任意时间，按上文修改许可证有效期的办法重新生成许可证

5. 纸质许可证提取

部分客户会收到一份纸质版(PDF)许可证提取证书，先注册 TEK.COM 账号，注册完成之后，访问 <https://www2.tek.com/slam/sl/licenses/ui/redeem>

完全按照文档中的 Redemption Code 输入 5 段提取码，然后点击 **继续**，然后点击关联客户的下拉菜单，选中您**账号关联**的单位，点击**完成**

此许可证即进入**库存**里，从 [2.1.许可证生成](#) 开始操作即可。

相关链接: [Keithley KickStart 软件](#)

最近更新: 2020-11-17 lht

顺颂商祺！

泰克亚太区技术支持部门

发送邮件给泰克，为您提供全面可靠的测试测量解决方案，原来解决问题可以这么简单快速，来信：

获取在线技术支持 400@tektronix.com

获取产品报价 china-iam@tektronix.com

维修、延保、校准 china-service@tektronix.com