



**AWG52UP
Option SSD
AWG5200 Series Upgrades
Instructions**

www.tek.com



075-1096-00

Copyright © Tektronix. All rights reserved. Licensed software products are owned by Tektronix or its subsidiaries or suppliers, and are protected by national copyright laws and international treaty provisions.

Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supersedes that in all previously published material. Specifications and price change privileges reserved.

TEKTRONIX and TEK are registered trademarks of Tektronix, Inc.

Contacting Tektronix

Tektronix, Inc.
14150 SW Karl Braun Drive
P.O. Box 500
Beaverton, OR 97077
USA

For product information, sales, service, and technical support:

- In North America, call 1-800-833-9200.
- Worldwide, visit www.tek.com to find contacts in your area.

Service safety summary

Only qualified personnel should perform service procedures. Read this *Service safety summary* before performing any service procedures.

Do not service alone. Do not perform internal service or adjustments of this product unless another person capable of rendering first aid and resuscitation is present.

Disconnect power. To avoid electric shock, switch off the instrument power, then disconnect the power cord from the mains power.

Use care when servicing with power on. Dangerous voltages or currents may exist in this product. Disconnect power, remove battery (if applicable), and disconnect test leads before removing protective panels, soldering, or replacing components.

To avoid electric shock, do not touch exposed connections.

Upgrade kit overview

This document provides instructions for to install the solid state drive on the following Tektronix products:

- AWG5202 Arbitrary Waveform Generators
- AWG5204 Arbitrary Waveform Generators
- AWG5208 Arbitrary Waveform Generators

For a list of available options, see the Tektronix website (www.tektronix.com) or your Tektronix representative.

Kit parts lists

AWG52UP SSD

This upgrade provides a preprogrammed solid state drive to use as either a secondary hard drive or as a replacement for a failed hard drive.

The kit contains the following items:

Tektronix part number	Qty.	Description
211-1081-XX ¹	4	SCREW, MACHINE; M3 X 0.5 X 3.5MM, FLAT WAFER HD W/SERRATIONS STRESS RELIEVED, PHL, ZINC PLATED STEEL
335-3376-XX ¹	1	MARKER, IDENT; HD ADAPTER (SLED); SAFETY CONTROLLED
850-0358-XX ¹	1	HARD DRIVE, PROGRAMMED; SOLID STATE DRIVE PROGRAMMED W/ OS & APP SW Contains the Windows 7 Operating System and the most current instrument application software.
407-5883-XX ¹	1	BRACKET, HARD DRIVE, FRONT COVER
407-5884-XX ¹	1	BRACKET, HARD DRIVE, SLED
075-1096-XX	1	MANUAL, KIT INSTRUCTIONS

¹ The hard drive and the mechanical sled components are pre-assembled.

Upgrade kit installation

Refer to the one (or more) of the following installation sections pertaining to the upgrade(s) you are installing.

Minimum tool and equipment list

No special tools are required to install any of the upgrade kits covered by these installation instructions.

AWG52UP SSD installation


NOTE. Before installing the new hard drive, use an external backup device to back up any files on your instrument for use on the new hard drive.

Install the hard drive using the following procedure:

1. Power off the instrument.
2. Loosen the thumb screws and remove the existing hard drive.

NOTE. The hard drive and hard drive sled components are pre-assembled.

3. Install the new hard drive, and then tighten the thumb screws to secure the drive in the instrument.
4. Power on the instrument to verify operation.



Verify instrument software version

Tektronix recommends to update to the latest available application software for your instrument.

1. Select **Utilities > About my AWG**. Under System Information, note the Software Version number.
2. Use your Web browser to go to: www.tektronix.com/software.
3. Search for your instrument's model number and follow the link to the software.
4. If the installed software is older than that available, download the software.
5. Follow the instructions on the Web page to install the software.