PCIE4 PRO BUNDLE

See the TMT4 Help for detailed information on how to use these accessories.

PCIE4-M2.22-EDGE

PCIE4-U2-EDGE

PCIE4-U3-EDGE

PCIE4-M2.22-EXTENDER

PCIE4-CEM-EDGEX1

PCIE4-CEM-EDGEX8

PCIE4-ADAPTER-BAS

PCIE4-CEM-EDGEX4

PCIE4-CEM-EDGEX16

PCIE4-M2-SLOT

PCIE4-U3-SLOT

PCIE4-CEM-SLOTX16

PCIE4-U2-SLOT

Tektronix®

Product documentation

The following user documentation is available for your product. See the TMT4 Help for detailed information on how to use these accessories. These and other user documents are available for download from www.tek.com. Other information, such as demonstration guides, technical briefs, and application notes, can also be found at www.tek.com.

Document	Content
Installation and Safety Instructions	Safety, compliance, and basic connection and turn on information. Multi-language document.
Help	In-depth operating information for the product. Available from the Help button in the product UI and as a downloadable PDF on *www.tek.com*.
User Manual	In-depth operating information for the product.
Specifications and Performance Verification Technical Reference	Instrument specifications and performance verification instructions for testing instrument performance.
API Programming	API commands for remotely controlling the instrument. Accessible from the instrument application online.
Declassification and Security Instructions	Information about the location of memory in the instrument. Instructions for declassifying and sanitizing the instrument.
Service Manual	Replaceable parts list, theory of operations, and repair and replace procedures for servicing an instrument.

How to find your product documentation

1. Go to *www.tek.com*.
2. Click **Download** in the green sidebar on the right side of the screen.
3. Select **Manuals** as the Download Type, enter your product model, and click **Search**.