

Instructions



**TDS5UP, TDS6UP, TDS7UP & CSA7UP
Option W2K**

**TDS5000, TDS6000, CSA7000 & TDS7000 Series
Windows 2000 Upgrade Kit**

075-0776-02

Warning

The servicing instructions are for use by qualified personnel only. To avoid personal injury, do not perform any servicing unless you are qualified to do so. Refer to all safety summaries prior to performing service.

www.tektronix.com



075077602

Copyright © Tektronix, Inc. All rights reserved. Licensed software products are owned by Tektronix or its suppliers and are protected by United States copyright laws and international treaty provisions.

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013, or subparagraphs (c)(1) and (2) of the Commercial Computer Software - Restricted Rights clause at FAR 52.227-19, as applicable.

Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supercedes that in all previously published material. Specifications and price change privileges reserved.

Tektronix, Inc., P.O. Box 500, Beaverton, OR 97077

TEKTRONIX and TEK are registered trademarks of Tektronix, Inc.

Kit Description and Installation

This kit includes software with instructions to install Windows 2000 operating system (Option W2K) onto your TDS5000, TDS6000, CSA7000 & TDS7000 Series oscilloscopes. Once installed the oscilloscope will operate using Windows 2000.

Products

TDS5000 Series B029999 and Below
TDS6000 Series All serial numbers
CSA7000 Series All serial numbers
TDS7000 Series All serial numbers

Kit Parts List

Instrument	Quantity	Part number	Description
All	1 ea	075-0776-XX	Kit Instructions: Windows 2000, TDS5000, TDS6000, CSA7000 & TDS7000 Series
TDS5000 Series	1 ea	063-3508-XX	Software:Product, TDS5000 Series
	1 ea	063-3509-XX	Software:TDS5000 Series Operating System Restore, Windows 2000
TDS6000, TDS7000 & CSA7000 Series	1 ea	020-2521-XX	Kit, Software: Operating System Restore, Includes subparts:
		NS	Certificate of Authenticity
		NS	License agreement
		NS	Certificate, Easy Restore
		NS	Sticker, Checkit
		071-1263-XX	Manual, Changing Windows Language
NS	071-1263-XX	Software: Operating System Restore: Manual and 2 CDs	
	063-3645-XX	Software: BIOS Update CD	

NS - Not Saleable

Install

Windows 2000 Installation

To install Windows 2000 follow these steps:



CAUTION. *To avoid data loss, back up any important user files stored on the hard disk. This operating system restoration process reformats the hard disk, which erases any user-installed files and applications.*

1. Install the new TDS5000 or TDS6000, CSA7000, TDS7000 Series Windows 2000 Operating System Restore CD. Follow the instructions provided with the Windows 2000 Operating system CD.
2. Install the new TDS5000 or TDS6000, CSA7000, TDS7000 Series Product Software CD. Follow the instructions provided with the Product software CD.
3. Install the Optional Applications Software on Windows-Based Oscilloscopes CD. Follow the instructions provided with the software CD.

BIOS Update

TDS6000, TDS7000 & CSA7000 only: To update the instrument BIOS, follow the instructions in the Instructions.txt file on the *BIOS Update* CD.

❏ End of document ❏