

**PQA6CUP Upgrades  
PQA600C Picture Quality Analyzer  
Instructions**

[www.tektronix.com](http://www.tektronix.com)



075-1089-00

**Tektronix**

Copyright © Tektronix. All rights reserved. Licensed software products are owned by Tektronix or its subsidiaries or suppliers, and are protected by national copyright laws and international treaty provisions.

Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supersedes that in all previously published material. Specifications and price change privileges reserved.

TEKTRONIX and TEK are registered trademarks of Tektronix, Inc.

## **Contacting Tektronix**

Tektronix, Inc.  
14150 SW Karl Braun Drive  
P.O. Box 500  
Beaverton, OR 97077  
USA

For product information, sales, service, and technical support:

- In North America, call 1-800-833-9200.
- Worldwide, visit [www.tektronix.com](http://www.tektronix.com) to find contacts in your area.



# Table of Contents

Kit description ..... 1  
    Supported products ..... 1  
    Kit parts list..... 1  
Installation instructions ..... 2



---

## Kit description

This kit describes the installation of the following software options in a PQA600C Picture Quality Analyzer.

- Option ADV: Advanced measurement package (script execution, user-configurable measurement, artifact/attention weighting measurement)
- Option BAS: Base measurement package
- Option IP: IP generation and capture

## Supported products

**PQA600C.** All serial numbers.

## Kit parts list

Quantity	Part number	Description
1 ea	075-1089-xx	MANUAL, TECH INSTALLATION, PQA6CUP OPTIONS BAS, ADV, AND IP (this document)
1 ea	—	IMPORTANT DOCUMENTS ENVELOPE CONTAINING SOFTWARE OPTION KEY

## Installation instructions

Install Options BAS, ADV, and IP in a PQA600C as follows:

1. Find the software option key included in the important papers envelope that originally shipped with these instructions. If you ordered Option ADV, the Requested Options will be listed as MI, SE, FM, UM, and BS.
2. Double-click the PQA icon on the PQA600C or PC desktop to start the PQA software.
3. Click **Help > License Manager** in the menu bar and the License Manager screen will appear.
4. Type in the new option key in the **New Option Key** field.
5. Click **Apply**.
6. Check that the following descriptions related to the options(s) you installed appear in the list under **Available Options**.

<b>Option</b>	<b>Description</b>
BAS	Basic Software
ADV	Load Full Template Measurements
	Loading Custom/User Measurements
	Multiple Instance Execution
	Script Execution
IP	IP Generation/Capture

7. Click **Close**.
8. Click **OK** when a screen appears telling you that the application will close.
9. The new options in the PQA software are now ready to use. When you are ready, double-click the PQA icon on the desktop to start the application.