

Problem: Noise in Low Current Measurements

Low current measurements (current < lnA) often encounter noise. Here are a few likely causes of noise in low current measurements and how they can be avoided.

Potential Cause: Electrostatic Coupling

This occurs when an electrically charged object is brought near an uncharged object.

Remedies

- A. Shield the device/circuit—High impedance materials do not allow the charge to decay quickly. Shielding the device or circuit to be measured greatly reduces the electrostatic interference. Connect the shield to circuit low.
- B. Movement—Avoid movement and vibration near the test area.
- C. Keep all charged objects (including people) and conductors away from sensitive areas of the test circuit.

Potential Cause: Vibration

Vibration can cause noise currents to flow due to the triboelectric effect.

Remedies

- A. Use low noise cables, which have graphite lubrication on the shield braid, to cut down the friction between insulators in the cable to reduce this effect.
- B. Secure the cables to avoid any unnecessary vibration.

Potential Cause: Low Source Impedance

Remedies

- A. When the impedance of the source is low a less sensitive measurement range can be used
- B. Adding some series resistance when measuring current from a capacitive source reduces noise.

C. A useful alternative to the series resistance is to put a forward-biased diode in series. The diode acts like a variable resistance—low when the charging current is high and then increasing in value as the current decreases with time.

Potential Cause: Offset Current Drift

Offset currents can drift over a period of time, usually because of temperature changes in the device and the meter.

Remedy

Stabilize the temperature of the meter, the device, and the general environment of the measurement.

Specifications are subject to change without notice.

All Keithley trademarks and trade names are the property of Keithley Instruments, Inc. All other trademarks and trade names are the property of their respective companies.



Keithley Instruments, Inc.

28775 Aurora Road • Cleveland, Ohio 44139 • 440-248-0400 • Fax: 440-248-6168

 $\textbf{1-888-KEITHLEY} \ (\textbf{534-8453}) \bullet www.keithley.com$

© Copyright 2004 Keithley Instruments, Inc. Printed in the U.S.A.

No. 2563