


Enhance Productivity with HSI

TECHNICAL BRIEF



Enhance Productivity with HSI

Faster waveform transfer from oscilloscope to PC is crucial for applications ranging from monitoring particle collisions in particle accelerators to neurological monitoring during surgeries. The need for near real-time data transfers has never been more pressing. In this technical brief, we will explore how HSI is revolutionizing the data transfer game for these important applications. We will delve into the technical details of HSI and explore its key features that can transform the way you work. We'll also show you how to enable HSI on your oscilloscope and how to use HSI with TekScope PC and the TekHSI Python library.

What is HSI?

HSI (High Speed Interface) is a new capability that improves waveform transfer from your oscilloscope to your PC. It is a server-client solution where the instrument runs as a server, and clients can be other software like TekScope PC, or user written automation code in Python, C++, C#, etc. All you need is a supported oscilloscope with firmware v2.10 or higher connected to your computer over LAN.

With HSI, you can transfer waveforms at five times the speed of SCPI. This is because the performance of Curve and Curvestream is dependent on the specific implementation of the SCPI standard by the instrument, whereas HSI has been optimized for high performance and scalability. HSI uses a binary protocol that is optimized for high-speed data transfer. HSI also supports streaming, so you can receive waveforms in real-time as they are captured by the oscilloscope.

HSI is based on Google's Remote Procedure Call (gRPC) protocol, a modern, high-performance framework. HSI leverages gRPCs' asynchronous capabilities, allowing you to use your oscilloscope even while it is transferring data to a PC. For example, if you change horizontal or vertical settings or add measurements on the oscilloscope, data transfer will continue and these updates will be reflected in the next transfer. You do not have to worry about updating your code to account for these scaling changes.

Key Features of HSI

HSI has many key features that make it easy to integrate into your work.

- HSI is supported on the most widely used Tektronix instruments. HSI is a core feature of instrument firmware starting with version 2.10, enabling seamless interaction with our most widely used instruments, including the 4 Series B MSO Oscilloscope and the 5 and 6 Series MSO Oscilloscopes (B, LP, Windows and Linux included) where high data transfer rates are important.
- Use Python for easy automation. Python is one of the most popular languages used for test automation. The Python library 'HSI' can easily be integrated into your workflow. HSI is included in our open-source Python package and is equipped with auto-complete, built-in help and real-time syntax checking.
- Use TekScope PC with HSI for remote analysis. TekScope PC can be used for offline and remote analysis. It features the same intuitive user interface found on Tektronix oscilloscopes, making it easy to integrate into your workflow.
- HSI reduces complexity and time around acquiring and formatting instrument data. This is a huge improvement compared to slow and complex SCPI based curve and curvestream commands.
- Enjoy the flexibility of cross-platform support. HSI can be used on multiple operating systems via Python drivers.
- HSI is free. Access all these benefits without any cost.
 HSI is included free as part of instrument firmware v2.10,
 TekScope PC v2.10 and Python client libraries.

How to use HSI

HSI is available through:

- Instrument Support: Since oscilloscopes capture and create a large amount of data, we picked oscilloscopes as the first
 place to start implementing HSI. New oscilloscope firmware for Tektronix MSO 4B, MSO 5 (B and LP) and MSO 6 (B and
 LP) are HSI capable. We are continuously experimenting with other T&M instruments where HSI can make a difference.
 Learn more.
- 2. **TekScope PC:** This GUI-based offline and remote analysis software features the same user interface as our modern oscilloscopes, as well as various measurement options through a flexible license offering. You can start experiencing HSI right now by starting a free 30-day trial or starting the Basic license. Download now.
- 3. **Python Library:** If you like to automate your T&M instrument interactions, use our Python library 'HSI' to leverage this fast interface for data transfer. Download now.

Enable HSI on your oscilloscope

To start using HSI, you first need to enable HSI on your oscilloscope.

To enable HSI on your supported oscilloscope, navigate to Utility > I/O > and then scroll down to 'High Speed Interface'. Enable the feature and define a custom port if needed as shown in **Figure 1**.




Figure 1: Enable HSI on a supported oscilloscope.

Use HSI with TekScope PC

As a TekScope PC user, you do not have to enable HSI on your oscilloscope. When you add new oscilloscopes, at the time of connection, TekScope PC will perform a discovery process to identify if this oscilloscope supports HSI. If it does, TekScope PC uses HSI for all acquisitions and falls back to the SCPI curve command when HSI is not available.

Use HSI with Python Library

HSI is our core technology allowing faster data transfers, and the two python libraries — tek_hsi and tm_data_types — will help you use this high-speed technology in your automation environments and projects. tm_data_types is a Python library to help translate between the scope's binary waveform objects into the more popular waveform formats like .wfm, .csv., etc. These Python libraries will be available as simple pip install tekhsi and pip install tm_data_types commands.

Using HSI makes your automation projects much simpler and easier to read. HSI code also performs much faster than the SCPI code. **Figure 2 and 3** compare SCPI code versus HSI code. **Figure 3**. is an example of how data is traditionally obtained from an oscilloscope to PC using SCPI.

```
pip install tekhsi
pip install tm_data_types
```

 $Figure~2.~HSI~and~tm_data_types~Python~libraries.$

```
import visa
rm = visa.ResourceManager()
scope = rm.open_resource('TCPIP::192.168.1.1::INSTR')
scope.write('DAT:SOU CH1')
scope.write('DAT:ENC RPB')
scope.write('DAT:WID 1')
data = scope.query_binary_values('CURV?', datatype='B')
```

Figure 3: Example code using traditional SCPI commands for data transfer.

Figure 4 is an example of how to get data using HSI. Notice that you do not need to format your waveform data like scaling and encoding, etc. unlike curve. With HSI, you just ask for the data, and it comes with the formatting information needed to decipher this data correctly. Not only is this much easier and simpler to read, but it also executes much faster than the SCPI code.

```
import tekhsi
scope = tekhsipy.TekScope('192.168.1.1')
data = scope.read_waveform('CH1')
```

Figure 4: Example code using new HSI python library for data transfer.

When using HSI, the command-and-control pieces of the automation still flow through VISA/SCPI, and HSI is responsible only for the actual data transfer.

Performance Gains with TekScope PC and HSI

When using TekScope PC with HSI, you can expect to see significant improvements in waveform transfer speed and performance compared to using curve query. **Figure 5** shows a performance comparison.




Figure 5: Performance comparison between HSI and curve query.

HSI compared to LXI and HiSLIP is a modern, high-performance RPC framework that is optimized for waveform data transfer. LXI and HiSLIP are older, legacy protocols that are not as efficient as gRPC. Additionally, HSI is designed specifically for Tektronix oscilloscopes, whereas LXI and HiSLIP are more general-purpose protocols.

Coming Soon

Since HSI is based on gRPC, our special implementation is defined and captured in something called the proto file. We plan to make our proto file available to the public soon, which will allow users to create similar libraries for other languages like C++. Releasing this super secret source file is common in the open-source community but a first in the test and measurement industry. Follow tek.com/HSI for updates.

Conclusion

HSI comes standard as part of the latest oscilloscope firmware for Tektronix 4 Series B MSOs and 5 and 6 Series MSOs (B and low-profile models). HSI is free! Start using HSI today and forever change your experience moving data from your instruments to your computer. Learn more at tek.com/HSI.

Contact Information:

Australia 1800 709 465

Austria* 00800 2255 4835

Balkans, Israel, South Africa and other ISE Countries +41 52 675 3777

Belgium* 00800 2255 4835

Brazil +55 (11) 3530-8901

Canada 1800 833 9200

Central East Europe / Baltics +41 52 675 3777

Central Europe / Greece +41 52 675 3777

Denmark +45 80 88 1401

Finland +41 52 675 3777

France* 00800 2255 4835

Germany* 00800 2255 4835

Hong Kong 400 820 5835

India 000 800 650 1835

Indonesia 007 803 601 5249

Italy 00800 2255 4835

Japan 81 (3) 6714 3086

Luxembourg +41 52 675 3777

Malaysia 1800 22 55835

Mexico, Central/South America and Caribbean 52 (55) 88 69 35 25

Middle East, Asia, and North Africa +41 52 675 3777

The Netherlands* 00800 2255 4835

New Zealand 0800 800 238

Norway 800 16098

People's Republic of China 400 820 5835

Philippines 1800 1601 0077

Poland +41 52 675 3777

Portugal 80 08 12370

Republic of Korea +82 2 565 1455

Russia / CIS +7 (495) 6647564

Singapore 800 6011 473

South Africa +41 52 675 3777

Spain* 00800 2255 4835

Sweden* 00800 2255 4835

Switzerland* 00800 2255 4835

Taiwan 886 (2) 2656 6688

Thailand 1800 011 931

United Kingdom / Ireland* 00800 2255 4835

USA 1800 833 9200

Vietnam 12060128

* European toll-free number. If not

accessible, call: +41 52 675 3777

Rev. 02.2022

