INSTRUCTION MANUAL
Control Unit
Model 780

©COPYRIGHT 1975 KEITHLEY INSTRUMENTS, INC.

FIRST PRINTING, NOV. 1975, CLEVELAND, OHIO, U.S.A. DOCUMENT NO. 27444, REVISION CODE AA.

CONTENTS

| OΝ | NTENTS | Р |
|-----|--|---|
| L | NTENTS | į |
|) E | ECIFICATIONS | i |
| | GENERAL INFORMATION | į |
| | 1-1. GENERAL INFORMATION | 1 |
| | The management of the order of the second of | 1 |
| | | 1 |
| | | 1 |
| | INITIAL PREPARATION | 2 |
| | | 2 |
| | | 2 |
| | 2-3. SYSTEM CONSIDERATIONS | 2 |
| | The state of the third in the state of the s | 2 |
| | 2-5. HOW TO RACK MOUNT THE CONTROL UNIT | 2 |
| | 2-6. HOW TO APPLY POWER TO THE CONTROL UNIT | 2 |
| | 2-/. HOW TO USE REAR PANEL CONNECTORS | 2 |
| | INTERFACE CONSIDERATIONS | • |
| | 3-1. GENERAL | |
| | 3-2. INTERFACE BUS CONFIGURATION | 3 |
| | 3-3. SCANNER INTERFACE | - |
| | THEORY OF OPERATION | 7 |
| | 4-1. GENERAL | L |
| | 4-2. CIRCUIT DESCRIPTION | 7 |
| | 4-3. HOW TO INTERPRET THE FRONT PANEL INDICATORS | 4 |
| | MAINTENANCE | 4 |
| | MAINTENANCE | - |
| | | 5 |
| | | 5 |
| | | 5 |
| | ACCESSORIES | 6 |
| | 6-1. RACK MOUNTING KIT | 6 |
| | 6-2. MULTI-SCANNER COUPLER (Model 7819-MSC) | 6 |
| | □ → → → → → → → → → → → → → → → → → → → | 6 |
| | 6-4. CUSTOM INTERFACE (Model 7802-CIK) | 6 |
| | 6-5. DUAL CONTROL UNIT COUPLER (Mode) 7819-DCC) | 6 |
| | REPLACEABLE PARTS | 7 |
| | 7-1. GENERAL | 7 |
| | 7-2. ORDERING INFORMATION | 7 |
| | 7-3. SCHEMATICS | |
| | , | 7 |

INSTRUCTION MANUAL Control Unit Model 780

ILLUSTRATIONS

| No. | Title | Page |
|-----|--|------|
| 1 | Front Panel | 1-2 |
| 2 | Rear Panel | 1-2 |
| 3 | Installation of Series 7801, 7802, 7819-IEC and 7813 Cards | 2-3 |
| 4 | Installation of Dual Control Unit Coupler (Model 7819-DCC) | 2-4 |
| 5 | Top View of Control Unit With Cover Removed | 2-6 |
| 6 | Card-edge Connector (J101, J102, or J103) | 3-2 |
| 7 | Scanner Connector (P110) | 3-3 |
| 8 | Front Panel Indicators | 4-6 |
| 9 | Trace for Test #1 | 5-2 |
| 10 | Trace For Test #2 | 5-3 |
| 11 | Trace For Test #3 | 5-4 |
| 12 | Trace For Test #4 | 5-5 |
| 13 | Trace For Test #5 | 5-6 |
| 14 | Trace For Test #6 | 5-7 |
| 15 | Trace For Test #7 | 5-8 |
| 16 | Trace For Test #10 | 5-11 |
| 17 | Trace For Test #11 | 5-12 |
| 18 | Trace For Test #13 | 5-15 |
| 19 | Trace For Test #14 | 5-16 |
| 20 | Trace For Test #15 | 5-17 |
| 21 | Trace For Test #16 | 5-18 |
| 22 | Trace For Test #19 | 5-24 |
| 23 | Trace For Test #20 | 5-25 |
| 24 | Trace For Test #21 | 5-26 |
| 25 | Trace For Test #22 | 5-27 |
| 26 | Rack Mounting of the Control Unit | 6-1 |
| 27 | Multi-Scanner Coupler (Model 7819-MSC) | 6-2 |
| 28 | Typical System 1 Multi-Scanner Connection | 6-3 |
| 29 | Custom Interface (Model 7802-CIK) | 6-6 |
| 30 | Chassis Assembly | 7-3 |
| 31 | Component Layout For PC-395 | 7-11 |

AA

SPECIFICATIONS

GENERAL: Holds up to three System 1 Instrument Interface or special-purpose cards. Supplies power to cards. Captive cable plugs directly into the System 1 Programmable Calculating Unit.

DISPLAY: 18 LED lamps indicate the last Output 8-bit word transferred, the next 8-bit word to be input, and whether the last word transferred was Data or Control.

CONTROLS: Front panel power switch. Internal switch sets Control Unit address. 702/702X INTERFACE:

GENERAL: Built-in interface connects directly to one Model 702/702X 10-channel Scanner, or with 7819-MSC, to as many as eight 10-channel Scanners for random access to single channels. For parallel-channel or matrix operation, one channel on each Scanner may be selected.

OUTPUT INSTRUCTION:

Control Transfer: Deactivates all or selectively activates one of up to 80 channels.

Power up/Reset: All scanner channels Off.

Nominal Instruction Time: 70 milliseconds.

ISOLATION (PCU GROUND TO ANALOG LO): Provided by Model 702X plug-in cards. ENVIRONMENT:

OPERATING: 0°C to 40°C up to 80% relative humidity.

STORAGE: -25°C to 80°C

POWER: 90-110, 105-125, 210-250 volts (switch selected), 50-60 Hz, 50 watts. DIMENSIONS, WEIGHT: 3-1/2 in. full rack, overall bench size 4 in. high x 17-1/4 in. wide x 15-1/2 in. deep (105 x 440 x 395 mm); 5 ft. (1-1/2m) captive cable to PCU. Net weight, 13 pounds (5,8 kg).

ACCESSORIES FURNISHED: Hardware for standard 3-1/2 in. x 19 in. rack mounting. 15-1/2 in. (395 mm) depth behind front panel.

Λ Λ

SECTION 1. GENERAL INFORMATION

1-1. INTRODUCTION. The Model 780 Control Unit provides the link between the Programmable Calculating Unit (PCU) and all other instrumentation in the System 1. The Control Unit may be used with up to three Instrument Interfaces or other devices and eight Scanners. (A PCU and appropriate I/O Handler Software is needed to communicate with the Control Unit.)

Instrument Interfaces may be installed in any of three rear panel plug-in compartments or "slots". The locations of the Instrument Interfaces are labeled as Interface Number 1, 2, and 3.

Scanner interface circuitry is built into each Control Unit. The rear panel "SCANNER" connector mates with a System Interconnect Cable (Model 7021-2) furnished with the Keithley Model 702 Scanner.

When a Multi-Scanner Coupler is connected to the Control Unit, up to eight Scanners (80 channels total) may be used. Each Scanner connects to the MSC via individual System Interconnect Cables.

The Control Unit has 18 indicators on the front panel which display pertinent information as to the status of System 1 operations.

- •INPUT Indicators: These indicators represent an 8-bit word to be transferred from the Control Unit to the PCU.
- •OUTPUT Indicators: These indicators represent an 8-bit word which has been transferred from the PCU.
- •DATA Indicator: This indicator identifies the last 8-bit word transferred as DATA.
- \cdot CONTROL Indicator: This indicator identifies the last 8-bit word transferred as a CONTROL byte.

In a System 1/782-XY, two Control Units are used. In this configuration an internal switch on each Control Unit is used to identify Control Unit #1 (CU1) and Control Unit #2 (CU2) in the System. This identification enables the user to communicate to either Control Unit via 1/0 Handler Software. A Dual Control-Unit Coupler must be installed on either Control Unit CU1 or CU2 to facilitate connection of a second Control Unit. The Control Units may be rack mounted using hardware furnished. The captive cable on the Control Unit is five feet long and mates with a 37-pin connector on the PCU or 2nd Control Unit. Cabling to instrument or other devices is furnished with individual Instrument Interfaces.

- 1-2. WARRANTY INFORMATION. See GUIDE TO USING THE SYSTEM 1 for detailed information.
- 1-3. CHANGES. Improvements or changes to the Control Unit which are not incorporated into the INSTRUCTION MANUAL can be found in the System | Instruction Manual Addenda.




FIGURE 1. Front Panel.




FIGURE 2. Rear Panel.

SECTION 2. INITIAL PREPARATION

- 2-1. GENERAL. This section provides information needed for incoming inspection and preparation for use.
- 2-2. INSPECTION. The equipment furnished was carefully inspected both mechanically and electrically before shipment. Upon receiving the equipment, check for obvious damage which may have occured during transit. Report any damage to the shipping agent and your Keithley representative.
- 2-3. SYSTEM CONSIDERATIONS. The Control Unit is used in all configurations of the System I Calculator-Based Instrumentation System. It is recommended that the user determine the configuration to be used prior to placing the Control Unit in the System. The following factors should be considered:
- a. Use of more than one Control Unit. The Control Unit has an internal switch (S103) which is set at the factory in CUI position, to designate the Control Unit as "Control Unit 1". If two Control Units are to be used in the System 1, the Dual Control-Unit Coupler must be incorporated and the second Control Unit must be designated as CU2. If only one Control Unit is used, no modification of the Control Unit is needed. See Figure 5 for location of internal switch S103.

TABLE 2-1.

Control Unit Useage in System 1

| Model No. | Number of Control Units Needed | Dual Control- Unit Coupler | S103 Setting |
|--------------|-----------------------------------|-------------------------------|-----------------------------------|
| System 1/781 | 1 | Not Required. | CUI |
| System 1/782 | 2 | Required. See Table 2-4. | First unit-CU1 Second unit-CU2 |

- b. Use of two or more Scanners. If two or more Scanners are to be used in the System 1, the Multi-Scanner Coupler must be used with the Control Unit. (See page 6-2.)
- c. Use of more than one Instrument Interface. If more than one Instrument Interface is installed in a Control Unit at the same time, Model 7820-GPA !/O Handler Software must be used. See GUIDE TO USING THE SYSTEM 1 for system hardware and software requirements.
- 2-4. HOW TO INSTALL INTERFACES. (SERIES 7801, 7802, 7813)
- a. Locations. The rear panel of the Control Unit has three plug-in compartments, identified as Interface Numbers 1, 2, and 3. These compartments can accept any Keithley Instrument Interface or Accessory listed in Table 2-2.

TABLE 2-2.

Instrument Interfaces and Accessories Useable in the System 1

| Model No. | Name | | | |
|--|---|--|--|--|
| Model 7801-160B/1602B Model 7801-171/1712 Model 7801-180/1802 Model 7801-445 Model 7801-616/6162 Model 7802-110 Model 7813 Model 7802-C1K Model 7819-IEC | Instrument Interface Instrument Interface Instrument Interface Instrument Interface Instrument Interface Instrument Interface 8-Bit Isolated I/O Interface Interval Timer/Clock Custom Interface Card Interface Extender Card | | | |

- b. Installation. Any Keithley System 1 Interface will mate with any of the three plug-in compartments. Slide the Plug-in Card into the compartment with "component side" facing up. Make certain the card edges are aligned with the grooves in the compartment. When the card is fully inserted, the "locking tabs" on the card should be snapped into locking position as shown in Figure 3. On some Instrument Interfaces a switch setting must be made on the pc card prior to installing in the Control Unit. (See INSTRUCTION MANUAL, Instrument Interface.)
- c. Removal. Unfasten "locking tabs" by pulling both tabs outward. Grasp the end of the card and pull out of chassis.
- 2-5. HOW TO RACK MOUNT THE CONTROL UNIT. The Control Unit is designed for 19 inch full rack mounting when used with the Model 1007 Rack Mounting Kit. The position of the Control Unit in a rack should be determined relative to the instruments or devices used in the System 1. For example, Series 7801 Instrument Interfaces have a 6 foot (2m) length cable which mates with a digital measuring instrument. Therefore considerations should be made for cable routing behind the rear panel. See page 6-1 for rack mounting information.
- 2-6. HOW TO APPLY POWER TO THE CONTROL UNIT.
- a. How to set the Line Switch. The Control Unit has a single Line Switch which permits the user to select line voltage in three ranges. See Table 2-3.

CAUTION

Remove line cord before changing switch positions.

TABLE 2-3.
Line Voltage Selection

| Position | Line Voltage | Fuse (Keithley Part No.) |
|--------------|--------------|--------------------------|
| (* . | 90-110V rms | 1/2A (FU-4) |
| - | 105-125V rms | 1/2A (FU-4) |
| <u>-</u> | 210-250V rms | 1/4A (FU-17) |

b. Line Power. The Control Unit line power receptacle mates with Keithley line cord CO-7 (furnished). The line cord is designed for use with three-prong receptacles having a grounded connection.




FIGURE 3. Installation of Series 7801, 7802, 7819-IEC and 7813 Cards.




FIGURE 4. Installation of Dual Control Unit Coupler (Model 7819-DCC).

- c. Power-Up Reset. When power is applied to the Control Unit a "Power-Up" reset is generated which causes all installed interfaces to go to their specific "power up" condition. The "power up" condition is listed in INSTRUCTION MANUAL, Instrument Interface, Series 7801, 7802 or 7813.
- 2-7. HOW TO USE REAR PANEL CONNECTORS (See Figure 2).
- a. SCANNER Connector (P110). This connector is a 26-pin 3M Electro Products Division Part No. 3429. Pin 4 has been removed to admit a "polarizing key" on the mating System Interconnect Cable (Model 7021-2 or 7021-10).
- b. TO PCU Cable (P112). This five foot long cable is a 37-conductor integrally mounted cable terminated by an ITT Cannon Part No. DC-37P male connector. The cable mates with a receptacle on Keithley PCU, Peripheral Coupler, or second Control Unit.
- c. 2ND CONTROL UNIT (Spare opening). This opening is used when modifying a Control Unit for use in a System 1/782. When shipped from the factory the Control Unit has a cover plate (part no. 26864) over the opening. When a Dual Control-Unit Coupler is installed on the Control Unit the cover plate must be removed and replaced with a 37-pin receptacle. See Table 2-4 and Figure 4.
- d. INTERFACE NUMBER 1 (J103). This connector is a 50-pin card-edge type which mates with Series 7801 and 7802 Instrument Interfaces and Model 7813.
- e. INTERFACE NUMBER 2 (J102). This connector is a 50-pin card-edge type which mates with Series 7801 and 7802 Instrument Interfaces and Model 7813.
- f. INTERFACE NUMBER 3 (J101). This connector is a 50-pin card-edge type which mates with Series 7801 and 7802 Instrument Interfaces and Model 7813.

TABLE 2-4.

How to Install the Dual Control-Unit Coupler

- 1. Disconnect power cord.
- 2. Remove cover plate over 2nd CONTROL UNIT opening.
- Remove the Control Unit top cover.
- 4. Install 37-pin receptable using original screws used with cover plate.
- 5. Install Berg housing (8-pin) as shown in Figure 4.
- 6. Replace top cover.




FIGURE 5. Top View of Control Unit With Cover Removed.

SECTION 3. INTERFACE CONSIDERATIONS

- 3-1. GENERAL. This section provides basic operating information concerning the interface bus and Scanner interface.
- 3-2. INTERFACE BUS CONFIGURATION. The Control Unit has three 50-pin card-edge connectors J101, J102, and J103 corresponding to Interface Numbers 3, 2, and 1. Except for Slot Address lines, all signals are wired in parallel on the three connectors. See Figure 6.

TABLE 3-1.
Summary of Signals on Interface Bus

| Name | Remarks |
|--|---|
| Slot Address (SA) | All three Slot address lines are wired to connectors J101, J102, and J103. Refer to Figure 6 for wiring |
| 9VAC | This voltage is an auxiliary ac voltage used for certain instrument interfaces. |
| PWR UP RESET | This signal is generated when power is applied to the Control Unit. |
| CO, C1, C2 | These signals are Control commands. |
| CP (Control Pulse) | This signal is generated after a Control Byte has been received. |
| DP (Data Pulse) | This signal is generated after a Data Byte has been transferred. |
| RESET | This signal is generated for either of the follow- ing conditions: RESET code is received from the PCU PWR UP RESET is generated |
| vcc | This is a +5V logic supply for Interface logic. |
| GND | This is a logic supply "LO". |
| DIH8, DIH4, DIH2, DIH1 DIL8, DIL4, DIL2, DIL1 | These lines are the eight input data lines. Data which is to be sent to the PCU is applied to these lines. |
| BC7, BC6, BC5, BC4, BC3, BC2, BC1, BC0 | These lines are outputs of the Byte Counter circuit. |
| CP (Control Pulse) | See CP above. |
| DP (Data Pulse) | See DP above. |
| RESET | See RESET above. |
| DOH8, DOH4, DOH2, DOH1 DOL8, DOL4, DOL2, DOL1 | These lines are the eight data output lines. These lines represent data at the Output Register, except that the data has been inverted. |

٠




FIGURE 6. Card-edge Connector (J101, J102, or J103).

INSTRUCTION MANUAL Control Unit Model 780

3-3. SCANNER INTERFACE. The Scanner interface provides capability to control up to 8 Keithley Model 702/702X Scanners. The "SCANNER" connector is a 26-pin connector that mates with a Series 702l System Interconnect Cable. When used with a single Scanner, only one System Interconnect Cable is needed. If two or more Scanners are to be connected to a single Control Unit, a Multi-Scanner Coupler must be connected to the Control Unit. See Section 6, ACCESSORIES for detailed information on the use of the Multi-Scanner Coupler (Model 7819-MSC).

TABLE 3-2.

Connector (PIIO) Pin Identification on the Control Unit

| Pin No. | Name | Remarks |
|---------------------------------|----------------|---------------------------------|
| 1 | CHAD 1 | CHannel ADdress Input |
| 2 | CHAD 4 | CHannel ADdress Input |
| 2 3 4 5 6 7 8 | Not Used | No Connection |
| 4 | Polarizing Pin | No Connection |
| 5 | LOCHAD 6 | LOad CHannel ADdress-Scanner #6 |
| 6 | LOCHAD 7 | LOad CHannel ADdress-Scanner #7 |
| 7 | LOCHAD 8 | LOad CHannel ADdress-Scanner #8 |
| 8 | RELAY READY | |
| 9 | REMOTE ALL OFF | |
| 10 | Not Used | No Connection |
| 11 | Not Used | No Connection |
| 12 | LOCHAD 2 | LOad CHannel ADdress-Scanner #2 |
| 13 | LOCHAD 4 | LOad CHannel ADdress-Scanner #4 |
| 14 | CHAD 2 | CHannel ADdress Input |
| 15 | CHAD 8 | CHannel ADdress Input |
| 16 | LOCHAD 1 | LOad CHannel ADdress-Scanner #1 |
| 17 | Not Used | No Connection |
| , 18 | COMMON | Digital Common |
| 19 | COMMON | Digital Common |
| 20 | COMMON | Digital Common |
| 21 | СОММОИ | Digital Common |
| 22 | COMMON | Digital Common |
| 23 | Not Used | No Connection |
| 24 | Not Used | No Connection |
| 25 | LOCHAD 3 | LOad CHannel ADdress-Scanner #3 |
| 26 | LOCHAD 5 | LOad CHannel ADdress-Scanner #5 |
| | | |
| | | · |




FIGURE 7. Scanner Connector (P110) on Rear Panel.

TABLE 3-3.

Typical Logic Definitions Based on Manufacturers' Data

| Input | Lines | Output | Lines |
|-----------------------------|-----------------------------|-----------------------------|-----------------------------|
| LOGIC '' '' (Minimum) +2.0V | LOGIC ''O'' (Maximum) +0.8V | LOGIC ''1'' (Minimum) +2.4V | LOGIC ''0'' (Maximum) +0.4V |

NOTE

Absolute maximum input voltage = +5.25V Absolute minimum input voltage = -0.5V

TABLE 3-4.
Standard Terminology Used For Logic Lines

| Symbol Name | Definition | Comments |
|-------------|------------|-------------------|
| ABC | High True | True = Logic ''1" |
| ABC | Low True | True = Logic "0" |

SECTION 4. THEORY OF OPERATION

4-1. GENERAL. The Control Unit contains circuitry which links the Programmable Calculating Unit (PCU) and all other System 1 instrumentation. This circuitry handles data transfers between the PCU and accessory interfaces or the built-in scanner interface.

4-2. CIRCUIT DESCRIPTION.

- a. The circuitry can be divided into ten functional circuits.
 - 1. Control/Data Byte Detector Circuit.
 - 2. Output Control/Data Register Circuit.
 - 3. Input Data Register Circuit.
 - 4. Indicator Circuit.
 - 5. Control Byte Decoder Circuit.
 - 6. Reset Circuit.
 - 7. Control Byte One-Shot Multivibrator Circuit.
 - 8. Data Byte One-Shot Multivibrator Circuit.
 - 9. Byte Counter Circuit.
 - 10. Scanner Interface Circuit.

b. Control/Data Byte Detector Circuit.

- 1. General Circuit Description. This circuit indicates whether a Control Operation (OPCB) or Data Operation (OPDB, IPDB) is being executed. Input signals are OTCT and DTEN.
- 2. Detailed Circuit Description. When neither Control or Data operations are executed, OTCT and DTEN are a logic "O" during T8 to T15 of a machine cycle. When an OPCB instruction is executed, OTCT is at logic "1" during the entire machine cycle. When either an OPDB or IPDB instruction is executed, DTEN will remain a logic "1" for the entire machine cycle (i.e. DTEN will not have a transition from logic "1" to logic "O").

c. Output Control/Data Register Circuit.

- 1. General Circuit Description. This circuit is a serial in/parallel out Shift Register. Output control/data from the PCU is loaded into this register (U110) and clocked by $\phi 2$. BYOT is the serial input. BYOT is the inversion of signal BYOT.
- 2. Detailed Circuit Description. When an output instruction (OPCB or OPDB) is executed, the contents of the Index Register is shifted into the Output Register. Output lines DOLI through DOHB are buffered and applied to the bus. If an OPCB instruction is executed the Control Byte Decoder is activated.

d. Input Data Register Circuit.

- 1. General Circuit Description. This circuit is a parallel in/serial out Shift Register. Input data from the Control Unit is transferred to the PCU via this register. A byte (8 bits) of data is serially transmitted to the PCU via BYIN, and clocked by $\phi 2$.
- 2. Detailed Circuit Description. Data input lines on the bus (DILI through DIH8) are shifted into the PCU Index Register and replace previous contents.

e. Indicator Circuit.

- 1. General Circuit Description. A total of 18 LED indicators are used on the Control Unit front panel to display data or status of control operations. The indicators are grouped as follows:
 - a) INPUT indicators (L1 through H8). These indicators represent data to be transferred from the Control Unit to the PCU.
 - b) OUTPUT indicators (L1 through H8). These indicators represent data which has been transferred from the PCU.
 - c) INSTRUCTION indicators. These indicators show whether the last I/O instruction executed was a control operation (OPCB) or a data operation (OPDB or IPDB).
 - 2. Detailed Circuit Description. All indicators are driven by two-input NAND gates.
 - a) INPUT indicators (L1 through H8). Input data to be shifted into the PCU Index Register is displayed on indicators L1 through H8.
 - b) OUTPUT indicators. The data on the Output Control/Data Register is displayed on indicators LI through H8.
 - c) INSTRUCTION indicators. The NAND gates are connected to form an RS Flip-Flop. The R and S inputs to the Flip-Flop are the two outputs of the Control/Data Byte Detector.

f. Control Byte Decoder Circuit.

- 1. General Circuit Description. This circuit accepts control information and decodes it into individual control signals. These signals are then used for controlling or transferring data to accessory instruments (when appropriate accessory Instrument Interface is installed).
 - 2. Detailed Circuit Description.
 - a) PCU peripherals and the Control Unit are addressed using IH of an OPCB. Since IH is four bits wide, there are sixteen possible addresses, 0 through 15. System I uses two of sixteen possible addresses. Addresses 8 (binary 1000) and 9 (binary 1001) are used to address CUI and CU2 respectively. The address to which a Control Unit will respond is determined by the setting of S103, located on the Control Unit printed circuit board.
 - b) As mentioned above, the contents of the Output Control/Data Register is a copy of the Index Register after an output instruction has been executed. Of these outputs, DOHI through DOH8 represent the contents of IH. Execution of an OPCB instruction enables these bits to be applied to an address decoder. This decoder determines whether IH contains an eight or a nine depending on the position of the SIO3. The decoder's output will go high if IH contains a "one of us" code.
 - c) The low-order four bits of a Control Byte represent an operation code. If the address contained in IH is "one of us", that is an eight or nine, the DOL1 through DOL8 data are latched into Ul20. The contents of IL are then decoded into Slot Addresses and Control signals. It is these signals which control the action of the instrument interface cards.

- d) In addition to enabling the IL latch, the address decoder also sets an RS flipflop when IH contains a "one of us" code. The output of this flip-flop is used to enable BYIN so that data can be transferred to the PCU. When the address part of a Control Byte is not "one of us", the flip-flop is reset. This prevents our interface from interferring with other peripherals which might be connected to the PCU. g. Reset Circuit.
- 1. General Circuit Description. A RESET signal is generated under the following conditions:
 - a) Control Unit Power Up. When power is first applied to the Control Unit via the Power Switch, or disconnecting and reconnecting line power to the Control Unit with Power Switch set to ON.
 - b) PCU Reset. When a RESET command is generated at the PCU.
 - 2. Detailed Circuit Description.
 - a) Control Unit Power Up. The RESET signal is applied to the bus and causes the following actions:
 - 1) Clears Output Data Register.
 - 2) Sets all accessory instrument Interface circuitry to "Power-Up" condition. (See individual Instrument Interface Instruction Manual for detailed information.)
 - 3) Clears control signals CO, CI, and C2.
 - 4) Disables BYIN (resets Flip-Flop).
 - 5) Initiates a PWR UP RESET.
 - b) PCU Reset. When a RESET command (\hat{OPCB} and $IL = 13_{10}$) occurs, the following actions result:
 - 1) Output Data Register = 1310.
 - 2) Sets all accessory Instrument Interface circuitry to "Power-Up" condition. (See individual INSTRUCTION MANUAL for detailed information.)
 - 3) Clears control signals $C\theta$, Cl, and C2.
 - 4) Disables BYIN (resets Flip-Flop).

h. Control Byte One-Shot Multivibrator Circuits.

- 1. General Circuit Description. These circuits are used to synchronize transfer of control information within the Control Unit.
 - 2. Detailed Circuit Description.
 - a) U131. This One-Shot is fired at a logic "1" to logic "0" transition of the Control Byte Detector signal. This occurs at T15 of an OPCB instruction. The One-Shot output enables the Address Decoder and Reset Command Detector.
 - b) U132. This One-Shot is fired at a logic "1" to logic "0" transition of the above one-shot and causes a Control Pulse (CP) on the bus.

i. Data Byte One-Shot Multivibrator Circuit.

1. General Circuit Description. The output of this circuit is called Data Pulse (DP). This signal is similar to CP.

2. Detailed Circuit Description (Ull9). This One-Shot is fired at a logic "I" to logic "O" transition of the Data Byte Detector signal, i.e. when either IPDB or OPDB operations are executed.

j. Byte Counter Circuit.

- 1. General Circuit Description. This circuit generates eight control signals, BCO through BC7, and are used as Strobe and Latch Enable functions.
- 2. Detailed Circuit Description. This circuit consists of a Decade Counter (U128) and a "One-out-of-Ten" Decoder (U129). When a Control Byte is detected, the Counter is reset to zero. The counter is incremented by DP. The Counter is wired so that when the counter is incremented beyond 7, the output is set to 9. The Byte Counter outputs are available on the bus, and permits data byte transfer without the need for a Control Byte Command (i.e. after an IPDB or OPDB instruction is executed, the Byte Counter is incremented, enabling the next data byte).

k. Scanner Interface Circuit.

- 1. General Circuit Description. This circuit contains logic to control one Scanner (or up to 8 Scanners, when the Multi-Scanner Coupler is used). The logic is divided into three functional circuits.
 - a) REMOTE ALL OFF Logic. When a REMOTE ALL OFF command is initiated by the PCU, the Scanner interface logic generates a logic ''O'' on pin 9 of SCANNER connector.
 - b) LOCHAD Logic. The LOCHAD logic latches a LOCHAD code coming from the PCU. A logic "O" is generated on the appropriate LOCHAD line.
 - c) CHAD Buffer Logic. These buffer stages provide fan-out drive capability.
 - 2. Detailed Circuit Description.
 - a) REMOTE ALL OFF Logic. Three logic gates (UI21C, UI18A, UI23D) are used to generate a REMOTE ALL OFF command. The specific logic requirements for activating REMOTE ALL OF are given in Table 4-1.

TABLE 4-1.
Logic for REMOTE ALL OFF

| | INPUT | | | | | | |
|--------------|-------|--------|----|--------|-------|----------------------------------|--|
| SCAN ADDR | C1 | U121-8 | СР | 1-8110 | RESET | REMOTE ALL OFF (Pin 9) | |
| 1 | 1 | 0 | 0 | 1 | 0 | O (REMOTE ALL OFF activated) | |
| 1 | 1 | 0 | 1 | 0 | 0 | 1 (REMOTE ALL OFF not activated) | |
| X | X | Х | Χ | Х | 1 | O (REMOTE ALL OFF activated) | |

X = Don't care

- b) LOCHAD Logic. Five Logic gates are used with the Latch and Decoder. These gates control the operation of the latch and enable the LOCHAD buffers. Eight OR gates are used for buffering the LOCHAD outputs. When enabled, these gates apply the output of the decoder to the Scanners connected to the Control Unit.
- c) CHAD Buffer Logic. The CHAD Buffer circuits (UII3A, D, E, F) provide fan-out capability.

TABLE 4-2.

LOCHAD Lines Used on Scanner Connector

| Scanner Number | Pin Number |
|----------------|------------|
| 1 | 16 |
| 2 | 12 |
| 3 | 25 |
| 4 | 13 |
| 5 | 26 |
| 6 | 5 |
| 7 | 6 |
| 8 | 7 |

TABLE 4-3.
Logic for LOCHAD Lines

| | | | T-18 | ОИТРИТ | | | | | | |
|---------------|------------|---------|------|--------|-------------|-----|--------|---------|-------|----------------------------|
| S CAN ADDR | c <i>o</i> | u121-11 | DP | U104-4 | BC <i>0</i> | BC1 | U121-6 | U108-10 | RESET | |
| 1 | 1 | 0 | 0 | 1 | 1 | 0 | 0 | 1 | 1 | Latch enable is logic "l" |
| 1 | 1 | 0 | 1 | 0 | l | 0 | 1 | 0 | 1 | Latch enable is logic "0" |
| X | Х | X | Х | X | Х | Х | Х | Х | 0 | Latch enable is logic "!" |
| 1 | 1 | 0 | 0 | 1 | 0 | 1 | 1 | 0 | 1 | Lochad enable is logic "!" |
| 1 | 1 | 0 | 1 | 0 | 0 | 1 | 1 | 0 | 1 | Lochad enable is logic "3" |

TABLE 4-4.

Illustration of Logic for CHAD Lines (Four of Ten Useable Combinations Shown)

| | INP | UΤ | | OUTPUT | | | | | | | | | | |
|------|------|------|------|--------|--------|--------|--------|--|--|--|--|--|--|--|
| DOL8 | DOL4 | DOL2 | DOL1 | CHAD 8 | CHAD 4 | CHAD 2 | CHAD 1 | | | | | | | |
| 1 | 1 | 1 | 0 | 0 | 0 | 0 | 1 | | | | | | | |
| 1 | 1 | 0 | 1 | 0 | 0 | 1 | 0 | | | | | | | |
| 1 | 0 | 1 | 1 | 0 | 1 | 0 | 0 | | | | | | | |
| 0 | 1 | 1 | 1 | 1 | 0 | 0 | 0 | | | | | | | |

TABLE 4-5.
RELAY READY Logic

| | INPU | Т | OUTPUT |
|----------------|------------|---------|-------------------------|
| S C AN ADDR | c <i>0</i> | U121-11 | U101-12 |
| 1 | 1 | 0 | i (RELAY READY enabled) |
| 0 | 1 | 1 | 0 |
| 1 | 0 | 1 | 0 |
| 0 | 0 | 1 | 0 |

4-3. HOW TO INTERPRET THE FRONT PANEL INDICATORS. The Control Unit has 18 indicators as shown in Figure 8.

INPUT. These indicators represent data to be sent to the PCU from Interface Number 1, 2, or 3 or Scanner interface.

OUTPUT. These indicators represent data which has been received from the PCU.

The data represented by the indicators is sometimes in the form of two 8-4-2-1 BCD digits. Data from the PCU is represented in program memory as a three digit octal number from 000 to 377.




FIGURE 8. Front Panel Indicators.

SECTION 5. MAINTENANCE

- 5-1. GENERAL. This section contains procedures for Performance Verification.
- 5-2. REQUIRED TEST EQUIPMENT. Recommended test equipment is given in Table 5-1. Test equipment other than recommended may be substituted if specifications equal or exceed the stated characteristics.
- 5-3. PERFORMANCE VERIFICATION. Use the following procedures to verify basic operation of the instrument (apart from any other component of the Keithley System 1 except the PCU). If the instrument is out of specification at any point, perform the troubleshooting check as in Section 5-4. In addition to test equipment a series 7810 I/O Handler Software program will be needed.

TABLE 5-1.

Recommended Test Equipment Accessories Needed For Performance Verification

| ltem | Name | Specification | Mfr. | Model |
|------|---|--|-----------|----------------|
| А | Oscilloscope | DC coupled, 4 channels, 2V & 5V/div. Sweep rate 50ms/div to 5µs/div External Triggering Capability | Tektronix | 560 |
| 8 | Programmable Calcu- lating Unit | -11 Memory installed (minimum size) | КІ | PCU |
| С | <pre>I/O Handler Software (magnetic card)</pre> | Series 7810 | КІ | Series 7810 |

a. Initial Set-Up

- 1. Connect the PCU to line power, set Power ON, and set RUN/STEP/LOAD switch to RUN.
- 2. Set the Control Unit as described in Section 2-6 of this manual.
- 3. Plug the 37-pin connector from the Control Unit to the rear panel of the PCU.
- 4. Apply power to the Oscilloscope for measurements to follow. Specific settings will be given for each test.

NOTE

Wherever a test point on the circuit board is specified, the circuit designation of the circuit module (such as U103) is given followed by the pin number on that module or integrated circuit (example U103-12).

b. Test #1. This test procedure checks the Control/Data Byte Detector under the condition that the PCU is executing no 1/0 instructions. No program is needed for this test.

- 1. Ensure that the PCU is set to ON and that the IDLE light is on.
- 2. Set the oscilloscope as follows:
 - a) Vertical Sensitivity 5 volts/div.
 - b) Horizontal Sweep 50 µs/div.
 - c) Trigger Source Channel 1, positive slope.
- 3. Make connections to the Control Unit circuitry as follows:
 - a) Connect Channel | Input to U103-12 (OTCT).
 - b) Connect Channel 2 Input to U103-11 (DTEN).
 - c) Connect Channel 3 Input to U103-8 (Control Detector output).
 - d) Connect Channel 4 Input to U103-9 (Data Detector output).
- 4. Verify that OTCT and DTEN are present as shown in Figure 9.
- 5. Verify that Control Detector output and Data Detector output are at signal LO as shown in Figure 9.




FIGURE 9. Trace for Test #1.

- c. Test #2. This test procedure checks the Control/Data Byte Detector outputs under the OPCB condition. A program is needed to obtain the OPCB condition.
 - 1. Enter the program listed in Table 5-2. (See page 5-9.)
 - 2. Set the RUN/STEP/LOAD switch on the PCU to RUN.
 - 3. Set the Oscilloscope as follows:
 - a) Vertical Sensitivity 5 volts/div.
 - b) Horizontal Sweep 50 μs/div.
 - c) Trigger Source Channel 1, positive slope.
 - 4. Make connections to the Control Unit circuitry as follows:
 - a) Connect Channel 1 Input to U103-12 (OTCT).
 - b) Connect Channel 2 Input to U103-11 (DTEN).
 - c) Connect Channel 3 Input to U103-8 (Control Detector output).
 - d) Connect Channel 4 Input to U103-9 (Data Detector output).
 - 5. Run the program beginning at branch point 0 0.
 - 6. Verify that OTCT is present except during each execution of an OPCB instruction (three consecutive OPCB instructions as in this example), as shown in Figure 10.
 - 7. Verify that DTEN is present regardless of an OPCB instructions.
 - 8. Verify that the Control Detector output goes to Logic "I" during each execution of an OPCB instruction.




FIGURE 10. Trace For Test #2.

- d. Test #3. This test procedure checks the Control/Data Byte Detector outputs under the OPDB condition. A program is needed to obtain the OPCB condition.
 - 1. Enter the program listed in Table 5-3. (See page 5-9.)
 - 2. Set the RUN/STEP/LOAD switch on the PCU to RUN.
 - 3. Set the Oscilloscope as follows:
 - a) Vertical Sensitivity 5 volts/div.
 - b) Horizontal Sweep 50µs/div.
 - c) Trigger Source Channel 2, positive slope.
 - 4. Make connections to the Control Unit circuitry as follows:
 - a) Connect Channel 1 Input to U103-12 (OTCT).
 - b) Connect Channel 2 Input to Ul03-11 (DTEN).
 - c) Connect Channel 3 Input to UlO3-8 (Control Detector output).
 - d) Connect Channel 4 Input to Ul03-9 (Data Detector output).
 - 5. Run the program beginning at branch point 0 0.
 - 6. Verify that DTEN is present except during each execution of a OPDB instruction (three consecutive OPDB instructions as in this example), as shown in Figure 11.
 - 7. Verify that OTCT is present regardless of a OPDB instruction.
 - 8. Verify that the Data Detector output goes to Logic "l" during each execution of a OPDB instruction.




FIGURE 11. Trace for Test #3.

- e. Test #4. This test procedure checks the Control/Data Byte Detector outputs under the IPDB condition. A program is needed to obtain the IPDB condition.
 - 1. Enter the program listed in Table 5-4. (See page 5-9.)
 - 2. Set the RUN/STEP/LOAD switch on the PCU to RUN.
 - 3. Set the oscilloscope as follows:
 - a) Vertical Sensitivity 5 volts/div.
 - b) Horizontal Sweep 50µs/div.
 - c) Trigger Source Channel 2, positive slope.
 - 4. Make connections to the Control Unit circuitry as follows:
 - a) Connect Channel | Input to Ul03-12 (OTCT).
 - b) Connect Channel 2 Input to U103-11 (DTEN).
 - c) Connect Channel 3 Input to U103-8 (Control Detector output)
 - d) Connect Channel 4 Input to UlO3-9 (Data Detector output)
 - 5. Run the program beginning at branch point 0 0.
 - 6. Verify that DTEN is present except during each execution of a IPDB instruction (three consecutive IPDB instructions as in this example), as shown in Figure 12.
 - 7. Verify that OTCT is present regardless of a IPDB instruction.
 - 8. Verify that the Data Detector output goes to Logic "1" during each execution of a IPDB instruction.




FIGURE 12. Trace for Test #4.

- \underline{f} . Test #5. This test procedure checks the $\phi 2$ Enable Line. The $\phi 2$ Enable line, PCU clock line, and PCU BYOT line are used to control the operation of the Output Control/Data Register. A program must be loaded into the PCU to obtain an OPCB condition.
 - 1. Enter the program as listed in Table 5-5. (See page 5-9.)
 - 2. Set the RUN/STEP/LOAD switch on the PCU to RUN.
 - 3. Set the Oscilloscope as follows:
 - a) Vertical Sensitivity 5 volts/div.
 - b) Horizontal Sweep 5µs/div.
 - c) Trigger Source Channel 1, positive slope.
 - 4. Make connections to the Control Unit circuitry as follows:
 - a) Connect Channel | Input to U107-10 (φ2 Enable).
 - b) Connect Channel 2 Input to U107-9 (\$\phi 2).
 - c) Connect Channel 3 Input to UllO-1 (BYOT, Data Out)
 - 5. Run the program beginning at branch point 0 0.
 - 6. Verify the traces shown in Figure 13.

NOTES.

Data is clocked into the Output Control/Data Register on the falling edge of $\phi 2$. Data is clocked with L1 being sent first. L1 to H8 is 10010101 binary.




FIGURE 13. Trace for Test #5.

INSTRUCTION MANUAL Control Unit Model 780

- g. Test #6. This test procedure checks the relationship between: Control Byte Detector Output and the two one shots associated with Control Bytes under the OPCB condition. A program must be loaded into the PCU to obtain the OPCB condition.
 - 1. Enter the program listed in Table 5-6. (See page 5-9.)
 - 2. Set the RUN/STEP/LOAD switch on the PCU to RUN.
 - 3. Set the Oscilloscope as follows:
 - a) Vertical Sensitivity 5 volts/div.
 - b) Horizontal Sweep 10µs/div.
 - c) Trigger Source Channel I, positive slope.
 - 4. Make connections to the Control Unit circuitry as follows:
 - a) Connect channel | Input to UIO3-8 (Control Byte Detector output).
 - b) Connect Channel 2 Input to U131-6 (Q output of 1st one-shot).
 - c) Connect Channel 3 Input to U132-6 (Control Pulse CP)
 - 5. Run the program beginning at branch point 0 0.
 - 6. Verify the traces shown in Figure 14.
 - a) Q output of first one-shot should coincide with Logic "1" to Logic "0" transition of the Control Byte Detector output. (Synchronizes signals for the Control Unit.)
 - b) Q output of second one-shot should coincide with Logic "1" to Logic "0" transition of Q output of first one-shot. (Synchronizes control signals for Instrument Interfaces.)




FIGURE 14. Trace For Test #6.

h. Test #7. This test procedure checks the relationship between: Data Byte Detector Output and the Data Pulse (DP) one-shot under the OPDB condition. A program must be loaded into the PCU to obtain the OPDB condition.

- 1. Enter the program listed in Table 5-7. (See page 5-9.)
- 2. Set the RUN/STEP/LOAD switch on the PCU to RUN.
- 3. Set the Oscilloscope as follows:
 - a) Vertical Sensitivity 5 volts/div.
 - b) Horizontal Sweep 10µs/div.
 - c) Trigger Source Channel I, positive slope.
- 4. Make connections to the Model 780 circuitry as follows:
 - a) Connect Channel | Input to UlO3-9 (Data Byte Detector output).
 - b) Connect Channel 2 Input to Ul28-14 (Data Pulse DP).
 - c) Connect Channel 3 Input to U132-6 (Control Pulse CP).
- 5. Run the program beginning at branch point 0 0.
- 6. Verify the traces shown in Figure 15.
- a) Data Pulse should coincide with the Logic "I" to Logic "O" transition of the Byte Detector Output.
 - b) Control Pulse does not appear (remains at Logic "O").




FIGURE 15. Trace For Test #7.

Table 5-3

TABLE 5-5.

TABLE 5-7.

Table 5-2 Program Needed to Perform Test #2

| | Pr | og i | ram | Need | lea | to | rertorm | lest #2 | | | Pro | gra | m Ne | ede | ed to | Perfo | rm Test #3 |
|---|----|-------------|--------|------|------------|------------|------------------------|-------------------------|---|---|------------|--------|-----------|------------|-------|------------------------|----------------------|
| | | CIMA TEP | L | | RU(COD | CTION E | l | INSTRUCTION MNEMONIC | ı | | IMAI EP | _ | INST C | RUC ODI | | | INSTRUCTION MNEMONIC |
| C | 0 | 0 | 0 | 3 | 1 | 4 | OPCB | | 0 | 0 | 0 | 0 | 3 | 1 | 5 | OPDB | • |
| | | | 1 | 3 | 1 | 4 | OPCB | | | | | 1 | 3 | 1 | 5 | OPDB | |
| | | | 2 3 | - | 1 2 | - | OPCB JU <i>00</i> , | 000 | | | | 2 3 | _ | 1 2 | _ | OPDB JU <i>00</i> , | 000 |
| | | | 4 | 0 | 0 | 0 | | | | | | 4 | 0 | 0 | 0 | - | |

Table 5-4

| | 1 | Pro | gra | am Ne | ed | ed t | o Perfo | rm Test #4 | i | r | o g | ram | Ne | e d | e d | То | Perf | orm T | est | # 5 |
|---|------------|------------|-----|-----------|-----|------|---------|----------------------|---|---|------------|-----|----|------------|-----------|----|----------------|----------|-----|-----|
| | DEC' ST | IMAI EP | L | INST (| RUC | | | INSTRUCTION MNEMONIC | | | IMA TEP | L | | RU(COD | TION E | | | INSTRUC' | | |
| 0 | 0 | 0 | 0 | 3 | 0 | 5 | IPDB | | 0 | 0 | 0 | 0 | 2 | 6 | 6 | l | LDIX, | 251 | | |
| | | | 1 | 3 | 0 | 5 | IPDB | | | | | 1 | 2 | 5 | 1 | | | | | |
| | | | 2 | 3 | 0 | 5 | IPDB | | | | | 2 | 3 | 1 | 4 | 0 | PCB | | | |
| | | | 3 | 2 | 2 | 0 | JU00, | 000 | | | | 3 | 2 | 2 | 0 | | JU <i>00</i> , | 000 | | |
| | | | 4 | 0 | 0 | 0 | | | | | | 4 | 0 | 0 | 0 | | | | | |

TABLE 5-6.

| | | Pro | ogra | am Ne | ed | ed To | o Perfor | m Test #6 | | | Pro | ogra | am Ne | eed | ed t | o Perfo | rm Test #7 | |
|---|---|--------------|------|-------|-----|------------|----------|----------------------|---|---|------------|------|-------|------------|------------|---------|----------------------|--|
| | | CIMA STEP | L | | COD | CTION E | | INSTRUCTION MNEMONIC | | | IMA TEP | L | | RU(COD | CTION E | | INSTRUCTION MNEMONIC | |
| 0 | 0 | 0 | 0 | | 6 | | LDIX, | 251 | 0 | 0 | 0 | 0 | 2 | 6 | 6 | LDIX, | 015 | |
| | | | 1 | 2 | 5 | 1 | | | | | | 1 | 0 | 1 | 5 | | | |
| | | | 2 | 3 | 1 | 4 | OPCB | | | | | 2 | 3 | 1 | 5 | OPDB | | |
| | | | 3 | 2 | 2 | 0 | JU00, | 000 | | | | 3 | 2 | 2 | 0 | JU00, | 002 | |
| | | | 4 | 0 | 0 | 0 | | | | | | 4 | 0 | 0 | 2 | | | |

- i. Test #8. This test procedure checks the Data Output Register and the Data Output lamp drivers. A series 7810 1/0 Handler program (magnetic card) is needed to perform the test, as well as a specific keyboard entered program.
 - 1. Enter a series 7810 I/O Handler program via the magnetic card reader at branch point 0 0.
 - 2. Enter the program listed in Table 5-8. (See page 5-13.)
 - 3. Place the PCU in Program Mode.
 - Run the program beginning at branch point 0 0.
 - 5. Verify that the Data Output indicators (representing DOL1, DOL2, DOL4, DOL8, DOH1, DOH2, DOH4, DOH8) are lighted corresponding to a "walking one" moving towards the left. The Data Output lines DOL1 through DOL8 may also be observed. Since the data lines are inverted, a "walking zero" should be observed.
 - 6. Enter the program listed in Table 5-9.
 - 7. Place the PCU in Program Mode.
 - 8. Run the program beginning at branch point 0 0.
 - 9. Verify that the Data Output indicators (representing DOL1, DOL2, DOL4, DOL8, DOH1, DOH2, DOH4, DOH8) are lighted corresponding to a 'walking zero' moving towards the left. The Data Output lines, DOL1 through DOH8 may also be observed. Since the data lines are inverted, a 'walking one' should be observed.
- j. Test #9. This test procedure checks the Byte Counter circuitry using a static test. A program must be loaded into the PCU to obtain OPCB and OPDB conditions.
 - 1. Enter the program listed in Table 5-10. (See page 5-13.)
 - 2. Place the PCU in Program mode.
 - Set the oscilloscope as follows:
 - a) Vertical Sensitivity 2 volts/div.
 - b) Horizontal Sweep 50 ms/div.
 - c) Trigger Source AUTO Trigger.
 - 4. Make connections to the following Byte Count (BC) lines at Interface Number 1: BCO, BC1, BC2, BC3, BC4, BC5, BC6, BC7.
 - 5. Run the program beginning at branch point 0 0.
 - Verify that the BCO line is at Logic "I" when the PCU "IDLE" indicator is lighted.
 - 7. Depress RESUME.
 - Verify that BCl line is at Logic "1" when the PCU "IDLE" indicator is lighted.
 - 9. Depress RESUME.
 - 10. Verify that BC2 line is at Logic "!" when the PCU "IDLE" indicator is lighted.

NOTE

Continue the test in a similar fashion until BC7 has been tested. Each time RESUME is depressed the program will cause the next BC line to go to Logic "l". After BC7 has been tested, all succeeding RESUME key strokes will have no effect on the BC lines (that is, all BC lines will remain at Logic "O"). The program may be run again by jumping to branch point 0 0.

INSTRUCTION MANUAL Control Unit Model 780

- k. Test #10. This procedure checks the Byte Counter circuitry using a dynamic test. A program must be loaded into the PCU to obtain OPCB and OPDB conditions.
 - 1. Enter the program listed in Table 5-11. (See page 5-13.)
 - 2. Set the RUN/STEP/LOAD switch on the PCU to RUN.
 - 3. Set the oscilloscope as follows:
 - a) Vertical Sensitivity 5 volts/div.
 - b) Horizontal Sweep DELAYED 50µs/div.
 - c) Trigger Source Channel 1, positive slope.
 - 4. Make connections to the Control Unit circuitry as follows:
 - a) Connect Channel 7 input to U128-14 (Data Pulse DP).
 - b) Connect Channel 2 input to U128-1 (QA on Data Byte Counter).
 - c) Connect Channel 3 input to U105-2 (BC0).
 - d) Connect Channel 4 input to U105-4 (BC1).
 - 5. Run the program beginning at branch point 0 0.
 - 6. Verify that QA is toggled by the Logic "I" to Logic "O" transition of the Data Pulse (DP), thus incrementing the Byte Counter from BCO to BC1.
 - 7. Change the oscilloscope connection on the Channel 4 Input from U105-4 to U103-8 (Control Byte Detector output).
 - 8. Verify that BCO is set to Logic "1" by the Logic "0" to Logic "1" transition of OPCB.




FIGURE 16. Trace For Test #10.

- 1. Test #11. This procedure checks the "one of us" decoder. This circuit is activated by a Control Byte with IH = 8 or 9 depending on the position of Switch S103. A program must be loaded in the PCU to obtain an OPCB condition.
 - 1. Set the Control Unit internal switch \$103 to CUI position.
 - 2. Enter the program listed in Table 5-12. (See page 5-13.)
 - 3. Set the RUN/STEP/LOAD switch on the PCU to RUN.
 - 4. Set the oscilloscope as follows:
 - a) Vertical sensitivity 5 volts/div.
 - b) Horizontal Sweep 20µs/div.
 - c) Trigger Source Channel I (negative slope).
 - 5. Make connections to the Control Unit circuitry as follows:
 - a) Connect Channel 1 to U131-1 ($\overline{\mathbb{Q}}$ of first CTRL one-shot).
 - b) Connect Channel 2 to U107-11 (one of us).
 - c) Connect Channel 3 to Ul18-13 (Latch Enable).
 - d) Connect Channel 4 to Ul18-10 (BYIN Enable).
 - 6. Run the program beginning at branch point 0 0.
 - 7. Verify the traces shown in Figure 17.




FIGURE 17. Trace For Test #11.

Model 780

TABLE 5-8.

TABLE 5-9.

| | | • | ···- | · · |
|-----------------|------------------|-------------------------|-------------------------------|-------------------------|
| Program Ne | eded to Pe | rform Test #8 (Part 1) | Program Needed To Per | form Test #8 (Part 2) |
| DECIMAL STEP | INSTRUCTION CODE | INSTRUCTION MNEMONIC | DECIMAL INSTRUCTION STEP CODE | INSTRUCTION Mnemonic |
| 0 0 0 0 | 2 6 6 | LDIX, 001 | 0 0 0 0 2 6 6 | LDIX, 376 |
| 1 | 0 0 1 | | 1 376 | |
| 2 | 3 1 5 | OPDB | 2 3 1 5 | OPDB |
| 3 | 3 4 7 | SLCI | 3 3 4 7 | SLCI |
| 4 | 1 6 0 | STIO | 4 1 6 0 | STIO |
| 5 | 0 0 1 | 1111 | 5 0 0 1 | 11 ₁ 11 |
| 6 | 107 | WAIT | 6 107 | WAIT |

TABLE 5-10.

2 2 0 JU00,002

RCIO

7 1 6 1

9 0 0 2

TABLE 5-11.

2 2 0 JU00, 002

RCI0

1 6 1

0 0 2

| | | Pr | ogr | am N | ee | led | to Perfo | rm Test #9 | | | ρ | ro | gram | Ne | ede | d to | Perform | n Test #10 |
|---|---|-------------|-----|------|-----|------------|----------|----------------------|---|----|-----------|----|------|----|-------------|------------|---------|----------------------|
| | | CIMA TEP | L | | RU(| CTION E | , | INSTRUCTION MNEMONIC | | DE | CI STI | | L | | rru(Cod | CTION E | | INSTRUCTION MNEMONIC |
| 0 | 0 | 0 | 0 | 3 | 1 | 4 | OPCB | | 0 | 0 | ı | 0 | 0 | 2 | 6 | 6 | LDIX, | 200 |
| | | | 1 | 0 | 5 | 6 | HALT | | | | | | 1 | 2 | 0 | 0 | - | |
| | | | 2 | 3 | 1 | 5 | OPDB | | | | | | 2 | 3 | I | 4 | OPCB | |
| | | | 3 | 0 | 5 | 6 | HALT | | | | | | 3 | 3 | 1 | 5 | OPDB | |
| | | | 4 | 2 | 2 | 0 | JU00, | 002 | | | | | 4 | 3 | 1 | 5 | OPDB | |
| | | | 5 | 0 | 0 | 2 | | | | | | | 5 | 3 | 1 | 5 | OPDB | |
| | | | | | | | | | | | | | 6 | 3 | 1 | 5 | OPDB | |
| | | | | | | | | | | | | | 7 | 2 | 2 | 0 | JU00, | 000 |
| | | | | | | | | | | | | | 8 | 0 | 0 | 0 | | |

TABLE 5-12.

TABLE 5-13.

| | F | ro | gram | Ne | ede | d to | Perform | n Test #11 | | F | ro | gram | 1 Ne | ede | d to | Perform | n Test #12 |
|---|---|------------|--------|--------|-------------|-----------|--------------|----------------------|---|---|------------|--------|--------|--------|-----------|--------------|-------------------------|
| | - | IMA Tep | L | | rruc Cod | TION E | | INSTRUCTION MNEMONIC | | | IMA TEP | L | | RU(| TION E | | INSTRUCTION MNEMONIC |
| 0 | 0 | 0 | 0 | | 6 0 | | LDIX, | 200 | 0 | 0 | 0 | 0 | 2 2 | 6 0 | | LDIX, | 200 |
| | | | 2 | | 1 | 4 | OPCB | | | | | 2 | 3 | 1 | 4 | OPCB | |
| | | | 3 4 | 3 3 | _ | 1 4 | ICIH OPCB | | | | | 3 4 | 3 0 | 4 5 | 0 6 | ICIL HALT | |
| | | | 5 6 | 2 0 | 2 0 | 0 0 | JU00, | 000 | | | | 5 6 | 2 0 | 2 0 | 0 2 | JU00, | 002 |

- m. Test #12. This procedure checks the Control Byte Operation Decoder. The Control Byte operation Decoder decodes the IL portion of a Control Byte. A program must be loaded into the PCU to obtain an OPCB condition.
 - 1. Enter the program listed in Table 5-13. (See page 5-13.)
 - 2. Set the RUN/STEP/LOAD switch on the PCU to RUN.
 - 3. Set the oscilloscope as follows:
 - a) Vertical Sensitivity 2 volts/div.
 - b) Horizontal Sweep 50 ms/div.
 - c) Trigger Source AUTO Trigger.
 - 4. Run the program beginning at branch point 0 0.
 - 5. Make a connection between Channel 1 Input and the following pins on Interface Number 1: 1 (SA1), 2 (SA2), 3 (SA3), 13 (CO), 19 (C1), 17 (C2) and U121-10 (SCAN ADDR) on the Model 780 pc board.
 - 6. Verify that the signals in Table 5-14 are at Logic "1" depending on the contents of IL. Each time RESUME is depressed another Control Byte will be sent out of the PCU and the contents of IL will be incremented by one. After IL = 15, the program loops to |L| = 0.

NOTE

The operation codes above a decimal 10 are not presently used by the Control Unit, except 13 (RESET) which is 1H independent.

TABLE 5-14.

Summary of Signal Condition

| | (BASE 10) | | STATUS OF SIGNAL LINES | | | | | | | | | | |
|---------------|-------------|-----|------------------------|-----|----|----|-----|-----------|--|--|--|--|--|
| ACTION | IL CONTENTS | SAI | SA2 | SA3 | CO | C1 | C 2 | SCAN ADDR | | | | | |
| un Program | 0 | ì | × | × | 1 | × | × | × | | | | | |
| epress Resume | 1 | × | 1 | × | 1 | × | × | × | | | | | |
| epress Resume | 2 | × | X | 1 | ì | × | X | × | | | | | |
| epress Resume | 3 | × | × | x | 1 | × | x | 1 | | | | | |
| epress Resume | 4 | 1 | × | × | × | 1 | × | × | | | | | |
| epress Resume | 5 | × | 1 | x | x | 1 | × | × | | | | | |
| epress Resume | 6 | × | × | 1 | × | ì | × | × | | | | | |
| epress Resume | . 7 | × | × | × | x | ĺ | × | 1 | | | | | |
| epress Resume | 8 | 1 | × | x | X | × | 1 | × | | | | | |
| epress Resume | . 9 | × | 1 | x | × | X | i | × | | | | | |
| epress Resume | 10 | × | × | 1 | X | × | į | × | | | | | |
| epress Resume | 11 | × | × | × | × | × | 1 | 1 | | | | | |
| epress Resume | 12 | 1 | × | X | X | × | × | x | | | | | |
| epress Resume | 13 | × | 1 | × | × | × | × | × | | | | | |
| epress Resume | 14 | × | × | 1 | X | × | × | × | | | | | |
| epress Resume | 15 | × | × | × | x | × | × | 1 | | | | | |
| epress Resume | Ó | 1 | x | | ĺ | | | × | | | | | |
| epress Resume | Ū | 1 | X | × | ' | × | × | ^ | | | | | |

INSTRUCTION MANUAL Control Unit Model 780

- n. Test #13. This test procedure checks the BYIN Enable Flip-Flop. A program must be loaded into the PCU to obtain an OPCB condition.
 - 1. Enter the program listed in Table 5-15. (See page 5-19.)
 - 2. Set the RUN/STEP/LOAD switch on the PCU to RUN.
 - 3. Set the oscilloscope as follows:
 - a) Vertical Sensitivity 2 volts/div.
 - b) Horizontal Sweep 100µs/div. (MAIN TIME BASE) 50µs/div. (DELAYED SWEEP)
 - c) Trigger Source Channel 1 (Negative slope).
 - 4. Make connections to the Control Unit circuitry as follows:
 - a) Connect Channel I Input to Ul18-10 (BYIN Enables F/F Q output).
 - b) Connect Channel 2 Input to UIO7-1 (RESET).
 - 5. Run the program beginning at branch point 0 0.
 - 6. Verify that output of BYIN F/F is:
 - a) Set by a valid "one of us" code.
 - b) Reset by a RESET signal.




FIGURE 18. Trace For Test #13.

- o. Test #14. This test procedure checks the IH Independent RESET Code Detector. This circuit detects Control Bytes with IH = don't care' and IL = 15 octal, such as RESET Control Byte. A program must be loaded into the PCU to obtain an OPCB condition.
 - 1. Enter the program listed in Table 5-16. (See page 5-19.)
 - Set the RUN/STEP/LOAD switch on the PCU to RUN.
 - 3. Set the oscilloscope as follows:
 - a) Vertical Sensitivity 5 volts/div.
 - b) Horizontal Sweep 100µs/div. (MAIN TIME BASE) 50µs/div. (DELAYED SWEEP)
 - c) Trigger Source Channel | (Negative Slope).
 - 4. Make connections to the Control Unit circuitry as follows:
 - a) Connect Channel | Input to U114-6 (Reset Code Detector output).
 - b) Connect Channel 2 Input to U104-2 (First CTRL one-shot $\overline{\mathbb{Q}}$).
 - c) Connect Channel 3 Input to UiO4-1 (Reset Signal to OR Gate).
 - 5. Run the program beginning at branch point 0 0.
 - 6. Verify traces shown in Figure 19.




FIGURE 19. Trace For Test #14.

- p. Test #15. This test procedure checks—the Power Up Reset circuitry. This circuitry operates when power is first applied to the Control Unit. Both a RESET and a POWER UP RESET pulse is generated. No program is needed for this test. (No PCU connection is needed).
 - 1. Set the oscilloscope as follows:
 - a) Vertical Sensitivity Channel 1: 2 volts/div.
 Channel 2: 1 volt/div.
 - b) Horizontal Sweep 50 ms/div.
 - c) Trigger Source See below for suggested settings using an oscilloscope with storage capability.
 - 2. Make connections to the Control Unit circuitry as follows:
 - a) Connect Channel 1 Input to Ul14-8 (Power Up Reset output).
 - b) Connect Channel 2 Input to Ull4-9 (Input from RC circuit).
 - 3. Set the oscilloscope to SINGLE SWEEP mode.
 - 4. Manually start the sweep with the LEVEL control.
 - 5. Turn on the Control Unit Power Switch when the sweep reaches the approximate center of the screen.
 - 6. Verify a Power-Up Reset signal on Channel 1 as shown in Figure 20.




FIGURE 20. Trace For Test #15.

- q. Test #16. This test procedure checks the RESET and RESET lines. A program must be loaded into the PCU to obtain an OPCB condition.
 - 1. Enter the program listed in Table 5-17. (See page 5-19.)
 - 2. Set the RUN/STEP/LOAD switch on the PCU to RUN.
 - 3. Set the oscilloscope as follows:
 - a) Vertical Sensitivity 5 volts/div.
 - b) Horizontal Sweep 50µs/div. (MAIN TIME BASE)
 10µs/div. (DELAYED SWEEP)
 - c) Trigger Source Channel 1, positive slope.
 - 4. Make connections to the Control Unit circuitry as follows:
 - a) Connect Channel 1 Input to U101-8 (RESET).
 - b) Connect Channel 2 Input to U104-13 (RESET).
 - c) Connect Channel 3 Input to U104-2 (First CTRL One-Shot \overline{Q}).
 - 5. Run the program beginning at branch point 0 0.

NOTE

The program will run continuously. Depress RESET to stop the program.

6. Verify that the FIRST CTRL one-shot $\overline{\mathbb{Q}}$ goes to Logic "O" when RESET goes to Logic "I", as shown in Figure 21.




FIGURE 21. Trace For Test #16.

TABLE 5-15.

TABLE 5-16.

Program Needed to Perform Test #13

Program Needed to Perform Test #14

| DECIMAL STEP | INSTRUCTION CODE | INSTRUCTION MNEMONIC | DECIMAL INSTRUCTION STEP CODE | INSTRUCTION MNEMONIC | | |
|-----------------|------------------|-------------------------|-------------------------------|----------------------|--|--|
| 0 0 0 0 | 2 6 6 2 0 0 | LDIX, 200 | 0 0 0 0 2 6 6 L 1 2 0 0 | DIX, 200 | | |
| • 2 | 3 1 4 | OPCB | 2 3 1 4 0 | PCB | | |
| 3 | 2 6 6 | LDIX, 015 | <i>3 2 6 6</i> L | DIX, 015 | | |
| 4 | 0 1 5 | | 4 0 1 5 | | | |
| 5 | 3 1 4 | OPCB | 5 3 1 4 0 | PCB | | |
| 6 | 2 2 0 | JU00, 000 | 6 2 2 0 J | U00, 000 | | |
| 7 | 0 0 0 | | 7 0 0 0 | | | |

TABLE 5-17.

| | | Pro | gram | Ne | ede | ed to | Perform | n Test | #16 | | | | | | | | | |
|---|---|-------------|--------|--------|-------------|------------|---------|--------------------|-----|---|-----|-----|--------|------|-----|----------------|---------|-------------|
| | | CIMA Tep | Ĺ | | COD | CTION E | | INSTRUCT MNEMON | | | | | | | | | | |
| 0 | 0 | 0 | 0 1 | 2 0 | 6 1 | 6 5 | LDIX, | 015 | | | | | | | - | Γ AB LE | 5-18. | |
| | | | 2 | 3 | 1 | | OPCB | | | | F | ro | gra | m Ne | ede | ed to | Perform | n Test #17 |
| | | | 3 | 2 | 2 | 0 | JU00, | 000 | | | ĐEC | | | | | CTION | | INSTRUCTION |
| | | | 4 | 0 | 0 | 0 | | | | | | ΓEΡ | L | 1116 | COD | | | MNEMONIC |
| | | | | | | | | | | 0 | 0 | 0 | 0 1 | 2 | | 6 0 · · · | LDIX, | 200 |
| | | | | | | | | | | | | | 2 | . 3 | • 1 | 4 | OPCB | |
| | | | | | | | | | | | | | 3 | 2 | 0 | 0 | BROO, | 015 |
| | | | | | | | | | | | | | 4 | 0 | 1 | 5 | | |
| | | | | | _ | | ~ 10 | | | | | | 5 | 2 | 6 | 6 | LDIX, | 204 |
| | | | | | I | ABLE | 5-19. | | | | | | 6 | 2 | 0 | 4 | | |
| | | Pro | gram | Ne | ede | d to | Perform | n Test | #18 | | | | 7 | 3 | 1 | 4 | OPCB | |
| | | CIMA TEP | L | | TRUC Cod | CTION E | | INSTRUCT MNEMO | | | | | 8 9 | 2 | | 0 5 | BR00, | 015 |
| 0 | 0 | 0 | 0 | 2 | 6 | 6 | LDIX, | 000 | | | | 1 | 0 | 2 | 6 | 6 | LDIX, | 210 |
| | | | 1 | 0 | 0 | | | | | | | 1 | 1 | 2 | 1 | 0 | · | |
| | | | 2 | 3 | 1 | 5 | OPDB | | | | | 1 | 2 | 3 | 1 | 4 | OPCB | |
| | | | 3 | 3 | 4 | 0 | 101L | | | | | 1 | 3 | 0 | 5 | 6 | HALT | |
| | | | 4 | 0 | 5 | 6 | HALT | | | | | 1 | 4 | 2 | 6 | 6 | LDIX, | 015 |
| | | | 5 | 2 | 2 | 0 | JU00, | 002 | | | | 1 | 5 | 0 | 1 | 5 | | |
| | | | 6 | 0 | 0 | 2 | | | | | | 1 | 6 | 3 | 1 | 4 | OPCB | |
| | | | | | | | | | | | | 1 | 7 | 0 | 5 | 6 | HALT | |
| | | | | | | | | | | | | 1 | 8 | 3 | 7 | 1 | RCLP | |
| | | | | | | | | | | | | 1 | 9 | 3 | 7 | 1 | RCLP | |

- r. Test #17. This test procedure checks the CO, Cl and C2 lines.* A program must be loaded into the PCU to obtain an OPCB condition.
 - Enter the program listed in Table 5-18.
 - 2. Set the RUN/STEP/LOAD switch on the PCU to RUN.
 - 3. Run the program beginning at branch point 0 0.
 - 4. Verify that SAI and CO are set to Logic "1".
 - 5. Depress RESUME. A RESET will be sent out.
 - 6. Verify that CO is set to Logic "O".
 - 7. Depress RESUME.
 - 8. Verify that SAI and CI are set.
 - 9. Depress RESUME.
 - 10. Verify that RESET is sent out and Cl is reset.
 - 11. Depress RESUME.
 - 12. Verify that SA1 and C2 are set.
 - 13. Depress RESUME.
 - 14. Verify that RESET is sent out and C2 is reset.
 - 15. To run the program again, jump to branch point 0 0 and RESUME.

*NOTE

These lines can be examined on connector J101, J102, or J103 as shown in Figure 6, page 3-2.

- s. Test #18. This test procedure tests the Scanner interface circuitry (CHAD lines).
 A program must be loaded into the PCU.
 - 1. Enter the program listed in Table 5-19. (See page 5-19.)
 - 2. Set the RUN/STEP/LOAD switch on the PCU to RUN.
 - 3. Set the Oscilloscope as follows:
 - a) Vertical Sensitivity 2 volts/div.
 - b) Horizontal Sweep 2 ms/div.
 - c) Trigger Source Channel 1
 - 4. Connect Channel 1 to the "TO SCANNER" connector at the various CHAD lines indicated in Table 5-20.
 - Run the program beginning at branch point 0 0.

NOTE

The program steps through the 16 possible combinations of addresses in binary sequence (mod 16). Verify that front panel indicators and CHAD lines are as given in Table 5-20.

TABLE 5-20.
Summary of CHAD Testing

| Program Action | | OUT ndic L4 | | | | | ines (PI (Pin 14) CHAD 2 | | Remarks |
|-------------------|---|-------------------|---|-----|-----|----|--------------------------------|---|--------------------|
| Start Program | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | Channel O selected |
| RESUME | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 1 | Channel 1 selected |
| RESUME | 0 | 0 | 1 | 0 | 0 | 0 | Ī | 0 | Channel 2 selected |
| RESUME | 0 | 0 | 1 | 1 | 0 | 0 | 1 | 1 | Channel 3 selected |
| RESUME | 0 | 1 | 0 | 0 | 0 | 1. | 0 | 0 | Channel 4 selected |
| RESUME | 0 | 1 | 0 | 1 | 0 | 1 | 0 | 1 | Channel 5 selected |
| RESUME | 0 | 1 | 1 | 0 | 0 | 1 | 1 | 0 | Channel 6 selected |
| RESUME | 0 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | Channel 7 selected |
| RESUME | 1 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | Channel 8 selected |
| RESUME | 1 | 0 | 0 | 1 | 1 | 0 | 0 | 1 | Channel 9 selected |
| RESUME | 1 | 0 | 1 | 0 | 1 | 0 | 1 | 0 | No Channel |
| RESUME | 1 | 0 | 1 | 1 | 1 | 0 | ī | 1 | No Channel |
| RESUME | 1 | 1 | 0 | 0 | 1 | 1 | 0 | 0 | No Channel |
| RESUME | 1 | 1 | Ō | 1 | 1 | 1 | 0 | 1 | No Channel |
| RESUME | 1 | 1 | 1 | Ó | 1 | 1 | i | 0 | No Channel |
| RESUME | l | ì | 1 | 1 - | . 1 | 1 | t | 1 | No Channel |

- <u>t. Test #19.</u> This test procedure tests the Scanner interface circuitry (LOCHAD lines), except for gates U126 and U127. A program must be loaded into the PCU. (No Scanner needs to be connected.)
 - 1. Enter the program listed in Table 5-21. (See page 5-22.)
 - 2. Set the RUN/STEP/LOAD switch on the PCU to RUN.
 - 3. Set the Oscilloscope as follows:
 - a) Vertical Sensitivity 2 volts/div.
 - b) Horizontal Sweep 2 ms/div.
 - c) Trigger Source AUTO trigger
 - 4. Connect Channel 1 to the "SCANNER" connector at the various LOCHAD lines indicated in Table 5-22.
 - 5. Run the program beginning at branch point 0 0.

NOTE

The program can be used to step through all eight LOCHAD commands. Verify that the logic on the appropriate LOCHAD line is as given in Table 5-22. Also verify that the correct indicators are lighted.

NOTE

Part 2 of Test #19 is continued on page 5-23.

TABLE 5-21.

Program Needed to Perform Test #19 (Part 1)

| | F | ro | gram | Ne | ede | be | to | Pertor | n Test | #19 | (Part | 1) |
|---|-----------|-----------|------|------|------------|----|----|--------|--------------------|-----|-------|----|
| | DEC S1 | IMA EP | L | INST | RUC Cod | | N | | INSTRUCT Mnemon | | | |
| 0 | 0 | 0 | 0 | 2 | 6 | 6 | | LDIX, | 010 | | | |
| | | | 1 | 0 | 1 | 0 | | | | | | |
| | | | 2 | 1 | 6 | 3 | | ST11 | | | | |
| | | | 3 | 2 | 6 | 6 | | LDIX, | 001 | | | |
| | | | 4 | 0 | 0 | 1 | | | | | | |
| | | | 5 | 1 | 6 | 0 | | STIO | | | | |
| | | | 6 | 2 | 6 | 6 | | LDIX, | 203 | | | |
| | | | 7 | 2 | 0 | 3 | | | | | | |
| | | | 8 | 3 | 1 | 4 | | OPCB | | | | |
| | | | 9 | 1 | 6 | 1 | | RCI0. | | | | |
| | | 1 | 0 | 3 | 1 | 5 | | OPDB | | | | |
| | | 1 | 1 | 3 | 4 | 0 | | ICIL | | | | |
| | | 1 | 2 | 1 | 6 | 0 | | STIO | | | | |
| | | 1 | 3 | 1 | 6 | 4 | | RC11 | | | | |
| | | 1 | 4 | 3 | 4 | 0 | | ICIL | | | | |
| | | 1 | 5 | 1 | 6 | 3 | | STI1 | | | | |
| | | 1 | 6 | 2 | 6 | 0 | | JLNZ, | 025 | | | |
| | | 1 | 7 | 0 | 2 | 5 | | | | | | |
| | | 1 | 8 | 0 | 5 | 6 | | HALT | | | | |
| | | 1 | 9 | 2 | 2 | 0 | | JU00, | 000 | | | |
| | | 2 | 0 | 0 | 0 | 0 | | | | | | • |
| | | 2 | 1 | 0 | 5 | 6 | | HALT | | | | |
| | | 2 | 2 | 2 | 2 | 0 | | JU00, | 006 | | | |
| | | 2 | 3 | 0 | 0 | 6 | | | | | | |

TABLE 5-22.
Summary of Test Points Used in Test #19.

| Scanner LOCHAD Line | Ul25 Logic Levels | | | | | | | | "SCANNER" Connector P110 | OU | TPUT I | ndicat | ors |
|---------------------------|----------------------|---------|-----------------|---------------|-------|-----------------|---------------|---------------|--------------------------------------|----------------------------|---------------------------------|---------------------------------|-------------|
| | 2 | 3 | 4 | 5 | 6 | 7 | 9 | 10 | Pin No. | L8 | L4 | L2 | L1 |
| 1 2 3 4 5 6 7 8 | 0 1 1 1 1 1 1 1 1 1 | 1 1 1 1 | 0 1 1 1 1 1 1 1 | 1 0 1 1 1 1 1 | 0 1 1 | 1 1 1 1 0 1 1 1 | 1 1 1 1 1 0 1 | 1 1 1 1 1 1 0 | 16 12 25 13 26 5 6 | 0 0 0 0 0 0 | 0 0 0 1 1 1 1 | 0 1 1 0 0 1 1 | 0 0 1 0 1 0 |

Part 2 of Test #19

- 6. Enter the program listed in Table 5-23.
- 7. Set the RUN/STEP/LOAD switch on the PCU to RUN.
- 8. Set the Oscilloscope as follows:
 - a) Vertical Sensitivity 2 volts/div.
 - b) Horizontal Sweep 10µs/div.
 - c) Trigger Source Channel 1, positive slope.
- 9. Connect Channel 1 to the "SCANNER" connector at the various LOCHAD lines indicated in Table 5-22.
- 10. Run the program beginning at branch point 0 0.
- 11. Verify the waveform shown in Figure 22. (See page 5-24.)

NOTE

The program runs continuously. To halt the program, depress RESET. The program has been written specifically for LOCHAD 1 only. To test the remaining 7 LOCHAD lines the program must be altered. For example, to test LOCHAD 2, change location 0004 to code 002 instead of code 001.

TABLE 5-23.

| Pr | - | ram IMAI | | | | Pei | rform | | st #19 INSTRUCT | (Part | 2) |
|----|---|-------------|---|---|------------------|-----|-------|----|--------------------|-------|----|
| | S | ΓEΡ | | (| COD | E | | | MNEMON | IC | |
| 0 | 0 | 0 | 0 | 2 | 6 | 6 | LDI | х, | 203 | | |
| | | | 1 | 2 | 0 | 3 | | | | | |
| | | | 2 | 3 | 1 | 4 | 0 P C | В | | | |
| | | | 3 | 2 | $\boldsymbol{6}$ | 6 | LDI | Χ, | 001 | | |
| | | | 4 | 0 | 0 | 1 | | | | | |
| | | | 5 | 3 | 1 | 5 | OPD | В | | | |
| | | | 6 | 3 | 1 | 5 | OPD | В | | | |
| | | | 7 | 2 | 2 | 0 | JU0 | 0, | 000 | | |
| | | | 8 | 0 | 0 | 0 | | - | | | |




FIGURE 22. Trace For Test #19 (Part 2).

<u>u. Test #20.</u> This test procedure checks the Scanner interface circuitry (Latch Enable). A program must be loaded into the PCU to obtain OPCB and OPDB conditions.

- 1. Enter the program listed in Table 5-24. (See page 5-28.)
- 2. Set the RUN/STEP/LOAD switch on the PCU to RUN.
- 3. Set the Oscilloscope as follows:
 - a) Vertical Sensitivity 5 voits/div.
 - b) Horizontal Sweep 200µs/div. (MAIN TIME BASE) 50µs/div. (DELAYED SWEEP)
 - c) Trigger Source Channel 1, positive slope.
- 4. Make connections to the Control Unit circuitry as follows:
 - a) Connect Channel 1 Input to U104-6 (DP).
 - b) Connect Channel 2 Input to U117-2 (CO · SCAN ADDR).
 - c) Connect Channel 3 Input to U121-5 (BCO).
 - d) Connect Channel 4 Input to U108-10 (Latch Enable).
- 5. Run the program beginning at branch point 0 0.
- 6. Verify that Latch Enable is at Logic "I" under the following conditions:
 - a) CO · SCAN ADDR is at Logic "!".
 - b) BCO is at Logic "I".
 - c) \overline{DP} is at Logic "0".




FIGURE 23. Trace For Test #20.

v. Test #21. This test procedure checks the Scanner interface circuitry (LOCHAD Enable). A program must be loaded into the PCU to obtain OPCB and OPDB conditions.

- 1. Enter the program listed in Table 5-24 (same program used in Test No. 20).
- 2. Set the RUN/STEP/LOAD switch on the PCU to RUN.
- 3. Set the Oscilloscope as in Test No. 20.
- 4. Make connections to the Control Unit circuitry as follows:
 - a) Connect Channel | Input to U104-6 (DP).
 - b) Connect Channel 2 Input to U117-2 (CO · SCAN ADDR).
 - c) Connect Channel 3 Input to U121-1 (BC1).
 - d) Connect Channel 4 Input to U121-3 (LOCHAD Gate Enable).
- 5. Run the program beginning at branch point 0 0.
- 6. Verify that LOCHAD Gate Enable is at Logic '10" under the following conditions:
 - a) CO · SCAN ADDR is at Logic "1".
 - b) BCl is at Logic "l".
 - c) \overrightarrow{DP} is at Logic "0".




FIGURE 24. Trace For Test #21.

 \underline{w} . Test #22. This test procedure is used to check the Input Data Register. A program must be loaded into the PCU to obtain OPCB and IPDB conditions.

- 1. Enter the program listed in Table 5-25 (See page 5-28.)
- 2. Set the RUN/STEP/LOAD switch on the PCU to RUN.
- 3. Set the Oscilloscope as follows:
 - a) Vertical Sensitivity Channel 1, 2: 5 volts/div.
 Channel 3: 2 volts/div.
 - b) Horizontal Sweep 50μs/div. (MAIN TIME BASE) 5μs/div. (DELAYED SWEEP)
 - c) Trigger Source Channel I, positive slope.
- 4. Make connections to the Control Unit circuitry as follows:
 - a) Connect Channel 1 Input to U109-1 (Data Byte Detector Output).
 - b) Connect Channel 2 Input to U109-2 (PCU Clock Signal).
 - c) Connect Channel 3 Input to U108-11 (PCU Byte Input Line).
- 5. Run program beginning at branch point 0 0.
- 6. Verify traces shown in Figure 25.

NOTE

The OPCB instruction sends out a Control Byte with 200 code. This is a "one-of-us" code and sets the BYIN Flip-Flop to enable the BYIN line. The data being applied to the INPUT REGISTER is (L1 to H8) 01001011 binary.




FIGURE 25. Trace For Test #22.

INSTRUCTION MANUAL Control Unit Model 780

TABLE 5-24.

TABLE 5-25.

| | ı | Pro | gram | Ne | ede | ed to | Perform | n Test #20 | | | ۲r | ogr | am N | ee | ted t | to Perfo | rm Test #22 | |
|---|---|------------|------|----|-------------|-------|---------|----------------------|---|---|-------------|-----|------|-----|-------|-------------------------|-------------|--|
| | | IMA Tep | L | | TRU(COD | CTION | | INSTRUCTION MNEMONIC | | | CIMA Tep | L | | COD | CTION | INSTRUCTION MNEMONIC | | |
| 0 | 0 | 0 | 0 | 2 | 6 | 6 | LDIX, | 203 | 0 | 0 | 0 | 0 | 2 | 6 | 6 | LDIX, | 200 | |
| | | | 1 | 2 | 0 | 3 | | | | | | 1 | 2 | 0 | 0 | | | |
| | | | 2 | 3 | 1 | 4 | OPCB | | | | | 2 | 3 | 1 | 4 | OPCB | | |
| | | | 3 | 3 | 1 | 5 | OPDB | | | | | 3 | 3 | 0 | 5 | IPDB | | |
| | | | 4 | 3 | 1 | 5 | OPDB | | | | | 4 | 3 | 0 | 5 | IPDB | | |
| | | | 5 | 2 | 6 | 6 | LDIX, | 200 | | | | 5 | 2 | 2 | 0 | JU00, | 003 | |
| | | | 6 | 2 | 0 | 0 | | | | | | 6 | 0 | 0 | 3 | | | |
| | | | 7 | 3 | 1 | 4 | OPCB | | | | | | | | | | | |
| | - | | 8 | 2 | 2 | 0 | JU00, | 000 | | | | | | | | | | |
| | | | 9 | 0 | 0 | 0 | | | | | | | | | | | | |

SECTION 6. ACCESSORIES

- 6-1. RACK MOUNTING KIT. (Similar to hardware supplied with Model 1007 Rack Mounting Kit)
- a. General. The rack mounting hardware furnished with the instrument permits standard 3-1/2 in. x 19 in. rack mounting, 15-1/2 in. (395 mm) depth behind the front panel. The hardware included consists of two angle brackets and extra mounting screws.

b. Installation Instructions.

- 1. Remove the "side dress" panels on both sides of the instrument as follows:
 - a) Remove two screws ($\#6-32 \times 1/4$) on each side of the instrument.
 - b) Slide the "side dress" panels toward the rear of the instrument to remove.
- 2. Install an "angle bracket" (Item 21) on each side using longer screws (Items 22 and 28) in place of original screws (a total of three screws is needed per side).

TABLE 6-1.

Parts List For Rack Mounting Kit

| ltem No. | Description | Qty Req'd | Keithley Part No. |
|-------------|------------------------------|--------------|----------------------|
| 21 | Angle Bracket | 2 | 274108 |
| 22 | Screw, #6-32 x 5/8, Phillips | 4 | |
| 28 | Screw, #6-32 x 1/2, Phillips | 2 | |
| | | | |




FIGURE 26. Rack Mounting of the Control Unit.

- 6-2. MULTI-SCANNER COUPLER (Model 7819-MSC).
- <u>a. General.</u> The Multi-Scanner Coupler provides additional connections for up to 8 Scanners. I/O Handler Software, furnished with any Series 7801 Instrument Interface, Series 7802, or Model 7813, may be used to control multiple Scanners connected to the MSC.
 - 1. A single Model 7021-10 System Interconnect Cable is furnished with the MSC to couple to the Control Unit.
 - 2. In addition, the MSC provides eight connectors which mate with any System Interconnect Cable (furnished with each Scanner).
 - 3. A set of slide switches enable the user to modify the Scanner interconnections if necessary. When set to NORMAL, only one active Scanner at a time is permitted.

NOTE

Each switch connects the Scanner VCH line (pin 24) to a "VCH bus", when set to NOR-MAL (ON). If it is desired to use the System 1 for parallel-channel or matrix operation refer to PAT PROGRAMMING TECHNIQUES. The 1/O Handler program must be altered to permit parallel-channel selections since the software routine sends out a REMOTE ALL OFF signal prior to executing a new channel address. See also schematic 27357D in Section 7 of this manual.




FIGURE 27. Multi-Scanner Coupler (Model 7819-MSC).

SPECIFICATIONS

GENERAL: Couples single scanner output connector of Model 780 to eight connectors for controlling up to eight Model 702 Scanners. Total length (sum) of all scanner interconnection cables must not exceed 40 feet.

MULTIPLE-CHANNEL SELECT: Scanner interconnections prevent inadvertent selection of multiple channels. This protection feature can be defeated by switches on Model 7819-MSC, permitting one channel on each scanner to be selected for parallel-channel or matrix operation.

SIZE. WEIGHT: 2 in. high x 9 in. wide x 3-1/2 in. deep (50 x 230 x 90 mm). Net weight, 1-1/4 pounds (0,6 kg).

ACCESSORIES FURNISHED: Model 7021-10 cable, 10 ft. (3m) long.

b. How to Install the MSC.

- 1. Connect a System Interconnect Cable (Model 7021-2 or Model 7021-10) between SCANNER on the Control Unit and TO 780 CONTROL UNIT on the MSC.
- 2. Connect Scanner 1 DIGITAL INPUT and SCANNER 1 input on the MSC, Scanner 2 DIGITAL INPUT and SCANNER 2 input on the MSC, etc.

NOTE

Total length (sum) of all scanner interconnection cables must not exceed 40 feet.

3. Set all slide switches on the MSC to NORMAL.




FIGURE 28. Typical System 1 Multi-Scanner Connection.

6-3. INTERFACE EXTENDER CARD (Model 7819-IEC). This Interface Card is a System I compatible plug-in board that mates with a card-edge connector at Interface Number 1, 2, or 3 on a Control Unit. It permits operation of an Interface (Series 7801) or special-purpose card (Series 7802 and 7813) external to the Model 780 for troubleshooting and repair.

- 6-4. CUSTOM INTERFACE (Model 7802-CIK).
- a. The Custom Interface Card is a System 1 compatible plug-in board for constructing custom interfaces. Provision is made for accessibility to input, output, and control signals (TTL) on the Control Unit.
- b. The printed circuit board accepts up to 20 sixteen-pin wire-wrapped DIP sockets. All internal and external connections are terminated in pads for wire-wrappable post insertion.
- c. Power is available from the Control Unit to supply logic power. Circuit tapes are provided for power and ground distribution.
- d. Due to the card structure the CIK can be installed at Interface Number 3 or Interface Number 1 (if Interface Number 2 is empty). Clearance for wire-wrappable pins prohibits installation of a CIK in Interface Number 2.
- e. Typical mating components which may be used with the Model 7819-CIK include the following.
 - 1. Wire-wrappable 14-pin DIP socket, Ampheno! part no. 82120013-144 (not furnished).
 - 2. Wire-wrappable 16-pin DIP sockets, Amphenol part no. 82120013-164 (not furnished).
 - 3. PC-mountable 50-pin ribbon-cable header, Keithley part no. CS-311 (not furnished).
 - 4. Wire-wrappable terminals, Vector T44-1 (not furnished).

NOTE

No active electronic components are furnished with the CIK.

SPECIFICATIONS, MODEL 7802-CIK

GENERAL: PC board for convenient construction of custom interfaces. Provides access to System 1 input, output, and control signals (TTL).

COMPONENT MOUNTING: PC board accepts up to 20 sixteen-pin wire-wrappable DIP sockets. All internal and external connections terminated in pads for wire-wrappable post insertion.

CONNECTORS:

INTERNAL: 50-pin gold-plated card edge mates with connector in Model 780 Control Unit.

EXTERNAL: Provision for PC mounting of 50 conductor ribbon-cable header $(3M^R)$ Model 3426-0000), or metal mounting plate may be machined to accept a connector.

POWER AVAILABLE: Logic power; +5 volts referenced to PCU ground, 0.5 amperes maximum. Power and ground are distributed on board.

SIZE, WEIGHT: 4-1/2 in. \times 9 in. (115 \times 230 mm) printed circuit card. Depth with wire-wrappable posts installed limits mounting to slot 3 in Model 780, and slot 1 if slot 2 is not used. Net weight, 3 ounces (85 g).

ACCESSORIES FURNISHED: Card latch/pull assembly and external connector mounting plate are attached.

f. Limitations on Signal Lines.

- 1. Output Lines. In general, each Output line can drive a maximum of three TTL loads. The Slot Address (SA) lines can drive up to eight TTL loads. If more drive capability is needed, a buffer can be used, consisting of two 7404 Series inverters connected in series.
- 2. Input Lines. The data input lines must be driven with open collector gates. Use 7401 Series Quad 2-Input NAND gates for DIL2 through DIH8. Use a power gate such as an MC858 to drive DIL1. The data input line drivers must be disabled when they are not actively driving the lines.

NOTE

Pull-up resistors are furnished on the pc board in the Control Unit for DILI-DIH8 lines.

- g. Limitations on +5V Power Supply. The Model 7802-CIK may draw a maximum of 0.5 ampere.
- h. Custom Interface Design. Since an interface used with the System 1 involves both 1/0 Handler Software and interface circuitry (hardware), the designer should be thoroughly familiar with contents of the following manuals.
 - 1. INSTRUCTION MANUAL, Control Unit, Model 780
 - 2. PCU PROGRAMMING TECHNIQUES
 - 3. PCU ADVANCED PROGRAMMING

NOTE

An interface design such as any series 7801 Interface may be used as an example when designing a custom interface.

6-5. DUAL CONTROL UNIT COUPLER (Model 7819-DCC). The DCC is a field-installable accessory that may be used to expand any System 1 for use with two Control Units. The DCC provides a 37-pin connector into which a second Control Unit may be plugged. (See pages 2-4 and 2-5 for detailed installation instructions.)




FIGURE 29. Custom Interface (Model 7802-CIK)

SECTION 7. REPLACEABLE PARTS

- 7-1. GENERAL. This section contains information for ordering replacement parts. The parts list is arranged in alphabetical order of their Circuit Designations.
- 7-2. ORDERING INFORMATION. To place an order or to obtain information concerning replacement parts, contact your Keithley representative or the factory. See the inside front cover of the catalog for addresses. When ordering, include the following information.
 - a. Instrument Model Number
 - b. Instrument Serial Number
 - c. Part Description
 - d. Circuit Designation (if applicable)
 - e. Keithley Part Number.
- 7-3. SCHEMATICS.
- a. Control Unit, PC-383, PC-395. Schematic Number 27007E describes all Control Unit circuitry including the Scanner interface.
- b. Instrument Interfaces. Schematics for all accessory interfaces are found in the individual INSTRUCTION MANUAL for Series 7801, 7802, and 7813 interfaces.
 - c. Multi-Scanner Coupler (Model 7819-MSC). Schematic 27357D

TABLE 7-1.
PC Board Designation Series

| Description | Designation | Page No. | |
|---------------------|---------------------|----------------------------|--------------------------------|
| Control Unit, Logic | PC-395 | 7-5 | |
| Display Board | PC-383 | 7-5 | |
| | Control Unit, Logic | Control Unit, Logic PC-395 | Control Unit, Logic PC-395 7-5 |

TABLE 7-2.
Mechanical Parts List

| ltem No. | Description | Qty. Per Assembly | Keithley Part No. | Figure No. |
|--------------------------------------|------------------------------------|----------------------|----------------------|------------|
| - | Chassis Assembly | - | | 30 |
| - | Front Panel Assembly | _ | | |
| 1 | Front Panel | 1 | 26860C | |
| 2 | Screw, Slotted, 6-32 x 3/8 | 4 | | |
| 2 3 4 5 6 7 8 9 | Front Panel Overlay | 1 | 26865C | |
| 4 | Rear Panel | | 26892C | |
| 5 | Side Extrusion Left | 1 | 24378B | |
| 6 | Side Extrusion Right | 1 | 24378B | |
| 7 | Corner Bracket | 2 | 24745B | |
| 8 | Screw, Socket, $6-32 \times 1/4$ | 4 | | |
| 9 | Screw, Phillips, $6-32 \times 1/4$ | 4 | | |
| 10 | Clip for Side Dress | 2 | FA-101 | |
| 11 | Side Dress Panel | 2 | 24360B | |
| - | Top Cover Assembly | _ | | 30 |
| 12 | Top Cover | 1 | 26875C | |
| 13 | Screw, Socket, 6-32 x 5/16 | 4 | | |
| | Bottom Cover Assembly | _ | 27264B | 30 |
| 14 | Bottom Cover | 1 | 27263C | |
| 15 | Screw, Socket, 6-32 x 5/16 | 4 | | |
| _ | Feet Assembly | _ | | |
| 16 | Molded Foot | 4 | 24322B | |
| 17 | Rubber Foot | 4 | FE-6 | |
| 18 | Tilt Bail | l i | 14704B | |
| 19 | Screw, Phillips, 6-32 | 1 4 | | |
| 20 | Kep Nut, 6-32 | 4 | | |




FIGURE 30. Chassis Assembly

TABLE 7-3.
Cross-Reference of Manufacturers

| St. Louis, MO 63107 Phoenix, AZ 85008 | ABREV. | NAME AND ADDRESS | ABREV. | NAME AND ADDRESS |
|--|--------|---------------------------------------|--------|---|
| BERG Berg Electronics, Inc. New Cumberland, PA 17070 BUSS Bussmann Mfg. Div. St. Louis, MO 63107 C-W Continental-Wirt Electronics Corp. Warminster, PA 18974 CAN ITT Cannon Electric Santa Ana, CA 92702 CENLB Centralab Division Milwaukee, WI 53201 COMPI Components, Inc. Beddeford, ME 04005 ECI Electrocube Inc. San Gabriel, CA 91776 ERIE Erie Technological Products, Inc. Erie, PA 16512 H-P Hewlett-Packard MOLEX Molex Downers Grove, IL 60515 MOT Motorola Semiconductor Productor Product | A-B | · · · · · · · · · · · · · · · · · · · | KI | |
| BUSS Bussmann Mfg. Div. St. Louis, MO 63107 C-W Continental-Wirt Electronics Corp. Warminster, PA 18974 CENLB Centralab Division Milwaukee, WI 53201 COMPI Components, Inc. Beddeford, ME 04005 ECI Electrocube Inc. San Gabriel, CA 91776 ERIE Erie Technological Products, Inc. Erie, PA 16512 Downers Grove, IL 60515 MOT Motorola Semiconductor Product Phoenix, AZ 85008 MOT Motorola Semiconductor Corp. Mational Semiconductor Corp. Santa Clara, CA 95051 REI Richey Electronics, Inc. Nashville, TN 37213 S-C Switchcraft, Inc. Chicago, IL 60630 Signetics Corp. Sunnyvale, CA 94086 SOL Solitron Devices, Inc. Tappan, NY 10983 Texas Instruments, Inc. Dallas, TX 75231 H-P Hewlett-Packard 3M 3M Company Headquarters | ALCO | | MALL | |
| St. Louis, MO 63107 C-W Continental-Wirt Electronics Corp. Warminster, PA 18974 CAN ITT Cannon Electric Santa Ana, CA 92702 CENLB Centralab Division Milwaukee, WI 53201 COMPI Components, Inc. Beddeford, ME 04005 ECI Electrocube Inc. San Gabriel, CA 91776 ERIE Erie Technological Products, Inc. Erie, PA 16512 Phoenix, AZ 85008 NAT National Semiconductor Corp. Santa Clara, CA 95051 Switchcraft, Inc. Chicago, IL 60630 Signetics Corp. Sunnyvale, CA 94086 Solitron Devices, Inc. Tappan, NY 10983 ERIE Erie Technological Products, Inc. Erie, PA 16512 Hewlett-Packard 3M 3M Company Headquarters | BERG | | MOLEX | · · · · · · · · · · · · · · · · · · · |
| Warminster, PA 18974 CAN ITT Cannon Electric Santa Ana, CA 92702 CENLB Centralab Division Milwaukee, WI 53201 COMPI Components, Inc. Beddeford, ME 04005 ECI Electrocube Inc. San Gabriel, CA 91776 ERIE Erie Technological Products, Inc. Erie, PA 16512 H-P Hewlett-Packard REI Richey Electronics, Inc. Nashville, TN 37213 S-C Switchcraft, Inc. Chicago, IL 60630 Switchcraft, Inc. Chicago, IL 60630 Signetics Corp. Sunnyvale, CA 94086 SOL Solitron Devices, Inc. Tappan, NY 10983 Texas Instruments, Inc. Dallas, TX 75231 | BUSS | | мот | Motorola Semiconductor Products Phoenix, AZ 85008 |
| Santa Ana, CA 92702 CENLB Centralab Division Milwaukee, WI 53201 COMPI Components, Inc. Beddeford, ME 04005 ECI Electrocube Inc. San Gabriel, CA 91776 ERIE Erie Technological Products, Inc. Erie, PA 16512 Nashville, TN 37213 S-C Switchcraft, Inc. Chicago, IL 60630 Signetics Corp. Sunnyvale, CA 94086 SOL Solitron Devices, Inc. Tappan, NY 10983 Texas Instruments, Inc. Dallas, TX 75231 H-P Hewlett-Packard 3M 3M Company Headquarters | C-W | | NAT | National Semiconductor Corp. Santa Clara, CA 95051 |
| Milwaukee, WI 53201 COMPI Components, Inc. Beddeford, ME 04005 ECI Electrocube Inc. San Gabriel, CA 91776 ERIE Erie Technological Products, Inc. Erie, PA 16512 H-P Hewlett-Packard Chicago, IL 60630 Signetics Corp. Sunnyvale, CA 94086 SOL Solitron Devices, Inc. Tappan, NY 10983 Texas Instruments, Inc. Dallas, TX 75231 | CAN | | REI | |
| Beddeford, ME 04005 EC1 Electrocube Inc. San Gabriel, CA 91776 ERIE Erie Technological Products, Inc. Erie, PA 16512 H-P Hewlett-Packard Sunnyvale, CA 94086 Solitron Devices, Inc. Tappan, NY 10983 Texas Instruments, Inc. Dallas, TX 75231 3M 3M Company Headquarters | CENLB | | S-C | |
| San Gabriel, CA 91776 ERIE Erie Technological Products, Inc. Erie, PA 16512 H-P Hewlett-Packard Tappan, NY 10983 Texas Instruments, Inc. Dallas, TX 75231 3M Company Headquarters | COMPI | | SIG | |
| Erie, PA 16512 Dallas, TX 75231 Dallas, TX 75231 Brien Dallas, TX 75231 Brien Dallas, TX 75231 Dallas, TX 75 | EC1 | _ | SOL | • |
| | ERIE | | TEXAS | |
| | H-P | | 3M | |

INSTRUCTION MANUAL Control Unit Model 780

CAPACITORS

| Circuit Desig. | Description | Mfr. Code | Mfr. Desig. | Keithley Part No. | Qty. |
|--|---|--|---|--|------------------------|
| C101 C102 C103 C104 C105 | 10000 μF, 15V | MALL COMPI COMPI REI CENLB | TCG103U015N3C3P TD1-20-474-20 TD1-20-474-20 JC6100158P UK16-104 | C-266-10000M C-179-0.47M C-179-0.47M C-210-100M C-238-0.01M | 1 2 - 1 10 |
| C106 C107 C108 C109 C110 | 0.01 μF, 16V, CerD | CENLB CENLB CENLB CENLB | UK16-104 UK16-104 UK16-104 UK16-104 UK16-104 | C-238-0.01M C-238-0.01M C-238-0.01M C-238-0.01M C-238-0.01M | - - - - |
| C111 C112 C113 C114 C115 | 22 μF, 20V, ET | COMPIERIE ERIE ECI ECI | TD1-20-226-20 831-Z5U0-222M 831-Z5U0-222M 625B1A 625B1A | C-179-22M C-22-0.0022M C-22-0.0022M C-201-0.01M C-201-0.01M | 1 2 - 3 - |
| C116 C117 C118 C119 C120 C121 | 0.01 μF , 50V, Metal Poly Carbonate 0.01 μF , 16V, CerD 0.01 μF , 16V, CerD | CENLB CENLB CENLB CENLB | 625B1A UK16-104 UK16-104 UK16-104 UK16-104 DD-681 | C-201-0.01M C-238-0.01M C-238-0.01M C-238-0.01M C-238-0.01M C-64-680P | 1 |
| Circuit Desig. | Description | Mfr. Code | Mfr. Desig. | Keithley Part No. | Qty. |
| CR101 CR102 CR103 CR104 CR105 | Rectifier, 3A, 50V (1N4139) Rectifier, 3A, 50V (1N4139) Rectifier, 75 mA, 75V Rectifier, 75 mA, 75V Rectifier, 75 mA, 75V | SOL TEXAS TEXAS TEXAS | 3A50 3A50 1N914 1N914 1N914 | RF-34 RF-34 RF-28 RF-28 RF-28 | 2 - 3 |
| | DIGITAL | | | | |
| Circuit Desig. | Description | Mfr. Code | Mfr. Desig. | Keithley Part No. | Qty. |
| DS601 DS602 DS603 DS604 DS605 | Pilot Light, Light Emitting Diode Pilot Light, Light Emitting Diode Pilot Light, Light Emitting Diode Pilot Light, Light Emitting Diode Pilot Light, Light Emitting Diode | H-P H-P H-P H-P | HP5082-4494 HP5082-4494 HP5082-4494 HP5082-4494 HP5082-4494 | PL-63 PL-63 PL-63 PL-63 PL-63 | 18 - - - |

DIGITAL DISPLAY (Cont'd)

| Circuit Desig. | Description | Mfr. Code | Mfr. D e sig. | Keithley Part No. | Qty. | | | | | | | | | |
|--|---|--|--|--|-----------------------|--|--|--|--|--|--|--|--|--|
| DS606 DS607 DS608 DS609 DS610 DS611 | Pilot Light, Light Emitting Diode | H-P H-P H-P H-P H-P H-P | HP5082-4494 HP5082-4494 HP5082-4494 HP5082-4494 HP5082-4494 HP5082-4494 | PL-63 PL-63 PL-63 PL-63 PL-63 PL-63 | - | | | | | | | | | |
| DS613 DS614 DS615 DS616 DS617 DS618 | Pilot Light, Light Emitting Diode | H-P H-P H-P H-P H-P | HP5082-4494 HP5082-4494 HP5082-4494 HP5082-4494 HP5082-4494 HP5082-4494 | PL-63 PL-63 PL-63 PL-63 PL-63 | - | | | | | | | | | |
| FUSE | | | | | | | | | | | | | | |
| Circuit Desig. | Description | Mfr. Code | Mfr. Desig. | Keithley Part No. | Qty. | | | | | | | | | |
| F101 | (117V) Fuse, 1/2A, 250V, Slo-Blo 3AG (250V) Fuse, 1/4A, 250V, Slo Blo 3AG CONNEC | LITFU | MDL-1/2A 313-250 | FU-4 FU-17 | 1 | | | | | | | | | |
| Circuit Desig. | Description | Mfr. Code | Mfr. Desig. | Keithley Part No. | Qty. | | | | | | | | | |
| J101 J102 J103 J104 J105 | Card Edge | 3M 3M 3M MOLEX MOLEX | 3415-0000 3415-0000 3415-0000 2139-2 2139-3 | CS-294-2 CS-294-2 CS-294-2 CS-275 CS-287-3 | 3 - - 1 2 | | | | | | | | | |
| J106 J107 J601 J602 | Receptacle, 3-pin, Female | MOLEX BERG BERG BERG | 2139-3 65039-c 20052 20052 | CS-287-3 CS-310 CS-237 CS-237 | - 1 2 - | | | | | | | | | |
| P101 P102 P103 P104 | Not Used | MOLEX | A-2391-2A | cs-288-2 | - - - 1 | | | | | | | | | |
| P105 P106 P107 P108 | Receptacle, 3-pin | MOLEX MOLEX KI KI | A-2391-3A A-2391-4A | CS-288-3 CS-288-4 24249A 24249A | 1 1 | | | | | | | | | |

CONNECTORS (Cont'd)

| Circuit Desig. | Description | Mfr. Code | Mfr. Desig. | Keithley Part No. | Qty. | | | | | | | | | | |
|--|---|--------------------------|--|---|----------------------------|--|--|--|--|--|--|--|--|--|--|
| P109 P110 | Male Pin | KI KI | Modified | 24249A 26744A | - | | | | | | | | | | |
| P111 P112 P113 | Receptacle, 3-pin, "LINE POWER" Connector, 37-pin, Female | CAN | CS-295-1 EAC 301 DC-37P | CS-254 CS-302 24249A | 1 1 - | | | | | | | | | | |
| | TRANSISTORS | | | | | | | | | | | | | | |
| Circuit Desig. | Description | Mfr. Code | Mfr. Desig. | Keithley Part No. | Qty. | | | | | | | | | | |
| Q101 | PNP Transistor, TO-3 Case | мот | 2N5875 | TG-114 | 1 | | | | | | | | | | |
| | RESISTORS | | | | | | | | | | | | | | |
| Circuit Desig. | Description | Mfr. Code | Mfr. Desig. | Keithley Part No. | Qty. | | | | | | | | | | |
| R101 R102 R103 R104 R105 R106 R107 | 33 Ω, 10%, 1/4W, Comp | A-B A-B A-B A-B | CB-330-10% CB-473-10% CB-103-10% CB-330-10% CB-330-10% CB-471-10% CB-471-10% | R-76-33 R-76-47K R-76-10K R-76-33 R-76-33 R-76-470 R-76-470 | 3 1 9 - - 7 | | | | | | | | | | |
| R108 R109 R110 | 470 Ω, 10%, 1/4W, Comp | A-B A-B | CB-471-10% CB-471-10% CB-103-10% | R-76-470 R-76-470 R-76-10K | - | | | | | | | | | | |
| R111 R112 R113 R114 R115 R116 | 470 Ω, 10%, 1/4W, Comp | A-B A-B A-B | CB-471-10% CB-471-10% CB-471-10% CB-271-10% CB-103-10% CB-103-10% | R-76-470 R-76-470 R-76-470 R-76-270 R-76-10K R-76-10K | - - 1 | | | | | | | | | | |
| R117 R118 R119 R120 R121 | 10 KΩ, 10%, 1/4W, Comp | A-B A-B A-B | CB-103-10% CB-103-10% CB-103-10% CB-103-10% CB-103-10% | R-76-10K R-76-10K R-76-10K R-76-10K R-76-10K | - - - - | | | | | | | | | | |
| R601 R602 | 180 Ω, 10%, 1/4W, Comp | A-B A-B | CB-181-10% CB-181-10% | R-76-180 R-76-180 | 18 | | | | | | | | | | |

RESISTORS (Cont'd)

| Circuit Desig. | Description | Mfr. Code | Mfr. Desig. | Keithley Part No. | Qty. | | | | | | | | | | |
|--|---|---|--|--|------------------|--|--|--|--|--|--|--|--|--|--|
| R603 R604 R605 R606 R607 | 180 Ω, 10%, 1/4W, Comp | A-B A-B A-B A-B A-B | CB-181-10% CB-181-10% CB-181-10% CB-181-10% CB-181-10% | R-76-180 R-76-180 R-76-180 R-76-180 R-76-180 | - - - - | | | | | | | | | | |
| R608 R609 R610 R611 R612 R613 | 180 Ω, 10%, 1/4W, Comp | A-B A-B A-B A-B A-B | CB-181-10% CB-181-10% CB-181-10% CB-181-10% CB-181-10% CB-181-10% | R-76-180 R-76-180 R-76-180 R-76-180 R-76-180 R-76-180 | - - - - | | | | | | | | | | |
| R614 R615 R616 R617 R618 | 180 Ω, 10%, 1/4W, Comp | A-B A-B A-B A-B | CB-181-10% CB-181-10% CB-181-10% CB-181-10% CB-181-10% | R-76-180 R-76-180 R-76-180 R-76-180 R-76-180 | - - - - | | | | | | | | | | |
| | SWITCHES | | | | | | | | | | | | | | |
| Circuit Desig. | Description | Mfr. Code | Mfr. Desig. | Keithley Part No. | Qty. | | | | | | | | | | |
| \$101 \$102 \$103 | Toggle Switch, "POWER" | ALCO S-C C-W | MSTZO5N 11D-1139 GG-350-PC-DPDT | SW-271 SW-273 SW-385 | 1 1 1 | | | | | | | | | | |
| | TRANSF | ORMER | | | | | | | | | | | | | |
| Circuit Desig. | Description | Mfr. Code | Mfr. Desig. | Keithley Part No. | Qty. | | | | | | | | | | |
| T101 | Power Transformer, Center-Tapped Secondary | KI | ••• | TR-162 | 1 | | | | | | | | | | |
| | INTEGRATED | CIRCUI | тѕ | | | | | | | | | | | | |
| Circuit Desig. | Description | Mfr. Code | Mfr. Desig. | Keithley Part No. | Qty. | | | | | | | | | | |
| U10! U102 U103 U104 U105 | Hex Inverters TTL, 14-Pin DIP Hex Inverters TTL, 14-Pin DIP Positive NOR Gates, 14-Pin DIP Positive NOR Gates, 14-Pin DIP Hex Inverters TTL, 14-Pin DIP | TEXAS TEXAS TEXAS TEXAS TEXAS | SN7404N SN7404N SN7402N SN7402N SN7404N | 1C-33 1C-33 1C-32 1C-32 1C-33 | 6 - 5 - | | | | | | | | | | |

INTEGRATED CIRCUITS (Cont'd)

| Circuit Desig. | Description | Mfr. Code | Mfr. Desig. | Keithley Part No. | Qty. |
|--------------------------------------|--|---------------------------------------|--|---|-----------------------|
| U106 U107 | Hex Inverters TTL, 14-Pin DIP Positive NAND Gates, Quad 2-Input, | TEXAS | SN7404N | IC-33 | _ |
| U108 U109 | 14-Pin DIP | TEXAS MOT | SN7400N MC858P | 1C-38 1C-52 | 2 6 |
| | 16-Pin DIP | SIG | N74165 | IC-123 | 1 |
| U110 U111 U112 U113 U114 | 8-Bit Parallel Out, Serial Shift Registers, 14-Pin DIP Quad NAND Gate, 14-Pin DIP Quad NAND Gate, 14-Pin DIP Hex Inverters TTL, 14-Pin DIP Dual NAND Schmitt Trigger, 14-Pin | TEXAS MOT MOT TEXAS | SN74164J MC858P MC858P SN7404N | 1C-119 1C-52 1C-52 1C-33 | 1 - - - |
| | DIP | SIG | N7413A | IC-121 | 1 |
| U115 U116 U117 U118 | Quad NAND Gate, 14-Pin DIP Quad NAND Gate, 14-Pin DIP Quad NAND Gate, 14-Pin DIP Positive NOR Gates, 14-Pin DIP | MOT MOT MOT TEXAS | MC858P MC858P MC858P SN7402N | C-52 C-52 C-52 C-32 | - - - |
| U119 | Monostable Multivibrator, 14-Pin | | | _ | |
| U120 U121 | DIP | TEXAS TEXAS | SN74121N SN7475N | 1C-118 IC-36 | 3 2 |
| U122 U123 | 14-Pin DIP | TEXAS TEXAS TEXAS | SN7400N SN7402N SN7402N | 10-38 10-32 10-32 | - - - |
| U124 U125 U126 U127 U128 | Bistable Latches, 16-Pin DIP BCD/Decimal decoder, 16-Pin DIP Quad, 2-Input OR, 14-Pin DIP Quad, 2-Input OR, 14-Pin DIP Decode Counters, 14-Pin DIP | TEXAS TEXAS SIG SIG TEXAS | SN7475N SN7442 N7432A N7432A SN7490N | 10-36 10-51 10-115 10-115 10-37 | - 2 2 - 1 |
| U129 U130 U131 | BCD/Decimal decoder, 16-Pin DIP Hex Inverters TTL, 14-Pin DIP Monostable Multivibrator, 14-Pin | TEXAS TEXAS | SN7442 SN7404N | 1C-51 1C-33 | - |
| U132 | DIP | TEXAS | SN74121N | IC-118 | - |
| 01,52 | DIP | TEXAS | SN74121N | 10-118 | - |
| | VOLTAGE RE | EGULATO | R | | |
| Circuit Desig. | Description | Mfr. Code | Mfr. Desig. | Keithley Part No. | Qty. |
| VR101 | 5 volt Regulator, TO-3 Case | NAT | LM309K | IC-98 | 1 |


INSTRUCTION MANUAL Control Unit Model 780

SECTION 7

End of Section 7
[This page has been intentionally left blank.]

| A B C D E F G H J K L | State of the state | | The state of the s | 9014 | • 11194 • 11194 | | = | OIN CONTRACTOR OF THE PROPERTY | | CIŞI | | | OID | • | 101 | SPI | IN P | 5 | With the second of the second | 6III | 811 | | UISO UISO UISO UISO UISO UISO UISO UISO | L | | SIIS | • SIO3 | UI26 UI27 UII8 UI3 UI3 UI03 | # #, | 90 | NA COLUMN TO THE PARTY OF THE P | REV. 8 | | FIGURE 31. Component Layout For Pt-395. |
|------------------------------|--|----|--|----------|--------------------|-----|-----|--|----------|----------|----------|--|---------|---|-----|-----|-----------|---|---|------|-----|----------|---|---|---------|------|--------|-----------------------------|---------|----|--|--------|----|---|
| COMPONENTS LOCATED ON PC-395 | Circuit Location Desig. Code | 4 | rv v | R117 G-6 | ∞ (| ח כ |) | S103 F-8 | T101 L-7 | U101 B-6 | U102 G-7 | | | | | | U111 F-3 | | יים טיים ציים | | | | | | | | | | | | | | ÷. | on the chassis |
| COMPONENTS | Circuit Location Desig. Code | 工. | <u> </u> | C104 (-3 | U (| ں د | . 0 | щ | | | | | | | | | CR101 J-4 | | | | | P108 G-5 | | | P112 ** | | | | | | R109 H-3 | | | |

7-11



* 0



Keithley Instruments Division / Keithley Instruments, Inc.

28775 Aurora Road / Cleveland, Ohio 44139 / U.S.A. / (216) 248-0400 / Telex: 98-5469 / Telefax: 248-6168

FRANCE: NETHERLANDS: SWITZERLAND: AUSTRIA: ITALY:

WEST GERMANY: Keithley Instruments GmbH / Heiglhofstr. 5 / München 70 / 089-71002-0 / Telex: 52-12160 / Telefax: 089-7100259 GREAT BRITAIN: Keithley Instruments, Ltd. / 1 Boulton Road / Reading, Berkshire RG 2 ONL / 0734-861287 / Telex: 847 047 / Telefax: 0734-863665 Keithley Instruments SARL/3 Allée des Garays/B.P. 60/91124 Palaiseau/Z.I. / 1-6-0115 155/Telex: 600 933/Telefax: 1-6-0117726 Keithley Instruments BV/Avelingen West 49/4202 MS Gorinchem/P.O. Box 559/4200 AN Gorinchem/01830-35333/Telex: 24 684/Telefax: 01830-30821 Keithley Instruments SA / Kriesbachstr, 4 / 8600 Dübendorf / 01-821-9444 / Telex: 828 472 / Telefax: 0222-315366

Keithley Instruments GesmbH / Rosenhügelstrasse 12 / A-1120 Vienna / (0222) 84 65 48 / Telex: 131677 / Telefax: (0222) 84 35 97 Keithley Instruments SRL / Viale S. Gimignano 4/A / 20146 Milano / 02-4120360 or 02-4156540 / Telefax: 02-4121249