



Keithley Instruments, Inc.
28775 Aurora Road
Cleveland, Ohio 44139-1891
440-248-0400 • Fax: 440-248-6168
<http://www.keithley.com>

Contents

Contents	1
General Information	1
Supported Models	1
Installation Instructions	1
v1.06 Release	2
Overview	2
Critical Fixes	2
Non-Critical Fixes	2
Enhancements	3
v1.05 Release	3
Overview	3
Critical Fixes	3
Non-Critical Fixes	3
Enhancements	3
v1.04 Release	3
v1.03 Release	3
Overview	3
Critical Fixes	3
Non-Critical Fixes	4
Enhancements	4
v1.02 Release	4
Overview	4
Critical Fixes	4
Non-Critical Fixes	4
Enhancements	5
v1.01 Release	5
Overview	5

General Information

Supported Models

This release note applies to the Keithley 2100 6 ½ Digit Multimeter.

Installation Instructions

Detailed instructions are included in Chapter 4 of the Model 2100 User's Manual (Document Number: 2100-900-01B). The manual is available on the Product Information CD that ships with the Model 2100 Multimeter and is also available for download from the Keithley website at

<http://www.keithley.com/support/data?asset=50760> . Alternatively, Keithley factory upgrades can be arranged by calling your local Keithley support office.

v1.06 Release

Overview

v1.06 is a maintenance release.

Critical Fixes

Symptom:

False -410 query interrupted error occurs.

Resolution:

Issue has been resolved. -410 query interrupted error is no longer generated when the receive buffer length is equal to response length.

Symptom:

No response sent when the requested return count is between 116 and 239.

Resolution:

Issue has been resolved.

Symptom:

When performing a ZERO calibration, the gain constant saved in flash was incorrect.

Resolution:

Issue has been resolved.

Non-Critical Fixes

Symptom:

SPRTD selection menu shows R-ZERO for the R(0.01°C)

Resolution:

Issue has been resolved. Menu now shows R 0.01°C.

Symptom:

Invalid separator error is generated when extra characters are sent after commands. .

Resolution:

Undefined header reported properly when extra characters are sent after valid commands.

Enhancements

Added calibration test point. -10VDC input 10V, 0.1V, 1V, 100V, 100V calibration at >10G Ohms.

Added command “:INPut:IMPedance:AUTO {OFF|ON}”

v1.05 Release

Overview

v1.05 was a maintenance release. It corrects one critical issue

Critical Fixes

ENG.
DISC.

Symptom:

Model 2100 with version 1.03 firmware does not accept zero calibration.

Resolution:

Update 2100 to accept zero calibration. Any unit with firmware version 1.03 will need to be updated to 1.05 prior to calibration.

Non-Critical Fixes

There were no non-critical fixes included in this release. See the Critical Fixes section for more information about release content.

Enhancements

There were no enhancements included in this release.

v1.04 Release

Overview

Internal working engineering release never formally released.

v1.03 Release

Overview

v1.03 was a maintenance release. It corrects several non-critical issues

Critical Fixes

There were no critical fixes included in this release. See the Non-critical Fixes section for more information about release content.

Non-Critical Fixes

ENG. **Symptom:**
DISC. When the user enters self-test from the front panel, the instrument generates Error +604.

Resolution:

The error is no longer generated when the 2100 performs a self-test.

ENG. **Symptom:**
DISC. When the user selects the FREQ function, the Model 2100 would generate Error +603.

Resolution:

The error is no longer generated when the 2100 performs a self-test.

ENG. **Symptom:**
DISC. The Model 2100 does not return to all default parameters upon receipt of “*RST”.

Resolution:

The Model 2100 restores all power-on default functions and values upon receipt of “*RST”.

Enhancements

There were no enhancements included in this release.

v1.02 Release

Overview

v1.02 was an internal release.

Critical Fixes

ENG. **Symptom:**
DISC. The Model 2100 does not correctly measure temperature in RTD mode when the actual temperature is less than 0 degrees.

Resolution:

The multimeter now correctly measures temperature below 0 degrees.

Non-Critical Fixes

ENG. **Symptom:**
DISC. Response to “*IDN?” does not follow Keithley format standard.

Resolution:

Response to “*IDN” query changed to “KEITHLEY INSTRUMENTS INC.,MODEL 2100 <system version>”.

ENG.
DISC.

Symptom:

When measuring 4W ohms, the multimeter displays “OVLD” if the Sense HI and Sense LO terminals are connected in reverse with respect to the Input HI and Input LO terminals.

Resolution:

The multimeter will now correctly display a negative resistance value when the Sense HI and Sense Lo terminals are connected in reverse with respect to the Input HI and Input Lo terminals.

Enhancements

There were no enhancements included in this release.

v1.01 Release

Overview

This is the initial release, there are no critical problems to document in this version.