

Building a Benchtop PID Controller

Raymond Rogers
Keithley Instruments, Inc.

Proportional, integral, and derivative (PID) control is a feedback control scheme widely used in engineering, science, and industry. The popularity of PID is largely due to its ease of implementation and effectiveness. Motivation for the use of PID stems from its cost-efficiency: a PID controller is never an optimum controller but is good enough in most cases that the added cost and complexity of an optimum controller is not worth the marginal increase in performance. Furthermore, PID control does not require a deep understanding of the underlying workings of a process; all that matters is that some measured process variable can be strongly influenced by some controlled variable.

Although most PID controllers are dedicated instruments designed for controlling specific processes, this white paper explores how to create a PID controller with exceptional performance quickly and easily using standard benchtop test equipment and minimal programming. Today, nearly all process actuators (valves, agitators, heaters, motors, etc.) and process meters are electronic, so the only two instruments required to build a PID controller are a digital multimeter (to measure the process variable) and a power source (to drive an actuator). In fact, many applications require only a voltmeter and a unipolar power supply.

The acronym “PID” is derived from the controller’s constituent elements and how they act on the difference between some desired value or *set point* (SP) of a process variable and that variable’s current value. The process variable (PV) of interest is often referred to as the *measured (or manipulated) variable* (MV). The instantaneous difference between the SP and MV is known as the error; the goal of the PID controller is to eliminate this error. In other words, the controller works to ensure the process is operating in such a way that the measured variable is always at the set point.

A PID controller is made up of three parts: the proportional part, which drives the output in proportion to the instantaneous error; the integral part, which drives the output in proportion to the accumulated error; and the derivative part, which drives the output in proportion to the instantaneous rate of change of the error. Each part has a weighted contribution to the total output signal of the controller. The process of establishing those weights in order to get the best response from the controller is known as *tuning*.

Not every controller requires all three PID elements: some are satisfactory with just the proportional part and many others with just the proportional and integral parts. These controllers are referred to as “P,” “PI,” “PD,” and “PID” in the context of PID control.

Each PID element is combined to create a controller with a unique and desired response. The proportional part acts to eliminate the *present* error. As a result, a “P” controller is the only feasible single-element PID controller. The integral part has a slow response but accounts for process offsets that the proportional part cannot eliminate on its own. The derivative part acts in response to the change in error. If the error is increasing, then the derivative output adds to the total output; if the error is decreasing, then the derivative output subtracts from the total output. The primary effect is that the derivative action responds strongly to quick changes in the error but moderates the measured variable’s approach to the set point.

Tuning the PID controller involves giving each PID element the proper weight in order to introduce desirable effects into the controller response while minimizing the drawbacks of each element. The process to be controlled dictates what is desirable in the controller response. For example, some processes may not accommodate overshoot well, which puts additional limits on the rise time of the measured variable. On the other hand, another process may accept some overshoot, allowing for a quick rise time of the measured variable.

PID Implementation

A DMM, a power supply, and a bit of programming are the only things required to build a benchtop PID controller. Minimal programming experience is required because the PID algorithm is relatively straightforward. A numerical realization of the PID controller will be built upon its individual components. *Figure 1* offers a graphic overview of PID control.




Figure 1. PID process diagram.

The PID controller takes the error as an input parameter and outputs a signal whose magnitude is determined by the sum of the “P,” “I,” and “D” components of the PID controller. Remember that the error is the difference between the desired value of some process variable and that variable’s present value or the set point minus the measured value:

$$e(t) = SP(t) - MV(t)$$

The “P” contribution, $u_p(t)$, is determined by the following relation:

$$u_p(t) = e(t)$$

By similar notation, the “I” and “D” contributions are defined thus:

$$u_I(t) = \int_0^t e(\tau) d\tau$$

$$u_D(t) = \frac{de(t)}{dt}$$

The integral is run from the start of the controller to the present time. The total output, $u(t)$, is the weighted sum of each of the contributions:

$$u(t) = K_p u_p(t) + K_I u_I(t) + K_D u_D(t)$$

where K_p , K_I , and K_D are the gain coefficients for each of the components as indicated by their subscripts. The coefficients are user-supplied parameters and are determined through tuning the controller for a particular use. The process of tuning is addressed in the section titled “Tuning.”




Figure 2. PID component contributions following a set point change from S_0 to S_1 at t_1 .

The proportional component acts on the instantaneous error. The integral component acts on the error accumulated since the beginning of the control loop. The derivative component acts on the instantaneous rate of change of error. *Figure 2* illustrates how these components are calculated.

It is important to note that the phrase “increasing error” could be misleading as to whether the *magnitude* of $e(t)$ is increasing or if $e(t)$ has a positive slope. The derivative component acts on the instantaneous slope of $e(t)$ and can be negative even if the magnitude is increasing, as is the case when the measured variable is deviating more and more above the set point. The potential confusion arises from the fact that error has a sign associated with it; a negative error indicates that the measured variable is above the set point. For the rest of this white paper, “increasing error” means a positive slope of $e(t)$, regardless of what the error magnitude is doing.

The previous equations are realized numerically in this algorithm:

1. Determine the set point of the measured variable.
2. Make a measurement of the measured variable.

3. Measure the present time, call it t_n , and calculate the time difference between the present measurement and the previous measurement: $\Delta t_n = t_n - t_{n-1}$
4. Calculate the error: $e(t_n) = SP(t_n) - MV(t_n)$
5. Determine each of the PID component outputs:
 - a. $u_P(t_n) = e(t_n)$
 - b. $u_I(t_n) = u_I(t_{n-1}) + 3(t_n) * \Delta t_n$
 - c. $u_D(t_n) = \frac{e(t_n) - e(t_{n-1})}{\Delta t_n}$
6. Determine the total PID output from user-supplied gain coefficients:
 - a. $u(t_n) = K_P u_P(t_n) + K_I u_I(t_n) + K_D u_D(t_n)$
7. Begin again from step 1.

Keep two important details about this algorithm in mind. The first is that the loop takes a finite amount of time to iterate through. If that time is controlled, then step 3 is unnecessary because Δt_n is the same for every iteration. Furthermore, the multiplication and division by a fixed Δt_n in steps 5b and 5c are not strictly necessary to carry out because they can be factored out from each term and accounted for in the respective gain coefficients. The second detail is that the loop is continued indefinitely until the controller is turned off.

The numerical integral and derivative presented in steps 5b and 5c are the simplest approximations, that is, a Riemann Sum and a finite difference. Both have first-order error in the time step. It is possible to make closer approximations for a given time step by using the trapezoid rule (for example) for integration or a multi-point approximation for derivation.

The algorithm can be easily adapted to P, PI, or PD controllers by removing the corresponding sub-step(s) in step 5 and the corresponding term(s) in step 6. Each of the three components is computationally and functionally independent, so there are no extra steps required when using less than full PID.

The output of the PID controller has been generalized and abstracted, but in practice it will depend solely on the intended application. For instance, two PID controllers, each from a separate process, may have the same output as determined from step 6. However, the conversion from $u(t_n)$ to some meaningful physically controlled variable (such as voltage or current) in order to drive a reactant flow rate or heating element *is* process dependent.

Some processes require a limit on the output so that the output of the PID does not drive an actuator to failure or cause unnecessary stress. On the other hand, all actuators have physical limits; a valve cannot open any wider than fully open. In these cases, it may be useful

to scale $u(t_n)$ as a ratio to fully open or fully actuated. It is generally easier to work with a PID controller on both the coding and tuning sides if the output is appropriately scaled and limited before tuning. Note that limits on the output must be hardcoded in some fashion.

As mentioned previously, PID controllers are easy to implement, in part because they can be moved quickly from one process to another. The only changes needed will be to select an appropriate output scale, the gain coefficients (via tuning), and maybe the output limits. This modularity is a major reason PID controllers are so widely used.

The standard implementation would make use of a DMM to make voltage or current measurements from an electronic sensor of some sort (a thermocouple, strain gauge, pressure gauge, flow meter, etc.). The measurement would be fed into the PC running the PID algorithm. The algorithm calculates the PID output and converts it to a source value for the power supply. The power supply sources into some sort of electronic actuator (heating element, motor, pump, valve, etc.), which drives the measured variable toward the process set point.

LabVIEW Implementation

Implementing a PID controller via software is the simple matter of realizing the previous algorithm numerically. National Instruments' LabVIEW programming environment is used here to demonstrate a PID controller implementation for two reasons. The first is that LabVIEW is widely used in industry and research and second is that the flowchart-like representation of the code serves well to show how everything fits together. An example PID controller written in LabVIEW is available for download at <http://www.keithley.com/data?asset=57762>.

Figures 3, 4, and 5 show the block diagrams of the “P,” “I,” and “D” components of a PID controller. *Figure 6* shows how all of them fit into a single subVI (a.k.a. a subroutine).




Figure 3. LabVIEW implementation of “P.”




Figure 4. LabVIEW implementation of “I.”




Figure 5. LabVIEW implementation of “D.”




Figure 6. LabVIEW implementation of “PID.”

As **Figure 3** indicates, the proportional component is the simplest; it takes the error and gain coefficient as inputs and multiplies them together. The integral component takes the error, gain coefficient, and time since start as inputs. The time step is accomplished by subtracting the previous timing from the current timing via a feedback node. The integral is kept as a running tally (Riemann Sum) of the error, which is then multiplied by the gain coefficient. The derivative component keeps track of the time in the same way as the integral but also keeps track of the previous error. The change in error is divided by the change in time to approximate the derivative via a finite difference. The smaller subVIs can be used when only a “P” or “PI,” for example, is needed. Otherwise, the total PID subVI is available when all three components are needed.

The PID controller takes in six inputs: the present value (measurement), the set point, the time since the start of the controller, and all three of the gain coefficients. The controller has four outputs: the total output and the output for each of the three components. Each of the six inputs must be supplied, but any of the outputs can be used.

The output of the PID controller is simply a number. That number needs to be converted into something that’s meaningful to the physical system being controlled, such as the source value for the power supply. Furthermore, it is possible that the user may want to limit the source value further to a certain range. Thus, the output of the controller must be mapped to the range to be used.

For example, if the actuator to be controlled is determined to safely accept between 0V and 5V then the number out of the PID controller needs to be mapped to fall within that range. The midpoint of the range also needs to be determined and the controller output mapped so that an output of zero gets mapped to the midpoint.

The midpoint is best defined as the ideal point at which lower source values decrease the measured variable and higher source values increase the measured variable. This poses a problem of definition because the midpoint can very well end up dynamic and dependent on the current state of the system to be controlled, particularly if there are system losses in proportion to the measured variable. One manifestation of this dynamic behavior is what's known as droop (see the section titled "Droop and Windup" for details). Ultimately, the midpoint is an estimate that is close to the ideal point for the majority of system states, particularly in the region of control interest. This is not a big problem because the PID controller is self-regulating and any significant deviation is corrected primarily through the integral term.

The simplest way to map the controller output is to choose an arbitrary maximum, such as 1000. All that is required is to map the output of the controller linearly so that an output of -1000 gives 0V and 1000 gives 5V. The midpoint is determined to be 2.5V and an output of 0 maps to 2.5V. *Figure 7* illustrates various mapping procedures.




Figure 7. PID controller output mapping from a virtual quantity (dimensionless) to a physical quantity (volts, amps). The asymmetric mapping has different slopes before and after the midpoint. Although the example illustrated here is linear, the mapping could take another form, for example, logarithmic or polynomial.

The number 1000 is arbitrary and serves only as a scale basis. The response of the controller is determined from the gain coefficients. Consider that the controller described would have an identical response if the maximum output were to be increased to 10,000 and all the gain coefficients were increased by a factor of 10. The absolute contribution from each of the components is accordingly greater by a factor of 10, but the relative contributions are unchanged, which causes the controller to behave exactly the same as before. Whatever controller maximum is chosen, it should be chosen on the basis of simplifying the mapping procedure.

The final steps are to convert the DMM measured value to a number to feed into the PID controller measurement pin and to format the controller output to a number to send to the power supply. This is done by using Instrument I/O and string to/from number conversions. The controller is complete (*Figure 8*) when the set point and gain coefficients are supplied.




Figure 8. Full PID Controller employing a Keithley Model 2000 DMM to monitor the measured variable and a Keithley Model 2200 Power Supply to power the actuator. The subVI shown in Figure 6 is the KI-PID block seen in the center here. An example PID controller written in LabVIEW is available for download at <http://www.keithley.com/data?asset=57762>.

Tuning

Although implementing the PID controller is relatively straightforward, tuning the controller is a more open-ended aspect of PID control. Tuning is not a simple process because it requires understanding how each of the PID components affects the response. A poorly designed PID controller will display one or more of the following performance problems: oscillation, poor damping, overshoot, slow rise/fall times, kick, droop, and excessive windup. This section describes each of these problems and their primary causes.

Oscillation

Oscillation is one of the more complicated performance issues and can be the result of several factors. The most common cause is too large a proportional gain (**Figure 9**) for the loop iteration rate (frequency) of the PID controller. A second cause is a mostly integral controller; the proportional acts as a dampener in this case. Thirdly, and easily overlooked, is that the physical system being controlled could be oscillatory in nature and the PID controlling this system may have to accept some oscillation. This does not necessarily indicate a poor PID controller.




Figure 9. Measured variable response to proportional gain coefficient.

An integral-heavy PID controller will also oscillate (*Figure 10*) because the error accumulated while the measured variable is below the set point takes time to correct while the measured variable is over the set point. The integral component then starts to accumulate error in the opposite direction, which will not be corrected until the measured variable crosses the set point again. The proportional component will act as a dampener in this situation.




Figure 10. Oscillation due to high integration gain coefficient.

The frequency of the controller is the rate at which the control loop operates and the power supply output is updated once per cycle. This single-update behavior can be problematic if the proportional gain is too high. A small error produces a large output, which causes a large change in the measured variable, even in one cycle. If that change takes the measured variable past the set point, then the output reverses polarity for the next cycle. If the measured variable keeps jumping across the set point from cycle to cycle, then the controller is oscillating. If the gain is high enough and causes the measured variable to jump across with increasing error magnitude, then the controller is deemed unstable. The quickest fix is to lessen the proportional gain. However, increasing the controller frequency, if possible, will help as well.

This is an inherent limitation of a digital controller; there will always be some degree of oscillation. In addition to the loop frequency issue already described, the output of the power supply can only be resolved to some finite value and nothing smaller. The problem then becomes a question of how much can the oscillation be reduced. A perfectly continuous controller would not have this problem because the output is continually updating along with the changing error. However, oscillation from frequency limitations still occurs in analog PID control. Such controllers are analog circuits and they still have an effective operation frequency resulting from reactive components that cause a time lag between output and input.

Oscillation due to a high integral gain can be reduced either by reducing the integral gain (the obvious solution) or by increasing the proportional gain (not immediately obvious). The proportional action will dampen the oscillations caused by the integral action. This example showcases the difficulty of tuning and the user must decide which characteristics of controller responses are required, desired, and unacceptable. Each characteristic has a tradeoff associated with it and the priority of the controller characteristics should be established before attempting to tune the system.

Droop and Windup

Most physical systems have some sort of parasitic mechanism that causes a loss or reduction of the measured variable. For example, a heater/cooler system must take heat loss/gain through system boundaries into consideration. The effort of a proportional-only control system will always reduce to the point where the controller output is just enough to bring the measured variable to the set point minus system losses. This point is where the controller output is not enough to change the error but just enough to keep it constant – a steady-state error, in other words. This phenomenon, known as *droop* (**Figure 11**), prevents the measured variable from reaching the set point. Despite the term “droop,” the offset can be either below or above the set point as it depends on the state of the physical system being controlled.




Figure 11. PID “droop.”

One’s first instinct might be to increase the proportional gain in an attempt to lessen the droop amount. But that is all increasing the proportional gain will do; a proportional-only controller will always encounter droop because there is nothing to account for system losses. For some systems, a small droop may be acceptable and a proportional-only controller remains useful. For other systems, droop is undesirable and increasing the proportional gain may introduce more problems, such as oscillation and set point overshoot.

The heater/cooler mentioned previously represents a generic temperature control system, complete with boundaries and temperature differences across them. Accurately controlling the system temperature and accounting for droop may require a complicated algorithm relating temperature gradients and time constants. Alternatively, the proportional-only controller may expand to a PI controller and allow the integral component to account for droop (*Figure 12*). The output of the controller will continually increase (or decrease) while the measured variable is less than (or greater than) the set point. The integral component builds up a “buffer” and establishes it as an offset of the controller output that compensates for system losses.




Figure 12. Integration correction to droop.

The time required for the integral component to build this buffer from the start of the controller is known as *windup*. There may also be a significant windup period following a large set point change because the integral offset required at one set point is different than the offset required at another set point. Some control systems start a control loop with a non-zero addition to the integral term in an attempt to reduce the initial windup.

A large set point change can also induce a long windup. This effect can be reduced by stopping the integral mechanism from accumulating while the output is already at an extremum. This is because the integral term is not affecting the output but is still accumulating error, which will have to be cancelled out later.

Rise Time and Overshoot

The rise (or fall) time of the measured variable is the time it takes for the measured variable to reach the set point following a change. A fast rise time is desirable for obvious reasons, but too fast a rise time will cause an overshoot of the measured variable across the set point. The overshoot may then result in damped oscillation as the measured variable settles out to the set point. For some applications, some overshoot is an acceptable tradeoff for a short rise time.

For others, no overshoot can be tolerated and carefully selecting the PID component gains can produce the fastest rise time with no overshoot.

Rise time is principally affected through the proportional and derivative gains. The derivative action responds strongly to an abrupt change but slows the approach to the set point. The integral component doesn't affect rise time appreciably because of its error accumulation nature but can cause overshoot. Furthermore, as described previously, a large integral gain will cause oscillation.

The rise time is typically defined as the time for the variable of interest to rise from 10% of the final value to 90% of the final value. This is the definition used here.

Disturbance Robustness

A disturbance occurs when anomalies in any of the process variables cause an abrupt or unusual change in the measured variable, such as a pipe burst in a feedstock that causes a dramatic drop in vessel pressure (the measured variable). A malfunction of a pre-heating phase in a process, which causes the system temperature to droop much lower than during normal operation, is another typical example. Disturbance robustness is then a property of a PID controller to handle these changes effectively.

Disturbances may or may not be accounted for in a process scheme. This means that a controller attempting to control a process without a feedback loop would certainly fail to account for a disturbance simply because it is difficult to consider every possible source of a disturbance. One of the biggest advantages of a PID controller is that it can be tuned to reject disturbances, even if they originate with something seemingly unrelated (or unconsidered) to the process at hand.

An abrupt change in the measured variable can be viewed as functionally equivalent to a step change of the set point (*Figure 13*). Therefore, the tuning performed to ensure the best response to a step change of the set point will do much the same for disturbance rejection. This is the case unless the disturbance affects the PID controller's ability to control the measured variable, either because the actuation becomes compromised or the disturbance brings the measured variable near or outside of the actuation boundaries. The burst pipe mentioned previously would be an example of compromised actuation; controlling the pressure inside a breached pipe will surely overtax the pump.




Figure 13. Each peak is either a step change or a sudden disturbance. The two are indistinguishable.

Kick, Noise, and the Derivative Action

Figure 13 displays the usual controller response to a step change or disturbance. The issue to point out is that the response is an abrupt spike. This is known as *kick* and can be undesirable for several reasons: this sort of response may be stressing the power supply or actuator unnecessarily or the controller output could be telling a power supply to force a current into an inductive load, such as a motor. If kick is undesirable, consider one of the following options:

- Hard code a limit to how much the output can change from iteration to iteration. This may not impact the controller performance appreciably if kick is determined to occur on certain extreme conditions. Otherwise, the limit will affect the rise time of the measured variable.
- Consider that the derivative action has the potential to cause a very high kick due to division by a very small time step. The solution may be to remove the derivative component completely.

A related problem, particularly with the derivative action, is that of noise. The small rapid changes in the measured variable can be magnified to large controller responses solely from

the derivative action. The problem is that the derivative term needs to be large enough to have an appreciable effect on the controller output, but the larger the derivative term is, the more adversely it amplifies noise. The easiest solution is to include a dead-band of error change to which the derivative component does not respond, that is, has a set output of zero.

Frequency

The control loop frequency is understood to be the rate at which a control loop operates. The inverse is the period (T) and corresponds to the time in between iterations of the loop. Frequency is an important parameter because it determines what kind of systems the PID loop can adequately control. Consider that every physical system has a time constant associated with the measured variable. In other words, how fast does the measured variable change with an associated change in the actuator?

This is important because, if the period of the PID loop is much greater than the time constant of the measured variable, then the measured variable will not be able to be brought to the set point, if at all, on an order of time faster than T. For instance, if the output is determined to increase the measured variable for the next T seconds, then the measured variable will be increasing by some rate associated with the system's time constant. The measured variable might very well overshoot the set point in that time, possibly drastically. The output will not be updated until the next iteration, which will then respond to decrease the measured variable for the following T seconds. The end result is an oscillation and the only way to reduce, but not eliminate, this oscillation is to have the controller respond weakly (low gain coefficients) to the error. In effect, this increases the time constant of the physical system to the period of the control loop and the potential for fast control is wasted.

If the period is much smaller than the time constant of the physical system, then the controller is over-designed for the application. This doesn't have a drawback in controlling the system, per se, but the controller itself may be more expensive or harder to build, maintain, and run due to specialized parts, faster clocks, etc.

The period of a control loop can be determined from its implementation. To first approximation, the period is equal to the slowest running part of the entire system, be it the meter, power supply, actuator, etc. If the power supply takes 100ms to respond to commands from a host PC running a software PID, then the period is 100ms, assuming the meter and PID loop itself can respond quicker. The software loop can certainly run faster, but the power supply won't be changing any quicker than once every 100ms.

The best way to tune a PID controller is first to decide which kind of control response is desired. Is a fast rise time needed? Can there be any oscillation? Is the process to be controlled too fast for my equipment? Start by using only the proportional component and then add in the

integral and derivative as the proportional-only inadequacies become apparent. A well-tuned PID controller is an effective and simple solution to many process control needs.

Temperature Control Example

This example describes the implementation of a simple PID scheme that employs a Peltier device, a J-type thermocouple, a Keithley Model 2000 DMM, a Keithley Model 2200-20-5 power supply unit, and the PID algorithm as run on a National Instruments' LabVIEW application. It allows controlling temperature to within $\pm 0.05^\circ\text{C}$ under most operating conditions with just a J-type thermocouple and no shielding of the signal line. The implementation is a temperature controller that consists of the Peltier device sandwiched between a bottom aluminum plate and an insulator. The bottom plate is contained within an ice-water bath and the PID loop controls the temperature of a small aluminum plate underneath the insulator (*Figure 14*). This example demonstrates the effectiveness of a PID loop, even when run from a PC.

The DMM is used to collect voltage measurements from the thermocouple. These readings are internally converted to temperature measurements, which are fed as the measured variable into the PID loop running on the LabVIEW application. The loop then compares these measurements against the user-supplied set point and an appropriate output is determined via the PID algorithm. The output is converted to a current to be sourced by the power supply into the Peltier device. The current ranges between 0A and 5A.




Figure 14. The heat sink is kept at a constant temperature by placing it in an ice bath.

Some details about the PID system require clarification. For example, the Model 2200-20-5 is a unipolar power supply, which is not necessarily a problem, but it does mean that the top aluminum plate will have to cool passively. The concern is the rate of passive cooling vs. that of active heating. The difference can be significant unless the region of control is chosen such that the control midpoint is the center of the power supply's output

range, namely 2.5A. This occurs at about 80°C for this system. At this temperature, any current less than 2.5A fed into the Peltier will cause the top plate to cool down. In other words, active heating and passive cooling are symmetric about 2.5A at this temperature.

The second detail is that the PID loop is operating at 20Hz or 50ms per cycle. The rise time associated with this system is several seconds, which is much longer than the PID loop period. The loop period could be increased to about one second before any significant performance degradation becomes apparent.

The last detail is that the PID output is linearly mapped so that an output of -1000 correlates to 0A and an output of 1000 correlates to 5A. This gives the 0A to 5A range with a 2.5A midpoint described previously. The ± 1000 output of the controller dictates the order of magnitude of the gains. Again, be aware that these numbers are completely arbitrary; the output could have been mapped to ± 100 instead and the gains seen in the following figures would be ten times less for identical responses.

A dead-band for the derivative action and a controlled accumulator for the integral action were implemented as discussed in the “Tuning” section as a way to reduce the derivative response to noise and the integral windup respectively. The dead-band has a user-settable threshold and the integral does not accumulate error if the controller is already operating at maximum output.




Figure 15. Temperature controller proportional-only droop.

The PID controller is run at several different gain coefficients in order to demonstrate tuning and the problems involved in it as discussed in the “Tuning” section. **Figure 15** illustrates the primary problems associated with a P-only controller: droop and oscillation. Increasing the proportional gain only reduces the droop; it will never eliminate it. Furthermore, too high a proportional gain will introduce oscillation into the response. The rise time is approximately nine seconds.




Figure 16. *Temperature controller integral correction to droop.*

Figure 16 shows how adding even a small integral gain will correct the droop of a proportional-only controller. The speed of this correction depends strongly on the integral gain. The rise time of the PI trace is about nine seconds, but the settling time from the overshoot extends for more than a minute.




Figure 17. Temperature controller integral heavy oscillation.

Figure 17 demonstrates that a moderate integral gain will quickly correct droop, but adding too much will introduce oscillations. One of the best responses seen for this controller was the black trace (Kp 400, Ki 50). The rise time of this trace is approximately nine seconds and the measured variable settles to 1% of the set point in approximately six seconds after the rise time. The response settles to within $\pm 0.05^{\circ}\text{C}$ of the set point after about eleven more seconds.




Figure 18. Temperature controller derivative damping.

Figure 18 shows how a derivative gain slows the approach to the set point. A high derivative gain will introduce artifacts into the response, resulting from the derivative action on noise. These artifacts can easily lead to system instability because the change resulting from a derivative action against a noise spike will cause the derivative action in the next loop iteration to be stronger and so on. The red trace (Kp 600, Kd 600) shows that the artifacts will emerge randomly and can be sustained for upwards of a second. The controller would be significantly less stable without the dead-band mentioned previously.

Specifications are subject to change without notice. All Keithley trademarks and trade names are the property of Keithley Instruments, Inc.
All other trademarks and trade names are the property of their respective companies.



A Greater Measure of Confidence

KEITHLEY INSTRUMENTS, INC. ■ 28775 AURORA RD. ■ CLEVELAND, OH 44139-1891 ■ 440-248-0400 ■ Fax: 440-248-6168 ■ 1-888-KEITHLEY ■ www.keithley.com

BENELUX
+31-40-267-5506
www.keithley.nl

FRANCE
+33-01-69-86-83-60
www.keithley.fr

ITALY
+39-049-762-3950
www.keithley.it

MALAYSIA
60-4-643-9679
www.keithley.com

SINGAPORE
01-800-8255-2835
www.keithley.com.sg

BRAZIL
55-11-4058-0229
www.keithley.com

GERMANY
+49-89-84-93-07-40
www.keithley.de

JAPAN
81-120-441-046
www.keithley.jp

MEXICO
52-55-5424-7907
www.keithley.com

TAIWAN
886-3-572-9077
www.keithley.com.tw

CHINA
86-10-8447-5556
www.keithley.com.cn

INDIA
080-30792600
www.keithley.in

KOREA
82-2-6917-5000
www.keithley.co.kr

RUSSIA
+7-495-664-7564
www.keithley.ru

UNITED KINGDOM
+44-1344-39-2450
www.keithley.co.uk

For further information on how to purchase or to locate a sales partner please visit www.keithley.com/company/buy