

Measurement Data Logging with TekBench™ Oscilloscope Control Software

APPLICATION NOTE



Introduction

Over the last few decades, a growing number of colleges and universities have revised their approach to laboratory teaching to help students get ready to face real-world electrical engineering challenges after graduation. As part of this process, instructors are updating many legacy lab experiments by incorporating the latest industrial applications. In this way, the method of managing a project in an industrial setting is also being applied in the project (student) laboratory. In addition, instructors have begun using industrial standards to evaluate their students' designs.

When comparing the design mindsets of students with those of engineers, one of the biggest differences relates to design reliability. For students, the main objective is often to finish a

design that meets the requirements of the assignment, but the design's reliability is often a secondary consideration. In contrast, for engineers, reliability is the most critical aspect of the design, even more important than specifications in many circumstances, because reliability is among the main criteria used when customers make purchasing decisions. All specifications of the design must be tested in a temperature chamber over an extended period over its rated temperature ranges.

This application note describes how to use TekBench™ software and a Tek oscilloscope to perform measurement data logging for evaluating a design's reliability in a room-temperature environment, such as a project laboratory.

Preparation

• TekBench™ software

Visit www.tek.com/tekbench to download the TekBench software and install it on a laptop.* Apply a demo license, which can be accessed via the same page, to activate the software. Until the software is activated, the measurement data logging function can only take 30 minutes' worth of data.

*Minimal operating requirements: Win7 or Win10, dual core 2 GHz CPU or above, 4 G DDR3 RAM or above, 1 GB free hard disk space, 1366x768 screen resolution or above, USB interface.

• Oscilloscope

The list of supported oscilloscopes can be found in the TekBench software under: About-> About. Here, the MDO3102 is used as an example.

• Circuit board

Use a circuit board that can output a Sine signal with **1 MHz** frequency and **1 V** amplitude.

1. Connect the oscilloscope to the circuit board via a probe and adjust the parameters of the oscilloscope to take the measurement shown in **Figure 1**.
2. Open the TekBench application, then connect the oscilloscope to the laptop using a USB cable as shown in **Figure 2**. The application will detect the oscilloscope within a few seconds.




Figure 1: Frequency and amplitude on Channel 1.



Figure 2: Oscilloscope connection.

Configure measurement data logging

3. Double-click the oscilloscope icon to load it into the software application. Then click the Datalog tab to access the measurement data logging interface (**Figure 3**).
4. In the measurement data logging interface (**Figure 4**) click the arrow in the lower right corner to hide the instrument icon, then set up the measurement parameters as listed here:

Select measurement items:

CH1 Frequency and
CH1 Amplitude

Set measurement interval: **60 S**

Set After Elapsed time: **24 Hours**

Click the Start icon (the green arrow in **Figure 4**) to start measurement data logging; it will finish automatically after 24 hours.




Figure 3: Accessing the measurement data logging interface.




Figure 4: Measurement parameter setup.

Analyze the testing results

5. The TekBench application offers three ways to check the results.
 - i. Trend plot: Click the arrows to navigate the test results.

As illustrated in **Figure 5**, the Amplitude value (the purple line) decreased after working for around 30 minutes. This might be due to the poor temperature coefficient of the resistor used in the design.




Figure 5: Trend plot.

- ii. List mode: Scroll down to navigate the results or click measurement items to find the max/min value quickly.
 - iii. Histogram: Check the distribution of the measurement results. As shown in **Figure 7**, most of the amplitude values are <math><0.92\text{ V}</math>.

6. Click Export to export the results into a *.csv file, then use Excel to perform further analysis.




Figure 6: List mode.

1	Measurement Data logging		
2	Model	MDO3102	
3	Serial Number:	C028267	
4			
5	Start Time	6/22/2018 20:22:31	
6	Stop Time	6/23/2018 20:22:30	
7	Sample Period	1	
8			
9	Time	CH1-Frequency(Hz)	CH1-Amplitude(V)
10	6/22/2018 20:22:32	1002565	0.998
11	6/22/2018 20:22:33	1002042	0.999
12	6/22/2018 20:22:34	998455	1.001
13	6/22/2018 20:22:35	1001919	1
14	6/22/2018 20:22:36	998817	0.999
15	6/22/2018 20:22:37	999741	1
16	6/22/2018 20:22:38	1000731	1.002
17	6/22/2018 20:22:39	999736	0.999




Figure 7: Histogram.

Conclusion

TekBench software offers tools for intuitive instrument control and automated measurement data logging to help students perform reliability testing on their designs. In addition to helping students reduce the time and effort required to complete their assigned lab assignments, TekBench can help students gain more insights into their designs.

For more information about TekBench software, visit www.tek.com/tekbench.

Contact Information

Australia* 1 800 709 465
Austria 00800 2255 4835
Balkans, Israel, South Africa and other ISE Countries +41 52 675 3777
Belgium* 00800 2255 4835
Brazil +55 (11) 3759 7627
Canada 1 800 833 9200
Central East Europe / Baltics +41 52 675 3777
Central Europe / Greece +41 52 675 3777
Denmark +45 80 88 1401
Finland +41 52 675 3777
France* 00800 2255 4835
Germany* 00800 2255 4835
Hong Kong 400 820 5835
India 000 800 650 1835
Indonesia 007 803 601 5249
Italy 00800 2255 4835
Japan 81 (3) 6714 3086
Luxembourg +41 52 675 3777
Malaysia 1 800 22 55835
Mexico, Central/South America and Caribbean 52 (55) 56 04 50 90
Middle East, Asia, and North Africa +41 52 675 3777
The Netherlands* 00800 2255 4835
New Zealand 0800 800 238
Norway 800 16098
People's Republic of China 400 820 5835
Philippines 1 800 1601 0077
Poland +41 52 675 3777
Portugal 80 08 12370
Republic of Korea +82 2 6917 5000
Russia / CIS +7 (495) 6647564
Singapore 800 6011 473
South Africa +41 52 675 3777
Spain* 00800 2255 4835
Sweden* 00800 2255 4835
Switzerland* 00800 2255 4835
Taiwan 886 (2) 2656 6688
Thailand 1 800 011 931
United Kingdom / Ireland* 00800 2255 4835
USA 1 800 833 9200
Vietnam 12060128

* European toll-free number.

If not accessible, call: +41 52 675 3777

Rev. 090617



Find more valuable resources at TEK.COM

Copyright © Tektronix. All rights reserved. Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supersedes that in all previously published material. Specification and price change privileges reserved. TEKTRONIX and TEK are registered trademarks of Tektronix, Inc. All other trade names referenced are the service marks, trademarks or registered trademarks of their respective companies.

071318.SBG 61W-61442-0

