

**80C12B**  
**Optical Sampling Module**  
**User Manual**



071-2994-00

**Tektronix**



**80C12B  
Optical Sampling Module  
User Manual**

Copyright © Tektronix. All rights reserved. Licensed software products are owned by Tektronix or its subsidiaries or suppliers, and are protected by national copyright laws and international treaty provisions.

Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supersedes that in all previously published material. Specifications and price change privileges reserved.

TEKTRONIX and TEK are registered trademarks of Tektronix, Inc.

## **Contacting Tektronix**

Tektronix, Inc.  
14150 SW Karl Braun Drive  
P.O. Box 500  
Beaverton, OR 97077  
USA

For product information, sales, service, and technical support:

- In North America, call 1-800-833-9200.
- Worldwide, visit [www.tektronix.com](http://www.tektronix.com) to find contacts in your area.

## Warranty

Tektronix warrants that this product will be free from defects in materials and workmanship for a period of three (3) years from the date of shipment. If any such product proves defective during this warranty period, Tektronix, at its option, either will repair the defective product without charge for parts and labor, or will provide a replacement in exchange for the defective product. Parts, modules and replacement products used by Tektronix for warranty work may be new or reconditioned to like new performance. All replaced parts, modules and products become the property of Tektronix.

In order to obtain service under this warranty, Customer must notify Tektronix of the defect before the expiration of the warranty period and make suitable arrangements for the performance of service. Customer shall be responsible for packaging and shipping the defective product to the service center designated by Tektronix, with shipping charges prepaid. Tektronix shall pay for the return of the product to Customer if the shipment is to a location within the country in which the Tektronix service center is located. Customer shall be responsible for paying all shipping charges, duties, taxes, and any other charges for products returned to any other locations.

This warranty shall not apply to any defect, failure or damage caused by improper use or improper or inadequate maintenance and care. Tektronix shall not be obligated to furnish service under this warranty a) to repair damage resulting from attempts by personnel other than Tektronix representatives to install, repair or service the product; b) to repair damage resulting from improper use or connection to incompatible equipment; c) to repair any damage or malfunction caused by the use of non-Tektronix supplies; or d) to service a product that has been modified or integrated with other products when the effect of such modification or integration increases the time or difficulty of servicing the product.

THIS WARRANTY IS GIVEN BY TEKTRONIX WITH RESPECT TO THE PRODUCT IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED. TEKTRONIX AND ITS VENDORS DISCLAIM ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TEKTRONIX' RESPONSIBILITY TO REPAIR OR REPLACE DEFECTIVE PRODUCTS IS THE SOLE AND EXCLUSIVE REMEDY PROVIDED TO THE CUSTOMER FOR BREACH OF THIS WARRANTY. TEKTRONIX AND ITS VENDORS WILL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES IRRESPECTIVE OF WHETHER TEKTRONIX OR THE VENDOR HAS ADVANCE NOTICE OF THE POSSIBILITY OF SUCH DAMAGES.

[W4 – 15AUG04]



---

# Table of Contents

General Safety Summary .....	iv
Environmental Considerations .....	vi
Preface .....	vii
Specifications.....	vii
Manual Structure.....	vii
Related Documentation .....	viii
Getting Started .....	1
Instrument Requirements .....	1
Module Features .....	1
Options and Accessories .....	3
Installation.....	6
Operating Basics .....	9
Usage.....	9
System Interaction .....	10
Front Panel Controls.....	11
Commands from the Main Instrument Front Panel .....	12
Programmer Interface Commands .....	14
User Adjustments .....	14
Optimizing Measurement Accuracy .....	14
Cleaning .....	18
Reference .....	21
Wavelength, Filter, and Bandwidth Selection .....	21
Clock Recovery .....	21
Electrical versus Optical Bandwidth.....	21
Glossary	
Index	

## List of Figures

Figure 1: Module compartments.....	7
Figure 2: Connecting optical cables correctly.....	9
Figure 3: 80C12B optical module front panel.....	11
Figure 4: Vertical Setup dialog boxes (DSA8300).....	13

## List of Tables

Table 1: 80C12B module features .....	2
Table 2: Standard accessories .....	3
Table 3: Available 80C12B filter options .....	3
Table 4: Available 80C12B calibration and warranty options .....	4
Table 5: Optional accessories .....	5

## General Safety Summary

Review the following safety precautions to avoid injury and prevent damage to this product or any products connected to it.

To avoid potential hazards, use this product only as specified.

*Only qualified personnel should perform service procedures.*

While using this product, you may need to access other parts of a larger system. Read the safety sections of the other component manuals for warnings and cautions related to operating the system.

### To Avoid Fire or Personal Injury

**Ground the product.** This product is indirectly grounded through the grounding conductor of the mainframe power cord. To avoid electric shock, the grounding conductor must be connected to earth ground. Before making connections to the input or output terminals of the product, ensure that the product is properly grounded.

**Observe all terminal ratings.** To avoid fire or shock hazard, observe all ratings and markings on the product. Consult the product manual for further ratings information before making connections to the product.

The inputs are not rated for connection to mains or Category II, III, or IV circuits.

Do not apply a potential to any terminal, including the common terminal, that exceeds the maximum rating of that terminal.

**Do not operate without covers.** Do not operate this product with covers or panels removed.

**Do not operate with suspected failures.** If you suspect that there is damage to this product, have it inspected by qualified service personnel.

**Avoid exposed circuitry.** Do not touch exposed connections and components when power is present.

**Wear eye protection.** Wear eye protection if exposure to high-intensity rays or laser radiation exists.

**Do not operate in wet/damp conditions.**

**Do not operate in an explosive atmosphere.**

**Keep product surfaces clean and dry.**

**Provide proper ventilation.** Refer to the manual's installation instructions for details on installing the product so it has proper ventilation.

**Terms in This Manual** These terms may appear in this manual:



**WARNING.** *Warning statements identify conditions or practices that could result in injury or loss of life.*



**CAUTION.** *Caution statements identify conditions or practices that could result in damage to this product or other property.*

**Symbols and Terms on the Product**

These terms may appear on the product:

- DANGER indicates an injury hazard immediately accessible as you read the marking.
- WARNING indicates an injury hazard not immediately accessible as you read the marking.
- CAUTION indicates a hazard to property including the product.

The following symbol(s) may appear on the product:



CAUTION  
Refer to Manual



Protective Ground  
(Earth) Terminal

# Environmental Considerations

This section provides information about the environmental impact of the product.

## Product End-of-Life Handling

Observe the following guidelines when recycling an instrument or component:

**Equipment Recycling.** Production of this equipment required the extraction and use of natural resources. The equipment may contain substances that could be harmful to the environment or human health if improperly handled at the product's end of life. In order to avoid release of such substances into the environment and to reduce the use of natural resources, we encourage you to recycle this product in an appropriate system that will ensure that most of the materials are reused or recycled appropriately.



This symbol indicates that this product complies with the applicable European Union requirements according to Directives 2002/96/EC and 2006/66/EC on waste electrical and electronic equipment (WEEE) and batteries. For information about recycling options, check the Support/Service section of the Tektronix Web site ([www.tektronix.com](http://www.tektronix.com)).

## Restriction of Hazardous Substances

This product has been classified as Monitoring and Control equipment, and is outside the scope of the 2002/95/EC RoHS Directive.

---

# Preface

This manual includes the following information:

- The capabilities of the module
- How to install the module
- How to control signal acquisition, processing, and input/output of information

The latest version of this document is available at the Tektronix manuals Web site ([www.tek.com/manuals](http://www.tek.com/manuals)).

## Specifications

Specifications are located in the specifications and performance verification document for your main instrument. You can download the manual from the Tektronix Web site ([www.tek.com/manuals](http://www.tek.com/manuals)).

To meet measurement specifications, ensure that:

- The instrument was calibrated/adjusted at an ambient temperature between +20 °C and +30 °C.
- The instrument has been operating continuously for 20 minutes within the operating temperature range specified.
- Vertical compensation has been performed with the module installed in the same compartment used when the compensation was performed. Ambient temperature must be within  $\pm 2$  °C of the compensation temperature.
- The instrument must be in an environment with temperature, altitude, humidity, and vibration within the operating limits described in the specifications.

## Manual Structure

This manual contains the following chapters:

- *Getting Started* shows you how to configure and install your optical module.
- *Operating Basics* describes controlling the module using the front panel and the instrument user interface.
- *Reference* provides information on wavelength selection, clock recovery, and optical bandwidth.

## Related Documentation

This document covers installation and usage of the sampling module and its features. For information about the main instrument in which the sampling module is installed, refer to the user documents and online help provided with your main instrument.

---

# Getting Started

The 80C12B Series Optical Sampling Module is a high-performance optical module that supports high bandwidth telecom and datacom standards from 155 Mb/s to 11.7 Gb/s in a single optical sampling module. The module is compatible with the following main instruments (mainframes):

- DSA8300 Digital Serial Analyzer
- DSA8200 Digital Serial Analyzer
- CSA8000, CSA8000B, and CSA8200 Communications Signal Analyzers
- TDS8000, TDS8000B, and TDS8200 Digital Sampling Oscilloscopes

## Instrument Requirements

### DSA8300

- TekScope application software version 6.0.3.X or greater.

Select **Help > About** from the TekScope application Help menu to show your current version.

- Microsoft Windows 7 Ultimate (32 bit) operating system.

### DSA8200, CSA8200, CSA8000B, CSA8000, TDS8200, TDS8000B, and TDS8000

- TekScope application software version 5.1 or greater.

Select **Help > About** from the TekScope application Help menu to show your current version.

- Microsoft Windows XP operating system.

Contact Tektronix Customer Support ([www.tek.com](http://www.tek.com)) for information on how to upgrade your instrument to meet these requirements.

## Module Features

Table 1 lists the 80C12B optical module features. (See Table 1 on page 2.)

The *Operating Basics* section has information on the module controls, connectors, and indicators. (See Figure 3 on page 11.)

**Table 1: 80C12B module features**

<b>Feature</b>	<b>Description <sup>1</sup></b>
Number of input channels	1
Effective wavelength range	700 nm to 1650 nm
Calibrated wavelength settings	850 nm, 1310 nm, 1550 nm
Supported standards or data filtering rates	(See Table 3 on page 3.)
Typical optical bandwidth at optical connector	>12 GHz (available with Options F0, 10G, or 10GP)
Clock recovery	Connect the BUFFERED electrical outputs to a CR175A or CR286A Clock Recovery instrument (purchased separately). (See page 21, <i>Clock Recovery</i> .)
Absolute maximum nondestructive optical input <sup>2</sup>	4 mW average power (850 nm) 2 mW average power (1310 nm, 1550 nm) 10 mW peak power for 60 ms.
Internal fiber diameter	62.5 $\mu$ m/125 $\mu$ m multimode fiber <sup>3</sup>
Optical return loss	>14 dB for multimode fiber >24 dB for single-mode fiber
Output zero	<1 $\mu$ W immediately after dark calibration $\pm 2\%$ $\times$ (vertical offset)
Independent channel deskew	Standard
Offset capability at front of module	Standard
Power meter	Standard

<sup>1</sup> Some values in the table are typical. See the product data sheet or the *DSA8300 Specifications and Performance Verification Technical Reference* for more information.

<sup>2</sup> Optical input powers below maximum nondestructive levels may exceed module input saturation and compression limits.

<sup>3</sup> Compatible with single-mode fiber of equal or smaller diameter.

## Options and Accessories

This section lists the standard and optional accessories available for the sampling modules.

### Standard Accessories

The following accessories are shipped with the module:

**Table 2: Standard accessories**

Item	Part number
80C12B Optical Sampling Module User Manual (this document)	071-2994-XX
Certificate of Traceable Calibration for product at first shipment	Not orderable
SMA male 50 $\Omega$ termination (installed, one per buffered electrical signal output connector)	015-1022-XX
Fiber cleaning kit	020-2494-XX

### Options

**80C12B.** The standard 80C12B module provides user-selected filter options for measuring specified sets of standards. There are three module configurations available:

- **Option 10G** provides Optical Reference Receiver (ORR) filters for all standard rates between 8.5 and 11.7 Gb/s.
- **Options F0 - F12** provide 4 "tributary" filters for standards at data rates from 155 Mb/s to 7.373 Gb/s. Select the four filter options when ordering the module. (See Table 3.)
- **Option 10GP plus any three F1–F12 filters** provides Optical Reference Receiver (ORR) filters for all standard rates between 8.5 Gb/s and 11.7 Gb/s plus the three selected tributary standard rates. (See Table 3.)

---

**NOTE.** Options 10GP and F0 are mutually exclusive, as Option 10GP already includes Option F0.

---

Available 80C12B filter options are:

**Table 3: Available 80C12B filter options**

Option	Description
F0	Unfiltered 12 GHz bandwidth
F1	OC-3/STM-1 (155.52 Mb/s)
F2	OC-12/STM-4 (622 Mb/s)

**Table 3: Available 80C12B filter options (cont.)**

Option	Description
F3	FC1063 (1.0625 Gb/s)
F4	ENET1250 Gigabit Ethernet (1.250 Gb/s)
F5	FC2125 (2.125 Gb/s)
F6	OC-48/STM-16 (2.488 Gb/s) 2GBE (2.500 Gb/s) INF2500 (2.500 Gb/s)
F7	FEC2.666 Gb/s (2.666 Gb/s)
F8	10GBASE-X4 (3.125 Gb/s) 10GFC-X4 FC-3188 (3.188 Gb/s)
F9	FC4250 (4.250 Gb/s)
F10	INF5000 (5.000 Gb/s)
F11	OBSAI6144 (6.144 Gb/s)
F12	CPRI7373 (7.373 Gb/s)
10GP	FC8500 (8.500 Gb/s) OC-192/STM-64 (9.95 Gb/s) 8GFC (8.500 Gb/s) 10GBASE-W (9.95 Gb/s) 10GBASE-R (10.31 Gb/s) 40GBASE-R4 (10.31 Gb/s) 100GBASE-R10 (10.31 Gb/s) 10GFC (10.51 Gb/s) FEC10.66 (10.66 Gb/s) FEC10.71 (10.71 Gb/s) FEC11.10 (11.1 Gb/s) FC11317 (11.3 Gb/s) Unfiltered 12 GHz bandwidth

**80C12B-10G.** The 80C12B-10G module contains only the 10GP filters and bandwidth.

#### Calibration and Warranty.

**Table 4: Available 80C12B calibration and warranty options**

Option	Description
C3	Three years of calibration service
C5	Five years of calibration service
D1	Calibration data report
D3	Three years of calibration data reports (requires Opt. C3)
D5	Five years of calibration data reports (requires Opt. C3)
R3	Extended repair warranty to three years
R5	Extended repair warranty to five years

**Optional Accessories**

You can order the following accessories for use with the sampling modules. See the Tektronix Web site for the current list of optional accessories:

**Table 5: Optional accessories**

<b>Item</b>	<b>Part number</b>
D4/PC Universal Optical Input (UCI) adapter	119-4514-XX
Biconic UCI adapter	119-4515-XX
FC/PC UCI adapter, APC-108	119-5115-XX
SMA 2.5 UCI adapter	119-4517-XX
SC/PC UCI adapter	119-5116-XX
DIN/PC UCI adapter	119-4546-XX
DIAMOND 2.5 UCI adapter	119-4556-XX
SMA UCI adapter	119-4557-XX
DIAMOND 3.5 UCI adapter	119-4558-XX
ST/PC UCI adapter	119-4513-XX
3.5 male to 3.5 female SMA	015-0552-XX
Slip-on SMA connector	015-0553-XX
CSA8000 & TDS8000 Series Service Manual	071-0438-XX
DSA8300 Service Manual	077-0572-00 (PDF file downloadable from the Tektronix Web site)
DSA8200 Service Manual	071-2049-XX
DSA8300 Specifications and Performance Verification Technical Reference	077-0571-00 (PDF file downloadable from the Tektronix Web site)
80C12B Series Optical Sampling Module User Manual (this document)	071-2994-00

## Installation

### Electrostatic Discharge Cautions



---

**CAUTION.** *The electrical data outputs on the optical module are subject to damage from electrostatic discharge (ESD). To prevent damage from electrostatic discharge, observe the following guidelines:*

*Store the module, with the supplied SMA terminations installed, in a static-free container, such as the shipping container.*

*Whenever you move the optical module from one instrument to another, use a static-free container to carry the optical module.*

*Be sure to only operate the optical module in a static-controlled environment (grounded conductive table top, wrist strap, floor mat, and ionized air blower).*

*Always use a grounded wrist strap (provided with your instrument) when installing, removing, or handling an optical module or making connections.*

*Discharge to ground any electrostatic charge on cables before attaching the cable to the optical module.*

---

### Correct Module Handling Guidelines



---

**CAUTION.** *Take the following precautions to avoid damaging your optical module:*

*Never install or remove a module when the instrument is powered on (front-panel On/Standby power switch is ON).*

*Do not drop the module since damage and misalignment of the photodiode optical assembly can result. Store the module in a secure location when not in use.*

*Place the protective cap(s) on the optical and electrical input connectors when the module is not in use.*

*To prevent loss of optical power or damage to the optical connectors, keep the connectors clean at all times.*

*Check that all connectors, jumpers, and protective caps are clean before connecting them to the module. (See page 18, *Cleaning the Optical Connectors.*)*

---


## Optical Signal Overdrive Caution



**CAUTION.** *Circuitry in the optical module is very susceptible to damage from overdriven signals. Verify that input optical signals are within acceptable power levels for the module.*

## Module Locations

The optical modules fit in the large upper module slots of the instrument. The large compartments support single channel modules, while the small compartments support single or dual channel modules. Eight of the 10 inputs are usable at one time. (See Figure 1.)



**Figure 1: Module compartments**

At least one module must be installed in an instrument to acquire signals.

**NOTE.** *Installing a large module in either large compartment disables some of the small compartment channels. Refer to the instrument Online Help for information about compartment interaction.*

## Installing a Module

1. Power off the instrument using the front-panel On/Standby power switch.
2. Plug the grounding strap into the instrument ground connector, and place the ground strap on your wrist, with contact to skin.
3. Turn the hold-down screws all the way counterclockwise so that they are completely out and the module retaining tab is flush with the edge of the module.
4. Insert the module into a compartment and slowly push it in with firm pressure until it is seated.

5. Turn the hold-down screws clockwise to lock the module in place.
6. Once you have installed the module, power on the instrument. Verify that the module passes power-on tests.

---

**NOTE.** *When first installing a sampling module(s) or after moving a sampling module from one compartment to another, run a module compensation (Utilities > Compensation) to ensure that the instrument meets its specifications. You must also run a compensation if an extender is installed, changed, or removed from a module. (See page 14, Optimizing Measurement Accuracy.)*

*After running compensation, save the new values to retain them; otherwise they are lost when powering off the instrument.*

---

### Removing a Module

1. Power off the instrument using the front-panel On/Standby power switch.
2. Plug the grounding strap into the instrument ground connector, and place the ground strap on your wrist, with contact to skin.
3. Turn the hold-down screws all the way counterclockwise so that they are completely out and the module retaining tabs are flush with the edge of the module.
4. Slide the appropriate large module ejector lever sideways to unseat the module from the mainframe connector.
5. Pull on the hold-down screws to remove the module from the slot.
6. Handle the module appropriately. For example, move it to another slot in the instrument or place it in a static-protected environment for transport or storage.

# Operating Basics

This section contains optical module signal connection and operation information.

## Usage

Handle your optical module carefully at all times.

### Connecting Optical Signals

Keep optical signal connectors clean to preserve the signal integrity. (See page 18, *Cleaning the Optical Connectors*.)


The input of the 80C12B module can couple to any single-mode or multimode dimension not exceeding a core diameter/cladding diameter of 62.5/125  $\mu\text{m}$ . Use UCI (universal connector interface) series adapters to couple alternate cable types to the optical module. Refer to the Tektronix Web site for details.

To connect the fiber optic cable to the module optical input:

1. Line up the key with the slot in the UCI adapter before inserting.



**CAUTION.** Do not insert the connector into the UCI adapter at an angle. Do not insert the connector and then rotate to line up the key with the slot. Either action can damage the UCI adapter.



**Figure 2: Connecting optical cables correctly**

2. Firmly push the cable connector or adapter into the interface ferrule until it reaches the stop. Do not twist the cable while inserting.

3. Firmly tighten the cable connector or the adapter shell. Tighten with finger pressure only.
4. To remove, loosen the cable connector or adapter shell and pull out without rotating or bending the cable or adapter.

### Attenuating Optical Signals

To keep the optical input power to an appropriate level, you may need to attenuate the optical signal. The 80C12B absolute maximum optical signal levels are:

- 4 mW average optical power at 850 nm
- 2 mW average optical power at 1310 nm and 1550 nm
- 10 mW peak at wavelength of highest responsivity



**CAUTION.** To avoid damaging the optical input of the module, attenuate the input optical signal to the absolute maximum optical signal levels listed above.

---

**NOTE.** The 80C12B module can have a somewhat deteriorated response for signals greater than  $800 \mu W_{p-p}$  (1310 nm and 1550 nm) and  $1300 \mu W_{p-p}$  (850 nm). Optical sampling modules can have dynamic ranges exceeded without obvious visual indication on the waveform because the overloaded signal output of the photodetector may still be within the dynamic range of the internal electrical sampler. To ensure accurate measurements, make sure that input signal levels are within allowed ranges.

---

## System Interaction

Your optical module is a part of a larger instrument system. Most optical module functions are controlled automatically by the main instrument. These include such things as vertical scaling and horizontal sampling rate. You do not directly control these parameters; they are controlled for you as you perform tasks on the main instrument. The parameters that you control from the optical module front panel are explained in the *Front Panel Controls* section.

An additional optical module function that you control from the main instrument is external channel attenuation. External Attenuation lets you enter a number representing any external attenuation you have added to a channel.

## Front Panel Controls

The following figure shows the 80C12B front panel. (See Figure 3.)

### Channel Selection

Each channel has a SELECT channel button and an amber channel light. The button operates as follows:

- If the amber channel light is on, the channel is acquiring a waveform.
- If you push the channel button and the channel is not being acquired (for any channel or math waveform), then the instrument activates (turns on) the channel.
- If you push the button and the channel is active as a channel waveform, then the instrument selects the channel waveform.
- If the channel waveform is already selected when you push the channel button, the instrument turns the channel off.




Figure 3: 80C12B optical module front panel

### Optical Input Connector

The optical input connector uses a universal connector interface (UCI) that allows use of many standard fiber-optic female connector styles. Some of the standard UCI interfaces supported are FC, ST, SC, and DIN.

**Outputs** The 80C12B module provides buffered electrical signal outputs. For clock recovery purposes, route this signal to the input of a Tektronix CR175A or CR286A Electrical Clock Recovery instrument, or to an 80A05 Electrical Clock Recovery module installed in the same mainframe.



---

**CAUTION.** *Electrostatic discharge (ESD) will cause permanent damage to electrical outputs. Adhere to standard ESD handling precautions when using the outputs. In particular, make sure to discharge all electrical signal cables or connectors to ground before attaching them to the BUFFERED outputs. To discharge a cable, touch the center pin of the coaxial cable to a grounded conductor (such as the outside ground conductor of the BUFFERED output connector) just before connecting the cable to the module.*

---

---

**NOTE.** *Use 50  $\Omega$  terminations, provided with your optical module, on all unused electrical outputs.*

---

**Hold-Down Screws** Hold-down screws attach the module to the main instrument. Once the hold-down screws are loosened, use the module slot eject levers to remove the module from a powered-down main instrument. Indicators on the hold-down screws point in the direction that the latch is pointing.

---

**NOTE.** *Do not pull on module connectors to remove a module; always use the hold-down screws to pull the module out far enough for you to hold the module and remove it from the instrument.*

---

## Commands from the Main Instrument Front Panel

The Vertical Setup dialog box (click **Setup > Vertical** from the instrument menu) lets you toggle between the basic and optical module vertical setup controls. (See Figure 4.)

Select the channel you want to set in the Waveform section of the dialog box. Then select the Setup Wavelength, Filter, Bandwidth, or Compensate controls in the dialog box to change those settings or to initiate a compensation. Optical modules with the clock recovery option also have source and rate controls in the Trigger dialog box.

Detailed information on these dialog boxes is found in the Online Help of your main instrument.




Figure 4: Vertical Setup dialog boxes (DSA8300)

**NOTE.** The user interface (UI) images in this manual are from the DSA8300 instrument. The DSA8200 UI, although different in appearance, has a similar UI layout as the DSA8300 for most functions.

## Programmer Interface Commands

The remote programming commands for all sampling modules are documented in the *Programmer Guide* accessible from the instrument Help menu.

## User Adjustments

All optical module setups, parameters, and adjustments are controlled by the main instrument. To save, recall, or change any module settings, use the main-instrument menus or front-panel controls. Consult the *Online Help* for your main instrument.



## Optimizing Measurement Accuracy

Performing the following procedures to increase (or maintain) the measurement accuracy of the optical module:

- Run Vertical Compensation
- Clean the Optical Connectors
- Run Dark-Level and User Wavelength Gain Compensations

### Perform Vertical Compensation

Performing a vertical compensation will maximize the accuracy of the automatic measurements you take. This procedure uses internal routines to optimize the vertical offset, gain, and linearity.

Overview	To perform optical compensations	Control elements and resources
<p><b>Prerequisites</b></p> <ol style="list-style-type: none"> <li>1. Install the optical sampling module(s).</li> <li>2. Place dust covers on all optical module channels (or otherwise turn off optical inputs to the module).</li> <li>3. Power on the instrument and allow a 20 minute warm-up before doing this procedure.</li> <li>4. Set the acquisition to run continuously.</li> </ol>	<ol style="list-style-type: none"> <li>5. Select <b>Utilities &gt; Compensation</b> from the application menu bar to open the Compensation dialog box. The Compensation dialog box lists the main instrument (mainframe) and installed sampling modules. The temperature change from the last compensation is also listed.</li> <li>6. Wait until the Status for all items changes from <b>Warm Up to Pass, Fail, or Comp Req'd.</b></li> </ol>	 <p>See the instrument user documentation and online help for details on operating the instrument controls.</p> 

Overview	To perform optical compensations	Control elements and resources
<b>Set save compensation values</b>	7. Click <b>Compensate and Save</b> in the Select Action area. Make sure to save the compensation values. In-memory compensation values are lost when you power off the instrument.	
<b>Select what to compensate</b>	8. Select what to compensate <ul style="list-style-type: none"> <li>■ <b>For DSA8300:</b> You will need to run two compensations to compensate the mainframe and all modules. Select <b>Mainframe</b> and run the compensation, then select <b>All Modules</b> and run the compensation.</li> <li>■ <b>For DSA8200:</b> From the top pulldown list, choose <b>All</b> (default selection) to compensate the main instrument and all installed modules.</li> </ul>	
<b>Run compensation</b>	9. Click <b>Execute</b> to begin the compensation. 10. Follow any on-screen instructions to disconnect inputs and install terminations; be sure to follow static precautions when following these instructions.	
<b>Verify that the compensation routines pass</b>	11. The compensation may take several minutes to complete. Verify that <b>Pass</b> appears as <b>Status</b> for the main instrument and for all sampling modules listed in the Compensation dialog box when compensation completes.	
<b>Compensation fail actions</b>	12. If <b>Fail</b> appears as the <b>Status</b> , rerun the compensation. If <b>Fail</b> status continues after rerunning compensation, and the instrument has passed the 20-minute warm-up period, the module or main instrument may need service. Contact Tektronix Customer Service.	

### Perform Dark-Level and User Wavelength Gain Compensations

Performing a dark-level calibration maximizes the accuracy of the extinction ratio and other optical automatic measurements you take. Performing a User Wavelength Gain compensation optimizes an optical channel for your custom input signal. Use the following procedure to perform either compensation; this procedure applies only to optical modules.

---

**NOTE.** *The user interface (UI) images in this manual are from the DSA8300 instrument. The DSA8200 UI, although different in appearance, has a similar UI layout as the DSA8300 for most functions.*

---



---

**NOTE.** *These procedures compensate the selected module and its current bandwidth or filter selection. The compensation values are not saved when powering off the instrument.*

---


**Overview**

**To perform optical compensations**

**Control elements and resources**

**Prerequisites**


1. Install the optical sampling module in the instrument.  
Set the acquisition system to run continuously.



See the instrument user documentation and online help for details on operating the instrument controls.

**Select the waveform**

2. Use the Vertical buttons to select the channel to compensate.



**Access the dark-level compensation**

3. Click **Setup > Vertical**.

**Run the dark-level compensation**

4. Click the **Dark Level** button under Compensation. Follow the on-screen instructions.
5. Repeat steps 2 through 4 for any additional optical channels that you want to compensate.

If any of the following settings or conditions change after performing a dark level compensation, run another dark level compensation to maintain the measured accuracy.

- Trigger rate setting
- Vertical offset setting
- Filter or bandwidth setting
- Ambient temperature change of more than 1 °C



**Overview**

**Run the user wavelength gain compensation**



**To perform optical compensations**

You can optionally use a custom input signal to compensate an optical channel:

**NOTE.** *You must know the optical power value of the custom signal. Use an independently calibrated average optical power meter to precisely measure and record the custom optical signal power. Then connect the signal to the module using the same fiber cables.*

6. In the Vert Setup dialog box, click the **User Wavelength Gain** button under Compensation. Follow the on-screen instructions.
  - Set the wavelength and power values of the signal to be applied to the channel in the User Wavelength Gain Compensation dialog box.
7. Click **OK** to execute the compensation.
8. Repeat steps 2, 6, and 7 to compensate additional optical channels.

**Control elements and resources**



## Cleaning

**Exterior** The case of the module keeps dust out and should not be opened. Confine cleaning to the front panel of the module. To clean the case, remove the module from the main instrument but first read the entire *Installation* procedure for proper handling of the module. (See page 6.)



**WARNING.** *To prevent injury, power off the instrument and disconnect it from line voltage before performing any cleaning.*

---

Clean the exterior surfaces of the module with a dry lint-free cloth or a soft-bristle brush. If any dirt remains, use a damp cloth or swab dipped in a 75% isopropyl alcohol solution. Use a swab to clean narrow spaces around controls and connectors. Do not allow moisture inside the module. Do not use abrasive compounds on any part of the chassis that may damage the chassis.



**CAUTION.** *To prevent damage, avoid the use of chemical cleaning agents which might damage the plastics in this instrument. Use a 75% isopropyl alcohol solution as a cleaner and wipe with deionized water. Use only deionized water when cleaning the menu buttons or front-panel buttons. Before using any other type of cleaner, consult your Tektronix Service Center or representative.*

---

Do not open the module case. There are no user serviceable components inside the module and cleaning the interior is not required.

### Cleaning the Optical Connectors

Small dust particles and oils can easily contaminate optical connectors and reduce or block the signal. Take care to preserve the integrity of the connectors by keeping them free of contamination.



**CAUTION.** *To prevent loss of optical power or damage to the optical connectors, keep the connectors clean at all times.*

*To reduce the need for cleaning, immediately replace protective caps on the optical connectors when not in use.*

---

Use the following items to clean optical connectors:

- Dry, clean, and dust-free compressed air
- Fiber cleaning cassette and/or tape dispenser cleaner
- Pipe cleaner




**CAUTION.** Clean both ferrule endfaces with a dry cloth tape cleaner (casseted or in a dispenser).

For safe and effective cleaning of the optical male fiber end-face exposed after removing the UCI adapter, Tektronix recommends the following method and tools.

Overview	To clean the optical connectors	Related information
<b>Supplies required</b>	<ul style="list-style-type: none"> <li>■ One compressed air can, such as Tektronix part number 118-1068-01.</li> <li>■ A cleaning tool, such as:                             <ul style="list-style-type: none"> <li>■ a FIS cassette cleaner, (such as FI-6270)</li> <li>■ a FIS tape dispenser cleaner (such as FI-7111).</li> <li>■ an Optipop pipe cleaner (such as F1-6364).</li> </ul> </li> </ul>	Cleaning kits for optical connectors (such as the Tektronix Optical Connector Cleaner part number 020-2494-XX) are available from several suppliers.

**Remove UCI adapter** 1. Loosen the UCI adapter and remove it. This exposes the male fiber end-face behind the UCI connector.




**Clean UCI adapter** 2. Clean contaminants from the inside wall of the hollow female-to-female ferrule alignment tube inside the UCI adapter.

- Use the compressed air can to clean the female input of the UCI adapter end-to-end.
- Pull the pipe cleaner through the UCI adapter.



**CAUTION.** Do not blow compressed air into the female input of the UCI adapter when it is installed on the module.



**Overview**

**To clean the optical connectors**

**Related information**

**Clean fiber input**

3. Advance the fiber cleaning cassette or tape-dispenser cleaner to expose an unused clean section of the lint-free, dry, cleaning surface.
4. Lightly drag the clean, dry, surface of the cleaning tool cloth against the male end-face of the fiber input for a short distance (a centimeter or two).
5. Place the UCI adapter back on the cleaned fiber end-face.



**Dust cap**

6. When the module does not have a fiber cable attached to its input(s), attach the black dust-cap to prevent airborne contaminants from lodging in the female optical input.



**Clean attaching devices**

7. Clean any male fiber end-face input fiber or device that you attach to the UCI input.

Use a similar cleaning method to clean the fiber end-face input fiber or device.

---

## Reference

This section describes available filter selections, clock recovery enabling procedures, and optical bandwidths.

### Wavelength, Filter, and Bandwidth Selection

See Tables 1 and 3 for available wavelength, filter, and bandwidth information. (See Table 1 on page 2.) (See Table 3 on page 3.)

To select the optical wavelength, open the Vertical Setups menu. (See Figure 4 on page 13.)

Select the channel in the Waveform section of the menu. Then select the wavelength of the signal to measure from the Setup Wavelength drop down box.

Use the Signal Conditioning boxes to select the filter and bandwidth appropriate for your optical standard.

For more information, see the Online Help for your main instrument.

### Clock Recovery

The 80C12B module comes standard with buffered electrical signal outputs. Connect the buffered outputs to a CR175A or CR286A Clock Recovery module to obtain a clock recovery signal. Refer to the CR175A or CR286A module user documentation for triggering information.

When connecting cables to the BUFFERED outputs, make sure to torque the connector to the proper value of 56 N•c (5 in-lb) ±2.8 N•c (0.25 in-lb)

Make sure to torque the SMA connector to the proper value when connecting cables to the BUFFERED outputs:

56 N•c (5 in-lb) ±2.8 N•c (0.25 in-lb)

### Electrical versus Optical Bandwidth

Electrical bandwidth is defined as the frequency at which the power out is one half the power out at a frequency near DC. In the voltage domain the power dissipated into a resistive load (such as a 50 Ω termination of a sampler) is the  $V_{\text{RMS}}^2/R$  where  $V_{\text{RMS}}$  is the RMS of the voltage swing seen at the resistive load, and R is the resistance value. The frequency dependent response of a system is typically described using a logarithmic decibel scale. A value expressed in terms of a decibel relative to a reference is defined as:

$$dB = 10 \log \left( \frac{\text{value}}{\text{reference}} \right)$$

For electrical bandwidths the reference of a system is commonly the response of the system to a sinusoidal frequency at or near DC. The point at which the system response (power) is at one half would therefore be:

$$dB = 10 \log \left( \frac{0.5}{\text{response at DC}} \right) = -3 dB$$

In terms of frequency, voltage, and resistance the bandwidth is expressed as:

$$-3 dB = 10 \log \left( \frac{V(f)^2}{R} \div \frac{V(DC)^2}{R} \right)$$

where V(f) is the RMS of the voltage swing response at the bandwidth frequency, and V(DC) is the RMS voltage swing response at a frequency approaching DC. Further math yields  $V(f) = 0.707 V(DC)$ .

The expression is simplified by canceling the R and moving the squared term inside the log expression to a multiple outside the log expression:

$$10 \log \left( \frac{V(f)^2}{R} \div \frac{V(DC)^2}{R} \right) = 2 \times 10 \log \left( \frac{V(f)}{V(DC)} \right) = 20 \log \left( \frac{V(f)}{V(DC)} \right)$$

In the DSA8300, DSA8200, CSA8000 and TDS8000 Series instruments, the vertical units displayed for an optical module are not in volts, but in watts, which are units of power. The optical-to-electrical converter inside the module outputs a voltage the amplitude of which is linearly dependent on the incoming optical power; in this condition the voltage applied at the electrical sampler already represents optical power in its linear form (as opposed to having to square the voltage and divide by R).

For the optical sampling modules, the bandwidth where the displayed optical power is one half that approaching DC is:

$$dB = 10 \log \left( \frac{0.5}{\text{response at DC}} \right) = -3 dB$$

The V(f) is the frequency at which the vertical swing is one half (0.5) the V(DC) (not 0.707). The optical bandwidth therefore corresponds to the electrical bandwidth of -6 dB.

During impulse testing of optical modules, the resulting impulse waveform is converted to a frequency by Fourier transform and the bandwidth is defined as  $-3 dB = 10 \log(\text{vertical swing at frequency}/\text{vertical swing at DC})$ . During reference receiver curve calculation, however, the definition is changed to match the industry standard definition which assumes electrical bandwidths are  $-3 dB = 20 \log(\text{vertical swing at frequency}/\text{vertical swing at DC})$ .

**Bandwidth for Unfiltered  
Frequency Settings**

The curve calculation of frequency response for the unfiltered frequency settings (for example, 2 GHz, 2.5 GHz, 21 GHz, 12.5 GHz, 14 GHz, 20 GHz, 30 GHz, 40 GHz, 50 GHz, 65 GHz, and 80 GHz) uses the definition for dB and optical bandwidth:

$$-3 \text{ dB} = 10 \log(\text{vertical swing at frequency} / \text{vertical swing at DC})$$

**Bandwidth for Reference  
Receiver Settings**

The curve calculation of frequency response for reference receiver settings (FC, GbE, Infiniband, and OC/STM standards) uses the definition of dB and bandwidth that matches the industry standard which assumes electrical bandwidths:

$$-3 \text{ dB} = 20 \log(\text{vertical swing at frequency} / \text{vertical swing at DC})$$



---

# Glossary

## **Accuracy**

The closeness of the indicated value to the true value.

## **Analog-to-Digital Converter**

A device that converts an analog signal to a digital signal.

## **Attenuation**

A decrease in magnitude (for optical systems this is usually optical power) of a signal.

## **Autoset**

A means of letting the instrument set itself to provide a stable and meaningful display of a given waveform.

## **Average Optical Power (AOP)**

The time averaged measurement of the optical power over a much longer time period than the bit rate of the signal.

## **Bandwidth**

The difference between the limiting frequencies of a continuous frequency spectrum. Bandwidth is the frequency at which the power out is one half the power out at a frequency near DC. The range of frequencies handled by a device or system. Bandwidth is a measure of network capacity. Analog bandwidth is measured in cycles per second. Digital bandwidth is measured in bits of information per second. (See page 21, *Electrical versus Optical Bandwidth*.)

## **Channel**

A place to connect a signal or attach a network or transmission line to sampling heads. Also, the smallest component of a math expression. A transmission path between two or more stations.

## **Channel Number**

The number assigned to a specific signal input connector. The top channel of the left-most sampling head compartment of the main instrument is always channel 1, regardless of any repositioning or omission of sampling heads.

## **Clock**

A signal that provides a timing reference.

**Common Mode**

A circumstance where a signal is induced in phase on both sides of a differential network.

**dB**

Decibel: a method of expressing power or voltage ratios. The decibel scale is logarithmic. It is often used to express the efficiency of power distribution systems when the ratio consists of the energy put into the system divided by the energy delivered (or in some cases, lost) by the system. One milliwatt of optical power is usually the optical reference for 0 dBm. The formula for decibels is:

$$dB = 20 \log \left( \frac{V_i}{V_l} \right) \text{ for optical, } db = \left( \frac{P_o}{P_i} \right)$$

where  $V_i$  is the voltage of the incident pulse,  $V_l$  is the voltage reflected back by the load,  $P_o$  is the power out, and  $P_i$  is the power in. (See page 21, *Electrical versus Optical Bandwidth*.)

**dBm**

A logarithmic measure of power referenced to 1 milliwatt (1 mW optical power = 0.0 dBm).

**Degradation**

A deterioration in a signal or system.

**Differential Mode**

A method of signal transmission where the true signal and its logical complement are transmitted over a pair of conductors.

**Digital signal**

A signal made up of a series of on and off pulses.

**Digital transmission system**

A transmission system where information is transmitted in a series of on and off pulses.

**Extinction Ratio**

The ratio of two optical power levels of a digital signal generated by an optical source.  $P_1$  is the optical power level generated when the light source is high, and  $P_2$  is the power level generated when the light source is low.

$$r_e = \frac{P_1}{P_2}$$

**FEC: Forward Error Correction**

Additional bits and/or coding added to a data stream to allow for automatic error detection and correction at the receiving end. These extra bits and/or coding tend to increase a serial data rate above the original nonFEC data stream to accommodate the extra information added by the FEC.

**Fiber Optics**

A method of transmitting information in which light is modulated and transmitted over high-purity, filaments of glass. The bandwidth of fiber optic cable is much greater than that of copper wire.

**Impedance**

The opposition to an AC signal in the wire. Impedance is very much like resistance to a DC signal in a DC circuit. Impedance is made up of resistance, inductive, and capacitive reactance.

**Initialize**

Setting the instrument main instrument to a completely known, default condition.

**Internal Clock**

An internally generated trigger source that is synchronized with the Internal Clock Output signal.

**Mode**

A stable condition of oscillation in a laser. A laser can operate in one mode (single mode) or in many modes (multimode).

**Modulation**

A process whereby a signal is transformed from its original form into a signal that is more suitable for transmission over the medium between the transmitter and the receiver.

**Multimode Cable**

A thick cored optical fiber (compared to single mode cable) that can propagate light of multiple modes.

**OMA (Optical Modulation Amplitude)**

The difference between the average power levels of the logic 1 level, High, and the logic 0 level, Low, of the optical pulse signal. The levels are the Means of the logical levels sampled within an Aperture of the logical 1 and 0 regions of the pulse. The logical 1 and 0 time intervals are marked by the crossings of a reference level determined as the Average Optical Power (AOP) of the signal.

**Protocol**

Formal conventions that govern the format and control of signals in a communication process.

**Recovered Clock**

A clock signal derived from and synchronous with a received data sequence.

**Setting**

The state of the front panel and system at a given time.

**Single-Mode Cable**

An optical cable with a very small core diameter (usually in the range of 2-10 microns). Such cables are normally used only with laser sources due to their very small acceptance cone. Since the cone diameter approaches the wavelength of the source, only a single mode is propagated.

**Trigger**

An electrical event that initiates acquisition of a waveform as specified by the time base.

**Waveform**

The visible representation of an input signal or combination of signals.

# Index

## A

- Accessories, 3
  - list, 3
  - optional, 5
  - standard, 3
- Accuracy, 25
  - optimizing, 14
- Adjustments, 14
- Analog-to-Digital converter, 25
- AOP
  - average optical power, 25
- Attenuating optical signals, 10
- Attenuation, 25
- Autoset, 25

## B

- Bandwidth, 25
  - electrical, description, 21
  - optical, description, 22
  - selection, 21
- BUFFERED connector torque, 21

## C

- Channel, 25
  - number, 25
  - selection, 11
- Cleaning
  - module, 18
  - optical connectors, 18
- Clock, 25
  - recovery, 21
  - recovery outputs, 12
- Clock recovery connector
  - torque, 21
- Common mode, 26
- Compensating a module, 8
- Compensation
  - dark-level, 15
  - vertical, 14
  - wavelength gain, 15
- Connecting optical signals, 9
- Connector torque, 21

## D

- Dark-level compensation
  - how to perform, 15
- Data
  - recovery, 21
- dB, 26
- dBm, 26
- Decibel, 26
- Degradation, 26
- Differential mode, 26
- Digital signal, 26
- Digital transmission system, 26

## E

- Electrostatic discharge cautions, 6
- Extinction ratio, 27

## F

- Features, 1
- FEC, 27
- Fiber optics, 27
- Filter selection, 21
- Forward Error Correction, 27
- Front panel controls, 11

## G

- Getting started, 1

## H

- handling guidelines (module), 6
- Hold down screws, 12

## I

- Impedance, 27
- Initialize, 27
- Input connector, 11
- Installation, 6
- Internal clock, 27

## M

- Main instrument commands, 12
- Manuals
  - part numbers, 3
- Measurement accuracy
  - optimizing, 14
- Mode, 27
- Modulation, 27
- Module features, 1
- Module handling guidelines, 6
- Multimode cable, 28

## O

- OMA
  - optical modulation
    - amplitude, 28
- Operating basics, 9
- Optical
  - dark-level compensation, 15
  - input connector, 11
  - vertical compensation, 14
  - wavelength gain
    - compensation, 15
- Optical input overdrive caution, 7
- Optimizing measurement
  - accuracy, 14
- Optional accessories list, 5
- Options
  - list, 3
- Outputs
  - clock, 12
  - data, 12
- Overdriven optical input, 7

## P

- Procedure
  - perform dark-level compensation, 15
  - perform user wavelength gain compensation, 15
  - perform vertical compensation, 14
- Product description, 1

Programmer interface, 14  
Protocol, 28

## R

Recovered  
    clock, 28  
Reference, 21

## S

Safety Summary, iv  
Sampling head features, 1  
SELECT CHANNEL button, 11  
Setting, 28  
Single-mode cable, 28

SMA connector torque, 21  
Specifications, vii  
Standard accessories, 3  
System interaction, 10

## T

Torque (BUFFERED  
    connectors), 21  
Trigger, 28

## U

Usage, 9  
User adjustments, 14

User wavelength compensation  
    how to perform, 15

## V

Vertical compensation  
    how to perform, 14

## W

Waveform, 28  
Wavelength  
    selection, 21  
Wavelength gain  
    compensation, 15