



## 2 Series Mixed Signal Oscilloscopes MSO22 and MSO24

### Specifications and Performance Verification

**Warning:** The servicing instructions are for use by qualified personnel only. To avoid personal injury, do not perform any servicing unless you are qualified to do so. Refer to all safety summaries prior to performing service.

Revision B

**Register now!**  
**Click the following link to protect your product.**  
**[tek.com/register](https://tek.com/register)**



077-1711-02 July 2023

Copyright © 2023, Tektronix. 2023 All rights reserved. Licensed software products are owned by Tektronix or its subsidiaries or suppliers, and are protected by national copyright laws and international treaty provisions. Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supersedes that in all previously published material. Specifications and price change privileges reserved. All other trade names referenced are the service marks, trademarks, or registered trademarks of their respective companies.

TEKTRONIX and TEK are registered trademarks of Tektronix, Inc.

Tektronix, Inc.  
14150 SW Karl Braun Drive  
P.O. Box 500  
Beaverton, OR 97077  
US

For product information, sales, service, and technical support visit [tek.com](https://www.tek.com) to find contacts in your area.

For warranty information visit [tek.com/warranty-status-search](https://www.tek.com/warranty-status-search).

# Contents

Important safety information.....	4
General safety summary.....	4
To avoid fire or personal injury.....	4
Probes and test leads.....	6
Service safety summary.....	7
Terms in this manual.....	7
Terms on the product.....	8
Symbols on the product.....	8
Specifications.....	9
Analog signal acquisition system.....	9
Triggering system.....	12
Digital channel acquisition.....	14
Digital pattern generator.....	15
Arbitrary function generator.....	15
Processor system.....	17
Display system.....	17
Interfaces, input, and output ports.....	18
Data handling characteristics.....	18
Power supply system.....	20
Safety characteristics.....	20
Mechanical characteristics.....	20
Electromagnetic compatibility.....	21
Environmental.....	24
Regulatory compliance.....	24
Performance verification procedures.....	25
Test records.....	26
Check probe compensation.....	30
Check Aux In.....	31
Check DC gain accuracy.....	31
Check analog bandwidth.....	34
Check digital threshold accuracy with 2-MSO option.....	36
Check long term sample rate.....	38
Check AFG DC offset accuracy.....	39

## Important safety information

This manual contains information and warnings that must be followed by the user for safe operation and to keep the product in a safe condition.

To safely perform service on this product, see the *Service safety summary* that follows the *General safety summary*.

### General safety summary

Use the product only as specified. Review the following safety precautions to avoid injury and prevent damage to this product or any products connected to it. Carefully read all instructions. Retain these instructions for future reference.

This product shall be used in accordance with local and national codes.

For correct and safe operation of the product, it is essential that you follow generally accepted safety procedures in addition to the safety precautions specified in this manual.

The product is designed to be used by trained personnel only.

Only qualified personnel who are aware of the hazards involved should remove the cover for repair, maintenance, or adjustment.

Before use, always check the product with a known source to be sure it is operating correctly.

This product is not intended for detection of hazardous voltages.

Use personal protective equipment to prevent shock and arc blast injury where hazardous live conductors are exposed.

While using this product, you may need to access other parts of a larger system. Read the safety sections of the other component manuals for warnings and cautions related to operating the system.

When incorporating this equipment into a system, the safety of that system is the responsibility of the assembler of the system.

### To avoid fire or personal injury

#### Use proper power cord

Use only the power cord specified for this product and certified for the country of use. Do not use the provided power cord for other products.

#### Ground the product

This product is grounded through the grounding conductor of the power cord. To avoid electric shock, the grounding conductor must be connected to earth ground. Before making connections to the input or output terminals of the product, ensure that the product is properly grounded. Do not disable the power cord grounding connection.

#### Power disconnect

The power cord disconnects the product from the power source. See instructions for the location. Do not position the equipment so that it is difficult to operate the power cord; it must remain accessible to the user at all times to allow for quick disconnection if needed.

#### Use proper AC adapter

Use only the AC adapter specified for this product.

#### Connect and disconnect properly

Do not connect or disconnect probes or test leads while they are connected to a voltage source.

Use only insulated voltage probes, test leads, and adapters supplied with the product, or indicated by Tektronix to be suitable for the product.

Connect the probe output to the measurement instrument before connecting the probe to the circuit under test. Connect the probe reference lead to the circuit under test before connecting the probe input. Disconnect the probe input and the probe reference lead from the circuit under test before disconnecting the probe from the measurement instrument.

De-energize the circuit under test before connecting or disconnecting the current probe.

### **Observe all terminal ratings**

To avoid fire or shock hazard, observe all rating and markings on the product. Consult the product manual for further ratings information before making connections to the product.

Do not exceed the Measurement Category (CAT) rating and voltage or current rating of the lowest rated individual component of a product, probe, or accessory. Use caution when using 1:1 test leads because the probe tip voltage is directly transmitted to the product.

Do not apply a potential to any terminal, including the common terminal, that exceeds the maximum rating of that terminal.

Do not float the common terminal above the rated voltage for that terminal.

The measurement terminals on this product are not rated for connection to Category III or IV circuits.

Do not connect a current probe to any wire that carries voltages above the current probe voltage rating.

### **Do not operate without covers**

Do not operate this product with covers or panels removed, or with the case open. Hazardous voltage exposure is possible.

### **Avoid exposed circuitry**

Do not touch exposed connections and components when power is present.

### **Do not operate with suspected failures**

If you suspect that there is damage to this product, have it inspected by qualified service personnel.

Disable the product if it is damaged. Do not use the product if it is damaged or operates incorrectly. If in doubt about safety of the product, turn it off and disconnect the power cord. Clearly mark the product to prevent its further operation.

Before use, inspect voltage probes, test leads, and accessories for mechanical damage and replace when damaged. Do not use probes or test leads if they are damaged, if there is exposed metal, or if a wear indicator shows.

Examine the exterior of the product before you use it. Look for cracks or missing pieces.

Use only specified replacement parts.

### **Replace batteries properly**

Replace batteries only with the specified type and rating.

Recharge batteries for the recommended charge cycle only.

### **Wear eye protection**

Wear eye protection if exposure to high-intensity rays or laser radiation exists.

### **Do not operate in wet/damp conditions**

Be aware that condensation may occur if a unit is moved from a cold to a warm environment.

## Do not operate in an explosive atmosphere

### Keep product surfaces clean and dry

Remove the input signals before you clean the product.

### Provide proper ventilation

Refer to the installation instructions in the manual for details on installing the product so it has proper ventilation.

Slots and openings are provided for ventilation and should never be covered or otherwise obstructed. Do not push objects into any of the openings.

### Provide a safe working environment

Always place the product in a location convenient for viewing the display and indicators.

Avoid improper or prolonged use of keyboards, pointers, and button pads. Improper or prolonged keyboard or pointer use may result in serious injury.

Be sure your work area meets applicable ergonomic standards. Consult with an ergonomics professional to avoid stress injuries.

Use only the Tektronix rackmount hardware specified for this product.

## Probes and test leads

Before connecting probes or test leads, connect the power cord from the power connector to a properly grounded power outlet.

Keep fingers behind the protective barrier, protective finger guard, or tactile indicator on the probes. Remove all probes, test leads and accessories that are not in use.

Use only correct Measurement Category (CAT), voltage, temperature, altitude, and amperage rated probes, test leads, and adapters for any measurement.

### Beware of high voltages

Understand the voltage ratings for the probe you are using and do not exceed those ratings. Two ratings are important to know and understand:

- The maximum measurement voltage from the probe tip to the probe reference lead.
- The maximum floating voltage from the probe reference lead to earth ground.

These two voltage ratings depend on the probe and your application. Refer to the Specifications section of the manual for more information.



**WARNING:** To prevent electrical shock, do not exceed the maximum measurement or maximum floating voltage for the oscilloscope input BNC connector, probe tip, or probe reference lead.

### Connect and disconnect properly.

Connect the probe output to the measurement product before connecting the probe to the circuit under test. Connect the probe reference lead to the circuit under test before connecting the probe input. Disconnect the probe input and the probe reference lead from the circuit under test before disconnecting the probe from the measurement product.

De-energize the circuit under test before connecting or disconnecting the current probe.

Connect the probe reference lead to earth ground only.

Do not connect a current probe to any wire that carries voltages or frequencies above the current probe voltage rating.

## Inspect the probe and accessories

Before each use, inspect probe and accessories for damage (cuts, tears, or defects in the probe body, accessories, or cable jacket). Do not use if damaged.

## Ground-referenced oscilloscope use

Do not float the reference lead of this probe when using with ground-referenced oscilloscopes. The reference lead must be connected to earth potential (0 V).

## Floating measurement use

Do not float the reference lead of this probe above the rated float voltage.

## Service safety summary

The *Service safety summary* section contains additional information required to safely perform service on the product. Only qualified personnel should perform service procedures. Read this *Service safety summary* and the *General safety summary* before performing any service procedures.

### To avoid electric shock

Do not touch exposed connections.

### Do not service alone

Do not perform internal service or adjustments of this product unless another person capable of rendering first aid and resuscitation is present.

### Disconnect power

To avoid electric shock, switch off the product power and disconnect the power cord from the mains power before removing any covers or panels, or opening the case for servicing.

### Use care when servicing with power on

Dangerous voltages or currents may exist in this product. Disconnect power, remove battery (if applicable), and disconnect test leads before removing protective panels, soldering, or replacing components.

### Verify safety after repair

Always recheck ground continuity and mains dielectric strength after performing a repair.

## Terms in this manual

These terms may appear in this manual:



**WARNING:** Warning statements identify conditions or practices that could result in injury or loss of life.



**CAUTION:** Caution statements identify conditions or practices that could result in damage to this product or other property.

## Terms on the product

These terms may appear on the product:

- DANGER indicates an injury hazard immediately accessible as you read the marking.
- WARNING indicates an injury hazard not immediately accessible as you read the marking.
- CAUTION indicates a hazard to property including the product.

## Symbols on the product



When this symbol is marked on the product, be sure to consult the manual to find out the nature of the potential hazards and any actions which have to be taken to avoid them. (This symbol may also be used to refer the user to ratings in the manual.)

The following symbol(s) may appear on the product.



CAUTION: Refer to Manual



Protective Ground (Earth) Terminal



Earth Terminal



Chassis Ground



WARNING: High Voltage



Breakable. Do not drop.



Standby



Functional Earth Terminal



Use only on an insulated wire.



Connection and disconnection to hazardous bare wire permitted.



Do not connect to or remove from an uninsulated conductor that is HAZARDOUS LIVE.



# Specifications

This chapter contains specifications for the instrument. All specifications are typical unless noted as guaranteed. Typical specifications are provided for your convenience but are not guaranteed. Specifications that are marked with the ✓ symbol are guaranteed and checked in Performance Verification.

To meet specifications, these conditions must first be met:

- The instrument must have been calibrated in an ambient temperature between 18 °C and 28 °C (64 °F and 82 °F).
- The instrument must be operating within the environmental limits. (See [Environmental characteristics](#)).
- The instrument must be powered from a source that meets the specifications. (See [Power supply system](#) on page 20).
- The instrument must have been operating continuously for at least 20 minutes within the specified operating temperature range.
- You must perform the Signal path compensation procedure after the warmup period. See the Signal path compensation procedure for how to perform signal path compensation. If the ambient temperature changes more than 5 °C (9 °F), repeat the procedure.

## Analog signal acquisition system

<b>Analog input channels</b>	MSO22: 2 channel MSO24: 4 channel
<b>Input coupling</b>	AC, DC
<b>Input termination selection</b>	1 M $\Omega$ only
<b>Input termination, 1 M<math>\Omega</math> DC-coupled</b>	1 M $\Omega$ $\pm$ 1%
<b>Input capacitance, 1 M<math>\Omega</math> DC-coupled</b>	14 pF $\pm$ 3 pF
<b>Digitized bits</b>	8 bits Displayed vertically with 25 digitization levels (DL) per division, 10.24 divisions dynamic range. A converter can resolve the smallest voltage level change by using an 8-bit A–D converter. This value is also known as the Least Significant Bit (LSB).
<b>Sensitivity range (coarse), 1 M<math>\Omega</math></b>	1 mV/Div to 10 V/Div in a 1-2-5 sequence
<b>Sensitivity range (fine)</b>	Continuous adjustment from 1 mV/DIV to 10 V/DIV, 1 M $\Omega$ 1x
<b>Sensitivity resolution (fine)</b>	$\leq$ 10% of current setting
<b>Maximum input voltage, 1 M<math>\Omega</math> DC-coupled</b>	Maximum input voltage at the BNC, 300 V <sub>rms</sub> . Installation category II Derate at 20 dB/decade between 3 MHz to 30 MHz Derate at 15.5 dB between 30 MHz to 300 MHz; above 300 MHz, 5 V <sub>rms</sub> Maximum peak input voltage at the BNC: $\pm$ 424 V
<b>✓ DC gain accuracy</b>	Guaranteed for 2 mV/div and above, typical otherwise. Specification valid after 30 minute warm-up and Signal Path Compensation (SPC) at ambient. $<$ 2 mV/div: $\pm$ 3.0%, typical, derated at 0.100%/°C above 30 °C $\geq$ 2 mV/div: $\pm$ 2.0%, derated at 0.100%/°C above 30 °C
<b>Offset ranges</b>	1 mV/div to 63.8 mV/div : $\pm$ 1 V 63.9 mV/div to 999.5 mV/div : $\pm$ 10 V 1 V/div to 10 V/div : $\pm$ 100 V
<b>Position range</b>	$\pm$ 5 divisions

**Offset accuracy** All terms must be converted to volts by multiplying by the current volts/div setting.  
 $>2 \text{ mV/div: } \pm (0.005 \times |\text{offset} - \text{position}| + 0.2 \text{ div})$   
 $\leq 2 \text{ mV/div: } \pm (0.005 \times |\text{offset} - \text{position}| + 0.3 \text{ div})$

**Waveforms for average acquisition mode** 2 to 10.24 k waveforms; default of 16 waveforms

**DC voltage measurement accuracy, average acquisition mode** The basic accuracy specification applies directly to any sample and to the following measurements: high, low, maximum, minimum, mean, cycle mean, RMS, and cycle RMS. The delta volts accuracy specification applies to subtractive calculations involving two of these measurements. The delta volts (difference voltage) accuracy specification applies directly to the following measurements; positive overshoot, negative overshoot, Pk-Pk, and amplitude.

Offset, position, and the constant offset term must be converted to volts by multiplying by the appropriate volts/div term.

The limits are as follows:

Measurement type	DC accuracy (in volts)
Average of > 16 waveforms	$\pm ((\text{DC Gain accuracy}) \times  \text{reading} - (\text{offset} - \text{position})  + \text{Offset accuracy} + 0.1 \text{ div} + 1 \text{ mV})$
Delta volts between any two averages of $\geq 16$ waveforms acquired with the same oscilloscope setup and ambient conditions	$\pm (\text{DC Gain accuracy} \times  \text{reading}  + 0.08 \text{ div} + 1.4 \text{ mV})$

**Bandwidth selections** 20 MHz, 70 MHz, 100 MHz, 200 MHz, 350 MHz, and 500 MHz (when equal to or less than instrument's rated bandwidth)

✓ **Analog bandwidth** Below 5 mV/div, 500 MHz bandwidth is specified as typical.

The limits stated below are for an ambient temperature of  $\leq 30 \text{ }^\circ\text{C}$ . For each degree above  $30 \text{ }^\circ\text{C}$ , reduce the upper bandwidth frequency by 1%.

Instrument bandwidth	Volts/div setting	Bandwidth
70 MHz	1 mV/div – 10 V/div	DC – 70 MHz
100 MHz	1 mV/div – 10 V/div	DC – 100 MHz
200 MHz	1 mV/div – 10 V/div	DC – 200 MHz
350 MHz	1 mV/div – 10 V/div	DC – 350 MHz
500 MHz	$<5 \text{ mV/div}$	DC – 500 MHz
500 MHz	$\geq 5 \text{ mV/div} - 10 \text{ V/div}$	DC – 500 MHz

**Lower frequency limit, AC-coupled**  $<10 \text{ Hz}$   
 The AC-coupled lower frequency limits are reduced by a factor of 10 ( $<1 \text{ Hz}$ ) when 10X passive probes are used.

**Upper frequency limit, 20 MHz bandwidth-limited** 20 MHz,  $\pm 25\%$ , DC-coupled

**Calculated rise time** Measurements made using the oscilloscope's automated measurement feature may read slower rise time values than those determined by the above equation. This is because the automated measurements do not take interpolation into account. Measuring using cursors on the interpolated waveform gives a more accurate result.

The formula is calculated by measuring the  $-3 \text{ dB}$  bandwidth of the oscilloscope. The formula accounts for the rise time contribution of the oscilloscope independent of the rise time of the signal source.

Calculated rise time (10% to 90%, in ps) equals  $0.35/BW$  except from 1000 to 2100 mentioned in below table.

Bandwidth	Rise time (ps)
500 MHz	1000
350 MHz	1400
200 MHz	2100
100 MHz	3500
70 MHz	5000

**Peak detect or envelope mode pulse response** Peak detect response indicates how effective the oscilloscope is at picking up a single narrow pulse and determining its amplitude.

The minimum single pulse widths for peak detect or envelope mode is at least:

Bandwidth (MHz)	Minimum pulse width
500	> 2 ns
350	> 3 ns
200	> 5 ns
100	> 10 ns
70	> 14 ns
50	> 20 ns

**Deskew range** -95 ns to +95 ns

**Crosstalk (channel isolation)**

	$\leq 100$ MHz	> 100 MHz
1 M $\Omega$	100:1	30:1

**Sample rate range** Maximum 1.25 GS/s - All channels  
Maximum 2.5 GS/s - Half channel

**Record length range** 10 M Standard

**Seconds/Division range** 1 ns/div to 1000 s/div when in half channel mode  
2 ns/div to 1000 s/div when in full channel mode

**Maximum triggered acquisition rate** >5k wfm/s

✓ **Timebase accuracy**

$\pm 25 \times 10^{-6}$  over any over any  $\geq 1$  ms interval

Guaranteed, the specification valid after 30 minute warm-up and Signal Path Compensation (SPC) at ambient.

**Timebase delay time range** -10 divisions to 5000 s

**Delta time measurement accuracy (DTA)**

The formula to calculate delta-time measurement accuracy (DTA) for a given instrument setting and input signal is as follows (assumes insignificant signal content above the Nyquist frequency).  $SR_1$  = Slew rate (1<sup>st</sup> Edge) around 1<sup>st</sup> point in measurement

$SR_2$  = Slew rate (2<sup>nd</sup> Edge) around 2<sup>nd</sup> point in measurement

N = Input-referred noise ( $V_{rms}$ )

TBA = Timebase accuracy

$t_p$  = Delta-time measurement duration (sec)

RD = (Record length)/(Sample rate)

(assume edge shape that results from Gaussian filter response)

$$DTApp = \pm 5 \times \sqrt{2 \cdot \left(\frac{N}{SR_1}\right)^2 + 2 \cdot \left(\frac{N}{SR_2}\right)^2 + (5ps + 1 \cdot 10^{-6} \cdot RD)^2 + 2 \cdot t_{sr} + TBA \cdot t_p}$$

$$DTArms = \sqrt{2 \cdot \left(\frac{N}{SR_1}\right)^2 + 2 \cdot \left(\frac{N}{SR_2}\right)^2 + (5ps + 1 \cdot 10^{-6} \cdot RD)^2 + \left(\frac{2 \cdot t_{sr}}{\sqrt{12}}\right)^2 + TBA \cdot t_p}$$

(Assumes insignificant error due to aliasing)

The term under the square root sign is stability and is due to Time Interval Error (TIE). The errors due to this term occur throughout a single-shot measurement. The second term is due to both the absolute center-frequency accuracy and the center-frequency stability of the time base and varies between multiple single-shot measurements over the observation interval (the amount of time from the first single-shot measurement to the final single-shot measurement).

## Triggering system

**Aux In (external) trigger channels**

One channel

**Aux In (external) trigger input impedance**

1 MΩ ± 1% in parallel with 14 pF ± 3 pF

**Aux In (external) trigger maximum input voltage**

300 V<sub>rms</sub>, Installation category II

Derate at 20 dB/decade above 3 MHz to 30 V<sub>rms</sub> at 30 MHz; 10 dB/decade above 30 MHz.

Based upon a sinusoidal or DC input signal. The excursion above 300 V should be less than 100 ms in duration, and the duty factor is limited to < 44%. The RMS signal level must be limited to 300 V. If these values are exceeded, damage to the instrument may result.

**Edge-type trigger sensitivity, DC-coupled**

The greater of 2 mV or 0.4 div from DC to 20 MHz

The greater of 3 mV or 0.5 div from >20 MHz to 70 MHz

The greater of 4 mV or 0.5 div from >70 MHz to 100 MHz

The greater of 4 mV or 0.6 div from >100 MHz to 200 MHz

The greater of 5 mV or 0.7 div from >200 MHz to 350 MHz

The greater of 6 mV or 0.8 div from >350 MHz to instrument bandwidth

**Edge trigger sensitivity, AC-coupled**

The minimum sensitivities are as follows:

Trigger coupling	Typical sensitivity
AC	1.0 times the DC coupled limits for frequencies above 10 Hz. Attenuates signals below 10 Hz
NOISE REJ	2.5 times the DC coupled limits
HF REJ	1.0 times the DC coupled limits from DC to 50 kHz. Attenuates signals above 50 kHz

Table continued...

Trigger coupling	Typical sensitivity
LF REJ	1.0 times the DC Coupled limits for frequencies above 50 kHz. Attenuates signals below 50 kHz

<b>Trigger modes</b>	Auto, normal, and single
<b>Trigger coupling</b>	DC, HF Reject (attenuates > 50 kHz), LF Reject (attenuates < 50 kHz), noise reject (reduces sensitivity)
<b>Trigger level ranges</b>	
<b>Any input channel</b>	±5 divisions from center of screen
<b>Aux In</b>	±8 V
<b>Trigger types</b>	
<b>Edge</b>	Positive, negative, or either slope on any channel.
<b>Pulse Width</b>	Trigger on width of positive or negative pulses. Event can be time- or logic-qualified.
<b>Timeout</b>	Trigger on an event which remains high, low, or either, for a specified time period. Event can be logic-qualified.
<b>Runt</b>	Trigger on a pulse that crosses one threshold but fails to cross a second threshold before crossing the first again. Event can be time- or logic-qualified.
<b>Logic</b>	Trigger when logic pattern goes true, goes false, or occurs coincident with a clock edge. Pattern (AND, OR, NAND, NOR) specified for all input channels defined as high, low, or don't care. Logic pattern going true can be time-qualified.
<b>Setup/Hold</b>	Trigger on violations of both setup time and hold time between clock and data present on any input channels.
<b>Rise/Fall</b>	Trigger on pulse edge rates that are faster or slower than specified. Slope may be positive, negative, or either. Event can be logic-qualified.
<b>Parallel (with MSO option)</b>	Trigger on a parallel bus data value. Parallel bus can be from 1 to 20 bits (from the digital and analog channels) in size. Supports binary and hex radices.
<b>I2C (option)</b>	Trigger on start, repeated start, stop, missing ack, address (7 or 10 bit), data, or address and data on I2C buses up to 10 Mb/s.
<b>SPI (option)</b>	Trigger on slave select, idle time, or data (1-16 words) on SPI buses up to 20 Mb/s.
<b>RS-232/422/485/UART (option)</b>	Trigger on start bit, end of packet, data, and parity error up to 15 Mb/s.
<b>CAN (option)</b>	Trigger on start of frame, type of frame (data, remote, error, or overload), identifier, data, identifier and data, end of frame, missing ack, and bit stuff error on CAN buses up to 1 Mb/s and CAN-FD buses up to 16 Mb/s.
<b>LIN (option)</b>	Trigger on sync, identifier, data, identifier and data, wakeup frame, sleep frame, and error on lin buses up to 1 Mb/s.
<b>SENT (option)</b>	Trigger on start of packet, fast channel status and data, slow channel message ID and data, and CRC errors.
<b>Lowest frequency for successful operation of "Set level to 50%" function</b>	50 Hz
<b>Logic trigger minimum logic or rearm time</b>	For logic, time between channels refers to the length of time a logic state derived from more than one channel must exist to be recognized. For events, the time is the minimum time between a main and delayed event that will be recognized if more than one channel is used. For all vertical settings, the minimums are:

Triggering type	Pulse width	Rearm time	Time between channels
Logic	Not applicable	2 ns	2 ns

Table continued...

Triggering type	Pulse width	Rearm time	Time between channels
Time qualified logic	4 ns	2 ns	2 ns

**Setup/hold violation trigger, setup and hold time ranges**

Input coupling on the clock and data channels must be the same.  
 For setup time, positive numbers mean a data transition before the clock.  
 For hold time, positive numbers mean a data transition after the clock edge.  
 Setup + hold time is the algebraic sum of the setup time and the hold time programmed by the user.  
 The limits are as follows:

Feature	Minimum	Maximum
Setup time	0 ns	20 s
Hold time	0 ns	20 s
Setup + hold time	400 ps	21 s

**Minimum pulse width, rearm time, and transition time**

For trigger class width and runt, pulse width refers to the width of the pulse being measured. Rearm time refers to the time between pulses.  
 For trigger class slew rate, pulse width refers to the delta time being measured. Rearm time refers to the time it takes the signal to cross the two trigger thresholds again.  
 For Slew rate triggering, the minimum transition time defined as the time signal spends between the two trigger threshold settings.

Pulse class	Minimum pulse width	Minimum rearm time
Runt	4 ns	2 s
Width	4 ns	2 ns + 5% of width upper limit setting
Slew rate	4 ns	8.5 ns + 5% of delta time setting

**Rise/fall time trigger, delta time range** 800 ps to 20 s

**Pulse width, or time-qualified runt trigger time range** 800 ps to 20 s

**Trigger holdoff range** 0 s minimum to 10 s maximum.  
 Hold off may not function correctly in sequence trigger mode.

## Digital channel acquisition

**Digital input channels** 16 Digital Inputs [D0:D15]

**Input resistance, typical** 101 KΩ to ground

**Input capacitance, typical** 8 pF

Specified at the input to the P6316 probe with all 8 ground inputs connected to the user's ground. Use of leadsets, grabber clips, ground extenders, or other connection accessories may compromise this specification.

**Minimum input signal swing, typical** 500mV peak-to-peak

	Specified at the input to the P6316 probe with all 8 ground inputs connected to the user's ground. Use of leadsets, grabber clips, ground extenders, or other connection accessories may compromise this specification.
<b>Maximum input signal swing, typical</b>	+30 V, -20 V
<b>DC input voltage range</b>	+30 V, -20 V
<b>Maximum input dynamic range</b>	50 V <sub>pp</sub> (threshold setting dependent)
<b>Channel to channel skew (typical)</b>	500 ps Digital Channel to Digital Channel only This is the propagation path skew, and ignores skew contributions due to bandpass distortion, threshold inaccuracies (see Threshold Accuracy), and sample binning (see Digital Channel Timing Resolution).
<b>Thresholds</b>	Thresholds per set of 8 channels
<b>Threshold Selections</b>	TTL, CMOS, ECL, PECL, User-Defined
<b>Threshold voltage range</b>	-15 V to +25 V
<b>Digital channel timing resolution</b>	Minimum: 2 ns
<b>✓ Threshold accuracy</b>	± [180 mV + 2% of threshold setting after calibration]. Requires valid SPC.
<b>Minimum detectable pulse</b>	5.0 ns Specified at the input to the P6316 probe with all eight ground inputs connected to the user's ground. Use of lead sets, grabber clips, ground extenders, or other connection accessories may compromise this specification.

## Digital pattern generator

<b>Number of channels</b>	4
<b>Pattern memory length</b>	4 K bits
<b>Output amplitude</b>	2.5 V, 3.3 V, 5 V (Continuous Mode) 5 V (Burst Mode) Typical voltages are 10% below the nominal settings to allow for voltage differentials and tolerances
<b>Bit Rate</b>	1 bps to 25 Mbps
<b>Pattern type</b>	Square, counter, user defined, and manual

## Arbitrary function generator

<b>Operating modes</b>	Continuous, burst
<b>Function types</b>	Arbitrary, sine, square, pulse, ramp, DC level, Gaussian, Lorentz, exponential rise/fall, sin(x)/x, random noise, Haversine, and Cardiac.
<b>Amplitude and frequency range</b>	Values are peak-to-peak voltages.

Waveform	Amplitude range 50 Ω	Amplitude range 1 MΩ	Frequency range
Arbitrary	10 mV to 2.5 V	20 mV to 5 V	0.1 Hz to 25 MHz
Sine	10 mV to 2.5 V	20 mV to 5 V	0.1 Hz to 50 MHz
Table continued...			

Waveform	Amplitude range 50 $\Omega$	Amplitude range 1 M $\Omega$	Frequency range
Square	10 mV to 2.5 V	20 mV to 5 V	0.1 Hz to 20 MHz
Pulse	10 mV to 2.5 V	20 mV to 5 V	0.1 Hz to 20 MHz
Ramp	10 mV to 2.5 V	20 mV to 5 V	0.1 Hz to 500 KHz
DC Level		20 mV to 5V	
Gaussian	10 mV to 1.25 V	20 mV to 2.5 V	0.1 Hz to 5 MHz
Lorentz	10 mV to 1.2 V	20 mV to 2.4 V	0.1 Hz to 5 MHz
Exponential rise	10 mV to 1.25 V	20 mV to 2.5 V	0.1 Hz to 5 MHz
Exponential decay	10 mV to 1.25 V	20 mV to 2.5 V	0.1 Hz to 5 MHz
Sin(X)/X	10 mV to 1.5 V	20 mV to 3.0 V	0.1 Hz to 2 MHz
Random noise	10 mV to 2.5 V	20 mV to 5 V	
Haversine	10 mV to 1.25 V	20 mV to 2.5 V	0.1 Hz to 5 MHz
Cardiac	10 mV to 2.5 V	20 mV to 5 V	0.1 Hz to 500 KHz

<b>Maximum sample rate</b>	250 MS/s
<b>Arbitrary function length</b>	128 K sample
<b>Sine waveform</b>	
<b>Frequency setting resolution</b>	0.1 Hz
<b>Amplitude flatness</b>	$\pm 0.5$ dB at 1 kHz $\pm 1.5$ dB at 1 kHz for $< 20$ mV <sub>pp</sub> amplitudes with 50 $\Omega$ termination
<b>Total harmonic distortion</b>	1% into 50 $\Omega$ for amplitude $> 100$ mV
<b>Spurious-free dynamic range</b>	40 dB ( $V_{pp} \geq 0.1$ V) 50 $\Omega$ load
<b>Square and pulse waveform</b>	
<b>Frequency setting resolution</b>	0.1 Hz
<b>Duty cycle range</b>	10% - 90% or 10 ns minimum pulse, whichever is larger Minimum pulse time applies to both on and off time, so maximum duty cycle will be reduced at higher frequencies to maintain 10 ns of off time.
<b>Minimum pulse width, typical</b>	10 ns. This is the minimum time for either on or off duration.
<b>Rise/fall time</b>	5.5 ns, 10% - 90% with 50 $\Omega$ termination
<b>Pulse width resolution</b>	100 ps
<b>Overshoot</b>	$< 5\%$ for signal steps $> 100$ mV <sub>pp</sub> and frequency settings $\geq 100$ kHz with 50 $\Omega$ termination $< 7\%$ for signal steps $> 100$ mV <sub>pp</sub> and frequency settings $< 100$ kHz with 50 $\Omega$ termination This applies to the overshoot of the positive-going transition (+overshoot) and the negative-going (-overshoot) transition.
<b>Asymmetry</b>	$\pm 1\% \pm 5$ ns, at 50% duty cycle with 50 $\Omega$ termination
<b>Jitter</b>	$< 500$ ps TIE <sub>rms</sub>



<60 ps TIE<sub>rms</sub>, ≥100 mV<sub>pp</sub> amplitude, 40% - 60% duty cycle (Square and pulse waveforms, 5 GHz measurement bandwidth)

### Ramp and triangle waveform

<b>Frequency setting resolution</b>	0.1 Hz
<b>Variable symmetry</b>	0% - 100%
<b>Symmetry resolution</b>	0.1%
<b>DC level range</b>	±2.5 V into Hi-Z ±1.25 V into 50 Ω
<b>Random noise amplitude range</b>	20 mV <sub>pp</sub> to 5 V <sub>pp</sub> in to Hi-Z 10 mV <sub>pp</sub> to 2.5 V <sub>pp</sub> into 50 Ω  For both isolated noise signal and additive noise signal. Additive noise is 0% to 100% of the peak-to-peak amplitude specified. The additive noise range is restricted in favor of amplitude in order not to exceed the maximum output limits. There is currently a linear reduction from 100% to 0% above 50% amplitude.
<b>Sine and ramp frequency accuracy</b>	130 ppm (frequency ≤10 kHz); 50 ppm (frequency > 10 kHz)
<b>Square and pulse frequency accuracy</b>	130 ppm (frequency ≤10 kHz); 50 ppm (frequency > 10 kHz)
<b>Signal amplitude resolution</b>	500 μV (50 Ω) 1 mV (Hi-Z)
<b>Signal amplitude accuracy</b>	±[ (1.5% of peak-to-peak amplitude setting) + (1.5% of absolute DC offset setting) + 1 mV ] (frequency = 1 kHz)
<b>DC offset Range</b>	±2.5 V into Hi-Z ±1.25 V into 50 Ω
<b>DC offset Resolution</b>	500 μV (50 Ω) 1 mV (Hi-Z)
<b>✓ DC offset accuracy</b>	± [ (1.5% of absolute offset voltage setting) + 1 mV ] Add 3 mV of uncertainty per 10 °C change from 25 °C ambient Guaranteed, specification valid after 30 minute warm-up and Signal Path Compensation (SPC) at ambient.

## Processor system

<b>Host processor</b>	Application processing unit: Dual-core Arm Cortex-A53 MPCore with CoreSight; NEON and single/double precision floating point; 32 KB/32 KB L1 cache, 1 MB L2 cache Real-time processing unit Dual-core Arm Cortex-R5F with CoreSight; single/double precision floating point; 32 KB/32 KB L1 cache, and TCM
-----------------------	---

## Display system

<b>Display type</b>	Display area – 217 mm x 135 mm, TFT active matrix, and Liquid Crystal Display (LCD) with capacitive touch.
<b>Display resolution</b>	1,280 horizontal × 800 vertical pixels
<b>Display modes</b>	Overlay and stacked

<b>Luminance</b>	260 cd/m <sup>2</sup> Display luminance is specified for a new display set at full white brightness.
<b>Color support</b>	16,777,216 (8-bit RGB) colors
<b>Zoom</b>	Horizontal and vertical zooming is supported in all waveform and plot views
<b>Interpolation</b>	Sin(x)/x and linear
<b>Waveform styles</b>	Vectors, dots, variable persistence, and infinite persistence
<b>Graticules</b>	Movable and fixed graticules, selectable between grid, time, full, and none
<b>Color palettes</b>	Normal and inverted for screen captures Individual waveform colors are user-selectable
<b>Format</b>	YT, XY
<b>Language support</b>	English, Japanese, Simplified Chinese, Traditional Chinese, French, German, Italian, Spanish, Portuguese, Russian, Korean

## Interfaces, input, and output ports

<b>USB interface</b>	Two USB 2.0 high speed host ports on the side of the instrument One USB 2.0 high speed device port on the side of the instrument (USBTMC support)
<b>Ethernet Interface</b>	One 8-pin RJ-45 connector that supports 10/100 Mb/s and 1000 Mbps Ethernet (in full duplex mode only)

**Probe compensator, output voltage and frequency**

Characteristic	Value
Output voltage	Normal: 0-2.5 V amplitude
Source impedance	Normal: 1 k $\Omega$
Frequency	1 kHz

**Auxiliary output (Aux out)**

- Aux out connector and functional modes**
- Aux out output voltage**

A single BNC connector  
Acquisition (main) trigger out and AFG out  
Non-AFG voltage thresholds are listed in the following table:

Characteristic	Limits
V <sub>out</sub> (HI)	≥ 2.5 V open circuit; ≥ 1.0 V into a 50 $\Omega$ load to ground
V <sub>out</sub> (LO)	≤ 0.7 V into a load of ≤ 4 mA; ≤ 0.25 V into a 50 $\Omega$ load to ground

<b>Aux input</b>	300 Vrms CAT II with peaks ≤ ±425 V
<b>Security lock</b>	Rear-panel security slot connects to standard Kensington-style lock
<b>VESA mount</b>	Standard (VESA MIS-D 100) 100 mm x 100 mm VESA mounting points on rear of instrument
<b>Ground lug</b>	Provides a safe ground return path when the instrument is operating on battery

## Data handling characteristics

<b>Real-time clock</b>	A programmable clock maintains and reports the current time in the units of years, months, days, hours, minutes, and seconds.
------------------------	---

- 
- Non-volatile memory capacity** One eMMC device (limited to 2 GB of usable space in SLC mode) contains the bootloader, operating system, application software, calibration constants, and user data storage.
- Mass storage device capacity** Linux:  $\geq 4$  GB.  
The form factor is an embedded eMMC BGA. It provides storage for saved customer data, all calibration constants and the Linux operating system. Not customer serviceable. Partition on the user device, with a nominal capacity of 2 GB, is available for the storage of saved customer data.  
The physical capacity is larger, but in SLC mode it is 2 GB only for the longevity of the NAND flash.

## Power supply system

<b>Power consumption</b>	60 W maximum
<b>Source voltage</b>	100 – 240 VAC ±10% (50/60 Hz)
<b>Source frequency</b>	50 – 60 Hz (100 – 240 VAC)
<b>AC Adapter output</b>	24 V DC, 2.71 A
<b>Fuse rating</b>	T3.15 A, 250 V The fuse is not customer replaceable. The line lead is fused, but the neutral lead is not fused.

### Battery

<b>Description</b>	Requires Opt 2-BATPK or 2-BP battery pack, with 2 slots for batteries Supports up to 2 TEKBAT-01 Li-Ion rechargeable batteries
<b>Cell chemistry</b>	Li-Ion
<b>Nominal capacity</b>	6700 mAh
<b>Voltage</b>	14.52 VDC
<b>Weight</b>	450 g (1 lb)
<b>Battery operating time, typical</b>	Up to 4 hours with single battery Up to 8 hours with dual batteries Hot swappable Battery life is measured under following conditions: <ul style="list-style-type: none"> <li>• Only one channel is turned on</li> <li>• Lowest timebase setting selected</li> <li>• Lowest record length is selected</li> <li>• Fastest sample rate is selected</li> <li>• All analysis or interpolation capabilities are turned off</li> <li>• Edge trigger is selected</li> <li>• Back-light set to low</li> </ul>

## Safety characteristics

<b>Safety certification</b>	The following certifications and compliance are applicable: UL/CSA/EN 61010-2-030. US NRTL Listed - UL61010-1. Canadian Certification - CAN/CSA-C22.2 No. 61010.1. EU Compliance – Low Voltage Directive 2014-35-EU and EN61010-1. International Compliance – IEC 61010-1.
<b>Pollution degree</b>	Pollution degree 2, indoor, and dry location use only.

## Mechanical characteristics

<b>Weight</b>	
<b>Instrument only</b>	1.8 kg (4 lbs)

<b>Instrument with battery pack</b>	3.2 kg (7 lbs) – one battery 3.6 kg (8 lbs) – two batteries
<b>Instrument only dimensions</b>	
<b>Height</b>	210 mm (8.26 in)
<b>Width</b>	344 mm (13.54 in)
<b>Depth</b>	40.4 mm (1.59 in)
<b>Instrument with battery pack dimensions</b>	
<b>Height</b>	210 mm (8.26 in)
<b>Width</b>	344 mm (13.54 in)
<b>Depth</b>	78 mm (3.07 in)
<b>Clearance requirements</b>	The clearance requirement for adequate cooling is 13 mm (0.5 in) on the rear of the instrument along the bottom edge (inlet vents) and top edge (exhaust vents).
<b>Rackmount configuration</b>	5U

## Electromagnetic compatibility

### Regional certifications, classifications, and standards list

<b>European union</b>	<p>EC Council EMC Directive 2014/30/EU</p> <p>Demonstrated using:</p> <p>EN 61326-2-1:2006 Electrical equipment for measurement, control, and laboratory, part 2-1. Emissions that exceed the levels required by this standard may occur when this equipment is connected to a test object. Compliance is demonstrated using high-quality, shielded interface cables.</p> <p>EN IEC 61326-1:2021 and EN IEC 61326-2-1:2021 EMC requirements for Class A electrical equipment.</p> <p>Emissions:</p> <p>EN 55011, Class A</p> <p>Immunity:</p> <p>IEC 61000-4-2</p> <p>IEC 61000-4-3</p> <p>IEC 61000-4-4</p> <p>IEC 61000-4-5</p> <p>IEC 61000-4-6</p> <p>IEC 61000-4-11</p> <p>EN 61000-3-2</p> <p>EN 61000-3-3</p>
<b>Australia</b>	EMC Framework, demonstrated per emission standard CISPR 11 in accordance with EN 61326-2-1.
<b>United Kingdom</b>	<p>Electromagnetic Compatibility Regulations 2016-UK SI 2016 No.1091</p> <p>Demonstrated using:</p> <p>EN 61326-2-1:2013 Electrical equipment for measurement, control, and laboratory, Part 2-1. Emissions that exceed the levels required by this standard may occur when this equipment is connected to a test object. Use high quality shielded cables to maintain compliance.</p> <p>Emissions:</p> <p>EN 55011, Class A</p> <p>Immunity:</p>

IEC 61000-4-2  
IEC 61000-4-3  
IEC 61000-4-4  
IEC 61000-4-5  
IEC 61000-4-6  
IEC 61000-4-11  
EN 61000-3-2  
EN 61000-3-3

**Ukraine**

Technical Regulations on Electromagnetic Equipment Compatibility TR 1077

DSTU EN 61326-1: 2016 (EN 61326-1: 2013. IDT) and DSTU EN 61326-2-1: 2016 (EN 61326-2-1: 2013. IDT): Electrical equipment for measuring control and laboratory use. Requirements for electromagnetic compatibility Part 1 consists of general requirements, and Part 2-1 consists of additional requirements. Test configurations, working conditions, and quality criteria for the operation of an accurate test.

Emissions:

DSTU EN 55011: 2019 (EN 55011: 2009. IDT. CISPR 11: 2009. MOD) / Amendment № 1: 2019 (EN 55011: 2009 / A1: 2010. IDT).

CISPR 11: 2009 / A1: 2010. IDT) - Industrial equipment, scientific, and medical radio frequency. Characteristics of electromagnetic interference, norms, and methods of measurement.

Immunity

DSTU EN 61000-4-11: 2019 (EN 61000-4-11: 2004. IDT. IEC 61000-4-11: 2004. IDT) - Electromagnetic compatibility Part 4-11 consists of test and measurement methods. Tests for immunity to voltage dips, short-term interruptions, and voltage changes.

DSTU EN 61000-4-2: 2018 (EN 61000-4-2: 2009. IDT. IEC 61000-4-2: 2008. IDT) - Electromagnetic compatibility Part 4-2 consists of test and measurement methods. Tests for resistance to electrostatic discharges.

DSTU EN 61000-4-3: 2019 (EN 61000-4-3: 2006. IDT. IEC 61000-4-3: 2006. IDT) / Amendment № 2: 2019 (EN 61000-4-3: 2006 / A2: 2010 IDT IEC 61000-4-3: 2006 / A2: 2010 IDT) - Electromagnetic compatibility. Part 4-3. Test and measurement methods. Tests for immunity to radio frequency electromagnetic fields of radiation.

DSTU EN 61000-4-4: 2019 (EN 61000-4-4: 2012. IDT. IEC 61000-4-4: 2012. IDT) - Electromagnetic compatibility Part 4-4 consists of test methods for testing and measurement. Tests for susceptibility to electrical rapid transition processes or pulse packets.

DSTU EN 61000-4-5: 2019 (EN 61000-4-5: 2014. IDT. IEC 61000-4-5: 2014. IDT) - Electromagnetic compatibility Part 4-5 consists of test and measurement methods. Tests for immunity to voltage and current surges.

DSTU EN 61000-4-6: 2019 (EN 61000-4-6: 2014. IDT. IEC 61000-4-6: 2013. IDT) - Electromagnetic compatibility Part 4 consists of test and measurement methods. Tests for immunity to conductive perturbations induced by radio frequency fields

Emissions that exceed the levels required by this standard may occur when this equipment is connected to a test object.

Compliance demonstrated using high quality, shielded interface cables.

**Korea**

EC Council EMC Directive 2014/30/EU

Demonstrated using:

EN 61326-2-1:2013 Electrical equipment for measurement, control, and laboratory, Part 2-1. Emissions that exceed the levels required by this standard may occur when this equipment is connected to a test object. Use high quality shielded cables to maintain compliance.

EN IEC 61326-1:2021 and EN IEC 61326-2-1:2021 EMC Requirements for Class A electrical equipment Emissions

EN 55011, Class A  
 Immunity  
 IEC 61000-4-2  
 IEC 61000-4-3  
 IEC 61000-4-4  
 IEC 61000-4-5  
 IEC 61000-4-6  
 IEC 61000-4-11  
 EN 61000-3-2  
 EN 61000-3-3

## Immunity

<b>Electrostatic discharge (ESD), and enclosure port</b>	IEC 61000-4-2
<b>Radiated radio frequency electromagnetic field, and enclosure port</b>	IEC 61000-4-3 Triggering when the trigger threshold is offset by less than 4 minor divisions from ground reference is allowed.
<b>Electrical fast Transient/burst, and common-mode</b>	IEC 61000-4-4
<b>Surge/electrical slow transient</b>	IEC 61000-4-5
<b>Conducted radio frequency</b>	IEC 61000-4-6 Ambient fields may induce triggering when the trigger threshold is offset by less than 1 major division from ground reference.
<b>Voltage dips and short interruptions, and AC power port</b>	IEC 61000-4-11

## Environmental

**Product recycling information and documentation** User information should include an explanation of the recycling mark and direct the customer to the appropriate resources for recycling the product via one of the following methods:

1. Operator manual boilerplate; or
2. Pack-in errata sheet (only use this method if manual has been finalized); or
3. Online help file (if no other documentation is shipped with the product).

### Temperature

**Operating** 0 °C to +50 °C (+32 °F to 120 °F)

**Operating battery** 0 °C to 45 °C (+32 °F to 113 °F)

**Non-operating** -20 °C to +60 °C (-4 °F to 140 °F)

### Humidity

**Operating** 5% to 90% relative humidity at temperatures up to +30 °C,  
5% to 60% relative humidity at temperatures greater than +30 °C and up to +50 °C

**Non-operating** 5% to 90% relative humidity at temperatures up to +30 °C  
5% to 60% relative humidity at temperatures greater than +30 °C and up to +60 °C

### Altitude

**Operating** Up to 3,000 meters (9,842 feet)

**Non-operating** Up to 12,000 meters (39,370 feet)

## Regulatory compliance

**EMC** Conforms to European Union EMC Directive (CE-marked)

**Safety** Conforms to European Union Low Voltage Directive (CE-marked)  
Conforms to ANSI/UL61010-1 and ANSI/UL61010-2-030 (CSA-marked)  
Certified to CAN/CSA C22.2 No.61010-1 and CAN/CSA C22.2 No.61010-2-030 (CSA-marked)

**RoHS** Conforms to European Union Restrictions on Hazardous Substances (CE-marked)



# Performance verification procedures

This chapter contains performance verification procedures for the specifications marked with the ✓ symbol. The following equipment, or a suitable equivalent, is required to complete these procedures.

The performance verification procedures verify the performance of your instrument. They do not adjust your instrument. If your instrument fails any of the performance verification tests, repeat the failing test, verifying that the test equipment and settings are correct. If the instrument continues to fail a test, contact Tektronix Customer Support for assistance.

These procedures cover all 2 Series MSO instruments. Completion of the performance verification procedure does not update the instrument time and date.

Print the test records on the following pages and use them to record the performance test results for your oscilloscope. Disregard checks and test records that do not apply to the specific model you are testing.

The following table lists the required equipment. You might need additional cables and adapters, depending on the actual test equipment you use.

Required equipment	Minimum requirements	Examples
DC voltage source	3 mV to 4 V, $\pm 0.1\%$ accuracy	Fluke 9500B Oscilloscope Calibrator with a 9530 Output Module
Leveled sine wave generator	50 kHz to 2 GHz, $\pm 4\%$ amplitude accuracy	
Time mark generator	80 ms period, $\pm 1.0 \times 10^{-6}$ accuracy, rise time $< 50$ ns	

## Test records

### DC Gain Accuracy test record

DC Gain Accuracy					
Performance checks	Bandwidth	Vertical scale	Low limit	Test result	High limit
Channel 1 DC Gain Accuracy, 0 V offset, 0 V vertical position	20 MHz	2 mV/div	-2%		2%
		4.98 mV/div	-2%		2%
		5 mV/div	-2%		2%
		10 mV/div	-2%		2%
		20 mV/div	-2%		2%
		49.8 mV/div	-2%		2%
		50 mV/div	-2%		2%
		100 mV/div	-2%		2%
		200 mV/div	-2%		2%
		500 mV/div	-2%		2%
		1 V/div	-2%		2%
		FULL	100 mV/div	-2%	
Channel 2 DC Gain Accuracy, 0 V offset, 0 V vertical position	20 MHz	2 mV/div	-2%		2%
		4.98 mV/div	-2%		2%
		5 mV/div	-2%		2%
		10 mV/div	-2%		2%
		20 mV/div	-2%		2%
		49.8 mV/div	-2%		2%
		50 mV/div	-2%		2%
		100 mV/div	-2%		2%
		200 mV/div	-2%		2%
		500 mV/div	-2%		2%
		1 V/div	-2%		2%
		FULL	100 mV/div	-2%	

Table continued...

DC Gain Accuracy					
Performance checks	Bandwidth	Vertical scale	Low limit	Test result	High limit
Channel 3 DC Gain Accuracy, 0 V offset, 0 V vertical position	20 MHz	2 mV/div	-2%		2%
		4.98 mV/div	-2%		2%
		5 mV/div	-2%		2%
		10 mV/div	-2%		2%
		20 mV/div	-2%		2%
		49.8 mV/div	-2%		2%
		50 mV/div	-2%		2%
		100 mV/div	-2%		2%
		200 mV/div	-2%		2%
		500 mV/div	-2%		2%
		1 V/div	-2%		2%
	FULL	100 mV/div	-2%		2%
Channel 4 DC Gain Accuracy, 0 V offset, 0 V vertical position	20 MHz	2 mV/div	-2%		2%
		4.98 mV/div	-2%		2%
		5 mV/div	-2%		2%
		10 mV/div	-2%		2%
		20 mV/div	-2%		2%
		49.8 mV/div	-2%		2%
		50 mV/div	-2%		2%
		100 mV/div	-2%		2%
		200 mV/div	-2%		2%
		500 mV/div	-2%		2%
		1 V/div	-2%		2%
	FULL	100 mV/div	-2%		2%

### Analog Bandwidth test record

Analog Bandwidth performance checks					
Bandwidth at Channel	Vertical scale	$V_{in-AC\ RMS}$	$V_{bw-AC\ RMS}$	Limit	Test result Gain = $V_{bw-AC\ RMS}/V_{in-AC\ RMS}$
Channel 1	1 mV/div			$\geq 0.707$	
	2 mV/div			$\geq 0.707$	
	5 mV/div			$\geq 0.707$	
	10 mV/div			$\geq 0.707$	
	20 mV/div			$\geq 0.707$	
	200 mV/div			$\geq 0.707$	
	700 mV/div			$\geq 0.707$	
	3 V/div			$\geq 0.707$	
	5 V/div			$\geq 0.707$	
Channel 2	1 mV/div			$\geq 0.707$	
	2 mV/div			$\geq 0.707$	
	5 mV/div			$\geq 0.707$	
	10 mV/div			$\geq 0.707$	
	20 mV/div			$\geq 0.707$	
	200 mV/div			$\geq 0.707$	
	700 mV/div			$\geq 0.707$	
	3 V/div			$\geq 0.707$	
	5 V/div			$\geq 0.707$	
Channel 3	1 mV/div			$\geq 0.707$	
	2 mV/div			$\geq 0.707$	
	5 mV/div			$\geq 0.707$	
	10 mV/div			$\geq 0.707$	
	20 mV/div			$\geq 0.707$	
	200 mV/div			$\geq 0.707$	
	700 mV/div			$\geq 0.707$	
	3 V/div			$\geq 0.707$	
	5 V/div			$\geq 0.707$	

Table continued...

Analog Bandwidth performance checks					
Bandwidth at Channel	Vertical scale	$V_{in-AC\ RMS}$	$V_{bw-AC\ RMS}$	Limit	Test result Gain = $V_{bw-AC\ RMS}/V_{in-AC\ RMS}$
Channel 4	1 mV/div			$\geq 0.707$	
	2 mV/div			$\geq 0.707$	
	5 mV/div			$\geq 0.707$	
	10 mV/div			$\geq 0.707$	
	20 mV/div			$\geq 0.707$	
	200 mV/div			$\geq 0.707$	
	700 mV/div			$\geq 0.707$	
	3 V/div			$\geq 0.707$	
	5 V/div			$\geq 0.707$	

### Digital threshold accuracy tests with 2-MSO option

Digital threshold accuracy performance checks						
Digital channel	Threshold	$V_{s-}$	$V_{s+}$	Low limit	Test result $V_{sAvg} = (V_{s-} + V_{s+})/2$	High limit
D0	0 V			-0.18 V		0.18 V
	4 V			3.74 V		4.26 V
D1	0 V			-0.18 V		0.18 V
	4 V			3.74 V		4.26 V
D2	0 V			-0.18 V		0.18 V
	4 V			3.74 V		4.26 V
D3	0 V			-0.18 V		0.18 V
	4 V			3.74 V		4.26 V
D4	0 V			-0.18 V		0.18 V
	4 V			3.74 V		4.26 V
D5	0 V			-0.18 V		0.18 V
	4 V			3.74 V		4.26 V
D6	0 V			-0.18 V		0.18 V
	4 V			3.74 V		4.26 V
D7	0 V			-0.18 V		0.18 V
	4 V			3.74 V		4.26 V
D8	0 V			-0.18 V		0.18 V
	4 V			3.74 V		4.26 V
D9	0 V			-0.18 V		0.18 V
	4 V			3.74 V		4.26 V

Table continued...

Digital threshold accuracy performance checks						
Digital channel	Threshold	V <sub>s-</sub>	V <sub>s+</sub>	Low limit	Test result V <sub>sAvg</sub> = (V <sub>s-</sub> + V <sub>s+</sub> )/2	High limit
D10	0 V			-0.18 V		0.18 V
	4 V			3.74 V		4.26 V
D11	0 V			-0.18 V		0.18 V
	4 V			3.74 V		4.26 V
D12	0 V			-0.18 V		0.18 V
	4 V			3.74 V		4.26 V
D13	0 V			-0.18 V		0.18 V
	4 V			3.74 V		4.26 V
D14	0 V			-0.18 V		0.18 V
	4 V			3.74 V		4.26 V
D15	0 V			-0.18 V		0.18 V
	4 V			3.74 V		4.26 V

### Long term sample rate test records

Long Term Sample Rate	Low limit	Test result	High limit
Performance checks			
Long Term Sample Rate	-2 divisions		+2 divisions

### AFG DC Offset Accuracy Tests


AFG DC Offset Accuracy			
Performance checks	Low limit	Test result	High limit
All models	20 mV DC offset @ 50 Ω	18.7 mV	21.3 mV
	1 V DC offset @ 50 Ω	984 mV	1.016 V
	- 1 V DC offset @ 50 Ω	-1.016 V	-984 mV

## Check probe compensation

Procedure to check the probe compensation.

### Procedure

1. Connect the probe compensation to **Ch 1**.
2. Turn on the Ch 1 and turn off all other channels.
3. Tap **File > Default Setup**.
4. Push **Autoset** button on the front-panel or tap **File > Autoset** from the menu bar.  
The screen displays a square wave. The levels should be approximately 0 V - 2.5 V and 1 kHz.



## Check Aux In

Procedure to check the Aux In.

### Procedure

1. Connect probe compensation to **Aux In**.
2. Tap **File > Default Setup**.
3. Double-tap the trigger badge on the settings bar and set the trigger **Source** to **Aux In**.
4. Set **Trigger Level** to **1 V**.
5. Tap **Trigger** on the settings bar and verify the oscilloscope is **Triggering**.

## Check DC gain accuracy


Procedure to test the DC gain accuracy.

### Procedure



**WARNING:** Set the generator output to Off or 0 volts before connecting, disconnecting, and/or moving the test hookup during the performance of this procedure. The generator is capable of providing dangerous voltages.

1. Connect the oscilloscope to a calibrated DC voltage source. If you are using the Fluke 9500 calibrator, connect the calibrator head to the oscilloscope channel to test.



1711-018

2. Tap **File > Default Setup**.
3. Double-tap the **Horizontal** badge and open the **Acquisition Settings**.
4. Set **Acquisition Mode** to **Average**.
5. Set the **Number of Waveforms** to **16**.
6. Tap outside the menu to close the menu.
7. Double-tap the **Trigger** badge and set the trigger **Source** to **Internal**.
8. Tap outside the menu to close it.
9. Add the **Mean** measurement to the Results bar:
  - a) Tap the **Measure** button to open the **Add Measurements** menu.
  - b) Set the **Source** to **Ch 1**.
  - c) In the **Amplitude Measurements** panel, double-tap the **Mean** button to add the Mean measurement badge to the Results bar.
10. Tap outside the menu to close it.
11. Double-tap the **Mean** results badge.
12. Tap **Show Statistics in Badge**.
13. Tap outside the menu to close it.
14. Tap the channel button of the channel to test, to add the channel badge to the Settings bar.
15. Double tap the channel to test badge to open its menu and set the channel settings:
  - a) Set **Vertical Scale** to **2 mV/div**.
  - b) Tap **Bandwidth Limit** and set to **20 MHz**.
  - c) Tap **Probe Setup** and set **Attenuation** to **1X**.
  - d) Tap outside the menu to close it.
16. Record the negative-measured and positive-measured mean readings in the *Expected gain worksheet* as follows:
  - a) On the calibrator, set the DC Voltage Source to the  $V_{\text{negative}}$  value as listed in the 2 mV row of the worksheet.
  - b) Double-tap the **Horizontal** badge and open **Acquisition Settings**.
  - c) Tap **Clear** to reset the measurement statistics.
  - d) Enter the **Mean** reading in the worksheet as  $V_{\text{negative-measured}}$ .
  - e) On the calibrator, set the DC Voltage Source to  $V_{\text{positive}}$  value as listed in the 2 mV row of the worksheet.
  - f) Double-tap the **Horizontal** badge and open **Acquisition Settings** (if not open).
  - g) Tap **Clear** to reset the measurement statistics.
  - h) Enter the **Mean** reading in the worksheet as  $V_{\text{positive-measured}}$ .



**Table 1: Expected gain worksheet**

Oscilloscope vertical scale setting	V <sub>diffExpected</sub>	V <sub>negative</sub>	V <sub>positive</sub>	V <sub>negative-measured</sub>	V <sub>positive-measured</sub>	V <sub>diff</sub>	Test result (Gain accuracy)
2 mV/div							
4.98 mV/div							
5 mV/div							
10 mV/div							
20 mV/div							
49.8 mV/div							
50 mV/div							
100 mV/div							
200 mV/div							
500 mV/div							
1.0 V/div							
100 mV/div at Full BW							

Tektronix recommends calculating the stimulus voltage using 7 vertical divisions. However, the stimulus voltage value could be what fits within the display area based on the vertical scale.

- TotalOffset = ((-Position \* VoltsPerDiv) + Offset)
- Voltage = (number of vertical divisions \* VoltsPerDiv)/2
- V<sub>negative</sub> = TotalOffset – Voltage
- V<sub>positive</sub> = TotalOffset + Voltage
- V<sub>diffExpected</sub> = abs(V<sub>negative</sub> – V<sub>positive</sub>)
- Divisions = peak to peak voltage in division equivalent (7 divisions at 1mV/div = 7mVpp signal, or ±3.5mV, around the TotalOffset)

**Table 2: Example expected gain worksheet with 7 vertical divisions stimulus voltage values**

Oscilloscope vertical scale setting	V <sub>diffExpected</sub>	V <sub>negative</sub>	V <sub>positive</sub>	V <sub>negative-measured</sub>	V <sub>positive-measured</sub>	V <sub>diff</sub>	Test result (Gain accuracy)
2 mV/div	14 mV	-7 mV	+7 mV				
4.98 mV/div	34.86 mV	-17.43 mV	+17.43 mV				
5 mV/div	35 mV	-17.5 mV	+17.5 mV				
10 mV/div	70 mV	-35 mV	+35 mV				
20 mV/div	140 mV	-70 mV	+70 mV				
49.8 mV/div	348.6 mV	-174.3 mV	+174.3 mV				
50 mV/div	350 mV	-175 mV	+175 mV				
100 mV/div	700 mV	-350 mV	+350 mV				
200 mV/div	1400 mV	-700 mV	+700 mV				

Table continued...

Oscilloscope vertical scale setting	V <sub>diffExpected</sub>	V <sub>negative</sub>	V <sub>positive</sub>	V <sub>negative-measured</sub>	V <sub>positive-measured</sub>	V <sub>diff</sub>	Test result (Gain accuracy)
500 mV/div	3500 mV	-1750 mV	+1750 mV				
1.0 V/div	7 V	-3.5 V	+3.5 V				
100 mV/div at Full BW	700 mV	-350 mV	+350 mV				

17. Calculate Gain Accuracy as follows:

a) Calculate  $V_{diff}$  as follows:

$$V_{diff} = |V_{negative-measured} - V_{positive-measured}|$$

b) Enter  $V_{diff}$  in the worksheet.

c) Calculate *Gain Accuracy* as follows:

$$\text{Gain Accuracy} = ((V_{diff} - V_{diffExpected}) / V_{diffExpected}) \times 100\%$$

d) Enter the *Gain Accuracy* value in the worksheet and in the test record.

18. Repeat steps 15 on page 32 through 17 on page 34 for all vertical scale settings in the work sheet and the test record.

19. Repeat the procedure for all remaining channels:

a) Set the calibrator to **0** volts.

b) Move the calibrator output to the next channel input to be tested.

c) Double-tap the channel badge of the channel that you have finished testing and set **Display** to **Off**.

d) Double-tap the **Mean** measurement badge.

e) Tap the **Configure** panel.

f) Tap the **Source 1** field and select the next channel to test.

g) Starting from step 15 on page 32, set the values from the test record for the channel under test, and repeat the above steps until all channels have been tested.

20. Touch outside a menu to close the menu.

## Check analog bandwidth

Procedure to check the bandwidth for each channel.


### Procedure



**WARNING:** Set the generator to off or 0 volts before connecting, disconnecting, and/or moving the test hookup during the performance of this procedure. The generator is capable of providing dangerous voltages.

1. Connect the output of the calibrated leveled sine wave generator to the 50 Ω terminator (Tektronix Part Number 011-0049-02) on Channel 1 as shown in the following illustration.

If using the Fluke 9500 calibrator as the sine wave generator, connect the calibrator head to the 50 Ω terminator with the Fluke 9500 in 50 Ω output mode. Do not connect the Fluke 9500 calibrator head directly to the oscilloscope channel.



2. Tap **File > Default Setup** to reset the instrument and add the channel 1 badge and signal to the display.
3. Add the AC RMS measurement as follows:
  - a) Tap the **Measure** button.
  - b) Set the **Source** to the channel under test.
  - c) In the **Amplitude Measurements** panel, double-tap the **AC RMS** measurement button to add the measurement badge to the Results bar.
4. Set the channel under test settings:
  - a) Double-tap the badge of the channel under test to open its configuration menu.
  - b) Set **Vertical Scale** to **1 mV/div**.
  - c) Tap outside the menu to close it.
5. Adjust the leveled sine wave signal source to display a waveform of 8 vertical divisions at the selected vertical scale with a set frequency of **1 kHz**.  
For example, at 5 mV/div, use a  $\geq 40$  mV<sub>p-p</sub> signal; at 2 mV/div, use a  $\geq 16$  mV<sub>p-p</sub> signal.  
At some V/div settings, the generator may not provide 8 vertical divisions of signal. Set the generator output to obtain as many vertical divisions of signal as possible.
6. Double-tap the **Horizontal** badge in the Settings bar.
7. Set the **Horizontal Scale** to **1 ms/division**.
8. Tap outside the menu to close it.
9. Record the **AC RMS** measurement in the  $V_{in-AC\ RMS}$  entry of the test record.
10. Double-tap the **Horizontal** badge in the Settings bar.
11. Set the **Horizontal Scale** to **4 ns/division**.
12. Adjust the signal source to the maximum bandwidth frequency for the bandwidth and model being tested.
13. Record the **AC RMS** measurement at the new frequency in the  $V_{bw-pp}$  entry of the test record.
14. Use the values of  $V_{bw-pp}$  and  $V_{in-pp}$  recorded in the test record, and the following equation, to calculate the Gain at bandwidth.  
$$Gain = V_{bw-pp} / V_{in-pp}.$$
To pass the performance measurement test, Gain should be  $\geq 0.707$ . Enter *Gain* in the test record.
15. Repeat steps from 4 on page 35 to 14 on page 35 for all combinations of Vertical Scale and Horizontal Scale settings listed in the test record.
16. Repeat the test for all remaining channels as follows:
  - a) Turn **Off** the generator.
  - b) Move the calibrator output to the next channel input to be tested.
  - c) Turn **On** the generator.

- d) Tap the channel button on the oscilloscope Settings bar of the next channel to test.
- e) Double-tap the **AC RMS** measurement badge.
- f) Tap the **Configure** panel.
- g) Tap the **Source 1** field and select the next channel to test.
- h) Starting from step 4 on page 35, repeat the procedure until all channels have been tested.

## Check digital threshold accuracy with 2-MSO option

This procedure checks the threshold accuracy of the digital channels and is for models with the 2-MSO option only.


### About this task

This procedure applies to digital channels D0 through D15, and to channel threshold values of 0 V and 4 V.

### Procedure

1. Connect the P6316 digital probe to the instrument.
2. Connect the P6316 Group 1 pod to the DC voltage source to run this test.

You will need a BNC-to-0.1 inch pin adapter to complete the connection. If using the Fluke 9500 calibrator as the DC voltage source, connect the calibrator head to the P6316 Group 1 pod. You will need a BNC-to-0.1 inch pin adapter to complete the connection.



1711-023

3. Push **Default Setup** on the front panel to set the instrument to the factory default settings.
4. Display the digital channels and set the thresholds as follows:
  - a) Tap the **D15-D0** button on the Settings bar.
  - b) Double-tap the **D15-D0** badge on the Settings bar.
  - c) Tap the **D15-D8 Turn All On** button to turn all bits on.
  - d) Tap the **D7-D0 Turn All On** button to turn all bits on.
  - e) Tap the D15-D8 **Thresholds** field at the bottom of the menu and set the value to **0 V**.
  - f) Tap the D7-D0 field at the bottom of the menu and set the value to **0 V**. The thresholds are set for the 0 V threshold check.
  - g) Tap outside the menu to close it.

5. You need to record the test values in the test record row for 0 V for each digital channel. See [Digital threshold accuracy performance checks table](#).
6. Double-tap the **Trigger** badge.
7. Tap **Slope** and change the slope to rising edge.
8. Set the **Source** to the appropriate channel, such as D0.  
By default, the Type is set to Edge, Coupling is set to DC, Slope is set to Rising, Mode is set to Auto, and Level is set to match the threshold of the channel being tested.
9. Tap outside the menu to close it.
10. Set the DC voltage source (Vs) to -400 mV. Wait 3 seconds. Check the logic level of the corresponding digital channel in the display. If the channel is a static logic level high (green), change the DC voltage source Vs to -500 mV.
11. Increment Vs by +20 mV. Wait 3 seconds and check the logic level of the corresponding digital channel in the display. If the channel is at a static logic level high (green), record the Vs value as in the 0 V row of the test record.  
If the channel is a logic level low (blue) or is alternating between high and low, repeat this step (increment Vs by 20 mV, wait 3 seconds, and check for a static logic high). Continue until a value for **Vs-** is found. In this procedure, the channel might not change state until after you pass the set threshold level.
12. Double-tap the **Trigger** badge.
13. Tap **Slope** and change the slope to falling edge.
14. Tap outside the menu to close it.
15. Set the DC voltage source (Vs) to +400 mV. Wait 3 seconds. Check the logic level of the corresponding digital channel in the display. If the channel is a static logic level low (blue), change the DC voltage source Vs to +500 mV.
16. Decrement Vs by -20 mV. Wait 3 seconds and check the logic level of the corresponding digital channel in the display. If the channel is at a static logic level low, record the Vs value as **Vs+** in the 0 V row of the test record.  
If the channel is a logic level high (green) or is alternating between high and low, repeat this step (decrement Vs by 20 mV, wait 3 seconds, and check for a static logic low). Continue until a value for **Vs+** is found.
17. Find the average,  $V_{sAvg} = (Vs- + Vs+)/2$ . Record the average as the test result in the test record.  
Compare the test result to the limits. If the result is between the limits, continue with the procedure to test the channel at the +4 V threshold value.
18. Repeat the procedure starting with step 6 on page 37 for each remaining digital channel.
19. Double-tap the **Trigger** badge.
20. Set the **Source** to the appropriate channel, such as D0.
21. Tap **Slope** and change the slope to falling edge.
22. The remaining part of this procedure is for the +4 V threshold test.
  - a) Double-tap the **D15-D0** badge on the Settings bar.
  - b) Tap the **D15-D8 Turn All On** button to turn all bits on.
  - c) Tap the **D7-D0 Turn All On** button to turn all bits on.
  - d) Tap the **D15-D8 Thresholds** field at the bottom of the menu and set the value to **4.00 V**.
  - e) Tap the **D7-D0 Thresholds** field at the bottom of the menu and set the value to **4.00 V**.
  - f) Tap outside the menu to close it.
23. Set the DC voltage source (Vs) to +4.4 V. Wait 3 seconds. Check the logic level of the corresponding digital channel in the display. If the channel is a static logic level low (blue), change the DC voltage source Vs to +4.5 V.
24. Decrement Vs by -20 mV. Wait 3 seconds and check the logic level of the corresponding digital channel in the display. If the channel is at a static logic level low, record the Vs value as **Vs+** in the 4 V row of the test record.  
If the channel is a logic level high (green) or is alternating between high and low, repeat this step (decrement Vs by 20 mV, wait 3 seconds, and check for a static logic low). Continue until a value for **Vs+** is found.
25. Double-tap the **Trigger** badge.

26. Tap **Slope** and change the slope to rising edge.
27. Tap outside the menu to close it.
28. Set the DC voltage source ( $V_s$ ) to +3.6 V. Wait 3 seconds. Check the logic level of the corresponding digital channel in the display. If the channel is a static logic level high (green), change the DC voltage source  $V_s$  to +3.5 V.
29. Increment  $V_s$  by +20 mV. Wait 3 seconds and check the logic level of the corresponding digital channel in the display. If the channel is at a static logic level high, record the  $V_s$  value as in the 4 V row of the test record. If the channel is a logic level low (blue) or is alternating between high and low, repeat this step (increment  $V_s$  by 20 mV, wait 3 seconds, and check for a static logic high). Continue until a value for  $V_{s-}$  is found.
30. Find the average,  $V_{sAvg} = (V_{s-} + V_{s+})/2$ . Record the average as the test result in the test record. Compare the test result to the limits. If the result is between the limits, the channel passes the test.
31. Repeat the procedure starting with step 19 on page 37 for each digital channel.

## Check long term sample rate


This procedure checks the sample rate and delay time accuracy (time base).

### Procedure



**WARNING:** Set the generator to off or 0 volts before connecting, disconnecting, and/or moving the test hookup during the performance of this procedure. The generator is capable of providing dangerous voltages.

1. Connect the output of a time mark generator to the oscilloscope channel 1 input.



1711-020

2. Set the time mark generator period to **80 ms**. Use a time mark waveform with a fast rising edge.
3. If it is adjustable, set the time mark amplitude to approximately **1 V<sub>p-p</sub>**.
4. Tap **File > Default Setup**.
5. Tap the channel 1 button on the Settings bar.
6. Double-tap the Channel 1 badge to open its Configuration menu.
7. Set **Vertical Scale** to **500 mV**.
8. Set the **Position** value to center the time mark signal on the screen.
9. Tap outside the menu area to close it.
10. Double-tap the **Horizontal** settings badge.
11. Set the **Horizontal Scale** to **1 us/div**.
12. Tap outside the menu area to close it.
13. Double-tap the **Trigger** settings badge.

14. Set **Source** to the channel being tested.
15. Set the **Level** as necessary for a triggered display.
16. Tap outside the menu area to close it.
17. Double-tap the **Horizontal** settings badge.
18. Adjust the **Position** value to move the trigger point to the center of the screen.
19. Turn **Delay** to **On** and set **Position** to **80 ms**.
20. Set the **Horizontal Scale** to **1 us/div**.
21. Observe where the rising edge of the marker crosses the center horizontal graticule line. The rising edge should cross within  $\pm 2$  divisions of the vertical center graticule. Enter the deviation in the test record.  
A  $2.5 \times 10^{-6}$  time base error is 2 divisions of displacement.

## Check AFG DC offset accuracy

This procedure checks the AFG DC Offset Accuracy.

### Procedure

1. Connect the AFG output to the DMM through a 50  $\Omega$  termination.



1711-022

2. Push the **Default Setup** button on the oscilloscope front panel.
3. Tap the **AFG** button.
4. Tap **Waveform Type** and select **DC** from the drop down list.
5. Tap **Amplitude** and set amplitude to the value shown in the test record.
6. Set DMM to measure DC Voltage.
7. Measure voltage on the DMM. Compare the result to the limits in the test record.
8. Repeat steps from 3 on page 39 to 7 on page 39 above for each line in the test record. This completes the procedure.