

MDO4000 Series Mixed Domain Oscilloscopes Specifications and Performance Verification

Technical Reference





MDO4000 Series Mixed Domain Oscilloscopes Specifications and Performance Verification Technical Reference

This document supports firmware version 2.94 and above for MDO4000 Series instruments.

Warning

The servicing instructions are for use by qualified personnel only. To avoid personal injury, do not perform any servicing unless you are qualified to do so. Refer to all safety summaries prior to performing service.

Published 20190211

www.tek.com

Copyright © Tektronix. All rights reserved. Licensed software products are owned by Tektronix or its subsidiaries or suppliers, and are protected by national copyright laws and international treaty provisions.

Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supersedes that in all previously published material. Specifications and price change privileges reserved.

TEKTRONIX and TEK are registered trademarks of Tektronix, Inc.

Contacting Tektronix

Tektronix, Inc. 14150 SW Karl Braun Drive P.O. Box 500 Beaverton, OR 97077 USA

For product information, sales, service, and technical support:

- In North America, call 1-800-833-9200.
- Worldwide, visit www.tek.com to find contacts in your area.

Table of Contents

General safety summary	11
Specifications	
Analog Signal Acquisition System Specifications	
Time Base System Specifications	
Triggering System Specifications	1
Digital Acquisition System Specifications	1
P6616 Digital Probe Input Specifications	1
RF Input Specifications	1
Display System Specifications	2
Interfaces and Input/Output Port Specifications	2
Data Handling Specifications	2
Power Supply System Specifications	2
Environmental Specifications	2
Mechanical Specifications	2
TPA-N-PRE Specifications	2
Performance Verification	2
Test Record	2
Performance Verification Procedures	6
Self Test	6
Check Input Impedance (Resistance)	6
Check DC Balance	6
Check DC Gain Accuracy.	6
Check Offset Accuracy	7
Check Analog Bandwidth	7
Check Random Noise, Sample Acquisition Mode	7
Check Sample Rate and Delay Time Accuracy	7
Check Delta Time Measurement Accuracy	8
Check Digital Threshold Accuracy	8
Check Phase Noise.	8
Check Displayed Average Noise Level (DANL)	
Check Level Measurement Uncertainty	9
Check Third Order Intermodulation Distortion.	
Check Residual Spurious Response.	
Check Crosstalk to RF Channel from Analog Channels	
Check Trigger Out	
With TPA-N-PRE Attached: Check Display Average Noise Level (DANL)	

List of Tables

Table 1: Analog signal acquisition system specifications	1
Table 2: Time base system specifications.	8
Table 3: Delta-Time measurement accuracy formula	9
Table 4: Trigger specifications	10
Table 5: Digital acquisition specifications	15
Table 6: P6616 digital probe input specifications.	16
Table 7: RF input specifications	17
Table 8: Display system specifications	20
Table 9: Interfaces and Input/Output port specifications	21
Table 10: Data handling specifications.	22
Table 11: Power supply system specifications	22
Table 12: Environmental specifications	23
Table 13: Mechanical specifications.	24
Table 14: TPA-N-PRE specifications.	25
Table 15: Required equipment	28
Table 16: Gain expected worksheet	69
Table 17: Maximum bandwidth frequency worksheet	74

General safety summary

Review the following safety precautions to avoid injury and prevent damage to this product or any products connected to it.

To avoid potential hazards, use this product only as specified.

Only qualified personnel should perform service procedures.

To avoid fire or personal injury

Use proper power cord. Use only the power cord specified for this product and certified for the country of use.

Connect and disconnect properly. Do not connect or disconnect probes or test leads while they are connected to a voltage source.

Connect and disconnect properly. De-energize the circuit under test before connecting or disconnecting the current probe.

Ground the product. This product is grounded through the grounding conductor of the power cord. To avoid electric shock, the grounding conductor must be connected to earth ground. Before making connections to the input or output terminals of the product, ensure that the product is properly grounded.

Observe all terminal ratings. To avoid fire or shock hazard, observe all ratings and markings on the product. Consult the product manual for further ratings information before making connections to the product.

Connect the probe reference lead to earth ground only.

Do not apply a potential to any terminal, including the common terminal, that exceeds the maximum rating of that terminal.

Power disconnect. The power cord disconnects the product from the power source. Do not block the power cord; it must remain accessible to the user at all times.

Do not operate without covers. Do not operate this product with covers or panels removed.

Do not operate with suspected failures. If you suspect that there is damage to this product, have it inspected by qualified service personnel.

Avoid exposed circuitry. Do not touch exposed connections and components when power is present.

Do not operate in wet/damp conditions.

Do not operate in an explosive atmosphere.

Keep product surfaces clean and dry.

Provide proper ventilation. Refer to the manual's installation instructions for details on installing the product so it has proper ventilation.

Terms in this manual

These terms may appear in this manual:



WARNING. Warning statements identify conditions or practices that could result in injury or loss of life.



CAUTION. Caution statements identify conditions or practices that could result in damage to this product or other property.

Symbols and terms on the product

These terms may appear on the product:

- DANGER indicates an injury hazard immediately accessible as you read the marking.
- WARNING indicates an injury hazard not immediately accessible as you read the marking.
- CAUTION indicates a hazard to property including the product.

The following symbol(s) may appear on the product:









CAUTION Refer to Manual

Protective Ground (Earth) Terminal

Chassis Ground

Standb

Specifications

This chapter contains specifications for the MDO4000 Series oscilloscopes. All specifications are guaranteed unless noted as "typical." Typical specifications are provided for your convenience but are not guaranteed. Specifications that are marked with the \checkmark symbol are checked in *Performance Verification*.

All specifications apply to all MDO4000 models unless noted otherwise. To meet specifications, two conditions must first be met:

- The oscilloscope must have been operating continuously for twenty minutes within the specified operating temperature range. (See Table 12 on page 23.)
- You must perform the Signal Path Compensation (SPC) operation described in step 2 of the *Self Test* before evaluating specifications. (See page 62, *Self Test*.) If the operating temperature changes by more than 10 °C (18 °F), you must perform the SPC operation again.

Analog Signal Acquisition System Specifications

The following table shows the specifications for the analog signal acquisition system.

Table 1: Analog signal acquisition system specifications

Characteristic	Description			
Number of input channels	4 analog channels, o	digitized simultaneously		
Input coupling	DC or AC			
Input resistance	1 MΩ or 50 Ω			
selection	250 $k\Omega$ (to be selected for performance verification only).			
✓ Input impedance,	1 ΜΩ	1 MΩ ±1%		
DC coupled	50 Ω	50 Ω ±1%		
		MDO4104-X	VSWR ≤1.5:1 from DC to 1 GHz, typical	
		MDO4054-X	VSWR ≤1.5:1 from DC to 500 MHz, typical	
		MDO4034-3	VSWR ≤1.5:1 from DC to 350 MHz, typical	
		MDO4014-3	VSWR ≤1.5:1 from DC to 100 MHz, typical	
Input Capacitance, 1 MΩ DC coupled, typical	13 pF ± 2 pF			

Table 1: Analog signal acquisition system specifications (cont.)

Characteristic	Description		
Maximum input	1 ΜΩ	300 V _{RMS} at the BNC	
voltage		Installation Category II	
		Derate at 20 dB/decade between 4.5 MHz and 45 MHz	
		Derate 14 dB/decade between 45 MHz and 450 MHz	
		Above 450 MHz, 5 V _{RMS} .	
		Maximum peak input voltage at the BNC, ±424 V	
	250 ΚΩ	75 V _{RMS} at the BNC	
		Installation Category II	
		Derate at 20 dB/decade between 1.3 MHz and 13 MHz	
		Derate 10 dB/decade between 13 MHz and 130 MHz	
		Above 130 MHz, 5 V _{RMS} .	
		Maximum peak input voltage at the BNC, ±106 V	
	50 Ω	5 V _{RMS} with peaks ≤±20 V (Duty Factor ≤ 6.25%)	
		Overvoltage trip is intended to protect against overloads that might damage termination resistors. A sufficiently large impulse might cause damage regardless of the overvoltage protection circuitry because of the finite time required to detect and respond.	
✓ DC Balance	0.1 div with the input DC coupled, set to 50 Ω termination, and input terminated with 50 Ω BNC terminator		
	0.2 div at 1 mV/div with the BNC terminator	the input DC coupled, set to 50 Ω termination, and input terminated with 50 Ω	
	0.2 div with the input DC	Coupled, set to 1 M Ω termination, and input terminated with 50 Ω BNC terminator	
Number of digitized	8 bits		
oits	Displayed vertically with	25 digitization levels (DL) per division, 10.24 divisions dynamic range.	
	"DL" is the abbreviation for "digitization level." A DL is the smallest voltage level change that can be resolved by an 8-bit A-D Converter. This value is also known as the least significant bit (LSB).		
Sensitivity range	1 ΜΩ	1 mV/div to 10 V/div in a 1-2-5 sequence	
coarse)	50 Ω	1 mV/div to 1 V/div in a 1-2-5 sequence	
Sensitivity range (fine)	1 ΜΩ	1 mV/div to 5 V/div < -50% to > +50% of selected setting	
		10 V/div < -50% to 0%	
		Allows continuous adjustment from 1 mV/div to 10 V/div	
	50 Ω	1 mV/div to 500 mV/div < -50% to > +50% of selected setting	
		1 V/div < -50% to 0%	
		Allows continuous adjustment from 1 mV/div to 1 V/div	
Sensitivity resolution (fine), typical	≤1% of current setting	·	

Table 1: Analog signal acquisition system specifications (cont.)

Characteristic	Description				
✓ DC gain accuracy	For 50 Ω , 1 M Ω , and 250 k Ω (250 k Ω checked indir	ectly):			
	±1.5%, derated at 0.100%/°C above 30 °C				
	±2.0%, derated at 0.100%/°C above 30 °C, 1 mV/D	oiv setting			
	±3.0% variable gain, derated at 0.100%/°C above 3	30 °C			
Offset ranges,	Volts/div setting	Offset range			
minimum		1 MΩ input	50 Ω input		
	1 mV/div to 50 mV/div	±1 V	±1 V		
	50.5 mV/div to 99.5 mV/div	±0.5 V	±0.5 V		
	100 mV/div to 500 mV/div	±10 V	±10 V		
	505 mV/div to 995 mV/div	±5 V	±5 V		
	1 V/div to 5 V/div	±100 V	±5 V		
	5.05 V/div to 10 V/div	±50 V	Not applicable		
	For 50 Ω path, 1 V/div is the maximum vertical setting	ng.	•		
	The input signal cannot exceed Max Input Voltage for the 50 Ω input path. Refer to the Max Input Voltage specification for more information.				
Position range	±5 divisions				
✓ Offset accuracy	±[0.005 × offset – position + DC Balance]				
,	Both the position and the constant offset term must livelts/div term.	be converted to volts b	y multiplying by the appropriate		
Number of waveforms for average acquisition mode	2 to 512 waveforms Default of 16 waveforms				
DC voltage	Measurement type	DC Accuracy (in V	olts)		
measurement accuracy	Average of ≥ 16 waveforms	±[DC Gain Accuracy × reading – (offset - position) + offset accuracy + 0.1 division]			
average acquisition mode		Refer to DC Gain Accuracy for temperature derating information.			
	Delta Volts between any two averages of ≥16	±[DC gain accurac	y × reading + 0.05 div]		
	waveforms acquired with the same oscilloscope setup and ambient conditions	Refer to DC Gain Accuracy for temperature derating information.			
	Offset, position, and the constant offset term must be converted to volts by multiplying by the appropriate volts/div term.				
	The basic accuracy specification applies directly to any sample and to the following measurements: High, Low, Max, Min, Mean, Cycle Mean, RMS, and Cycle RMS. The delta volt accuracy specification applies to subtractive calculations involving two of these measurements.				
	The delta volts (difference voltage) accuracy specification applies directly to the following measurements: Positive Overshoot, Negative Overshoot, Pk-Pk, and Amplitude.				

Table 1: Analog signal acquisition system specifications (cont.)

Characteristic	Description	
DC voltage measurement accuracy	Measurement type	DC Accuracy (in volts)
	Any sample	±[DC gain accuracy × reading – (offset – position) + Offset Accuracy + 0.15 div + 0.6 mV]
Sample acquisition mode, typical		Refer to DC Gain Accuracy for temperature derating information.
	Delta volts between any two samples acquired with the same oscilloscope setup and ambient	±[DC gain accuracy × reading + 0.15 div + 1.2 mV]
	conditions	Refer to DC Gain Accuracy for temperature derating information.
	Offset, position, and the constant offset term must by volts/div term.	be converted to volts by multiplying by the appropriate

Table 1: Analog signal acquisition system specifications (cont.)

Characteristic	Description				
Analog bandwidth	MDO4104-6, M	DO4104-3, MDO	4054-6, MDO4054-3, MDO4034-3: 2	20 MHz, 250 MHz, and Full	
selections	MDO4014-3: 2	0 MHz and Full			
Analog bandwidth, DC	These limits are for ambient temperature of ≤30°C and the bandwidth selection set to FULL. Reduce the upper bandwidth frequency by 1% for each °C above 30°C				
coupled			Volts/Div setting	Bandwidth	
	50 Ω	MDO4104-X	5 mV/div — 1 V/div	DC to 1.00 GHz	
			2 mV/div — 4.98 mV/div	DC to 350 MHz	
			1 mV/div — 1.99 mV/div	DC to 175 MHz	
		MDO4054-X	5 mV/div — 1 V/div	DC to 500 MHz	
			2 mV/div — 4.98 mV/div	DC to 350 MHz	
			1 mV/div — 1.99 mV/div	DC to 175 MHz	
		MDO4034-3	2 mV/div — 1 V/div	DC to 350 MHz	
			1 mV/div — 1.99 mV/div	DC to 175 MHz	
		MDO4014-3	1 mV/div — 1 V/div	DC to 100 MHz	
	1 MΩ, typical	MDO4104-X	5 mV/div — 10 V/div	DC to 500 MHz	
			2 mV/div — 4.98 mV/div	DC to 350 MHz	
			1 mV/div — 1.99 mV/div	DC to 175 MHz	
		MDO4054-X	5 mV/div — 10 V/div	DC to 500 MHz	
			2 mV/div — 4.98 mV/div	DC to 350 MHz	
			1 mV/div — 1.99 mV/div	DC to 175 MHz	
		MDO4034-3	2 mV/div — 10 V/div	DC to 350 MHz	
			1 mV/div — 1.99 mV/div	DC to 175 MHz	
		MDO4014-3	1 mV/div — 10 V/div	DC to 100 MHz	
	With TPPXX00	MDO4104-X (TPP1000 probe)	50 mV/div — 100 V/div	DC to 1 GHz	
			20 mV/div — 49.8 mV/div	DC to 350 MHz	
	10X probes, typical		10 mV/div — 19.9 mV/div	DC to 175 MHz	
	, p. 66.	MDO4054-X	50 mV/div — 100 V/div	DC to 500 MHz	
		(TPP0500	20 mV/div — 49.8 mV/div	DC to 350 MHz	
		probe)	10 mV/div — 19.9 mV/div	DC to 175 MHz	
		MDO4034-3	20 mV/div — 100 V/div	DC to 350 MHz	
		(TPP0500)	10 mV/div — 19.9 mV/div	DC to 175 MHz	
		MDO4014-3 (TPP0500)	10 mV/div — 100 V/div	DC to 100 MHz	
ower frequency limit,	< 10 Hz when	AC, 1 MΩ coupled	d		
AC coupled, typical	The AC coupled lower frequency limits are reduced by a factor of 10 when 10X passive probes are used.				
Upper frequency limit, 250 MHz bandwidth limited, typical	250 MHz, ±20%, all models except MDO4014-3				

Table 1: Analog signal acquisition system specifications (cont.)

Upper frequency limit, 20 MHz bandwidth limited, typical	20 MHz, ±20%, all r	nodels			
Calculated rise time at 0.350/BW = t _r , typical		lated by measuring -3 dB ban n of the oscilloscope independ			
	Model	50 Ω 1 mV/div to 1.99 mV/div	50 Ω 2 mV/div to 4.99 mV/div	50 Ω 5 mV/div to 1 V/div	
	MDO4104-X	2 ns	1 ns	350 ps	
	MDO4054-X	2 ns	1 ns	700 ps	
	MDO4034-3	2 ns	1 ns	1 ns	
	MDO4014-3	3.5 ns	3.5 ns	3.5 ns	
	Model	TPP1000 probe 10 mV/div to 19.9 mV/div	TPP1000 probe 20 mV/div to 49.8 mV/div	TPP1000 probe 50 mV/div to 10 V/div	
	MDO4104-X	2 ns	1 ns	350 ps	
	MDO4054-X	2 ns	1 ns	700 ps	
	MDO4034-3	2 ns	1 ns	1 ns	
	MDO4014-3	3.5 ns	3.5 ns	3.5 ns	
	Model	TPP0500 probe 10 mV/div to 19.9 mV/div	TPP0500 probe 20 mV/div to 49.8 mV/div	TPP0500 probe 50 mV/div to 10 V/div	
	MDO4104-X	2 ns	1 ns	700 ps	
	MDO4054-X	2 ns	1 ns	700 ps	
	MDO4034-3	2 ns	1 ns	1 ns	
	MDO4014-3	3.5 ns	3.5 ns	3.5 ns	
Peak Detect or Envelope mode pulse response, typical	Model (Sample Rate	Maximum)	Minimum pulse width	Minimum pulse width	
	MDO4104-X (≤2 channels enabled)		>800 ps		
	MDO4104-X (≥3 channels enabled), MDO4054-X, MDO4034-3, MDO4014-3		>1.6 ns		

Table 1: Analog signal acquisition system specifications (cont.)

Random Noise, Sample Acquisition Mode	Model	Bandwidth limit	RMS noise (mV)	RMS noise (mV)		
			1 Μ Ω	50 Ω		
	MDO4104-X	Full Bandwidth	\leq (300 µV + 8.0% of Volts/div setting)	≤ (75 µV + 6.0% of Volts/div setting)		
		250 MHz bandwidth	≤ (100 µV + 5.0% of Volts/div setting)	≤ (50 µV + 4.0% of Volts/div setting)		
		20 MHz bandwidth	\leq (100 µV + 5.0% of Volts/div setting)	\leq (50 μ V + 4.0% of Volts/div setting)		
	MDO4054-X, MDO4034-3,	Full Bandwidth	≤ (130 µV + 8.0% of Volts/div setting)	≤ (130 µV + 8.0% of Volts/div setting)		
	MDO4014-3	250 MHz bandwidth (except MDO4014-3)	\leq (100 µV + 6.0% of Volts/div setting)	\leq (100 μ V + 6.0% of Volts/div setting)		
		20 MHz bandwidth	\leq (100 μ V + 4.0% of Volts/div setting)	≤ (100 µV + 4.0% of Volts/div setting)		
Delay between channels, full	≤100 ps between any two analog or digital channels with input impedance set to 50 Ω, DC coupling, with equal volts/division setting or above 10 mV/div					
bandwidth, typical	All settings in the instrument can be manually time aligned using the Probe Deskew function from –125 ns to +125 ns with a resolution of 20 ps					
	This specification does not pertain to the RF channel. For RF channel delay, see the RF Input Specifications.					
Deskew range	-125 ns to +125 ns with a resolution of 20 ps					
Crosstalk (channel isolation), typical	≥100:1 at ≤100 MHz and ≥30:1 at >100 MHz up to the rated bandwidth for any two channels having equal Volts/Div settings					
TekVPI Interface	The probe interface allows installing, powering, compensating, and controlling a wide range of probes offering a variety of features.					
	The interface is available on all front panel inputs. (RF channel requires TPA-N-VPI adapter.)					
Total probe power	FiveTektronix VPI-compliant probe interfaces (one per channel). (RF channel requires TPA-N-VPI adapter.)					
	50 W maximum internal probe power (total for all 5 VPI ports)					
Probe power per	Voltage	Max Amperage	Voltage Tolerance			
channel	5 V	50 mA (250 mW)	±5%			
	12 V	2 A (24 W)	±10%			

Time Base System Specifications

The following table shows the horizontal and acquisition system specifications for the MDO4000 Series oscilloscopes.

Table 2: Time base system specifications

Characteristic	Description				
Sample-rate range	MDO4104-X	2.5 S/s – 5 GS/s (1 – 2 analog channels enabled) 2.5 S/s – 2.5 GS/s (3 – 4 analog channels enabled) 2.5 S/s – 2.5 GS/s			
	MDO4054-X, MDO4034-3, MDO4014-3				
Record Length Range	20 M, 10 M, 1 M, 100 k, 10 k,	1 k			
Seconds/Division range	Instrument	1 k	10 k	100 k – 20 M	
	MDO4104-X (2 channels enabled)	400 ps – 40 s	400 ps – 400 s	400 ps – 1,000 s	
	MDO4104-X (4 channels enabled), MDO4054-X, MDO4034-3, MDO4014-3	1 ns – 40 s	1 ns – 400 s	1 ns – 1,000 s	
Maximum triggered acquisition rate	> 50,000 wfm/s				
Aperture Uncertainty	≤(3 ps + 0.1 ppm × record duration) _{RMS} , for records having ≤1 minute duration				
Long-term sample rate and delay time accuracy	±5 ppm over any ≥1 ms time interval				

Table 2: Time base system specifications (cont.)

Characteristic

Description

Delta-time measurement accuracy

The formula to calculate the delta-time measurement accuracy (DTA) for a given instrument setting and input signal is given in the following table. (See Table 3.) The formula assumes insignificant signal content above Nyquist and insignificant error due to aliasing. The abbreviations used in the formula are as follows:

SR₁ = slew rate around 1st point in measurement (1st edge)

SR₂ = slew rate around 2nd point in measurement (2nd edge)

N =input-referred noise (V_{RMS}) (Refer to *Random Noise* and *Sample Acquisition Mode* specifications.)

TBA = time base accuracy (5 ppm) (Refer to Long-term Sample Rate and Delay Time Accuracy specifications.)

t_p = delta-time measurement duration (sec)

RD = (record length)/(sample rate)

 $t_{sr} = 1/(sample rate)$

assume edge shape that results from Gaussian filter response

The term under the squareroot sign is the stability and is due to TIE (Time Interval Error). The errors due to this term occur throughout a single-shot measurement. The second term is due to both the absolute center-frequency accuracy and the center-frequency stability of the time base and varies between multiple single-shot measurements over the observation interval (the amount of time from the first single-shot measurement to the final single-shot measurement).

Table 3: Delta-Time measurement accuracy formula

The terms used in these formulas are defined under *Delta-time measurement accuracy*, in the preceding table. (See Table 2.)

$$DTA_{pk-pk} = \pm 5 \times \sqrt{2 \left[\frac{N}{SR_1}\right]^2 + 2 \left[\frac{N}{SR_2}\right]^2 + (3ps + 1 \times 10^{-7} \times RD)^2} + 2t_{sr} + TBA \times t_p$$

$$DTA_{rms} = \sqrt{2\left[\frac{N}{SR_1}\right]^2 + 2\left[\frac{N}{SR_2}\right]^2 + (3ps + 1 \times 10^{-7} \times RD)^2 + \left(\frac{2 \times t_{sr}}{\sqrt{12}}\right)^2} + TBA \times t_p}$$

Triggering System Specifications

The following table shows the trigger specifications for analog and digital channels on the MDO4000 Series oscilloscopes. These specifications do not apply to the RF input channel.

NOTE. For RF, please see the analog to RF trigger skew specification. (See page 17, RF Input Specifications.)

Table 4: Trigger specifications

Characteristic	Description		
Trigger bandwidth, Edge, typical	MDO4104-X	1 GHz	
	MDO4054-X	500 MHz	
	MDO4034-3	350 MHz	
	MDO4014-3	100 MHz	
Trigger bandwidth, Pulse and Logic, typical	MDO4104-X	1 GHz	
	MDO4054-X	500 MHz	
	MDO4034-3	350 MHz	
	MDO4014-3	100 MHz	
Edge-type trigger sensitivity, DC coupled, typical	Model	Trigger Source	Sensitivity
	MDO4104-X	Any input	50 Ω path:
		channel	0.40 div from DC to 50 MHz, increasing to 1 div at oscilloscope bandwidth
	MDO4054-X, MDO4034-3, MDO4014-3	Any input channel	50 Ω path:
			1 mV/div to 4.98 mV/div — 0.75 div from DC to 50 MHz, increasing to 1.3 div at oscilloscope bandwidth.
			≥5 mV/div — 0.40 div from DC to 50 MHz, increasing to 1 div at oscilloscope bandwidth.
	All models	Any input channel	1 MΩ path:
			1 mV/div to 4.98 mV/div – 0.75 div from DC to 50 MHz, increasing to 1.3 div at oscilloscope bandwidth.
			≥5 mV/div – 0.40 div from DC to 50 MHz, increasing to 1 div at oscilloscope bandwidth.
	All models	Line	Fixed
Trigger jitter, typical	≤10 ps _{RMS} for edge-type trigg	er	
	≤100 ps _{RMS} for non edge-type	e trigger modes	

Table 4: Trigger specifications (cont.)

Characteristic	Description			
Edge-type trigger sensitivity, not DC	Trigger Coupling	Typical Sei	nsitivity	
coupled, typical	AC Coupling	1 div for fre	quencies above 45	5 Hz.
		Attenuates	signals below 45 H	łz.
	NOISE REJ	2.5 times the	ne DC-coupled limit	ts
	HF REJ		ne DC-coupled limi signals above 50 k	ts from DC to 50 kHz. Hz
	LF REJ		ne DC-coupled limitenuates signals be	ts for frequencies above low 50 kHz
Video-type trigger formats and field rates	Triggers from negative sync composite video, field 1, or field 2 for interlaced systems, on any field, specific line, or any line for interlaced or noninterlaced systems. Supported systems include NTSC, PAL, and SECAM.			
Video-type trigger sensitivity, typical	Delayed and main trig	ger		
	Source	Sensitivity		
	Any input channel	0.6 to 2.5 d	livisions of video sy	vnc tip
Lowest frequency for successful operation of "Set Level to 50%" function, typical	45 Hz			
Logic-type or logic qualified trigger or events-delay sensitivities, DC coupled, typical	1.0 division from DC to	maximum bandwidt	n	
Pulse-type runt trigger sensitivities, typical	1.0 division from DC to maximum bandwidth			
Pulse-type trigger width and glitch sensitivities, typical	1.0 division			
Logic-type triggering, minimum logic	For all vertical settings	, the minimums are:		
or rearm time, typical	Trigger type	Pulse width	Re-arm time	Time between channels
	Logic	Not applicable	2 ns	1 ns
	Time Qualified Logic	4 ns	2 ns	1 ns
	more than one channe	I must exist to be reco	ognized. For events	e a logic state derived from s, the time is the minimum time ore than one channel is used.
Minimum clock pulse widths for	For all vertical settings	, the minimums are:		
setup/hold time violation trigger,	Clock active	Clock inact	ive	
typical	User hold time + 2.5 ns	s 2 ns		
		el menu item) to its in	active edge. An ina	tive edge (as defined in the active pulse width is the width
	The user hold time is t	he number selected I	by the user.	

Table 4: Trigger specifications (cont.)

Catus/bald violation trigger patus	Footure	Min	Mov	
Setup/hold violation trigger, setup and hold time ranges	Feature	–0.5 ns	Max 1.0 ms	
	Setup time			
	Hold time	1 ns	1.0 ms	
	Setup + Hold time	0.5 ns	2.0 ms	
	Input coupling on clock and data channels must be the same.			
	For Setup time, positive num			
	For Hold time, positive numbers mean a data transition after the clock edge.			
	Setup + Hold time is the alg programmed.	ebraic sum of the	Setup Time and Hold Time that you	
Pulse type trigger, minimum pulse, rearm time, transition time	Pulse class	Minimum pulse width	Minimum rearm time	
	Glitch	4 ns	2 ns + 5% of glitch width setting	
	Runt	4 ns	2 ns	
	Time-qualified runt	4 ns	8.5 ns + 5% of width setting	
	Width	4 ns	2 ns + 5% of width upper limit setting	
	Slew rate (transition time)	4 ns	8.5 ns + 5% of delta time setting	
	For the trigger class width and the trigger class runt, the pulse width refers to the width of the pulse being measured. The rearm time refers to the time between pulses.			
			refers to the delta time being measured. The I to cross the two trigger thresholds again.	
Transition time trigger, delta time range	4 ns to 8 s			
Time range for glitch, pulse width, timeout, time-qualified runt, or time-qualified window triggering	4 ns to 8 s			
Time Accuracy for Pulse, Glitch,	Time Range	Accuracy		
Timeout, or Width Triggering	1 ns to 500 ns	±(20% of sett	ting + 0.5 ns)	
	520 ns to 1 s		etting + 100 ns)	
B trigger after events, minimum pulse width and maximum event frequency, typical	4 ns, 500 MHz	,	,	
B trigger, minimum time between	4 ns			
arm and trigger, typical		the time between	the end of the time period and the B trigger	
	For trigger after events, this event.	is the time betwee	en the last A trigger event and the first B trigger	
B trigger after time, time range	4 ns to 8 seconds			
B trigger after events, event range	1 to 4,000,000			

Table 4: Trigger specifications (cont.)

Trigger level ranges	Source	Range	
	Any input channel	±8 divisions from center of screen	
		±8 divisions from 0 V when vertical LF reject trigger coupling is selected	
	Line	Not applicable	
	Line trigger level is fixed at about 50%	% of the line voltage.	
	This specification applies to logic and	I pulse thresholds.	
Trigger level accuracy, DC coupled,	For signals having rise and fall times	≥10 ns.	
typical	Source	Range	
	Any input channel	±0.20 div	
	Line	Not applicable	
Trigger holdoff range	20 ns minimum to 8 s maximum		
Maximum serial trigger bits	128 bits		
Standard serial bus interface triggering			
I ² C	Address Triggering: 7 and 10 bit us byte, HS-mode, EEPROM, and CBUS	er specified addresses, as well as General Call, START S	
	Data Trigger: 1 to 5 bytes of user specified data		
	Trigger On: Start, Repeated Start, Stop, Missing Ack, Address, Data, or Address and Data		
	Maximum Data Rate: 10 Mbps		
SPI	Data Trigger: 1 to 16 bytes of user-s	specified data	
	Trigger On: SS Active, MOSI, MISO, or MOSI & MISO		
	Maximum Data Rate: 50 Mbps		
CAN		ecified data, including qualifiers of equal to (=), not equal , less than or equal to (<=), greater than or equal to (>=)	
	Trigger On: Start of Frame, Type of Frame, Missing Ack, or Bit Stuffing E	Frame, Identifier, Data, Identifier and Data, End of rrors	
	Frame Type: Data, Remote, Error, C	Overload	
	Identifier: Standard (11 bit) and Extended (29 bit) identifiers		
	Maximum Data Rate: 1 Mbps		
LIN	Identifier Trigger: 6 bits of user-spec	cified data, equal to (=)	
		pecified data, including qualifiers of equal to (=), not han (>), less than or equal to (<=), greater than or erange	
	Error: Sync, Identifier Parity, Checks	sum	
	Trigger On: Sync, Identifier, Data, Identifier, Data, Identifier, Data	entifier & Data, Wakeup Frame, Sleep Frame, or Error	
	Maximum Data Rate: 100 kbps		

Table 4: Trigger specifications (cont.)

FlexRay	Indicator bits: Normal Frame, Payload Frame, Null Frame, Sync Frame, Startup Frame
	Identifier Trigger : 11 bits of user-specified data, equal to (=), not equal to (<>), less than (<), greater than (>), less than or equal to (<=), greater than or equal to (>=), Inside Range, or Outside Range
	Cycle Count Trigger: 6 bits of user-specified data, equal to (=)
	Header Fields Trigger : 40 bits of user-specified data comprising Indicator Bits, Identifier, Payload Length, Header CRC, Cycle Count, or equal to (=)
	Data Trigger: 1 to 16 Bytes of user-specified data, with 0 to 253, or "don't care" bytes of data offset, including qualifiers of equal to (=), not equal to <>, less than (<), greater than (>), less than or equal to (<=), greater than or equal to (>=), Inside Range, Outside Range
	End Of Frame: User-chosen types Static, Dynamic (DTS), and All
	Error: Header CRC, Trailer CRC, Null Frame-static, Null Frame-dynamic, Sync Frame, Startup Frame
	Trigger On: Start of Frame, Indicator Bits, Identifier, Cycle Count, Header Fields, Data, Identifier & Data, End of Frame, or Error
	Maximum Data Rate: 100 Mbps
ıdio	
12S	Data Trigger: 32 bits of user-specified data in a left word, right word, or either, including qualifiers of equal to (=), not equal to <>, less than (<), greater than (>), less than or equal to (<=), greater than or equal to (>=), inside range, outside range
	Trigger on: Word Select, Data
	Maximum Data Rate: 12.5 Mbps
Left Justified	Data Trigger: 32 bits of user-specified data in a left word, right word, or either, including qualifiers of equal to (=), not equal to <>, less than (<), greater than (>), less than or equal to (<=), greater than or equal to (>=), inside range, outside range
	Trigger on: Word Select, Data
	Maximum Data Rate: 12.5 Mbps
Right Justified	Data Trigger: 32 bits of user-specified data in a left word, right word, or either, including qualifiers of equal to (=), not equal to <>, less than (<), greater than (>), less than or equal to (<=), greater than or equal to (>=), inside range, outside range
	Trigger on: Word Select, Data
	Maximum Data Rate: 12.5 Mbps
TDM	Data Trigger: 32 bits of user-specified data in a channel 0-7, including qualifiers of equal to (=), not equal to <>, less than (<), greater than (>), less than or equal to (<=), greater than or equal to (>=), inside range, outside range
	Trigger on: Frame Sync, Data
	Maximum Data Rate: 25 Mbps
RS-232	Bit Rate: 50 bps to 10 Mbps
	Data Bits: 7, 8, or 9
	Parity: None, Odd, or Even
	Trigger on: Tx Start bit, Rx Start bit, Tx End of Packet, Rx End of Packet, Tx Data, Rx Data, Tx Parity Error, Rx Parity Error
	End of Packet: 00 (NUL), OA (LF), OD (CR), 20 (SP), FF

Table 4: Trigger specifications (cont.)

MIL-STD-1553	Bit Rate: 1 Mb/s
	Trigger on: Sync, Word Type (Command, Status, Data), Command Word (set RT Address $(=, \neq, <, >, \leq, \geq, inside range, outside range)$, T/R, Sub-address/Mode, Data Word Count/Mode Code, and Parity individually), Status Word (set RT Address ($(=, \neq, <, >, \leq, \geq, inside range, outside range)$, Message Error, Instrumentation, Service Request Bit, Broadcast Command Received, Busy, Subsystem Flag, Dynamic Bus Control Acceptance (DBCA), Terminal Flag, and Parity individually) Data Word (user-specified 16-bit data value) Error (Sync, Parity, Manchester, Non-contiguous data) Idle Time (minimum time selectable from 4 μ s to 100 μ s; maximum time selectable from 12 μ s to 100 μ s; trigger on < minimum, > maximum, inside range, outside range)
USB	Data Rates Supported: HS: 480 Mbps, Full: 12 Mbps, Low: 1.5 Mbps
	Trigger On: Sync, Reset, Suspend, Resume, End of Packet, Token (Address) Packet, Data Packet, Handshake Packet, Special Packet, Error
	NOTE. HIGH SPEED support available only on MDO4104-3 and MDO4104-6 models.
Ethernet	Bit Rate: 10BASE-T, 10 Mbps; 100BASE-TX, 100 Mbps
	Trigger On: Start Frame Delimiter (SFD), MAC Address, MAC Length/Type, IP Header, TCP Header, TCP/IPv4/MAC Client Data, End of Packet, Idle, FCS (CRC) Error, MAC Q-Tag control Information.

Digital Acquisition System Specifications

The following table shows the digital acquisition specifications for the MDO4000 Series oscilloscopes.

Table 5: Digital acquisition specifications

Characteristic	Description		
Threshold voltage range	–40 V to +40 V		
Digital channel timing resolution	2 ns main memory, 60.6 ps for MagniVu memory		
Logic threshold accuracy	±(100 mV + 3% of threshold setting after calibration)		
	Requires valid SPC, as described in step 2 of the Self Test. (See page 62, Self Test.)		
Minimum detectable pulse width,	1 ns		
typical	Using MagniVu memory. Requires the use of 342-1140-00 ground clip on each channel.		

P6616 Digital Probe Input Specifications

The following table shows the P6616 Digital Probe specifications.

Table 6: P6616 digital probe input specifications

Characteristic	Description	
Number of channels	16 digital inputs	
Input resistance, typical	100 kΩ to ground	
Input capacitance, typical	3.0 pF	
	Measured at the podlet input. Requires the use of 342-1140-00 ground clip on each channel	
Minimum input signal swing, typical	400 mV _{p-p}	
	Requires the use of 342-1140-00 ground clip on each channel	
Maximum input signal swing, typical	30 V_{pp} for $f_{in} \le 200$ MHz (centered around the DC threshold voltage) at the P6616 probe tip.	
	10 $V_{\text{p-p}}$ for $f_{\text{in}}\!>\!\!200$ MHz (centered around the DC threshold voltage) at the P6616 probe tip.	
	Failure to meet this input signal requirement will compromise the AC performance of the digital channel. It might also damage the input circuitry. See the Absolute maximum input voltage specification.	
Maximum Input Toggle Rate, typical	500 MHz	
	Maximum frequency sine wave input (at the minimum signal swing amplitude) that can accurately be reproduced as a logic square wave.	
	Requires the use of a 342-1140-00 ground clip on each channel.	
	Higher toggle rates can be achieved with higher amplitudes.	
Absolute maximum input voltage, typical	±42 V peak at the P6616 input (not at the instrument input)	
	Probe input voltages beyond this limit could permanently damage the instrument and the P6616 probe.	
Channel-to-channel skew, typical	200 ps	
	Digital channel to digital channel only.	
	This is the propagation path skew and ignores skew contributions due to threshold inaccuracies (see Threshold accuracy) and sample binning (see Digital channel timing resolution). Factory calibration/deskew is required to achieve this number.	

RF Input Specifications

The following table shows the RF input specifications for the MDO4000 Series oscilloscopes.

Table 7: RF input specifications

Characteristic	Description		
Center frequency range	MDO4104-6, MDO4054-6 50 kHz to 6 GHz		
	MDO4104-3, MDO4054-3, 50 kHz to 3 GHz MDO4034-3, MDO4014-3		
Frequency measurement resolution	1 Hz		
Span	Span adjustable in 1-2-5 sequence		
	Variable resolution = 1% of the next span setting		
	The MDO4XX4-6 Span is adjustable from 1 kHz to 6 GHz		
	The MDO4XX4-3 Span is adjustable from 1 kHz to 3 GHz		
Resolution bandwidth (RBW)	Adjustable in 1-2-3-5 sequence. Maximum of 10 MHz RBW		
	Minimum RBW for Windowing functions as follows:		
	30 Hz Kaiser, Blackman-Harris		
	20 Hz Rectangular, Hamming, Hanning		
	50 Hz Flat-Top		
	60 dB/3 dB shape factor (Kaiser, Blackman-Harris) 4:1 ratio		
Input vertical range	Vertical measurement range +30 dBm to DANL.		
	Vertical setting of 1 dB/div to 20 dB/div in a 1-2-5 sequence		
	Attenuator settings from 0 to 45 dB, in 5 dB steps		
Level display range	Log scale and units: dBm, dBmV, dBμV, dBμW, dBmA, dBμA		
	Measurement points: 1000		
	Marker level readout resolution: Log scale: 0.1 dB		
	Maximum number of RF traces: 4		
	Trace functions: maximum hold, average, minimum hold, normal, spectrogram slice (uses normal trace)		
	Detection methods: Positive-Peak, negative-peak, sample, average		
Reference level	Setting range: -140 dBm to +30 dBm, in steps of 5 dBm		
	Default setting: 0 dBm		
Vertical position	–10 divisions to +10 divisions (displayed in dB)		
Maximum operating input level	Average continuous power: +30 dBm (1W)		
	DC maximum before damage: ±40 Vdc		
	Maximum "no damage" 33 dBm (2W) CW		
	Peak pulse power: +45 dBm (32W)		
	Peak Pulse Power is defined as: <10 us pulse width, <1% duty cycle, and a reference level of ≥ +10 dBm.		

Table 7: RF input specifications (cont.)

Characteristic	Description		
Frequency measurement accuracy	Marker Frequency		
	All models: ±(Reference Frequency Error * MarkerFrequency + .001 * span + 2) Hz.		
	Marker Frequency with Span/RBW ≤ 1000:1		
	Reference frequency error =	±5 ppm	
✓ Phase noise	10 kHz offset: < -90 dBc/Hz	(< –95 dBc/Hz, typical)	
	100 kHz offset: < -95 dBc/H	z (< –98 dBc/Hz, typical)	
	1 MHz offset: < -113 dBc/Hz (< -118 dBc/Hz, typical)		
Residual FM, typical	≤100 Hz peak-to-peak in 10	0 ms	
Resolution bandwidth (RBW) accuracy	Max RBW % Error = (0.5/(2	5 x WF)) * 100	
	WF =		
	Rectangular: 0.89		
	Hamming: 1.30		
	Hanning: 1.44		
	Blackman-Harris: 1.90		
	Kaiser: 2.23		
	Flat-Top: 3.77		
✓ Displayed average noise level	MDO4104-6	50 kHz to 5 MHz:	
(DANL)	MDO4054-6	< –130 dBm/Hz (< –134 dBm/Hz, typical)	
		5 MHz to 3 GHz:	
		< -148 dBm/Hz (< -152 dBm/Hz, typical)	
		3 GHz to 6 GHz:	
		< -140 dBm/Hz (< -143 dBm/Hz, typical)	
	MDO4104-3, MDO4054-3,	50 kHz to 5 MHz:	
	MDO4034-3, MDO4014-3	< -130 dBm/Hz (< -134 dBm/Hz, typical)	
		5 MHz to 3 GHz:	
		< -148 dBm/Hz (< -152 dBm/Hz, typical)	
1 dB gain compression	>5 dBm		
	With reference level set to -10 dBm		
Level measurement uncertainty		0 °C to 30 °C temperature range, reference level 10 dBm to g from reference level to 30 dB below reference level.	
		a < 20 °C temperature range, reference level 10 dBm to –25 m reference level to 30 dB below reference level.	

Table 7: RF input specifications (cont.)

Characteristic	Description		
Spurious response	2nd and 3rd harmonic distortion >100 MHz: < -55 dBc (< -60 dBc Typical)		
	With auto settings on, signals –5 dB below reference level		
	2nd and 3rd harmonic distortion: >50 kHz: < -55 dBc (< -60 dBc Typical)		
	With auto settings on, signals –5 dB below reference level, and reference level ≤ -15 dBm		
	2nd order intermodulation distortion: >200 MHz: < -55 dBc (< -60 dBc Typical)		
	With auto settings on and signals -5 dB below reference level		
	2nd order intermodulation distortion: >50 kHz: < -55 dBc (< -60 dBc Typical)		
	With auto settings on, signals –5 dB below reference level, and reference level ≤ –15 dBm		
	Other A/D spurs: < -55 dBc (< -60 dBc Typical)		
Third order intermodulation	3rd order intermodulation distortion >15 MHz: < -60 dBc (< -63 dBc Typical)		
distortion	With auto settings on, signals –5 dB below reference level		
	3rd order intermodulation distortion >50 kHz: < -60 dBc (< -63 dBc Typical)		
	With auto settings on, signals –5 dB below reference level, and reference level ≤ –15 dBm		
Image and IF rejection	< –50 dBc (< –55 dBc typical)		
	With –10 dBm reference level		
✓ Residual spurious response	< –78 dBm		
	With \leq -25 dBm reference level and RF input terminated with 50 Ω .		
Power level trigger frequency and	Frequency range:		
amplitude range	1 MHz to 6 GHz (MDO4XX4-6 models)		
	1 MHz to 3 GHz (MDO4XX4-3 models)		
	Amplitude range: 30 dBm to -40 dBm		
RF to analog channel skew, typical	Maximum time between analog channels triggered and RF channel:		
	< 5 ns		
Power level trigger limits	Center frequency 1 MHz to 3.25 GHz: –35 dB from reference level		
	Center frequency >3.25 GHz: -13 dB from reference level		
	Minimum pulse duration: 10 μs ON time with a minimum settling OFF time of 10 μs.		
Crosstalk to RF channel from	< -68 dB from reference level (≤1 GHz oscilloscope input frequencies)		
analog channels	< -48 dB from reference level (>1 GHz to 2 GHz oscilloscope input frequencies)		
	Full scale amplitude with 50 Ω input and 100 mV/div vertical setting with direct input (no probes).		
Channel power accuracy, Typical	< ±1 dB (<±0.5 dB Typical) 20-30 °C temperature range		
	< ±1.5 dB, Ta >30 °C and Ta <20 °C temperature range		
Occupied bandwidth accuracy, Typical	± Span/1000		
Adjacent channel power ratio, Typical	-58 dBc		

Display System Specifications

The following table shows the display specifications for the MDO4000 Series oscilloscopes.

Table 8: Display system specifications

Characteristic	Description
Display type	Display area: 210.4 mm (8.28 in) (H) x 157.8 mm (6.21 in) (V), 264 mm (10.4 in) diagonal, 6-bit RGB full color, XGA (1024 x 768) TFT liquid crystal display (LCD).
Display resolution	1024 X 768 XGA display resolution
Luminance, typical	400 cd/m ²
Waveform display color scale	The TFT display can support up to 262,144 colors. A subset of these colors is used for the oscilloscope display. The colors that are used are fixed and not changeable by the user.

Interfaces and Input/Output Port Specifications

The following table shows the interfaces and input/output port specifications for the MDO4000 Series oscilloscopes.

Table 9: Interfaces and Input/Output port specifications

Characteristic	Description	
Ethernet interface	Standard on all models: 10/100/1000 Mbps	
GPIB interface	Available as an optional accessory (TEK-USB-488 GPIB to USB Adapter), which connects to the USB Device and USB Host port.	
	The control interface is incorporated into the instrument user interface.	
Video signal output	A 15-pin D-sub VGA connector.	
USB interface	4 USB host connectors (2.0 HS), two on the instrument front and two on the rear.	
	1 USB device connector (2.0 HS), on the instrument rear panel.	
	All are standard on all models.	
Probe compensator output voltage	Output Voltage	
and frequency, typical	Default: $0 - 2.5 \text{ V}$ amplitude, $\pm 2\%$ (Source Impedance of $1k\Omega$)	
	TPPXX00 Cal Mode: 0 – 2.5 V amplitude, ± 5% (Source Impedance of ≤25Ω)	
	Frequency	
	1 kHz, ± 25%	
✓ Auxiliary output (AUX OUT)	You can set the Auxiliary output to Trigger Out or Reference Clock Out.	
Trigger Out or	Reference Clock Out: Outputs the 10 MHz oscilloscope reference clock.	
Reference Clock Out	Trigger Out: A HIGH to LOW transition indicates that the trigger occurred.	
	Trigger output logic levels	
	Characteristic Limits	
	Vout (HI) ≥2.5 V open circuit	
	≥1.0 V into a 50 Ω load to ground	
	Vout (LO) ≤0.7 V into a load of ≤4 mA	
	≤0.25 V into a 50 Ω load to ground	
External Reference nominal input	10 MHz	
frequency	You must select either the internal reference (default) or 10 MHz external.	
External Reference input frequency	9.9 MHz to 10.1 MHz	
variation tolerance, typical	You must run SPC, described in step 2 of the <i>Self Test</i> , whenever the external reference is more than 0.2% (2000 ppm) different than the nominal reference frequency or reference at which SPC was last run. (See page 62, <i>Self Test</i> .) The time base changes in correspondence to the fluctuations in the external reference.	
External Reference input sensitivity, typical	1.5 V _{p-p} for input frequencies between 9.9 MHz and 10.1 MHz	
External Reference input maximum input signal	7 V _{p-p}	
External Reference input impedance, typical	Rin = 1.5 k Ω ±20% in parallel with 15 pF ±5 pF at 10 MHz	

Data Handling Specifications

The following table shows the data handling specifications for the MDO4000 Series oscilloscopes.

Table 10: Data handling specifications

Characteristic	Description
Nonvolatile memory retention time,	No time limit for front-panel settings, saved waveforms, setups, or calibration constants.
typical	10 M and 20 M records saved as Reference waveforms are not saved in the nonvolatile memory and they will not be saved across a power cycle.
Real-time clock	A programmable clock providing time in years, months, days, hours, minutes, and seconds

Power Supply System Specifications

The following table shows the power supply system specifications for the MDO4000 Series oscilloscopes.

Table 11: Power supply system specifications

Characteristic	Description
Operating line frequency and voltage	Volts: 100 – 240; Hz: 50 – 60
range	Volts: 115: Hz: 400
Maximum power consumption:	225 W
Source voltage	100 V to 240 V ±10%
Source frequency	(85 to 264 V) 45 Hz to 66 Hz
	(100 V to 132 V) 360 Hz to 440 Hz
Fuse rating	T6.3AH, 250 VAC
	The fuse cannot be replaced by the user.

Environmental Specifications

The following table shows the environmental specifications for the MDO4000 Series oscilloscopes.

Table 12: Environmental specifications

Characteristic	Description	
Temperature	Operating: 0 °C to +50 °C (32 °F to +122 °F)	
	Nonoperating: -20 °C to +60 °C (-4 °F to +140 °F)	
Humidity	Operating:	
	High: 40 °C to 50 °C (104 °F to 122 °F), 10% to 60% relative humidity	
	Low: 0 °C to 40 °C (32 °F to 104 °F), 10% to 90% relative humidity	
	Nonoperating:	
	High: 40 °C to 60 °C (104 °F to 140 °F), 5% to 60% relative humidity	
	Low: 0 °C to 40 °C (32 °F to 104 °F), 5% to 90% relative humidity	
Altitude	Operating: 3,000 m (9,843 ft)	
	Nonoperating: 12,000 m (39,370 ft)	
Pollution Degree	Pollution Degree 2, indoor use only	

Mechanical Specifications

The following table shows the mechanical specifications for the MDO4000 Series oscilloscopes.

Table 13: Mechanical specifications

Characteristic	Description
Weight	Benchtop configuration (oscilloscope only)
	Requirements that follow are nominal: 11.0 lbs (5.0 kg), stand-alone instrument, without front cover. 18.8 lbs (8.5 kg), instrument with rackmount, without front cover 23.6 lbs (10.7 kg), when packaged for domestic shipment (without rackmount)
Dimensions	Benchtop configuration (oscilloscope only)
	Requirements that follow are nominal and unboxed Height: 9.0 in (229 mm) feet folded in, handle folded down 9.8 in (249 mm) feet folded out, handle folded down 11.5 in (292 mm) feet folded in, handle folded up 12.3 in (312 mm) feet folded out, handled folded up
	Width: 17.3 in (439 mm) from handle hub to handle hub
	Depth: 5.8 in (147 mm) from back of feet to front of knobs 6.1 in (155 mm) from back of feet to front of front cover 9.8 in (249 mm) from handle to front of knobs (handle folded to back side of unit)
	Box Dimensions: Height: 15.7 in (399 mm) Width: 15.6 in (396 mm) Length: 22.2 in (564 mm)
	Rackmount configuration Requirements that follow are nominal and unboxed (5U rack sizes): Height: 8.6 in (218 mm) Width: 19.2 in (488 mm), from outside of handle to outside of handle Depth: 15.1 in (384 mm), from outside of handle to back of slide
Clearance Requirements	0 mm (0 in), top
	0 in (0 mm), bottom, on feet, with flip stands down
	2 in (50.8 mm), left side (facing the front of the instrument)
	0 in (0 mm), right side (facing the front of the instrument)
	2 in (50.8 mm), rear (where the power cord is plugged in)

TPA-N-PRE Specifications

The following tables shows the TPA-N-PRE Preamplifier specifications.

Table 14: TPA-N-PRE specifications

Characteristic	Description	
Frequency range	Preamp: 9 kHz to 6 GHz	
	MDO4XX4-6 with preamp: 50 kHz to 6 GHz	
	MDO4XX4-3 with preamp: 50 kHz to 3 GHz	
Preamp gain	Amplifying state: 12 dB (nominal)	
	Bypass state: -1.5 dB (nominal)	
Displayed average noise level	With the preamp mode set to "Auto" and the reference level set to -40 dBm	
(DANL) of the MDO4000 with the	MDO4XX4-6:	
preamp attached to the MDO's RF input	50 kHz to 5 MHz: < –140 dBm/Hz (–144 dBm/Hz typical)	
mpat	5 MHz to 3 GHz: < –158 dBm/Hz (–162 dBm/Hz typical)	
	3 GHz to 6 GHz: < –150 dBm/Hz (–153 dBm/Hz typical)	
	MDO4XX4-3:	
	50 kHz to 5 MHz: < -140 dBm/Hz (-144 dBm/Hz typical)	
	5 MHz to 3 GHz: < –158 dBm/Hz (–162 dBm//Hz typical)	
Level measurement uncertainty of the MDO4000 with the preamp attached to the MDO's RF input	With the preamp mode set to "Auto", reference level 10 dBm to -40 dBm and input level ranging from reference level to 30 dB below reference level. Specifications exclude mismatch error at the preamp input and applies to both amplifying and bypass states.	
	< ±1.5 dB (typical), 20 °C to 30 °C temperature range.	
	≤ ±2.3 dB (typical), over full operating range.	
Maximum operating input level of the	Average continuous power: +30 dBm (1 W)	
MDO4000 with the preamp attached	DC maximum before damage: ±20 V DC	
to the MDO's RF input	Maximum power before damage (CW): +30 dBm (1 W)	
	Maximum power before damage (pulse): +45 dBm (32 W)	
	(<10 µs pulse width, <1% duty cycle, and reference level of ≥ +10 dBm)	
Reference level range of the	Amplifying state: -30 dBm to DANL	
MDO4000 with the preamp attached to the MDO's RF input	Bypass state: +30 dBm to DANL	
Connector type	SMA – female (outside threads)	
Temperature	Operating: 0 °C to +50 °C	
	Non-operating: -20 °C to +60 °C	
Humidity	Operating:	
	High: 40 °C to 50 °C (104 °F to 122 °F), 10% to 60% RH	
	Low: 0 °C to 40 °C (32 °F to 104 °F), 5% to 90% RH	
	Non-operating:	
	High: 40 °C to 50 °C (104 °F to 122 °F), 10% to 60% RH	
	Low: 0 °C to 40 °C (32 °F to 104 °F), 5% to 90% RH	

Specifications

Characteristic	Description	
Altitude	Operating: Up to 3,000 meters	
	Non-operating: Up to 12,000 meters	
Power requirements	The TPA-N-PRE is powered directly from the RF input on the MDO4000 Series oscilloscope	
Regulatory	Compliance labeling: WEEE (European Union)	
Recommended oscilloscopes	MDO4000 Mixed Domain Oscilloscopes	
	NOTE. For best probe support, download and install the latest version of the oscilloscope firmware from www.tektronix.com	

Performance Verification

The performance verification procedures verify the performance of your instrument. They do not adjust your instrument. If your instrument fails any of the performance verification tests, you should contact Tektronix to have the factory adjustment performed. See the contact information on the back of the title page of this manual.

This section contains performance verification procedures for the specifications marked with the \checkmark symbol. These procedures cover all MDO4000 Series models. Please ignore checks that do not apply to the specific model you are testing.

Print the test record on the following pages and use it to record the performance test results for your oscilloscope.

NOTE. Completion of the performance verification procedure does not update the stored time and date of the latest successful adjustment. The date and time are updated only when the instrument is adjusted by Tektronix.

The following equipment, or a suitable equivalent, is required to complete these procedures. You might need additional cables and adapters, depending on the actual test equipment you use.

Table 15: Required equipment

Description	Minimum requirements	Examples
DC voltage source	3 mV to 4 V, ±0.1% accuracy	Fluke 9500B Oscilloscope Calibrator with
Leveled sine wave generator	50 kHz to 1000 MHz, ±4% amplitude accuracy	a 9510 Output Module
Time mark generator	80 ms period, ±1 ppm accuracy, rise time < 50 ns	
Signal generator	Frequency: to at least 6 GHz Frequency accuracy: 5 ppm	Anritsu MG3692B Options 2A, 3A, 4, 15A, 16, 22, SM5821
	requestly accountry to ppos	Rohde & Schwarz SMT06
		(Two generators are needed for checking Third Order Intermodulation Distortion)
Hybrid coupler (power combiner)	Connects the output of two generators to the oscilloscope RF input	Krytar 3005070
Logic probe	Low capacitance digital probe, 16 channels.	P6616 probe; standard accessory shipped with MDO4000 Series oscilloscopes.
BNC-to-0.1 inch pin adapter to connect the logic probe to the signal source.	BNC-to-0.1 inch pin adapter; female BNC to 2x16. 01 inch pin headers.	Tektronix adapter part number 679-6240-00; to connect the Fluke 9500B to the P6616 probe.
Digital multimeter (DMM)	0.1% accuracy or better	Fluke 177 Series Digital Multimeter
Power meter		Agilent N1913A Single-Channel Power Meter
Power head	Frequency range at least 50 kHz – 6 GHz	Agilent E9304A Average Power Sensor
Power splitter		Agilent 11667A Power Splitter
Male N-N adapter		For connecting between the power splitter ad the oscilloscope RF Input
One 50 Ω terminator	Impedance 50 Ω; connectors: female BNC input, male BNC output	Tektronix part number 011-0049-02
One 50 Ω terminator	Impedance 50 Ω; Male N connector	For terminating the RF Input
One 50 Ω BNC coaxial cable	Male-to-male connectors	Tektronix part number 012-0057-01
One 50 Ω SMA coaxial cable	N connector to SMA	
Three SMA cables	With the correct connector to fit your generator output.	Tektronix part number 174-6025-00 (6 ft) Tektronix part number 174-6026-00 (2 ft)

Test Record

Model	Serial	Procedure performed by	Date

Test Passed Failed
Self Test

Input Impedance

Performance checks	Vertical scale	Low limit	Test result	High limit	
Channel 1 Input	10 mV/div	990 kΩ		1.01 ΜΩ	
Impedance, 1 $M\Omega$	100 mV/div	990 kΩ		1.01 ΜΩ	
	1 V/div	990 kΩ		1.01 ΜΩ	
Channel 1 Input Impedance, 250 kΩ	100 mV/div	245 kΩ		255 kΩ	
Channel 1 Input	10 mV/div	49.5 Ω		50.5 Ω	
Impedance, 50 Ω	100 mV/div	49.5 Ω		50.5 Ω	
Channel 2 Input	10 mV/div	990 kΩ		1.01 ΜΩ	
Impedance, 1 MΩ	100 mV/div	990 kΩ		1.01 ΜΩ	
	1 V/div	990 kΩ		1.01 ΜΩ	
Channel 2 Input Impedance, 250 kΩ	100 mV/div	245 kΩ		255 kΩ	
Channel 2 Input	10 mV/div	49.5 Ω		50.5 Ω	
Impedance, 50 Ω	100 mV/div	49.5 Ω		50.5 Ω	
Channel 3 Input	10 mV/div	990 kΩ		1.01 ΜΩ	
Impedance, 1 MΩ	100 mV/div	990 kΩ		1.01 ΜΩ	
	1 V/div	990 kΩ		1.01 ΜΩ	
Channel 3 Input Impedance, 250 kΩ	100 mV/div	245 kΩ		255 kΩ	
Channel 3 Input	10 mV/div	49.5 Ω		50.5 Ω	
Impedance, 50 Ω	100 mV/div	49.5 Ω		50.5 Ω	
Channel 4 Input	10 mV/div	990 kΩ		1.01 ΜΩ	
Impedance, 1 MΩ	100 mV/div	990 kΩ		1.01 ΜΩ	
	1 V/div	990 kΩ		1.01 ΜΩ	
Channel 4 Input Impedance, 250 kΩ	100 mV/div	245 kΩ		255 kΩ	
Channel 4, Input	10 mV/div	49.5 Ω		50.5 Ω	
Impedance, 50 Ω	100 mV/div	49.5 Ω		50.5 Ω	

Performance checks	Vertical scale	Low limit	Test result	High limit
Channel 1 DC	1 mV/div	-0.2 mV		0.2 mV
Balance, 50 Ω, 20 MHz	2 mV/div	-0.2 mV		0.2 mV
BW	5 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-1 mV		1 mV
	20 mV/div	-2 mV		2 mV
	49.8 mV/div	-4.98 mV		4.98 mV
	50 mV/div	-5 mV		5 mV
	100 mV/div	-10 mV		10 mV
	200 mV/div	-20 mV		20 mV
	500 mV/div	-50 mV		50 mV
	1 V/div	-100 mV		100 mV
Channel 1 DC	1 mV/div	-0.2 mV		0.2 mV
Balance, 1 MΩ,	2 mV/div	-0.4 mV		0.4 mV
20 MHz BW	5 mV/div	-1 mV		1 mV
	10 mV/div	-2 mV		2 mV
	20 mV/div	-4 mV		4 mV
	100 mV/div	-20 mV		20 mV
	500 mV/div	-100 mV		100 mV
	1 V/div	-200 mV		200 mV
	10 V/div	-2 V		2 V
Channel 1 DC Balance, 50 Ω, 250 MHz BW	20 mV/div	-2 mV		2 mV
Channel 1 DC Balance, 1 MΩ, 250 MHz BW	20 mV/div	-4 mV		4 mV
Channel 1 DC Balance, 50 Ω, Full BW	20 mV/div	-2 mV		2 mV
Channel 1 DC Balance, 1 MΩ, Full BW	20 mV/div	-4 mV		4 mV

Performance checks	Vertical scale	Low limit	Test result	High limit
Channel 2 DC	1 mV/div	-0.2 mV		0.2 mV
Balance, 50 Ω, 20 MHz	2 mV/div	-0.2 mV		0.2 mV
3W	5 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-1 mV		1 mV
	20 mV/div	-2 mV		2 mV
	49.8 mV/div	-4.98 mV		4.98 mV
	50 mV/div	-5 mV		5 mV
	100 mV/div	-10 mV		10 mV
	200 mV/div	-20 mV		20 mV
	500 mV/div	-50 mV		50 mV
	1 V/div	-100 mV		100 mV
Channel 2 DC	1 mV/div	-0.2 mV		0.2 mV
Balance, 1 MΩ,	2 mV/div	-0.4 mV		0.4 mV
20 MHz BW	5 mV/div	-1 mV		1 mV
	10 mV/div	-2 mV		2 mV
	20 mV/div	-4 mV		4 mV
	100 mV/div	-20 mV		20 mV
	500 mV/div	-100 mV		100 mV
	1 V/div	-200 mV		200 mV
	10 V/div	-2 V		2 V
Channel 2 DC Balance, 50 Ω, 250 MHz BW	20 mV/div	-2 mV		2 mV
Channel 2 DC Balance, 1 MΩ, 250 MHz BW	20 mV/div	-4 mV		4 mV
Channel 2 DC Balance, 50 Ω, Full BW	20 mV/div	-2 mV		2 mV
Channel 2 DC Balance, 1 MΩ, Full BW	20 mV/div	-4 mV		4 mV

Performance checks	Vertical scale	Low limit	Test result	High limit
Channel 3 DC	1 mV/div	-0.2 mV		0.2 mV
Balance, 50 Ω, 20 MHz	2 mV/div	-0.2 mV		0.2 mV
BW	5 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-1 mV		1 mV
	20 mV/div	-2 mV		2 mV
	49.8 mV/div	-4.98 mV		4.98 mV
	50 mV/div	-5 mV		5 mV
	100 mV/div	-10 mV		10 mV
	200 mV/div	-20 mV		20 mV
	500 mV/div	-50 mV		50 mV
	1 V/div	-100 mV		100 mV
Channel 3 DC	1 mV/div	-0.2 mV		0.2 mV
Balance, 1 MΩ,	2 mV/div	-0.4 mV		0.4 mV
20 MHz BW	5 mV/div	-1 mV		1 mV
	10 mV/div	-2 mV		2 mV
	20 mV/div	-4 mV		4 mV
	500 mV/div	-100 mV		100 mV
	100 mV/div	-20 mV		20 mV
	1 V/div	-200 mV		200 mV
	10 V/div	-2 V		2 V
Channel 3 DC Balance, 50 Ω, 250 MHz BW	20 mV/div	-2 mV		2 mV
Channel 3 DC Balance, 1 MΩ, 250 MHz BW	20 mV/div	-4 mV		4 mV
Channel 3 DC Balance, 50 Ω, Full BW	20 mV/div	-2 mV		2 mV
Channel 3 DC Balance, 1 M Ω , Full BW	20 mV/div	-4 mV		4 mV

Performance checks	Vertical scale	Low limit	Test result	High limit
Channel 4 DC	1 mV/div	-0.2 mV		0.2 mV
Balance, 50 Ω, 20 MHz	2 mV/div	-0.2 mV		0.2 mV
BW	5 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-1 mV		1 mV
	20 mV/div	-2 mV		2 mV
	49.8 mV/div	-4.98 mV		4.98 mV
	50 mV/div	-5 mV		5 mV
	100 mV/div	-10 mV		10 mV
	200 mV/div	-20 mV		20 mV
	500 mV/div	-50 mV		50 mV
	1 V/div	-100 mV		100 mV
Channel 4 DC	1 mV/div	-0.2 mV		0.2 mV
Balance, 1 MΩ,	2 mV/div	-0.4 mV		0.4 mV
20 MHz BW	5 mV/div	-1 mV		1 mV
	10 mV/div	-2 mV		2 mV
	20 mV/div	-4 mV		4 mV
	500 mV/div	-100 mV		100 mV
	100 mV/div	-20 mV		20 mV
	1 V/div	-200 mV		200 mV
	10 V/div	-2 V		2 V
Channel 4 DC Balance, 50 Ω, 250 MHz BW	20 mV/div	-2 mV		2 mV
Channel 4 DC Balance, 1 MΩ, 250 MHz BW	20 mV/div	-4 mV		4 mV
Channel 4 DC Balance, 50 Ω, Full BW	20 mV/div	-2 mV		2 mV
Channel 4 DC Balance, 1 MΩ, Full BW	20 mV/div	-4 mV		4 mV

Performance checks	Bandwidth	Vertical scale	Low limit	Test result	High limit
MDO4104-3, MDO4104-6					
Channel 1	20 MHz	1 mV/div	-2.0%		2.0%
DC Gain Accuracy, 0 V offset, 0 V vertical		2 mV/div	-1.5%		1.5%
position, 50 Ω		5 mV/div	-1.5%		1.5%
p		10 mV/div	-1.5%		1.5%
		20 mV/div	-1.5%		1.5%
		49.8 mV/div	-3.0%		3.0%
		50 mV/div	-1.5%		1.5%
		100 mV/div	-1.5%		1.5%
		200 mV/div	-1.5%		1.5%
		500 mV/div	-1.5%		1.5%
		1 V/div	-1.5%		1.5%
	250 MHz	20 mV/div	-1.5%		1.5%
	Full	20 mV/div	-1.5%		1.5%
Channel 2	20 MHz	1 mV/div	-2.0%		2.0%
DC Gain Accuracy, 0 V offset, 0 V vertical		2 mV/div	-1.5%		1.5%
position, 50 Ω		5 mV/div	-1.5%		1.5%
, ,		10 mV/div	-1.5%		1.5%
		20 mV/div	-1.5%		1.5%
		49.8 mV/div	-3.0%		3.0%
		50 mV/div	-1.5%		1.5%
		100 mV/div	-1.5%		1.5%
		200 mV/div	-1.5%		1.5%
		500 mV/div	-1.5%		1.5%
		1 V/div	-1.5%		1.5%
	250 MHz	20 mV/div	-1.5%		1.5%
	Full	20 mV/div	-1.5%		1.5%

Performance checks	Bandwidth	Vertical scale	Low limit	Test result	High limit
MDO4104-3, MDO4104-6)				
Channel 3	20 MHz	1 mV/div	-2.0%		2.0%
DC Gain Accuracy,		2 mV/div	-1.5%		1.5%
0 V offset, 0 V vertical position, 50 Ω		5 mV/div	-1.5%		1.5%
pooro, oo <u></u>		10 mV/div	-1.5%		1.5%
		20 mV/div	-1.5%		1.5%
		49.8 mV/div	-3.0%		3.0%
		50 mV/div	-1.5%		1.5%
		100 mV/div	-1.5%		1.5%
		200 mV/div	-1.5%		1.5%
		500 mV/div	-1.5%		1.5%
		1 V/div	-1.5%		1.5%
	250 MHz	20 mV/div	-1.5%		1.5%
	Full	20 mV/div	-1.5%		1.5%
Channel 4	20 MHz	1 mV/div	-2.0%		2.0%
DC Gain Accuracy,		2 mV/div	-1.5%		1.5%
0 V offset, 0 V vertical position, 50 Ω		5 mV/div	-1.5%		1.5%
		10 mV/div	-1.5%		1.5%
		20 mV/div	-1.5%		1.5%
		49.8 mV/div	-3.0%		3.0%
		50 mV/div	-1.5%		1.5%
		100 mV/div	-1.5%		1.5%
		200 mV/div	-1.5%		1.5%
		500 mV/div	-1.5%		1.5%
		1 V/div	-1.5%		1.5%
	250 MHz	20 mV/div	-1.5%		1.5%
	Full	20 mV/div	-1.5%		1.5%

Performance checks	Bandwidth	Vertical scale	Low limit	Test result	High limit
All Models					
Channel 1	20 MHz	1 mV/div	-2.0%		2.0%
DC Gain Accuracy,		2 mV/div	-1.5%		1.5%
0 V offset, 0 V vertical position, 1 MΩ		5 mV/div	-1.5%		1.5%
pool		10 mV/div	-1.5%		1.5%
		20 mV/div	-1.5%		1.5%
		50 mV/div	-1.5%		1.5%
		63.5 mV/div	-3.0%		3.0%
		100 mV/div	-1.5%		1.5%
		200 mV/div	-1.5%		1.5%
		500 mV/div	-1.5%		1.5%
		1 V/div	-1.5%		1.5%
		5 V/div	-1.5%		1.5%
	250 MHz	20 mV/div	-1.5%		1.5%
	(Not applicable for the MDO4014-3)				
	FULL	20 mV/div	-1.5%		1.5%
Channel 2	20 MHz	1 mV/div	-2.0%		2.0%
DC Gain Accuracy,		2 mV/div	-1.5%		1.5%
O V offset, 0 V vertical position, 1 MΩ		5 mV/div	-1.5%		1.5%
		10 mV/div	-1.5%		1.5%
		20 mV/div	-1.5%		1.5%
		50 mV/div	-1.5%		1.5%
		63.5 mV/div	-3.0%		3.0%
		100 mV/div	-1.5%		1.5%
		200 mV/div	-1.5%		1.5%
		500 mV/div	-1.5%		1.5%
		1 V/div	-1.5%		1.5%
		5 V/div	-1.5%		1.5%
	250 MHz	20 mV/div	-1.5%		1.5%
	(Not applicable for the MDO4014-3)				
	FULL	20 mV/div	-1.5%		1.5%

Performance checks	Bandwidth	Vertical scale	Low limit	Test result	High limit
All Models					
Channel 3	20 MHz	1 mV/div	-2.0%		2.0%
DC Gain Accuracy, 0 V offset, 0 V vertical		2 mV/div	-1.5%		1.5%
position, 1 MΩ		5 mV/div	-1.5%		1.5%
,		10 mV/div	-1.5%		1.5%
		20 mV/div	-1.5%		1.5%
		50 mV/div	-1.5%		1.5%
		63.5 mV/div	-3.0%		3.0%
		100 mV/div	-1.5%		1.5%
		200 mV/div	-1.5%		1.5%
		500 mV/div	-1.5%		1.5%
		1 V/div	-1.5%		1.5%
		5 V/div	-1.5%		1.5%
	250 MHz	20 mV/div	-1.5%		1.5%
	(Not applicable for the MDO4014-3)				
	FULL	20 mV/div	-1.5%		1.5%
Channel 4	20 MHz	1 mV/div	-2.0%		2.0%
DC Gain Accuracy,		2 mV/div	-1.5%		1.5%
0 V offset, 0 V vertical position, 1 MΩ		5 mV/div	-1.5%		1.5%
pooluon, i miz		10 mV/div	-1.5%		1.5%
		20 mV/div	-1.5%		1.5%
		50 mV/div	-1.5%		1.5%
		63.5 mV/div	-3.0%		3.0%
		100 mV/div	-1.5%		1.5%
		200 mV/div	-1.5%		1.5%
		500 mV/div	-1.5%		1.5%
		1 V/div	-1.5%		1.5%
		5 V/div	-1.5%		1.5%
	250 MHz	20 mV/div	-1.5%		1.5%
	(Not applicable for the MDO4014-3)				
	101004014-3)				

DC Offset Accuracy

Performance checks	Vertical scale	Vertical offset 1	Low limit	Test result	High limit
All models:					
Channel 1	1 mV/div	900 mV	895.3 mV		904.7 mV
DC Offset Accuracy,	1 mV/div	-900 mV	-904.7 mV		-895.3 mV
20 MHz BW, 50 Ω	100 mV/div	5.0 V	4.965 V		5.035 V
	100 mV/div	-5.0 V	-5.035 V		-4.965 V
Channel 1	1 mV/div	900 mV	895.3 mV		904.7 mV
DC Offset Accuracy,	1 mV/div	-900 mV	-904.7 mV		-895.3 mV
20 MHz BW, 1 MΩ	100 mV/div	9.0 V	8.935 V		9.065 V
	100 mV/div	- 9.0 V	-9.065 V		-8.935 V
	500 mV/div	9.0 V	8.855 V		9.145 V
	500 mV/div	- 9.0 V	-9.145 V		-8.855 V
	1.01 V/div	99.5 V	98.80 V		100.2 V
	1.01 V/div	-99.5 V	-100.2 V		-98.80 V
	3 V/div	99.5 V	98.40 V		100.6 V
	3 V/div	-99.5 V	-100.6 V		-98.4 V
	5 V/div	99.5 V	98.00 V		101.0 V
	5 V/div	-99.5 V	-101.0 V		-98.00 V
Channel 2	1 mV/div	900 mV	895.3 mV		904.7 mV
DC Offset Accuracy,	1 mV/div	-900 mV	-904.7 mV		-895.3 mV
20 MHz BW, 50 Ω	100 mV/div	5.0 V	4.965 V		5.035 V
	100 mV/div	-5.0 V	-5.035 V		-4.965 V
Channel 2	1 mV/div	900 mV	895.3 mV		904.7 mV
DC Offset Accuracy,	1 mV/div	-900 mV	-904.7 mV		-895.3 mV
20 MHz BW, 1 MΩ	100 mV/div	9.0 V	8.935 V		9.065 V
	100 mV/div	-9.0 V	-9.065 V		-8.935 V
	500 mV/div	9.0 V	8.855 V		9.145 V
	500 mV/div	- 9.0 V	-9.145 V		-8.855 V
	1.01 V/div	99.5 V	98.80 V		100.2 V
	1.01 V/div	-99.5 V	-100.2 V		-98.80 V
	3 V/div	99.5 V	98.40 V		100.6 V
	3 V/div	-99.5 V	-100.6 V		-98.4 V
	5 V/div	99.5 V	98.00 V		101.0 V
	5 V/div	-99.5 V	-101.0 V		-98.00 V

DC Offset Accuracy

Performance checks	Vertical scale	Vertical offset 1	Low limit Test result	High limit
Channel 3	1 mV/div	900 mV	895.3 mV	904.7 mV
DC Offset Accuracy,	1 mV/div	-900 mV	-904.7 mV	-895.3 mV
20 MHz BW, 50 Ω	100 mV/div	5.0 V	4.965 V	5.035 V
	100 mV/div	-5.0 V	-5.035 V	-4.965 V
Channel 3	1 mV/div	900 mV	895.3 mV	904.7 mV
DC Offset Accuracy,	1 mV/div	-900 mV	-904.7 mV	-895.3 mV
20 MHz BW, 1 MΩ	100 mV/div	9.0 V	8.935 V	9.065 V
	100 mV/div	-9.0 V	-9.065 V	-8.935 V
	500 mV/div	9.0 V	8.855 V	9.145 V
	500 mV/div	- 9.0 V	-9.145 V	-8.855 V
	1.01 V/div	99.5 V	98.80 V	100.2 V
	1.01 V/div	-99.5 V	-100.2 V	-98.80 V
	3 V/div	99.5 V	98.40 V	100.6 V
	3 V/div	-99.5 V	-100.6 V	-98.4 V
	5 V/div	99.5 V	98.00 V	101.0 V
	5 V/div	-99.5 V	-101.0 V	-98.00 V
Channel 4	1 mV/div	900 mV	895.3 mV	904.7 mV
DC Offset Accuracy, 20 MHz BW, 50 Ω	1 mV/div	-900 mV	-904.7 mV	-895.3 mV
20 IVITZ BVV, 30 12	100 mV/div	5.0 V	4.965 V	5.035 V
	100 mV/div	-5.0 V	-5.035 V	-4.965 V
Channel 4	1 mV/div	900 mV	895.3 mV	904.7 mV
DC Offset Accuracy,	1 mV/div	-900 mV	-904.7 mV	-895.3 mV
20 MHz BW, 1 MΩ	100 mV/div	9.0 V	8.935 V	9.065 V
	100 mV/div	-9.0 V	-9.065 V	-8.935 V
	500 mV/div	9.0 V	8.855 V	9.145 V
	500 mV/div	- 9.0 V	-9.145 V	-8.855 V
	1.01 V/div	99.5 V	98.80 V	100.2 V
	1.01 V/div	-99.5 V	-100.2 V	-98.80 V
	3 V/div	99.5 V	98.40 V	100.6 V
	3 V/div	-99.5 V	-100.6 V	-98.4 V
	5 V/div	99.5 V	98.00 V	101.0 V
	5 V/div	-99.5 V	-101.0 V	-98.00 V

¹ Use this value for both the calibrator output and the oscilloscope offset setting.

Sample Rate and Delay Time Accuracy

Performance checks	Low limit	Test result	High limit
	-1 divisions		+1 divisions

Performance	checks						
Bandwidth at Channel	Impedance	Vertical scale	Horizontal scale	V_{in-pp}	${\sf V}_{\sf bw-pp}$	Limit	Test result Gain = V _{bw-pp} /V _{in-pp}
All Models	<u> </u>			FF			
Channel 1	50 Ω	1 mV/div	4 ns/div (175 MHz for all models except the 100 MHz MDO4014-3)			≥ 0.707	
		2 mV/div	2 ns/div (350 MHz for all models except the 100 MHz MDO4014-3)			≥ 0.707	
		5 mV/div	1 ns/div (Full BW)			≥ 0.707	
		10 mV/div	1 ns/div (Full BW)			≥ 0.707	
		50 mV/div	1 ns/div (Full BW)			≥ 0.707	
		100 mV/div	1 ns/div (Full BW)			≥ 0.707	
		1 V/div	1 ns/div (Full BW)			≥ 0.707	
MDO4104-3, N	/IDO4104-6 Mode	els Only					
Channel 1	1 ΜΩ	1 mV/div	4 ns/div (175 MHz)			≥ 0.707	
		2 mV/div	2 ns/div (350 MHz)			≥ 0.707	
		5 mV/div	1 ns/div (500 MHz)			≥ 0.707	
	10 mV/div	1 ns/div (500 MHz)			≥ 0.707		
		50 mV/div	1 ns/div (500 MHz)			≥ 0.707	
		100 mV/div	1 ns/div (500 MHz)			≥ 0.707	
		1 V/div	1 ns/div (500 MHz)			≥ 0.707	

Performance	checks						
Bandwidth at Channel	Impedance	Vertical scale	Horizontal scale	$V_{\text{in-pp}}$	${f V}_{ m bw-pp}$	Limit	Test result Gain = V _{bw-pp} /V _{in-pp}
All Models							
Channel 2	50 Ω	1 mV/div	4 ns/div (175 MHz for all models except the 100 MHz MDO4014-3)			≥ 0.707	
		2 mV/div	2 ns/div (350 MHz for all models except the 100 MHz MDO4014-3)			≥ 0.707	
	5 mV/div	1 ns/div (Full BW)			≥ 0.707		
	10 mV/div	1 ns/div (Full BW)			≥ 0.707		
		50 mV/div	1 ns/div (Full BW)			≥ 0.707	
		100 mV/div	1 ns/div (Full BW)			≥ 0.707	
		1 V/div	1 ns/div (Full BW)			≥ 0.707	
MDO4104-3, N	/IDO4104-6 Mode	els Only					
Channel 2	1 ΜΩ	1 mV/div	4 ns/div (175 MHz)			≥ 0.707	
		2 mV/div	2 ns/div (350 MHz)			≥ 0.707	
		5 mV/div	1 ns/div (500 MHz)			≥ 0.707	
		10 mV/div	1 ns/div (500 MHz)			≥ 0.707	
		50 mV/div	1 ns/div (500 MHz)			≥ 0.707	
		100 mV/div	1 ns/div (500 MHz)			≥ 0.707	
		1 V/div	1 ns/div (500 MHz)			≥ 0.707	

Performance (checks						
Bandwidth at Channel	Impedance	Vertical scale	Horizontal scale	$V_{\text{in-pp}}$	V_{bw-pp}	Limit	Test result Gain = V _{bw-pp} /V _{in-pp}
All Models							
Channel 3	50 Ω	1 mV/div	4 ns/div (175 MHz for all models except the 100 MHz MDO4014-3)			≥ 0.707	
		2 mV/div	2 ns/div (350 MHz for all models except the 100 MHz MDO4014-3)			≥ 0.707	
	5 mV/div	1 ns/div (Full BW)			≥ 0.707		
	10 mV/div	1 ns/div (Full BW)			≥ 0.707		
		50 mV/div	1 ns/div (Full BW)			≥ 0.707	
		100 mV/div	1 ns/div (Full BW)			≥ 0.707	
		1 V/div	1 ns/div (Full BW)			≥ 0.707	
MDO4104-3, N	MDO4104-6 Mode	els Only					
Channel 3	1 ΜΩ	1 mV/div	4 ns/div (175 MHz)			≥ 0.707	
		2 mV/div	2 ns/div (350 MHz)			≥ 0.707	
		5 mV/div	1 ns/div (500 MHz)			≥ 0.707	
		10 mV/div	1 ns/div (500 MHz)			≥ 0.707	
		50 mV/div	1 ns/div (500 MHz)			≥ 0.707	
		100 mV/div	1 ns/div (500 MHz)			≥ 0.707	
		1 V/div	1 ns/div (500 MHz)			≥ 0.707	

Performance	checks						
Bandwidth at Channel	Impedance	Vertical scale	Horizontal scale	$V_{\text{in-pp}}$	$V_{ m bw-pp}$	Limit	Test result Gain = V _{bw-pp} /V _{in-pp}
All Models							
Channel 4	50 Ω	1 mV/div	4 ns/div (175 MHz for all models except the 100 MHz MDO4014-3)			≥ 0.707	
		2 mV/div	2 ns/div (350 MHz for all models except the 100 MHz MDO4014-3)			≥ 0.707	
	5 mV/div	1 ns/div (Full BW)			≥ 0.707		
		10 mV/div	1 ns/div (Full BW)			≥ 0.707	
		50 mV/div	1 ns/div (Full BW)			≥ 0.707	
		100 mV/div	1 ns/div (Full BW)			≥ 0.707	
		1 V/div	1 ns/div (Full BW)			≥ 0.707	
MDO4104-3, N	/IDO4104-6 Mode	els Only					
Channel 4	1 ΜΩ	1 mV/div	4 ns/div (175 MHz)			≥ 0.707	
		2 mV/div	2 ns/div (350 MHz)			≥ 0.707	
		5 mV/div	1 ns/div (500 MHz)			≥ 0.707	
		10 mV/div	1 ns/div (500 MHz)			≥ 0.707	
		50 mV/div	1 ns/div (500 MHz)			≥ 0.707	
		100 mV/div	1 ns/div (500 MHz)			≥ 0.707	
		1 V/div	1 ns/div (500 MHz)			≥ 0.707	

Random Noise, Sample Acquisition Mode

		Vertical sensitivity	= 100 mV/div		
Performance ch	necks	1 ΜΩ		50 Ω	
	Bandwidth	Test result (mV)	High limit (mV)	Test result (mV)	High limit (mV)
MDO4104-3, MD	004104-6				
Channel 1	Full		8.30		6.08
	250 MHz limit		5.10		4.05
	20 MHz limit		5.10		4.05
Channel 2	Full		8.30		6.08
	250 MHz limit		5.10		4.05
	20 MHz limit		5.10		4.05
Channel 3	Full		8.30		6.08
	250 MHz limit		5.10		4.05
	20 MHz limit		5.10		4.05
Channel 4	Full		8.30		6.08
	250 MHz limit		5.10		4.05
	20 MHz limit		5.10		4.05
MDO4054-3, MD	004054-6				
Channel 1	Full		8.13		8.13
	250 MHz limit		6.10		6.10
	20 MHz limit		4.10		4.10
Channel 2	Full		8.13		8.13
	250 MHz limit		6.10		6.10
	20 MHz limit		4.10		4.10
Channel 3	Full		8.13		8.13
	250 MHz limit		6.10		6.10
	20 MHz limit		4.10		4.10
Channel 4	Full		8.13		8.13
	250 MHz limit		6.10		6.10
	20 MHz limit		4.10		4.10

formance checks			
O4104-3, MDO4104-6			
innel 1			
MDO = 4 ns/div, Source	e freq = 240 MHz		
MDO V/div	Source V _{pp}	Test result	High limit
5 mV	40 mV		118 ps
100 mV	800 mV		117 ps
500 mV	4 V		117 ps
1 V	4 V		122 ps
MDO = 40 ns/div, Sour	ce freq = 24 MHz		
1 mV	8 mV		464 ps
5 mV	40 mV		276 ps
100 mV	800 mV		234 ps
500 mV	4 V		232 ps
1 V	4 V		417 ps
MDO = 400 ns/div, Sou	rce freq = 2.4 MHz		
1 mV	8 mV		4.50 ns
5 mV	40 mV		2.52 ns
100 mV	800 mV		2.05 ns
500 mV	4 V		2.03 ns
1 V	4 V		4.01 ns
MDO = 4 µs/div, Source	e freq = 240 kHz		
1 mV	8 mV		45.0 ns
5 mV	40 mV		25.2 ns
100 mV	800 mV		20.5 ns
500 mV	4 V		20.3 ns
1 V	4 V		40.1 ns
MDO = 40 µs/div, Sour	ce freq = 24 kHz		
1 mV	8 mV		450 ns
5 mV	40 mV		252 ns
100 mV	800 mV		205 ns
500 mV	4 V		203 ns
1 V	4 V		401 ns
MDO = 400 µs/div, Sou	rce freq = 2.4 kHz		
1 mV	8 mV		4.50 µs
5 mV	40 mV		2.52 µs
100 mV	800 mV		2.05 μs
500 mV	4 V		2.03 µs

4 V

1 V

4.01 µs

MDO4104-3. MDO4104-

MDO V/div	Source V _{pp}	Test result	High limit
5 mV	40 mV		118 ps
100 mV	800 mV		117 ps
500 mV	4 V		117 ps
1 V	4 V		122 ps
DO = 40 ns/div, Source	e freq = 24 MHz		
1 mV	8 mV		464 ps
5 mV	40 mV		276 ps
100 mV	800 mV		234 ps
500 mV	4 V		232 ps
1 V	4 V		417 ps
DO = 400 ns/div, Sour	ce freq = 2.4 MHz		
1 mV	8 mV		4.50 ns
5 mV	40 mV		2.52 ns
100 mV	800 mV		2.05 ns
500 mV	4 V		2.03 ns
1 V	4 V		4.01 ns
DO = 4 μs/div, Source	freq = 240 kHz		
1 mV	8 mV		45.0 ns
5 mV	40 mV		25.2 ns
100 mV	800 mV		20.5 ns
500 mV	4 V		20.3 ns
1 V	4 V		40.1 ns
DO = 40 μs/div, Source	e freq = 24 kHz		
1 mV	8 mV		450 ns
5 mV	40 mV		252 ns
100 mV	800 mV		205 ns
500 mV	4 V		203 ns
1 V	4 V		401 ns
DO = 400 µs/div, Sour	ce freq = 2.4 kHz		
1 mV	8 mV		4.50 µs
5 mV	40 mV		2.52 µs
100 mV	800 mV		2.05 µs
500 mV	4 V		2.03 µs
1 V	4 V		4.01 µs

MDO4104-3	, MDO4104-6
-----------	-------------

C

nnel 3				
MDO = 4 ns/div, Source	freq = 240 MHz			
MDO V/div	Source V _{pp}	Test result	High limit	
5 mV	40 mV		118 ps	
100 mV	800 mV		117 ps	
500 mV	4 V		117 ps	
1 V	4 V		122 ps	
MDO = 40 ns/div, Sourc	e freq = 24 MHz			
1 mV	8 mV		464 ps	
5 mV	40 mV		276 ps	
100 mV	800 mV		234 ps	
500 mV	4 V		232 ps	
1 V	4 V		417 ps	
MDO = 400 ns/div, Sour	ce freq = 2.4 MHz			
1 mV	8 mV		4.50 ns	
5 mV	40 mV		2.52 ns	
100 mV	800 mV		2.05 ns	
500 mV	4 V		2.03 ns	
1 V	4 V		4.01 ns	
MDO = 4 μs/div, Source	freq = 240 kHz			
1 mV	8 mV		45.0 ns	
5 mV	40 mV		25.2 ns	
100 mV	800 mV		20.5 ns	
500 mV	4 V		20.3 ns	
1 V	4 V		40.1 ns	
MDO = 40 μs/div, Sourc	e freq = 24 kHz			
1 mV	8 mV		450 ns	
5 mV	40 mV		252 ns	
100 mV	800 mV		205 ns	
500 mV	4 V		203 ns	
1 V	4 V		401 ns	
MDO = 400 μs/div, Sour	ce freq = 2.4 kHz			
1 mV	8 mV		4.50 μs	
5 mV	40 mV		2.52 μs	
100 mV	800 mV		2.05 μs	
500 mV	4 V		2.03 µs	
1 V	4 V		4.01 µs	

MDO4104-3	MDO4104-6
-----------	-----------

L -			_ [
na	n	n	eı	4

MDO V/div	Source V _{pp}	Test result	High limit
5 mV	40 mV		118 ps
100 mV	800 mV		117 ps
500 mV	4 V		117 ps
1 V	4 V		122 ps
OO = 40 ns/div, Source	e freq = 24 MHz		
1 mV	8 mV		464 ps
5 mV	40 mV		276 ps
100 mV	800 mV		234 ps
500 mV	4 V		232 ps
1 V	4 V		417 ps
OO = 400 ns/div, Sour	ce freq = 2.4 MHz		
1 mV	8 mV		4.50 ns
5 mV	40 mV		2.52 ns
100 mV	800 mV		2.05 ns
500 mV	4 V		2.03 ns
1 V	4 V		4.01 ns
OO = 4 μs/div, Source	freq = 240 kHz		
1 mV	8 mV		45.0 ns
5 mV	40 mV		25.2 ns
100 mV	800 mV		20.5 ns
500 mV	4 V		20.3 ns
1 V	4 V		40.1 ns
OO = 40 µs/div, Source	e freq = 24 kHz		
1 mV	8 mV		450 ns
5 mV	40 mV		252 ns
100 mV	800 mV		205 ns
500 mV	4 V		203 ns
1 V	4 V		401 ns
OO = 400 µs/div, Sour	ce freq = 2.4 kHz		
1 mV	8 mV		4.50 μs
5 mV	40 mV		2.52 µs
100 mV	800 mV		2.05 μs
500 mV	4 V		2.03 µs
1 V	4 V		4.01 μs

ᄾ	-			1 4
Jh	a	M	ıe	ш

	freq = 240 MHz (except for the			
MDO V/div	Source V _{pp}	Test result	High limit	
5 mV	40 mV		234 ps	
100 mV	800 mV		233 ps	
500 mV	4 V		233 ps	
1 V	4 V		237 ps	
IDO = 40 ns/div, Source	e freq = 24 MHz			
1 mV	8 mV		736 ps	
5 mV	40 mV		423 ps	
100 mV	800 mV		357 ps	
500 mV	4 V		354 ps	
1 V	4 V		581 ps	
IDO = 400 ns/div, Sour	ce freq = 2.4 MHz			
1 mV	8 mV		6.99 ns	
5 mV	40 mV		3.54 ns	
100 mV	800 mV		2.73 ns	
500 mV	4 V		2.69 ns	
1 V	4 V		5.34 ns	
IDO = 4 μs/div, Source	freq = 240 kHz			
1 mV	8 mV		69.9 ns	
5 mV	40 mV		35.4 ns	
100 mV	800 mV		27.3 ns	
500 mV	4 V		26.9 ns	
1 V	4 V		53.4 ns	
IDO = 40 μs/div, Source	e freq = 24 kHz			
1 mV	8 mV		699 ns	
5 mV	40 mV		354 ns	
100 mV	800 mV		273 ns	
500 mV	4 V		269 ns	
1 V	4 V		534 ns	
IDO = 400 µs/div, Sour	ce freq = 2.4 kHz			
1 mV	8 mV		6.99 µs	
5 mV	40 mV		3.54 µs	
100 mV	800 mV		2.73 µs	
500 mV	4 V		2.69 µs	
1 V	4 V		5.34 μs	

•	L	_			_	1
	n	а	n	n	е	_

MDO V/div	Source V _{pp}	Test result	High limit
5 mV	40 mV		234 ps
100 mV	800 mV		233 ps
500 mV	4 V		233 ps
1 V	4 V		237 ps
OO = 40 ns/div, Source	e freq = 24 MHz		
1 mV	8 mV		736 ps
5 mV	40 mV		423 ps
100 mV	800 mV		357 ps
500 mV	4 V		354 ps
1 V	4 V		581 ps
OO = 400 ns/div, Sour	ce freq = 2.4 MHz		
1 mV	8 mV		6.99 ns
5 mV	40 mV		3.54 ns
100 mV	800 mV		2.73 ns
500 mV	4 V		2.69 ns
1 V	4 V		5.34 ns
O = 4 μs/div, Source	freq = 240 kHz		
1 mV	8 mV		69.9 ns
5 mV	40 mV		35.4 ns
100 mV	800 mV		27.3 ns
500 mV	4 V		26.9 ns
1 V	4 V		53.4 ns
OO = 40 µs/div, Source	e freq = 24 kHz		
1 mV	8 mV		699 ns
5 mV	40 mV		354 ns
100 mV	800 mV		273 ns
500 mV	4 V		269 ns
1 V	4 V		534 ns
OO = 400 μs/div, Sour	ce freq = 2.4 kHz		
1 mV	8 mV		6.99 µs
5 mV	40 mV		3.54 µs
100 mV	800 mV		2.73 µs
500 mV	4 V		2.69 µs
1 V	4 V		5.34 μs

1	ha	n	n	۵	3

nnel 3			
IDO = 4 ns/div, Source	freq = 240 MHz (except for the	MDO4014-3)	
MDO V/div	Source V _{pp}	Test result	High limit
5 mV	40 mV		234 ps
100 mV	800 mV		233 ps
500 mV	4 V		233 ps
1 V	4 V		237 ps
IDO = 40 ns/div, Source	e freq = 24 MHz		
1 mV	8 mV		736 ps
5 mV	40 mV		423 ps
100 mV	800 mV		357 ps
500 mV	4 V		354 ps
1 V	4 V		581 ps
IDO = 400 ns/div, Sour	ce freq = 2.4 MHz		
1 mV	8 mV		6.99 ns
5 mV	40 mV		3.54 ns
100 mV	800 mV		2.73 ns
500 mV	4 V		2.69 ns
1 V	4 V		5.34 ns
IDO = 4 μs/div, Source	freq = 240 kHz		
1 mV	8 mV		69.9 ns
5 mV	40 mV		35.4 ns
100 mV	800 mV		27.3 ns
500 mV	4 V		26.9 ns
1 V	4 V		53.4 ns
IDO = 40 μs/div, Source	e freq = 24 kHz		
1 mV	8 mV		699 ns
5 mV	40 mV		354 ns
100 mV	800 mV		273 ns
500 mV	4 V		269 ns
1 V	4 V		534 ns
IDO = 400 μs/div, Sour	ce freq = 2.4 kHz		
1 mV	8 mV		6.99 µs
5 mV	40 mV		3.54 µs
100 mV	800 mV		2.73 µs
500 mV	4 V		2.69 µs
1 V	4 V		5.34 µs

MDO V/div	Source V _{pp}	Test result	High limit
5 mV	40 mV		234 ps
100 mV	800 mV		233 ps
500 mV	4 V		233 ps
1 V	4 V		237 ps
DO = 40 ns/div, Source	e freq = 24 MHz		
1 mV	8 mV		736 ps
5 mV	40 mV		423 ps
100 mV	800 mV		357 ps
500 mV	4 V		354 ps
1 V	4 V		581 ps
DO = 400 ns/div, Sour	ce freq = 2.4 MHz		
1 mV	8 mV		6.99 ns
5 mV	40 mV		3.54 ns
100 mV	800 mV		2.73 ns
500 mV	4 V		2.69 ns
1 V	4 V		5.34 ns
DO = 4 μs/div, Source	freq = 240 kHz		
1 mV	8 mV		69.9 ns
5 mV	40 mV		35.4 ns
100 mV	800 mV		27.3 ns
500 mV	4 V		26.9 ns
1 V	4 V		53.4 ns
DO = 40 µs/div, Sourc	e freq = 24 kHz		
1 mV	8 mV		699 ns
5 mV	40 mV		354 ns
100 mV	800 mV		273 ns
500 mV	4 V		269 ns
1 V	4 V		534 ns
DO = 400 μs/div, Sour	ce freq = 2.4 kHz		
1 mV	8 mV		6.99 µs
5 mV	40 mV		3.54 µs
100 mV	800 mV		2.73 µs
500 mV	4 V		2.69 µs
1 V	4 V		5.34 µs

Digital Threshold Accuracy

Performance	checks:					
Digital channel	Threshold	$V_{\sf slow}$	${f V}_{\sf shigh}$	Low limit	Test result	High limit
D0	0 V		-	-0.1 V		0.1 V
	4 V			3.78 V		4.22 V
D1	0 V			-0.1 V		0.1 V
	4 V			3.78 V		4.22 V
D2	0 V			-0.1 V		0.1 V
	4 V			3.78 V		4.22 V
D3	0 V			-0.1 V		0.1 V
	4 V			3.78 V		4.22 V
D4	0 V			-0.1 V		0.1 V
	4 V			3.78 V		4.22 V
D5	0 V			-0.1 V		0.1 V
	4 V			3.78 V		4.22 V
D6	0 V			-0.1 V		0.1 V
	4 V			3.78 V		4.22 V
D7	0 V			-0.1 V		0.1 V
	4 V			3.78 V		4.22 V
D8	0 V			-0.1 V		0.1 V
	4 V			3.78 V		4.22 V
D9	0 V			-0.1 V		0.1 V
	4 V			3.78 V		4.22 V
D10	0 V			-0.1 V		0.1 V
	4 V			3.78 V		4.22 V
D11	0 V			-0.1 V		0.1 V
	4 V			3.78 V		4.22 V
D12	0 V			-0.1 V		0.1 V
	4 V			3.78 V		4.22 V
D13	0 V			-0.1 V		0.1 V
	4 V			3.78 V		4.22 V
D14	0 V			-0.1 V		0.1 V
	4 V			3.78 V		4.22 V
D15	0 V			-0.1 V		0.1 V
	4 V			3.78 V		4.22 V

Phase Noise

Performance checks		Low limit	Test result	High limit
Center Frequency 2 GHz	10 kHz	N/A	-90 dBc/Hz	
	100 kHz	N/A		-95 dBc/Hz
	1 MHz	N/A		-113 dBc/Hz

Displayed Average Noise Level (DANL)

Performance checks		Low limit	Test result	High limit
All models	50 kHz – 5 MHz	N/A		- 130 dBm/Hz
	5 MHz – 3 GHz	N/A		- 148 dBm/Hz
MDO4104-6 and MDO4054-6 only	3 GHz – 4 GHz	N/A		- 140 dBm/Hz
	4 GHz – 6 GHz	N/A		- 140 dBm/Hz

Level Measurement Uncertainty

Performance che	ecks		Low limit	Test result	High limit
+10 dBm	All models	50 kHz	-1 dBm		+1 dBm
		100 kHz – 900 kHz	-1 dBm		+1 dBm
		1 MHz – 9 MHz	-1 dBm		+1 dBm
		10 MHz – 90 MHz	-1 dBm		+1 dBm
	MDO4104-3, MDO4054-3, MDO4034-3, MDO4014-3	100 MHz – 3 GHz	-1 dBm		+1 dBm
	MDO4104-6, MDO4054-6	100 MHz – 6 GHz	-1 dBm		+1 dBm
0 dBm	All models	50 kHz	-1 dBm		+1 dBm
		100 kHz – 900 kHz	-1 dBm		+1 dBm
		1 MHz – 9 MHz	-1 dBm		+1 dBm
		10 MHz – 90 MHz	-1 dBm		+1 dBm
	MDO4104-3, MDO4054-3, MDO4034-3, MDO4014-3	100 MHz – 3 GHz	-1 dBm		+1 dBm
	MDO4104-6, MDO4054-6	100 MHz – 6 GHz	-1 dBm		+1 dBm
–15 dBm	All models	50 kHz	-1 dBm		+1 dBm
		100 kHz – 900 kHz	-1 dBm		+1 dBm
		1 MHz – 9 MHz	-1 dBm		+1 dBm
		10 MHz – 90 MHz	-1 dBm		+1 dBm
	MDO4104-3, MDO4054-3, MDO4034-3, MDO4014-3	100 MHz – 3 GHz	-1 dBm		+1 dBm
	MDO4104-6, MDO4054-6	100 MHz – 6 GHz	-1 dBm		+1 dBm

Third Order Intermodulation Distortion

Performance che	ecks		Low limit	Test result	High limit
All models	Center Frequency	Generator 1 signal	N/A		-60 dBc
	2.745 GHz	Generator 2 signal	N/A		-60 dBc
MDO4XX4-6	Center Frequency 4.5 GHz	Generator 1 signal	N/A		-60 dBc
		Generator 2 signal	N/A		-60 dBc

Residual Spurious Response

Performance checks		Low limit	Test result	High limit	
All models	50 kHz to 3 GHz	N/A		-78 dBm	
MDO4XX4-6	2.75 GHz to 4.5 GHz	N/A		-78 dBm	
	3.5 GHz to 6.0 GHz	N/A		-78 dBm	

Crosstalk to RF channel from analog c	hannels			
Performance checks				
Channel 1 crosstalk		Low limit	Test result	High limit
Generator signal frequency and	100 MHz	N/A		-68 dBm
Oscilloscope Center Frequency setting	200 MHz	N/A		-68 dBm
	300 MHz	N/A		-68 dBm
	400 MHz	N/A		-68 dBm
	500 MHz	N/A		-68 dBm
	600 MHz	N/A		-68 dBm
	700 MHz	N/A		-68 dBm
	800 MHz	N/A		-68 dBm
	900 MHz	N/A		-68 dBm
	1 GHz	N/A		-68 dBm
	1.1 GHz	N/A		-48 dBm
	1.2 GHz	N/A		-48 dBm
	1.3 GHz	N/A		-48 dBm
	1.4 GHz	N/A		-48 dBm
	1.5 GHz	N/A		-48 dBm
	1.6 GHz	N/A		-48 dBm
	1.7 GHz	N/A		-48 dBm
	1.8 GHz	N/A		-48 dBm
	1.9 GHz	N/A		-48 dBm
	2 GHz	N/A		-48 dBm

Crosstalk to RF channel from analog channels

Channel 2 crosstalk		Low limit	Test result	High limit
Generator signal frequency and	100 MHz	N/A		-68 dBm
Oscilloscope Center Frequency setting	200 MHz	N/A		-68 dBm
	300 MHz	N/A		-68 dBm
	400 MHz	N/A		-68 dBm
	500 MHz	N/A		-68 dBm
	600 MHz	N/A		-68 dBm
	700 MHz	N/A		-68 dBm
	800 MHz	N/A		-68 dBm
	900 MHz	N/A		-68 dBm
	1 GHz	N/A		-68 dBm
	1.1 GHz	N/A		-48 dBm
	1.2 GHz	N/A		-48 dBm
	1.3 GHz	N/A		-48 dBm
	1.4 GHz	N/A		-48 dBm
	1.5 GHz	N/A		-48 dBm
	1.6 GHz	N/A		-48 dBm
	1.7 GHz	N/A		-48 dBm
	1.8 GHz	N/A		-48 dBm
	1.9 GHz	N/A		-48 dBm
	2 GHz	N/A		-48 dBm

Crosstalk to RF channel from analog channels

Channel 3 crosstalk		Low limit	Test result	High limit
Generator signal frequency and	100 MHz	N/A		-68 dBm
Oscilloscope Center Frequency setting	200 MHz	N/A		-68 dBm
	300 MHz	N/A		-68 dBm
	400 MHz	N/A		-68 dBm
	500 MHz	N/A		-68 dBm
	600 MHz	N/A		-68 dBm
	700 MHz	N/A		-68 dBm
	800 MHz	N/A		-68 dBm
	900 MHz	N/A		-68 dBm
	1 GHz	N/A		-68 dBm
	1.1 GHz	N/A		-48 dBm
	1.2 GHz	N/A		-48 dBm
	1.3 GHz	N/A		-48 dBm
	1.4 GHz	N/A		-48 dBm
	1.5 GHz	N/A		-48 dBm
	1.6 GHz	N/A		-48 dBm
	1.7 GHz	N/A		-48 dBm
	1.8 GHz	N/A		-48 dBm
	1.9 GHz	N/A		-48 dBm
	2 GHz	N/A		-48 dBm

Crosstalk to RF channel from analog channels

Channel 4 crosstalk		Low limit	Test result	High limit
Generator signal frequency and	100 MHz	N/A		-68 dBm
Oscilloscope Center Frequency setting	200 MHz	N/A		-68 dBm
	300 MHz	N/A		-68 dBm
	400 MHz	N/A		-68 dBm
	500 MHz	N/A		-68 dBm
	600 MHz	N/A		-68 dBm
	700 MHz	N/A		-68 dBm
	800 MHz	N/A		-68 dBm
	900 MHz	N/A		-68 dBm
	1 GHz	N/A		-68 dBm
	1.1 GHz	N/A		-48 dBm
	1.2 GHz	N/A		-48 dBm
	1.3 GHz	N/A		-48 dBm
	1.4 GHz	N/A		-48 dBm
	1.5 GHz	N/A		-48 dBm
	1.6 GHz	N/A		-48 dBm
	1.7 GHz	N/A		-48 dBm
	1.8 GHz	N/A		-48 dBm
	1.9 GHz	N/A		-48 dBm
	2 GHz	N/A		-48 dBm

Auxiliary (Trigger) Output

Performance check	S	Low limit	Test result	High limit	
Trigger Output	High 1 MΩ	≥ 2.5 V		-	
	Low 1 MΩ	-		≤ 0.7 V	
Trigger Output	High 50 Ω	≥ 1.0 V		-	
	Low 50 Ω	-		≤ 0.25 V	

With TPA-N-PRE Attached:

With TPA-N-PRE attached: Displayed Average Noise Level (DANL)

Performance checks		Low limit	Test result	High limit	
All models (with TPA-N-PRE attached)	50 kHz – 5 MHz	N/A		- 140 dBm/Hz	
	5 MHz – 3 GHz	N/A		- 158 dBm/Hz	
MDO4XX4-6 only (with TPA-N-PRE attached)	3 GHz – 4 GHz	N/A		- 150 dBm/Hz	
	4 GHz – 6 GHz	N/A		- 150 dBm/Hz	

Performance Verification Procedures

The Performance Verification Procedures consist of a self test and several check steps, which check the oscilloscope performance to specifications. The following three conditions must be met before performing these procedures:

- 1. The oscilloscope must have been operating continuously for twenty (20) minutes in an environment that meets the operating range specifications for temperature and humidity.
- 2. You must perform the Signal Path Compensation (SPC) operation described in step 2 of the *Self Test* before evaluating specifications. (See page 62, *Self Test*.) If the operating temperature changes by more than 10 °C (18 °F), you must perform the SPC operation again.
- **3.** You must connect the oscilloscope and the test equipment to the same AC power circuit. Connect the oscilloscope and test instruments to a common power strip if you are unsure of the AC power circuit distribution. Connecting the oscilloscope and test instruments to separate AC power circuits can result in offset voltages between the equipment, which can invalidate the performance verification procedure.

The time required to complete the entire procedure is more than one hour. To ensure instrument performance to the Level Measurement Uncertainty specification, it is necessary to check at many points, which can add significant time to the procedure.



WARNING. Some procedures use hazardous voltages. To prevent electrical shock, always set voltage source outputs to $0\ V$ before making or changing any interconnections.

Self Test This procedure uses internal routines to verify that the oscilloscope functions and passes its internal self tests. No test equipment or hookups are required.

- **1.** Run the System Diagnostics (may take several minutes):
 - **a.** Disconnect everything from the oscilloscope inputs.
 - **b.** Push the front-panel **Default Setup** button.
 - c. Push the Utility menu button.
 - **d.** Push the **Utility Page** lower-bezel button.
 - e. Select Self Test.
 - **f.** Push the **Self Test** lower-bezel button. The Loop X Times side-bezel menu will be set to **Loop 1 Times**.
 - g. Push the OK Run Self Test side-bezel button.
 - **h.** Wait. The internal diagnostics perform an exhaustive verification of proper instrument function. This verification may take several minutes.
 - i. Verify that the status of all tests on the readout is **Pass**.
 - **j.** Push the **Menu** button twice to clear the dialog box and Self Test menu.
- **2.** Run the signal path compensation routine (may take 5 to 15 minutes):
 - a. Push the front-panel **Default Setup** button.
 - **b.** Push the **Utility** menu button.
 - **c.** Push the **Utility Page** lower-bezel button.
 - d. Select Calibration.
 - e. Push the **Signal Path** lower-bezel button.
 - **f.** Push the **OK-Compensate Signal Paths** side bezel button.
 - **g.** When the signal path compensation is complete, push the **Menu** button twice to clear the dialog box and Self Test menu.
 - **h.** Check the lower-bezel **Signal Path** button to verify that the status is **Pass**.

Check Input Impedance (Resistance)

This test checks the Input Impedance.

1. Connect the output of the oscilloscope calibrator (for example, the Fluke 9500) to the oscilloscope channel 1 input, as shown below.




WARNING. The generator is capable of providing dangerous voltages. Be sure to set the generator to off or 0 volts before connecting, disconnecting, and/or moving the test hookup during the performance of this procedure.

- 2. Push the front-panel **Default Setup** button.
- **3.** Set the impedance to $1 M\Omega$ as follows:
 - **a.** Push the channel 1 button.
 - **b.** Set the **Termination** (input impedance) to 1 $M\Omega$.
- 4. Set the Vertical Scale to 10 mV/division.
- **5.** Measure the input resistance of the oscilloscope with the calibrator. Record this value in the test record.
- **6.** Repeat steps 4 and 5 for each vertical scale setting in the test record.
- 7. Repeat the tests at 250 k Ω as follows:
 - **a.** Set the calibrator impedance to 1 M Ω .
 - **b.** Push the **Utility** front-panel button.
 - c. Push the Utility Page lower-bezel button.
 - d. Select Self Test.
 - e. Push the 250 k Ω Impedance Verification lower-bezel button to set the oscilloscope input impedance to 250 k Ω .
 - **f.** Push the channel **1** side-bezel button to enable channel 1.
 - g. Set the Vertical Scale to 100 mV/division.
 - **h.** Measure the input resistance of the oscilloscope with the calibrator. Record this value in the test record.

- **8.** Repeat the tests at 50 Ω as follows:
 - **a.** Set the calibrator impedance to 50 Ω .
 - **b.** Set the **Termination** (input impedance) to 50Ω .
 - c. Repeat steps 4 through 6.
- **9.** Repeat the procedure for all remaining channels as follows:
 - **a.** Push the front-panel channel button to deselect the channel that you already tested.
 - **b.** Connect the calibrator to the input for the next channel to be tested.
 - **c.** Starting from step 3, repeat the procedure for each channel.

Check DC Balance

This test checks the DC balance. You do not need to connect any equipment (other than a 50Ω terminator) to the oscilloscope to perform this check.




- 1. Attach a 50 Ω terminator to the oscilloscope channel 1 input.
- 2. Push the front-panel **Default Setup** button.
- **3.** Set the input impedance to 50 Ω as follows:
 - **a.** Push the channel 1 button.
 - **b.** Set the **Termination** (input impedance) to **50** Ω .
- **4.** Set the bandwidth to 20 MHz:
 - **a.** Push the lower-bezel **Bandwidth** button.
 - **b.** Push the side-bezel button for **20 MHz**.
- 5. Set the Horizontal Scale to 1 ms per division.
- **6.** *Set the Acquisition mode to Average as follows:*
 - **a.** Push the front-panel **Acquire** button.
 - **b.** Push the **Average** side bezel button.
 - **c.** Make sure that the number of averages is **16**.
- 7. Set the trigger source to AC line as follows:
 - **a.** Push the Trigger **Menu** front-panel button.
 - **b.** Select the **AC** Line trigger source.
- **8.** Set the Vertical **Scale** to **1 mV** per division.
- **9.** Select the mean measurement (if not already selected) as follows:
 - **a.** Push the front-panel Wave Inspector **Measure** button.
 - **b.** Push the **Add Measurement** lower bezel button.
 - c. Select the Mean measurement.
 - **d.** Push the **OK Add Measurement** side-bezel button.
 - **e.** View the **Mean** measurement value in the display.

- **10.** Enter the mean value as the test result in the test record.
- 11. Repeat steps 8 through 10 for each vertical scale setting in the test record.
- **12.** Push the channel 1 button and then repeat steps 4 thorough 11 for each bandwidth setting.
- **13.** Repeat the tests at I $M\Omega$ impedance as follows:
 - **a.** Push the front-panel channel 1 button.
 - **b.** Set the **Termination** (input impedance) to **1M** Ω .
 - **c.** Repeat steps 4 through 12.
- **14.** Repeat the procedure for all remaining channels as follows:
 - **a.** Deselect the channel that you already tested.
 - **b.** Move the 50 Ω terminator to the next channel input to be tested.
 - **c.** Starting from step 3, repeat the procedure for each channel.

Check DC Gain Accuracy

This test checks the DC gain accuracy.

1. Connect the oscilloscope to a DC voltage source. If using the Fluke 9500 calibrator, connect the calibrator head to the oscilloscope channel to test.





WARNING. The generator is capable of providing dangerous voltages. Be sure to set the generator to off or 0 volts before connecting, disconnecting, and/or moving the test hookup during the performance of this procedure.

2. Push the front-panel **Default Setup** button. The Termination (input impedance) is set to 1 M Ω and channel 1 input is selected.

NOTE. 50 Ω termination testing (steps 4 through 14) is required only for MDO4104-3 and MDO4104-6 models.

 $1~M\Omega$ termination testing (step 15) is required for all models.

- **3.** For MDO4104-3 and MDO4104-6 models, perform steps 4 through 15. For other models, go to step 15 now.
- **4.** Select 50 Ω input impedance as follows:
 - **a.** Set the calibrator to 50 Ω output impedance.
 - **b.** Push the channel 1 button.
 - c. Set the **Termination** (input impedance) to 50 Ω .
- **5.** *Set the bandwidth to 20 MHz as follows:*
 - a. Push the lower-bezel Bandwidth button.
 - **b.** Push the **20 MHz** side-bezel button to select the bandwidth.

- **6.** Set the Acquisition mode to Average as follows:
 - **a.** Push the front-panel **Acquire** button.
 - **b.** Push the **Mode** lower-bezel button (if it is not already selected), and then push the **Average** side bezel button.
 - c. Make sure that the number of averages is 16.
- 7. Select the Mean measurement as follows:
 - **a.** Push the front-panel Wave Inspector **Measure** button.
 - **b.** Push the **Add Measurement** lower-bezel button (if it is not already selected).
 - c. Select the Mean measurement.
 - d. Push the OK Add Measurement side-bezel button.
- **8.** *Set the trigger source to AC line as follows:*
 - **a.** Push the Trigger **Menu** button on the front panel.
 - **b.** Push the **Source** lower-bezel button.
 - c. Select the AC Line as the trigger source.
- 9. Set the Vertical Scale to 1 mV/division.
- **10.** Record the negative-measured and positive-measured mean readings in the worksheet as follows:
 - **a.** Set the DC Voltage Source to V_{negative} .
 - **b.** Push the front-panel Wave Inspector **Measure** button.
 - **c.** Push the **More** lower-bezel button.
 - **d.** Push **Reset Statistics** in the side-bezel menu.
 - **e.** Enter the mean reading in the worksheet as $V_{\text{negative-measured}}$. (See Table 16.)
 - **f.** Set the DC Voltage Source to $V_{positive-measured}$
 - **g.** Push **Reset Statistics** in the side-bezel menu again.
 - **h.** Enter the mean reading in the worksheet as $V_{\text{positive-measured}}$

Table 16: Gain expected worksheet

Termination	Vertical Scale	$V_{diffExpected}$	$V_{negative}$	$V_{positive}$	V _{negative-measured}	$V_{ m positive-measured}$	V_{diff}	DC Gain Accuracy
50Ω	1 mV	9 mV	-4.5 mV	+4.5 mV		F	-	-
	2 mV	18 mV	-9 mV	+9 mV				
	5 mV	45 mV	-22.5 mV	+22.5 mV				
	10 mV	90 mV	-45 mV	+45 mV				
	20 mV	180 mV	-90 mV	+90 mV				
	49.8 mV	448.2 mV	-224.1 mV	+224.1 mV				
	50 mV	450 mV	-225 mV	+225 mV				
	100 mV	900 mV	-450 mV	+450 mV				
	200 mV	1800 mV	-900 mV	+900 mV				
	500 mV	4900 mV	-2450 mV	+2450 mV				
	1 V	9000 mV	-4500 mV	+4500 mV				
1ΜΩ	1 mV	9 mV	-4.5 mV	+4.5 mV				
	2 mV	18 mV	-9 mV	+9 mV				
	5 mV	45 mV	-22.5 mV	+22.5 mV				
	10 mV	90 mV	-45 mV	+45 mV				
	20 mV	180 mV	-90 mV	+90 mV				
	50 mV	450 mV	-225 mV	+225 mV				
	63.5 mV	571.5 mV	-285.75 mV	+285.75 mV				
	100 mV	900 mV	-450 mV	+450 mV				
	200 mV	1800 mV	-900 mV	+900 mV				
	500 mV	4900 mV	-2450 mV	+2450 mV				
	1 V	9000 mV	-4500 mV	+4500 mV				
	5 V	45 V	-22.5 V	+22.5 V				

11. Record Gain Accuracy:

a. Calculate V_{diff} as follows:

$$V_{\textit{diff}} \!\!=\! \mid V_{\textit{negative-measured}} \!\!-\! V_{\textit{positive-measured}} \mid$$

- **b.** Enter V_{diff} in the worksheet. (See Table 16.)
- **c.** Calculate *Gain Accuracy* as follows:

Gain Accuracy = ((
$$V_{diff}$$
- $V_{diffExpected}$)/ $V_{diffExpected}$) * 100%


- **d.** Enter *Gain Accuracy* in the worksheet and in the test record.
- **12.** Repeat steps 9 through 11 for each vertical scale setting in the test record.
- **13.** Repeat steps 9 through 12 for each bandwidth setting in the test record.

- **14.** Repeat the procedure for all remaining channels as follows:
 - **a.** Push the front-panel button to deselect the channel that you have already tested.
 - **b.** Move the DC voltage source connection to the next channel input to be tested.
 - **c.** Starting from step 9, repeat the procedure for each channel.
- **15.** Repeat tests at 1 M Ω impedance:
 - **a.** Set the calibrator to 1 $M\Omega$ output.
 - **b.** Push the front-panel channel 1 button.
 - c. Set the Termination to 1 $M\Omega$.
 - **d.** Repeat steps 9 through 14.

Check Offset Accuracy

This test checks the offset accuracy.

1. Connect the oscilloscope to a DC voltage source. If you are using the Fluke 9500 calibrator as the DC voltage source, connect the calibrator head to the oscilloscope channel 1.






- 2. Push the front-panel **Default Setup** button.
- **3.** *Set the Acquisition mode to Average as follows:*
 - **a.** Push the front-panel **Acquire** button.
 - **b.** Push the **Mode** lower-bezel button (if not already selected).
 - **c.** Push the **Average** side bezel button.
 - **d.** Make sure that the **number of averages** is set to **16**.
- **4.** Set the trigger source to AC line:
 - **a.** Push the Trigger **Menu** front-panel button.
 - **b.** Push the **Source** lower-bezel button.
 - **c.** Select the **AC** Line as the trigger source.
- 5. Set the Horizontal Scale to 1.00 ms per division.
- **6.** *Set the Bandwidth to 20 MHz as follows:*
 - **a.** Push the channel 1 button.
 - **b.** Push the lower-bezel **Bandwidth** button.
 - c. Push the side-bezel button to set the bandwidth to 20 MHz.

- 7. Check that the vertical position is set to 0 divs:
 - a. Push the lower-bezel **More** button to select **Position**.
 - **b.** In the side-bezel button, check that the **Vertical Position** is set to **0 divs**.
 - **c.** If it is not 0 divs, turn the Vertical **Position** knob to set the position to 0.
- **8.** Select 50 Ω impedance as follows:
 - **a.** Set the calibrator to 50 Ω output impedance (50 Ω source impedance).
 - **b.** Push the channel 1 button.
 - c. Set the Termination to 50 Ω .
- 9. Set the vertical Scale to 1 mV per division.
- **10.** *Set the offset as follows:*
 - **a.** Set the calibrator to 900 mV vertical offset.
 - **b.** Push the lower-bezel **More** button to select **Offset**.
 - c. Set the Vertical Offset to 900 mV, as shown in the test record.
- 11. Select the Mean measurement (if not already selected) as follows:
 - **a.** Push the front-panel Wave Inspector **Measure** button.
 - **b.** Push the **Add Measurement** lower-bezel button.
 - c. Select the **Mean** measurement.
 - **d.** Push the **OK Add Measurement** side-bezel button.
- 12. View the mean value in the measurement pane at the bottom of the display and enter it as the test result in the test record.
- **13.** Repeat step 12 for each vertical scale and offset setting combination shown in the test record.
- **14.** Repeat the tests at I $M\Omega$ impedance as follows:
 - **a.** Change the calibrator impedance to 1 M Ω .
 - **b.** Push the front-panel channel 1 button.
 - c. Set the **Termination** (input impedance) to 1 $M\Omega$.
 - **d.** Repeat steps 9 through 13.
- **15.** Repeat the procedure for all remaining channels as follows:
 - **a.** Deselect the channel that you have already tested.
 - **b.** Move the DC voltage source connection to the next channel to be tested.
 - **c.** Starting from step 6, repeat the procedure for each channel.

Check Analog Bandwidth

This test checks the bandwidth at 50 Ω and 1 M Ω for each channel.

1. Connect the output of the leveled sine wave generator (for example, Fluke 9500) to the oscilloscope channel 1 input as shown in the following illustration.





- 2. Push the front-panel **Default Setup** button.
- **3.** Select 50 Ω impedance as follows:
 - a. Set the calibrator to 50 Ω output impedance and to generate a sine wave.
 - **b.** Push the front-panel channel 1 button.
 - c. Set the **Termination** (input impedance) to 50 Ω .
- **4.** *Set the Acquisition mode to Sample as follows:*
 - **a.** Push the front-panel **Acquire** button.
 - **b.** Push the **Mode** lower-bezel button (if not already selected).
 - **c.** Push the **Sample** side bezel button.
- 5. Set the Vertical Scale to 1 mV per division.
- **6.** For vertical scales less than 500 mV/div, adjust the signal source to at least 8 vertical divisions at the selected vertical scale with a set frequency of 50 kHz. For example, at 5 mV/div, use a \geq 40 mV_{p-p} signal, at 2 mV/div, use a \geq 16 mV_{p-p} signal, and at 1 mV/div, use a \geq 8 mV_{p-p} signal. For vertical scales of 500 mV/div and 1 V/div adjust the signal source to 3 V_{p-p}. Use a sine wave for the signal source.
- 7. Set the Horizontal Scale to 10 μ s per division.

- **8.** Record the peak-to-peak measurement:
 - **a.** Push the front-panel Wave Inspector **Measure** button.
 - b. Select the Peak-to-Peak measurement.
 - **c.** Push the **OK Add Measurement** side-bezel button.
 - **d.** This will provide a mean V_{p-p} of the signal. Call this value V_{in-pp} .
 - e. Enter this value in the test record.
- 9. Set the Horizontal Scale to 4 ns per division.
- **10.** Adjust the signal source to the maximum bandwidth frequency for the bandwidth and model desired, as shown in the following worksheet.
- **11.** Record the peak-to-peak measurement as follows:
 - **a.** View the mean V_{p-p} of the signal. Call this value V_{bw-pp} .
 - **b.** Enter this value in the test record.

NOTE. For more information on the contents of this worksheet, refer to the bandwidth specifications. (See Table 1 on page 1.)

Table 17: Maximum bandwidth frequency worksheet

Model: MDO4104-3, MDO4104-6

Impedance	Vertical Scale	Maximum bandwidth
50 Ω	5 mV/div — 1 V/div	1 GHz
	2 mV/div — 4.98 mV/div	350 MHz
	1 mV/div — 1.99 mV/div	175 MHz

Table 17: Maximum bandwidth frequency worksheet (cont.)

Model: MDO4104-3, MDO4104-6

Impedance	Vertical Scale	Maximum bandwidth		
1 ΜΩ	5 mV/div — 1 V/div	500 MHz ¹		
	2 mV/div — 4.98 mV/div	350 MHz		
	1 mV/div — 1.99 mV/div	175 MHz		
Model: MDO4054-3, MD	OO4054-6			
50 Ω and 1 MΩ	5 mV/div — 1 V/div	500 MHz		
	2 mV/div — 4.98 mV/div	350 MHz		
	1 mV/div — 1.99 mV/div	175 MHz		
Model: MDO4034-3				
50 Ω and 1 MΩ	2 mV/div — 1 V/div	350 MHz		
	1 mV/div — 1.99 mV/div	175 MHz		
Model: MDO4014-3				
50 Ω and 1 MΩ	1 mV/div — 1 V/div	100 MHz		

¹ For MDO4104-3 and MDO4104-6 performance verification, use 500 MHz, rather than 1 GHz, on the 5 mV/div vertical scale.

12. Use the values of V_{bw-pp} and V_{in-pp} that you entered in the test record to calculate the *Gain* at bandwidth with the following equation:

$$Gain = V_{bw-pp} / V_{in-pp}$$

To pass the performance measurement test, Gain should be ≥ 0.707 . Enter *Gain* in the test record.

- **13.** Repeat steps 5 through 12 for all combinations of Vertical Scale and Horizontal Scale settings listed in the test record.
- **14.** Repeat the tests at $1 M\Omega$ impedance as follows:
 - **a.** Change the calibrator impedance to 1 M Ω .
 - **b.** Push the front-panel channel 1 button.
 - c. Set the **Termination** (input impedance) to 1 $M\Omega$.
 - **d.** Repeat steps 5 through 13.
- **15.** Repeat the procedure for all remaining channels as follows:
 - **a.** Push the front-panel button to deselect the channel that you have already tested.
 - **b.** Move the calibrator connection to the next channel input to be tested.
 - **c.** Starting from step 3, repeat the procedure for each input channel.

Check Random Noise, Sample Acquisition Mode

This test checks random noise. You do not need to connect any test equipment to the oscilloscope for this test.


- 1. Disconnect everything from the oscilloscope inputs.
- **2.** Push the front-panel **Default Setup** button.
- **3.** *Set Gating to Off as follows:*
 - **a.** Push the front-panel Wave Inspector **Measure** button.
 - **b.** Push the bottom-bezel **More** button to select **Gating**.
 - **c.** Push the side-bezel **Off (Full Record)** button.
- **4.** Select the RMS measurement as follows:
 - **a.** Push the bottom-bezel **Add Measurement** button.
 - **b.** Select the **RMS** measurement.
 - c. Push the side-bezel **OK Add Measurement** button.
- **5.** Reset statistics as follows:
 - **a.** Push the bottom-bezel **More** button to select **Statistics**.
 - **b.** Push the side-bezel **Reset Statistics** button.
- **6.** Read and make a note of the RMS Mean value. This is the Sampled Mean Value (SMV).
- 7. Set the Acquisition mode to Average as follows:
 - **a.** Push the front-panel **Acquire** button.
 - **b.** Push the bottom-bezel **Mode** button to display the Acquisition Mode menu (if it is not already selected).
 - **c.** Push the side-bezel **Average** button.
 - **d.** Make sure that the **number of averages** is set to **16**.
- **8.** Reset statistics as follows:
 - **a.** Push the front-panel Wave Inspector **Measure** button.
 - **b.** Push the bottom-bezel **More** button to select **Statistics** (if it is not already selected).
 - c. Push the side-bezel **Reset Statistics** button.
- **9.** Read and make a note of the RMS Mean value. This is the Averaged Mean Value (AMV).
- **10.** Calculate the RMS noise (RMS noise = SMV AMV), and enter the calculated RMS noise in the test record.

- **11.** *Set the Acquisition mode to Sample as follows:*
 - **a.** Push the front-panel **Acquire** button.
 - **b.** Push the **Mode** lower-bezel button (if it is not already selected).
 - **c.** Push the **Sample** side bezel button.
- **12.** Repeat the tests at 50 Ω as follows:
 - **a.** Push the front-panel channel 1 button.
 - **b.** Set the **Termination** (input impedance) to **50** Ω .
 - **c.** Push the front-panel Wave Inspector **Measure** button, and repeat steps 5 through 11.
- **13.** Repeat the tests at 250 MHz bandwidth as follows:
 - **a.** Push the front-panel channel 1 button.
 - **b.** Set the **Termination** (input impedance) to 1 $M\Omega$.
 - c. Push the bottom-bezel **Bandwidth** button.
 - d. Push the side-bezel 250 MHz button.
 - e. Push the front-panel Waveform Inspector Measure button.
 - **f.** Repeat steps 5 through 12.
- **14.** Repeat the tests at 20 MHz bandwidth as follows:
 - **a.** Push the front-panel channel 1 button.
 - **b.** Set the **Termination** (input impedance) to 1 $M\Omega$.
 - c. Push the bottom-bezel **Bandwidth** button.
 - d. Push the side-bezel 20 MHz button.
 - **e.** Push the front-panel Waveform Inspector **Measure** button.
 - **f.** Repeat steps 5 through 12.
- **15.** Repeat the procedure for all remaining channels as follows:
 - **a.** Push the front-panel button to deselect the channel that you have already tested.
 - **b.** Starting from step 3, repeat the procedure for each input channel.

Check Sample Rate and Delay Time Accuracy

This test checks the sample rate and delay time accuracy (time base).

1. Connect the output of a time mark generator to the oscilloscope channel 1 input using a 50 Ω cable, as shown in the following illustration.





- 2. Set the time mark generator period to 80 ms. Use a time mark waveform with a fast rising edge.
- **3.** Push the front-panel **Default Setup** button.
- **4.** Set the impedance to 50 Ω as follows:
 - **a.** Push the front-panel channel 1 button.
 - **b.** Set the Termination to 50 Ω .
- 5. If it is adjustable, set the time mark amplitude to approximately $1 V_{p-p}$.
- 6. Set the Vertical Scale to 500 mV per division.
- 7. Set the Horizontal Scale to 20 ms per division.
- **8.** Adjust the Vertical **Position** knob to center the time mark signal on the screen.
- 9. Adjust the Trigger Level as necessary for a triggered display.
- **10.** Adjust the Horizontal **Position** to move the trigger location to the center of the screen (50%).
- **11.** *Set the delay to 80 ms as follows:*
 - **a.** Push the front-panel **Acquire** button.
 - **b.** Push the lower-bezel **Delay** button to turn delay on (if it is not already on).
 - **c.** Turn the Horizontal **Position** knob clockwise to set the delay to exactly **80 ms**.


- 12. Set the Horizontal Scale to 400 ns/div.
- 13. Compare the rising edge of the marker with the center horizontal graticule line. The rising edge should be within ± 1 divisions of center graticule. Enter the deviation in the test record.

NOTE. One division of displacement from graticule center corresponds to a 5 ppm time base error.

Check Delta Time Measurement Accuracy

This test checks the Delta-time measurement accuracy (DTA) for a given instrument setting and input signal.

Connect a 50 Ω coaxial cable from the signal source to the oscilloscope channel 1, as shown in the following illustration.





- **2.** Push the oscilloscope front-panel **Default Setup** button.
- **3.** Select 50 Ω impedance as follows:
 - **a.** Set the sine wave generator output impedance to 50 Ω .
 - **b.** Push the channel 1 button to display the channel 1 menu.
 - c. Set the **Termination** (input impedance) to 50 Ω .
- **4.** *Set the trigger source to channel 1 as follows:*
 - **a.** Push the Trigger **Menu** button.
 - **b.** Push the **Source** lower-bezel button (if not already selected).
 - **c.** Select channel 1 (if not already selected).
- **5.** *Set the Mean & St Dev Samples to 100 as follows:*
 - **a.** Push the Wave Inspector **Measure** button.
 - **b.** Push the bottom-bezel **Add Measurement** button.
 - c. Select the Burst Width measurement.
 - **d.** Push the side-bezel **OK Add Measurement** button.
 - e. Push the bottom-bezel More button to select Statistics.
 - **f.** Set the **Mean & Std Dev Samples** to **100**, as shown in the side menu.

6. Set the signal source to 240 MHz and 40 mV as shown in the test record.


NOTE. To provide consistent results, set the signal source frequency such that the zero crossing does not occur at the beginning or end of the record.

- 7. Set the Horizontal Scale to 4 ns per division.
- 8. Set the Vertical Scale to 5 mV per division.
- **9.** Record the Std Dev value as follows:
 - a. Push the side-bezel **Reset Statistics** button.
 - **b.** Push the **Menu** button to remove the side-bezel menu.
 - **c.** Wait five or 10 seconds for the oscilloscope to acquire all of the samples.
 - **d.** Verify that the **Std Dev** is less than the upper limit shown in the test record.
 - **e.** Enter the reading in the test record.
- **10.** Repeat steps 6 through 9 for each setting combination shown in the test record.
- **11.** Repeat the procedure for all remaining channels as follows:
 - **a.** Push the front-panel button to deselect the channel that you have already tested.
 - **b.** Connect the signal source to the input for the next channel to be tested.
 - **c.** Repeat the procedure from step 3 until all channels have been tested.

Check Digital Threshold Accuracy

This test checks the threshold accuracy of the digital channels. This procedure applies to digital channels D0 through D15, and to channel threshold values of 0~V and +4~V.

- 1. Connect the P6616 digital probe to the oscilloscope, as shown in the following illustration:
 - **a.** Connect the DC voltage source to the digital channel D0.
 - **b.** If you are using the Fluke 9500 calibrator as the DC voltage source, connect the calibrator head to the digital channel D0, using the BNC-to-0.1 inch pin adapter listed in the Required Equipment table. (See Table 15 on page 28.)
 - **c.** Connect channel D0 to both the corresponding signal pin and to a ground pin on the adapter.





- **2.** Turn on the digital channels as follows:
 - a. Push the front-panel **D15-D0** button.
 - **b.** Push the **D15-D0 On/Off** lower-bezel button.
 - c. Push the Turn On D7 D0 and the Turn On D15 D8 side-bezel buttons to turn these channels On.
 - **d.** Make sure that the side-bezel **Display** selection is **On**.
 - **e.** The instrument will display the 16 digital channels.

- **3.** *Set the channel threshold to 0 V as follows:*
 - **a.** Push the **Thresholds** lower-bezel button (if not already selected).
 - **b.** Select channel **D0**.
 - c. Set the value to **0.00** V (0 V/div), using the coarse and fine settings of the knob as necessary to set the exact value.
- 4. Push the Menu button and then set the Horizontal Scale to $4\mu s$ per division.
- **5.** *Set the Trigger source as follows:*
 - **a.** Push the front-panel Trigger **Menu** button.
 - **b.** Push the **Source** lower-bezel button (if not already selected).
 - c. Select channel D0.
- 6. Set the DC voltage source (Vs) to -400 mV. Wait 3 seconds. Check the logic level of the channel D0 signal display. If it is at a static logic high, change the DC voltage source Vs to -500 mV.
- 7. Increment Vs by +10 mV. Wait 3 seconds and check the logic level of the channel D0 signal display. If it is a static logic high, record the Vs value as in the 0 V row of the test record.

If the signal level is a logic low or is alternating between high and low, repeat this step (increment Vs by 10 mV, wait 3 seconds, and check for a static logic high) until a value for V_s is found.

- **8.** Click the lower-bezel **Slope** button to change the slope to **Falling**.
- 9. Set the DC voltage source (Vs) to +400 mV. Wait 3 seconds. Check the logic level of the channel D0 signal display.

If it is at a static logic low, change the DC voltage source Vs to +500 mV.

10. Reduce Vs by -10 mV. Wait 3 seconds and check the logic level of the channel D0 signal display. If it is a static logic low, record the Vs value as V_{s+} in the 0 V row of the test record.

If the signal level is a logic high or is alternating between high and low, repeat this step (decrement Vs by 10 mV, wait 3 seconds, and check for a static logic low) until a value for V_{s+} is found.

11. Find the average using this formula: $V_{sAvg} = (V_{s-} + V_{s+})/2$. Record the average as the test result in the test record.

Compare the test result to the limits. If the result is between the limits, continue with the procedure to test the channel at the +4 V threshold value.

- **12.** *Set the channel threshold to* +4 *V as follows:*
 - a. Push the front-panel **D15-D0** button.
 - **b.** Push the **Thresholds** lower-bezel button.

- c. Select channel **D0**
- **d.** Push the **Fine** front-panel button to turn off the fine adjustment.
- e. Set the value near 4.00 V (4 V/div).
- **f.** Push the **Fine** button to turn the fine adjustment on again.
- **g.** Set the value to exactly **4.00** V (4 V/div).
- **13.** Set the DC voltage source (Vs) to +4.4 V. Wait 3 seconds. Check the logic level of the channel D0 signal display.
- **14.** Decrement Vs by -10 mV. Wait 3 seconds and check the logic level of the channel D0 signal display. If it is a static logic low, record the Vs value as V_{s+} in the 4 V row of the test record.

If the signal level is a logic high or is alternating between high and low, repeat this step (decrement Vs by 10 mV, wait 3 seconds, and check for a static logic low) until a value for V_{s+} is found.

- **15.** Push the front-panel **Trigger Menu** button.
- **16.** Click the lower-bezel **Slope** button to change the slope to **Rising**.
- 17. Set the DC voltage source (Vs) to +3.6 V. Wait 3 seconds. Check the logic level of the channel D0 signal display.

If the signal level is a static logic high, change the DC voltage source Vs to +3.5 V.

18. Increment Vs by +10 mV. Wait 3 seconds and check the logic level of the channel D0 signal display. If it is a static logic high, record the Vs value as V_s in the 4 V row of the test record.

If the signal level is a logic low or is alternating between high and low, repeat this step (increment Vs by 10 mV, wait 3 seconds, and check for a static logic high) until a value for V_s is found.

19. Find the average using this formula: $V_{sAvg} = (V_{s-} + V_{s+})/2$. Record the average as the test result in the test record.

Compare the test result to the limits. If the result is between the limits, the channel passes the test.

- **20.** Repeat the procedure for all remaining digital channels as follows:
 - **a.** Push the D15–D0 button.
 - **b.** Move the DC voltage source connection, including the ground lead, to the next digital channel to be tested.
 - **c.** Starting from step 3, repeat the procedure until all 16 digital channels have been tested.

Check Phase Noise


This step checks the phase noise measured offset from a 2 GHz CW signal. It checks at three offset frequencies: 10 kHz, 100 kHz, and 1 MHz.



WARNING. The generator is capable of providing dangerous voltages. Be sure to set the generator to off or 0 volts before connecting, disconnecting, and/or moving the test hookup during the performance of this procedure.

NOTE. Do not use an N connector with the Anritsu generator. Equipment damage will result if an N connector is used.

1. Connect the output of a signal generator, such as the Anritsu generator, to the oscilloscope RF Input, using a 50 Ω SMA coaxial cable (see the following figure).



- 2. Set the generator for a 2 GHz, 0 dBm signal.
- **3.** *Initial oscilloscope setup:*
 - **a.** Push the front-panel **Default Setup** button.
 - **b.** Turn Channel 1 off.
 - **c.** Push the front-panel RF button to turn on the RF channel and display the bottom-bezel RF menu.
 - d. Turn on the average trace as follows: Push the bottom-bezel Spectrum Traces button. Push the side-bezel Average button to set the Average Traces to On. Push the side-bezel Normal button to set Normal to Off.
 - e. Set the center frequency to 2 GHz as follows: Push the front-panel Freq/Span button. Push the side-bezel Center Frequency button. Set the center frequency to 2 GHz.
 - **f.** Set the span to 50.0 kHz as follows: Set the Span to 50.0 kHz.
 - **g.** Center the signal on the display. To do this:


Push the Markers front-panel button.

Push the **R To Center** side-bezel button.

- **h.** Set the resolution bandwidth (RBW) to 250 Hz as follows: Push the front-panel **BW** button. Push the side-bezel **RBW Mode** button to set the RBW mode to Manual. Set the resolution bandwidth to 250 Hz.
- i. Set the markers to delta as follows: Push the front-panel Markers button. Push the side-bezel Manual Markers button to set the manual markers to On. Push the side-bezel Readout button to select Delta.
- **j.** Set the reference level to 0 dbm as follows: Push the front-panel **Ampl** button. Push the side-bezel **Ref Level** button. Set the reference level to 0 dBm.

4. *Check at 10 kHz:*

- a. Push the front-panel Markers button.
- **b.** Set marker a to the signal peak.
- **c.** Set marker b to 10 kHz as shown in the following figure.



- **d.** Note the bottom value in the marker b readout (in dBc/Hz) and enter it in the test record.
- **5.** *Repeat the check at 100 kHz:*
 - a. Change the span to 500 kHz.
 - **b.** Change the resolution bandwidth (RBW) to 1 kHz.
 - **c.** Set marker a to the signal peak.

- **d.** Set marker b to 100 kHz.
- **e.** Note the bottom value in the marker b readout (in dBc/Hz) and enter it in the test record. Make sure that the instrument meets the specification given in the test record.
- **6.** Repeat the check at 1 MHz:
 - **a.** Change the span to 5 MHz.
 - **b.** Change the resolution bandwidth (RBW) to 50 kHz.
 - **c.** Set marker a to the signal peak.
 - **d.** Set marker b to 1 MHz.
 - **e.** Note the bottom value in the marker b readout (in dBc/Hz) and enter it in the test record. Make sure that the instrument meets the specification given in the test record.

Check Displayed Average Noise Level (DANL)

This test does not require an input signal.


The test measures the average internal noise level of the instrument, ignoring residual spurs.

It checks four ranges:

- 50 kHz to 5 MHz (all models)
- 5 MHz to 3 GHz (all models)
- **3** GHz to 4 GHz (MDO4104-6 and MDO4054-6 only)
- 4 GHz to 6 GHz (MDO4104-6 and MDO4054-6 only)

NOTE. If the specific measurement frequency results in measuring a residual spur that is visible above the noise level, the DANL specification applies not to the spur but to the noise level on either side of the spur. Please refer to the Spurious Response specifications. (See page 19.)

- 1. *Initial oscilloscope setup:*
 - a. Terminate the RF input in 50 Ω and make sure that no input signal is applied.
 - **b.** Push the front-panel **Default Setup** button.
 - c. Turn channel 1 off.
 - **d.** Push the front-panel **RF** button to turn on the RF channel and display the bottom-bezel RF menu.
 - **e.** *Turn on the average trace as follows:* Push the bottom-bezel **Spectrum Traces** button and set Normal to Off. Push the side-bezel **Average** button to set the Average Traces to On.
 - **f.** Turn on the average detection as follows: Push the bottom-bezel **Detection Method** button. Push the side-bezel button to set the detection method to **Manual**. Push the side-bezel **Average Trace** button. Set the detection method to Average.
 - **g.** Set the reference level to -25.0 dBm as follows: Push the front-panel **Ampl** button. Push the side-bezel **Ref Level** button. Set the Ref Level to -25.0 dBm.
 - **h.** Set the start and stop frequency as follows: Push the front-panel **Freq/Span** button. Push the side-bezel **Start** button. Set the start frequency to 50 kHz. Push the side-bezel **Stop** button. Set the stop frequency to 5 MHz.
- **2.** Check from 50 kHz to 5 MHz (all models):
 - a. Set Manual Marker (a) at the frequency with the highest noise level as follows: Push the Markers front-panel button. Push the Manual Markers side bezel button to turn on the markers. Turn Multipurpose knob a to move the marker to the frequency at the noise threshold (highest point of noise), ignoring any spurs. For this span, it should be at 50 kHz on the far left of the screen. See the following figure.



- **b.** Record the noise threshold value (in dBm/Hz) in the test record and compare it to the instrument specification.
- **3.** Check from 5 MHz to 3 GHz (all models):
 - **a.** Set the stop frequency to 3 GHz.
 - **b.** Set the start frequency to 5 MHz.
 - **c.** Set Manual Marker (a) at the frequency of the highest noise, ignoring any spurs.
 - **d.** *Set the center frequency as follows:* Push the **R To Center** side-bezel button.
 - **e.** Set the span to 10 MHz as follows: Push the side-bezel **Span** button. Set the Span to 10 MHz.
 - **f.** Record the highest noise value (in dBm/Hz) in the test record and compare it to the instrument specification.
- **4.** *Check from 3 GHz to 4 GHz (MDO4104-6 and MDO4054-6 only):*
 - **a.** Set the stop frequency to 4 GHz.
 - **b.** Set the start frequency to 3 GHz.
 - **c.** Set Manual Marker (a) at the frequency of the highest noise, ignoring any spurs.
 - **d.** *Set the center frequency as follows:* Push the **R To Center** side-bezel button.

- **e.** Set the span to 10 MHz as follows: Push the side-bezel **Span** button. Set the Span to 10 MHz.
- **f.** Record the highest noise value (in dBm/Hz) in the test record and compare it to the instrument specification.
- **5.** *Check from 4 GHz to 6 GHz (MDO4104-6 and MDO4054-6 only):*
 - **a.** Set the stop frequency to 6 GHz.
 - **b.** Set the start frequency to 4 GHz.
 - **c.** Set Manual Marker (a) at the frequency of the highest noise, ignoring any spurs.
 - **d.** Set the center frequency as follows: Push the **R To Center** side-bezel button.
 - **e.** Set the span to 10 MHz as follows: Push the side-bezel **Span** button. Set the Span to 10 MHz.
 - **f.** Record the highest noise value (in dBm/Hz) in the test record and compare it to the instrument specification.

Check Level Measurement Uncertainty

This test checks the level measurement uncertainty at three reference levels: +10 dBm, 0 dBm, and -15 dBm. This check uses the generator to step frequencies across four spans to verify that the instrument meets the specification.

For this check, you will need the following equipment, which is described in the Required Equipment table. (See Table 15 on page 28.)


- Generator, such as the Anritsu generator
- Power meter
- Power head
- Power splitter
- Adapters and cables as shown in the following figure.



WARNING. The generator is capable of providing dangerous voltages. Be sure to set the generator to off or 0 volts before connecting, disconnecting, and/or moving the test hookup during the performance of this procedure.


NOTE. Use an SMA connector with the Anritsu generator. Equipment damage will result if an N connector is used.

1. Connect the equipment as shown in the following figure.



- **2.** *Initial oscilloscope setup:*
 - a. Push the front-panel **Default Setup** button.
 - **b.** Turn Channel 1 off.
 - **c.** Push the front-panel **RF** button to turn on the RF channel.

- 3. Check at +10 dBm:
 - **a.** Set the reference level to 10 dBm as follows: Push the front-panel **Ampl** button. Push the side-bezel **Ref Level** button. Set the Ref Level to 10 dBm.
 - **b.** *Set the frequency range as follows:*
 - = Push the front-panel **Freq/Span** button.
 - Push the side-bezel Start button.
 - Set the start frequency to 0 Hz.
 - Push the side-bezel Stop button.
 - Set the stop frequency to 1 MHz.
 - **c.** Set the generator to provide a 50 kHz, +10 dBm signal.
 - **d.** At 50 kHz, determine the test result as follows:
 - Note the reading on the power meter and the readout for the Reference marker on the oscilloscope. See the following figure.



- Calculate the difference between the two readings. This is the test result
- e. In the test record, enter the greatest result determined at this frequency (50 kHz).

- **f.** Step the generator, in 100 kHz intervals, through frequencies from 100 kHz to 900 kHz. At each interval, determine the test result as follows:
 - Note the reading on the power meter and the readout for the Reference marker on the oscilloscope.
 - Calculate the difference between the two readings. This is the test result.
- **g.** In the test record, enter the greatest result determined within this frequency range (100 kHz 900 kHz).
- **h.** Change the frequency range as follows:
 - Change the stop frequency to 10 MHz.
 - Change the start frequency to 980 kHz.
- i. Set the generator to provide a 1 MHz, +10 dBm signal.
- **j.** Step the generator, in 1 MHz intervals, through frequencies from 1 MHz to 9 MHz. At each interval, determine the test result as follows:
 - Note the reading on the power meter and the readout for the Reference marker on the oscilloscope.
 - Calculate the difference between the two readings. This is the test result.
- **k.** In the test record, enter the greatest result determined within this frequency range (1 MHz to 9 MHz).
- **l.** Change the frequency range as follows:
 - Change the stop frequency to 100 MHz.
 - Change the start frequency to 9.8 MHz.
- **m.** Set the generator to provide a 10 MHz, +10 dBm signal.
- **n.** Step the generator, in 10 MHz intervals, through frequencies from 10 MHz to 90 MHz. At each interval, determine the test result as follows:
 - Note the reading on the power meter and the readout for the Reference marker on the oscilloscope.
 - Calculate the difference between the two readings. This is the test result.
- **o.** In the test record, enter the greatest result determined within this frequency range (10 MHz to 90 MHz).

For MDO4104-3, MDO4054-3, MDO4034-3, and MDO4014-3 Only (steps p through s)

- **p.** Change the frequency range as follows:
 - Change the stop frequency to 3.05 GHz.
 - Change the start frequency to 50 MHz.
- **q.** Set the generator to provide a 100 MHz, +10 dBm signal.
- r. Step the generator, in 100 MHz intervals, through frequencies from 100 MHz to 2.9 GHz. At each interval, determine the test result as follows:
 - Note the reading on the power meter and the readout for the Reference marker on the oscilloscope.
 - Calculate the difference between the two readings. This is the test result
- **s.** In the test record, enter the greatest result determined within this frequency range (100 MHz to 2.9 GHz).

For MDO4104-6 and MDO4054-6 Only (steps t through w)

- **t.** Change the frequency range as follows:
 - Change the stop frequency to 6.05 GHz.
 - Leave the start frequency at 50 MHz.
- **u.** Set the generator to provide a 100 MHz, +10 dBm signal.
- v. Step the generator, in 100 MHz intervals, through frequencies from 100 MHz to 5.8 GHz. At each interval, determine the test result as follows:
 - Note the reading on the power meter and the readout for the Reference marker on the oscilloscope.
 - Calculate the difference between the two readings. This is the test result.
- **w.** In the test record, enter the greatest result determined within this frequency range (100 MHz to 5.8 GHz).
- **4.** *Check at 0 dBm:*
 - **a.** Set the reference level to 0 dBm as follows: Push the front-panel **Ampl** button. Push the side-bezel **Ref Level** button. Set the Ref Level to 0 dBm.
 - **b.** *Set the frequency range as follows:*
 - = Push the front-panel **Freq/Span** button.
 - Push the side-bezel Start button.
 - Set the start frequency to 0 Hz.

- **–** Push the side-bezel **Stop** button.
- Set the stop frequency to 1 MHz.
- **c.** Set the generator to provide a 50 kHz, 0 dBm signal.
- **d.** At 50 kHz, determine the test result as follows:
 - Note the reading on the power meter and the readout for the Reference marker on the oscilloscope. See the following figure.
 - Calculate the difference between the two readings. This is the test result.
- e. In the test record, enter the greatest result determined at this frequency (50 kHz).
- **f.** Step the generator, in 100 kHz intervals, through frequencies from 100 kHz to 900 kHz. At each interval, determine the test result as follows:
 - Note the reading on the power meter and the readout for the Reference marker on the oscilloscope.
 - Calculate the difference between the two readings. This is the test result.
- g. In the test record, enter the greatest result determined within this frequency range (100 kHz 900 kHz).
- **h.** Change the frequency range as follows:
 - Change the stop frequency to 10 MHz.
 - Change the start frequency to 980 kHz.
- i. Set the generator to provide a 1 MHz, 0 dBm signal.
- **j.** Step the generator, in 1 MHz intervals, through frequencies from 1 MHz to 9 MHz. At each interval, determine the test result as follows:
 - Note the reading on the power meter and the readout for the Reference marker on the oscilloscope.
 - Calculate the difference between the two readings. This is the test result.
- **k.** In the test record, enter the greatest result determined within this frequency range (1 MHz to 9 MHz).
- **l.** Change the frequency range as follows:
 - Change the stop frequency to 100 MHz.
 - Change the start frequency to 9.8 MHz.
- **m.** Set the generator to provide a 10 MHz, 0 dBm signal.

- **n.** Step the generator, in 10 MHz intervals, through frequencies from 10 MHz to 90 MHz. At each interval, determine the test result as follows:
 - Note the reading on the power meter and the readout for the Reference marker on the oscilloscope.
 - Calculate the difference between the two readings. This is the test result.
- **o.** In the test record, enter the greatest result determined within this frequency range (10 MHz to 90 MHz).

For MDO4104-3, MDO4054-3, MDO4034-3, and MDO4014-3 Only (steps p through s)

- **p.** Change the frequency range as follows:
 - Change the stop frequency to 3.05 GHz.
 - Change the start frequency to 50 MHz.
- **q.** Set the generator to provide a 100 MHz, 0 dBm signal.
- **r.** Step the generator, in 100 MHz intervals, through frequencies from 100 MHz to 2.9 GHz. At each interval, determine the test result as follows:
 - Note the reading on the power meter and the readout for the Reference marker on the oscilloscope.
 - Calculate the difference between the two readings. This is the test result.
- **s.** In the test record, enter the greatest result determined within this frequency range (100 MHz to 2.9 GHz).

For MDO4104-6 and MDO4054-6 Only (steps t through w).

- **t.** Change the frequency range as follows:
 - Change the stop frequency to 6.05 GHz.
 - **=** Leave the start frequency at 50 MHz.
- **u.** Set the generator to provide a 100 MHz, 0 dBm signal.

- v. Step the generator, in 100 MHz intervals, through frequencies from 100 MHz to 5.8 GHz. At each interval, determine the test result as follows:
 - Note the reading on the power meter and the readout for the Reference marker on the oscilloscope.
 - Calculate the difference between the two readings. This is the test result.
- w. In the test record, enter the greatest result determined within this frequency range (100 MHz to 5.8 GHz).

5. Check at -15 dBm:

- **a.** Set the reference level to −15 dBm as follows: Push the front-panel **Ampl** button. Push the side-bezel **Ref Level** button. Set the Ref Level to −15 dBm.
- **b.** *Set the frequency range as follows:*
 - = Push the front-panel **Freq/Span** button.
 - **–** Push the side-bezel **Start** button.
 - = Set the start frequency to 0 Hz.
 - Push the side-bezel **Stop** button.
 - Set the stop frequency to 1 MHz.
- c. Set the generator to provide a 50 kHz, -15 dBm signal.
- **d.** At 50 kHz, determine the test result as follows:
 - Note the reading on the power meter and the readout for the Reference marker on the oscilloscope.
 - Calculate the difference between the two readings. This is the test result.
- **e.** In the test record, enter the greatest result determined at this frequency (50 kHz).
- **f.** Step the generator, in 100 kHz intervals, through frequencies from 100 kHz to 900 kHz. At each interval, determine the test result as follows:
 - Note the reading on the power meter and the readout for the Reference marker on the oscilloscope.
 - Calculate the difference between the two readings. This is the test result.
- g. In the test record, enter the greatest result determined within this frequency range (100 kHz 900 kHz).

- **h.** Change the frequency range as follows:
 - Change the stop frequency to 10 MHz.
 - Change the start frequency to 980 kHz.
- i. Set the generator to provide a 1 MHz, -15 dBm signal.
- **j.** Step the generator, in 1 MHz intervals, through frequencies from 1 MHz to 9 MHz. At each interval, determine the test result as follows:
 - Note the reading on the power meter and the readout for the Reference marker on the oscilloscope.
 - Calculate the difference between the two readings. This is the test result.
- **k.** In the test record, enter the greatest result determined within this frequency range (1 MHz to 9 MHz).
- **l.** Change the frequency range as follows:
 - Change the stop frequency to 100 MHz.
 - Change the start frequency to 9.8 MHz.
- **m.** Set the generator to provide a 10 MHz, -15 dBm signal.
- **n.** Step the generator, in 10 MHz intervals, through frequencies from 10 MHz to 90 MHz. At each interval, determine the test result as follows:
 - Note the reading on the power meter and the readout for the Reference marker on the oscilloscope.
 - Calculate the difference between the two readings. This is the test result
- **o.** In the test record, enter the greatest result determined within this frequency range (10 MHz to 90 MHz).
- p. For MDO4104-3, MDO4054-3, MDO4034-3 and MDO4014-3 Only. Change the frequency range as follows:
 - Change the stop frequency to 3.05 GHz.
 - Change the start frequency to 50 MHz.
- **q.** Set the generator to provide a 100 MHz, -15 dBm signal.
- r. Step the generator, in 100 MHz intervals, through frequencies from 100 MHz to 2.9 GHz. At each interval, determine the test result as follows:
 - Note the reading on the power meter and the readout for the Reference marker on the oscilloscope.
 - Calculate the difference between the two readings. This is the test result.

- **s.** In the test record, enter the greatest result determined within this frequency range (100 MHz to 2.9 GHz).
- t. For MDO4104-6 and MDO4054-6 Only. Change the frequency range as follows:
 - Change the stop frequency to 6.05 GHz.
 - Leave the start frequency at 50 MHz.
 - Set the generator to provide a 100 MHz, −15 dBm signal.
- **u.** Step the generator, in 100 MHz intervals, through frequencies from 100 MHz to 5.8 GHz. At each interval, determine the test result as follows:
 - Note the reading on the power meter and the readout for the Reference marker on the oscilloscope.
 - Calculate the difference between the two readings. This is the test result.
- v. In the test record, enter the greatest result determined within this frequency range (100 MHz to 5.8 GHz).

Check Third Order Intermodulation Distortion

This check verifies that the oscilloscope meets the specification for Third Order Intermodulation Distortion.




WARNING. The generators are capable of providing dangerous voltages. Be sure to set the generators to off or 0 volts before connecting, disconnecting, and/or moving the test hookup during the performance of this procedure.

Required equipment. You will need the following equipment for this check. All items are shown in the required equipment list. (See Table 15.)


- Two generators. Each generator must be capable of providing signals up to 6 GHz. You can use two of the same model generator, or two different generators, depending on what you have available. Example generators are the Anritsu and the Rohde & Schwarz SMT06.
- A power combiner (hybrid coupler), such as the Krytar 3005070.
- Three SMA cables. Use cables that will connect to your generators' outputs.

- 1. Connect the equipment as follows. (See the following figure.)
 - Connect an SMA cable from the RF input on the oscilloscope to the power combiner connector labeled "IN."
 - Connect an SMA cable from the RF output of a generator to a -3 dB input on the power combiner.
 - Connect an SMA cable from the RF output of the other generator to the other -3 dB input on the power combiner.



- **2.** Set generator 1 to provide a 2.735 GHz, -5 dBm signal at the RF input of the oscilloscope.
- **3.** Set generator 2 to provide a 2.755 GHz, -5 dBm signal at the RF input of the oscilloscope.
- **4.** *Initial oscilloscope setup:*
 - **a.** Push the front-panel **Default Setup** button.
 - **b.** Turn channel 1 off.
 - **c.** Push the front-panel **RF** button to turn on the RF channel and show the bottom-bezel menu.
 - **d.** Turn on the average trace as follows: Push the bottom-bezel **Spectrum Traces** button. Push the side-bezel **Average** button to set the Average Traces to On. Push the side-bezel **Normal** button to set Normal to Off.

- e. Set the center frequency as follows: Push the front-panel Freq/Span button. Push the side-bezel Center Frequency button. Set the center frequency to 2.745 GHz.
- **f.** Set the span as follows: Push the side-bezel **Span** button. Set the Span to 100 MHz.
- **g.** *Set the resolution bandwidth (RBW) as follows:* Push the front-panel **BW** button. Push the side-bezel **RBW Mode** button to select Manual. Push the side-bezel **RBW** button. Set the resolution bandwidth to 100 kHz.
- **h.** *Set the vertical scale as follows:* Push the **Amplitude** front-panel button. Push the side-bezel **Vertical** button. Set the scale to 10 dB/division.
- **i.** Set the Ref Level as follows: Push the side-bezel **Ref Level** button and set the Ref Level to 0 dBm.
- j. Push the front-panel Markers button.
- Push the side-bezel Manual Markers button to set the manual markers to On
- **l.** Push the side-bezel **Readout** button to select **Delta**.
- **5.** *Check at 2.745 GHz as follows (all models):*
 - **a.** Set marker a to the peak of the generator 1 signal (2.735 GHz).
 - **b.** Check for peaks at two frequencies:
 - = 20 MHz lower frequency than the generator 1 signal
 - = 20 MHz higher frequency than the generator 2 signal
 - **c.** Set marker b to the highest of these two peaks. See the following figure.



- **d.** Note the difference in amplitude between marker a and marker b. This is the middle value given in the marker b readout, and is displayed in dBc units. Enter this value in the test record and make sure that the instrument meets the specification given in the test record.
- **6.** *Check at 4.5 GHz as follows (MDO4104-6 and MDO4054-6 only):*
 - **a.** Set generator 1 to provide a 4.49 GHz, -5 dBm signal at the RF input of the oscilloscope.
 - **b.** Set generator 2 to provide a 4.510 GHz, -5 dBm signal at the RF input of the oscilloscope.
 - **a.** Set the Center Frequency to 4.5 GHz.
 - **b.** Set marker a to the peak of the generator 1 signal (4.49 GHz).
 - **c.** Check for peaks at two frequencies:
 - 20 MHz lower frequency than the generator 1 signal
 - **=** 20 MHz higher frequency than the generator 2 signal
 - **d.** Set marker b to the highest of these two peaks. See the figure.
 - e. Note the difference in amplitude between marker a and marker b. This is the middle value given in the marker b readout, and is displayed in dBc units. Enter this value in the test record and make sure that the instrument meets the specification given in the test record.

Check Residual Spurious Response

This check verifies that the oscilloscope meets the specification for residual spurious response. This check does not require an input signal.

- 1. Terminate the oscilloscope RF input in 50 Ω and make sure that no input signal is applied.
- 2. Set the resolution bandwidth (RBW) as follows: Push the front-panel BW button. Push the side-bezel RBW Mode button to select Manual. Push the side-bezel RBW button. Set the resolution bandwidth to 50 kHz.
- **3.** *Turn auto level on as follows:*
 - **a.** Push the front-panel **Ampl** button.
 - **b.** Push the side-bezel **Auto Level** button to turn the auto level feature on. The instrument will automatically set the reference level correctly.
- **4.** Check in the range of 50 kHz to 3 GHz as follows:
 - **a.** Push the front-panel **Freq/Span** button. Push the side-bezel **Start** button. Set the start frequency to 50 kHz. Push the side-bezel **Stop** button. Set the stop frequency to 3 GHz.
 - **b.** Observe any spurs that are greater than –78 dBm and note them in the test record.
- **5.** *Check in the range of 2.75 GHz to 4.5 GHz as follows:*
 - **a.** Change the oscilloscope start frequency to 2.75 GHz and the stop frequency to 4.5 GHz.
 - **b.** Observe any spurs that are greater than –78 dBm and note them in the test record.
- **6.** Check in the range of 3.5 GHz to 6.0 GHz as follows:
 - **a.** Change the oscilloscope start frequency to 3.5 GHz and the stop frequency to 6.0 GHz.
 - **b.** Observe any spurs that are greater than –78 dBm and note them in the test record


Check Crosstalk to RF Channel from Analog Channels

This check verifies that the oscilloscope meets the specification for crosstalk from an analog channel to the RF channel.




WARNING. The generator is capable of providing dangerous voltages. Be sure to set the generator to off or 0 volts before connecting, disconnecting, and/or moving the test hookup during the performance of this procedure.

- 1. Terminate the oscilloscope RF input in 50 Ω .
- 2. Connect the output of a signal generator to all four analog inputs on the oscilloscope. If you are using the Fluke 9500 oscilloscope calibrator as the signal generator, you can connect the active heads to all four analog inputs at once (Ch 1, Ch 2, Ch 3, and Ch 4). If your generator does not have the capacity to hook up all four channels at once, you can move the connector to each channel in turn.



- 3. Set the generator to provide a 50 kHz, 40 dB, 1 V_{p-p} sine wave signal.
- **4.** *Initial oscilloscope setup:*
 - **a.** Push the front-panel **Default Setup** button.
 - **b.** Select all analog channels (CH1, CH2, CH3, and CH4), and in the vertical menu, push **Termination** to select **50** Ω impedance.
 - **c.** Turn the analog channels off (so that the RF display will fill the screen for easy viewing).
 - **d.** Push the front-panel **RF** button to turn on the RF channel and display the bottom-bezel menu.
 - e. Turn on the average trace as follows: Push the bottom-bezel Spectrum Traces button. Push the side-bezel Average button to set the Average Traces to On. Push the side-bezel Normal button to set Normal to Off.
 - **f.** Set the span to 50 MHz as follows: Push the front-panel **Freq/Span** button. Push the side-bezel **Span** button. Set the Span to 50 MHz.

- 5. Set the generator to provide the signal to channel 1
- **6.** Measure the Channel 1 crosstalk at 100 MHz as follows:
 - **a.** Set the center frequency to 100 MHz as follows: Push the front-panel **Freq/Span** button. Push the side-bezel **Center Frequency** button. Set the center frequency to 100 MHz.
 - **b.** Use a marker to measure the amplitude of any of the Channel 1 signal that appears in the RF display. See the following figure.




- **c.** Record the amplitude of the Channel 1 signal in the test record. Make sure that it is within the specified limit.
- 7. Repeat step 6, changing the generator signal frequency and the oscilloscope Center Frequency settings as indicated in the test record. Check all listed frequencies and record the results in the test record.
- **8.** Repeat steps 5 through 7 until you have checked the crosstalk of all four analog channels.

Check Trigger Out

This test checks the Trigger Output.

1. Connect the Trigger Out signal from the rear of the instrument to the channel 1 input using a 50 Ω cable, as shown in the following illustration.



- 2. Push the front-panel **Default Setup** button.
- 3. Set the Vertical Scale to 1 V per division.
- **4.** Record the Low and High measurements at 1 M Ω as follows:
 - **a.** Push the front-panel Wave Inspector **Measure** button.
 - b. Push the Add Measurement lower-bezel button.
 - c. Select the Low measurement.
 - **d.** Push the **OK Add Measurement** side bezel button.
 - e. Enter the Low measurement reading in the test record.
 - **f.** Select the **High** measurement.
 - g. Push the OK Add Measurement side bezel button.
 - **h.** Enter the High measurement reading in the test record.
- **5.** Record the Low and High measurements at 50 Ω as follows:
 - **a.** Push the front-panel channel 1 button.
 - **b.** Set the **Termination** (input impedance) to **50** Ω .
 - **c.** Repeat step 4.

When the MDO4000 Has a TPA-N-PRE Attached to its RF Input

The following instructions apply to situations where the MDO4000 has a TPA-N-PRE preamplifier attached to its RF input

Perform the following functional check to ensure proper operation of the TPA-N-PRE/MDO4000 system.

For this check, you will need the following equipment, which is described in the Required Equipment table. (See Table 15 on page 28.)


- Generator, such as the Anritsu generator
- Power meter
- Power head
- Power splitter
- Adapters and cables as shown in the following figure.



WARNING. The generator is capable of providing dangerous voltages. Be sure to set the generator to off or 0 volts before connecting, disconnecting, and/or moving the test hookup during the performance of this procedure.

NOTE. Use an SMA connector with the Anritsu generator. Equipment damage will result if an N connector is used.


1. Connect the equipment as shown in the following figure.



- **2.** *Initial oscilloscope setup:*
 - a. Push the front-panel **Default Setup** button.
 - **b.** Turn Channel 1 off.
 - **c.** Push the front-panel **RF** button to turn on the RF channel.
 - **d.** Push the Menu button on the TPA-N-PRE preamplifier. On the MDO4000, for the Mode, select **Auto**.

3. Check at 1.7 GHz

- **a.** Set the reference level to -25 dBm as follows: Push the front-panel **Ampl** button. Push the side-bezel **Ref Level** button. Set the Ref Level to -25 dBm.
- **b.** *Set the frequency range as follows:*
 - = Push the front-panel **Freq/Span** button.
 - Push the side-bezel Center Frequency button.
 - Set the center frequency to 1.7 GHz.
 - **Push the side-bezel Span button.**
 - Set the span to 50 MHz.
- **c.** Set the generator to provide a 1.7 GHz, –30 dBm signal.
- **d.** Note the reading on the power meter and the readout for the Reference marker on the oscilloscope. See the following figure:



- e. The absolute difference between the two readings should be small (~ 2dB or less). If the MDO4000 reading is too low, tighten the preamp more firmly to the MDO4000 by hand and check the reading again.
- **f.** Check at the –40 dBm reference level.
 - Set the generator to provide a 1.7 GHz, –45 dBm signal...
 - Set the reference level to –40 dBm.
 - Compare the MDO4000 and the power meter readings as before. The absolute difference between the readings should be \sim 2dB or less. If

the MDO4000 reading is too low, tighten the preamp more firmly to the MDO4000 by hand and check the reading again.

4. Check at 5.5 GHz

- a. Set the reference level to -25 dBm as follows: Push the front-panel **Ampl** button. Push the side-bezel **Ref Level** button. Set the Ref Level to -25 dBm.
- **b.** *Set the frequency range as follows:*
 - Set the center frequency to 5.5 GHz.
 - = Set the span to 50 MHz.
- **c.** Set the generator to provide a 5.5 GHz, –30 dBm signal.
- **d.** Note the reading on the power meter and the readout for the Reference marker on the oscilloscope.
- e. The absolute difference between the two readings should be small (~ 2dB or less). If the MDO4000 reading is too low, tighten the preamp more firmly to the MDO4000 by hand and check the reading again.
- **f.** Check at the –40 dBm reference level.
 - Set the generator to provide a 5.5 GHz, -45 dBm signal...
 - Set the reference level to -40 dBm.
 - Compare the MDO4000 and the power meter readings as before. The absolute difference between the readings should be ~2dB or less. If the MDO4000 reading is too low, tighten the preamp more firmly to the MDO4000 by hand and check the reading again.

With TPA-N-PRE Attached: Check Display Average Noise Level (DANL)

This test does not require an input signal.


The test measures the average internal noise level of the instrument, ignoring residual spurs.

It checks four ranges:

- 50 kHz to 5 MHz (all models)
- 5 MHz to 3 GHz (all models)
- 3 GHz to 4 GHz (MDO4104-6 and MDO4054-6 only)
- 4 GHz to 6 GHz (MDO4104-6 and MDO4054-6 only)

NOTE. If the specific measurement frequency results in measuring a residual spur that is visible above the noise level, the DANL specification applies not to the spur but to the noise level on either side of the spur. Please refer to the Spurious Response specifications. (See page 19.)

- 1. *Initial oscilloscope setup:*
 - a. Terminate the TPA-N-PRE preamp input in 50 Ω and make sure that no input signal is applied.
 - **b.** Push the front-panel **Default Setup** button.
 - c. Turn channel 1 off.
 - **d.** Push the front-panel **RF** button to turn on the RF channel and display the bottom-bezel RF menu.
 - **e.** *Turn on the average trace as follows:* Push the bottom-bezel **Spectrum Traces** button and set Normal to Off. Push the side-bezel **Average** button to set the Average Trace to On.
 - **f.** Turn on average detection as follows: Push the bottom-bezel **Detection Method** button. Push the side-bezel button to set the detection method to **Manual**. Push the side-bezel **Average Trace** button. Set the detection method to Average.
 - **g.** Push the Menu button on the TPA-N-PRE preamplifier. On the MDO4000, for the Mode, select **Auto**.
 - **h.** Set the reference level to -40.0 dBm as follows: Push the front-panel **Ampl** button. Push the side-bezel **Ref Level** button. Set the Ref Level to -40.0 dBm.
 - i. Set the start and stop frequency as follows: Push the front-panel Freq/Span button. Push the side-bezel Start button. Set the start frequency to 50 kHz. Push the side-bezel Stop button. Set the stop frequency to 5 MHz.
- **2.** Check from 50 kHz to 5 MHz (all models):
 - a. Set Manual Marker (a) at the frequency with the highest noise level as follows: Push the **Markers** front-panel button. Push the **Manual Markers** side bezel button to turn on the markers. Turn Multipurpose knob a to move the marker to the frequency at the noise threshold (highest point of noise), ignoring any spurs. For this span, it should be at 50 kHz on the far left of the screen. See the following figure.



- **b.** Record the noise threshold value (in dBm/Hz) in the test record and compare it to the instrument specification.
- **3.** Check from 5 MHz to 3 GHz (all models):
 - **a.** Set the stop frequency to 3 GHz.
 - **b.** Set the start frequency to 5 MHz.
 - **c.** Set Manual Marker (a) at the frequency of the highest noise, ignoring any spurs.
 - **d.** Set the center frequency as follows: Push the **R To Center** side-bezel button.
 - **e.** Set the span to 10 MHz as follows: Push the side-bezel **Span** button. Set the Span to 10 MHz.
 - **f.** Record the highest noise value (in dBm/Hz) in the test record and compare it to the instrument specification.
- **4.** *Check from 3 GHz to 4 GHz (MDO4104-6 and MDO4054-6 only):*
 - **a.** Set the stop frequency to 4 GHz.
 - **b.** Set the start frequency to 3 GHz.
 - **c.** Set Manual Marker (a) at the frequency of the highest noise, ignoring any spurs.
 - **d.** Set the center frequency as follows: Push the **R To Center** side-bezel button.

- **e.** Set the span to 10 MHz as follows: Push the side-bezel **Span** button. Set the Span to 10 MHz.
- **f.** Record the highest noise value (in dBm/Hz) in the test record and compare it to the instrument specification.
- **5.** *Check from 4 GHz to 6 GHz (MDO4104-6 and MDO4054-6 only):*
 - **a.** Set the stop frequency to 6 GHz.
 - **b.** Set the start frequency to 4 GHz.
 - **c.** Set Manual Marker (a) at the frequency of the highest noise, ignoring any spurs.
 - **d.** Set the center frequency as follows: Push the **R To Center** side-bezel button.
 - **e.** Set the span to 10 MHz as follows: Push the side-bezel **Span** button. Set the Span to 10 MHz.
 - **f.** Record the highest noise value (in dBm/Hz) in the test record and compare it to the instrument specification.

This completes the performance verification procedure.