

Instructions



CSA8UP, TDS8UP, CSA8BUP, and TDS8BUP Option W2K

TDS8000 and CSA8000 Series Instruments MS Windows 2000 Upgrade Kit

071-1389-00

Warning

The servicing instructions are for use by qualified personnel only. To avoid personal injury, do not perform any servicing unless you are qualified to do so. Refer to all safety summaries prior to performing service.

www.tektronix.com



071138900

Copyright © Tektronix, Inc. All rights reserved. Licensed software products are owned by Tektronix or its suppliers and are protected by United States copyright laws and international treaty provisions.

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013, or subparagraphs (c)(1) and (2) of the Commercial Computer Software - Restricted Rights clause at FAR 52.227-19, as applicable.

Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supercedes that in all previously published material. Specifications and price change privileges reserved.

Tektronix, Inc., P.O. Box 500, Beaverton, OR 97077

TEKTRONIX and TEK are registered trademarks of Tektronix, Inc.

Kit Description and Installation

This kit includes software and instructions to install the MS Windows 2000 Operating System (Option W2K) onto your CSA8000, TDS8000, CSA8000B, and TDS8000B Series instruments. Once installed, the instrument will operate using MS Windows 2000.

NOTE. *Installation of the MS Windows 2000 operating System onto CSA8000 or TDS8000 instruments requires that option CPU to this kit be installed first.*

Tektronix installation service (Option IF) is available for this upgrade. If installation service is desired, please contact the service center in your region to schedule installation.

This document supports Tektronix modification: ECO1092

Products

CSA8000 Series All serial numbers (requires option CPU)
TDS8000 Series All serial numbers (requires option CPU)
CSA8000B Series B029999 and below
TDS8000B Series B029999 and below

Kit Parts List

Quantity	Part number	Description
1 ea	071-1389-xx	Kit Instructions: Windows 2000, CSA8000 and TDS8000 Series
1 ea	020-2527-xx	8000 Series Operating System Restore: 2 CDROMs, Document

Install

MS Windows 2000 Installation



To install the MS Windows 2000 Operating System, follow these steps:

CAUTION. *To avoid data loss, back up any important user files stored on the hard disk. This operating system restoration process reformats the hard disk, which erases any user-installed files and applications.*

1. Install the 8000 Series Instruments Windows 2000 Operating System.

Use the *8000 Series Instruments Windows 2000 Operating System Restore* CDROMs provided in this kit to install the operating system. Follow the instructions provided with the Windows 2000 operating system restore CDROMs.

2. Install the 8000 and 8000B Instruments Product Software.

Use the *8000 and 8000B Instruments Product Software* CDROM to install the product software. The product software version in this kit can only be installed on instruments running the MS Windows 2000 Operating System. Follow the instructions provided with the Product Software CDROM.

3. Install the Optional Applications Software on Windows-Based Oscilloscopes.

Use the *Optional Applications Software on Windows-Based Oscilloscopes* CDROM. Follow the instructions provided with the software CDROM.

■ End of document ■