


A 3-Step Pre-Startup guide to setting up a DPO7000SX Multi-Instrument Configuration

Multi-Instrument Star Configuration cabling guide

1 UltraSync™ bus cable bundle

UltraSync bus cable will connect any Multi-Instrument Configuration capable unit.

Cables must be connected to units prior to start-up, restart will be required if unit is turned on before connecting cables. Use electrostatic protection, including an antistatic wrist strap.



2 Suggested UltraSync™ bus cable connection order


Connecting UltraSync bus cable bundles on Master

Select the master instrument

At *Master* connect each UltraSync cable bundle set to ports designated

“To Extension”

1. Connect Clock Out (8 in-lbs torque)
2. Connect Trigger
3. Connect PCIe




Connecting UltraSync bus cable bundles on Extension

At *Extension* connect each UltraSync cable bundle set to ports designated

“To Master”

1. Connect Clock In (8 in-lbs torque)
2. Connect Trigger
3. Connect PCIe




3 Unit connection order


Connect each Extension to Master sequentially from left to right.

Connect extensions to master in star pattern, do not daisy chain units.


Master




Extension B



Extension C



Extension D



4 Power up

1. Power up instruments.
2. Wait for warm-up time to complete.
3. Run Signal Path Compensation (SPC).